# Pictorial index

Search by illustration

1	For safety and security	Make sure to read through them	
2	Instrument cluster	How to read the gauges and meters, the variety of warning lights and indicators, etc.	
3	Operation of each component	Opening and closing the doors and windows, adjustment before driving, etc.	
4	Driving	Operations and advice which are necessary for driving	
5	Audio system	Operating the audio system	
6	Interior features	Usage of the interior features, etc.	
7	Maintenance and care	Caring for your vehicle and maintenance procedures	
8	When trouble arises	What to do in case of malfunction or emergency	
9	Vehicle specifications	Vehicle specifications, customizable features, etc.	
10	For owners	Reporting safety defects for U.S. owners, and seat belt and SRS airbag instructions for Canadian owners	
		Search by symptom	
	Index	Search alphabetically	

_			
Rea	your information	3	Operation of each component
	orial index14	3-1.	Key information
1	For safety and security	3-2.	Keys92 Opening, closing and locking the doors
1-1.	For safe use  Before driving		Doors
	Theft deterrent system Engine immobilizer system	3-5.	mirrors
2.	Instrument cluster Warning lights and indicators		

4 Driving	4-4.	Refueling Opening the fuel tank cap178	
4-1. Before driving	4-5.	Using the driving	
Driving the vehicle		support systems  Cruise control181  Dynamic radar cruise control186	1
Trailer towing		LDA (Lane Departure Alert)199	2
Engine (ignition) switch (vehicles without a smart key system) 153	4-6.	Rear view monitor system	3
Engine (ignition) switch (vehicles with a smart key system)155			4
Automatic transmission 160  Turn signal lever 164  Parking brake 165			5
4-3. Operating the lights and wipers Headlight switch166			6
Automatic High Beam 170 Windshield wipers and washer 176			7
			8
			9
			10

# 

# 

## 

5-3. Using the Multimedia

	multimedia system	258
5-4.	Using the radio	
	Radio operation	259

5-5.	Playing an audio CD and MP3/WMA/AAC discs	
	CD player operation	261
5-6.	Using an external device	
	Listening to an iPod	267
	Listening to a USB	
	memory device	
	Using the AUX port	275
5-7.	Connecting Bluetooth®	
	Preparations to	
	use wireless	
	communication	276
	Registering a Bluetooth® audio player for	
	the first time	280
	Registering a Bluetooth® phone for the	
	first time	281
	Registering a Bluetooth® device	282
	Connecting a Bluetooth® device	284
	Displaying a Bluetooth®	204
	device details	286
	Detailed Bluetooth®	

system settings......287

<b>5-8</b> .	Bluetooth <sup>®</sup> Audio			
	Listening to Bluetooth®	6	Interior features	
	Audio288			
5-9.	Bluetooth <sup>®</sup> phone	6-1.	Using the air conditioning	
	Using a Bluetooth <sup>®</sup>		system and defogger	
	Phone289		Manual air conditioning	1
	Making a call291		system326	
	Receiving a call 294		Automatic air	_
	Speaking on the phone 295		conditioning system331	2
	Bluetooth <sup>®</sup> phone		Seat heaters337	
	message function 298	6-2.	Using the interior lights	2
	Using the steering wheel switches 301		Interior lights list339	3
	Bluetooth <sup>®</sup> phone		Interior lights340	
	settings302		Personal lights340	4
	Contact/Call History Settings303	6-3.	Using the storage features	+
	What to do if		List of storage features 342	5
	(Troubleshooting) 311		• Glove box343	5
5-10. Bluetooth®			• Console box343	
	Bluetooth <sup>®</sup> 315		• Coin holder344	6
5-11	.Using the voice		Bottle holders344	
•	command system		• Cup holders345	
	Voice command		Auxiliary boxes346	7
	system320		• Open tray350	
			Trunk features351	
		6-4	Other interior features	8
		<b>0</b> 4.	Other interior features352	
			• Sun visors352	
			Vanity mirrors352	9
			• Clock353	
			• Ashtray354	10
			• Power outlets355	
			• Armrest356	
			Assist grips356	
			• Coat hooks357	
			Garage door opener358	
			Safety Connect364	
			Compass369	

# 7 Maintenance and care

7-1.	Maintenance and care
	Cleaning and protecting
	the vehicle exterior 374
	Cleaning and protecting
	the vehicle interior 377
7-2.	Maintenance
	Maintenance
	requirements 380
	General maintenance 383
	Emission inspection and
	maintenance (I/M)
	programs387
7-3.	Do-it-yourself
	maintenance
	Do-it-yourself service
	precautions 388
	Hood390
	Positioning a floor jack 391
	Engine compartment 392
	Tires 403
	Tire inflation pressure 413
	Wheels 416
	Air conditioning filter 418
	Wireless remote control/
	electronic key battery 420
	Checking and replacing
	fuses 424
	Light bulbs 427

# 8 When trouble arises

8-1.	Essential information
	Emergency flashers438
	If your vehicle has to be
	stopped in an
	emergency439
<b>8-2</b> .	Steps to take in an
	emergency
	If your vehicle needs to
	be towed441
	If you think something is
	wrong444
	Fuel pump shut off
	system445
	If a warning light turns
	on or a warning buzzer
	sounds446
	If a warning message or
	indicator is displayed 454
	If you have a flat tire470
	If the engine will not
	start482
	If the shift lever cannot be
	shifted from P484
	If the electronic key does
	not operate properly485
	If the vehicle battery is
	discharged488
	If your vehicle
	overheats492
	If the vehicle becomes stuck 495
	SIUCK 490

# Vehicle specifications Index What to do if... 9-1. Specifications (Troubleshooting).....548 Maintenance data (fuel, oil level, etc.) .......... 498 Alphabetical index ......552 Fuel information ...... 507 Tire information ...... 510 2 9-2. Customization Customizable features ..... 523 9-3. Items to initialize Items to initialize.....532 10 For owners Reporting safety defects for U.S. owners......534 Seat belt instructions for Canadian owners (in French) ...... 535 SRS airbag instructions for Canadian owners (in French) ...... 537

For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL" for information regarding the Entune Premium Audio or Entune Audio Plus.

# For your information

#### Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Toyota policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of color and equipment.

#### Noise from under vehicle after turning off the engine

Approximately five hours after the engine is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and, it does not indicate a malfunction.

#### Accessories, spare parts and modification of your Toyota

A wide variety of non-genuine spare parts and accessories for Toyota vehicles are currently available in the market. You should know that Toyota does not warrant these products and is not responsible for their performance, repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Toyota vehicle.

This vehicle should not be modified with non-genuine Toyota products. Modification with non-genuine Toyota products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

#### Installation of a mobile two-way radio system

The installation of a mobile two-way radio system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Dynamic radar cruise control system (if equipped)
- Cruise control system (if equipped)
- Anti-lock brake system
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Toyota dealer for precautionary measures or special instructions regarding installation of a mobile two-way radio system.

#### Vehicle data recordings

Your Toyota is equipped with several sophisticated computers that will record certain data, such as:

- · Engine speed
- · Accelerator status
- · Brake status
- · Vehicle speed
- · Shift position

The recorded data varies according to the vehicle grade level and options with which it is equipped. These computers do not record conversations or sounds, and only record images outside of the vehicle in certain situations.

Data Transmission

Your vehicle may transmit the data recorded in these computers to Toyota without notification to you.

Data usage

Toyota may use the data recorded in these computers to diagnose malfunctions, conduct research and development, and improve quality.

Toyota will not disclose the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee if the vehicle is leased
- In response to an official request by the police, a court of law or a government agency
- · For use by Toyota in a law suit
- For research purposes where the data is not tied to a specific vehicle or vehicle owner
- Usage of data collected through Safety Connect (U.S.mainland only)
   If your Toyota has Safety Connect and if you have subscribed to those services, please refer to the Safety Connect Telematics Subscription Service Agreement for information on data collected and its usage.
- To learn more about the vehicle data collected, used and shared by Toyota, please visit <u>www.toyota.com/privacyvts/</u>.

#### Event data recorder

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- · How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened:
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- · How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

- Disclosure of the EDR data
  - Toyota will not disclose the data recorded in an EDR to a third party except when:
  - An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
  - In response to an official request by the police, a court of law or a government agency
  - · For use by Toyota in a law suit

However, if necessary, Toyota may:

- · Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

#### Scrapping of your Toyota

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Toyota dealer before you scrap your vehicle.

#### **Perchlorate Material**

Special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate. Your vehicle has components that may contain perchlorate. These components may include airbag, seat belt pretensioners, and wireless remote control batteries.



#### General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

#### General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

# **Reading this manual**

## **WARNING:**


Explains something that, if not obeyed, could cause death or serious injury to people.

# ∧ NOTICE:


Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.

123 ··· Indicates operating or working procedures. Follow the steps in numerical order.

- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- Indicates the outcome of an operation (e.g. a lid opens).




- Indicates the component or position being explained.
- Means "Do not", "Do not do this", or "Do not let this happen".



# How to search

- Searching by name
  - Alphabetical index ......P. 552




- Searching by installation position
  - Pictorial index.....P. 14



- Searching by symptom or sound
  - What to do if... (Troubleshooting)......P. 548




- Searching by title
  - Table of contents ......P. 2



## **Pictorial index**


#### Exterior



4	Windshield wipers P.	176
	Precautions against winter season $\dots\dots\dots$ P.	234
5	Fuel filler doorP.Refueling methodP.Fuel type/fuel tank capacityP.	178
<ul><li>6</li><li>7</li></ul>	Tires	504 234 403 470
	Opening         P.           Engine oil         P.           Coping with overheat         P.           Warning message         P.	500 492
_	bulbs of the exterior lights for driving acing method: P. 427, Watts: P. 506)	
8	$\label{eq:headlights/halogen} \mbox{Headlights/halogen daytime running lights}^{\star} \ \dots \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	166
9	Front turn signal/parking lights/ LED daytime running lights*	166
10	Front side marker lights P.	166
11)	Rear turn signal lightsP.	164
12	Stop/tail lights/rear side marker lights $\hdots$	166
13	Back-up lights Shifting the shift lever to R	160
14)	License plate lights P.	166

\*: If equipped

# ■Instrument panel





1 Engine switch
Starting the engine/changing the positions or modes P. 153, 155
Emergency stop of the engine P. 439
When the engine will not start
Warning messages P. 454
(2) Shift lever
Changing the shift position P. 160
Precautions against towing P. 441
When the shift lever does not move P. 484
③ Meters
Reading the meters/adjusting the meter light P. 77
Warning lights/indicator lights P. 72
When the warning lights come on P. 446
Multi-information display P. 81
Display
When a warning message or indicator is displayed P. 454

4	Parking brake			
	Applying/releasing			
	Warning light/warning buzzer/warning message			
(5)	Turn signal lever		F	P. 164
	Headlight switch			
	Headlights/parking lights/side marker lights/tail lights/daytime running lights		F	P. 166
<b>(6)</b>	Windshield wiper and washer switch		F	2. 176
	Usage			
	Adding washer fluid			
	Warning message			
(7)	Emergency flasher switch			
8	Trunk opener		F	P. 107
9	Fuel filler door opener		F	P. 178
10	Hood lock release lever		F	P. 390
11)	Tilt and telescopic steering lock release lever $\ldots$		F	P. 125
12	Air conditioning system	P	. 326	s, <mark>331</mark>
	Usage Rear window defogger			
(13)	Entune Audio*1, 2  Entune Premium Audio*1, 2		+	ر. 240 ا
	Clock		F	P. 353
(14)	Glove box		F	P. 343


<sup>\*1:</sup> If equipped
\*2: For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to
"NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

### Switches







<sup>\*1:</sup> If equipped
\*2: For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to
"NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".



\*: If equipped

### Interior





<sup>\*1:</sup> If equipped
\*2: For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to
"NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

# For safety and security


1-1.	For safe use	
	Before driving 24	
	For safety drive26	
	Seat belts 28	
	SRS airbags34	
	Front passenger occupant classification system 47	
	Safety information for children 53	
	Child restraint systems 54	
	Installing child restraints 58	
	Exhaust gas precautions 66	
1-2.	Theft deterrent system	
	Engine immobilizer	
	system 67	
	Alarm69	

# **Before driving**


### Floor mat

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

1 Insert the retaining hooks (clips) into the floor mat eyelets.



- 2 Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.
  - \*: Always align the  $\triangle$  marks.



The shape of the retaining hooks (clips) may differ from that shown in the illustration.

### MARNING

Observe the following precautions.


Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle. This could lead to an accident, resulting in death or serious injury.

#### When installing the driver's floor mat

- On not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) pro-
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.

#### Before driving

- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the engine stopped and the shift lever in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.



## For safety drive

For safe driving, adjust the seat and mirror to an appropriate position before driving.

### **Correct driving posture**

- Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P. 119)
- ② Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P. 119)



- ③ Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (→P. 123)
- (4) Wear the seat belt correctly.  $(\rightarrow P. 28)$

#### Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.  $(\rightarrow P. 28)$ 

Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.  $(\rightarrow P. 54)$ 

### Adjusting the mirrors

Make sure that you can see backward clearly by adjusting the inside and outside rear view mirrors properly. (→P. 127, 129)

## **⚠** WARNING

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not adjust the position of the driver's seat while driving. Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback. A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- Do not place anything under the front seats. Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.
- Always observe the legal speed limit when driving on public roads.
- When driving over long distances, take regular breaks before you start to feel tired.


Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

# **Seat belts**

Make sure that all occupants are wearing their seat belts before driving the vehicle.


#### Correct use of the seat belts

- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.



## Fastening and releasing the seat belt

- 1 To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- ② To release the seat belt, press the release button.



## Adjusting the seat belt shoulder anchor height (front seats)

- 1 Push the seat belt shoulder anchor down while pressing the release button.
- 2 Push the seat belt shoulder anchor up.


Move the height adjuster up and down as needed until you hear a click.



## Seat belt pretensioners (front seats)

The pretensioners help the seat belts to quickly restrain the occupants by retracting the seat belts when the vehicle is subjected to certain types of severe frontal or side collision or a vehicle rollover.

The pretensioners do not activate in the event of a minor frontal impact, a minor side impact or a rear impact.



#### **■** Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

#### ■ Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold the child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more.  $(\rightarrow P. 58)$ 

#### ■ Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.


- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P. 54)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions regarding seat belt usage. (→P. 28)

#### ■ Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.


#### ■ Seat belt extender

If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Toyota dealer free of charge.



#### ■ Rear seat belt

Use the seat belt after passing it through the guide if the seat belt comes free from the guide.



#### WARNING

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failure to do so may cause death or serious injury.

#### ■Wearing a seat belt


- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Toyota recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

#### Pregnant women

Obtain medical advice and wear the seat belt in the proper way.  $(\rightarrow P. 28)$ 

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.



#### People suffering illness

Obtain medical advice and wear the seat belt in the proper way. (→P. 28)

#### WARNING

#### When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

#### Seat belt pretensioners (front seats)

- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.
- If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Toyota dealer.

#### Adjustable shoulder anchor (front seats)

Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident. ( $\rightarrow$ P. 29)

#### Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- Ensure that the belt and plate are locked and the belt is not twisted. If the seat belt does not function correctly, immediately contact your Toyota
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Toyota dealer. Inappropriate handling may lead to incorrect operation.
- Always make sure the shoulder belt passes through the guide when using the seat belt. Failure to properly position the belt may reduce the amount of protection in an accident and could lead to death or serious injury in a collision or sudden stop.
- Always make sure that the seat belt is not twisted, does not get caught in the guide or the seatback and is arranged in the proper position.

## **MARNING**

#### Using a seat belt extender

- Do not wear the seat belt extender if you can fasten the seat belt without the extender.
- Do not use the seat belt extender when installing a child restraint system because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.




#### When using a seat belt extender

When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt.

This helps prevent damage to the vehicle interior and the extender itself.

# **SRS** airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.




## SRS front airbags

- ① SRS driver airbag/front passenger airbag
  Can help protect the head and chest of the driver and front passenger from impact with interior components
- ② SRS knee airbags
  Can help provide driver and front passenger protection

## SRS side and curtain shield airbags

- ③ SRS front side airbags
  Can help protect the torso of the front seat occupants
- 4 SRS rear side airbags
  Can help protect the torso of occupants in the rear outer seats
- (5) SRS curtain shield airbags
  - Can help protect primarily the head of occupants in the outer seats
  - Can help prevent the occupants from being thrown from the vehicle in the event of vehicle rollover

## SRS airbag system components



- (1) Front impact sensors
- (2) Front passenger occupant classification system (ECU and sensors)
- (3) Knee airbags
- (4) Side impact sensors (front doors)
- (5) Side impact sensors (front)
- (6) Front passenger airbag
- (7) Front side airbags
- (8) Curtain shield airbags
- (9) Rear side airbags

- (1) "AIR BAG ON" and "AIR BAG OFF" indicator lights
- (11) SRS warning light
- (12) Front passenger's seat belt buckle switch
- (13) Airbag sensor assembly
- (14) Side impact sensors (rear)
- 15) Driver airbag
- (16) Driver's seat belt buckle switch
- Seat belt pretensioners and force limiters

Your vehicle is equipped with ADVANCED AIRBAGS designed based on the US motor vehicle safety standards (FMVSS208). The airbag sensor assembly (ECU) controls airbag deployment based on information obtained from the sensors etc. shown in the system components diagram above. This information includes crash severity and occupant information. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

### WARNING

### SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

• The driver and all passengers in the vehicle must wear their seat belts properly.

The SRS airbags are supplemental devices to be used with the seat belts.

• The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration (NHTSA) advises:

Since the risk zone for the driver's airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 10 in. (250 mm) away now, you can change your driving position in several ways:

- · Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, nonslippery cushion, or raise the seat if your vehicle has that feature.
- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended by NHTSA above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

### SRS airbag precautions

If the seat belt extender has been connected to the front seat belt buckles but the seat belt extender has not also been fastened to the latch plate of the seat belt, the SRS front airbags will judge that the driver and front passenger are wearing the seat belt even though the seat belt has not been connected. In this case, the SRS front airbags may not activate correctly in a collision, resulting in death or serious injury in the event of a collision. Be sure to wear the seat belt with the seat belt extender.




- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (→P. 54)

### SRS airbag precautions

Do not sit on the edge of the seat or lean against the dashboard.



- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not allow the front seat occupants to hold items on their knees.



Do not lean against the door, the roof side rail or the front, side and rear pillars.




Do not allow anyone to kneel on the passenger seat toward the door or put their head or hands outside the vehicle.



### SRS airbag precautions

- Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel. These items can become projectiles when the SRS driver, front passenger and knee airbags deploy.
- Do not attach anything to areas such as a door, windshield, windows, front or rear pillar, roof side rail and assist grip.





• Vehicles without a smart key system: Do not attach any heavy, sharp or hard objects such as keys and accessories to the key. The objects may restrict the SRS driver's knee airbag inflation or be thrust into the driver's seat area by the force of the deploying airbag, thus causing a danger.



 Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbags deploy.

### WARNING

### SRS airbag precautions

- If a vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the airbags. Such accessories may prevent the side airbags from activating correctly, disable the system or cause the side airbags to inflate accidentally, resulting in death or serious injury.
- Do not strike or apply significant levels of force to the area of the SRS airbag components.
  - Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillars garnishes, are damaged or cracked, have them replaced by your Toyota dealer.
- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the SRS front airbags for the front passenger may not deploy in the event of a collision.

### Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Toyota dealer. The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rails
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment
- Installation of a grille guard (bull bars, kangaroo bar, etc.), snow plows, winches, or roof luggage carrier
- Modifications to the vehicle's suspension system
- Installation of electronic devices such as mobile two-way radios and CD players
- Modifications to your vehicle for a person with a physical disability

### ■ If the SRS airbags deploy (inflate)

- Slight abrasions, burns, bruising etc., may be sustained from SRS airbags, due to the extremely high speed deployment (inflation) by hot gases.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, parts of the front and rear pillars, and roof side rails, may be hot for several minutes. The airbag itself may also be hot.
- The windshield may crack.
- For Safety Connect subscribers, if the SRS airbags deploy or in the event of a severe rear-end collision, the system is designed to send an emergency call to the response center, notifying them of the vehicle's location (without needing to push the "SOS" button) and an agent will attempt to speak with the occupants to ascertain the level of emergency and assistance required. If the occupants are unable to communicate, the agent automatically treats the call as an emergency and helps to dispatch the necessary emergency services. (→P. 364)

### ■ SRS airbag deployment conditions (SRS front airbags)

The SRS front airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 12 -18 mph [20 - 30 km/h] frontal collision with a fixed wall that does not move or deform).

However, this threshold velocity will be considerably higher in the following situations:

- If the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact
- If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck
- Depending on the type of collision, it is possible that only the seat belt pretensioners will activate.
- The SRS front airbags for the front passenger will not activate if there is no passenger sitting in the front passenger seat. However, the SRS front airbags for the front passenger may deploy if luggage is put in the seat, even if the seat is unoccupied.


### ■ SRS airbag deployment conditions (SRS side and curtain shield airbags)

- The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 3300 lb. [1500 kg] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 12 18 mph [20 30 km/h]).
- The SRS curtain shield airbags will deploy in the event of vehicle rollover.
- The SRS side and curtain shield airbags will deploy in the event of a severe frontal collision.

# ■ Conditions under which the SRS airbags may deploy (inflate), other than a collision


The SRS front airbags and SRS side and curtain shield airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.

- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or falling



The SRS curtain shield airbags may also deploy under the situations shown in the illustration.


- The angle of vehicle tip-up is marginal.
- The vehicle skids and hits a curb stone.



# ■Types of collisions that may not deploy the SRS airbags (SRS front airbags)

The SRS front airbags do not generally inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.


- Collision from the side
- Collision from the rear
- Vehicle rollover



# ■Types of collisions that may not deploy the SRS airbags (SRS side and curtain shield airbags)


The SRS side and curtain shield airbags may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.

- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle




The SRS side airbags do not generally inflate if the vehicle is involved in a rear collision, if it rolls over, or if it is involved in a low-speed side or low-speed frontal collision.

- Collision from the rear
- Vehicle rollover



The SRS curtain shield airbags do not generally inflate if the vehicle is involved in a rear collision, if it pitches end over end, or if it is involved in a low-speed side or low-speed frontal collision.


- Collision from the rear
- Pitching end over end




### ■When to contact your Toyota dealer

In the following cases, the vehicle will require inspection and/or repair. Contact your Toyota dealer as soon as possible.


- Any of the SRS airbags have been inflated.
- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS front airbags to inflate.




A portion of a door or its surrounding area is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side and curtain shield airbags to inflate.




• The pad section of the steering wheel, dashboard near the front passenger airbag or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.



■The surface of the seats with the side airbag is scratched, cracked, or otherwise damaged.




The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked, or otherwise damaged.



# Front passenger occupant classification system

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the devices for the front passenger.



- (1) SRS warning light
- (2) Seat belt reminder light
- (3) "AIR BAG OFF" indicator light
- (4) "AIR BAG ON" indicator light

# Condition and operation in the front passenger occupant classification system

# ■ Adult\*1

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indi- cator lights	"AIR BAG ON"
	SRS warning light	Off
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>
Devices	Front passenger airbag	
	Side airbag on the front passenger seat	
	Curtain shield airbag in the front passenger side	Activated
	Front passenger knee airbag	
	Front passenger's seat belt pretensioner	

## ■ Child\*4

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF" or "AIR BAG ON"*4	
	SRS warning light	Off	
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>	
Devices	Front passenger airbag	Deactivated or activated*4	
	Side airbag on the front passenger seat	Activated	
	Curtain shield airbag in the front passenger side	Activated	
	Front passenger knee airbag	Deactivated or activated*4	
	Front passenger's seat belt pretensioner	Activated	

# ■ Child restraint system with infant\*5

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"* <sup>6</sup>
	SRS warning light	Off
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seat	- Activated
	Curtain shield airbag in the front passenger side	
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Activated

# **■** Unoccupied

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"
	SRS warning light	Off
	Seat belt reminder light	
	Front passenger airbag	Deactivated
Devices	Side airbag on the front passenger seat	- Activated
	Curtain shield airbag in the front passenger side	
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Activated

### ■ There is a malfunction in the system

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"
	SRS warning light	On
	Seat belt reminder light	
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seats	- Activated
	Curtain shield airbag in the front passenger side	
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Activated

<sup>\*1:</sup> The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may not recognize him/her as an adult depending on his/her physique and posture.

<sup>\*2:</sup> In the event the front passenger is wearing a seat belt.

<sup>\*3:</sup> In the event the front passenger does not wear a seat belt.

<sup>\*4:</sup> For some children, child in seat, child in booster seat or child in convertible seat, the system may not recognize him/her as a child. Factors which may affect this can be the physique or posture.

<sup>\*5:</sup> Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P. 54)

<sup>\*6:</sup> In case the indicator light is not illuminated, consult this manual on how to install the child restraint system properly. (→P. 58)

### WARNING

### Front passenger occupant classification system precautions

Observe the following precautions regarding the front passenger occupant classification system.

Failure to do so may cause death or serious injury.

- Wear the seat belt properly.
- Make sure the front passenger's seat belt plate has not been left inserted into the buckle before someone sits in the front passenger seat.
- Make sure the "AIR BAG OFF" indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the "AIR BAG OFF" indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, and reconnect the seat belt. Reconnect the seat belt extender after making sure the "AIR BAG ON" indicator light is illuminated. If you use the seat belt extender while the "AIR BAG OFF" indicator light is illuminated, the SRS airbags for the front passenger may not activate correctly, which could cause death or serious injury in the event of a collision.
- Do not apply a heavy load to the front passenger seat or equipment (e.g. seatback pocket).
- Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- On not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- Do not put objects under the front passenger seat.

### **⚠** WARNING

### Front passenger occupant classification system precautions

- Do not recline the front passenger seatback so far that it touches a rear seat. This may cause the "AIR BAG OFF" indicator light to be illuminated, which indicates that the SRS airbags for the front passenger will not activate in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.
- If an adult sits in the front passenger seat, the "AIR BAG ON" indicator light is illuminated. If the "AIR BAG OFF" indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the "AIR BAG OFF" indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install a forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. (→P. 58)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the front passenger occupant classification system. In this case, contact your Toyota dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seatbacks.
- Do not use a seat accessory, such as a cushion and seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.

# **Safety information for children**

Observe the following precautions when children are in the vehicle.

Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the shift lever, wiper switch etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally.
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, trunk, seats etc.



Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

# **Child restraint systems**

A child restraint system for a small child or baby must itself be properly restrained on the seat with the LATCH anchors or the lap portion of the lap/shoulder belt.

The laws of all 50 states of the U.S.A. and Canada now require the use of child restraint systems.

### Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one on the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual.  $(\rightarrow P. 58)$ 

## Types of child restraints

Child restraint systems are classified into the following 3 types according to the age and size of the child:

- vertible seat
- ▶ Rear facing Infant seat/con- ▶ Forward facing Convertible seat





### ▶ Booster seat



## ■ Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If the child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. (→P. 28)

### WARNING

### Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Toyota strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Never install a rear-facing child restraint system on the front passenger seat even if the "AIR BAG OFF" indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.
- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat. Adjust the seatback as upright as possible and always move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.
- Do not use the seat belt extender when installing a child restraint system on the front or rear passenger seat. If installing a child restraint system with the seat belt extender connected to the seat belt, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or accident.
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front and rear pillars or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or accident.



### When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

### When the child restraint system is not in use

- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the trunk. This will prevent it from injuring passengers in the event of a sudden stop, sudden swerve or accident.

# **Installing child restraints**

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the seats using the LATCH anchors or a seat belt. Attach the top tether strap when installing a child restraint.

The lap/shoulder belt can be used if your child restraint system is not compatible with the LATCH (Lower Anchors and Tethers for Children) system.

Child restraint LATCH anchors  $(\rightarrow P. 59)$ 

LATCH anchors are provided for the outer rear seats. (Buttons displaying the location of the anchors are attached to the seats.)




Seat belts equipped with a child restraint locking mechanism (ALR/ELR belts except driver's seat belt) (→P. 30)



Anchor brackets (for top tether strap) ( $\rightarrow$ P. 63)

An anchor bracket is provided for each rear seat.




### Installation with LATCH system

- 1 Widen the gap between the seat cushion and seatback slightly.
- ▶ Type A
- 2 Latch the hooks of the lower straps onto the LATCH anchors. If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:


The symbol on a child restraint system indicates the presence of a lower connector system.



- ▶ Type B
- 2 Latch the buckles onto the LATCH anchors. If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:


The symbol on a child restraint system indicates the presence of a lower connector system.




# Installing child restraints using a seat belt (child restraint lock function belt)

### ■ Rear-facing — Infant seat/convertible seat

1 Place the child restraint system on the rear seat facing the rear of the vehicle.



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.




3 Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.




While pushing the child restraint system down into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.




### ■ Forward-facing — Convertible seat


1 Place the child restraint system on the seat facing the front of the vehicle.



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.




3 Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.



4 While pushing the child restraint system into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.



5 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor. (→P. 63)

### ■ Booster seat

1 Place the child restraint system on the seat facing the front of the vehicle.




2 Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.



Check that the shoulder belt is correctly positioned over the child's shoulder and that the lap belt is as low as possible.  $(\rightarrow P. 28)$ 


### Removing a child restraint installed with a seat belt

Push the buckle release button and fully retract the seat belt.




### Child restraint systems with a top tether strap

1 Secure the child restraint system using the seat belt or LATCH anchors.



2 Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top tether strap.

Make sure the top tether strap is securely latched.



### ■ Laws and regulations pertaining to anchorages

The LATCH system conforms to FMVSS225 or CMVSS210.2. Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to SAE J1819.

### WARNING

### When installing a booster seat


To prevent the belt from going into ALR lock mode, do not fully extend the shoulder belt. ALR mode causes the belt to tighten only. This could cause injury or discomfort to the child. ( $\rightarrow$ P. 30)

### When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving or an accident.

- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand
- Adjust the front passenger seat so that it does not interfere with the child restraint system.
- Only put a forward-facing child restraint system on the front seat when unavoidable. When installing a forward-facing child restraint system on the front passenger seat, move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated. Failure to do so may result in death or serious injury if the airbags deploy (inflate).





### WARNING

### When installing a child restraint system

- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.
- When securing some types of child restraint systems in rear seats, it may not be possible to properly use the seat belts in positions next to the child restraint without interfering with it or affecting seat belt effectiveness. Be sure your seat belt fits snugly across your shoulder and low on your hips. If it does not, or if it interferes with the child restraint, move to a different position. Failure to do so may result in death or serious injury.

### Do not use a seat belt extender

If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of a sudden braking, sudden swerving or an accident.

### To correctly attach a child restraint system to the anchors

When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of a sudden braking, sudden swerve or an accident.

## **Exhaust gas precautions**

Harmful substance to the human body is included in exhaust gases if inhaled.

### WARNING

Exhaust gases include harmful carbon monoxide (CO), which is colorless and odorless. Observe the following precautions.

Failure to do so may cause exhaust gases enter the vehicle and may lead to an accident caused by light-headedness, or may lead to death or a serious health hazard.

### Important points while driving

- Keep the trunk lid closed.
- If you smell exhaust gases in the vehicle even when the trunk lid is closed, open the windows and have the vehicle inspected at your Toyota dealer as soon as possible.

### When parking

- If the vehicle is in a poorly ventilated area or a closed area, such as a garage, stop the engine.
- Do not leave the vehicle with the engine on for a long time. If such a situation cannot be avoided, park the vehicle in an open space and ensure that exhaust fumes do not enter the vehicle interior.
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle.

### Exhaust pipe

The exhaust system needs to be checked periodically. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Toyota dealer.

# **Engine immobilizer system**

The vehicle's keys have built-in transponder chips that prevent the engine from starting if a key has not been previously registered in the vehicle's on-board computer.


Never leave the keys inside the vehicle when you leave the vehicle.

This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.

Vehicles without a smart key system:

The indicator light flashes after the key has been removed from the engine switch to indicate that the system is operating.

The indicator light stops flashing after the registered key has been inserted into the engine switch to indicate that the system has been canceled.



Vehicles with a smart key system:

The indicator light flashes after the engine switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the engine switch has been turned to ACCESSORY or IGNITION ON mode to indicate that the system has been canceled.

### ■ System maintenance

The vehicle has a maintenance-free type engine immobilizer system.

### ■ Conditions that may cause the system to malfunction

- If the grip portion of the key is in contact with a metallic object
- If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle

### ■ Certifications for the engine immobilizer system

▶ U.S.A.

Vehicles without a smart key system

FCC ID: WRKRI-44BTY

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Vehicles with a smart key system

FCC ID: NI4TMIMB-3

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### ▶ Canada

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### ■ Certifications for the immobilizer system

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



NOTICE

### To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

# Alarm<sup>°</sup>

### The alarm

The alarm uses light and sound to give an alert when an intrusion is detected.

The alarm is triggered in the following situations when the alarm is set:

- A locked door or trunk is unlocked or opened in any way other than using the entry function, wireless remote control or mechanical key. (The doors will lock again automatically.)
- The hood is opened.
- Some models: The window is tapped or broken.

### Setting the alarm system

Close the doors, trunk and hood, and lock all the doors. The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.



### Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarm:

- Unlock the doors or open the trunk.
- Vehicles without a smart key system:
   Turn the engine switch to the "ACC" or "ON" position, or start the engine. (The alarm will be deactivated or stopped after a few seconds.)
- Vehicles with a smart key system:

Turn the engine switch to ACCESSORY or IGNITION ON mode, or start the engine. (The alarm will be deactivated or stopped after a few seconds.)

\*: If equipped

### ■ System maintenance

The vehicle has a maintenance-free type alarm system.

### ■ Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following:

- Nobody is in the vehicle.
- The windows and moon roof are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

### ■ Triggering of the alarm

The alarm may be triggered in the following situations: (Stopping the alarm deactivates the alarm system.)

A person inside the vehicle opens a door, the trunk or hood.



• The battery is recharged or replaced when the vehicle is locked. (→P. 490)



### ■ Alarm-operated door lock

In the following cases, depending on the situation, the door may automatically lock to prevent improper entry into the vehicle:

- When a person remaining in the vehicle unlocks the door and the alarm is activated.
- While the alarm is activated, a person remaining in the vehicle unlocks the door.
- When recharging or replacing the battery



### **NOTICE**

### To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

## Instrument cluster

2


### 2. Instrument cluster

Warning lights and	
indicators	. 72
Gauges and meters	. 77
Multi-information display	. 81
Fuel consumption	
information	87

# Warning lights and indicators

The warning lights and indicators on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

For the purpose of explanation, the following illustration displays all warning lights and indicators illuminated.




The units used on the meters and some indicators may differ depending on the target region.

Tire pressure warning

light (→P. 448)

## Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.



(U.S.A.)

(U.S.A.)

((ABS))

(Canada)

ABS warning light

(→P. 446)

\*1: Vehicles without a smart key system:

These lights turn on when the engine switch is turned to the "ON" position to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Toyota dealer.

Vehicles with a smart key system:

These lights turn on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Toyota dealer.

- \*2: If equipped
- \*3: The light turns on when the system is turned off.

### Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator (→P. 164)



Cruise control "SET" indicator (→P. 181)



Headlight indicator (→P. 166)



Pre-collision system warning light (→P. 219)



Tail light indicator (→P. 166)



LDA (Lane Departure Alert) indicator (→P. 199)



Headlight high beam indicator (→P. 167)



Slip indicator (→P. 215)



Automatic High Beam indicator (→P. 170)



VSC OFF indicator (→P. 216)



Eco driving indicator (→P. 79)



"PASS AIR BAG ON/ OFF" indicator (→P. 47)



Cruise control indicator (→P. 181)



Security indicator (→P. 67, 69)



Radar cruise control indicator (→P. 186)



Low outside temperature indicator ( $\rightarrow$ P. 77)

\*1: Vehicles without a smart key system:

These lights turn on when the engine switch is turned to the "ON" position to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Toyota dealer.

Vehicles with a smart key system:

These lights turn on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Toyota dealer.

- \*2: If equipped
- \*3: The light does not turn on when the system is disabled.
- \*4: This light illuminates on the multi-information display.
- \*5: The light turns on when the system is off.
- \*6: The light flashes to indicate that the system is operating.
- \*7: This light illuminates on the center panel.
- \*8: When the outside temperature is approximately 37°F (3°C) or lower, the indicator will flash for approximately 10 seconds, then stay on.




### **MARNING**

### If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning lights not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Toyota dealer immediately if this occurs.

## **Gauges and meters**



(1) Tachometer

Displays the engine speed in revolutions per minute.

(2) Multi-information display

Presents the driver with a variety of driving-related data.

Displays warning messages in case of a malfunction (→P. 454)

(3) Outside temperature display

Displays the outside temperature within the range of -40°F (-40°C) to  $122^{\circ}F$  (50°C). Low outside temperature indicator comes on when the ambient temperature is  $37^{\circ}F$  (3°C) or lower.

- (4) Speedometer
- (5) Display change button
  - →P. 78
- (6) Fuel gauge
- (7) Odometer and trip meter display
  - →P. 78
- (8) Shift position/shift range display

Displays the currently selected the shift position and shift range.

- →P. 160
- (9) Engine coolant temperature gauge


Displays the engine coolant temperature.

(10) Instrument panel light control button

→P. 78

## Changing the odometer/trip meter display

Pressing the display change button changes the display as follows.



### ■ Odometer

Displays the total distance the vehicle has been driven.

## ■ Trip meter A\*/trip meter B\*


Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.

\*: Press and hold the display change button to reset.

## Instrument panel lights control button

The brightness of the Instrument panel lights can be adjusted.

Pressing the button will adjust brightness of the Instrument panel lights.



### ■ Eco driving indicator light

During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on. When the acceleration exceeds the Eco driving accelerator upper limit, or the vehicle is stopped, the light turns off.

Eco Driving Indicator Light will not operate in the following conditions:

- The shift lever is in anything other than D.
- The paddle shift switch is used. (If equipped)
- The vehicle speed is approximately 80 mph (130 km/h) or higher.

### ■ The meters and display illuminate when

▶ Vehicles without a smart key system

The engine switch is in the "ON" position.

▶ Vehicles with a smart key system

The engine switch is in IGNITION ON mode.

### ■ The brightness of the instrument panel lights

When the tail lights are turned on, the meter's brightness will be reduced slightly unless the meter brightness level adjustment is set to the brightest setting.

If the tail lights are turned on when the surroundings are dark, the meter's brightness will reduce slightly. However, when the surroundings are bright, such as during the daytime, the meter's brightness will not be reduced even if the tail lights are turned on.

### ■ Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 16 mph [25 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)

## **NOTICE**

## ■ To prevent damage to the engine and its components

- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P. 492)

## **Multi-information display**


## **Display contents**

The multi-information display presents the driver with a variety of vehicle data.

### Menu icons

Displays the following information when an icon is selected.  $(\rightarrow P. 82)$ 

Some of the information may be displayed automatically depending on the situation.





**Drive information** 

Select to display various drive data. (→P. 83)



Navigation system-linked display (if equipped)

Select to display the following navigation system-linked information.

- · Route guidance
- Compass display (north-up display/heading-up display)



Audio system-linked display (if equipped)

Select to enable selection of an audio source or track on the meter using the meter control switches.



Dynamic radar cruise control operation guide (if equipped)

Select to display operation procedures of the dynamic radar cruise control.  $(\rightarrow P. 186)$ 

The tab will change to when the vehicle is in constant speed control mode. (→P. 192)

If activated, the operational status of the LDA (Lane Departure Alert) system will also be displayed. (If equipped)  $(\rightarrow P. 200)$ 



## Warning message display

Select to display warning messages and measures to be taken if a malfunction is detected. (→P. 454)



## Settings display


Select to change the meter display settings.  $(\rightarrow P. 84)$ 

## ■ Operating the meter control switches

- 1 Scroll up/down the screen and move up/down the cursor
- (2) Switch menu
- (3) Press: Enters/Sets

Press and hold: Resets

(4) Returns to the previous screen



### Drive information

Average fuel economy\*1, 2/Tank average fuel economy\*1/Trip average fuel economy\*1

Displays the average fuel consumption since the function was reset, the vehicle was refueled, and the engine was started, respectively

Use the displayed average fuel consumption as a reference.

Current fuel economy\*1

Displays the current rate of fuel consumption

● Distance to empty\*1/Trip distance\*1/Distance\*1, 2

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining, the distance driven after the engine was started and the distance since the function was reset, respectively.

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.
  - When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.
- Trip elapse time\*1/Elapse time\*1, 2

Displays the engine was started and the elapsed time since the function was reset, respectively

Trip average speed\*¹/Average speed\*¹, ²

Displays the engine was started and the average vehicle speed since the function was reset, respectively

- Digital speedometer\*1
- Tire inflation pressure\*3
  - →P. 404

- \*2: Resetting procedures:
  - Select a function to be reset using the meter control switch and then
    press and hold to reset.
  - If there is more than one function that can be reset, check boxes will be displayed next to those functions.

<sup>\*1:</sup> Can be registered to Drive information 1 through 3.  $(\rightarrow P. 84)$ 

<sup>\*3:</sup> Vehicles with a tire inflation pressure display function

### Settings display

### ■ Changing the settings

- 1 Select using the meter control switch.
- 2 Select an item and then set it with the center button.

#### ■ Customizable items

Language

Select to change the language displayed on the multi-information display.

Units

Select to change the unit of measure displayed on the multi-information display.

Drive information 1 through 3

Select to select up to 2 items that will be displayed on a Drive information screen, up to 3 Drive information screens can be set.

Eco driving indicator light

Select to activate/deactivate the Eco Driving Indicator Light.  $(\rightarrow P. 79)$ 

Pop-up display

Select to set the following pop-up displays, which may appear in some situations, on/off.

- · Instrument panel brightness adjustment display
- Route guidance display of the navigation system-linked system (if equipped)
- Cruise control operation display (vehicles with dynamic radar cruise control)
- · Incoming call display of the hands-free phone system
- Shift position and range display
- Accent color

Select to change the accent colors on the screen, such as the cursor color.

Speed limit display\*

Select to set the display of speed limit information stored in the navigation system (if equipped) to on with the speed limit caution indicator (yellow) enabled, on with the speed limit caution not enabled, or off. If enabled, the speed limit caution indicator will come on if the vehicle speed exceeds the displayed speed limit.

Maintenance system (U.S.A.)

Select to reset the message after the required maintenance is performed. ( $\rightarrow$ P. 381)

Initialization

Registered or changed meter settings will be deleted or returned to their default setting.

### ■ Setting display automatic cancelation

In the following situations, a setting display in which the settings can be changed through the meter control switches will automatically be turned off.

- When a warning message appears while the setting display is displayed
- When the vehicle begins to move while the setting display is displayed

### ■ Tire inflation pressure (vehicles with a tire pressure warning system)

Vehicles without a smart key system:

It may take a few minutes to display the tire inflation pressure after the engine switch is turned to the "ON" position. It may also take a few minutes to display the tire inflation pressure after inflation pressure has been adjusted

Vehicles with a smart key system:

It may take a few minutes to display the tire inflation pressure after the engine switch is turned to IGNITION ON mode. It may also take a few minutes to display the tire inflation pressure after inflation pressure has been adjusted

- "---" may be displayed if the tire information cannot be determined due to unfavorable radio wave conditions.
- Tire inflation pressure changes with temperature. The displayed values may also be different from the values measured using a tire pressure gauge.

### ■ Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.

<sup>\*:</sup> Speed limit display may not be available for some regions.

## **MARNING**

### The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.

### Cautions during setting up the display

As the engine needs to be running during setting up the display, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.

## **↑** NOTICE


## During setting up the display

To prevent battery discharge, ensure that the engine is running while setting up the display features.

## **Fuel consumption information**

Fuel consumption information can be displayed on the Entune Audio and/or the Entune Premium Audio.

Entune Audio or Entune Premium Audio




## Trip information

▶ Entune Audio with "CAR" button


Press the "CAR" button.

If the "Past Record" screen is displayed, select "Trip Information".



- ▶ Entune Audio or Entune Premium Audio with "APPS" button
- 1 Press the "APPS" button.
- 2 Touch "Eco" on the "Apps" screen.

If the "Past Record" screen is displayed, select "Trip Information".



- (1) Resetting the consumption data
- 2 Average vehicle speed since the engine was started
- ③ Elapsed time since the engine was started
- 4 Fuel consumption in the past 15 minutes
- (5) Cruising range (→P. 89)
- (6) Current fuel consumption


Vehicles without a smart key system:

Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the engine switch was last turned to the "ON" position. Use the displayed average fuel consumption as a reference.

Vehicles with a smart key system:

Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the engine switch was last turned to IGNITION ON mode. Use the displayed average fuel consumption as a reference.

This image is an example only.



### Past record

▶ Entune Audio with "CAR" button

Press the "CAR" button.

If the "Trip Information" screen is displayed, select "Past Record".

- ▶ Entune Audio or Entune Premium Audio with "APPS" button
- 1 Press the "APPS" button.
- 2 Touch "Eco" on the "Apps" screen.

  If the "Trip Information" screen is displayed, select "Past Record".
- (1) Resetting the past record data
- (2) Best recorded fuel consumption
- (3) Average fuel consumption
- 4 Previous fuel consumption record
- (5) Current fuel economy
- 6 Updating the average fuel consumption data



The average fuel consumption history is divided by color into past averages and the average fuel consumption since the last updated. Use the displayed average fuel consumption as a reference.

This image is an example only.

### ■Updating the past record data

Update the average fuel consumption by selecting "Update" to measure the current fuel consumption again.

### ■ Resetting the data

The fuel consumption data can be deleted by selecting "Clear".

### ■ Cruising range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.

# Operation of each component

3


3-1.	Key information
	Keys 92
3-2.	Opening, closing and locking the doors
	Doors 99
	Trunk 107
	Smart key system 112
3-3.	Adjusting the seats
	Front seats 119
	Rear seats 121
	Head restraints 123
3-4.	Adjusting the steering wheel and mirrors
	Steering wheel 125
	Inside rear view mirror 127
	Outside rear view
	mirrors129
3-5.	Opening and closing the windows
	Power windows 131
	Moon roof 134

## Keys

## The keys

The following keys are provided with the vehicle.


- ▶ Vehicles without a smart key system (type A)
- Master keys
   Operating the wireless remote con
  - trol function (→P. 93)
- 2 Valet key
- (3) Key number plate




- ▶ Vehicles without a smart key system (type B)
- Master keys

Operating the wireless remote control function ( $\rightarrow$ P. 93)

- 2 Valet key
- (3) Key number plate




- Vehicles with a smart key system
- 1 Electronic keys
  - Operating the smart key system (→P. 112)
  - Operating the wireless remote control function (→P. 93)
- (2) Mechanical keys
- (3) Key number plate



### Wireless remote control


- ▶ Vehicles without a smart key system (type A)
- 1 Locks all the doors ( $\rightarrow$ P. 99)
- (2) Sounds the alarm ( $\rightarrow$ P. 95)
- $\bigcirc$  Unlocks all the doors  $\bigcirc$  P. 99) Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.
- (4) Opens the driver's window and moon roof (if equipped) (→P. 99)\*




- (5) Opens the trunk ( $\rightarrow$ P. 108)
- \*: This setting must be customized at your Toyota dealer.
- ► Vehicles without a smart key system (type B)
- 1 Locks all the doors ( $\rightarrow$ P. 99)
- (2) Unlocks all the doors ( $\rightarrow$ P. 99) Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.
- (3) Opens the driver's window and moon roof (if equipped) (→P. 99)\*




- (4) Sounds the alarm ( $\rightarrow$ P. 95)
- (5) Opens the trunk ( $\rightarrow$ P. 108)
- \*: This setting must be customized at your Toyota dealer.



- ▶ Vehicles with a smart key system
- 1 Locks all the doors ( $\rightarrow$ P. 99)
- ② Unlocks all the doors (→P. 99) Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.
- ③ Opens the driver's window and moon roof (if equipped)(→P. 99)\*




- $\bigcirc$  Sounds the alarm ( $\rightarrow$ P. 95)
- \*: This setting must be customized at your Toyota dealer.



### Using the mechanical key (vehicles with a smart key system)

To take out the mechanical key, push the release button and take the key out.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and reattempt to insert it.



After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key.  $(\rightarrow P.~485)$ 

#### ■ Panic mode

▶ Vehicles without a smart key system

When (() is pressed for longer than about one second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the wireless remote control.



### ▶ Vehicles with a smart key system

When (t) is pressed for longer than about one second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the electronic key.



#### ■ When required to leave the vehicle's key with a parking attendant

Lock the glove box as circumstances demand. (→P. 343)

Vehicles without a smart key system: Carry the master key for your own use and provide the attendant with the valet key.

Vehicles with a smart key system: Remove the mechanical key for your own use and provide the attendant with the electronic key only.

### ■ If you lose your keys

New genuine keys can be made by your Toyota dealer using the other key (vehicles without a smart key system) or the other mechanical key (vehicles with a smart key system) and the key number stamped on your key number plate. Keep the plate in a safe place such as your wallet, not in the vehicle.

### ■When riding in an aircraft

When bringing a key with wireless remote control function onto an aircraft, make sure you do not press any button on the key while inside the aircraft cabin. If you are carrying the key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the key to emit radio waves that could interfere with the operation of the aircraft.

#### ■ Conditions affecting operation

▶ Vehicles without a smart key system

The wireless remote control function may not operate normally in the following situations:

- When the wireless key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone or other wireless communication devices
- When the wireless key is in contact with, or is covered by a metallic object
- When other wireless key (that emit radio waves) is being used nearby
- If window tint with a metallic content or metallic objects are attached to the rear window
- ▶ Vehicles with a smart key system
- →P. 115

### ■ Key battery depletion

▶ Vehicles without a smart key system

If the wireless remote control function does not operate, the battery may be depleted. Replace the battery when necessary. (→P. 420)

- ▶ Vehicles with a smart key system
- The standard battery life is 1 to 2 years.
- If the battery becomes low, an alarm will sound in the cabin when the engine stops. (→P. 466)
- As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the electronic key battery may be depleted. Replace the battery when necessary. (→P. 420)
  - The smart key system or the wireless remote control does not operate.
  - · The detection area becomes smaller.
  - The LED indicator on the key surface does not turn on.
- To avoid serious deterioration, do not leave the electronic key within 3 ft. (1 m) of the following electrical appliances that produce a magnetic field:
  - TVs
  - · Personal computers
  - · Cellular phones, cordless phones and battery chargers
  - Recharging cellular phones or cordless phones
  - · Table lamps
  - · Induction cookers

#### ■ Replacing the battery

→P. 420

Operation of each component

## ■Confirmation of the registered key number (vehicles with a smart key system)

The number of keys already registered to the vehicle can be confirmed. Ask your Toyota dealer for details.

### ■ If a wrong key is used (vehicles with a smart key system)

The key cylinder rotates freely to isolate inside mechanism.

### ■ Customization that can be configured at Toyota dealer

Settings (e. g. smart key system) can be changed. (Customizable features:  $\rightarrow$ P. 523)

### ■Certification for the wireless remote control (vehicles without a smart key system)

▶ U.S.A.

FCC ID: HYQ23AAC FCC ID: HYQ23AAN FCC ID: HYQ12BDM

#### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### ▶ Canada

#### NOTE:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## Certification for wireless remote control (vehicles with a smart key system)

→P. 118

## **NOTICE**

### To prevent key damage

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for long periods of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the key with a wireless remote control function.
- Vehicles with a smart key system: Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers, or medical electrical equipment, such as low-frequency therapy equipment

## Carrying the electronic key on your person (vehicles with a smart key system)

Carry the electronic key 3.9 in. (10 cm) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 3.9 in. (10 cm) of the electronic key may interfere with the key, causing the key to not function properly.

In case of a smart key system malfunction or other key-related problems (vehicles with a smart key system)

Take your vehicle with all the electronic keys provided with your vehicle to your Toyota dealer.

When an electronic key is lost (vehicles with a smart key system)

If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit your Toyota dealer immediately with all remaining electronic keys that were provided with your vehicle.

## **Doors**

### Unlocking and locking the doors from the outside


### Smart key system (if equipped)

Carry the electronic key to enable this function.

 Grip the driver's door handle to unlock the door. Grip the front passenger's door handle to unlock all the doors.\*

Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked.



- \*: The door unlock settings can be changed. (→P. 105)
- 2 Touch the lock sensor (the indentation on the side of the door handle) to lock the doors.

Check that the door is securely locked.

## **♦** Wireless remote control

- ▶ Vehicles without a smart key system
  - 1 Locks all the doors


Check that the door is securely locked.

(2) Unlocks all the doors

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

Press and hold to open the driver's window and moon roof.\* (→P. 132, 135)

\*: This setting must be customized at your Toyota dealer.



## ▶ Vehicles with a smart key system


1) Locks all the doors

Check that the door is securely locked.

(2) Unlocks all the doors

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

Press and hold to open the driver's window and moon roof.\* (→P. 132, 135)



<sup>\*:</sup> This setting must be customized at your Toyota dealer.

## Key

Turning the key operates the doors as follows:

### ▶ Vehicles without a smart key system


1 Locks all the doors

Turn and hold to close the windows and moon roof.\*  $(\rightarrow P. 132, 135)$ 

(2) Unlocks the door

Turning the key unlocks the driver's door. Turning the key again unlocks the other doors.

Turn and hold to open the driver's window and moon roof.\*  $(\rightarrow P. 132, 135)$ 



- \*: This setting must be customized at your Toyota dealer.
- Vehicles with a smart key system

The doors can also be locked and unlocked with the mechanical key.  $(\rightarrow P.~485)$ 

### ■ Operation signals

Doors

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

Driver's window and moon roof:


A buzzer sounds to indicate that the driver's window and moon roof are opening.

### ■ Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

## ■When the door cannot be locked by the lock sensor on the upper part of the door handle

If the door will not lock even when the topside sensor area is touched, try using your palm to touch the lock sensor.



### ■ Door lock buzzer (vehicles with a smart key system)

If an attempt to lock the doors is made when a door is not fully closed, a buzzer will sound for 5 seconds. Fully close the door to stop the buzzer, and lock the doors again.

## ■ Alarm (if equipped)

Locking the doors will set the alarm system. ( $\rightarrow$ P. 69)

## If the smart key system or the wireless remote control does not operate properly (vehicles with a smart key system)


Use the mechanical key to lock and unlock the doors. (→P. 485)

Replace the battery with a new one if it is depleted. (→P. 420)

## Unlocking and locking the doors from the inside

### Door lock switches


- 1 Locks all the doors
- (2) Unlocks all the doors



### ◆ Inside lock buttons

- (1) Locks the door
- (2) Unlocks the door

The front doors can be opened by pulling the inside handle even if the lock buttons are in the lock position.



### Locking the front doors from the outside without a key

- 1 Move the inside lock button to the lock position.
- 2 Close the door.
- ▶ Vehicles without a smart key system

The door cannot be locked if either of the front doors is open and the key is in the engine switch.

▶ Vehicles with a smart key system

The door cannot be locked if the engine switch is in ACCESSORY or IGNITION ON mode, or the electronic key is left inside the vehicle.

The key may not be detected correctly and the door may be locked.

## Rear door child-protector lock

The door cannot be opened from inside the vehicle when the lock is set.

- 1 Unlock
- (2) Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.



## Automatic door locking and unlocking systems

The following functions can be set or cancelled:


Function	Operation
Shift position linked door locking function	Shifting the shift lever out of P locks all the doors.
Shift position linked door unlocking function	Shifting the shift lever to P unlocks all the doors.
Speed linked door lock- ing function	All the doors are locked when the vehicle speed is approximately 12 mph (20 km/h) or higher.
Driver's door linked door unlocking function (vehicles without a smart key system)	All the doors are unlocked when the driver's door is opened within 10 seconds after turning the engine switch to "ACC" or "LOCK".
Driver's door linked door unlocking function (vehicles with a smart key system)	All the doors are unlocked when the driver's door is opened within 10 seconds after turning the engine switch off.

### ■ Setting and canceling the functions

The automatic door locking and unlocking functions can be set or canceled on the audio system screen ( $\rightarrow$ P. 523) or by following the procedure below.

- 1 Vehicles without a smart key system: Close all the doors and switch the engine switch to the "ON" position. (Perform step 2 within 10 seconds.)
  - Vehicles with a smart key system: Close all the doors and switch the engine switch to IGNITION ON mode. (Perform step 2 within 10 seconds.)
- 2 Shift the shift lever to P or N, and press and hold the driver's door lock switch ( or or approximately 5 seconds and then release.

The shift lever and switch positions corresponding to the desired function to be set are shown as follows.



Use the same procedure to cancel the function.

Function	Shift lever position	Driver's door lock switch position
Shift position linked door locking function	P	a
Shift position linked door unlocking function	<b>'</b>	ū
Speed linked door locking function	N	£
Driver's door linked door unlocking function	14	ū

When the setting or canceling operation is complete, all doors are locked and then unlocked.

### ■ Switching the door unlock function (vehicles with a smart key system)

It is possible to set which doors the entry function unlocks using the wireless remote control.

- 1 Turn the engine switch off.
- 2 When the indicator light on the key surface is not on, press and hold
  - or (() for approximately 5 seconds while pressing and holding

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step  $\boxed{2}$ .)

Multi-information display	Unlocking function	Веер
- <u>-</u>	Holding the driver's door handle unlocks only the driver's door.	Exterior: Beeps 3 times Interior: Pings once
3	Holding the front passenger's door handle unlocks all the doors.	
1	Holding either front door handle unlocks all the doors.	Exterior: Beeps twice Interior: Pings once

Vehicles with an alarm: To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door is not opened within 60 seconds after is pressed, the doors will be locked again and the alarm will automatically be set.)

In case that the alarm is triggered, immediately stop the alarm. (→P. 69)

## ■ Conditions affecting the operation of the smart key system or wireless remote control

- ▶ Vehicles without a smart key system
- →P. 96
- ▶ Vehicles with a smart key system
- →P. 115

### **■** Customization

Settings (e.g. unlocking function using a key) can be changed. (Customizable features: →P. 523)

### **MARNING**

### To prevent an accident

Observe the following precautions while driving the vehicle. Failure to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.


- Ensure that all doors are properly closed.
- Do not pull the inside handle of the doors while driving. Be especially careful for the front doors, as the doors may be opened even if the inside lock buttons are in locked position.
- Set the rear door child-protector locks when children are seated in the rear seats.

## **Trunk**

The trunk can be opened using the trunk opener, entry function, wireless remote control.

## Opening the trunk from inside the vehicle

Pull up the lever to release the trunk lid.




## Opening the trunk from outside the vehicle

## Smart key system (if equipped)

While carrying the electronic key, press the button on the trunk lid.


When all the doors are unlocked with the power door lock system, the trunk can be opened without carrying the electronic key.



## **♦** Wireless remote control

▶ Vehicles without a smart key system

Press and hold the switch.



► Vehicles with a smart key system Press and hold the switch.



# Operation of each component

#### ■ Operation signal

A buzzer sounds to indicate that the trunk has been opened.

#### ■Trunk light

The trunk light turns on when the trunk is opened.


#### ■Function to prevent the trunk being locked with the electronic key inside (vehicles with a smart key system)

- When all doors are being locked, closing the trunk lid with the electronic key left inside the trunk will sound an alarm.
  - In this case, the trunk lid can be opened by pressing the trunk release button on the trunk lid.
- Even when the spare electronic key is put in the trunk with all the doors locked, the key confinement prevention function can be activated so the trunk can be opened. In order to prevent theft, take all electronic keys with you when leaving the vehicle.
- Even when the electronic key is put in the trunk with all the doors are locked, the key may not be detected depending on the places and the surrounding radio wave conditions. In this case, the key confinement prevention function cannot be activated, causing the doors to lock when the trunk is closed. Make sure to check where the key is before closing the trunk.
- The key confinement prevention function cannot be activated if any one of the doors is unlocked. In this case, open the trunk using the trunk opener.

#### ■ Internal trunk release lever

The trunk lid can be opened by pulling up the glow-in-the-dark lever located on the inside of the trunk lid.

The lever will continue to glow for some time after the trunk lid is closed.



Observe the following precautions.

Failure to do so may result in death or serious injury.

#### ■ Before driving

- Make sure that the trunk lid is fully closed. If the trunk lid is not fully closed, it may open unexpectedly while driving and hit near-by objects or luggage in the trunk may be thrown out, causing an accident.
- Do not allow children to play in the trunk.
   If a child is accidentally locked in the trunk, they could suffer from heat exhaustion, suffocation or other injuries.
- Do not allow a child to open or close the trunk lid.
   Doing so may cause the trunk lid to open unexpectedly, or cause the child's hands, head, or neck to be caught by the closing trunk lid.

#### ■Important points while driving

Never let anyone sit in the trunk. In the event of sudden braking or a collision, they are susceptible to death or serious injury.


#### Using the trunk

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in serious injury.

- Remove any heavy loads, such as snow and ice, from the trunk lid before opening it. Failure to do so may cause the trunk lid to suddenly shut again after it is opened.
- •When opening or closing the trunk lid, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- Use caution when opening or closing the trunk lid in windy weather as it may move abruptly in strong wind.
- The trunk lid may suddenly shut if it is not opened fully. It is more difficult to open or close the trunk lid on an incline than on a level surface, so beware of the trunk lid unexpectedly opening or closing by itself. Make sure that the trunk lid is fully open and secure before using the trunk.
- When closing the trunk lid, take extra care to prevent your fingers etc. from being caught.
- When closing the trunk lid, make sure to press it lightly on its outer surface.





 Do not attach any accessories other than genuine Toyota parts to the trunk lid. Such additional weight on the trunk lid may cause the lid to suddenly shut again after it is opened.


# Smart key system\*

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. (The driver should always carry the electronic key.)

- Locks and unlocks the doors (→P. 99)
- ullet Opens the trunk ( $\rightarrow$ P. 107)
- Starts the engine ( $\rightarrow$ P. 155)

#### ■Antenna location


- 1 Antennas outside the cabin
- ② Antennas inside the cabin
- ③ Antenna inside the trunk
- 4) Antenna outside the trunk



#### ■ Effective range (areas within which the electronic key is detected)

When locking or unlocking the doors

The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of either of the front outside door handles. (Only the doors detecting the key can be operated.)



- When starting the engine or changing engine switch modes
  The system can be operated when the electronic key is inside the vehicle.
- When opening the trunk

The system can be operated when the electronic key is within about  $2.3 \, \text{ft.} \, (0.7 \, \text{m})$  of the trunk release button.

#### ■ Alarms and warning indicators

A combination of exterior and interior alarms as well as warning messages shown on the multi-information display are used to prevent theft of the vehicle and accidents resulting from erroneous operation. Take appropriate measures in response to any warning message on the multi-information display.  $(\rightarrow P. 454)$ 

The following table describes circumstances and correction procedures when only alarms are sounded.

Alarm	Situation	Correction procedure		
Exterior alarm sounds once for 5 seconds	An attempt was made to lock the doors using the smart key system while the electronic key was still inside the vehicle.	Retrieve the electronic key from the passenger compartment and lock the doors again.		
	The trunk was closed while the electronic key was still inside the trunk and all the doors were locked.	Retrieve the electronic key from the trunk and close the trunk lid.		
	An attempt was made to lock the vehicle while a door was open.	Close all of the doors and lock the doors again.		

Alarm	Situation	Correction procedure		
Interior alarm pings once and exterior alarm sounds once for 5 sec- onds	An attempt was made to lock either front door by opening a door and putting the inside lock button into the lock position, then closing the door with the electronic key still inside the vehicle.	Retrieve the electronic key from the vehicle and lock the doors again.		
Interior alarm sounds continuously	The engine switch was turned to ACCESSORY mode while the driver's door was open (The driver's door was opened when the engine switch was in ACCESSORY mode.)	Turn the engine switch off and close the driver's door.		
	The driver's door was opened while any shift position other than P was selected without turning off the engine switch.	Shift the shift lever to P.		

#### ■ Battery-saving function

The battery-saving function will be activated in order to prevent the electronic key battery and the vehicle battery from being discharged while the vehicle is not in operation for a long time.


- In the following situations, the smart key system may take some time to unlock the doors.
  - The electronic key has been left in an area of approximately 6 ft. (2 m) of the outside of the vehicle for 10 minutes or longer.
  - The smart key system has not been used for 5 days or longer.
- If the smart key system has not been used for 14 days or longer, the doors cannot be unlocked at any doors except the driver's door. In this case, take hold of the driver's door handle, or use the wireless remote control or the mechanical key, to unlock the doors.

#### ■ Electronic Key Battery-Saving Function

When battery-saving mode is set, battery depletion is minimized by stopping the electronic key from receiving radio waves.

Press twice while pressing and holding . Confirm that the electronic key indicator flashes 4 times.

While the battery-saving mode is set, the smart key system cannot be used. To cancel the function, press any of the electronic key buttons.



#### ■ Conditions affecting operation

The smart key system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart key system, wireless remote control and engine immobilizer system from operating properly. (Ways of coping:  $\rightarrow$ P. 485)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication device
- When the electronic key is in contact with, or is covered by the following metallic objects
  - · Cards to which aluminum foil is attached
  - · Cigarette boxes that have aluminum foil inside
  - Metallic wallets or bags
  - Coins
  - · Hand warmers made of metal
  - Media such as CDs and DVDs
- When other wireless keys (that emit radio waves) are being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
  - · Another vehicle's electronic key or a wireless key that emits radio waves
  - Personal computers or personal digital assistants (PDAs)
  - · Digital audio players
  - · Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window
- When the electronic key is placed near a battery charger or electronic devices

#### ■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
  - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
  - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the trunk is opened.
  - The electronic key is on the instrument panel, rear package tray or floor, or in the door pockets or glove box when the engine is started or engine switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the door will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- Even if the electronic key is not inside the vehicle, it may be possible to start the engine if the electronic key is near the window.
- The doors may unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash, when the electronic key is within the effective range. (The doors will automatically be locked after approximately 60 seconds if the doors are not opened and closed.)
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- Touching the door lock or unlock sensor while wearing gloves may prevent lock or unlock operation.
- When the lock operation is performed using the lock sensor, recognition signals will be shown up to two consecutive times. After this, no recognition signals will be given.
- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In this case, follow the following correction procedures to wash the vehicle:
  - Place the electronic key in a location 6 ft. (2 m) or more away from the vehicle. (Take care to ensure that the key is not stolen.)
  - Set the electronic key to battery-saving mode to disable the smart key system. (→P. 115)

- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.
- The lock sensor may not work properly if it comes into contact with ice, snow, mud, etc. Clean the lock sensor and attempt to operate it again.
- If there is another electronic key in the detection area, it may take slightly longer to unlock the doors after the door handle is gripped.
- A sudden handle operation or a handle operation immediately after entering the effective range may prevent the doors from being unlocked. Touch the door unlock sensor and check that the doors are unlocked before pulling the door handle again.

#### ■ When the vehicle is not driven for extended periods

- To prevent theft of the vehicle, do not leave the electronic key within 6 ft. (2 m) of the vehicle.
- The smart key system can be deactivated in advance. ( $\rightarrow$ P. 523)

#### ■ To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention function may not operate.)

#### ■ If the smart key system does not operate properly

- Locking and unlocking the doors: Use the mechanical key. (→P. 485)
- Starting the engine: →P. 486

#### **■** Customization

Settings (e. g. smart key system) can be changed. (Customizable features: →P. 523)

#### ■ If the smart key system has been deactivated in a customized setting

- Locking and unlocking the doors and opening the trunk: Use the wireless remote control or mechanical key. (→P. 108, 485)
- Starting the engine and changing engine switch modes: →P. 486
- Stopping the engine: →P. 155

#### ■ Certification for the smart key system

▶ U.S.A.

FCC ID: NI4TMLF10-3 FCC ID: NI4TMLF10-51 FCC ID: HYQ23AAP FCC ID: HYQ14FBA

#### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### ▶ Canada

#### NOTE:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### **MARNING**

#### Caution regarding interference with electronic devices

- People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should keep away from the smart key system antennas. (→P. 112)
  - The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Toyota dealer for details, such as the frequency of radio waves and timing of the emitted radio waves. Then, consult your doctor to see if you should disable the entry function.
- Users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.


Radio waves could have unexpected effects on the operation of such medical devices.

Ask your Toyota dealer for details for disabling the entry function.

# **Front seats**


#### Adjustment procedure

#### ▶ Manual seat



- (1) Seat position adjustment lever
- (2) Seatback angle adjustment lever
- ③ Vertical height adjustment lever (driver's side only)

#### ▶ Power seat



- 1) Seat position switch
- switch
- (3) Seat cushion (front) angle adjustment switch (driver's side only)
- adjustment (4) Vertical height adjustment switch (driver's side only)
- 2) Seatback angle adjustment 5) Lumbar support adjustment switch (driver's side only)

#### WARNING

#### ■When adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.
  - Fingers or hands may become jammed in the seat mechanism.
- Make sure to leave enough space around the feet so they do not get stuck.

#### Seat adjustment


- Be careful that the seat does not hit passengers or luggage.
- To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.
- If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.
- Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.
- Manual seat only: After adjusting the seat, make sure that the seat is locked in position.

# Rear seats

The seatbacks of the rear seats can be folded down.

#### Folding down the rear seatbacks

Pull the seatback lever in the trunk for the seatback you wish to fold down.



### **WARNING**

#### When folding the rear seatbacks down

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not fold the seatbacks down while driving.
- Stop the vehicle on level ground, set the parking brake and shift the shift lever to P.
- Do not allow anyone to sit on a folded seatback or in the trunk while driving.
- Do not allow children to enter the trunk.

#### When returning the seat to its original position

- Ensure that the seat belt does not get caught between or behind the seats.
- If the seat belt has been released from its guide, pass the seat belt through its guide. (→P. 30)

#### Seat adjustment

Be careful not to get hands or feet pinched between the rear console box and the rear seat when folding down the rear seatback.

#### After returning the seatback to the upright position

Observe the following precautions. Failure to do so may result in death or serious injury.

- Make sure the seatback is securely locked by pressing it forward and rearward on the top.
- Check that the seat belts are not twisted or caught in the seatback.
- Make sure that the seat belt is passing through its guide.

#### NOTICE

#### When the left seatback is folded down

Make sure the luggage loaded in the enlarged trunk will not damage the webbing of the rear center seat belt.

# **Head restraints**

#### Head restraints are provided for all seats.

#### Front seats


Vertical adjustment

(1) Up

Pull the head restraint up.


2 Down

Push the head restraint down while pressing the lock release button.



#### ■ Removing the head restraints (front seats)

Pull the head restraint up while pressing the lock release button.



#### ■Installing the head restraints (front seats)


Align the head restraint with the installation holes and push it down to the lock position.

Press and hold the lock release button when lowering the head restraint.



#### ■ Adjusting the height of the head restraints (front seats)

Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.



# **WARNING**

#### Head restraint precautions (front seats)


Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.

# Steering wheel


## Adjustment procedure

1 Hold the steering wheel and push the lever down.




2 Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.



#### Horn

To sound the horn, press on or close to the mark.



#### Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

#### After adjusting the steering wheel

Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident, and resulting in death or serious injury. Also, the horn may not sound if the steering wheel is not securely locked.


# **Inside rear view mirror**

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

#### Adjusting the height of rear view mirror


The height of the rear view mirror can be adjusted to suit your driving posture.

Adjust the height of the rear view mirror by moving it up and down.



#### Anti-glare function

- ▶ Manual anti-glare inside rear view mirror Reflected light from the headlights of vehicles behind can be reduced by operating the lever.
- 1 Normal position
- 2 Anti-glare position



#### Auto anti-glare inside rear view mirror


Responding to the level of brightness of the headlights of vehicles behind, the reflected light is automatically reduced.

Changing automatic anti-glare function mode

#### On/off

When the automatic anti-glare function is in ON mode, the indicator illuminates.

Vehicles without a smart key system: The function will set to ON mode each time the engine switch is turned to the "ON" position. Pressing the button turns the function to OFF mode. (The indicator




Vehicles with a smart key system: The function will set to ON mode each time the engine switch is turned to IGNITION ON mode.

Pressing the button turns the function to OFF mode. (The indicator also turns off.)

#### ■ To prevent sensor error (vehicles with an auto anti-glare inside rear view mirror)

To ensure that the sensors operate properly, do not touch or cover them.





#### WARNING

also turns off.)


Do not adjust the position of the mirror while driving.

Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.


# **Outside rear view mirrors**

# Adjustment procedure

- 1 To select a mirror to adjust, press the switch.
  - 1) Left
  - 2 Right




- 2 To adjust the mirror, press the switch.
  - ① Up
  - 2 Right
  - ③ Down
  - 4 Left



# Folding the mirrors

Push the mirror back in the direction of the vehicle's rear.



#### ■ Mirror angle can be adjusted when

▶ Vehicles without a smart key system

The engine switch is in the "ACC" or "ON" position.

▶ Vehicles with a smart key system

The engine switch is in ACCESSORY or IGNITION ON mode.

#### ■When the mirrors are fogged up

The outside rear view mirrors can be cleared using the mirror defoggers. Turn on the rear window defogger to turn on the outside rear view mirror defoggers. ( $\rightarrow$ P. 327, 333)

## **WARNING**

#### Important points while driving

Observe the following precautions while driving.

Failure to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

#### When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

#### When the mirror defoggers are operating


Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

# **Power windows**

#### Opening and closing procedures

The power windows can be opened and closed using the switches. Operating the switch moves the windows as follows:


- (1) Closing
- ② One-touch closing (front side windows only)\*
- (3) Opening
- 4 One-touch opening (front side windows only)\*
  - \*: To stop the window partway, operate the switch in the opposite direction.



#### Window lock switch

Press the switch to lock the passenger window switches.

Use this switch to prevent children from accidentally opening or closing a passenger window.



#### ■ The power windows can be operated when

▶ Vehicles without a smart key system

The engine switch is in the "ON" position.

▶ Vehicles with a smart key system

The engine switch is in IGNITION ON mode.

#### ■ Operating the power windows after turning the engine off

▶ Vehicles without a smart key system

The power windows can be operated for approximately 45 seconds even after the engine switch is turned to the "ACC" or "LOCK" position. They cannot, however, be operated once either front door is opened.

▶ Vehicles with a smart key system

The power windows can be operated for approximately 45 seconds even after the engine switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once either front door is opened.

#### ■ Jam protection function (front door windows)

If an object becomes caught between the window and the window frame, window travel is stopped and the window is opened slightly.

#### ■When the power window does not close normally (front door windows)

If the jam protection function is operating abnormally and a window cannot be closed, perform the following operations using the power window switch on the relevant door.

- Vehicles without a smart key system: After stopping the vehicle, the window can be closed by holding the power window switch in the one-touch closing position while the engine switch is turned to the "ON" position.
  - Vehicles with a smart key system: After stopping the vehicle, the window can be closed by holding the power window switch in the one-touch closing position while the engine switch is turned to IGNITION ON mode.
- If the window still cannot be closed even by carrying out the operation as explained above, initialize the function by performing the following procedure.
- 1 Hold the power window switch in the one-touch closing position. Continue holding the switch for a further 6 seconds after the window has closed.
- 2 Hold the power window switch in the one-touch opening position. Continue holding the switch for a further 2 seconds after the window has opened completely.
- 3 Hold the power window switch in the one-touch closing position once again. Continue holding the switch for a further 2 seconds after the window has closed.

If you release the switch while the window is moving, start again from the beginning.

If the window continues to close but then re-open slightly even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

#### **■** Customization

Settings (e.g. key linked operation) can be changed. (Customizable features: →P. 523)

#### WARNING

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### Closing the windows

- The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch.  $(\rightarrow P. 131)$
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- When using the wireless remote control, key or mechanical key and operating the power windows, operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window. Also do not let a child operate window by the wireless remote control, key or mechanical key. It is possible for children and other passengers to get caught in the power window.
- When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

#### Jam protection function (front door windows)

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the window fully closes.

# **Moon roof**\*

Use the overhead switches to open and close the moon roof and tilt it up and down.


# Opening and closing

1) Opens the moon roof\*

The moon roof stops slightly before the fully open position to reduce wind noise.


Press the switch again to fully open the moon roof.

- (2) Closes the moon roof\*
- \*: Lightly press either side of the moon roof switch to stop the moon roof partway.



#### Tilt up and down

- 1) Tilts the moon roof up\*
- Tilts the moon roof down\*
  - \*: Lightly press either side of the moon roof switch to stop the moon roof partway.



\*: If equipped

#### ■The moon roof can be operated when

▶ Vehicles without a smart key system

The engine switch is in the "ON" position.

▶ Vehicles with a smart key system

The engine switch is in IGNITION ON mode.

#### ■ Operating the moon roof after turning the engine off

▶ Vehicles without a smart key system

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to the "ACC" or "LOCK" position. It cannot, however, be operated once either front door is opened.

▶ Vehicles with a smart key system

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

#### **■** Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

#### ■Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

#### ■When the moon roof does not close normally

Perform the following procedure:

- If the moon roof closes but then re-opens slightly
- 1 Stop the vehicle.
- 2 Press and hold the "CLOSE" switch.\*1

  The moon roof will close, reopen and pause for approximately 10 seconds.\*2 Then it will close again, tilt up and pause for approximately 1 seconds.
- 3 Check to make sure that the moon roof is completely closed and then release the switch.
- If the moon roof tilts down but then tilts back up

ond. Finally, it will tilt down, open and close.

- 1 Stop the vehicle.
- 2 Press and hold the "UP" switch\*1 until the moon roof moves into the tilt up position and stops.
- 3 Release the "UP" switch once and then press and hold the "UP" switch again. \*1

The moon roof will pause for approximately 10 seconds in the tilt up position.\*2 Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.

- 4 Check to make sure that the moon roof is completely closed and then release the switch.
- \*1: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
- \*2: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the open/close switch in the close position or press and hold the "UP" switch. The moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

#### ■ Moon roof open warning buzzer

The buzzer sounds and a message is shown on the multi-information display in the instrument cluster when the engine switch is turned off and the driver's door is opened with the moon roof open.

#### ■ Customization

Settings (e.g. key linked operation) can be changed. (Customizable features: →P. 523)

Observe the following precautions.

Failure to do so may cause death or serious injury.

#### Opening the moon roof

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

#### Closing the moon roof

- The driver is responsible for moon roof opening and closing operations. In order to prevent accidental operation, especially by a child, do not let a child operate the moon roof. It is possible for children and other passengers to have body parts caught in the moon roof.
- Check to make sure that all passengers do not have any part of their bodies in a position where they could be caught when the moon roof is being operated.
- When using the wireless remote control, key or mechanical key and operating the moon roof, operate the moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the moon roof. Also, do not let a child operate moon roof by the wireless remote control, key or mechanical key. It is possible for children and other passengers to get caught in the moon roof.
- When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

#### Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.

4

# Driving

4-1.	Before driving Driving the vehicle140	4-3.	Operating the lights and wipers
	Cargo and luggage 147		Headlight switch
	Vehicle load limits 150		Automatic High Beam 170
	Trailer towing		Windshield wipers and washer 176
4-2.	Driving procedures	4-4.	Refueling
T-2.	Engine (ignition) switch (vehicles without a		Opening the fuel tank cap 178
	smart key system) 153 Engine (ignition) switch	4-5.	Using the driving support systems
	(vehicles with a smart		Cruise control181
	key system)155 Automatic		Dynamic radar cruise control
	transmission		LDA (Lane Departure Alert) 199
	Parking brake		Rear view monitor
			system 205
			Driving assist systems 214
			PCS (Pre-Collision System)219
			BSM (Blind Spot Monitor)226
			The Blind Spot Monitor function 229
			• The Rear Cross Traffic Alert function 231
		4-6.	Driving tips
			Winter driving tips 234

# **Driving the vehicle**

The following procedures should be observed to ensure safe driving:

#### Starting the engine

→P. 153, 155

#### Driving

- With the brake pedal depressed, shift the shift lever to D.(→P. 160)
- 2 Release the parking brake. (→P. 165)
- 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

#### Stopping

- 1 With the shift lever in D, depress the brake pedal.
- If necessary, set the parking brake.

  If the vehicle is to be stopped for an extended period of time, shift the shift lever to P or N. (→P. 160)

#### Parking the vehicle

- 1 With the shift lever in D, depress the brake pedal.
- 2 Shift the shift lever to P.  $(\rightarrow P. 160)$
- 3 Set the parking brake. (→P. 165)
- 4 Vehicles without a smart key system:

  Turn the engine switch to the "LOCK" position to stop the engine.

Vehicles with a smart key system:

Press the engine switch to stop the engine.

5 Lock the door, making sure that you have the key on your person. If parking on a hill, block the wheels as needed.

#### Starting off on a steep uphill

- 1 Make sure that the parking brake is set and shift the shift lever to D.
- 2 Gently depress the accelerator pedal.
- Release the parking brake.

#### ■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

#### **■** Engine speed while driving

In the following conditions, the engine speed may become high while driving. This is due to automatic up-shifting control or down-shifting implementation to meet driving conditions. It does not indicate sudden acceleration.

- The vehicle is judged to be driving uphill or downhill
- When the accelerator pedal is released

#### ■ Breaking in your new Toyota

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 186 miles (300 km): Avoid sudden stops.
- For the first 621 miles (1000 km):
  - · Do not drive at extremely high speeds.
  - · Avoid sudden acceleration.
  - · Do not drive continuously in low gears.
  - Do not drive at a constant speed for extended periods.

#### ■ Drum-in-disc type parking brake system

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have your Toyota dealer perform the bedding down operation.

#### ■ Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel.  $(\rightarrow P. 500)$ 

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### When starting the vehicle

Always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

#### When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
  - Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident.
  - When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
  - Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
  - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.
- During normal driving, do not turn off the engine. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.
  - However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: →P. 439
- Use engine braking (downshift) to maintain a safe speed when driving down a steep hill.
  - Using the brakes continuously may cause the brakes to overheat and lose effectiveness.  $(\rightarrow P. 160)$
- Do not adjust the display, the positions of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.
   Doing so may result in a loss of vehicle control.
- Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle.
- Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has high-speed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle.
- Sudden acceleration, engine braking due to shifting, or changes in engine speed could cause the vehicle to skid.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected.

#### When shifting the shift lever

- Do not let the vehicle roll backward while the shift lever is in a driving position, or roll forward while the shift lever is in R.
  - Doing so may cause the engine to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.
- Do not shift the shift lever to P while the vehicle is moving.
   Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to R while the vehicle is moving forward.
   Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to a driving position while the vehicle is moving backward.
  - Doing so can damage the transmission and may result in a loss of vehicle control.
- Shifting the shift lever to N while the vehicle is moving will disengage the engine from the transmission. Engine braking is not available when N is selected.
- Be careful not to shift the shift lever with the accelerator pedal depressed. Shifting the shift lever to a gear other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

# If you hear a squealing or scraping noise (brake pad wear limit indicators)

Have the brake pads checked and replaced by your Toyota dealer as soon as possible.

Rotor damage may result if the pads are not replaced when needed.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### When the vehicle is stopped

Do not race the engine.

If the shift lever is any position other than P or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.

- In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.
- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.
- Avoid revving or racing the engine.
   Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

#### When the vehicle is parked

 Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.

Doing so may result in the following:

- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
- Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such as the glove box or on the floor, it may be lit accidentally when luggage is loaded or the seat is adjusted, causing a fire.
- Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle.
- Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.

#### **MARNING**

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### When the vehicle is parked

 Always apply the parking brake, shift the shift lever to P, stop the engine and lock the vehicle.

Do not leave the vehicle unattended while the engine is running.

 Do not touch the exhaust pipes while the engine is running or immediately after turning the engine off.

Doing so may cause burns.

#### When taking a nap in the vehicle

Always turn the engine off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

#### When braking

- When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle.
- If the power brake assist function does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking. In this case, braking is still possible, but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately.
- Do not pump the brake pedal if the engine stalls.
   Each push on the brake pedal uses up the reserve for the power-assisted brakes.
- The brake system consists of 2 individual hydraulic systems; if one of the systems fails, the other will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase.

Have your brakes fixed immediately.

### **NOTICE**

#### When driving the vehicle

- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain driving torque.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

#### When parking the vehicle

Always shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

#### Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.
  - Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

#### If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds or vibrations.
- The vehicle will lean abnormally.

Information on what to do in case of a flat tire ( $\rightarrow$ P. 470)

#### When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Toyota dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, transaxle, etc.
- Lubricant condition for the bearings and suspension joints (where possible), and the function of all joints, bearings, etc.

Take notice of the following information about storage precautions, cargo capacity and load:

#### **Capacity and distribution**

Cargo capacity depends on the total weight of the occupants.

(Cargo capacity) = (Total load capacity) — (Total weight of occupants)

#### Steps for Determining Correct Load Limit —

- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity.
  - For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.  $(1400 750 (5 \times 150) = 650 \text{ lbs.})$
- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- (6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

(→P. 150)


Toyota does not recommend towing a trailer with your vehicle. Your vehicle is not designed for trailer towing.

4

Driving

#### Calculation formula for your vehicle

- 1 Cargo capacity
- ② Total load capacity (vehicle capacity weight) (→P. 498)



When 2 people with the combined weight of A lb. (kg) are riding in your vehicle, which has a total load capacity (vehicle capacity weight) of B lb. (kg), the available amount of cargo and luggage load capacity will be C lb. (kg) as follows:

$$B^{*2}$$
 lb. (kg) -  $A^{*1}$  lb. (kg) =  $C^{*3}$  lb. (kg)

- \*1: A =Weight of people
- \*2: B =Total load capacity
- \*3: C =Available cargo and luggage load

In this condition, if 3 more passengers with the combined weight of D lb. (kg) get on, the available cargo and luggage load will be reduced E lb. (kg) as follows:

C lb. (kg) -  $D^{*4}$  lb. (kg) =  $E^{*5}$  lb. (kg)

- \*4: D =Additional weight of people
- \*5: E =Available cargo and luggage load

As shown in the example above, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.

#### **WARNING**

#### Things that must not be carried in the trunk

The following things may cause a fire if loaded in the trunk:

- Receptacles containing gasoline
- Aerosol cans

#### Storage precautions

Observe the following precautions.

Failure to do so may prevent the pedals from being depressed properly, may block the driver's vision, or may result in items hitting the driver or passengers, possibly causing an accident.

- Stow cargo and luggage in the trunk whenever possible.
- To prevent cargo and luggage from sliding forward during braking, do not stack anything in the enlarged trunk. Keep cargo and luggage low, as close to the floor as possible.
- Do not place cargo or luggage in or on the following locations.
  - At the feet of the driver
  - On the front passenger or rear seats (when stacking items)
  - On the package tray
  - On the instrument panel
  - On the dashboard
  - Tray that has no lid
- Secure all items in the occupant compartment.
- When you fold down the rear seats, long items should not be placed directly behind the front seats.
- Never allow anyone to ride in the enlarged trunk. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened.

#### Capacity and distribution

- Do not exceed the maximum axle weight rating or the total vehicle weight rating.
- Even if the total load of occupant's weight and the cargo load is less than the total load capacity, do not apply the load unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

### **Vehicle load limits**

Vehicle load limits include total load capacity, seating capacity, towing capacity and cargo capacity.

#### ◆ Total load capacity (vehicle capacity weight): (→P. 498)

Total load capacity means the combined weight of occupants, cargo and luggage.

### Seating capacity: 5 occupants (Front 2, Rear 3)

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

#### Towing capacity

Toyota does not recommend towing a trailer with your vehicle.

#### Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

#### ■ Total load capacity and seating capacity

These details are also described on the tire and loading information label.  $(\to P. 413)$ 




**⚠** WARNING

#### Overloading the vehicle

Do not overload the vehicle.

It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.

Toyota does not recommend towing a trailer with your vehicle. Toyota also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your vehicle is not designed for trailer towing or for the use of tow hitch mounted carriers.




4

Drivinc

# **Dinghy towing**

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.





■ To avoid serious damage to your vehicle

Do not tow your vehicle with four wheels on the ground.

# Engine (ignition) switch (vehicles without a smart key system)

#### Starting the engine

- 1 Check that the parking brake is set.
- 2 Check that the shift lever is in P.
- 3 Firmly depress the brake pedal.
- 4 Turn the engine switch to the "START" position and start the engine.

#### Changing the engine switch positions

1) "LOCK"

The steering wheel is locked and the key can be removed. (The key can be removed only when the shift lever is in P.)

(2) "ACC"

Some electrical components such as the audio system can be used.



All electrical components can be used.


(4) "START"

For starting the engine.

#### ■Turning the key from "ACC" to "LOCK"

- 1 Shift the shift lever to P.  $(\rightarrow P. 160)$
- 2 Push in the key and turn it to the "LOCK" position.





4


Driving

#### ■ If the engine does not start

The engine immobilizer system may not have been deactivated. ( $\rightarrow$ P. 67) Contact your Toyota dealer.

#### ■When the steering lock cannot be released

When starting the engine, the engine switch may seem stuck in the "LOCK" position. To free it, turn the key while turning the steering wheel slightly left and right.



#### ■ Key reminder function

A buzzer sounds if the driver's door is opened while the engine switch is in the "LOCK" or "ACC" position to remind you to remove the key.



#### When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

#### Caution when driving

Do not turn the engine switch to the "LOCK" position while driving. If, in an emergency, you must turn the engine off while the vehicle is moving, turn the engine switch only to the "ACC" position to stop the engine. An accident may result if the engine is stopped while driving.  $(\rightarrow P. 439)$ 

### **↑** NOTICE

#### ■To prevent battery discharge

Do not leave the engine switch in the "ACC" or "ON" position for long periods of time without the engine running.

#### When starting the engine

- Do not crank the engine for more than 30 seconds at a time. This may overheat the starter and wiring system.
- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by your Toyota dealer immediately.

# Engine (ignition) switch (vehicles with a smart key system)

Performing the following operations when carrying the electronic key on your person starts the engine or changes engine switch modes.

#### Starting the engine

- 1 Check that the parking brake is set.
- 2 Check that the shift lever is in P.
- 3 Firmly depress the brake pedal.

Messages indicating how to start the engine and how to turn to ACCES-SORY mode will be displayed alternately on the multi-information display.


4 Press the engine switch shortly and firmly.

When operating the engine switch, one short, firm press is enough. It is not necessary to press and hold the switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less.

Continue depressing the brake pedal until the engine is completely started.

The engine can be started from any engine switch mode.



#### Stopping the engine

- 1 Stop the vehicle.
- 2 Shift the shift lever to P.
- 3 Set the parking brake. (→P. 165)
- 4 Press the engine switch.

Driving-related data will be displayed on the multi-information display.

#### Changing engine switch modes

Modes can be changed by pressing the engine switch with the brake pedal released. (The mode changes each time the switch is pressed.)

#### Off\*


The emergency flashers can be used.

The multi-information display will not be displayed.

#### ACCESSORY mode

Some electrical components such as the audio system can be used.

A message indicating how to start the engine will be displayed on the multi-information display.



#### IGNITION ON mode

All electrical components can be used.

\*: If the shift lever is in a position other than P when turning off the engine, the engine switch will be turned to ACCESSORY mode, not to off.

# When stopping the engine with the shift lever in a position other than P

If the engine is stopped with the shift lever in a position other than P, the engine switch will not be turned off but instead be turned to ACCESSORY mode. Perform the following procedure to turn the switch off:

- 1 Check that the parking brake is set.
- 2 Shift the shift lever to P.
- 3 Check that "Turn Power OFF" is displayed on the multi-information display and then press the engine switch once.
- 4 Check that "Turn Power OFF" on the multi-information display is turned off.

#### ■ Auto power off function

If the vehicle is left in ACCESSORY mode for more than 20 minutes or IGNITION ON mode (the engine is not running) for more than an hour with the shift lever in P, the engine switch will automatically turn off. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the engine switch in ACCESSORY or IGNITION ON mode for long periods of time when the engine is not running.

#### ■ Electronic key battery depletion

→P. 96

#### ■ Conditions affecting operation

→P. 115

#### ■ Notes for the entry function

→P. 116

#### ■ If the engine does not start

- The engine immobilizer system may not have been deactivated. (→P. 67) Contact your Toyota dealer.
- Check that the shift lever is securely set in P. The engine may not start if the shift lever is displaced out of P.


#### ■ Steering lock

After turning the engine switch off and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the engine switch again automatically cancels the steering lock.

#### ■ When the steering lock cannot be released

A message informing the driver that the steering wheel is locked will be displayed on the multi-information display.

Check that the shift lever is set in P. Press the engine switch while turning the steering wheel left and right.



#### ■ Steering lock motor overheating prevention

To prevent the steering lock motor from overheating, the motor may be suspended if the engine is turned on and off repeatedly in a short period of time. In this case, refrain from operating the engine. After about 10 seconds, the steering lock motor will resume functioning.

# ■When a message requesting the smart key system be inspected is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

#### ■ If the electronic key battery is depleted

→P. 420

#### **■** Operation of the engine switch

- If the switch is not pressed shortly and firmly, the engine switch mode may not change or the engine may not start.
- If attempting to restart the engine immediately after turning the engine switch off, the engine may not start in some cases. After turning the engine switch off, wait a few seconds before restarting the engine.
- ■If the smart key system has been deactivated in a customized setting →P. 485



#### When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

#### Caution while driving

If engine failure occurs while the vehicle is moving, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.

#### Stopping the engine in an emergency

If you want to stop the engine in an emergency while driving the vehicle, press and hold the engine switch for more than 2 seconds, or press it briefly 3 times or more in succession.  $(\rightarrow P. 439)$ 

However, do not touch the engine switch while driving except in an emergency. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

#### ■To prevent battery discharge

- Do not leave the engine switch in ACCESSORY or IGNITION ON mode for long periods of time without the engine running.
- Do not stop the engine when the shift lever is in a position other than P. If the engine is stopped in another shift lever position, the engine switch will not be turned off but instead be turned to ACCESSORY mode. If the vehicle is left in ACCESSORY mode, battery discharge may occur.

#### When starting the engine

- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by your Toyota dealer immediately.

#### Symptoms indicating a malfunction with the engine switch


If the engine switch seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact your Toyota dealer immediately.

4

Driving

## **Automatic transmission**

#### Shifting the shift lever



Vehicles without a smart key system:

While the engine switch is in the "ON" position, move the shift lever with the brake pedal depressed.

Vehicles with a smart key system:

While the engine switch is in IGNITION ON mode, move the shift lever with the brake pedal depressed.

When shifting the shift lever between P and D, make sure that the vehicle is completely stopped.

### Shift position purpose

Shift position	Objective or function
Р	Parking the vehicle/starting the engine
R	Reversing
N	Neutral
D	Normal driving*1
S	S mode driving*2 (→P. 161)


- \*1: Shifting to the D position allows the system to select a gear suitable for the driving conditions. Setting the shift lever to the D position is recommended for normal driving.
- \*2: Selecting shift ranges using S mode restricts the upper limit of the possible gear ranges, controls engine braking force, and prevents upshifting above the selected range.

#### Changing shift ranges in S mode

When the shift lever is in the S position, the shift lever or paddle shift switches (if equipped) can be operated as follows:

▶ Shift lever

▶ Paddle shift switches (if equipped)





(1) Upshifting

(2) Downshifting

The initial shift range in S mode is set automatically to 4 or 5 according to vehicle speed. However, the initial shift range may be set to 3 if AI-SHIFT has operated while the shift lever was in the D position. (→P. 163)

#### ■ Shift ranges and their functions

- The vehicle is allowed to shift up and down to provide the most suitable gear selection based on your driving situation. (e.g. S4: 1 to 4 or, 4 to 1)
- You can choose from 6 levels of engine braking force.
   A lower shift range will provide greater engine braking force than a higher shift range, and the engine speed will also increase.
- You can choose the gear range you want for different levels of acceleration. (e.g. uphill, sporty driving, etc.)


# Selecting shift ranges in the D position (vehicles with paddle shift switches)

To drive using temporary shift range selection, operate the "-" paddle shift switch. The shift range can then be selected by operating the "-" and "+" paddle shift switches. Changing the shift range allows restriction of the highest gear, preventing upshifting and enabling the level of engine braking force to be selected.

- (1) Upshifting
- (2) Downshifting

The selected shift range, from 1 to 5, or D will be displayed in the meter.

To return to normal D position driving, the "+" paddle shift switch must be held down for a period of time.



When a shift range higher than 5 is selected, the shift range will return to the normal D position.

When the vehicle comes to a stop, the shift range will return to the normal D position.

#### S mode

- When the shift range is 4 or lower, holding the shift lever toward "+" sets the shift range to 6.
- To prevent the engine from over-revving, upshifting may automatically occur.
- To protect the automatic transmission, a function is adopted that automatically selects a higher shift range when the fluid temperature is high.

#### ■ Downshift restriction warning buzzer (S mode or paddle shifting)

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever or paddle shift switches are operated. (A buzzer will sound twice.)

#### ■When driving with cruise control or dynamic radar cruise control activated

When downshifting to 5 or 4 by shifting the shift lever to the S position or paddle shifting (if equipped), cruise control or dynamic radar cruise control will not be canceled. ( $\rightarrow$ P. 181, 186)

#### ■ If the shift lever cannot be shifted from P

→P. 484

#### ■If the S indicator does not come on or the D indicator is displayed even after shifting the shift lever to S

This may indicate a malfunction in the automatic transmission system. Have the vehicle inspected by your Toyota dealer immediately.

(In this situation, the transmission will operate in the same manner as when the shift lever is in D.)

#### ■ AI-SHIFT

AI-SHIFT automatically selects the suitable gear according to driver input and the driving situation.

AI-SHIFT automatically operates when the shift lever is in the D position. (Shifting the shift lever to the S position or paddle shifting cancels the func-



#### WARNING

#### When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.

### **Turn signal lever**

#### Operating instructions


- (1) Right turn
- 2 Lane change to the right (move the lever partway and release it)

The right hand signals will flash 3 times.

3 Lane change to the left (move the lever partway and release it)

The left hand signals will flash 3 times.

(4) Left turn



#### ■ Turn signals can be operated when

Vehicles without a smart key system:

The engine switch is in the "ON" position.

Vehicles with a smart key system:

The engine switch is in IGNITION ON mode.

#### ■If the indicator flashes faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out

# ■If the turn signals stop flashing before a lane change has been performed

Operate the lever again.

# ■ To discontinue flashing of the turn signals during a lane change Operate the lever in the opposite direction.


#### **■** Customization

The number of times the turn signals flash during a lane change can be changed. (Customizable features  $\rightarrow$ P. 529)

#### Operating instructions

To set the parking brake, fully depress the parking brake pedal with your left foot while depressing the brake pedal with your right foot.

(Depressing the pedal again releases the parking brake.)



#### ■ Parking brake engaged warning buzzer

→P. 446, 455

#### ■Usage in winter time

→P. 234



#### Before driving

Fully release the parking brake.

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

1

Driving


## **Headlight switch**

#### The headlights can be operated manually or automatically.

#### Operating instructions

Turning the end of the lever turns on the lights as follows:

(1) AUTO The headlights, daytime running lights ( $\rightarrow$ P. 167) and all the lights listed below turn on and off automatically. (Vehicles without a smart key system: When the engine switch is in the "ON" position) (Vehicles with a smart



- 2) =00= The side marker, parking, tail, license plate, daytime running lights (→P. 167) and instrument panel lights turn on.
- The headlights and all the lights listed above (except day-(3) time running lights) turn on.
- PRL \*1 The daytime running lights turn off.

IGNITION ON mode)


\*2 The daytime running lights turn on. ( $\rightarrow$ P. 167)

<sup>\*1:</sup> For U.S.A.

<sup>\*2:</sup> For Canada

#### Turning on the high beam headlights

- 1 With the headlights on, push the lever away from you to turn on the high beams.
  - Pull the lever toward you to the center position to turn the high beams off.
- Pull the lever toward you and release it to flash the high beams once.



You can flash the high beams with the headlights on or off.

#### ■ Daytime running light system

Vehicles with halogen daytime running lights:

To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically whenever the engine is started and the parking brake is released with the headlight switch in the "AUTO" position. (Illuminate darker than headlight high beams.) Daytime running lights are not designed for use at night.

Vehicles with LED daytime running lights:

To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically whenever the engine is started and the parking brake is released with the headlight switch in the "AUTO" position. (Illuminate brighter than parking lights.) Daytime running lights are not designed for use at night.


U.S.A.: Daytime running lights can be turned off by operating the switch. Canada: Daytime running lights are turned on even when the headlight switch is in **O** position.

Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve fuel economy.

#### ■ Headlight control sensor

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



#### ■ Automatic light off system

- ▶ Vehicles without a smart key system
- When the headlights are on: The headlights and tail lights turn off 30 seconds after the engine switch is turned to the "ACC" or "LOCK" position and a door is opened and closed. (The lights turn off immediately if on the key is pressed twice after all the doors are closed.)
- •When only the tail lights are on: The tail lights turn off automatically if the engine switch is turned to the "ACC" or "LOCK" position and the driver's door is opened.

To turn the lights on again, turn the engine switch to "ON" position, or turn the light switch off once and then back to 30% or 30%.

If any of the doors or trunk lid is kept open, the lights automatically turn off after 20 minutes.

- ▶ Vehicles with a smart key system
- When the headlights are on: The headlights and tail lights turn off 30 seconds after the engine switch is turned to ACCESSORY mode or turned off and a door is opened and closed. (The lights turn off immediately if on the key is pressed twice after all the doors are closed.)
- When only the tail lights are on: The tail lights turn off automatically if the engine switch is turned to ACCESSORY mode or turned off and the driver's door is opened.

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the light switch off once and then back to ⇒⊅♥ or ▮▷ . If any of the doors or trunk lid is kept open, the lights automatically turn off

#### ■ Automatic headlight leveling system (vehicles with LED headlights)

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

#### ■ Light reminder buzzer (except when the light switch is in AUTO )

Vehicles without a smart key system:

after 20 minutes.

A buzzer sounds when the engine switch is turned to the "LOCK" or "ACC" position and the driver's door is opened with the key removed from the engine switch while the lights are turned on.

Vehicles with a smart key system:

A buzzer sounds when the engine switch is turned off or turned to ACCES-SORY mode and the driver's door is opened while the lights are turned on.

#### ■ Battery-saving function

In the following conditions, the remaining lights will go off automatically after 20 minutes in order to prevent the vehicle battery from being discharged:

- The headlights and/or tail lights are on.
- Vehicles without a smart key system:

The engine switch is in the "ACC" or "LOCK" position.

Vehicles with a smart key system:

The engine switch is in ACCESSORY mode or turned off.

This function will be canceled in any of the following situations:

Vehicles without a smart key system:

When the engine switch is turned to the "ON" position.

Vehicles with a smart key system:

When the engine switch is turned to IGNITION ON mode.

- When the light switch is operated
- When a door or the trunk is opened or closed

#### **■** Customization

Settings (e.g. light sensor sensitivity) can be changed. (Customizable features: →P. 529)



NOTICE

#### ■To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running.

4


Driving

# **Automatic High Beam**\*

The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beam on or off as necessary.


#### Activating the Automatic High Beam system

1 Turn the headlight switch to AUTO .



2 Push the lever away from you.

The Automatic High Beam indicator will come on when the headlights are turned on automatically to indicate that the system is active.



### High beam automatic turning on or off conditions

When all of the following conditions are fulfilled, high beam will be automatically turned on:

- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few streetlights on the road ahead.


If any of the following conditions are fulfilled, high beam will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

### Turning the high beam on/off manually

#### ■ Switching to low beam


Pull the lever to the original position.



#### ■ Switching to high beam

Turn the light switch to ■

The Automatic High Beam indicator will turn off and the high beam indicator will turn on.



#### ■The Automatic High Beam can be operated when

The engine switch is in IGNITION ON mode.

#### ■ Camera sensor detection information

- High beam may not be automatically turned off in the following situations:
  - When oncoming vehicles suddenly appear from a curve
  - · When the vehicle is cut in front of by another
  - When oncoming or preceding vehicles are hidden from sight due to repeated curves, road dividers or roadside trees
  - · When oncoming vehicles appear from the faraway lane on wide road
  - · When oncoming or preceding vehicles have no lights
- High beam may be turned off if an oncoming vehicle that is using fog lights without using the headlights is detected.
- House lights, street lights, red traffic signals, and illuminated billboards or signs may cause the high beam to turn off.
- The following factors may affect the amount of time taken to turn high beam on or off:
  - The brightness of headlights, fog lights, and tail lights of oncoming and preceding vehicles
  - The movement and direction of oncoming and preceding vehicles
  - When a oncoming or preceding vehicle only has operational lights on one side
  - · When a oncoming or preceding vehicle is a two-wheeled vehicle
  - The condition of the road (gradient, curve, condition of the road surface etc.)
  - · The number of passengers and amount of luggage
- High beam may be turned on or off when unexpected by the driver.

- In the situations below, the system may not be able to correctly detect the surrounding brightness levels, and may flash or expose nearby pedestrians to the high beam. Therefore, you should consider turning the high beams on or off manually rather than relying on the Automatic High Beam system.
  - In bad weather (rain, snow, fog, sandstorms etc.)
  - The windshield is obscured by fog, mist, ice, dirt etc.
  - The windshield is cracked or damaged.
  - · The camera sensor is deformed or dirty.
  - The camera sensor temperature is extremely high.
  - Surrounding brightness levels are equal to those of headlights, tail lights or fog lights.
  - Vehicles ahead have headlights that are either switched off, dirty, are changing color, or are not aimed properly.
  - The inside rear view mirror or camera sensor is deformed or dirty.
  - When driving through an area of intermittently changing brightness and darkness.
  - When frequently and repeatedly driving ascending/descending roads, or roads with rough, bumpy or uneven surfaces (such as stone-paved roads, gravel tracks etc.).
  - When frequently and repeatedly taking curves or driving on a winding road
  - There is a highly reflective object ahead of the vehicle, such as a sign or a mirror.
  - The back of a vehicle ahead is highly reflective, such as a container on a truck.
  - · The vehicle's headlights are damaged or dirty.
  - The vehicle is listing or tilting, due to a flat tire, a trailer being towed etc.
  - The high beam and low beam are repeatedly being switched between in an abnormal manner.
  - The driver believes that the high beam may be causing problems or distress to other drivers or pedestrians nearby.

#### ■ Temporarily lowering sensor sensitivity

The sensitivity of the sensor can be temporarily lowered.

- 1 Turn the engine switch off while the following conditions are met.
  - The headlight switch is in AUTO .
  - The headlight switch lever is in high beam position.
- 2 Turn the engine switch to IGNITION ON mode.
- 3 Within 5 seconds after 2, repeat pulling the headlight switch lever to the original position then pushing it to the high beam position quickly 9 times, then leave the lever in high beam position.

Automatic High Beam (headlights) may turn on even the vehicle is stopped.

#### ■If a warning message for the Automatic High Beam is shown on the multi-information display

It may indicate a malfunction in the system. Contact your Toyota dealer.

#### ■ Customization

The Automatic High Beam can be deactivated. (Customizable features: →P. 529)

#### **MARNING**

#### Limitations of the Automatic High Beam


Do not rely on the Automatic High Beam. Always drive safely, taking care to observe your surroundings and turning high beam on or off manually if necessary.

#### **NOTICE**

#### Notes when using the Automatic High Beam system

Observe the following to ensure that the Automatic High Beam functions correctly.

- Do not touch the camera sensor.
- Do not subject the camera sensor to a strong impact.
- Do not disassemble the camera sensor.
- Do not spill liquid onto the camera sensor
- Do not apply window tinting or stickers to the camera sensor or the area of windshield near the camera sensor.



- Do not place items on the dashboard. There is a possibility that the camera sensor will mistake items reflected in the windshield for streetlights, the headlights of other vehicles, etc.
- Do not install a parking tag or any other accessories near or around the camera sensor.
- Do not overload the vehicle.
- Do not modify the vehicle.
- If the windshield needs to be replaced, contact your Toyota dealer.

4


Driving

# Windshield wipers and washer

#### Operating the wiper lever


The wiper operation is selected by moving the lever as follows. When intermittent windshield wiper operation is selected, the wiper interval can be also adjusted.

- 1 INT Intermittent windshield wiper operation
- 2 LO Low speed windshield wiper operation
- (3) HI High speed windshield wiper operation
- 4 MIST Temporary operation




Wiper intervals can be adjusted when intermittent operation is selected.

- (5) Increases the intermittent windshield wiper frequency
- 6 Decreases the intermittent windshield wiper frequency



#### (7) Washer/wiper dual operation

Wipers will automatically operate a couple of times after the washer squirts.



#### ■ The windshield wiper and washer can be operated when

Vehicles without a smart key system:

The engine switch is in the "ON" position.

Vehicles with a smart key system:

The engine switch is in IGNITION ON mode.

#### ■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the windshield washer fluid reservoir.



#### WARNING

#### Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.



#### **NOTICE**

#### ■When the windshield is dry

Do not use the wipers, as they may damage the windshield.

#### When the washer fluid tank is empty

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

#### When a nozzle becomes blocked

In this case, contact your Toyota dealer.

Do not try to clear it with a pin or other object. The nozzle will be damaged.

# Opening the fuel tank cap

#### Perform the following steps to open the fuel tank cap:

#### Before refueling the vehicle

- Close all the doors and windows, and turn the engine switch off.
- Confirm the type of fuel. ( $\rightarrow$ P. 507)

#### ■ Fuel types

→P. 507

#### ■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

#### **MARNING**

#### When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

- After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.
- Always hold the grips on the fuel tank cap and turn it slowly to remove it. A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel.
   Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.
   Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.

#### When refueling

Observe the following precautions to prevent fuel overflowing from the fuel tank:

- Securely insert the fuel nozzle into the fuel filler neck.
- Stop filling the tank after the fuel nozzle automatically clicks off.
- Do not top off the fuel tank.

## **MOTICE**


#### Refueling

Do not spill fuel during refueling.


Doing so may damage the vehicle, such as causing the emission control system to operate abnormally or damaging fuel system components or the vehicle's painted surface.

#### Opening the fuel tank cap

1 Pull up the opener to open the fuel filler door.




2 Turn the fuel tank cap slowly to remove it and hang it on the back of the fuel filler door.



#### Closing the fuel tank cap

After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.





#### **MARNING**


#### When replacing the fuel tank cap

Do not use anything but a genuine Toyota fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

# Summary of functions

Use the cruise control to maintain a set speed without depressing the accelerator pedal.

- 1 Display
- ② Indicators
- ③ Set speed
- 4 Cruise control switch



1

Drivino

\*: If equipped

### Setting the vehicle speed

1 Press the "ON-OFF" button to activate the cruise control.


Cruise control indicator will be displayed on the multi-information display.


Press the button again to deactivate the cruise control.

2 Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator and set speed will be displayed on the multi-information display.

The vehicle speed at the moment the lever is released becomes the set speed.






To change the set speed, operate the lever until the desired set speed is obtained.

- 1 Increases the speed
- (2) Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



The set speed will be increased or decreased as follows:

- · When the set speed is shown in "MPH"
  - Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated.

Large adjustment: The set speed can be increased or decreased continually until the lever is released.


- · When the set speed is shown in "km/h"
  - Fine adjustment: By approximately 0.6 mph (1 km/h) each time the lever is operated

Large adjustment: The set speed can be increased or decreased continually until the lever is released.

#### Canceling and resuming the constant speed control

- 1 Pulling the lever toward you cancels the constant speed control.
  - The speed setting is also canceled when the brakes are applied.
- 2 Pushing the lever up resumes the constant speed control.

Resuming is available when the vehicle speed is more than approximately 25 mph (40 km/h).



4

#### ■ Cruise control can be set when

- The shift lever is in D or range 4 or higher of S has been selected.
- Range 4 or higher of D has been selected by using the paddle shift.
   (vehicles with paddle shift switches)
- Vehicle speed is above approximately 25 mph (40 km/h).

#### ■ Accelerating after setting the vehicle speed

- The vehicle can be accelerated normally. After acceleration, the set speed resumes.
- Even without canceling the cruise control, the set speed can be increased by first accelerating the vehicle to the desired speed and then pushing the lever down to set the new speed.

#### ■ Automatic cruise control cancelation

Cruise control will stop maintaining the vehicle speed in any of the following situations:

- Actual vehicle speed falls more than approximately 10 mph (16 km/h) below the preset vehicle speed.
  - At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 25 mph (40 km/h).
- VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off by pressing the VSC OFF switch

# If a warning message for the cruise control is shown on the multi-information display

Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Toyota dealer.

### **▲** WARNING

#### ■ To avoid operating the cruise control by mistake

Switch the cruise control off using the "ON-OFF" button when not in use.

#### ■Situations unsuitable for cruise control

Do not use cruise control in any of the following situations. Doing so may result in loss of control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep hills


Vehicle speed may exceed the set speed when driving down a steep hill.

# Dynamic radar cruise control\*

# Summary of functions

Dynamic radar cruise control supplements conventional cruise control with a vehicle-to-vehicle distance control. In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates or decelerates in order to maintain a set following distance from vehicles ahead.

- 1 Vehicle-to-vehicle distance button
- (2) Indicators
- (3) Set speed
- (4) Display
- 5 Cruise control switch



# Setting the vehicle speed (vehicle-to-vehicle distance control mode)

1 Press the "ON-OFF" button to activate the cruise control.


Radar cruise control indicator will be displayed.


Press the button again to deactivate the cruise control.

2 Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator and set speed will be displayed.

The vehicle speed at the moment the lever is released becomes the set speed.





4


#### Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is displayed.

- 1) Increases the speed
- (2) Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



In the vehicle-to-vehicle distance control mode, the set speed will be increased or decreased as follows:

· When the set speed is shown in "MPH"

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated

Large adjustment: By approximately 5 mph (8 km/h) for each 0.6 seconds the lever is held

· When the set speed is shown in "km/h"

Fine adjustment: By approximately 0.6 mph (1 km/h) each time the lever is operated

Large adjustment: By approximately 3.1 mph (5 km/h) for each 0.6 seconds the lever is held

In the constant speed control mode ( $\rightarrow$ P. 192), the set speed will be increased or decreased as follows:

· When the set speed is shown in "MPH"

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated.

Large adjustment: The set speed can be increased or decreased continually until the lever is released.

· When the set speed is shown in "km/h"


Fine adjustment: By approximately 0.6 mph (1 km/h) each time the lever is operated

Large adjustment: The set speed can be increased or decreased continually until the lever is released. Pressing the button changes the vehicle-to-vehicle distance as follows:

- (1) Long
- (2) Medium
- (3) Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to IGNITION ON mode.

If a vehicle is running ahead of you, the preceding vehicle mark will also be displayed.



#### Vehicle-to-vehicle distance settings

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 50 mph (80 km/h). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

Distance options	Vehicle-to-vehicle distance
Long	Approximately 160 ft. (50 m)
Medium	Approximately 130 ft. (40 m)
Short	Approximately 100 ft. (30 m)


### Canceling and resuming the speed control

1 Pulling the lever toward you cancels the cruise control.

The speed setting is also canceled when the brakes are applied.

② Pushing the lever up resumes the cruise control and returns vehicle speed to the set speed.

Resuming is available when the vehicle speed is more than approximately 25 mph (40 km/h).




4

#### Driving in vehicle-to-vehicle distance control mode

This mode employs a radar sensor to detect the presence of vehicles up to approximately 400 ft. (120 m) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



1 Example of constant speed cruising When there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

② Example of deceleration cruising When the vehicle ahead is driving slower than the set speed

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

When following a vehicle driving slower than the set speed

The system continues follow-up cruising while adjusting for changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver.

(4) Example of acceleration

When there are no longer any vehicles ahead driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

### **Approach warning**

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

#### ■ Warnings may not occur when

In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle speed
- When the vehicle ahead is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- At the instant the accelerator is applied

4

#### Selecting conventional constant speed control mode


When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to dirt etc.

1) Press the "ON-OFF" button to activate the cruise control.

Press the button again to deactivate the cruise control.

Switch to constant speed control mode.

(Push the lever forward and hold for approximately 1 second.)



Constant speed control mode indicator will be displayed.

When in constant speed control mode, to return to vehicle-to-vehicle distance control mode, push the lever forward again and hold for approximately 1 second.

After the desired speed has been set, it is not possible to return to vehicle-to-vehicle distance control mode.

If the engine switch is turned off and then turned to IGNITION ON mode again, the vehicle will automatically return to vehicle-to-vehicle distance control mode.

Adjusting the speed setting:  $\rightarrow$ P. 188

Canceling and resuming the speed setting: →P. 189

#### ■ Dynamic radar cruise control can be set when

- The shift lever is in D or range 4 or higher of S has been selected.
- Range 4 or higher of D has been selected by using the paddle shift.
   (vehicles with paddle shift switches)
- Vehicle speed is above approximately 30 mph (50 km/h).

#### ■ Accelerating after setting the vehicle speed

The vehicle can accelerate normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

#### ■ Automatic cancelation of vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations:

- Actual vehicle speed falls below approximately 25 mph (40 km/h).
- VSC is activated.
- TRAC is activated for a period of time.
- •When the VSC or TRAC system is turned off by pressing the VSC OFF switch
- Pre-collision braking is activated.
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed (when the wiper switch is set to the high speed wiper operation position).

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact your Toyota dealer.

#### ■ Automatic cancelation of constant speed control


The cruise control will stop maintaining the vehicle speed in the following situations:

- Actual vehicle speed is more than approximately 10 mph (16 km/h) below the set vehicle speed.
  - At this time, the memorized set speed is not retained.
- Vehicle speed falls below approximately 25 mph (40 km/h).
- VSC is activated.
- TRAC is activated for a period of time.
- •When the VSC or TRAC system is turned off by pressing the VSC OFF switch
- Pre-collision braking is activated.

#### ■ Radar sensor and grille cover

Always keep the sensor and grille cover clean to ensure that the vehicle-to-vehicle distance control operates properly. (Some obstructions, such as snow, ice and plastic objects, cannot be detected by the obstruction sensor.) Dynamic radar cruise control is canceled if an obstruction is detected.

- 1 Grille cover
- (2) Radar sensor



#### ■ Operation guide display

When the dynamic radar cruise control switch is operated, a guidance display is shown on the multi-information display for a few seconds as to how to operate the dynamic radar cruise control switch or distance switch. ( $\rightarrow$ P. 84)

#### ■ Warning messages and buzzers for dynamic radar cruise control

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving.  $(\rightarrow P. 457)$ 

#### ■ Certification

▶ For vehicles sold in the U.S.A.

FCC ID: HYQDNMWR007

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### ▶ For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### WARNING

#### Before using dynamic radar cruise control

Do not overly rely on vehicle-to-vehicle distance control.

Be aware of the set speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc.

#### Cautions regarding the driving assist systems

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

- Assisting the driver to measure following distance The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings.
- Assisting the driver to judge proper following distance The dynamic radar cruise control determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is appropriate or not. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.
- Assisting the driver to operate the vehicle The dynamic radar cruise control has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

#### To avoid inadvertent cruise control activation

Switch the cruise control off using the "ON-OFF" button when not in use.

#### WARNING

#### Situations unsuitable for dynamic radar cruise control

Do not use dynamic radar cruise control in any of the following situations. Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- Roads where there are pedestrians, cyclers, etc.
- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep downhills, or where there are sudden changes between sharp up and down gradients

Vehicle speed may exceed the set speed when driving down a steep hill.


- At entrances to expressways and highways
- When weather conditions are bad enough that they may prevent the sensors from detecting correctly (fog, snow, sandstorm, heavy rain, etc.)
- When an approach warning buzzer is heard often

#### When the sensor may not be correctly detecting the vehicle ahead

In the case of the following and depending on the conditions, operate the brake pedal when deceleration of the system is insufficient or operate the accelerator pedal when acceleration is required.


As the sensor may not be able to correctly detect these types of vehicles, the approach warning ( $\rightarrow$ P. 191) will not be activated, which may lead to an accident resulting in death or serious injury.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving in the same lane
- Vehicles with small rear ends (trailers with no load on board etc.)



#### MARNING


- Motorcycles traveling in the same lane
- When water or snow thrown up by the surrounding vehicles hinders the detecting of the sensor
- When your vehicle is pointing upwards (caused by a heavy load in the trunk, etc.)




Conditions under which the vehicle-to-vehicle distance control mode may not function correctly

Operate the brake pedal (or accelerator pedal operation depending on the situation) as necessary in the following conditions as the radar sensor may not be able to correctly detect vehicles ahead, which may lead to an accident resulting in death or serious injury.

 When the road curves or when the lanes are narrow



 When steering wheel operation or your position in the lane is unstable



When the vehicle ahead of you decelerates suddenly

4

#### MARNING

#### Handling the radar sensor

Observe the following to ensure the dynamic radar cruise control system can function effectively.

Otherwise, the radar sensor may not detect correctly and could result in an accident.


- Keep the sensor and grille cover clean at all times. Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may become inaccurate or malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Toyota dealer.
- Do not disassemble the sensor.
- On one attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the radar sensor needs to be replaced, contact your Toyota dealer.

## Summary of function

While driving on a road that has lane markers, this system recognizes the lane markers using a camera as a sensor to alert the driver when the vehicle deviates from its lane.

If the system judges that the vehicle has deviated from its lane, it alerts the driver using a buzzer and indications on the multi-information display.

Camera sensor



4

Driving


# Turning the LDA system on

Press the LDA switch to activate the system.

The LDA indicator and lane lines will be displayed.

Press the switch again to turn the LDA system off.

The LDA system will remain on or off even if the engine switch is turned to IGNITION ON mode.



\*: If equipped

### Operating conditions

- When the vehicle speed is approximately 32 mph (50 km/h) or more
- When the lane width is more than approximately 8.2 ft. (2.5 m)
- When driving on a straight road or through a curve with a radius of more than approximately 328 ft. (100 m)

#### Indication on the multi-information display

When the inside of both lane lines turn white:

Indicates that both right and left lane markers are recognized.

If the vehicle deviates from the lane, the lane line on the side the vehicle has deviated from will flash.  $(\rightarrow P. 454)$ 

When the inside of either lane line turns white:

Indicates that the lane marker on the white-marked side is recognized.

If the vehicle deviates from the side of a lane with recognized lane markers, the lane line will flash.  $(\rightarrow P. 454)$ 

When the inside of both lane lines are black:

Indicates that no lane markers are recognized or the LDA system is temporarily canceled.







If any of the following occurs, the LDA system functions will be temporarily canceled. The functions will resume after the necessary operating conditions have returned.

- The turn signal lever is operated.
- The vehicle speed deviates from the operating range of the LDA system functions.
- When the lane lines cannot be recognized while driving.
- When the lane departure warning function is activated. The lane departure warning function will not operate again for a several seconds after it has been activated, even if the vehicle leaves the lane again.

#### ■ The lane departure warning

Depending on the audio system sound level or air conditioning fan noise while the audio system or air conditioning system is in use, it may be difficult to hear the warning sound.

#### ■ After the vehicle has been parked in the sun

The LDA system may not be available and a warning message ( $\rightarrow$ P. 457) will be displayed for a while after driving has started. When the temperature in the cabin decreases and the temperature around the camera sensor ( $\rightarrow$ P. 199) becomes suitable for its operation, the functions will begin to operate.

#### ■ If there are lane markers on only one side of the vehicle

The lane departure warning will not operate for the side on which lane markers could not be recognized.

4

#### ■ Conditions in which the function may not operate correctly

In the following situations, the camera sensor may be unable to recognize lane markers causing the lane departure warning function to operate incorrectly. However, this does not indicate a malfunction.

- When driving through an area with no lane markers, such as a tollbooth, a crossing or before a ticket checkpoint
- When driving on a sharp curve
- When lane markers are extremely narrow or extremely wide
- When the vehicle leans to one side an unusual amount due to a heavy load or improper tire inflation pressure
- When the following distance between your vehicle and the vehicle ahead is extremely short
- When the lane markers are yellow (These may be more difficult for the system to recognize compared to white markers.)
- When the lane markers are broken, Botts' dots (raised pavement markers) or stones
- When the lane markers are on a curb etc.
- When lane markers are obscured or partially obscured by sand, dirt, etc.
- When there are shadows on the road running parallel with lane markers, or if a shadow covers the lane markers
- When driving on a particularly bright road surface, such as concrete
- When driving on a road surface that is bright due to reflected light
- When driving in a location where the light level changes rapidly, such as the entrance to or exit from a tunnel
- When sunlight or the headlights of oncoming vehicles are shining directly into the camera lens
- When driving on roads that are branching or merging
- When driving on a road surface that is wet due to rain, previous rainfall, standing water, etc.
- When the vehicle experiences strong up-and-down motion such as when driving on an extremely rough road or on a seam in the pavement
- When headlight brightness at nighttime is reduced due to dirt on the lenses, or when the headlights are misaligned
- When driving on winding roads or roads that are uneven
- When driving on rough or unpaved roads

#### ■When changing the tires

Depending on the tires used, sufficient performance may not be maintainable.

#### ■ Warning messages for the LDA system

Warning messages are used to indicate a system malfunction or to inform the driver of the need for caution while driving.  $(\rightarrow P. 457)$ 

### **WARNING**

#### Before using the LDA system

Do not rely solely on the LDA system. The LDA system does not drive the vehicle automatically, nor does it reduce the amount of care you need to take. As such, the driver must always assume full responsibility for understanding his/her surroundings, for operating the steering wheel to correct the driving line, and for driving safely.

Inappropriate or negligent driving could lead to an accident.

#### To avoid operating the LDA by mistake

Switch the LDA system off using the LDA switch when not in use.

#### Situations unsuitable for LDA system

Do not use the LDA system in any of the following situations.

Otherwise, the system may not function correctly and could result in an accident.

- When driving with tire chains, a spare tire, or similar equipment
- When there are objects or structures along the roadside that might be misinterpreted as lane markers (such as guardrails, a curb, reflector posts, etc.)
- When driving on snowy roads
- When pavement lane markers are difficult to see due to rain, snow, fog, sand, dirt, etc.
- •When there are visible lines on the pavement from road repairs, or if the remains of old lane markers are still visible on the road
- When driving on a road with lane closures due to maintenance, or when driving in a temporary lane

# **NOTICE**


### ■To prevent damage to or incorrect operation of the LDA system

- Do not modify the headlights or attach stickers to the surface of the lights.
- Do not modify the suspension. If any suspension parts need to be replaced, contact Toyota dealer.
- Do not install or place anything on the hood or the grille. Also, do not install a grille guard (bull bars, kangaroo bar etc.).
- If your windshield needs repairs, contact your Toyota dealer.

#### Camera sensor

Observe the following to ensure that the LDA system functions correctly.

- Keep the windshield clean at all times.
   Performance could be affected if the windshield is dirty, or if raindrops, condensation or ice are adhering to the windshield.
- Do not attach a sticker or other items to the windshield near the camera sensor.



- Do not spill liquid onto the camera sensor
- Do not attach window tinting to the windshield.
- Do not install an antenna in front of the camera lens.
- If the windshield is fogged up, use the windshield defogger to remove fog from the windshield.
  - When it is cold, using the heater with air blowing to the feet may allow the upper part of the windshield to fog up. This will have a negative effect on the images.
- Do not scratch the camera lens, or let it get dirty. When cleaning the inside of the windshield, be careful not to get any glass cleaner etc. on the lens. Also, do not touch the lens. For lens repair, contact your Toyota dealer.
- Do not change the installation position or direction of the camera sensor or remove it. The direction of the camera sensor is precisely adjusted.
- Do not subject the camera sensor to strong impact or force, and do not disassemble the camera sensor.
- If the windshield needs to be replaced, contact your Toyota dealer.

# **Rear view monitor system**


The rear view monitor system assists the driver by displaying guide lines and an image of the view behind the vehicle while backing up, for example while parking.

The screen illustrations used in this text are intended as examples, and may differ from the image that is actually displayed on the screen.

Vehicles without a smart key system: The rear view image is displayed when the shift position is in R and the engine switch is in the "ON" position.

Vehicles with a smart key system: The rear view image is displayed when the shift position is in R and the engine switch is in IGNITION ON mode.


The rear view monitor system will be deactivated when the shift lever is in any position other than R.



4

### Using the rear view monitor system

#### ■ Screen description



1) Vehicle width guide lines

The line indicates a guide path when the vehicle is being backed straight up.

The displayed width is wider than the actual vehicle width.

(2) Vehicle center guide lines

These lines indicate the estimated vehicle center on the ground.

(3) Distance guide line

The line shows points approximately 1.5 ft. (0.5 m) (red) from the center of the edge of the bumper.

(4) Distance guide line


The line shows distance behind the vehicle, a point approximately 3 ft. (1 m) (blue) from the edge of the bumper.

#### ■ Area displayed on screen

The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle.

To adjust the image on the rear view monitor system screen.  $(\rightarrow P. 253)$ 


- The area displayed on the screen may vary according to vehicle orientation conditions.
- Objects which are close to either corner of the bumper or under the bumper cannot be seen on the screen.
- The camera uses a special lens.
   The distance of the image that appears on the screen differs from the actual distance.



 Items which are located higher than the camera may not be displayed by the monitor.

#### ■ Rear view monitor system camera

The camera for the rear view monitor system is located above the license plate.



#### Using the camera

If dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera, it cannot transmit a clear image. In this case, flush it with a large quantity of water and wipe the camera lens clean with a soft and wet cloth.

#### ■ Differences between the screen and the actual road


The distance guide lines and the vehicle width guide lines may not actually be parallel with the dividing lines of the parking space, even when they appear to be so. Be sure to check visually.

The distances between the vehicle width guide lines and the left and right dividing lines of the parking space may not be equal, even when they appear to be so. Be sure to check visually.

The distance guide lines give a distance guide for flat road surfaces. In any of the following situations, there is a margin of error between the fixed guide lines on the screen and the actual distance/course on the road.


When the ground behind the vehicle slopes up sharply

The distance guide lines will appear to be closer to the vehicle than the actual distance. Because of this, objects will appear to be farther away than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.




When the ground behind the vehicle slopes down sharply

The distance guide lines will appear to be further from the vehicle than the actual distance. Because of this, objects will appear to be closer than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.



When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the fixed guide lines on the screen and the actual distance/course on the road.




### ■ When approaching three-dimensional objects

The distance guide lines are displayed according to flat surfaced objects (such as the road). It is not possible to determine the position of three-dimensional objects (such as vehicles) using the distance guide lines. When approaching a three-dimensional object that extends outward (such as the flatbed of a truck), be careful of the following.

#### Distance guidelines

Visually check the surroundings and the area behind the vehicle. On the screen, it appears that a truck is parked at point ②. However, in reality if you back up to point ①, you will hit the truck. On the screen, it appears that ① is closest and ③ is furthest away. However, in reality, the distance to ① and ③ is the same, and ② is farther than ① and ③.




4

#### ■ Vehicle width guide lines

Visually check the surroundings and the area behind the vehicle. In the case shown below, the truck appears to be outside of the vehicle width guide lines and the vehicle does not look as if it hits the truck. However, the rear body of the truck may actually cross over the vehicle width guide lines. In reality if you back up as guided by the vehicle width guide lines, the vehicle may hit the truck.

Vehicle width guide lines



# Things you should know

# ■ If you notice any symptoms

If you notice any of the following symptoms, refer to the likely cause and the solution, and re-check.

If the symptom is not resolved by the solution, have the vehicle inspected by your Toyota dealer.

Likely cause	Solution
☐ The image is difficult to see	
<ul> <li>The vehicle is in a dark area</li> <li>The temperature around the lens is either high or low</li> <li>The outside temperature is low</li> <li>There are water droplets on the camera</li> <li>It is raining or humid</li> <li>Foreign matter (mud etc.) is adhering to the camera</li> <li>There are scratches on the camera</li> <li>Sunlight or headlights are shining directly into the camera</li> <li>The vehicle is under fluorescent lights, sodium lights, mercury lights etc.</li> </ul>	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings. (Use the monitor again once conditions have been improved.) To adjust the image on the rear view monitor system screen. (→P. 253)
☐ The image is blurry	
Dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera.	Flush the camera with a large quantity of water and wipe the camera lens clean with a soft and wet cloth.
☐ The image is out of alignment	
The camera or surrounding area has received a strong impact.	Have the vehicle inspected by your Toyota dealer.
☐ The fixed guide lines are very far out of alignment	
<ul> <li>The vehicle is tilted (there is a heavy load on the vehicle, tire pressure is low due to a tire puncture, etc.)</li> <li>The vehicle is used on an incline.</li> </ul>	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings.
The camera position is out of alignment.	Have the vehicle inspected by your Toyota dealer.

#### WARNING

#### When using the rear view monitor system

The rear view monitor system is a supplemental device intended to assist the driver when backing up. When backing up, be sure to check visually behind and all around the vehicle before proceeding.

Observe the following precautions to avoid an accident that could result in death or serious injuries.

- Never depend on the rear view monitor system entirely when backing up. The image and the position of the guide lines displayed on the screen may differ from the actual state.
  - Use caution, just as you would when backing up any vehicle.
- Be sure to back up slowly, depressing the brake pedal to control vehicle
- speed. The instructions given are only guidelines.

When and how much to turn the steering wheel will vary according to traffic conditions, road surface conditions, vehicle condition, etc. when parking. It is necessary to be fully aware of this before using the rear view monitor system.

- When parking, be sure to check that the parking space will accommodate your vehicle before maneuvering into it.
- Do not use the rear view monitor system in the following cases:
  - · On icy or slick road surfaces, or in snow
  - · When using tire chains or the compact spare tire
  - · When the trunk lid is not closed completely
  - On roads that are not flat or straight, such as curves or slopes.
- In low temperatures, the screen may darken or the image may become faint. The image could distort when the vehicle is moving, or you may become unable to see the image on the screen. Be sure to check direct visually and with the mirrors all around the vehicle before proceeding.
- If the tire sizes are changed, the position of the fixed guide lines displayed on the screen may change.
- The camera uses a special lens. The distances between objects and pedestrians that appear in the image displayed on the screen will differ from the actual distances. ( $\rightarrow$ P. 208)

# NOTICE

#### How to use the camera

- The rear view monitor system may not operate properly in the following cases.
  - If the back of the vehicle is hit, the position and mounting angle of the camera may change.
  - As the camera has a water proof construction, do not detach, disassemble or modify it. This may cause incorrect operation.
  - When cleaning the camera lens, flush the camera with a large quantity
    of water and wipe it with a soft and wet cloth. Strongly rubbing the camera lens may cause the camera lens to be scratched and unable to
    transmit a clear image.
  - Do not allow organic solvent, car wax, window cleaner or glass coat to adhere to the camera. If this happens, wipe it off as soon as possible.
  - If the temperature changes rapidly, such as when hot water is poured on the vehicle in cold weather, the system may not operate normally.
  - When washing the vehicle, do not apply intensive bursts of water to the camera or camera area. Doing so may result in the camera malfunctioning.
  - When the camera is used under fluorescent lights, sodium light or mercury light etc., the lights and the illuminated areas may appear to flicker.
- Do not expose the camera to strong impact as this could cause a malfunction. If this happens, have the vehicle inspected by your Toyota dealer as soon as possible.

4

# **Driving assist systems**

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

#### ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

#### **♦** Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

#### VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces

#### **◆ TRAC (Traction Control)**

Helps to maintain drive power and prevent the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

#### **◆** EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel


#### ◆ PCS (Pre-Collision System) (if equipped)

→P. 219

#### **♦** BSM (Blind Spot Monitor) (if equipped)

→P. 226

The slip indicator light will flash while the TRAC/VSC systems are operating.




## Disabling the TRAC system

If the vehicle gets stuck in mud, dirt or snow, the TRAC system may reduce power from the engine to the wheels. Pressing to turn the system off may make it easier for you to rock the vehicle in order to free it.

To turn the TRAC system off, quickly press and release .

The "TRAC OFF" and a message will be shown on the multi-information display.

Press again to turn the system back on.



4

#### ■ Turning off both TRAC and VSC systems

To turn the TRAC and VSC systems off, press and hold [3] for more than 3 seconds while the vehicle is stopped.

The VSC OFF indicator light will come on and the "TRAC OFF" and a message will be shown on the multi-information display\*.

Press 🖁 again to turn the systems back on.

- \*: On vehicles with pre-collision system, pre-collision brake assist and pre-collision braking will also be disabled. The pre-collision system warning light will come on and the message will be shown on the multi-information display. (→P. 222)
- ■When the message is displayed on the multi-information display showing that TRAC has been disabled even if has not been pressed TRAC cannot be operated. Contact your Toyota dealer.
- ■Sounds and vibrations caused by the ABS, brake assist, TRAC and VSC systems
  - A sound may be heard from the engine compartment when the brake pedal is depressed repeatedly, when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
  - · Vibrations may be felt through the vehicle body and steering.
  - · A motor sound may be heard after the vehicle comes to a stop.
  - The brake pedal may pulsate slightly after the ABS is activated.
  - The brake pedal may move down slightly after the ABS is activated.

#### **■ EPS operation sound**

When the steering wheel is operated, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

#### ■ Automatic reactivation of TRAC and VSC systems

After turning the TRAC and VSC systems off, the systems will be automatically re-enabled in the following situations:

- When the engine switch is turned off
- If only the TRAC system is turned off, the TRAC will turn on when vehicle speed increases
  - If both the TRAC and VSC systems are turned off, automatic re-enabling will not occur when vehicle speed increases

#### ■ Reduced effectiveness of the EPS system

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the engine off. The EPS system should return to normal within 10 minutes.



#### The ABS does not operate effectively when

- The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
- The vehicle hydroplanes while driving at high speed on wet or slick roads.

# Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations:

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or uneven surfaces

#### TRAC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRAC system is operating.

Drive the vehicle carefully in conditions where stability and power may be

#### When the VSC is activated

The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes.

#### When the TRAC/VSC systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help ensure vehicle stability and driving force, do not turn the TRAC/VSC systems off unless necessary.

#### MARNING

#### Replacing tires

Make sure that all tires are of the specified size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS, TRAC and VSC systems will not function correctly if different tires are installed on the vehicle.

Contact your Toyota dealer for further information when replacing tires or wheels.

#### Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause a system to malfunction.


## PCS (Pre-Collision System)\*

When the radar sensor detects possibility of a frontal collision, brakes are automatically engaged to lessen impact as well as vehicle damage.

The alert timing for the pre-collision system can be changed or turned on/off, as necessary, by operating the switch. ( $\rightarrow$ P. 220)

## Pre-collision warning

When a high possibility of a frontal collision is detected, a buzzer sounds and a message is shown on the multi-information display to urge the driver to take evasive action.



#### ◆ Pre-collision brake assist

When there is a high possibility of a frontal collision, the system applies greater braking force in relation to how strongly the brake pedal is depressed.

#### Pre-collision braking


When there is a high possibility of a frontal collision, the system warns the driver using warning display and buzzer. If the system determines that a collision is unavoidable, the brakes are automatically applied to reduce the collision speed.

## Changing the pre-collision system

#### ■ Changing the alert timing of the pre-collision system

Each time the PCS switch is pressed, the response to the distance changes as follows.

- 1) Far
- (2) Middle\*
- (3) Near
  - \*: Default setting




#### **■** Turning off the pre-collision system

Press the PCS switch for 3 or more seconds.


The PCS warning light turns on and a message is shown on the multi-information display.

To turn on the system, press the PCS switch again. The system is set to on each time the engine switch is turned to IGNITION ON mode.



## Radar sensor

The radar sensor detects vehicles or other obstacles on or near the road ahead and determines whether a collision is imminent based on the position, speed, and heading of the obstacles.



#### ■ The pre-collision system is operational when

The pre-collision system is on  $(\rightarrow P. 220)$  and the following conditions are met:

- Pre-collision warning:
  - Vehicle speed is greater than approximately 10 mph (15 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than approximately 7 mph (10 km/h).
- Pre-collision brake assist:
  - · The VSC is not turned off.
  - Vehicle speed is greater than approximately 19 mph (30 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than approximately 19 mph (30 km/h).
  - · The brake pedal is depressed.
- Pre-collision braking:
  - The VSC is not turned off.
  - Vehicle speed is greater than approximately 10 mph (15 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than approximately 7 mph (10 km/h).

## ■ Conditions that may trigger the system even if there is no possibility of a collision

In any of the following situations where the frontal area of the radar sensor is interrupted, the radar sensor may detect possibility of a frontal collision and the system may be activated.

- When passing by an oncoming vehicle in a curve or a turn to the right or the left
- When rapidly approaching an obstacle ahead (e.g.preceding vehicle, toll gate barrier, etc.)
- When there is a structural object (billboard, low ceiling, fluorescent light, etc.) above the uphill road ahead
- When driving on a narrow road or through under a low overhead structure (bridge, tunnel, fly-under, etc.)
- When driving on an uneven road surface
- When there is a metal object, bump, or protrusion on the road surface
- When vehicle's front part is raised or lowered depending on loading conditions
- When the direction of radar sensor is misaligned by strong impact applied on an area around the radar sensor, etc.
- When there is an obstacle (guard rail, etc.) by the roadside at the entrance to a curve
- When the front of your vehicle is pointing upwards (caused by putting a heavy load in the trunk etc.)

When the system is activated in the situations described above, there is also a possibility that the brakes may be applied with a force greater than normal.

#### ■ Obstacles not detected

The sensor cannot detect plastic obstacles such as traffic cones. There may also be occasions when the sensor cannot detect pedestrians, animals, bicycles, motorcycles, trees, or snowdrifts.

## ■Situations in which the pre-collision system does not function properly

The system may not function effectively in situations such as the following:

- On roads with sharp bends or uneven surfaces
- If a vehicle suddenly moves in front of your vehicle, such as at an intersection
- If a vehicle suddenly cuts in front of your vehicle, such as when overtaking
- In inclement weather such as heavy rain, fog, snow or sand storms
- When your vehicle is skidding with the VSC system off
- When an extreme change in vehicle height occurs
- When the radar sensor moves off position due to its surrounding area being subjected to a strong impact
- Due to greatly turning the wheel when an obstacle suddenly appears ahead

#### ■ Automatic cancelation of the pre-collision system

When a malfunction occurs due to sensor contamination, etc. that results in the sensors being unable to detect obstacles, the pre-collision system will be automatically disabled. In this case, the system will not activate even if there is a collision possibility.

# ■When there is a malfunction in the system, or if the system is temporarily unavailable

The PCS warning light flashes and a warning message is shown on the multi-information display. If a warning message is shown on the multi-information display, read the message and follow the instructions. (→P. 447, 458)

## ■ When the TRAC and VSC are turned off

- When the TRAC and VSC operations are turned off (→P. 216), the pre-collision brake assist and pre-collision braking are also turned off. However, the alert function operates.
- The PCS warning light turns on and a warning message is shown on the multi-information display. (→P. 447, 462)

▶ For vehicles sold in the U.S.A.

FCC ID: HYQDNMWR007

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

▶ For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

4

Driving

#### WARNING

#### Limitations of the pre-collision system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

Do not use the pre-collision system instead of normal braking operations under any circumstances. This system will not prevent collisions or lessen damage or injuries in all cases. Do not overly rely on this system. Failure to do so may cause an accident, resulting in death or serious injury.

This system has been designed to help avoid and reduce the impact of collisions.

However, the system operates differently depending on the situation ( $\rightarrow$ P. 221). As a result, the same level of performance may not be expected in all cases. Also, the pre-collision brakes may not operate if the driver is depressing the brake pedal or turning the steering wheel, as the system will determine such conditions as collision avoidance operations.

#### Handling the radar sensor

Observe the following to ensure the pre-collision system can function effec-

Otherwise, the system may not function correctly and could result in an

- Keep the sensor and grille cover clean at all times. Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may not work normally or malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Toyota dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the radar sensor needs to be replaced, contact your Toyota dealer.

#### WARNING

#### Cautions regarding the assist contents of the system

By means of alarms and brake control, the pre-collision system is intended to assist the driver in avoiding collisions through the process of LOOK-JUDGE-ACT. There are limits to the degree of assistance the system can provide, so please keep in mind the following important points.

- Assisting the driver in watching the road The pre-collision system is only able to detect obstacles directly in front of the vehicle, and only within a limited range. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for the driver to pay close attention to the vehicle's surroundings.
- Assisting the driver in making correct judgement When attempting to estimate the possibility of a collision, the only data available to the pre-collision system is that from obstacles it has detected directly in front of the vehicle. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of collision in any given situation.
- Assisting the driver in taking action The pre-collision system's braking assist feature is designed to help reduce the severity of a collision, and so only acts when the system has judged that a collision is unavoidable. This system is not capable of automatically avoiding a collision or bringing the vehicle to a stop safely without appropriate operations performed by the driver. For this reason, when encountering a dangerous situation the driver must take direct and immediate action in order to ensure the safety of all involved.

## **BSM** (Blind Spot Monitor)\*

#### Summary of the Blind Spot Monitor

The Blind Spot Monitor is a system that has 2 functions;


● The Blind Spot Monitor function

Assists the driver in making the decision when changing lanes

● The Rear Cross Traffic Alert function

Assists the driver when backing up

These functions use same sensors.



### (1) BSM main switch

Pressing the switch turns the system on or off. When the switch is set to on, the switch's indicator illuminates and the buzzer sounds. Common switch for Blind Spot Monitor function and Rear Cross Traffic Alert function

#### (2) Outside rear view mirror indicators

#### Blind Spot Monitor function:

When a vehicle is detected in the blind spot, the outside rear view mirror indicator comes on while the turn signal lever is not operated and the outside rear view mirror indicator flashes while the turn signal lever is operated.

#### Rear Cross Traffic Alert function:

When a vehicle approaching from the right or left rear of the vehicle is detected, the outside rear view mirror indicators flash.

\*: If equipped

When a vehicle approaching from the right or left rear of the vehicle is detected, a buzzer sounds from behind the rear seat.

#### ■ The outside rear view mirror indicators visibility

When under strong sunlight, the outside rear view mirror indicator may be difficult to see.

#### ■ Rear Cross Traffic Alert buzzer hearing

Rear Cross Traffic Alert function may be difficult to hear over loud noises such as high audio volume.

#### ■When there is a malfunction in the Blind Spot Monitor

If a system malfunction is detected due to any of the following reasons, warning message will be displayed:  $(\rightarrow P. 457, 458)$ 

- There is a malfunction with the sensors
- The sensors have become dirty
- The outside temperature is extremely high or low
- The sensor voltage has become abnormal

#### ■ Certification for the Blind Spot Monitor

▶ For vehicles sold in the U.S.A.

FCC ID: OAYSRR2A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference.
- (2)This device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

▶ For vehicles sold in Canada

Applicable law: Canada 310

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1)this device may not cause interference, and
- (2)this device must accept any interference, including interference that may cause undesired operation of the device.

Frequency bands: 24.05-24.25 GHz Output power: less than 20 milliwatts

4

Driving

#### MARNING

#### Handling the radar sensor

One Blind Spot Monitor sensor is installed inside the left and right side of the vehicle rear bumper respectively. Observe the following to ensure the Blind Spot Monitor can function correctly.

Keep the sensor and its surrounding area on the bumper clean at all times.



- Do not subject the sensor or surrounding area on the bumper to a strong impact. If the sensor moves even slightly off position, the system may malfunction and vehicles that enter the detection area may not be detected. If the sensor or surrounding area is subject to a strong impact, always have the area inspected by your Toyota dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor or surrounding area on the bumper.
- Do not modify the sensor or surrounding area on the bumper.
- Do not paint the rear bumper any color other than an official Toyota color.

The Blind Spot Monitor function uses radar sensors to detect vehicles that are traveling in an adjacent lane in the area that is not reflected in the outside rear view mirror (the blind spot), and advises the driver of the vehicles existence via the outside rear view mirror indicator.


### The Blind Spot Monitor function detection areas

The areas that vehicles can be detected in are outlined below.

The range of the detection area extends to:

- 1 Approximately 11.5 ft. (3.5 m) from the side of the vehicle

  The first 1.6 ft. (0.5 m) from the side of the vehicle is not in the detection area
- 2 Approximately 9.8 ft. (3 m) from the rear bumper
- ③ Approximately 3.3 ft. (1 m) forward of the rear bumper



4

Driving

## **MARNING**

#### Cautions regarding the use of the system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Blind Spot Monitor function is a supplementary function which alerts the driver that a vehicle is present in the blind spot. Do not overly rely on the Blind Spot Monitor function. The function cannot judge if it is safe to change lanes, therefore over reliance could cause an accident resulting in death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

#### ■ The Blind Spot Monitor function is operational when

- The BSM main switch is set to on
- Vehicle speed is greater than approximately 10 mph (16 km/h).

#### ■ The Blind Spot Monitor function will detect a vehicle when

- A vehicle in an adjacent lane overtakes your vehicle.
- Another vehicle enters the detection area when it changes lanes.

## ■ Conditions under which the Blind Spot Monitor function will not detect a vehicle

The Blind Spot Monitor function is not designed to detect the following types of vehicles and/or objects:


- Small motorcycles, bicycles, pedestrians etc.\*
- Vehicles traveling in the opposite direction
- Guardrails, walls, signs, parked vehicles and similar stationary objects\*
- Following vehicles that are in the same lane\*
- Vehicles driving 2 lanes across from your vehicle\*
- \*: Depending on the conditions, detection of a vehicle and/or object may occur.

# ■ Conditions under which the Blind Spot Monitor function may not function correctly

- The Blind Spot Monitor function may not detect vehicles correctly in the following conditions:
  - During bad weather such as heavy rain, fog, snow etc.
  - · When ice or mud etc. is attached to the rear bumper
  - When driving on a road surface that is wet due to rain, standing water etc.
  - When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area
  - When a vehicle is in the detection area from a stop and remains in the detection area as your vehicle accelerates
  - When driving up or down consecutive steep inclines, such as hills, a dip in the road etc.
  - When multiple vehicles approach with only a small gap between each vehicle
  - When vehicle lanes are wide, and the vehicle in the next lane is too far away from your vehicle
  - When the vehicle that enters the detection area is traveling at about the same speed as your vehicle
  - When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
  - · Directly after the BSM main switch is set to on
- Instances of the Blind Spot Monitor function unnecessarily detecting a vehicle and/or object may increase under the following conditions:
  - When there is only a short distance between your vehicle and a guardrail, wall etc.
  - When there is only a short distance between your vehicle and a following vehicle
  - When vehicle lanes are narrow and a vehicle driving 2 lanes across from your vehicle enters the detection area
  - When items such as a bicycle carrier are installed on the rear of the vehicle

#### The Rear Cross Traffic Alert function

The Rear Cross Traffic Alert functions when your vehicle is in reverse. It can detect other vehicles approaching from the right or left rear of the vehicle. It uses radar sensors to alert the driver of the other vehicle's existence through flashing the outside rear view mirror indicators and sounding a buzzer.



1) Approaching vehicles

2 Detection areas

## **MARNING**

#### Cautions regarding the use of the system


The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Rear Cross Traffic Alert function is only an assist and is not a replacement for careful driving. Driver must be careful when backing up, even when using Rear Cross Traffic Alert function. The driver's own visual confirmation of behind you and your vehicle is necessary and be sure there are no pedestrians, other vehicles etc. before backing up. Failure to do so could cause death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

#### The Rear Cross Traffic Alert function detection areas

The areas that vehicles can be detected in are outlined below.



To give the driver a more consistent time to react, the buzzer can alert for faster vehicles from farther away.

#### Example:

Approaching vehicle	Speed	1) Approximate alert distance
Fast	18 mph (28 km/h)	65 ft. (20 m)
Slow	5 mph (8 km/h)	18 ft. (5.5 m)

#### ■ The Rear Cross Traffic Alert function is operational when

- The BSM main switch is set to on.
- The shift lever is in R.
- Vehicle speed is less than approximately 5 mph (8 km/h).
- Approaching vehicle speed is between approximately 5 mph (8 km/h) and 18 mph (28 km/h).

# ■ Conditions under which the Rear Cross Traffic Alert function will not detect a vehicle


The Rear Cross Traffic Alert function is not designed to detect the following types of vehicles and/or objects.

- Small motorcycles, bicycles, pedestrians etc.\*
- Vehicles approaching from directly behind
- Guardrails, walls, signs, parked vehicles and similar stationary objects\*
- Vehicles moving away from your vehicle
- Vehicles approaching from the parking spaces next to your vehicle\*
- Vehicles backing up in the parking space next to your vehicle\*
- \*: Depending on the conditions, detection of a vehicle and/or object may occur.

# ■ Conditions under which the Rear Cross Traffic Alert function may not function correctly

The Rear Cross Traffic Alert function may not detect vehicles correctly in the following conditions:

- When ice or mud etc. is attached to the rear bumper
- During bad weather such as heavy rain, fog, snow etc.
- When multiple vehicles approach continuously
- Shallow angle parking
- When a vehicle is approaching at high speed
- When parking on a steep incline, such as hills, a dip in the road etc.
- Directly after the BSM main switch is set to on
- Directly after the engine is started with the BSM main switch on
- Vehicles that the sensors cannot detect because of obstacles



4

Driving

## Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

#### **Preparation for winter**

- Use fluids that are appropriate to the prevailing outside temperatures.
  - Engine oil
  - · Engine coolant
  - · Washer fluid
- Have a service technician inspect the condition of the battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires.

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

#### Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen.
   Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.

## When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

#### When parking the vehicle

Park the vehicle and move the shift lever to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

### Selecting tire chains


Use the correct tire chain size when mounting the snow chains. Chain size is regulated for each tire size.

#### Side chain:

- (1) 0.12 in. (3 mm) in diameter
- 2 0.39 in. (10 mm) in width
- (3) 1.18 in. (30 mm) in length

#### Cross chain:

- (4) 0.16 in. (4 mm) in diameter
- (5) 0.55 in. (14 mm) in width
- (6) 0.98 in. (25 mm) in length



## Regulations on the use of tire chains

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

## ■Tire chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location.
- Install tire chains on the front tires. Do not install tire chains on the rear tires.
- Install tire chains on front tires as tightly as possible. Retighten chains after driving 1/4 — 1/2 mile (0.5 — 1.0 km).
- Install tire chains following the instructions provided with the tire chains.

#### WARNING

#### Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the size specified.
- Maintain the recommended level of air pressure.
- Do not drive in excess of 75 mph (120 km/h), regardless of the type of snow tires being used.
- Use snow tires on all, not just some wheels.

#### Driving with tire chains

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 30 mph (50 km/h), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.
- Vehicles with LDA (Lane Departure Alert) system: Do not use LDA (Lane Departure Alert) system.



#### ♠ NOTICE

#### Repairing or replacing snow tires

Request repairs or replacement of snow tires from Toyota dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

#### Fitting tire chains

The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

5

## Audio system

5-1.	Basic Operations
	Audio system types 240
	Audio system 242
	Steering wheel audio
	switches 244
	USB port/AUX port 245
	Basic audio operations 247
5-2.	Setup
	Setup menu
	General settings 250
	Audio settings 252
	Display settings 253
	Voice settings 254
5-3.	Using the Multimedia
	system
	Selecting the audio
	source 255
	List screen operation 256
	Optimal use of the
	multimedia system 258
5-4.	
	Radio operation 259
5-5.	Playing an audio CD and MP3/WMA/AAC discs
	CD player operation 261

## 5


## Audio system

5-6.	Using an external device
	Listening to an iPod 267
	Listening to a USB
	memory device271
	Using the AUX port 275
5-7.	Connecting Bluetooth®
	Preparations to use
	wireless
	communication276
	Registering a Bluetooth®
	audio player for
	the first time 280
	Registering a Bluetooth <sup>®</sup>
	phone for the
	first time 281
	Registering a Bluetooth®
	device
	Connecting a Bluetooth®
	device
	Displaying a Bluetooth®
	device details
	Detailed Bluetooth®
	system settings 287

5-8.	Bluetooth <sup>®</sup> Audio		
	Listening to Bluetooth®		
	Audio	288	
5-9.	Bluetooth <sup>®</sup> phone		
	Using a Bluetooth <sup>®</sup> Phone	289	
	Making a call		
	Receiving a call		
	Speaking on the phone		
	Bluetooth <sup>®</sup> phone	293	
	message function	298	
	Using the steering		
	wheel switches	301	
	Bluetooth® phone		
	settings	302	
	Contact/Call History		
	Settings	303	
	What to do if		
	(Troubleshooting)	311	
5-10. Bluetooth <sup>®</sup>			
	Bluetooth <sup>®</sup>	315	
5-11. Using the voice			
command system			
	Voice command		
	svstem	320	


## **Audio system types**

## ► Entune Audio




## ▶ Entune Audio Plus

Owners of this system should refer to the "NAVIGATION AND MULTI-MEDIA SYSTEM OWNER'S MANUAL".



## ► Entune Premium Audio


Owners of this system should refer to the "NAVIGATION AND MULTI-MEDIA SYSTEM OWNER'S MANUAL".



## Audio system\*

Operations such as listening to audio, using the hands-free phone and changing multimedia system settings are started by using the following buttons.

#### Audio system operation buttons



- ① "AUDIO" button
  Display the "Select Audio Source" screen or audio top screen.
  (→P. 255)
- ② "CAR" button

  Press this button to access the fuel consumption screen. (→P. 87)
- ③ "SETUP" button Press this button to customize the function settings. (→P. 249)

Audio system

### Operating the touch screen

By touching the screen with your finger, you can control the multimedia system, etc.

## ■ Drag\*

Touch the screen with your finger, and move the screen to the desired position.

Scrolling the lists

#### ■ Flick\*

Touch the screen with your finger and quickly move the screen by flicking your finger.

- Scrolling the main screen page
- \*: The above operations may not be performed on all screens.

#### ■When using the touch screen

- If the screen is cold, the display may be dark, or the system may seem to be operating slightly slower than normal.
- The screen may seem dark and hard to see when viewed through sunglasses. Change your angle of viewing, adjust the display on the "Display Settings" screen (→P. 253) or remove your sunglasses.
- Flick operations may not be performed smoothly in high altitudes.



#### To avoid damaging the touch screen

- To prevent damaging the screen, lightly touch the screen buttons with your finger.
- Do not use objects other than your finger to touch the screen.
- Wipe off fingerprints using a glass cleaning cloth. Do not use chemical cleaners to clean the screen, as they may damage the touch screen.

## Steering wheel audio switches

Some audio features can be controlled using the switches on the steering wheel.

Operation may differ depending on the type of multimedia system or navigation system. For details, refer to the manual provided with the multimedia system or navigation system.

# Operating the multimedia system using the steering wheel switches

- (1) Volume switch
  - Increases/decreases volume
  - Press and hold: Continuously increases/decreases volume
- (2) Back switch
  - Returns to the previous screen






- Moves cursor
- Press and hold: Seek up/down (radio stations)
- Fast up/down (tracks/files)
- (4) Enter switch
  - · Displays the preset/list screen
  - · Selects items
- (5) "MODE/HOLD" switch
  - · Changes audio source
  - Press and hold this switch to mute or pause the current operation
     To cancel the mute or pause, press and hold.



#### To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.



Audio system


## **USB** port/AUX port

Connect an iPod, USB memory device or portable audio player to the USB/AUX port as indicated below. Select "iPod", "USB" or "AUX" on the audio source selection screen and the device can be operated via multimedia system.


### Connecting using the USB/AUX port

## ■ iPod

1 Push the lid.



Open the cover and connect an iPod using an iPod cable. Turn on the power of the iPod if it is not turned on.



#### ■ USB memory device

- 1 Push the lid.
- 2 Open the cover and connect the USB memory device.

  Turn on the power of the USB memory device if it is not turned on.

## ■ Portable audio player

- 1 Push the lid.
- 2 Open the cover and connect the portable audio player.

  Turn on the power of the portable audio player if it is not turned on.



## **MARNING**


## While driving

Do not connect a device or operate the device controls.

## **Basic audio operations**

Basic audio operations and functions common to each mode are explained in this section.

## Operating the multimedia system



- 1) Press: Turns the multimedia system on and off. Turn: Adjusts the volume.
- (2) Ejects a disc.
- (3) Disc slot
- (4) Pauses or resumes playing music.
- (5) Turn: Selects radio station bands, tracks and files. Selects items in the list display.
- (6) Seeks up or down for a radio station. Accesses a desired track or file.

### Random playback

Select range on/off.

#### Repeat play

Select to change on/off.

#### ■Using cellular phones

Interference may be heard through the multimedia system's speakers if a cellular phone is being used inside or close to the vehicle while the multimedia system is operating.

## **WARNING**

#### Laser product

This product is a class 1 laser product.

Do not open the cover of the player or attempt to repair the unit yourself. Refer servicing to qualified personnel.

#### Laser products

- Do not take this unit apart or attempt to make any changes yourself. This is an intricate unit that uses a laser pickup to retrieve information from the surface of compact discs. The laser is carefully shielded so that its rays remain inside the cabinet. Therefore, never try to disassemble the player or alter any of its parts since you may be exposed to laser rays and dangerous voltages.
- This product utilizes a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. THE USE OF OPTICAL INSTRUMENTS WITH THIS PRODUCT WILL INCREASE EYE HAZARD.



#### **NOTICE**

#### To prevent battery discharge

Do not leave the multimedia system on longer than necessary when the engine is off.

#### To avoid damaging the multimedia system

Take care not to spill drinks or other fluids on the multimedia system.


## Setup menu

You can adjust the multimedia system to your desired settings.

## Display "Setup" screen

Press the "SETUP" button to display the "Setup" screen.

- Select to adjust the settings for operation sounds, screen animation, etc. (→P. 250)
- ② Select to set the voice settings.(→P. 254)
- ③ Select to adjust the settings for contrast and brightness of the screen. (→P. 253)




- ④ Select to adjust the settings for registering, removing, connecting and disconnecting Bluetooth<sup>®</sup> devices. (→P. 287)
- (5) Select to adjust the settings for phone sound, contact, etc. (→P. 303)
- (6) Select to set audio settings. ( $\rightarrow$ P. 252)
- (7) Select to turn the screen off.
- (8) Select to set the vehicle customization ( $\rightarrow$ P. 523).

## **General settings**

Settings are available for adjusting the operation sounds, screen animation, etc.

### Screen for general settings

- 1 Press the "SETUP" button.
- Select "General" on the "Setup" screen.
  - 1) Select to adjust the clock.
  - ② "English", "Français" or "Español" can be selected.
  - ③ On/off can be selected to sound beeps.
  - (4) Select to change the screen color.
  - (5) Select to change the keyboard layout.



- (6) The animation effect for the screen can be set to on/off.
- (7) Select to delete personal data ( $\rightarrow$ P. 251)
- Select to update program versions. For details, contact your Toyota dealer.
- (9) Select to display the software information. Notices related to third party software used in this product are enlisted. (This includes instructions for obtaining such software, where applicable.)

#### ■ To return to the default volume settings

Select "Default", and then "Yes".

## Delete personal data

- 1 Select "Delete Personal Data" on the "General Settings" screen.
- 2 Select "Delete".

Check carefully beforehand, as data cannot be retrieved once deleted.

3 A confirmation screen will be displayed. Select "Yes".

The following personal data will be deleted or changed to its default settings.

- General settings
- Audio settings
- Phone settings

## **Audio settings**

Settings are available for adjusting the radio operation, cover art, etc.

## Screen for audio settings

- 1 Press the "SETUP" button.
- 2 Select "Audio" on the "Setup" screen.
  - 1 Number of Radio Presets Select the number of radio preset stations.
  - ② Display Cover Art on/off
  - ③ Automatic Sound Levelizer (→P. 252)



## Automatic sound leveliser (ASL)

- 1 Select "Automatic Sound Levelizer".
- 2 Select "High", "Mid", "Low" or "Off".

### ■ About Automatic Sound Leveliser (ASL)

ASL automatically adjusts the volume and tone quality according to the vehicle speed.

### **Display settings**

Settings are available for adjusting the contrast and brightness of the screen.

#### Screen for display settings

- 1 Press the "SETUP" button.
- 2 Select "Display" on the "Setup" screen.
  - Adjust screen contrast/brightness
  - 2 Adjust screen contrast/brightness of the rear view monitor camera
  - (3) Changes to day mode.



#### Adjusting the screen contrast/brightness

- 1 Select "General" on the "Display Settings" screen.
- 2 Adjust the display as desired by selecting "+" or "-".

#### Day mode

When the headlights are turned on, the screen dims.

However, the screen can be switched to day mode by selecting "Day Mode".

The screen will stay in day mode when the headlights are turned on until "Day Mode" is selected again.

## **Voice settings**

## This screen is used for guidance for voice command systems setting.

- 1 Adjust the voice guidance volume setting.
- ② Set the voice recognition prompts "High", "Low" or "Off".
- ③ Set the train voice recognition.
- ④ Set the voice prompt interrupt on/off.
- (5) Set the voice recognition tutorial.



 $\blacksquare$  To return to the default volume settings

Select "Default", and then "Yes".

Switching between audio sources such as radio and CD are explained in this section.

#### Changing audio source

1 Press the "AUDIO" button to display the audio source selection screen.

If the audio source selection screen is not displayed, press the "AUDIO" button again.

- 2 Select the desired audio source.
  - 1 Select the desired audio source then or to reorder.



Using the steering wheel switches to change audio source

The audio source changes as follows each time the "MODE/HOLD" switch is pressed.

5

Audio syster


#### **List screen operation**

When a list screen is displayed, use the appropriate buttons to scroll through the list.

#### How to scroll

- Select to scroll to the next or previous page.

Turn the "TUNE/SCROLL" knob to move the cursor box to select a desired item from the list, and press the "TUNE/SCROLL" knob to play it. The track that is being played is highlighted.



To return to the top screen, select "Now Playing" on the list screen.

#### Selecting, fast-forwarding and reversing tracks/files/songs

#### ■ Selecting a track/file/song

Press the "\" or "\" button on "SEEK/TRACK" or turn the "TUNE/ SCROLL" knob to select the desired track/file/song number.

To fast-forward or reverse, press and hold the " $\wedge$ " or " $\vee$ " button on "SEEK/TRACK".

- 1 Select "Browse" or cover art.
- 2 Select the desired track/file/song.



When an MP3/WMA/AAC disc or USB memory device is being used, the folder can be selected. When a Bluetooth  $^{\circledR}$  device or iPod is being used, the album can be selected.

According to the audio device, the following is displayed.

Audio source	List name		
Audio CD	Track		
MP3/WMA/AAC disc	Folder, File		
Bluetooth®	Album, Track		
USB	Artists, Albums, Songs, Genres, Composers		
iPod	Artists, Albums, Songs, Genres, Composers, Audiobooks, Videos		

5


Audio system

## Optimal use of the multimedia system

On the "Sound Settings" screen, sound quality (Treble/Mid/Bass), volume balance can be adjusted.

#### How to adjust the sound settings and sound quality

- 1 2 3 Select "-" or "+" to adjust the treble, mid or bass to a level between -5 and 5.
- (4) (5) Select "Front" or "Rear" to adjust the front/rear audio balance.
- 6 7 Select "L" or "R" to adjust the left/right audio balance.



#### ■ The sound quality level is adjusted individually

The treble, mid and bass levels can be adjusted for each audio mode separately.


## **Radio operation**

Select "AM" or "FM" on the audio source selection screen to begin listening to the radio.

#### Audio control screen

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

- 1 Audio source selection screen appears
- (2) Preset stations
- 3 Select to display RBDS text messages\*
- (4) Scanning for receivable station
- Select to display a list of receivable stations
- (6) Setting the sound (→P. 258)
- \*: FM only



#### Selecting a station

Tune in to the desired station using one of the following methods.

#### ■ Seek tuning

Press the "\" or "\" button on "SEEK/TRACK".

The radio will begin seeking up or down for a station of the nearest frequency and will stop when a station is found.

#### ■ Manual tuning

Turn the "TUNE/SCROLL" knob.

#### ■ Preset stations

Select the desired preset station.

#### Setting station presets

- Search for desired stations by turning the "TUNE/SCROLL" knob or pressing the "∧" or "∨" button on "SEEK/TRACK".
- 2 Select "(add new)".
  - To change the preset station to a different one, select and hold the preset station.
- 3 Select "Yes".
- 4 Select "OK" after setting the new preset station.

#### ■ Refreshing the station list

1 Select "Refresh" on the "Station List" screen. To cancel the refresh, select "Cancel Refresh".

#### ■ Reception sensitivity

- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- The radio antenna is mounted inside the rear window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear window.

## CD player operation

Insert disc or select "CD" on the audio source selection screen with a disc inserted to begin listening to a CD.

#### Audio control screen

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

1) Audio source selection screen appears



- 2 Displaying the track/file list
  - ► MP3/WMA/AAC

Displaying the folder list

- (3) Random playback (→P. 247)
- (4) Repeat play (→P. 247)
- 5 Pause Select to resume play
- $\bigcirc$  Setting the sound ( $\rightarrow$ P. 258)

5

Audio syster

#### ■ Displaying the title and artist name

If a CD-TEXT disc is inserted, the title of the disc and track will be displayed.

#### **■**Error messages

If an error message is displayed, refer to the following table and take the appropriate measures. If the problem is not rectified, take the vehicle to your Toyota dealer.

Message	Cause	Correction procedures
"Check DISC"	<ul> <li>The disc is dirty or damaged.</li> <li>The disc is inserted upside down.</li> <li>The disc is not playable with the player.</li> </ul>	<ul> <li>Clean the disc.</li> <li>Insert the disc correctly.</li> <li>Confirm the disc is playable with the player.</li> </ul>
"Disc Error"	There is a malfunction within the system.	Eject the disc.
"No music files found."	No playable data is included on the disc.	Eject the disc.

#### ■ Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.









CDs with copy-protection features may not play correctly.

#### ■CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected.

## ■ If a disc is left inside the CD player or in the ejected position for extended periods

Disc may be damaged and may not play properly.

#### ■Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

#### ■ MP3, WMA and AAC files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

AAC is short for Advanced Audio Coding and refers to an audio compression technology standard used with MPEG2 and MPEG4.

MP3, WMA and AAC file and media/formats compatibility are limited.

- MP3 file compatibility
  - Compatible standards

MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)

 Compatible sampling frequencies MPEG1 LAYER3: 32, 44.1, 48 (kHz)

MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)

Compatible bit rates (compatible with VBR)

MPEG1 LAYER3: 32-320 (kbps) MPEG2 LSF LAYER3: 8-160 (kbps)

- Compatible channel modes: stereo, joint stereo, dual channel and monaural
- WMA file compatibility
  - · Compatible standards

WMA Ver. 7, 8, 9 (only compatible with Windows Media Audio Standard)

- Compatible sampling frequencies 32, 44.1, 48 (kHz)
- Compatible bit rates (only compatible with 2-channel playback)
   Ver. 7, 8: CBR 48-192 (kbps)

Ver. 9: CBR 48-320 (kbps)

- AAC file compatibility
  - · Compatible standards

MPEG4/AAC-LC

- Compatible sampling frequencies 11.025/12/16/22.05/24/32/44.1/48 (kHz)
- Compatible bit rates 16-320 (kbps)

Compatible channel modes: 1ch and 2ch

Compatible media

Media that can be used for MP3, WMA and AAC playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible if the CD-R or CD-RW is not finalized. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

#### Compatible disc formats

The following disc formats can be used.

• Disc formats: CD-ROM Mode 1 and Mode 2

CD-ROM XA Mode 2, Form 1 and Form 2

• File formats: ISO9660 Level 1, Level 2, (Romeo, Joliet)

UDF (2.01 or lower)

MP3, WMA and AAC files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows.

- Maximum directory hierarchy: 8 levels (including the root)
- · Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- · Maximum number of files per disc: 255
- File names

The only files that can be recognized as MP3/WMA/AAC and played are those with the extension .mp3, .wma or .m4a.

Discs containing multi-session recordings

As the multimedia system is compatible with multi session discs, it is possible to play discs that contain MP3, WMA and AAC files. However, only the first session can be played.

ID3, WMA and AAC tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

AAC tags can be added to AAC files, making it possible to record the track title and artist name in the same way as with ID3 tags.

MP3, WMA and AAC playback

When a disc containing MP3, WMA or AAC files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3, WMA or AAC file is played. To make the file check finish more quickly, we recommend you do not write any files to the disc other than MP3, WMA or AAC files or create any unnecessary folders.

Discs that contain a mixture of music data and MP3, WMA or AAC format data cannot be played.

#### Extensions

If the file extensions .mp3, .wma and .m4a are used for files other than MP3, WMA and AAC files, they may be mistakenly recognized and played as MP3, WMA and AAC files. This may result in large amounts of interference and damage to the speakers.

#### Playback


- To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3, WMA and AAC files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- When files other than MP3, WMA or AAC files are recorded on a disc, it
  may take more time to recognize the disc and in some cases, playback
  may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.



#### Discs and adapters that cannot be used

Do not use the following types of CDs.

Also, do not use 3 in. (8 cm) CD adapters, Dual Discs or printable discs. Doing so may damage the CD player and/or the CD insert/eject function.



- Discs that have a diameter that is not 4.7 in. (12 cm).
- Low-quality or deformed discs.
- Discs with a transparent or translucent recording area.
- Discs that have tape, stickers or CD-R labels attached to them, or that have had the label peeled off.

#### Player precautions

Failure to follow the precautions below may result in damage to the discs or the player itself.

- Do not insert anything other than discs into the disc slot.
- Do not apply oil to the player.
- Store discs away from direct sunlight.
- Never try to disassemble any part of the player.

Connecting an iPod enables you to enjoy music from the vehicle speakers.

Select "iPod" on the audio source selection screen.

When the iPod connected to the system includes iPod video, the system can only output the sound by selecting the browse screen.

#### Connecting an iPod

→P. 245

#### Audio control screen

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

- 1) Audio source selection screen appears
- (2) Displays cover art
- ③ Selecting the play mode (→P. 267)
- (4) Shuffle play (→P. 267)
- (5) Repeat play (→P. 267)
- 6 Pause
  Select to resume playback
- (7) Setting the sound ( $\rightarrow$ P. 258)



5

Audio system

#### Selecting a play mode

- 1 Select "Browse" on the screen.
- 2 Select the desired play mode. Then select a song to begin using the selected play mode.

#### Shuffle play

Select to change on/off.

#### Repeat play

Select to change on/off.

#### ■ About iPod



- "Made for iPod", "Made for iPhone" and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod or iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone or iPad may affect wireless performance.
- •iPad, iPhone, iPod, iPod classic, iPod nano, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. Lightning is a trademark of Apple Inc.

#### **■iPod cover art**

- Depending on the iPod and songs in the iPod, iPod cover art may be displayed.
- This function can be changed to on/off. ( $\rightarrow$ P. 252)
- It may take time to display iPod cover art, and the iPod may not be operated while the cover art display is in process.
- Only iPod cover art that is saved in JPEG format can be displayed.

#### ■iPod functions

- When an iPod is connected and the audio source is changed to iPod mode, the iPod will resume play from the same point in which it was last used.
- Depending on the iPod that is connected to the system, certain functions may not be available. If a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it may resolve the problem.
- •While connected to the system, the iPod cannot be operated with its own controls. It is necessary to use the controls of the vehicle's multimedia system instead.
- When the battery level of an iPod is very low, the iPod may not operate. If so, charge the iPod before use.
- Compatible models (→P. 270)

#### **■iPod problems**

To resolve most problems encountered when using your iPod, disconnect your iPod from the vehicle iPod connection and reset it. For instructions on how to reset your iPod, refer to your iPod Owner's Manual.

#### **■** Error messages

Message	Cause/Correction procedures	
"Connection error. Please consult your Owner's Manual for instructions on how to connect the iPod."	This indicates a problem in the iPod or its connection.	
"No music files found."	This indicates that there is no music data in the iPod.	
"No videos found."	This indicates that no video files are included in the iPod.	
"There are no songs available for playback. Please add compatible files to your iPod."	This indicates that songs are not found in a	
"iPod authorization unsuccessful."	This indicates that the display multimedia system failed to authorize the iPod. Please check your iPod.	

#### ■ Compatible models

The following iPod  $^{\rm @}$ , iPod nano  $^{\rm @}$ , iPod classic  $^{\rm @}$ , iPod touch  $^{\rm @}$  and iPhone  $^{\rm @}$ devices can be used with this system.

- iPod touch (5th generation)
- iPod touch (4th generation)
- iPod touch (3rd generation)
- iPod touch (2nd generation)
- iPod touch (1st generation)
- · iPod classic
- · iPod with video
- iPod nano (7th generation)
- iPod nano (6th generation)
- iPod nano (5th generation)
- iPod nano (4th generation)
- iPod nano (3rd generation)
- iPod nano (2nd generation)
- iPod nano (1st generation)
- · iPhone 5s
- · iPhone 5c
- iPhone 5
- · iPhone 4S
- iPhone 4
- · iPhone 3GS
- · iPhone 3G
- iPhone

Depending on differences between models or software versions etc., some models might be incompatible with this system.



#### ♠ WARNING

#### While driving

Do not connect an iPod or operate the controls.



#### **NOTICE**

#### ■ To prevent damage to the iPod or its terminals

- Do not leave the iPod in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the iPod.
- Do not push down on or apply unnecessary pressure to the iPod while it is connected.
- Do not insert foreign objects into the port.

Connecting a USB memory device enables you to enjoy music from the vehicle speakers.

Touch "USB" on the audio source selection screen.

#### Connecting a USB memory device

→P. 245

#### Audio control screen

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

- 1) Audio source selection screen appears
- (2) Displays cover art
- (3) Displaying the folder list
- (4) Random playback (→P. 247)
- (5) Repeat play (→P. 247)
- 6 Pause Select to resume playback
- (7) Setting the sound ( $\rightarrow$ P. 258)



5

Audio system

#### Selecting a play mode

- 1 Select "Browse" on the screen.
- 2 Select the desired play mode. Then select a song to begin using the selected play mode.
- Displaying the now playing list

Touch the cover art display.

#### **■USB** memory functions

- Depending on the USB memory device that is connected to the system, the device itself may not be operable and certain functions may not be available. If the device is inoperable or a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it may resolve the problem.
- If the USB memory device still does not begin operation after being disconnected and reconnected, format the memory.

#### **■**Error messages for USB memory

Message	Cause/Correction procedures	
"Connection error. Please consult your Owner's Manual for instructions on how to connect the USB device."	This indicates a problem with the USB memory device or its connection.	
"There are no files available for playback. Please add compatible files to your USB device."	This indicates that no MP3/WMA/AAC files are included on the USB memory device.	

#### **■USB** memory

Compatible devices

USB memory device that can be used for MP3, WMA and AAC playback.

Compatible device formats

The following device format can be used:

- USB communication format: USB2.0 HS (480 Mbps) and FS (12 Mbps)
- File system format: FAT16/32 (Windows)
- Correspondence class: Mass storage class MP3, WMA and AAC files written to a device with any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- · Maximum directory hierarchy: 8 levels
- Maximum number of folders in a device: 3000 (including the root)
- · Maximum number of files in a device: 9999
- Maximum number of files per folder: 255
- MP3. WMA and AAC files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format. This format compresses audio data to a size smaller than that of the MP3 format.

AAC is short for Advanced Audio Coding and refers to an audio compression technology standard used with MPEG2 and MPEG4.

MP3, WMA and AAC file and media/formats compatibility are limited.

#### MP3 file compatibility

- · Compatible standards
  - MP3 (MPEG1 AUDIO LAYERII, III, MPEG2 AUDIO LAYERII, III)
- · Compatible sampling frequencies
  - MPEG1 AUDIO LAYERII, III: 32, 44.1, 48 (kHz)
  - MPEG2 AUDIO LAYERII, III: 16, 22.05, 24 (kHz)
- Compatible bit rates (compatible with VBR) MPEG1 AUDIO LAYERII, III: 32-320 (kbps)
  - MPEG2 AUDIO LAYERII, III: 8-160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural
- WMA file compatibility
  - Compatible standards WMA Ver. 7, 8, 9
  - Compatible sampling frequencies HIGH PROFILE 32, 44.1, 48 (kHz)
  - Compatible bit rates HIGH PROFILE 48-320 (kbps, VBR)
- AAC file compatibility
  - Compatible standards MPEG4/AAC-LC
  - Compatible sampling frequencies 11.025/12/16/22.05/24/32/44.1/48 (kHz)
  - Compatible bit rates 16-320 (kbps)
  - · Compatible channel modes: 1 ch and 2 ch
- File names

The only files that can be recognized as MP3/WMA/AAC and played are those with the extension .mp3, .wma or .m4a.

ID3, WMA and AAC tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

AAC tags can be added to AAC files, making it possible to record the track title and artist name in the same way as with ID3 tags.

#### MP3, WMA and AAC playback

- When a device containing MP3, WMA and AAC files is connected, all files in the USB memory device are checked. Once the file check is finished, the first MP3, WMA and AAC file is played. To make the file check finish more quickly, we recommend that you do not include any files other than MP3, WMA and AAC files or create any unnecessary folders.
- When a USB memory device is connected and the audio source is changed to USB memory mode, the USB memory device will start playing the first file in the first folder. If the same device is removed and reconnected (and the con- tents have not been changed), the USB memory device will resume play from the same point in which it was last used.

#### Extensions

If the file extensions .mp3, .wma and .m4a are used for files other than MP3, WMA and AAC files, they will be skipped (not played).

#### Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- There is a wide variety of freeware and other encoding software for MP3, WMA and AAC files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.



#### While driving

Do not connect a USB memory device or operate the device controls.



#### ■To prevent damage to the USB memory device or its terminals

- Do not leave the USB memory device in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the USB memory device.
- Do not push down on or apply unnecessary pressure to the USB memory device while it is connected.
- Do not insert foreign objects into the port.

To use the AUX port, connect a portable player, press the "AUDIO" button, then select "AUX" to display the audio control screen.

#### Connecting a portable audio player

→P. 245

- Operating portable audio players connected to the multimedia system

  The volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio player itself.
- ■When using a portable audio player connected to the power outlet

  Noise may occur during playback. Use the power source of the portable audio player.



#### While driving

Do not connect a portable audio player or operate the device controls.

5

Audio system

# **Preparations to use wireless communication**

The following can be performed using Bluetooth  $^{\! @}\!$  wireless communication:

- A portable audio player can be operated and listened to via multimedia system
- Hands-free phone calls can be made via a cellular phone In order to use wireless communication, register and connect a Bluetooth® device by performing the following procedures.

#### ■ About Bluetooth®

Bluetooth is a registered trademark of Bluetooth SIG, Inc.



#### ■ Certifications for the Bluetooth<sup>®</sup>

FCC ID: BABFT0049B FCC ID: AJDK068

CAUTION: Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 20cm and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

- · Co-location: This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- ●IC: 2024B-FT0049B IC: 775E-K068
  - · This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- CAUTION: Radio Frequency Radiation Exposure

This equipment complies with IC radiation exposure limits set forth for uncontrolled equipment and meets RSS-102 of the IC radio frequency (RF) Exposure rules.

This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE).

But it is desirable that it should be installed and operated with at least 20cm and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

#### Device registration/connection flow

 Register the Bluetooth<sup>®</sup> device to be used with multimedia system (→P. 280, 281, 282)



 Connect the Bluetooth<sup>®</sup> device to be used (→P. 284)

To be used for audio



To be used for hands-free phone



Start Bluetooth<sup>®</sup> connection (→P. 284)



3. Start Bluetooth<sup>®</sup> connection (→P. 284)



4. Check connection status (→P. 288)



4. Check connection status (→P. 290)




5. Use Bluetooth<sup>®</sup> audio (→P. 288)

5. Use Bluetooth<sup>®</sup> phone (→P. 289)

To display the screen shown below, press the "SETUP" button and select "Bluetooth\*" on the "Setup" screen.

- Select to connect the device to be used with multimedia system. (→P. 284)
- ② Select to register a Bluetooth<sup>®</sup> device to be used with multimedia system. (→P. 282)
- ③ Select to set detailed Bluetooth<sup>®</sup> system settings. (→P. 287)



- (4) Select to delete registered devices. (→P. 283)
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

5

Audio syster

# Registering a Bluetooth<sup>®</sup> audio player for the first time

To use the Bluetooth  $^{\mbox{\scriptsize B}}$  Audio, it is necessary to register an audio player with the system.

Once the player has been registered, it is possible to use the Bluetooth<sup>®</sup> Audio.

For details about registering a Bluetooth<sup>®</sup> device (→P. 282)

- 1 Turn the Bluetooth® connection setting of your audio player on.
- 2 Press the "AUDIO" button.
- 3 Select " Audio".
- 4 Select "Select Device".
- 5 Follow the steps in "How to registering a Bluetooth® device" from step 2. ( $\rightarrow$ P. 282)

To use the hands-free system, it is necessary to register a  $\mathsf{Bluetooth}^{\mathsf{B}}$  phone with the system.

Once the phone has been registered, it is possible to use the hands-free system.

For details about registering a Bluetooth<sup>®</sup> device (→P. 282)

- 1 Turn the Bluetooth® connection setting of your cellular phone on.
- 2 Press the " 📞 " button.
- 3 Select "OK" to register a phone.
- [4] Follow the steps in "How to registering a Bluetooth® device" from step  $\boxed{3}$ . ( $\rightarrow$ P. 282)

5

Audio syster

## Registering a Bluetooth® device

Bluetooth<sup>®</sup> compatible phones (HFP) and portable audio players (AVP) can be registered simultaneously. You can register up to 5 Bluetooth<sup>®</sup> devices.

#### How to registering a Bluetooth® device

- 1 Display the "Bluetooth\* Setup" screen. (→P. 279)
- 2 Select "Add".
- 3 When this screen is displayed, search for the device name displayed on this screen on the screen of your Bluetooth® device.

For details about operating the Bluetooth<sup>®</sup> device, see the manual that comes with it.

To cancel the registration, select "Cancel".



- [4] Register the Bluetooth<sup>®</sup> device using your Bluetooth<sup>®</sup> device.
  - A PIN-code is not required for SSP (Secure Simple Pairing) compatible Bluetooth devices. Depending on the type of Bluetooth device being connected, a message confirming registration may be displayed on the Bluetooth device's screen. Respond and operate the Bluetooth device according to the confirmation message.
- 5 Check that this screen is displayed when registration is complete.



<sup>\*:</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

If an error message is displayed, follow the guidance on the screen to try again.

Registration can be performed from screens other than the "Bluetooth\* Setup" screen.

#### ■ When registering from the "Bluetooth\* Audio" screen

- 1 Display the "Bluetooth\* Audio" screen. (→P. 255)
- 2 Select "Select Device".
- 3 Follow the steps in "How to registering a Bluetooth<sup>®</sup> device" from step 2. (→P. 282)
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

### Deleting a Bluetooth<sup>®</sup> device

- 1 Display the "Bluetooth\* Setup" screen. (→P. 279)
- 2 Select "Remove".
- 3 Select the desired device.
- 4 A confirmation message will be displayed, select "Yes" to delete the device.
- 5 Check that a confirmation screen is displayed when the operation is complete.
  - \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

## Connecting a Bluetooth<sup>®</sup> device

Up to 5 Bluetooth<sup>®</sup> devices (Phones [HFP] and audio players [AVP]) can be registered.


If more than 1 Bluetooth<sup>®</sup> device has been registered, select which device to connect to.

- 1 Press the "SETUP" button.
- 2 Select "Bluetooth\*".
- 3 Select the device to be connected.

Supported profile icons will be displayed.

- 1 Phone
- (2) Audio player

Supported profile icons for currently connected devices will illuminate.



Dimmed icons can be selected to connect to the function directly.

#### **Auto connection**

To turn auto connection mode on, set "Bluetooth\* Power" to on.  $(\rightarrow P. 287)$ 

When you register a phone, auto connection will be activated. Always set it to this mode and leave the Bluetooth<sup>®</sup> phone in a place where a connection can be established.

When the engine switch is turned to the "ACC" or "ON" position (vehicles without a smart key system) or ACCESSORY or IGNITION ON mode (vehicles with a smart key system), the system will search for a nearby cellular phone you have registered.

Next, the system automatically connects with the most recent of the phones connected to in the past. Then, the connection result is displayed.

<sup>\*:</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

<sup>\*:</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

When auto connection has failed or "Bluetooth\* Power" is turned off, you must connect the Bluetooth® device manually.

- Follow the steps in "Connecting a Bluetooth® device" from step 1.
   (→P. 284)
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### Connecting a Bluetooth<sup>®</sup> audio player

- ▶ Registering an additional device
- 1 Select "Select Device" on the Bluetooth® audio control screen.
- 2 For more information: →P. 282
- ▶ Selecting a registered device
- 1 Select "Select Device" on the Bluetooth® audio control screen.
- 2 For more information: →P. 284

#### ■ Reconnecting a Bluetooth® phone

If the system cannot connect due to poor signal strength with the engine switch in the "ACC" or "ON" position (vehicles without a smart key system) or ACCESSORY or IGNITION ON mode (vehicles with a smart key system), the system will automatically attempt to reconnect.

If the system is attempting to connect to a Bluetooth  $^{\circledR}$  phone and the Bluetooth  $^{\circledR}$  phone is turned off and then back on, the system will attempt to reconnect.

5

Audio system

## Displaying a Bluetooth<sup>®</sup> device details

You can confirm and change the registered device details.

#### Bluetooth<sup>®</sup> device registration status

- 1 Display the "Bluetooth\* Setup" screen. (→P. 279)
- 2 Select the device.
- 3 Select "Device Info".
- The following screen is displayed:
  - 1 Device Name
  - ② Change connection method (→P. 286)
  - (3) Bluetooth<sup>®</sup> Address
  - 4 Display your telephone number

The number may not be displayed depending on the model of phone.

- (5) Compatibility profile of the device
- (6) Restore default settings

#### Changing connection method

- 1 Select "Connect Audio Player from".
- 2 Select "Vehicle" or "Device".

"Vehicle": Connect the multimedia system to the portable audio player.

"Device": Connect the portable audio player to the multimedia system.



<sup>\*:</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

## Detailed Bluetooth® system settings

You can confirm and change the detailed Bluetooth® settings.

#### How to check and change detailed Bluetooth® settings

- 1 Display the "Bluetooth\* Setup" screen. (→P. 279)
- 2 Select "System Settings".
- 3 The following screen is displayed:
  - Bluetooth\* Power on/off
     You can change Bluetooth\*
     function on/off.
  - (2) Bluetooth\* Name
  - (3) Change PIN-code (→P. 287)
  - (4) Bluetooth\* Address
  - (5) Display Phone Status

You can set the system to show the status confirmation display when connecting a telephone.

(6) Display Audio Player Status

You can set the system to show the status confirmation display when connecting an audio player.

- (7) Compatibility profile of the system
- (8) Restore default settings
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### Editing the Bluetooth\* PIN

You can change the PIN-code that is used to register your Bluetooth<sup>®</sup> devices in the system.

- 1 Select "Bluetooth\* PIN".
- 2 Input a PIN-code, and select "OK".
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.



Э

## Listening to Bluetooth® Audio

The Bluetooth<sup>®</sup> audio system enables the user to enjoy music played on a portable player from the vehicle speakers via wireless communication.

When a Bluetooth<sup>®</sup> device cannot be connected, check the connection status on the "Bluetooth\* Audio" screen. If the device is not connected, either register or reconnect the device. (→P. 284)

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### Status display

You can check such indicators as signal strength and battery charge on the screen.

- (1) Connection status
- (2) Battery charge



Indicators	Conditions		
Connection status	Good ←	*	Not connected
Battery charge	Full ←		→ Empty
	İ		Ò

#### Playing Bluetooth<sup>®</sup> audio

Select or II to Play/Pause.

For details on "Bluetooth\* Audio" screen operation methods, refer to Basic Audio Operations. (→P. 247)

For details on how to select a track or album, refer to selecting, fast-forwarding and reversing tracks/files/songs. (→P. 257)

<sup>\*:</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Audio system

## Using a Bluetooth<sup>®</sup> Phone

The hands-free system is a function that allows you to use your cellular phone without touching it.

This system supports  $Bluetooth^{\otimes}$ .  $Bluetooth^{\otimes}$  is a wireless data system that allows the cellular phone to wirelessly connect to the hands-free system and make/receive calls.

Before making a phone call, check the connection status, battery charge, call area and signal strength. ( $\rightarrow$ P. 290)

If a Bluetooth<sup>®</sup> device cannot be connected, check the connection status on the phone screen. If the device is not connected, either register or reconnect it. ( $\rightarrow$ P. 284)

## Phone screen

Several functions are available to operate on each screen that is displayed by selecting the 4 tabs.

- 1) Device name
- (2) Bluetooth® connection status




## ■ Telephone switch (→P. 301)

## **■** Microphone

The vehicle's built in microphone is used when talking on the phone.

The person you are speaking to can be heard from the front speakers.



To use the hands-free system, you must register your Bluetooth<sup>®</sup> phone in the system. ( $\rightarrow$ P. 282)

## Status display

You can check indicators such as signal strength and battery charge on the phone screen.

- (1) Connection status
- 2 Signal strength
- (3) Battery charge



Indicators	Conditions		
Connection status	Good	Poor	Not connected
	* -	→ 🔻 ←	<b>→</b>
Battery charge	Full		Empty
	<b>i</b> ←		<b>→</b> []
Call area	"Rm": Roaming area		
Signal strength	Excellent		Poor
	<b>₩</b>		h   <b> </b>

Once a Bluetooth® phone is registered, you can make a call using the following procedure:

### Dialing

- 1 Display the phone screen. (→P. 289)
- Select the "Dial Pad" tab and enter a phone number. To delete the input phone number, select For the first digit, you can enter "+" by selecting "\*" for a while.
- Press the switch on the steering wheel or select ...

## Dialing from the contacts list

You can dial a number from the contact data imported from your cellular phone. The system has one contact for each registered phone. Up to 2500 contacts may be stored in each contact. (→P. 305)

- 1 Display the phone screen. (→P. 289)
- 2 Select "Contacts" tab.
- 3 Choose the desired contact to call from the list.
- 4 Choose the number and then press the « switch on the steering wheel or select &

#### When the contact is empty

You can transfer the phone numbers in a Bluetooth® phone to the sys-

Operation methods differ between PBAP (Phone Book Access Profile) compatible and PBAP incompatible Bluetooth® phones. If the cellular phone does not support either PBAP or OPP (Object Push Profile) service, you cannot transfer contacts.

- 1 Press the switch on the steering wheel.

  If the phonebook is empty, a message will be displayed.
- ▶ For a PBAP compatible Bluetooth<sup>®</sup> phone and "Automatic Transfer" is off
- 2 Select the desired item.
  - Select to transfer new contacts from a cellular phone, select "Always" and then enable "Automatic Transfer".
  - Select to transfer all the contacts from a connected cellular phone only once.





► For PBAP incompatible but OPP compatible Bluetooth<sup>®</sup> phones

2 Select the desired item.

- 1 Select to transfer the contacts from the connected cellular phone.
- ② Select to add a new contact manually.
- (3) Select to cancel transferring.



- ▶ When "Transfer" is selected
- 3 Follow the steps in "Update contacts from phone" from step 2. (→P. 304)
- ▶ When "Add" is selected
- Follow the steps in "Registering a new contact to the contacts list" from step 2. ( $\rightarrow$ P. 305)

You can make a call using numbers registered in the contact.

- $\bigcirc$  Display the phone screen. ( $\rightarrow$ P. 289)
- 2 Select "Favorites" tab.
- 3 Select the desired number to make a call.

## Dialing from call history

You can make a call using the call history, which has the 3 functions below.

- : calls which you received
- : calls which you made
- 1 Display the phone screen. (→P. 289)
- 2 Select "Call History" tab.
- 3 Select or the desired entry from the list.
- ▶ When 📞 is selected
- [4] Check that the "Call" screen is displayed.
- ▶ When the desired contact is selected
- 4 Select the desired number.
- 5 Check that the "Call" screen is displayed.

#### ■ Call history list

- If you make a call to or receive a call from a number registered in the contact, the name is displayed in the call history.
- If you make multiple calls to the same number, only the last call made is displayed in the call history.

#### ■International calls

You may not be able to make international calls, depending on the mobile phone in use.

## Receiving a call

When a call is received, the following screen is displayed together with a sound.

## To answer the phone

Press the switch on the steering wheel or select.



## To refuse a call

Press the switch on the steering wheel or select .

## To adjust the incoming call volume

Turn the "PWR/VOL" knob. You can also adjust the volume using the steering switches.

#### ■International calls

Received international calls may not be displayed correctly depending on the cellular phone in use.

## The following screen is displayed when speaking on the phone.



## To adjust the call volume

Select "-" or "+". You can also adjust the volume using the steering switches or the volume knob.

## To prevent the other party from hearing your voice

Select "Mute".

## Inputting tones

When using phone services such as an answering service or a bank, you can store phone numbers and code numbers in the contact.

- 1 Select "0-9".
- 2 Input the number.

### **■** Release Tones

"Release Tones" appear when a continuous tone signal(s) containing a (w) is registered in the contact list.

1 Select "Release Tones".

5

Audio systen

#### ■ Release Tones

- A continuous tone signal is a character string that consists of numbers and the characters p or w. (e.g.056133w0123p#1\*)
- When the "p" pause tone is used, the tone data up until the next pause tone will be automatically sent after 2 seconds have elapsed. When the "w" pause tone is used, the tone data up until the next pause tone will be automatically sent after a user operation is performed.
- Release tones can be used when automated operation of a phone based service such as an answering machine or bank phone service is desired. A phone number with continuous tone signals can be registered in the contact list.
- Tone data after a "w" pause tone can be operated on voice command during a call.

#### To transfer a call

Select "Handset Mode" to on from a hands-free call to a cellular phone call.

Select "Handset Mode" to off from a cellular phone call to a hands-free call.

### Transmit volume setting

- 1 Select "Transmit Volume".
- 2 Select the desired level for the transmit volume.
- 3 Select "OK".

#### To hang up

## Call waiting

When a call is interrupted by a third party while talking, an incoming call message will be displayed.

To talk with the other party:

- Press the switch on the steering wheel.
- Select .

To refuse the call:

- Press the switch on the steering wheel.
- Select \_\_\_\_\_.



Every time you press the switch on the steering wheel or select during call waiting, you will be switched to the other party.

## ■ Transferring calls

- If you transfer from the cellular phone to hands-free, the hands-free screen will be displayed, and you can operate the system using the screen.
- Transfer method and operation may vary according to the cellular phone used.
- For operation of the cellular phone in use, see the phone's manual.

#### ■ Call waiting operation

Call waiting operation may differ depending on your phone company and cellular phone.

## Bluetooth<sup>®</sup> phone message function

Received messages can be forwarded from the connected Bluetooth<sup>®</sup> phone, enabling checking and replying using the multimedia system.

Depending on the type of Bluetooth<sup>®</sup> phone connected, received messages may not be transferred to the message inbox.

If the phone does not support the message function, this function cannot be used.

#### Displaying message inbox screen

- 🔟 Press the " 📞 " button.
- 2 Select 🔼 .

### Receiving a message

When an e-mail/SMS/MMS is received, the incoming message screen pops up with sound and is ready to be operated on the screen.

- (1) Select to check the message.
- (2) Select to refuse the message.
- ③ Select to call the message sender.



#### ■ Receiving a message

- Depending on the cellular phone used for receiving messages, or its registration status with the navigation system, some information may not be displayed.
- The pop up screen is separately available for incoming e-mail and SMS/ MMS messages under the following conditions:

#### E-mail:

- "Incoming E-mail Display" is set to "Full Screen". (→P. 309)
- "E-mail Notification Popup" is set to on. ( $\rightarrow$ P. 309) SMS/MMS:
- "Incoming SMS/MMS Display" is set to "Full screen". (→P. 309)
- "SMS/MMS Notification Popup" is set to on. (→P. 309)

## Checking the messages

- 1 Display the message inbox screen. (→P. 298)
- 2 Select the desired message from the list.
- 3 Check that the message is displayed.
  - ① E-mails: Select "Mark Unread" or "Mark Read" to mark mail unread or read on the message inbox screen.

This function is available when "Update Read Status on Phone" is set to on. (→P. 309)



- 2 Select to make a call to the sender.
- ③ Select to have messages read out. To cancel this function, select "Stop".
- (4) Select to display the previous or next message.
- (5) Select to reply the message.

#### ■ Check the messages

- Depending on the type of Bluetooth<sup>®</sup> phone being connected, it may be necessary to perform additional steps on the phone.
- Messages are displayed in the appropriate connected Bluetooth<sup>®</sup> phone's registered mail address folder.
   Select the tab of the desired folder to be displayed.
- Only received messages on the connected Bluetooth® phone can be displayed.
- The text of the message is not displayed while driving.
- When "Automatic Message Readout" is set to on, messages will be automatically read out. (→P. 309)
- Turn the "PWR/VOL" knob, or use the volume switch on the steering wheel to adjust the message read out volume.
- The message read out function is available even while driving.

## Replying to a message

- 1 Display the message inbox screen. (→P. 298)
- 2 Select the desired message from the list.
- 3 Select "Quick Message".
- 4 Select the desired message.
- 5 Select "Send".

#### ■ Editing quick reply message

- 1 Select "Quick Message".
- Select corresponding to the desired message to edit.
- 3 Select "OK" when editing is completed.

### Calling the message sender

Calls can be made to an e-mail/SMS/MMS message sender's phone number.

- 1 Display the message inbox screen. (→P. 298)
- 2 Select the desired message.
- 3 Select .
- 4 Check that the "Call" screen is displayed.

#### ■ Calling from a number within a message

Calls can be made to a number identified in a message's text area.

- 1 Display the message inbox screen. (→P. 298)
- 2 Select the desired message.
- 3 Select the text area.
- 4 Select corresponding to the desired number.
- 5 Check that the "Call" screen is displayed.

#### ■ Calling from the incoming message screen

→P. 297


## Using the steering wheel switches

The steering wheel switches can be used to operate a connected cellular phone.

## Operating a telephone using the steering wheel switches

## ■ Steering wheel switches on the right hand side


- 1 Off hook switch
  - · Make a call
  - · Receive a call
  - Display "Phone" screen
- (2) On hook switch
  - · End a call
  - · Refuse a call



## ■ Steering wheel switches on the left hand side

- (1) Volume switch
  - Increase/Decrease the volume
  - Press and hold:

     Continuously increase/
     decrease the volume
- (2) Back switch
  - Return to the previous screen
- (3) Cursor switch
  - · Select a list/tab
- (4) Enter switch
  - · Select an item



5

Audio system

## Bluetooth<sup>®</sup> phone settings

You can adjust the hands-free system to your desired settings.

### "Phone/Message Settings" screen

To display the screen shown below, press the "SETUP" button, and select "Phone" on the "Setup" screen.

- Set the phone connection (→P. 282)
- ② Setting the sound (→P. 302)
- ③ Contact/Call History Settings (→P. 303)
- ④ Set the message settings (→P. 309)
- (5) Set the phone display(→P. 310)



### Sound setting

- 1 Display the "Phone/Message Settings" screen. (→P. 302)
- 2 Select "Sound Settings" on the "Phone/Message Settings" screen.
  - (1) Set the desired ringtone.
  - (2) Adjust the ringtone volume.
  - 3 Adjust the message readout volume.
  - (4) Set the desired incoming SMS/MMS tone.
  - (5) Adjust the incoming SMS/MMS tone volume.
  - (6) Set the incoming e-mail tone.
  - (7) Adjust the incoming e-mail tone volume.
  - (8) Adjust the default volume of the other party's voice.
- To return to the default volume settings
  Select "Default", and then "Yes".



The call history can be deleted and contact and favorites can be changed.

- 1 Display the "Phone/Message Settings" screen. (→P. 302)
- 2 Select "Contact/Call History Settings".
- 3 Select the desired item to be set.
  - 1 For **PBAP** compatible Bluetooth® phones, select to set "Automatic Transfer" on/ off. When set to on, the phone's contact data and history are automatically transferred.
  - (2) Select to update contacts from the connected phone.  $(\to P. 304)$



- CTHDAAK121US
- (3) Select to sort contacts by the first name or last name field.
- (4) Select to add contacts to the favorites list. (→P. 307)
- (5) Select to delete contacts from the favorites list. ( $\rightarrow$ P. 308)
- (6) Select to display contact images.
- (7) Select to clear contacts from the call history.\*
- (8) Select to add new contacts to the contact list.\* ( $\rightarrow$ P. 305)
- (9) Select to edit contacts in the contact list.\* (→P. 306)
- (1) Select to delete contacts from the contact list.\* (→P. 306)
- (1) Select to reset all setup items.
  - \*: For PBAP compatible Bluetooth® phones only, this function is available when "Automatic Transfer" is set to off.

#### Update contacts from phone

Operation methods differ between PBAP compatible and PBAP incompatible but OPP compatible Bluetooth<sup>®</sup> phones.

If your cellular phone is neither PBAP nor OPP compatible, the contacts cannot be transferred.

## ■ For PBAP Compatible Bluetooth® Phones

- 1 Select "Update Contacts from Phone".
- 2 Check that a confirmation screen is displayed when the operation is complete.

This operation may be unnecessary depending on the type of cellular phone.

Depending on the type of cellular phone, OBEX authentication may be required when transferring contact data. Enter "1234" into the Bluetooth<sup>®</sup> phone.

If another Bluetooth<sup>®</sup> device is connected when transferring contact data, depending on the phone, the connected Bluetooth<sup>®</sup> device may need to be disconnected.

Depending on the type of Bluetooth<sup>®</sup> phone being connected, it may be necessary to perform additional steps on the phone.

# ■ For PBAP Incompatible but OPP compatible Bluetooth® Phones

- 1 Select "Update Contacts from Phone".
- 2 Transfer the contact data to the system using a Bluetooth<sup>®</sup> phone.

This operation may be unnecessary depending on the type of cellular phone.

Depending on the type of cellular phone, OBEX authentication may be required when transferring contact data. Enter "1234" into the Bluetooth® phone.

To cancel this function, select "Cancel".

- 3 Select "Done" when it appears on the screen.
- 4 Check that a confirmation screen is displayed when the operation is complete.

For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Transfer" is set to off.  $(\rightarrow P. 303)$ 

- $\square$  Display the phone screen. ( $\rightarrow$ P. 289)
- 2 Select the "Call History" tab and select a contact not yet registered in the contact list.
- Select "Update Contact".
- 4 Select the desired contact.
- [5] Select a phone type for the phone number.

## Registering a new contact to the contact list

New contact data can be registered. Up to 4 numbers per person can be registered. For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Transfer" is set to off. ( $\rightarrow$ P. 303)

- 1 Select "New Contact".
- 2 Enter the name and select "OK".
- 3 Enter the phone number and select "OK".
- [4] Select the phone type for the phone number.
- 5 To add another number to this contact, select "Yes".
- Registering a new contact in a different way (From the "Call History" screen)
  - 1 Display the phone screen. (→P. 289)
  - 2 Select the "Call History" tab and select a contact not yet registered in the contact list.
  - 3 Select "Add to Contacts".
- Follow the steps in "Registering a new contact to the contacts list" from step 3.

### Editing the contact data

For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Transfer" is set to off.  $(\rightarrow P. 303)$ 

- Select "Edit Contact".
- 2 Select the desired contact.
- 3 Select corresponding to the desired name or number.
- ▶ For editing the name
- [4] Follow the steps in "Registering a new contact to the contacts list" from step [3]. (→P. 305)
- ▶ For editing the number
- [4] Follow the steps in "Registering a new contact to the contacts list" from step [4]. (→P. 305)
- Editing the contacts in a different way (From the "Contact Details" screen)
  - $\boxed{1}$  Display the phone screen. ( $\rightarrow$ P. 289)
  - 2 Select the "Contacts", "Call History" tab or the "Favorites" tab and select the desired contact.
  - 3 Select "Edit Contact".
    - "E-mail Addresses": Select to display all registered e-mail addresses for the contact.
  - 4 Follow the steps in "Editing the contact data" from step 4.

#### Deleting the contact data

For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Transfer" is set to off.  $(\rightarrow P. 303)$ 

- 1 Select "Delete Contacts".
- Select the desired contact and select "Delete".
- 3 Select "Yes" when the confirmation screen appears.
- Deleting the contact in a different way (From the "Contact Details" screen)
  - 1 Display the phone screen. (→P. 289)
  - 2 Select the "Contacts", "Call History" tab or the "Favorites" tab and select the desired contact.
- 3 Select "Edit Contact".
- 4 Select "Yes" when the confirmation screen appears.

### ravorites list setting

Up to 15 contacts (maximum of 4 numbers per contact) can be registered in the favorites list.

#### Registering the contacts in the favorites list

- 1 Select "Add Favorite".
- 2 Select the desired contact to add to the favorites list. Dimmed contacts are already stored as a favorite.
- 3 Check that a confirmation screen is displayed when the operation is complete.
- ▶ When 15 contacts have already been registered to the favorites list
- 1 When 15 contacts have already been registered to the favorites list, a registered contact needs to be replaced.

  Select "Yes" when the confirmation screen appears to replace a contact.
- 2 Select the contact to be replaced.
- 3 Check that a confirmation screen is displayed when the operation is complete.
- ▶ Registering contacts in the favorites list in a different way (from the "Contacts" screen)
- $\bigcirc$  Display the phone screen. ( $\rightarrow$ P. 289)
- 2 Select the "Contacts" tab.
- 3 Select ☆ at the beginning of the desired contact list name to be registered in the favorites list.
  - When selected,  $\, \not \searrow \,$  is changed to  $\, \bigstar \,$  , and the contact is registered in the favorites list.
- ▶ Registering contacts in the favorites list in a different way (from the "Contact Details" screen)
- 1 Display the phone screen. (→P. 289)
- 2 Select the "Contacts" tab or the "Call History" tab and select the desired contact.
- 3 Select "Add Favorite".
- 4 Check that a confirmation screen is displayed when the operation is complete.

#### ■ Deleting the contacts in the favorites list

- 1 Select "Remove Favorite".
- 2 Select the desired contacts and select "Remove".
- 3 Select "Yes" when the confirmation screen appears.
- 4 Check that a confirmation screen is displayed when the operation is complete.
- ▶ Deleting contacts in the favorites list in a different way (from the "Contacts" screen)
- $\boxed{1}$  Display the phone screen. ( $\rightarrow$ P. 289)
- 2 Select the "Contacts" tab.
- 3 Select ★ at the beginning of the contact list name to be deleted from the favorites list.
  - When selected,  $\bigstar$  is changed to  $\leftrightarrows$ , and the data is deleted from the list.
- ▶ Deleting contacts in the favorites list in a different way (from the "Contact Details" screen)
- $\boxed{1}$  Display the phone screen. ( $\rightarrow$ P. 289)
- 2 Select the "Contacts", "Call History" tab or the "Favorites" tab and select the desired contact to delete.
- 3 Select "Remove Favorite".
- 4 Select "Yes" when the confirmation screen appears.
- 5 Check that a confirmation screen is displayed when the operation is complete.

## Message Settings

- ☐ Display the "Phone/Message Settings" screen. (→P. 302)
- 2 Select "Messaging Settings".
- 3 Select the desired item to be set.
  - (1) Set automatic message transfer on/off.
  - (2) Set automatic message readout on/off.
  - (3) Set the SMS/MMS notification popup on/off.
  - (4) Set the e-mail notification popup on/off.
  - (5) Set adding the vehicle signature to outgoing messages on/off.



- (6) Set updating message read status on phone on/off.
- (7) Change the incoming SMS/MMS display.
  - "Full Screen": When an SMS/MMS message is received, the incoming SMS/MMS display screen is displayed and can be operated on the screen.
  - "Drop-Down": When an SMS/MMS message is received, a message is displayed on the upper side of the screen.
- (8) Change the incoming e-mail display.
  - "Full Screen": When an e-mail is received, the incoming e-mail display screen is the displayed and can be operated on the screen.
  - "Drop-Down": When an e-mail is received, a message is displayed on the upper side of the screen.
- (9) Set display of messaging account names on the inbox tab on/off. When set to on, messaging account names used on the cellular phone will be displayed.

#### ■ To return to the default volume settings

Select "Default", and then "Yes".

## ■ Displaying the "Messaging Settings" screen in a different way

- $\boxed{1}$  Display the phone screen. ( $\rightarrow$ P. 289)
- 2 Select 🧪
- 3 Select "Settings".

## Phone Display Settings

- ☐ Display the "Phone/Message Settings" screen. (→P. 302)
- 2 Select "Phone Display Settings".
- 3 Select the desired item to be set.
  - 1 Change the incoming call display.

"Full Screen": When a call is received, the hands-free screen is displayed and can be operated on the screen.

"Drop-Down": A message is displayed on the upper side of the screen.



② Set display of the contact/ history transfer completion message on/off.

## What to do if... (Troubleshooting)

If there is a problem with the hands-free system or a Bluetooth<sup>®</sup> device, first check the table below.

▶ When using the hands-free system with a Bluetooth<sup>®</sup> device

The hands-free system or Bluetooth® device does not work.

The connected device may not be a compatible Bluetooth® cellular phone.

→ For a list of specific devices which operation has been confirmed on this system, check with your Toyota dealer or the following website: http://www.toyota.com/entune.html

The Bluetooth version of the connected cellular phone may be older than the specified version.

→ Use a cellular phone with Bluetooth version 2.0 or higher (recommended: Ver. 3.0 with EDR or higher). (→P. 315)

▶ When registering/connecting a cellular phone

#### A cellular phone cannot be registered.

An incorrect passcode was entered on the cellular phone.

→ Enter the correct passcode on the cellular phone.

The registration operation has not been completed on the cellular phone side.

→ Complete the registration operation on the cellular phone (approve registration on the phone).

Old registration information remains on either this system or the cellular phone.

→ Delete the existing registration information from both this system and the cellular phone, then register the cellular phone you wish to connect to this system. (→P. 283)

#### A Bluetooth® connection cannot be made.

Another Bluetooth® device is already connected.

→ Manually connect the cellular phone you wish to use to this system. (→P. 285)

Bluetooth® function is not enabled on the cellular phone.

→ Enable the Bluetooth<sup>®</sup> function on the cellular phone.

"Please check your device settings." message is displayed.

Bluetooth<sup>®</sup> function is not enabled on the cellular phone.

→ Enable the Bluetooth® function on the cellular phone.

Old registration information remains on either this system or the cellular phone.

- → Delete the existing registration information from both this system and the cellular phone, then register the cellular phone you wish to connect to this system. (→P. 283)
- When making/receiving a call

#### A call cannot be made/received.

Your vehicle is in a "Out of cellular service area. Please try again later."

→ Move to where "Out of cellular service area. Please try again later." no longer appears on the display.

#### ▶ When using the phonebook

#### Phonebook data cannot be transferred manually/automatically.

The profile version of the connected cellular phone may not be compatible with transferring phonebook data.

→ For a list of specific devices which operation has been confirmed on this system, check with your Toyota dealer or the following website: http://www.toyota.com/entune.html

Automatic phonebook transfer function on this system is set to off.

→ Set automatic phonebook transfer function on this system to on. (→P. 303)

Passcode has not been entered on the cellular phone.

→ Enter the passcode on the cellular phone if requested (default passcode: 1234).

Transfer operation on the cellular phone has not completed.

→ Complete transfer operation on the cellular phone (approve transfer operation on the phone).

#### Phonebook data cannot be edited.

Automatic phonebook transfer function on this system is set to on.

- → Set automatic phonebook transfer function on this system to off. (→P. 303)
- ▶ When using the Bluetooth® message function

#### Messages cannot be viewed.

Message transfer is not enabled on the cellular phone.

→ Enable message transfer on the cellular phone (approve message transfer on the phone).

Automatic transfer function on this system is set to off.

 $\rightarrow$  Set automatic transfer function on this system to on. ( $\rightarrow$ P. 309)

#### New message notifications are not displayed.

Notification of SMS/MMS/E-mail reception on this system is set to off.

→ Set notification of SMS/MMS/E-mail reception on this system to on. (→P. 309)

Automatic message transfer function is not enabled on the cellular phone.

→ Enable automatic transfer function on the cellular phone.

#### ▶ In other situations

Even though all conceivable measures have been taken, the symptom status does not change.

The cellular phone is not close enough to this system.

→ Bring the cellular phone closer to this system.

The cellular phone is the most likely cause of the symptom.

- → Turn the cellular phone off, remove and reinstall the battery pack, and then restart the cellular phone.
- → Enable the cellular phone's Bluetooth® connection.
- $\rightarrow$  Stop the cellular phone's security software and close all applications.
- → Before using an application installed on the cellular phone, carefully check its source and how its operation might affect this system.

## Bluetooth<sup>®</sup>

## ■When using the Bluetooth<sup>®</sup> audio system

- In the following conditions, the system may not function.
  - · If the portable audio player is turned off
  - · If the portable audio player is not connected
  - · If the portable audio player's battery is low
- ■There may be a delay if a cellular phone connection is made during Bluetooth<sup>®</sup> audio play.
- Depending on the type of portable audio player that is connected to the system, operation may differ slightly and certain functions may not be available.

#### ■When using the hands-free system

- The multimedia system is muted when making a call.
- If both parties speak at the same time, it may be difficult to hear.
- If the received call volume is overly loud, an echo may be heard.
  If the Bluetooth<sup>®</sup> phone is too close to the system, quality of the sound may deteriorate and connection status may deteriorate.
- In the following circumstances, it may be difficult to hear the other party:
  - · When driving on unpaved roads
  - · When driving at high speeds
  - · If a roof or window is open
  - If the air conditioning is blowing directly on the microphone
  - If there is interference from the network of the cellular phone

#### ■ Conditions under which the system will not operate

- If using a cellular phone that does not support Bluetooth®
- If the cellular phone is turned off
- If you are outside of cellular phone service coverage
- If the cellular phone is not connected
- If the cellular phone's battery is low
- When outgoing calls are controlled, due to heavy traffic on telephone lines, etc.
- When the cellular phone itself cannot be used
- When transferring contact data from the cellular phone

#### ■ Bluetooth<sup>®</sup> antenna

The antenna is built into the display.

If the portable audio player is behind the seat or in the glove box or console box, or is touching or covered by metal objects, the connection status may deteriorate.

If the cellular phone is behind the seat or in the console box, or touching or covered by metal objects, the connection status may deteriorate.

#### ■ Battery charge/signal status

- This display may not correspond exactly with the portable audio player or cellular phone itself.
- This system does not have a charging function.
- ■The portable audio player or cellular phone battery will be depleted quickly when the device is connected to Bluetooth<sup>®</sup>.

## ■When using the Bluetooth® audio and hands-free system at the same time

The following problems may occur.

- The Bluetooth<sup>®</sup> audio connection may be interrupted.
- Noise may be heard during Bluetooth<sup>®</sup> audio playback.

## ■ About the contact in this system

The following data is stored for every registered cellular phone. When another phone is connecting, you cannot read the registered data.

- Contact data
- Call history
- Favorite
- Message

When removing a Bluetooth® phone from the system, the above-mentioned data is also deleted.

#### **■** Compatible models

The Bluetooth® audio system supports portable audio players with the following specifications

- Bluetooth<sup>®</sup> specifications:
  - Ver. 2.0, or higher (Recommended: Ver. 3.0+EDR or higher)
- Profiles:
  - A2DP (Advanced Audio Distribution Profile) Ver. 1.0, or higher (Recommended: Ver. 1.2 or higher)
    - This is a profile to transmit stereo audio or high quality sound to the multimedia system.
  - AVRCP (Audio/Video Remote Control Profile) Ver. 1.0 or higher (Recommended: Ver. 1.4 or higher)

This is a profile to allow remote control the A/V equipment.

However, please note that some functions may be limited depending on the type of portable audio player connected.

The hands-free system supports cellular phones with the following specifications.

- Bluetooth<sup>®</sup> specification:
  - Ver. 2.0 or higher (Recommended: Ver. 3.0+EDR or higher)
- Profiles:
  - HFP (Hands Free Profile) Ver. 1.0 or higher (Recommended: Ver. 1.6 or higher)
    - This is a profile to allow hands-free phone calls using a cellular phone or head set. It has outgoing and incoming call functions.
  - OPP (Object Push Profile) Ver. 1.1 or higher (Recommended: Ver. 1.2)
     This is a profile to transfer contact data. When a Bluetooth<sup>®</sup> compatible cellular phone has both PBAP and OPP, OPP cannot be used.
  - PBAP (Phone Book Access Profile) Ver. 1.0 or higher (Recommended: Ver. 1.1)
    - This is a profile to transfer contact data.
  - MAP (Message Access Profile) Ver.1.0 or higher This is a profile to using phone message.

If the cellular phone does not support HFP, you cannot register it with the hands-free system. OPP, PBAP or MAP services must be selected individually.

#### ■ Certification

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### CAUTION

#### Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 20 cm and more between the radiator and person's body in normal use position.

#### Co-location:

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

#### ■ Reconnecting the portable audio player

If the portable audio player is disconnected due to poor reception when the engine switch is in the "ACC" or "ON" position (vehicles without a smart key system) or ACCESSORY or IGNITION ON mode (vehicles with a smart key system), the system automatically reconnects the portable audio player.

If you have switched off the portable audio player yourself, follow the instructions below to reconnect:

- Select the portable audio player again
- Enter the portable audio player

#### ■When you sell your car

Be sure to delete your personal data. ( $\rightarrow$ P. 251)

## **WARNING**

#### While driving

Do not use the portable audio player, cellular phone or connect a device to the Bluetooth  $^{\circledR}$  system.

#### Caution regarding interference with electronic devices

- Your audio unit is fitted with Bluetooth<sup>®</sup> antennas. People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the Bluetooth<sup>®</sup> antennas. The radio waves may affect the operation of such devices.
- Before using Bluetooth® devices, users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical devices.



#### NOTICE

#### When leaving the vehicle

Do not leave your portable audio player or cellular phone in the vehicle. The inside of the vehicle may become hot, causing damage to the portable audio player or cellular phone.

5

Audio system


## **Voice command system**

The voice command system enables the hands-free system to be operated using voice commands.

Operations of the voice command system can be performed by selecting the menu corresponding to each function on the screen. Even if any menu is selected, commands displayed on all menus can be operated.

### Using the voice command system

1 Press the talk switch.



- 1) Select to train voice recognition.
- Select to start the voice recognition tutorial.



2 Select "OK" and say the desired command.

On the list screen, you can select the desired command.

To cancel the voice command system, press and hold the talk switch.

#### ■ Microphone

→P. 290

#### ■When using the microphone

- It is unnecessary to speak directly into the microphone when giving a command
- When "Voice Prompt Interrupt" set to on, it is not necessary to wait for the confirmation beep before speaking a command. (→P. 254)
- Voice commands may not be recognized if:
  - · Spoken too quickly.
  - · Spoken at a low or high volume.
  - The roof or windows are open.
  - · Passengers are talking while voice commands are spoken.
  - The air conditioning speed is set high.
  - The air conditioning vents are turned towards the microphone.
- In the following conditions, the system may not recognize the command properly and using voice commands may not be possible:
  - The command is incorrect or unclear. Note that certain words, accents or speech patterns may be difficult for the system to recognize.
  - There is excessive background noise, such as wind noise.

### Casual speech recognization

Due to natural language speech recognition technology, this system enables recognition of a command when spoken naturally. However, the system cannot recognize every variation of each command.

In some situations, it is possible to omit the command for the procedure and directly state the desired operation.

Not all voice commands are displayed in the short cut menu.

This function is available in English, Spanish and French.

#### **■** Expression examples for each function

Command	Expression examples
"Call <name> <type>"</type></name>	Get me <robert brown="">. I need to call <robert brown=""> at <work> right away.</work></robert></robert>
"Dial <number>"</number>	Please dial the number <3334445555>. Ring <3334445555>.

## Command list

Some recognizable voice commands and their actions are shown below as examples.


## ▶ Basic

Command	Action
"Help"	Prompts voice guidance to offer examples of commands or operation methods
"Go Back"	Returns to the previous screen

## ▶ Phone

Command	Action	
"Redial"	Places a call to the phone number of the latest outgoing call	
"Call Back"	Places a call to the phone number of latest incoming call	
"Show Recent Calls"	Displays the call history screen	
"Dial <phone number="">"</phone>	Places a call to the said phone number	
"Call <contacts> <phonetypes>"</phonetypes></contacts>	Place a call to the said phone type of the contact from the phone book	

1 Press and hold the until you hear the beeps.



The Mobile Assistant can be used only when the following screen is displayed.

To cancel the Mobile Assistant, select "Cancel", or press and hold the 
on the steering wheel.

To restart the Mobile Assistant for additional commands, press the 
so on the steering wheel.



- Mobile Assistant can only be restarted after the system responds to a voice command.
- After some phone and music commands, the Mobile Assistant feature will automatically end to complete the requested action.

#### ■ Adjusting the Mobile Assistant volume

The volume of the Mobile Assistant can be adjusted using the "PWR/VOL" knob or steering wheel volume switches. The Mobile Assistant and phone call volumes are synchronized.

5

Audio system


#### ■ Notes about Mobile Assistant

- The available features and functions may vary based on the iOS version installed on the connected device.
- Some Siri features are limited in Eyes Free mode. If you attempt to use an unavailable function, Siri will inform you that the function is not available.
- If Siri is not enabled on the cellular phone connected via Bluetooth<sup>®</sup>, an error message will be displayed on the screen.
- While a phone call is active, the Mobile Assistant cannot be used.
- If using the navigation feature of the cellular phone, ensure the active audio source is Bluetooth<sup>®</sup> audio or iPod in order to hear turn by turn direction prompts.

6-1.	Using the air conditioning system	6-3.	Using the storage features
	and defogger  Manual air conditioning		List of storage features 342
	system326		• Glove box
	Automatic air conditioning system 331		• Coin holder 344
	Seat heaters337		Bottle holders344
6-2.	Using the interior lights		• Cup holders 345
	Interior lights list 339		Auxiliary boxes
	Interior lights 340		• Open tray 350
	Personal lights 340		Trunk features351
	-	6-4.	Other interior features
			Other interior features 352
			• Sun visors 352
			Vanity mirrors 352
			• Clock 353
			Ashtray354
			Power outlets 355
			• Armrest 356
			Assist grips 356
			• Coat hooks 357
			Garage door opener 358
			Safety Connect 364
			Compass

# Manual air conditioning system<sup>\*</sup>

# Air conditioning controls



## ■ Adjusting the temperature setting

To adjust the temperature setting, turn clockwise to increase the temperature and counterclockwise to decrease the temperature.

If  $\bar{x}$  is not pressed, the system will blow ambient temperature air or heated air.

### ■ Fan speed setting


To adjust the fan speed, turn clockwise to increase the fan speed and counterclockwise to decrease the fan speed.


Turning the dial to "OFF" turns off the fan.

### ■ Change the airflow mode

To change the airflow mode, press  $\overline{\ddot{y}}$ ,  $\overline{\ddot{y}}$ , or

- 1 Air flows to the upper body.
- 2 Air flows to the upper body and feet.
- (3) Air flows to the feet.





\*: If equipped

### ■ Switching between outside air and recirculated air modes

Press S.

The mode switches between outside air mode (indicator off) and recirculated air mode (indicator on) each time is pressed.

## ■ Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

1 Press Proof

If the recirculated air mode is used, it will automatically switch to the outside air mode.

- 2 Perform the following operations accordingly:
  - To adjust the fan speed, turn
  - To adjust the temperature setting, turn .
  - If the dehumidification function is not operating, press to operate the dehumidification function.

To defog the windshield and the side windows early, turn the air flow and temperature up.

#### ■ Defogging the rear window and outside rear view mirrors

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.


Press .

The defoggers will automatically turn off after a period of time.

# Air outlets


#### ■ Location of air outlets

The air outlets and air volume change according to the selected airflow mode.



# Adjusting the position of and opening and closing the air outlets

- ① Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.



### For quick cooling

Turn to "MAX A/C". The air conditioning will automatically turn on. will be set for recirculated air mode when it is selected. It is not possible to turn to the outside air mode.

#### ■ Fogging up of the windows

- The windows will easily fog up when the humidity in the vehicle is high. Turning \_\_\_\_ on will dehumidify the air from the outlets and defog the wind-shield effectively.
- If you turn off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

#### Outside/recirculated air mode

- When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode button to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.
- Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.

#### ■When the outside temperature exceeds 75°F (24°C) and the air conditioning system is on

- In order to reduce the air conditioning power consumption, the air conditioning system may switch to recirculated air mode automatically. This may also reduce fuel consumption.
- Vehicles without a smart key system:

Recirculated air mode is selected as a default mode when the engine switch is turned to the "ON" position.

Vehicles with a smart key system:

Recirculated air mode is selected as a default mode when the engine switch is turned to IGNITION ON mode.

It is possible to switch to outside air mode at any time by pressing \( \still \).



#### ■When the outside temperature is low

The dehumidification function may not operate even when \_\_\_\_ is pressed.

#### ■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
  - U.S.A and Puerto Rico: This vehicle is equipped with a deodorizing charcoal air filter. This filter should be inspected and replaced according to the maintenance schedule. (Air conditioning filter: →P. 418)
  - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.


#### ■ Air conditioning filter

→P. 418

# **MARNING**

#### To prevent the windshield from fogging up

- Do not use \_\_\_\_ during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- Do not place anything on the instrument panel which may cover the air outlets.
   Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



#### To prevent burns


Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.



## ■To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is stopped.

### Air conditioning controls



# ■ Adjusting the temperature setting

To adjust the temperature setting, turn clockwise to increase the temperature and counterclockwise to decrease the temperature.

# ■ Fan speed setting

Press vore to turn the fan off.


6

#### ■ Change the airflow mode

To change the airflow mode, press  $\lceil \frac{1}{1000} \rceil$ .

The air outlets used are switched each time the button is pressed.

- 1) Air flows to the upper body.
- ② Air flows to the upper body and feet.
- (3) Air flows to the feet.
- (4) Air flows to the feet and the windshield defogger operates.



#### Using automatic mode

1 Press Auto.

The dehumidification function begins to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

- 2 Adjust the temperature setting.
- 3 To stop the operation, press Stoff.

#### ■ Automatic mode indicator

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated is maintained.

# Adjusting the temperature for driver and passenger seats separately ("SYNC" mode)

To turn on the "SYNC" mode, perform any of the following procedures:

- Press SYNC .
- Adjust the passenger's side temperature setting.

The indicator comes on when the "SYNC" mode is on.

While in "SYNC" mode, the temperature of the rear air outlets is set at the driver's side temperature setting.

Other functions

Press

The mode switches between outside air mode (indicator off) and recirculated air mode (indicator on) each time (is pressed.

## ■ Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Press

The dehumidification function operates and fan speed increases. Set the outside/recirculated air mode button to the outside air mode if the recirculated air mode is used. (It may switch automatically.) To defog the windshield and the side windows early, turn the air flow and

temperature up. To return to the previous mode, press again when the windshield is defogged.

#### ■ Defogging the rear window and outside rear view mirrors

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.


Press

The defoggers will automatically turn off after a period of time.

# Air outlets


# ■ Location of air outlets

The air outlets and air volume change according to the selected airflow mode.




# ■ Adjusting the position of and opening and closing the air outlets

▶ Front



▶ Rear



- 1) Direct air flow to the left or right, up or down.
- ② Turn the knob to open or close the vent.

#### ■ Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and the ambient conditions.

Therefore, the fan may stop for a while until warm or cool air is ready to flow immediately after is pressed.

#### ■ Fogging up of the windows

- The windows will easily fog up when the humidity in the vehicle is high. Turning on will dehumidify the air from the outlets and defog the windshield effectively.
- If you turn \(\sum\_\mathrix\) off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

#### ■ Outside/recirculated air mode

- When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode button to recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.
- Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.

# ■ When the outside temperature exceeds 75°F (24°C) and the air conditioning system is on

- In order to reduce the air conditioning power consumption, the air conditioning system may switch to recirculated air mode automatically. This may also reduce fuel consumption.
- Vehicles without a smart key system:

Recirculated air mode is selected as a default mode when the engine switch is turned to the "ON" position.

Vehicles with a smart key system:

Recirculated air mode is selected as a default mode when the engine switch is turned to IGNITION ON mode.

It is possible to switch to outside air mode at any time by pressing



#### ■When the outside temperature is low

The dehumidification function may not operate even when 🐷 is pressed.

#### ■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
  - · U.S.A and Puerto Rico: This vehicle is equipped with a deodorizing charcoal air filter. This filter should be inspected and replaced according to the maintenance schedule. (Air conditioning filter:  $\rightarrow$ P. 418)
  - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
  - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

### ■ Air conditioning filter

→P. 418

#### Customization


Settings (e.g. air conditioning setting) can be changed. (Customizable features →P. 530)



# **WARNING**

#### To prevent the windshield from fogging up

- Do not use during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



#### To prevent burns

Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.



#### NOTICE

#### To prevent battery discharge


Do not leave the air conditioning system on longer than necessary when the engine is stopped.

# **⚠** WARNING

- Care should be taken to prevent injury if anyone in the following categories comes in contact with the seats when the heater is on:
  - · Babies, small children, the elderly, the sick and the physically challenged
  - Persons with sensitive skin
  - Persons who are fatigued
  - · Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)
- Observe the following precautions to prevent the minor burns or overheat-
  - · Do not cover the seat with a blanket or cushion when using the seat heater.
  - · Do not use seat heater more than necessary.

# ♠ NOTICE

- Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.
- To prevent battery discharge, do not use the functions when the engine is not running.
- 1) Turns the seat heater on The indicator light comes on.
- (2) Adjusts the seat temperature The further you move the dial forward, the warmer the seat becomes.



Vehicles without a smart key system:


The seat heaters can be used when the engine switch is in the "ON" position.

Vehicles with a smart key system:

The seat heaters can be used when the engine switch is in IGNITION ON mode.

When not in use, move the dial fully backward. The indicator light will turn off.


# Interior lights list



- (1) Rear interior/personal lights (vehicles with moon roof) (→P. 340)
- (2) Interior light (vehicles without moon roof) (→P. 340)
- ③ Front interior/personal lights (vehicles with moon roof) or personal lights (vehicles without moon roof) (→P. 340)
- (4) Shift lever light (vehicles with moon roof)
- (5) Engine switch light
- 6 Door courtesy lights


# Interior lights

Vehicles without moon roof



- 1 Turns the lights on
- ② Turns the lights on/off linked to door positions.
- (3) Turns the lights off

▶ Vehicles with moon roof




- 1 Turns the lights on/off linked to door positions.
- 2 Turns the lights on/off

The rear interior lights will turn on/ off together with the front interior lights.


# Personal lights

Turns the lights on/off

▶ Front



▶ Rear (vehicles with moon roof)



Vehicles without a smart key system:

The lights automatically turn on/off according to the engine switch position, whether the doors are locked/unlocked, and whether the doors are open/closed.


Vehicles with a smart key system:

The lights automatically turn on/off according to the engine switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are open/closed.

- If the following lights are left on when the engine switch is turned off, the lights will go off automatically after 20 minutes:
  - · Interior lights
  - Personal lights
  - · Door courtesy lights
- Setting (e.g. the time elapsed before lights turn off) can be changed. (Customizable features: →P. 530)

6

# **List of storage features**




1 Auxiliary boxes	(→P. 346)	4 Cup holders	(→P. 345)
② Glove box	(→P. 343)	Open tray	(→P. 350)
3 Bottle holders/doo	Bottle holders/door pockets		(→P. 343)
	(→P. 344)	(7) Coin holder	(→P. 344)

# **MARNING**

- Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:
  - Glasses may be deformed by heat or cracked if they come into contact with other stored items.
  - Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.
- When driving or when the storage compartments are not in use, keep the lids closed.
  - In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open lid or the items stored inside.


# Glove box

- 1 Open (press the button)
- 2 Lock with the master key (vehicles without a smart key system) or mechanical key (vehicles with a smart key system)
- ③ Unlock with the master key (vehicles without a smart key system) or mechanical key (vehicles with a smart key system)




# Console box


Lift the lid while pulling up the lever to release the lock.




• When using the console box lid as an armrest, slide the console box lid forward as needed. Slide the lid forward while pulling up the lever.



The lid can also be opened from the forwardmost position.




■The console box is provided with a cut out that allows cables to be routed from the power outlet in the console box with the lid closed.




# Coin holder

Pull the lid down while pressing down the button.




# Bottle holders

▶ Front



▶ Rear



- When storing a bottle, close the cap.
- The bottle may not be stored depending on its size or shape.



# **MARNING**


Do not place anything other than a bottle in the bottle holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury.

### **NOTICE**

Put the cap on before stowing a bottle. Do not place open bottles in the bottle holders, or glass or paper cups containing liquid. The contents may spill and glass cups may break.

# **Cup holders**

► Front



▶ Rear



Pull the armrest down.

The insert for the front cup holders can be removed for cleaning.




# **MARNING**

- On not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking, causing injury.
- To prevent burns, cover hot drinks when placed in the cup holders.

# Auxiliary boxes


# ▶ Type A

Push the lid.




# ► Type B

Push the lid.




# ► Type C (if equipped)



# ■ Cable pass through (type B)

The auxiliary box is provided with a groove that allows cables to be routed from the power outlet in the auxiliary box with the lid closed.



#### ■When using wireless charger (if equipped)


A mobile device can be charged wirelessly on the tray.

Charging can only be performed with the engine switch in ACCESSORY or IGNITION ON mode and only on mobile devices with the "di" logo.

- ① Open the lid and press the wireless charger switch.
- ② Place a mobile device on the tray as shown in the illustration.

An amber indicator is illuminated while charging is in progress. When charging is complete, a green indicator will also be illuminated.

Some phones, cases or cover type wireless chargers may not cause the green indicator to illuminate even though it is fully charged.



When placing the mobile device on the wireless charging surface of the tray, make sure that there are no objects in-between the mobile device and the tray. They may interfere with charging.

#### ■ If the wireless charger LED indicators flash

If the wireless charging surface of the tray becomes too hot, the LED indicators will flash and charging is canceled. The LED indicators will be illuminated if the surface of the tray cools down.

If the LED indicators flash even though the surface of the tray is not hot, the wireless charger may be malfunctioning. Consult your Toyota dealer.

## ■When charging of the wireless charger stops temporarily

If any of the following operations are performed with the electronic key present, charging may stop temporarily. Charging will start again after a while.

- Locking/unlocking the doors by touching the door handle
- Opening/closing the doors
- Opening/closing the trunk lid
- Starting the engine
- Locking the doors by pressing the lock button on the electronic key
- When the electronic key is out of the detection area

#### ■ Certification for the wireless charger

▶ For vehicles sold in the U.S.A.

This device complies with Part 18 of the FCC Rules.

Toyota Motor Sales, U.S.A., Inc. 19001 S. Western Avenue Torrance, CA 90501

▶ For vehicles sold in Canada

This ISM device complies with Canadian ICES-001. Cet appareil ISM est conforme à la norme NMB-001 du Canada.



#### WARNING

#### Items unsuitable for storing (type A only)

Do not store items heavier than 0.4 lb. (0.2 kg).

Doing so may cause the auxiliary box to open and the items inside may fall out, resulting in an accident.

#### Caution regarding interference with electronic devices (vehicles with a wireless charger)

- People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the wireless charger. The radio waves may affect the operation of such devices.
- Before using the wireless charger, users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical devices.
- To avoid interference with other electrical devices, turn the wireless charger off by turning off the wireless charger switch.

#### To prevent damage or fire (vehicles with a wireless charger)

Observe the following precautions.

Failure to do so may result in the possibility of equipment failure or damage, vehicle fire, burns due to heat, or even electrical shock.

- Do not put any metallic objects between the charging area and the portable device.
- Do not place anything but a device to be charged on the wireless charger. It is not designed for use as an auxiliary box.
- Do not apply force or impact to the wireless charger.
- Do not disassemble or modify the wireless charger.

## **MARNING**

- Do not attempt to charge portable devices which are not compatible with the Qi wireless charging standard.
- Do not bring magnetized objects close to the wireless charger.
- Do not perform charging if the charging area is dusty.
- Keep foreign objects away from the wireless charger, and do not spill liquid on the wireless charger.
- Do not cover the wireless charger with a cloth or other object while charging.
- Do not attach metallic objects, such as aluminum stickers, to the charging area

## **NOTICE**

# Conditions in which the wireless charger may not operate correctly (vehicles with a wireless charger)

In the following situations, the wireless charger may not operate correctly:

- When a portable device is fully charged
- When there is a foreign object between the charging area and portable device
- When a portable device becomes hot while charging
- When a portable device is placed on the wireless area with its charging surface facing up
- When a portable device is not centered on the charging area
- When the vehicle is near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When the portable device is in contact with, or is covered by any of the following metallic objects
  - · Cards to which aluminum foil is attached
  - · Cigarette boxes that have aluminum foil inside
  - Metallic wallets or bags
  - Coins
  - · Metal hand warmers
  - Media such as CDs and DVDs
- When wireless keys (that emit radio waves) other than those of your vehicle are being used nearby.

If in situations other than above the wireless charger does not operate properly or the operation indicator light is blinking, the wireless charger may be malfunctioning. Contact your Toyota dealer.


# **NOTICE**

#### ■ To prevent failure or damage to data (vehicles with a wireless charger)

- Do not bring magnetic cards, such as a credit card, or magnetic recording media, close to the wireless charger. Otherwise, data may be erased due to the influence of magnetism.
  - Additionally, do not bring precision instruments such as wrist watches, close to the wireless charger, as such objects may malfunction.
- Do not leave portable devices in the cabin. The temperature inside the cabin may become high when parked in the sun, and cause damage to the device.
- To prevent battery discharge (vehicles with a wireless charger)

  Do not use the wireless charger for a long period of time with the engine is stopped.

## Open tray




## **MARNING**

Observe the following precautions when putting items in the open tray. Failure to do so may cause items to be thrown out of the tray in the event of sudden braking or steering. In these cases, the items may interfere with pedal operation or cause driver distraction, resulting in an accident.

- Do not store items in the tray that can easily shift or roll out.
- Do not stack items in the tray higher than the tray's edge.
- Do not put items in the tray that may protrude over the tray's edge.

# Grocery bag hooks



<u>^</u>

# NOTICE


To prevent damage to the hooks, do not apply too much load to the hooks.

2

# Other interior features

# Sun visors


- 1) To set the visor in the forward position, flip it down.
- ② To set the visor in the side position, flip down, unhook, and swing it to the side.
- 3 To use the side extender, place the visor in the side position, then slide it backward.



# Vanity mirrors

Slide the cover to open.

Vehicles with vanity lights: The light turns on when the cover is opened.




Vehicles with vanity lights: If the vanity lights remain on for 20 minutes while the engine is off, the lights will turn off automatically.

For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

Press the "SETUP" button and select "General" and then select "Clock".

- 1 Adjust hour/minute
- (2) Switch AM/PM
- (3) Rounds to the nearest hour\*
- (4) Displays in the 24-hour/12-hour format

\*e.g.: 1:00 to 1:29  $\rightarrow$  1:00 1:30 to 2:00  $\rightarrow$  2:00



Vehicles without a smart key system:

The clock is displayed when the engine switch is in the "ACC" or "ON" position.


Vehicles with a smart key system:

The clock is displayed when the engine switch is in ACCESSORY or IGNI-TION ON mode.

When disconnecting and reconnecting battery terminals, the clock will automatically be set to --:--.

# Ashtray (if equipped)

An ashtray can be installed in the cup holder. ( $\rightarrow$ P. 345)



# MARNING

- When not in use, keep the ashtray closed. In the event of sudden braking, an accident may occur due to an occupant being struck by the open ashtray or ash flying out.
- To prevent fire, fully extinguish matches and cigarettes before putting them in the ashtray, then make sure the ashtray is fully closed.
- To prevent fire, do not place paper or any other type of flammable object in the ashtray.

### Power outlets

Please use as a power supply for electronic goods that use less than 12 VDC/10 A (power consumption of 120 W).


When using electronic goods, make sure that the power consumption of all the connected power outlets is less than 120 W.


▶ Instrument cluster

Open the auxiliary box lid  $(\rightarrow P$ . 346) and open the lid.

Console box

Open the console box lid ( $\rightarrow$ P. 343) and open the lid.





Vehicles without a smart key system:

The power outlets can be used when, the engine switch is in the "ACC" or "ON" position.

Vehicles with a smart key system:

The power outlets can be used when, the engine switch is in ACCESSORY or IGNITION ON mode.

- Cable pass through
  - →P. 344, 346


#### 1

#### NOTICE

- To avoid damaging the power outlets, close the power outlet lids when the power outlets are not in use.
  - Foreign objects or liquids that enter the power outlets may cause a short circuit.
- To prevent battery discharge, do not use the power outlets longer than necessary when the engine is not running.

# Armrest

Fold down the armrest for use.






### **NOTICE**

To prevent damage to the armrest, do not apply too much load on the armrest.

# Assist grips

An assist grip installed on the ceiling can be used to support your body while sitting on the seat.





# **MARNING**

Do not use the assist grip when getting in or out of the vehicle or rising from your seat.




# NOTICE

To prevent damage to the assist grip, do not put a heavy load on the assist grip.

# Coat hooks

Coat hooks are provided on the rear assist grips.



# **⚠** WARNING

Do not hang coat hangers or other hard or sharp objects on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.

# Garage door opener\*


The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.

The garage door opener (HomeLink<sup>®</sup> Universal Transceiver) is manufactured under license from HomeLink<sup>®</sup>.

# Programming HomeLink® (for U.S. owners)

The HomeLink<sup>®</sup> compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.


- 1 Buttons
- (2) Indicator



# ■ Programming the HomeLink®


Point the remote control transmitter for the device 1 to 3 in. (25 to 75 mm) from the HomeLink® control buttons.

Keep the HomeLink® indicator light in view while programming.





\*: If equipped

If the HomeLink<sup>®</sup> indicator light comes on but does not flash, or flashes rapidly for 2 seconds and remains lit, the HomeLink<sup>®</sup> button is already programmed. Use the other buttons or follow the "Reprogramming a Home-Link<sup>®</sup> button" instructions. (→P. 361)



If a HomeLink® button has been programmed for a garage door, check to see if the garage door opens and closes. If the garage door does not operate, see if your remote control transmitter is of the rolling code type. Press and hold the programmed HomeLink® button. The remote control transmitter is of the rolling code type if the HomeLink® indicator light flashes rapidly for 2 seconds and then remains lit. If your transmitter is of the rolling code type, proceed to the heading "Programming a Rolling Code system".





Interior features

4 Repeat the steps above to program another device for any of the remaining HomeLink® buttons.

#### ■ Programming a Rolling Code system (for U.S. owners)

If your device is Rolling Code equipped, follow the steps under the heading "Programming HomeLink®" before proceeding with the steps listed below.

1 Locate the learn button on the ceiling mounted garage door opener motor. The exact location and color of the button may vary by brand of garage door opener motor.

Refer to the operation manual supplied with the garage door opener motor for the location of the learn button.

2 Press the learn button.

Following this step, you have 30 seconds in which to initiate step 3 below.

3 Press and hold the vehicle's programmed HomeLink<sup>®</sup> button for 2 seconds and then release it. Repeat this step once again. The garage door may open.

If the garage door opens, the programming process is complete. If the door does not open, press and release the button a third time. This third press and release will complete the programming process by opening the garage door.

The ceiling mounted garage door opener motor should now recognize the HomeLink® signal and operate the garage door.

Repeat the steps above to program another rolling code system for any of the remaining HomeLink<sup>®</sup> buttons.

# ■ Programming an entry gate (for U.S. owners)/Programming a device in the Canadian market

1 Place the remote control transmitter 1 to 3 in. (25 to 75 mm) away from the HomeLink<sup>®</sup> buttons.

Keep the HomeLink® indicator light in view while programming.

- 2 Press and hold the selected HomeLink® button.
- Repeatedly press and release (cycle) the remote control transmitter for 2 seconds each until step 4 is completed.
- 4 When the HomeLink® indicator light starts to flash rapidly, release the buttons.
- 5 Test the HomeLink® operation by pressing the newly programmed button. Check to see if the gate/device operates correctly.
- Repeat the steps above to program another device for any of the remaining HomeLink<sup>®</sup> buttons.

To program other devices such as home security systems, home door locks or lighting, contact your Toyota dealer for assistance.

### ■ Reprogramming a button

The individual HomeLink<sup>®</sup> buttons cannot be erased but can be reprogrammed. To reprogram a button, follow the "Reprogramming a HomeLink<sup>®</sup> button" instructions.

### Operating HomeLink®

Press the appropriate  $\mathsf{HomeLink}^{\$}$  button. The  $\mathsf{HomeLink}^{\$}$  indicator light should come on.

The HomeLink® compatible transceiver in your vehicle continues to send a signal for up to 20 seconds as long as the button is pressed.


### Reprogramming a HomeLink® button

Press and hold the desired HomeLink<sup>®</sup> button. After 20 seconds, the HomeLink<sup>®</sup> indicator light will start flashing slowly. Keep pressing the HomeLink<sup>®</sup> button and press and hold the transmitter button until the HomeLink<sup>®</sup> indicator light changes from a slow to a rapid flash. Release the buttons.

### Erasing the entire HomeLink® memory (all three programs)

Press and hold the 2 outside buttons for 10 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the  $HomeLink^{\circledR}$  memory.



6

Interior features

### ■ Before programming

- Install a new battery in the remote control transmitter.
- ■The battery side of the remote control transmitter must be pointed away from the HomeLink<sup>®</sup> button.

#### ■ To prevent battery discharge

Vehicles without a smart key system:

HomeLink<sup>®</sup> will turn off if a door has not been opened and closed for 20 minutes or the engine switch is left turned off. (After which programming cannot be completed.) Open and close a door or turn the engine switch to the "ACC" position to turn HomeLink<sup>®</sup> on. We recommend programming while the engine switch is in the "ACC" position.

Vehicles with a smart key system:

HomeLink<sup>®</sup> will turn off if a door has not been opened and closed for 20 minutes or the engine switch is left turned off. (After which programming cannot be completed.) Open and close a door or turn the engine switch to ACCESSORY mode to turn HomeLink<sup>®</sup> on. We recommend programming while the engine switch is in ACCESSORY mode.

### ■ Certification for the garage door opener

▶ U.S.A.

FCC ID: CB2051AHL4/CB251AHL4NR

NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### ▶ Canada

IC ID: 051AHL4/51AHL4NR

NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### ■When support is necessary

Visit on the web at www.homelink.com or call 1-800-355-3515.

### **MARNING**

### When programming a garage door or other remote control devices

The garage door or other devices may operate, so ensure people and objects are out of danger to prevent potential harm.

### Conforming to federal safety standards

Do not use the HomeLink® compatible transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an interfering object. A door or device without these features increases the risk of death or serious injury.

### Safety Connect\*


Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Toyota's designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

By using the Safety Connect service, you are agreeing to be bound by the Telematics Subscription Service Agreement and its Terms and Conditions, as in effect and amended from time to time, a current copy of which is available at Toyota.com. All use of the Safety Connect service is subject to such then-applicable Terms and Conditions.

### **■** System components

- 1 Microphone
- (2) LED light indicators
- ③ "SOS" button



\*: If equipped

#### ■ Services

Subscribers have the following Safety Connect services available:

- Automatic Collision Notification\*
   Helps drivers receive necessary response from emergency service providers. (→P. 366)
- \*: U.S. Patent No. 7,508,298 B2
- Stolen Vehicle Location
   Helps drivers in the event of vehicle theft. (→P. 367)
- Emergency Assistance Button (SOS)
   Connects drivers to response-center support. (→P. 367)
- Enhanced Roadside Assistance
   Provides drivers various on-road assistance. (→P. 367)

### ■ Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services. A variety of subscription terms are available for purchase. Contact your Toyota dealer, call 1-800-331-4331, or push the "SOS" button in your vehicle for further subscription details.

### ■ Safety Connect Services Information

- Phone calls using the vehicle's Bluetooth® technology will not be possible during Safety Connect.
- Safety Connect is available beginning Fall 2009 on select Toyota models. Contact with the Safety Connect response center is dependent upon the telematics device being in operative condition, cellular connection availability, and GPS satellite signal reception, which can limit the ability to reach the response center or receive emergency service support. Enrollment and Telematics Subscription Service Agreement are required. A variety of subscription terms are available; charges vary by subscription term selected.
- Automatic Collision Notification, Emergency Assistance, Stolen Vehicle Location, and Enhanced Roadside Assistance will function in the United States, including Hawaii and Alaska, and in Canada. No Safety Connect services will function outside of the United States in countries other than Canada.
- Safety Connect services are not subject to section 255 of the Telecommunications Act and the device is not TTY compatible.

#### Languages

The Safety Connect response center will offer support in multiple languages. The Safety Connect system will offer voice prompts in English and Spanish. Please indicate your language of choice when enrolling.

### ■ When contacting the response center

You may be unable to contact the response center if the network is busy.

### Safety Connect LED light Indicators

When the engine switch is turned to IGNITION ON mode, the red indicator light comes on for 2 seconds then turns off. Afterward, the green indicator light comes on, indicating that the service is active.

The following indicator light patterns indicate specific system usage conditions:

- Green indicator light on = Active service
- Green indicator light flashing = Safety Connect call in process
- Red indicator light (except at vehicle start-up) = System malfunction (contact your Toyota dealer)
- No indicator light (off) = Safety Connect service not active

### Safety Connect services

### **■** Automatic Collision Notification

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

#### ■ Stolen Vehicle Location

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-331-4331 and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at Toyota.com.

### ■ Emergency Assistance Button ("SOS")

In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.

### **■** Enhanced Roadside Assistance

Enhanced Roadside Assistance adds GPS data to the already included warranty-based Toyota roadside service.

Subscribers can press the "SOS" button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Enhanced Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at Toyota.com.

### Safety information for Safety Connect

Important! Read this information before using Safety Connect.

### **■** Exposure to radio frequency signals

The Safety Connect system installed in your vehicle is a low-power radio transmitter and receiver. It receives and also sends out radio frequency (RF) signals.

In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for mobile wireless phones. Those guidelines are consistent with the safety standards previously set by the following U.S. and international standards bodies.

- ANSI (American National Standards Institute) C95.1 [1992]
- NCRP (National Council on Radiation Protection and Measurement) Report 86 [1986]
- ICNIRP (International Commission on Non-Ionizing Radiation Protection) [1996]

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. Over 120 scientists, engineers, and physicians from universities, and government health agencies and industries reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of Safety Connect complies with the FCC guidelines in addition to those standards.

#### ■ Certification for Safety Connect

FCC ID: O6Y-CDMRF101 FCC ID: XOECDMRF101B

FCC ID: N7NGTM2

NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Compass\*

The compass on the inside rear view mirror indicates the direction in which the vehicle is heading.

### Operation

To turn the compass on or off, press and hold the switch for 3 seconds.




### Displays and directions

Display	Direction
N	North
NE	Northeast
E	East
SE	Southeast
S	South
SW	Southwest
W	West
NW	Northwest

\*: If equipped

### Calibrating the compass



The direction display deviates from the true direction determined by the earth's magnetic field. The amount of deviation varies according to the geographic position of the vehicle.


If you cross over a map boundary shown in illustration, the compass will deviate.

To obtain higher precision or perfect calibration, refer to the following.

### **■** Deviation calibration

- 1 Stop the vehicle.
- 2 Press and hold the switch.

A number (1 to 15) appears on the compass display.




3 Press the switch and referring to the map above, select the number of the zone where you are.

If the direction is displayed several seconds after adjustment, the calibration is complete.

When "C" appears on the display, drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until a direction is displayed.



### ■ Conditions unfavorable to correct operation

The compass may not show the correct direction in the following conditions:

- The vehicle is stopped immediately after turning.
- The vehicle is on an inclined surface.
- The vehicle is in a place where the earth's magnetic field is subject to interference by artificial magnetic fields (underground car park/parking lot, under a steel tower, between buildings, roof car park/parking lot, near an intersection, near a large vehicle, etc.).
- The vehicle has become magnetized. (There is a magnet or metal object near the inside rear view mirror.)
- The battery has been disconnected.
- A door is open.

### WARNING

### While driving the vehicle

Do not adjust the display. Adjust the display only when the vehicle is stopped.

### When doing the circling calibration

Secure a wide space, and watch out for people and vehicles in the neighborhood. Do not violate any local traffic rules while performing circling calibration.

Interior features

### **↑** NOTICE

### ■To avoid compass malfunctions

Do not place magnets or any metal objects near the inside rear view mirror. Doing this may cause the compass sensor to malfunction.

### ■ To ensure normal operation of the compass

- Do not perform circling calibration of the compass in a place where the earth's magnetic field is subject to interference by artificial magnetic fields.
- During calibration, do not operate electric systems (moon roof, power windows, etc.) as they may interfere with the calibration.

### 7

### Maintenance and care

7-1.	Maintenance and care
	Cleaning and protecting
	the vehicle exterior 374
	Cleaning and protecting
	the vehicle interior 377
<b>7-2</b> .	Maintenance
	Maintenance
	requirements380
	General maintenance 383
	Emission inspection and
	maintenance (I/M)
	programs387
7-3.	- · · · <b>,</b> · · · · · · · · · · · · · · · · · · ·
	maintenance
	Do-it-yourself service
	precautions 388
	Hood 390
	Positioning a floor jack 391
	Engine compartment 392
	Tires 403
	Tire inflation pressure 413
	Wheels416
	Air conditioning filter 418
	Wireless remote control/
	electronic key battery 420
	Checking and replacing
	fuses 424
	Light bulbs 427

# Cleaning and protecting the vehicle exterior

## Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

### ■ Automatic car washes

- Fold the mirrors before washing the vehicle. Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.
- Vehicles with rear spoiler: In certain automatic car washes, the rear spoiler may interfere with machine operation. This may prevent the vehicle from being cleaned properly or result in damage to the rear spoiler.

### ■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows.
- Before using the car wash, check that the fuel filler door on your vehicle is closed properly.

#### ■When using a car wash (vehicles with a smart key system)

If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:

- Place the key in a position 6 ft. (2 m) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- Set the electronic key to battery-saving mode to disable the smart key system. (→P. 115)

#### ■ Aluminum wheels (if equipped)

 Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners.

Use the same mild detergent and wax as used on the paint.

- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

#### Bumpers

Do not scrub with abrasive cleaners.



### When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components etc. to catch fire.

### Precautions regarding the exhaust pipes

Exhaust gasses cause the exhaust pipes to become quite hot.

When washing the vehicle, be careful not to touch the pipes until it has cooled sufficiently, as touching a hot exhaust pipes can cause burns.

## Precaution regarding the rear bumper with Blind Spot Monitor (if equipped)

If the paint of the rear bumper is chipped or scratched, the system may malfunction. If this occurs, avoid using the system and consult your Toyota dealer.

### **♠** NOTICE

## To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

- Wash the vehicle immediately in the following cases:
  - · After driving near the sea coast
  - · After driving on salted roads
  - If coal tar or tree sap is present on the paint surface
  - If dead insects, insect droppings or bird droppings are present on the paint surface
  - After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
  - · If the vehicle becomes heavily soiled with dust or mud
  - If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

### ■Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush.
   This may damage the surfaces of the lights.
- Do not apply wax to the surfaces of the lights.
   Wax may cause damage to the lenses.

#### When using a high pressure car wash

Do not bring the nozzle tip close to boots (rubber or resin manufactured cover), connectors or the following parts. The parts may be damaged if they come into contact with high-pressure water.

- · Traction related parts
- Steering parts

- · Suspension parts
- · Brake parts

# Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

### Protecting the vehicle interior

- Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.
- If dirt cannot be removed, wipe it off with a soft cloth dampened with neural detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

### Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe off any excess dirt and dust with a soft cloth dampened with diluted detergent.
  - Use a diluted water solution of approximately 5% neutral wool detergent.
- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area.

### Cleaning the synthetic leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

#### ■ Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

#### ■Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. Wipe dirty surfaces and let them dry. Excellent results are obtained by keeping the carpet as dry as possible.

#### ■ Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.



### WARNING

### Water in the vehicle

- Do not splash or spill liquid in the vehicle. Doing so may cause electrical components etc. to malfunction or catch
- Do not get any of the SRS components or wiring in the vehicle interior wet. (→P. 36)
  - An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.
- Vehicles with wireless charger:
  - Do not let the wireless charger (→P. 347) get wet. Failure to do so may cause the charger to become hot and cause burns or could cause electric shock resulting in death or serious injury.

### Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

care

### **№** NOTICE

### Cleaning detergents

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
  - Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach
  - Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

### Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- Remove any dust or dirt from leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time.
   Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

### Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

## When cleaning the inside of the windshield (vehicles with LDA [Lane Departure Alert] and Automatic High Beam)

Be careful not to touch the camera sensor ( $\rightarrow$ P. 199).

If the camera is accidentally scratched or hit, LDA and Automatic High Beam may not operate properly or may cause a malfunction.

### Cleaning the inside of the rear window

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.
- Be careful not to scratch or damage the heater wires or antenna.

### **Maintenance requirements**

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. It is the owner's responsibility to perform regular checks. Toyota recommends the following maintenance:

### General maintenance

General maintenance should be performed on a daily basis. This can be done by yourself or by a Toyota dealer.

### Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".

### Do-it-yourself maintenance

You can perform some maintenance procedures by yourself. Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Toyota Repair Manuals is recommended.

For details about warranty coverage, refer to the separate "Owner's Warranty Information Booklet" or "Owner's Manual Supplement".

### ■ Repair and replacement

It is recommended that genuine Toyota parts be used for repairs to ensure performance of each system. If non-Toyota parts are used in replacement or if a repair shop other than a Toyota dealer performs repairs, confirm the warranty coverage.

### ■ Resetting the message indicating maintenance is required (U.S.A. only)

After the required maintenance is performed according to the maintenance schedule, please reset the message.

To reset the message, follow the procedure described below:

- ▶ Using the trip meter
- 1 Vehicles without a smart key system: Turn the engine switch to the "LOCK" position with the trip meter A reading shown.
  - Vehicles with a smart key system: Turn the engine switch off with the trip meter A reading shown.
- 2 Vehicles without a smart key system: While pressing the trip meter reset button (→P. 78), turn the engine switch to the "ON" position (do not start the engine, reset mode will be canceled).
  - Vehicles with a smart key system: While pressing the trip meter reset button ( $\rightarrow$ P. 78), turn the engine switch to the IGNITION ON mode (do not start the engine, otherwise the reset mode will be canceled).
- 3 Continue to press and hold the button until the trip meter displays "000000".
- ▶ Using the multi-information display
- While the engine is running, switch the multi-information display to the "Settings" screen. (→P. 77)
- 2 Select "Maintenance Reset" on the "Settings" screen.
- 3 Select "Yes" on the "Maintenance Reset" screen.

"Maintenance Reset Complete" will be displayed on the multi-information display when the reset procedure has been completed.

### ■ Allow inspection and repairs to be performed by a Toyota dealer

- Toyota technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operations of all systems on your vehicle.
- Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Toyota dealer will promptly take care of it.

### **WARNING**

### If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

### Handling of the battery

- Engine exhaust, some of its constituents, and a wide variety of automobile components contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. Work in a well ventilated area.
- Oils, fuels and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
- Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (→P. 400)

### **General maintenance**

Listed below are the general maintenance items that should be performed at the intervals specified in the "Owner's Warranty Information Booklet" or "Owner's Manual Supplement/Scheduled Maintenance Guide". It is recommended that any problem you notice should be brought to the attention of your Toyota dealer or qualified service shop for advice.

### Engine compartment

Items	Check points
Battery	Check the connections. (→P. 400)
Brake fluid	Is the brake fluid at the correct level? $(\rightarrow P. 399)$
Engine coolant	Is the engine coolant at the correct level? $(\rightarrow P. 397)$
Engine oil	Is the engine oil at the correct level? (→P. 394)
Exhaust system	There should not be any fumes or strange sounds.
Radiator/condenser	The radiator and condenser should be free from foreign objects. (→P. 398)
Washer fluid	Is there sufficient washer fluid? (→P. 402)

### Vehicle interior

Items	Check points
Accelerator pedal	The accelerator pedal should move smoothly (without uneven pedal effort or catching).
Automatic transmission "Park" mechanism	<ul> <li>When parked on a slope and the shift lever is in P, is the vehicle securely stopped?</li> </ul>
Brake pedal	<ul> <li>Does the brake pedal move smoothly?</li> <li>Does the brake pedal have appropriate clearance from the floor?</li></ul>
Brakes	<ul> <li>The vehicle should not pull to one side when the brakes are applied.</li> <li>The brakes should work effectively.</li> <li>The brake pedal should not feel spongy.</li> <li>The brake pedal should not get too close to the floor when the brakes are applied.</li> </ul>
Head restraints (front seat)	Do the head restraints move smoothly and lock securely?
Indicators/buzzers	Do the indicators and buzzers function properly?
Lights	Do all the lights come on?
Parking brake	<ul> <li>Does the parking brake pedal move smoothly?</li> <li>When parked on a slope and the parking brake is on, is the vehicle securely stopped?</li> </ul>

Items	Check points
Seat belts	<ul> <li>Do the seat belts operate smoothly?</li> <li>The seat belts should not be damaged.</li> </ul>
Seats	Do the seat controls operate properly?
Steering wheel	<ul> <li>Does the steering wheel rotate smoothly?</li> <li>Does the steering wheel have the correct amount of free play?</li> <li>There should not be any strange sounds coming from the steering wheel.</li> </ul>

### Vehicle exterior

Items	Check points
Doors/trunk	Do the doors/trunk operate smoothly?
Engine hood	Does the engine hood lock system work properly?
Fluid leaks	There should not be any signs of fluid leakage after the vehicle has been parked.
Tires	<ul> <li>Is the tire inflation pressure correct?</li> <li>The tires should not be damaged or excessively worn.</li> <li>Have the tires been rotated according to the maintenance schedule?</li> <li>The wheel nuts should not be loose.</li> </ul>
Windshield wipers	<ul> <li>The wiper blades should not show any signs of cracking, splitting, wear, contamination or deforma- tion.</li> <li>The wiper blades should clear the windshield without streaking or skipping.</li> </ul>

### **MARNING**

### If the engine is running

Turn the engine off and ensure that there is adequate ventilation before performing maintenance checks.

# Emission inspection and maintenance (I/M) programs

Some states have vehicle emission inspection programs which include OBD (On Board Diagnostics) checks. The OBD system monitors the operation of the emission control system.

### If the malfunction indicator lamp comes on

The OBD system determines that a problem exists somewhere in the emission control system. Your vehicle may not pass the I/M test and may need to be repaired. Contact your Toyota dealer to service the vehicle.

### Your vehicle may not pass the I/M test in the following situations:

- When the battery is disconnected or discharged
   Readiness codes that are set during ordinary driving are erased.
   Also, depending on your driving habits, the readiness codes may not be completely set.
- When the fuel tank cap is loose
   The malfunction indicator lamp comes on indicating a temporary malfunction and your vehicle may not pass the I/M test.

# When the malfunction indicator lamp still remains on after several driving trips

The error code in the OBD system will not be cleared unless the vehicle is driven 40 or more times.

### If your vehicle does not pass the I/M test

Contact your Toyota dealer to prepare the vehicle for re-testing.

## **Do-it-yourself service precautions**

If you perform maintenance by yourself, be sure to follow the correct procedure as given in these sections.

Items	Parts and tools
Battery condition (→P. 400)	<ul> <li>Warm water</li> <li>Baking soda</li> <li>Grease</li> <li>Conventional wrench (for terminal clamp bolts)</li> </ul>
Brake fluid level (→P. 399)	FMVSS No.116 DOT 3 or SAE J1703 brake fluid     Rag or paper towel     Funnel (used only for adding brake fluid)
Engine coolant level (→P. 397)	<ul> <li>"Toyota Super Long Life Coolant" or a similar high quality ethylene glycol-based non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology U.S.A.:</li> <li>"Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water.</li> <li>Canada:</li> <li>"Toyota Super Long Life Coolant" is pre-mixed with 55% coolant and 45% deionized water.</li> <li>Funnel (used only for adding engine coolant)</li> </ul>
Engine oil level (→P. 394)	<ul> <li>"Toyota Genuine Motor Oil" or equivalent</li> <li>Rag or paper towel</li> <li>Funnel (used only for adding engine oil)</li> </ul>
Fuses (→P. 424)	Fuse with same amperage rating as original
Light bulbs (→P. 427)	<ul> <li>Bulb with same number and wattage rating as original</li> <li>Phillips-head screwdriver</li> <li>Flathead screwdriver</li> <li>Wrench</li> </ul>
Radiator/con- denser (→P. 398)	_
Tire inflation pressure (→P. 413)	Tire pressure gauge     Compressed air source
Washer fluid (→P. 402)	<ul> <li>Water or washer fluid containing antifreeze (for winter use)</li> <li>Funnel (used only for adding water or washer fluid)</li> </ul>

### WARNING

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

### When working on the engine compartment

- Keep hands, clothing and tools away from the moving fan and engine drive belt.
- Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper and rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel or the battery. Fuel and battery fumes are flammable.
- Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.

### ■When working near the electric cooling fans or radiator grille

Vehicles without a smart key system:

Be sure the engine switch is off. With the engine switch in the "ON" position, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high.  $(\rightarrow P. 398)$ 

Vehicles with a smart key system:

Be sure the engine switch is off. With the engine switch in IGNITION ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high.  $(\rightarrow P. 398)$ 

### Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.



### NOTICE

### If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air.


7

Maintenance and car


### Hood

### Release the lock from the inside of the vehicle to open the hood.

1 Pull the hood lock release lever.
The hood will pop up slightly.



2 Pull up the auxiliary catch lever and lift the hood.



### **MARNING**

### Pre-driving check

Check that the hood is fully closed and locked.


If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

## Positioning a floor jack

When using a floor jack, follow the instructions in the manual provided with the jack and perform the operation safely.


When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

### **♦** Front




### Rear

### ▶ 2.5 L 4-cylinder (2AR-FE) engine




▶ 3.5 L V6 (2GR-FE) engine



### **Engine compartment**

### ▶ 2.5 L 4-cylinder (2AR-FE) engine




- 1 Fuse boxes (if equipped)
  - (→P. 424)
- ② Engine oil filler cap (→P. 395)
- ③ Engine oil level dipstick (→P. 394)
- (4) Brake fluid reservoir

(→P. 399)

- ⑤ Battery
- (→P. 400)
- 6 Radiator
- (→P. 398)
- 7 Electric cooling fans
- 8 Condenser
- (→P. 398)
- 9 Engine coolant reservoir
  - (→P. 397)
- ① Washer fluid tank (→P. 402)

### ▶ 3.5 L V6 (2GR-FE) engine



- (1) Fuse boxes
- (→P. 424)
- 6 Radiator (7) Electric cooling fans
- (→P. 398)

- (2) Engine oil filler cap (→P. 395)
- 3 Engine oil level dipstick
  - 8 Condenser
- (→P. 398)
- (→P. 394)

(4) Brake fluid reservoir

- (9) Engine coolant reservoir
- (→P. 399)

(→P. 397)


- (5) Battery
- (→P. 400)
- ① Washer fluid tank (→P. 402)


### Engine oil

With the engine at operating temperature and turned off, check the oil level on the dipstick.

### ■ Checking the engine oil


- 1 Park the vehicle on level ground. After warming up the engine and turning it off, wait more than 5 minutes for the oil to drain back into the bottom of the engine.
- 2 Holding a rag under the end, pull the dipstick out.
- ▶ 2.5 L 4-cylinder (2AR-FE) ▶ 3.5 L V6 (2GR-FE) engine engine






- 3 Wipe the dipstick clean.
- 4 Reinsert the dipstick fully.
- 5 Holding a rag under the end, pull the dipstick out and check the oil level.
- ▶ Flat dipstick

▶ Non-flat dipstick





- (1) Low
- (2) Normal


(3) Excessive

The shape of the dipstick may differ depending on the type of vehicle or engine.

6 Wipe the dipstick and reinsert it fully.

### ■ Adding engine oil

If the oil level is below or near the low level mark, add engine oil of the same type as that already in the engine.



Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection	→P. 501
Oil quantity (Low → Full)	1.6 qt. (1.5 L, 1.3 lmp. qt.)
Items	Clean funnel

- 1 Remove the oil filler cap by turning it counterclockwise.
- 2 Add engine oil slowly, checking the dipstick.
- 3 Install the oil filler cap by turning it clockwise.

### ■ Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance intervals.

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used
- When driving at high engine speeds or with a heavy load, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

### MARNING

### Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation and skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the
  - Call your Toyota dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.



### ■To prevent serious engine damage

Check the oil level on a regular basis.

#### When replacing the engine oil


- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, or the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.

# Engine coolant

The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir when the engine is cold.

- (1) Reservoir cap
- (2) "F" line
- (3) "L" line

If the level is on or below the "L" line, add coolant up to the "F" line.  $(\rightarrow P. 492)$ 



#### ■ Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

#### U.S.A.:

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Minimum temperature: -31°F [-35°C])

#### Canada:

"Toyota Super Long Life Coolant" is a mixture of 55% coolant and 45% deionized water. (Minimum temperature: -44°F [-42°C])

For more details about engine coolant, contact your Toyota dealer.

# ■ If the coolant level drops within a short time of replenishing

Visually check the radiator, hoses, engine coolant reservoir caps, drain cock and water pump.

If you cannot find a leak, have your Toyota dealer test the cap and check for leaks in the cooling system.

# MARNING

#### When the engine is hot

Do not remove the engine coolant reservoir cap or the radiator cap. The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.



## **NOTICE**

#### When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

## If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

# Radiator and condenser

Check the radiator and condenser and clear away any foreign objects. If either of the above parts is extremely dirty or you are not sure of their condition, have your vehicle inspected by your Toyota dealer.



# ♠ WARNING

# When the engine is hot

Do not touch the radiator or condenser as they may be hot and cause serious injuries, such as burns.


care

# Brake fluid

# ■ Checking fluid level

The brake fluid level should be between the "MAX" and "MIN" lines on the tank.

- ① "MAX"
- (2) "MIN"



# Adding fluid

Make sure to check the fluid type and prepare the necessary item.

Fluid type	FMVSS No.116 DOT 3 or SAE J1703 brake fluid
Item	Clean funnel

#### ■ Brake fluid can absorb moisture from the air

Excess moisture in the brake fluid can cause a dangerous loss of braking efficiency. Use only newly opened brake fluid.



# **WARNING**

# When filling the reservoir

Take care as brake fluid can harm your hands and eyes and damage painted surfaces.

If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.



## **NOTICE**

# If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear out or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, there may be a serious problem.


# Battery

Check the battery as follows.

# ■ Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.

- (1) Terminals
- (2) Hold-down clamp



# ■ Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.

# After recharging/reconnecting the battery (vehicles with a smart key system)

- Unlocking the doors using the smart key system may not be possible immediately after reconnecting the battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- Start the engine with the engine switch in ACCESSORY mode. The engine may not start with the engine switch turned off. However, the engine will operate normally from the second attempt.
- The engine switch mode is recorded by the vehicle. If the battery is reconnected, the vehicle will return the engine switch mode to the status it was in before the battery was disconnected. Make sure to turn off the engine before disconnecting the battery. Take extra care when connecting the battery if the engine switch mode prior to discharge is unknown.

If the system will not start even after multiple attempts, contact your Toyota dealer.

# MARNING

#### Chemicals in the battery

Batteries contain poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the battery:

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.

#### ■ Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is insufficient ventilation.

# How to recharge the battery

Only perform a slow charge (5 A or less). The battery may explode if charged at a guicker rate.

### Emergency measures regarding electrolyte

- If electrolyte gets in your eyes
  - Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin
   Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes
   It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte
   Drink a large quantity of water or milk. Get emergency medical attention immediately.



### **NOTICE**


## When recharging the battery

Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.

# Washer fluid

Add washer fluid in the following situations:

- A washer does not work.
- The warning message appears on the multi-information display. (→P. 460)





# **MARNING**

# When adding washer fluid

Do not add washer fluid when the engine is hot or running as washer fluid contains alcohol and may catch fire if spilled on the engine etc.



# ∧ NOTICE

# Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.

# Diluting washer fluid

Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.


# **Tires**

Replace or rotate tires in accordance with maintenance schedules and treadwear.

# Checking tires

Check if the treadwear indicators are showing on the tires. Also check the tires for uneven wear, such as excessive wear on one side of the tread.

Check the spare tire condition and pressure if not rotated.



- 1 New tread
- (2) Worn tread
- (3) Treadwear indicator

The location of treadwear indicators is shown by a "TWI" or " $\Delta$ " mark, etc., molded into the sidewall of each tire.


Replace the tires if the treadwear indicators are showing on a tire.

# Tire rotation

Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Toyota recommends that tire rotation is carried out at the same interval as tire inspection.

Do not fail to initialize the tire pressure warning system after tire rotation.




# Tire pressure warning system (if equipped)

Your vehicle is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise.

- ▶ Vehicles without a tire inflation pressure display function

  If the tire pressure drops below a predetermined level, the driver is warned by a warning light. (→P. 448)
- ▶ Vehicles with a tire inflation pressure display function
- If the tire pressure drops below a predetermined level, the driver is warned by a screen display and a warning light. (→P. 459)
- The tire pressure detected by the tire pressure warning system can be displayed on the multi-information display.



## ◆ Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. Have tire pressure warning valves and transmitter ID codes registered by your Toyota dealer. ( $\rightarrow$ P. 405)

# Initializing the tire pressure warning system

- The tire pressure warning system must be initialized in the following circumstances:
  - When the tire inflation pressure is changed such as when changing traveling speed or load weight.
  - When the tire inflation pressure is changed such as when the tire size is changed.
  - When rotating the tires.

When the tire pressure warning system is initialized, the current tire inflation pressure is set as the benchmark pressure.

# ■ How to initialize the tire pressure warning system


- 1 Park the vehicle in a safe place and turn the engine switch off. Initialization cannot be performed while the vehicle is moving.
- 2 Adjust the tire inflation pressure to the specified cold tire inflation pressure level. (→P. 504)

Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.

- 3 Vehicles without a smart key system:
  Turn the engine switch to the "ON" position.
  Vehicles with a smart key system:
  Turn the engine switch to IGNITION ON mode.
- 4 Press and hold the tire pressure warning reset switch until the tire pressure warning light blinks slowly 3 times.

  "--" will be displayed for inflation pressure of each tire on the multi-information display while the tire pressure warning system determines the position of each tire.

When position of each tire is determined, the inflation pressure of each tire will be displayed on the multi-information display.



Drive the vehicle at approximately 25 mph (40 km/h) or more for approximately 10 minutes.

When initialization is complete, the inflation pressure of each tire will be displayed on the multi-information display.

Initialization will take longer than approximately 10 minutes if the vehicle is stopped for a long time, such as at traffic signals.

## Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code. Have the ID code registered by your Toyota dealer.

# ■When to replace your vehicle's tires

Tires should be replaced if:

- The treadwear indicators are showing on a tire.
- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult with your Toyota dealer.

# ■Replacing tires and wheels (vehicles with a tire pressure warning system)

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 10 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.

#### ■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.

# ■ Routine tire inflation pressure checks (vehicles with a tire pressure warning system)

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

#### ■ Tire inflation pressure

→P. 85


# ■Low profile tires (18-inch tires)

Generally, low profile tires will wear more rapidly and tire grip performance will be reduced on snowy and/or icy roads when compared to standard tires. Be sure to use snow tires or tire chains on snowy and/or icy roads and drive carefully at a speed appropriate for road and weather conditions.

#### ■ Maximum load of tire

Check that the maximum load of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.

For the GAWR, see the Certification Label. For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire. (→P. 510)



#### ■ Tire types

## Summer tires

Summer tires are high-speed performance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

#### All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions as well as for use year-round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving.

#### Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restrictions. Snow tires should be installed on all wheels. ( $\rightarrow$ P. 234)

■Initializing the tire pressure warning system (vehicles with a tire pressure warning system)

Initialize the system with the tire inflation pressure adjusted to the specified level.

■If the tread on snow tires wears down below 0.16 in. (4 mm)

The effectiveness of the tires as snow tires is lost.

If you press the tire pressure warning reset switch accidentally (vehicles with a tire pressure warning system)

If initialization is performed, adjust the tire inflation pressure to the specified level and initialize the tire pressure warning system again.

# Situations in which the tire pressure warning system may not operate properly (vehicles with a tire pressure warning system)

- In the following cases, the tire pressure warning system may not operate properly.
  - If non-genuine Toyota wheels are used.
  - A tire has been replaced with a tire that is not an OE (Original Equipment) tire.
  - A tire has been replaced with a tire that is not of the specified size.
  - Tire chains etc. are equipped.
  - If a window tint that affects the radio wave signals is installed.
  - If there is a lot of snow or ice on the vehicle, particularly around the wheels or wheel housings.
  - If the tire inflation pressure is extremely higher than the specified level.
  - If tires not equipped with tire pressure warning valves and transmitters are used.
  - If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
- Performance may be affected in the following situations.
  - Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
  - When carrying a portable radio, cellular phone, cordless phone or other wireless communication device
  - Vehicles with a tire inflation pressure display function: If tire position information is not correctly displayed due to the radio wave conditions, the display may be corrected by driving and changing the radio wave conditions.
- When the vehicle is parked, the time taken for the warning to start or go off could be extended.
- When tire inflation pressure declines rapidly for example when a tire has burst, the warning may not function.

# ■The initialization operation (vehicles with a tire pressure warning system)

- Make sure to carry out initialization after adjusting the tire inflation pressure.
  - Also, make sure the tires are cold before carrying out initialization or tire inflation pressure adjustment.
- If you have accidentally turned the engine switch to the "LOCK" position (vehicles without a smart key system) or off (vehicles with a smart key system) during initialization, it is not necessary to press the reset switch again as initialization will restart automatically when the engine switch has been turned to the "ON" position (vehicles without a smart key system) or IGNITION ON mode (vehicles with a smart key system) for the next time.
- If you accidentally press the reset switch when initialization is not necessary, adjust the tire inflation pressure to the specified level when the tires are cold, and conduct initialization again.
- While the position of each tire is being determined and the inflation pressures are not being displayed on the multi-information display, if the inflation pressure of a tire drops, the tire pressure warning light will come on.

# ■ Warning performance of the tire pressure warning system (vehicles with a tire pressure warning system)

The warning of the tire pressure warning system will change in accordance with the conditions under which it was initialized. For this reason, the system may give a warning even if the tire pressure does not reach a low enough level, or if the pressure is higher than the pressure that was adjusted to when the system was initialized.

# ■When initialization of the tire pressure warning system has failed (vehicles with a tire pressure warning system)

Initialization may take longer to complete if the vehicle is driven on an unpaved road. When performing initialization, drive on a paved road if possible. Depending on the driving environment and condition of the tires, initialization will be completed in approximately 10 minutes. If initialization is not complete after driving approximately 10 minutes, continue driving for a while.

If the inflation pressure of each tire is not displayed after driving for approximately 1 hour, perform the following procedure.

Park the vehicle in a safe place for approximately 20 minutes. Then drive straight (with occasional left and right turns) at approximately 25mph (40 km/h) or more for approximately 10 to 20 minutes. However, in the following situations, the tire inflation pressure will not be recorded and the system will not operate properly. Perform initialization again.

- When operating the tire pressure warning reset switch, the tire pressure warning light does not blink 3 times.
- After performing initialization, the tire pressure warning light blinks for 1 minute then stays on while driving.

If the inflation pressure of each tire is still not displayed, have the vehicle inspected by your Toyota dealer.

# ■ Tire pressure warning system certification

FCC ID: HYQ23AAP FCC ID: HYQ23AAN FCC ID: HYQ23AAC

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: PAXPMVC015 FCC ID: PAXPMVC010

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# **WARNING**

# When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Toyota.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle. Do not use tires if you do not know how they were used previously.

# When initializing the tire pressure warning system (vehicles with a tire pressure warning system)

Do not operate the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

# **NOTICE**

- Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps (vehicles with a tire pressure warning system)
- When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact your Toyota dealer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.
- When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.
- To avoid damage to the tire pressure warning valves and transmitters (vehicles with a tire pressure warning system)

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire.  $(\rightarrow P. 404)$ 

# Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes.

These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.


### Low profile tires (18-inch tires)

Low profile tires may cause greater damage than usual to the tire wheel when sustaining impact from the road surface. Therefore, pay attention to the following:

- Be sure to use proper tire inflation pressure. If tires are under-inflated, they may be damaged more severely.
- Avoid potholes, uneven pavement, curbs and other road hazards. Failure to do so may lead to severe tire and wheel damage.
- If tire inflation pressure of each tire becomes low while driving Do not continue driving, or your tires and/or wheels may be ruined.

# Tire inflation pressure

The recommended cold tire inflation pressure and tire size are displayed on the tire and loading information label. ( $\rightarrow$ P. 504)




7

Maintenance and care

# Inspection and adjustment procedure

- 1) Tire valve
- (2) Tire pressure gauge



- 1 Remove the tire valve cap.
- 2 Press the tip of the tire pressure gauge onto the tire valve.
- 3 Read the pressure using the gauge gradations.
- 4 If the tire inflation pressure is not at the recommended level, adjust the pressure.
  - If you add too much air, press the center of the valve to deflate.
- After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.
- 6 Put the tire valve cap back on.

#### ■ Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month.

Do not forget to check the spare.

## **■** Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel economy
- Reduced driving comfort and poor handling
- Reduced tire life due to wear
- Reduced safety
- Damage to the drivetrain

If a tire needs frequent inflating, have it checked by your Toyota dealer.

#### ■Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold. If your vehicle has been parked for at least 3 hours or has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge. It is difficult to judge if a tire is properly inflated based only on its appearance.
- It is normal for the tire inflation pressure to be higher after driving as heat is generated in the tire. Do not reduce tire inflation pressure after
- Never exceed the vehicle capacity weight. Passengers and luggage weight should be placed so that the vehicle is balanced.



# WARNING

# Proper inflation is critical to save tire performance

Keep your tires properly inflated.

If the tires are not properly inflated, the following conditions may occur which could lead to an accident resulting in death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Air leaking from between tire and wheel
- Wheel deformation and/or tire damage
- Greater possibility of tire damage while driving (due to road hazards, expansion joints, sharp edges in the road, etc.)



# NOTICE

# When inspecting and adjusting tire inflation pressure

Be sure to put the tire valve caps back on.

If a valve cap is not installed, dirt or moisture may get into the valve and cause an air leak, resulting in decreased tire inflation pressure.

# **Wheels**

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause a loss of handling control.

## Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width and inset\*.

Replacement wheels are available at your Toyota dealer.

\*: Conventionally referred to as "offset".

Toyota does not recommend using the following:

- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

# Aluminum wheel precautions (if equipped)

- Use only Toyota wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1000 miles (1600 km).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Toyota genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

# ■When replacing wheels (vehicles with a tire pressure warning system)

The wheels of your vehicle are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. ( $\rightarrow$ P. 404)


## WARNING

# ■When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in a loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

## ■When installing the wheel nuts

Be sure to install the wheel nuts with the tapered ends facing inward. Installing the nuts with the tapered ends facing outward can cause the wheel to break and eventually cause the wheel to come off while driving, which could lead to an accident resulting in death or serious injury.



• Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts.



#### NOTICE

# Replacing tire pressure warning valves and transmitters (vehicles with a tire pressure warning system)

- Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Toyota dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Toyota dealer.
- Ensure that only genuine Toyota wheels are used on your vehicle.
   Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.

7


Maintenance and care

# Air conditioning filter


The air conditioning filter must be changed regularly to maintain air conditioning efficiency.

# Removal method

- 1 Turn the engine switch off.
- 2 Open the glove box and remove the glove box cover inside the glove box.




3 Remove the filter cover.



Remove the air conditioning filter and replace it with a new one.

The "TUP" marks shown on the filter should be pointing up.



## ■ Checking interval

Inspect and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, early replacement may be required. (For scheduled maintenance information, please refer to the "Schedule maintenance guide" or "Owner's Manual Supplement".)

## ■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

## ■ Air conditioning filter deodorizing function (U.S.A and Puerto Rico)

This vehicle is equipped with a deodorizing charcoal air filter to reduce odor from the air conditioning system.

When items or products which emit fragrances or odors are placed in your vehicle, the deodorizing effect may be significantly weakened in a short period of time.

If frequent or strong odor comes from your air conditioning system, replace the air conditioning filter.



#### When using the air conditioning system

Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

# Wireless remote control/electronic key battery

Replace the battery with a new one if it is depleted.

# You will need the following items:

- Flathead screwdriver
- Small flathead screwdriver
- Lithium battery CR2016 (vehicles without a smart key system), or CR2032 (vehicles with a smart key system)


# Replacing the battery


- ▶ Vehicles without a smart key system (type A)
- 1 Remove the cover.

To prevent damage to the key, cover the tip of the screwdriver with a rag.

To prevent the buttons from being disassembled, face the button surface downward.


2 Remove the module.





3 Open the case cover using a coin protected with tape etc. and remove the depleted battery using a small flathead screwdriver.

Insert a new battery with the "+" terminal facing up.





- ▶ Vehicles without a smart key system (type B)
- 1 Remove the cover.

To prevent damage to the key, cover the tip of the screwdriver with

To prevent the buttons from being disassembled, face the button surface downward.


2 Remove the module.






3 Open the case cover using a coin protected with tape etc. and remove the depleted battery using a small flathead screwdriver.

Insert a new battery with the "+" terminal facing up.




Maintenance and care

- ▶ Vehicles with a smart key system
- 1 Take out the mechanical key.




2 Remove the cover.

To prevent damage to the key, cover the tip of the screwdriver with a rag.



Remove the depleted battery using a small flathead screwdriver.

Insert a new battery with the "+" terminal facing up.



# ■Use a CR2016 (vehicles without a smart key system) or CR2032 (vehicles with a smart key system) lithium battery

- Batteries can be purchased at your Toyota dealer, local electrical appliance shops or camera stores.
- Replace the battery only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to local laws.

#### ■ If the key battery is depleted

The following symptoms may occur:

- The smart key system (if equipped) and wireless remote control will not function properly.
- The operational range will be reduced.



# **WARNING**

### Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.



#### NOTICE

#### For normal operation after replacing the battery


Observe the following precautions to prevent accidents:

- Always work with dry hands. Moisture may cause the battery to rust.
- Do not touch or move any other component inside the remote control.
- Do not bend either of the battery terminals.

# **Checking and replacing fuses**

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.


- 1 Turn the engine switch off.
- 2 Open the fuse box cover.
- ► Engine compartment (type A)
- ► Engine compartment (type B) (if equipped)



Push the tabs in and lift the lid off.


Push the tabs in and lift the lid

▶ Under the driver's side instrument panel




Remove the lid.


Only type A fuses can be removed using the pullout tool.




- 4 Check if the fuse is blown.
- ▶ Type A



▶ Type B



▶ Type C



- 1 Normal fuse
- (2) Blown fuse

Type A and B:

Replace the blown fuse with a new fuse of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

Type C:

Contact your Toyota dealer.

7

Maintenance and care

#### ■ After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P. 427)
- If the replaced fuse blows again, have the vehicle inspected by your Toyota dealer.

#### ■ If there is an overload in a circuit

The fuses are designed to blow, protecting the wiring harness from damage.

#### ■When replacing light bulbs

Toyota recommends that you use genuine Toyota products designed for this vehicle. Because certain bulbs are connected to circuits designed to prevent overload, non-genuine parts or parts not designed for this vehicle may be unusable.

# **▲** WARNING

## To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than that indicated, or use any other object in place of a fuse.
- Always use a genuine Toyota fuse or equivalent.
   Never replace a fuse with a wire, even as a temporary fix.
- Do not modify the fuses or fuse boxes.



### Before replacing fuses

Have the cause of electrical overload determined and repaired by your Toyota dealer as soon as possible.

# **Light bulbs**

You may replace the following bulbs yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact your Toyota dealer.


For more information about replacing other light bulbs, contact your Toyota dealer.

# Preparing for light bulb replacement


Check the wattage of the light bulb to be replaced. (→P. 506)

# **Bulb locations**

▶ Front




▶ Rear




- (1) Headlight high beams (halogen (1) Back-up lights bulb)/daytime running lights (halogen bulb)
- (2) Headlight low beams (halogen bulb)
- (3) Front side marker lights
- (4) Front turn signal/parking lights (bulb type)
- (2) Rear turn signal lights
- ③ Stop/tail/rear side marker lights
- (4) License plate lights

# Replacing light bulbs

- Headlight high beams (halogen bulb)/daytime running light (halogen bulb)
- 1 Turn the bulb base counterclockwise.




2 Pull the bulb out while pressing the lock release of the connector.




3 When installing, reverse the steps listed.

# ■ Headlight low beams (halogen bulb)

1 Turn the bulb base counterclockwise.




2 Pull the bulb out while pressing the lock release of the connector.




3 When installing, reverse the steps listed.

# **■** Front side marker lights

1 Turn the bulb base counterclockwise.



2 Remove the light bulb.



3 When installing, reverse the steps listed.


Maintenance and care


# ■ Front turn signal/parking lights (bulb type)

1 To ensure enough space to perform work, turn the steering wheel to rotate the front wheel away from the bulb to be replaced.


Turn the steering wheel to the left when replacing the right side light bulb, and turn the steering wheel to the right when replacing the left side light bulb.


2 Remove the fender liner screws.







- 3 Remove the fender liner clip.
  - 1) After turning the clip, pull the clip until it stops.
  - ② Turn the clip again, and then pull out the clip.
- 4 Partly remove the fender liner and turn the bulb base counterclockwise.
- \*1: Vehicles without LED daytime running lights
- \*2: Vehicles with LED daytime running lights









- 6 When installing, reverse the steps listed.
- Stop/tail/rear side marker lights and rear turn signal lights
  - 1 Open the trunk lid and remove the luggage trim cover clips. (→P. 435)



2 Pull the hook while depressing the button.




3 Partly remove the luggage trim cover.




Maintenance and care

- 4 Turn the bulb base counterclockwise.
  - 1 Rear turn signal light
  - ② Stop/tail/rear side marker light




- 5 Remove the light bulb.
  - 1 Rear turn signal light
  - ② Stop/tail/rear side marker light




6 When installing, reverse the steps listed.

## ■ Back-up lights

1 Open the trunk lid and remove the clips. (→P. 435) Then partly remove the trunk panel cover.




2 Unplug the connector while depressing the lock release.



3 Turn the bulb base counterclockwise.



4 Remove the light bulb.




5 When installing, reverse the steps listed.

Maintenance and care

## ■ License plate lights

1 Remove the cover.

To prevent damaging the vehicle, wrap the tip of the flathead screwdriver with tape.





2 Remove the lens.

Put the flathead screwdriver behind the tab of the lens, and turn it as shown in the illustration to pry off the lens.

To prevent damaging the vehicle, wrap the tip of the screwdriver with tape.

3 Remove the light bulb.





4 When installing, reverse the steps listed.

## ■ Replacing the following bulbs

If any of the lights listed below has burnt out, have it replaced by your Toyota dealer.

- Headlight low/high beams (LED type)
- Parking lights/daytime running lights (LED type)
- High mounted stoplights

care

## ■LED light bulbs

The headlight low/high beams (LED type), parking lights/daytime running lights (LED type) and high mounted stoplights consist of a number of LEDs. If any of the LEDs burns out, take your vehicle to your Toyota dealer to have the light replaced.

## ■ Condensation build-up on the inside of the lens


Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction.

Contact your Toyota dealer for more information in the following situations:

- Large drops of water have built up on the inside of the lens.
- Water has built up inside the headlight.

## ■Removing and installing the luggage trim cover and trunk panel cover clips

- 1) Removing
- 2 Installing



## ■When replacing light bulbs

→P. 426

## WARNING

#### Replacing light bulbs

- Turn off the lights. Do not attempt to replace the bulb immediately after turning off the lights.
  - The bulbs become very hot and may cause burns.
- Do not touch the glass portion of the light bulb with bare hands. When it is unavoidable to hold the glass portion, use and hold with a clean dry cloth to avoid getting moisture and oils on the bulb.
  - Also, if the bulb is scratched or dropped, it may blow out or crack.
- Fully install light bulbs and any parts used to secure them. Failure to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.

#### To prevent damage or fire

Make sure bulbs are fully seated and locked.

## When trouble arises


8-1.	Essential information
	Emergency flashers 438
	If your vehicle has to be
	stopped in an
	emergency 439
8-2.	Steps to take in an
	emergency
	If your vehicle needs to
	be towed 441
	If you think something is
	wrong 444
	Fuel pump shut off
	system 445
	If a warning light turns
	on or a warning buzzer
	sounds 446
	If a warning message or indicator is displayed 454
	If you have a flat tire 470
	If the engine will not start482
	If the shift lever cannot be
	shifted from P 484
	If the electronic key does
	not operate properly 485
	If the vehicle battery is
	discharged488
	If your vehicle
	overheats 492
	If the vehicle becomes
	stuck 495

## **Emergency flashers**

The emergency flashers are used to warn other drivers when the vehicle has to be stopped in the road due to a breakdown, etc.

Press the switch.

All the turn signal lights will flash. To turn them off, press the switch once again.




## ■ Emergency flashers

If the emergency flashers are used for a long time while the engine is not operating, the battery may discharge.


Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

- 1 Steadily step on the brake pedal with both feet and firmly depress it.

  Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.
- 2 Shift the shift lever to N.
- ▶ If the shift lever is shifted to N
- 3 After slowing down, stop the vehicle in a safe place by the road.
- 4 Stop the engine.
- ▶ If the shift lever cannot be shifted to N
- 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- 4 Vehicles without a smart key system: Stop the engine by turning the engine switch to the "ACC" position.



4 Vehicles with a smart key system: To stop the engine, press and hold the engine switch for 2 consecutive seconds or more, or press it briefly 3 times or more in succession.



5 Stop the vehicle in a safe place by the road.

## **MARNING**

## If the engine has to be turned off while driving

- Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.
- Vehicles without a smart key system: Never attempt to remove the key, as doing so will lock the steering wheel.

If towing is necessary, we recommend having your vehicle towed by your Toyota dealer or commercial towing service, using a wheel-lift type truck or flatbed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.


## Situations when it is necessary to contact dealers before towing

The following may indicate a problem with your transmission. Contact your Toyota dealer or commercial towing service before towing.

- The engine is running but the vehicle does not move.
- The vehicle makes an abnormal sound.


## Towing with a sling-type truck

Do not tow with a sling-type truck to prevent body damage.




## Towing with a wheel-lift type truck

## ▶ From the front



Release the parking brake.


## ▶ From the rear



Use a towing dolly under the front wheels.


## Using a flatbed truck

If your vehicle is transported by a flatbed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.




## MARNING

Observe the following precautions.

Failure to do so may result in death or serious injury.

### When towing the vehicle

Be sure to transport the vehicle with the front wheels raised or with all four wheels raised off the ground. If the vehicle is towed with the front wheels contacting the ground, the drivetrain and related parts may be damaged.



<u>^</u>

## **NOTICE**

## To prevent damage to the vehicle when towing using a wheel-lift type truck

- Vehicles without a smart key system: Do not tow the vehicle from the rear when the engine switch is in the "LOCK" position or the key is removed. The steering lock mechanism is not strong enough to hold the front wheels straight.
- Vehicles with a smart key system: Do not tow the vehicle from the rear when the engine switch is off. The steering lock mechanism is not strong enough to hold the front wheels straight.
- When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.
- To prevent damage to the vehicle when towing with a sling-type truck

  Do not tow with a sling-type truck, either from the front or rear.

8

When trouble arises

## If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Toyota dealer as soon as possible.

## Visible symptoms

- Fluid leaks under the vehicle.
   (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- The rightmost segment of the engine coolant temperature display flashes

## **Audible symptoms**

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

## **Operational symptoms**

- Engine missing, stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

## Fuel pump shut off system

To minimize the risk of fuel leakage when the engine stalls or when an airbag inflates upon collision, the fuel pump shut off system stops the supply of fuel to the engine.

Follow the procedure below to restart the engine after the system is activated.

- ▶ Vehicles without a smart key system
- 1 Turn the engine switch to the "ACC" or "LOCK" position.
- 2 Restart the engine.
- ▶ Vehicles with a smart key system
- 1 Turn the engine switch off.
- 2 Restart the engine.



## Before starting the engine

Inspect the ground under the vehicle.

If you find that fuel has leaked onto the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

# If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Toyota dealer.

## Warning light and warning buzzer list

Warning light	Warning light/Details/Actions	
(Canada)	Brake system warning light (warning buzzer)*1 Indicates that: • The brake fluid level is low; or • The brake system is malfunctioning This light also comes on when the parking brake is not released. If the light turns off after the parking brake is fully released the system is operating normally.  → Immediately stop the vehicle in a safe place and contact your Toyota dealer. Continuing to drive the vehicle may be dangerous.	
CHECK (U.S.A.)	<ul> <li>Malfunction indicator lamp Indicates a malfunction in: <ul> <li>The electronic engine control system;</li> <li>The electronic throttle control system; or</li> <li>The electronic automatic transmission control system</li> </ul> </li> <li>→ Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>	
SRS warning light Indicates a malfunction in: • The SRS airbag system; • The front passenger occupant classification syste • The seat belt pretensioner system  → Have the vehicle inspected by your Toyota immediately.		
(U.S.A.) (Canada)	<ul> <li>ABS warning light Indicates a malfunction in:</li> <li>The ABS; or</li> <li>The brake assist system</li> <li>→ Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>	

Warning light	Warning light/Details/Actions
<b>@!</b>	Electric power steering system warning light (warning buzzer) Indicates a malfunction in the EPS (Electric Power Steering) system → Have the vehicle inspected by your Toyota dealer immediately.
*\Q_#E	<ul> <li>Pre-collision system warning light*2 Indicates a malfunction in the PCS (Pre-Collision System) The warning light will operate as follows, even when the system is not malfunctioning: <ul> <li>The light will turn on when the pre-collision system is disabled. (→P. 220)</li> <li>The light will turn on when the VSC (Vehicle Stability Control) system is disabled. (→P. 216)</li> <li>The light will flash when the system cannot temporarily be used. (→P. 462)</li> </ul> → Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>
<b>2</b>	<ul> <li>Slip indicator Indicates a malfunction in: <ul> <li>The VSC (Vehicle Stability Control) system;</li> <li>The TRAC (Traction Control) system; or</li> <li>The ABS</li> <li>The light will flash when the VSC or the TRAC system is operating.</li> </ul> </li> <li>→ Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>
	Low fuel level warning light Indicates that remaining fuel is approximately 2.6 gal. (9.7 L, 2.1 lmp. gal.) or less → Refuel the vehicle.
Ä	Seat belt reminder light (warning buzzer)*3  Warns the driver and/or front passenger to fasten their seat belts  → Fasten the seat belt.  If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.
A	Master warning light A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunction. → P. 454

Warning light	Warning light/Details/Actions
<u>(!)</u>	Tire pressure warning light*2 When the light comes on: Low tire inflation pressure such as • Natural causes (→P. 449) • Flat tire (→P. 470)  → Adjust the tire inflation pressure to the specified level.  The light will turn off after a few minutes. In case the light does not turn off even if the tire inflation pressure is adjusted, have the system checked by your Toyota dealer.  When the light comes on after blinking for 1 minute: Malfunction in the tire pressure warning system  → Have the system checked by your Toyota dealer.

<sup>\*1:</sup> Parking brake engaged warning buzzer:

→P. 455

\*2: If equipped

\*3: Driver's seat belt buzzer:

Vehicles without a smart key system: The driver's seat belt buzzer sounds to alert the driver that his or her seat belt is not fastened. Once the engine switch is turned to the "ON" position, the buzzer sounds for 6 seconds. If the vehicle reaches a speed of 12 mph (20 km/h), the buzzer sounds once. If the seat belt is still unfastened after 30 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

Vehicles with a smart key system: The driver's seat belt buzzer sounds to alert the driver that his or her seat belt is not fastened. Once the engine switch is turned to IGNITION ON mode, the buzzer sounds for 6 seconds. If the vehicle reaches a speed of 12 mph (20 km/h), the buzzer sounds once. If the seat belt is still unfastened after 30 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

Front passenger's seat belt buzzer:

The front passenger's seat belt buzzer sounds to alert the front passenger that his or her seat belt is not fastened. The buzzer sounds once if the vehicle reaches a speed of 12 mph (20 km/h). If the seat belt is still unfastened after 30 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

## **■**SRS warning light

This warning light system monitors the airbag sensor assembly, front impact sensors, side impact sensors (front door), side impact sensors (front), side impact sensors (rear), driver's seat belt buckle switch, front passenger occupant classification system, "AIR BAG ON" indicator light, "AIR BAG OFF" indicator light, front passenger's seat belt buckle switch, seat belt pretensioners (front), airbags, interconnecting wiring and power sources. (→P. 36)

## ■ Front passenger detection sensor, seat belt reminder and warning buzzer

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

#### ■ If the malfunction indicator lamp comes on while driving

First check the following:

- Is the fuel tank empty?
  If it is, fill the fuel tank immediately.
- Is the fuel tank cap loose?
  If it is, tighten it securely.

The light will go off after several driving trips.

If the light does not go off even after several trips, contact your Toyota dealer as soon as possible.

## ■ Electric power steering system warning light (warning buzzer)

When the battery charge becomes insufficient or the voltage temporarily drops, the electric power steering system warning light may come on and the warning buzzer may sound.

## ■When the tire pressure warning light comes on (vehicles with a tire pressure warning system)

Check the tire inflation pressure and adjust to the appropriate level. Pushing the tire pressure warning reset switch will not turn off the tire pressure warning light.

## ■The tire pressure warning light may come on due to natural causes (vehicles with a tire pressure warning system)

The tire pressure warning light may come on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

## ■When a tire is replaced with a spare tire (vehicles with a tire pressure warning system)

The compact spare tire is not equipped with a tire pressure warning valve and transmitter. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire. Replace the spare tire with the repaired tire and adjust the tire inflation pressure. The tire pressure warning light will go off after a few minutes.

■ Conditions that the tire pressure warning system may not function properly (vehicles with a tire pressure warning system)

→P. 408

## ■If the tire pressure warning light frequently comes on after blinking for 1 minute (vehicles with a tire pressure warning system)

If the tire pressure warning light frequently comes on after blinking for 1 minute when the engine switch is turned on, have it checked by your Toyota dealer.

## ■Warning buzzer

In some cases, the buzzer may not be heard because of noisy place or an audio sound.

## WARNING

#### If both the ABS and the brake system warning lights remain on

Stop your vehicle in a safe place immediately and contact your Toyota dealer. The vehicle will become extremely unstable during braking, and the ABS system may fail, which could cause an accident resulting in death or serious injury.

## When the electric power steering system warning light comes on

The steering wheel may become extremely heavy.

If the steering wheel becomes heavier than usual when operating, hold firmly and operate using more force than usual.

## If the tire pressure warning light comes on (vehicles with a tire pressure warning system)

Be sure to observe the following precautions. Failure to do so could cause a loss of vehicle control and result in death or serious injury.

- Stop your vehicle in a safe place as soon as possible. Adjust the tire inflation pressure immediately.
- If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If a tire is flat, change it with the spare tire and have the flat tire repaired by the nearest Toyota dealer.
- Avoid abrupt maneuvering and braking. If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes.

## If a blowout or sudden air leakage should occur (vehicles with a tire pressure warning system)

The tire pressure warning system may not activate immediately.

When trouble arises

#### WARNING

#### Maintenance of the tires

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.

## **NOTICE**

■To ensure the tire pressure warning system operates properly (vehicles with a tire pressure warning system)

Do not install tires with different specifications or makers, as the tire pressure warning system may not operate properly.


# If a warning message or indicator is displayed

# If a warning is shown on the multi-information display, stay calm and perform the following actions:

1 Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

(2) Multi-information display



If any of the warning message or indicator comes on again after the following actions have been performed, contact your Toyota dealer.

## Warning message and warning buzzer list

Warning message	Details/Actions
BRAKEI (If equipped)	<ul> <li>Indicates that:</li> <li>There is a high possibility of a frontal collision; or</li> <li>The pre-collision braking function is operating A buzzer also sounds.</li> <li>→ Slow the vehicle by applying the brakes.</li> </ul>
(If equipped)	Indicates that your vehicle is nearing the vehicle ahead (in vehicle-to-vehicle distance mode) A buzzer also sounds. → Slow the vehicle by applying the brakes.
(If equipped)	Alerts the driver that the vehicle has deviated from the lane (while the LDA [Lane Departure Alert] system is operating)  The lane line on the side the vehicle has deviated from flashes.  The warning buzzer sounds continuously.  → Check around the vehicle and back to inside of the lane lines.

Warning message	Details/Actions
Door Ajar	Indicates that one or more of the doors is not fully closed  The system also indicates which doors are not fully closed.  If the vehicle reaches a speed of 3 mph (5 km/h),
	Indicates that the hood is not fully closed If the vehicle reaches a speed of 3 mph (5 km/h),
	Indicates that the trunk is not fully closed If the vehicle reaches a speed of 3 mph (5 km/h),
Check Electric Power Steering System	Indicates a malfunction in the EPS (Electric Power Steering) system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Release Parking Brake  BRAKE (U.S.A.) (Canada) (Flashes)	Indicates that the vehicle is being driven at 3 mph (5 km/h) or more with the parking brake still engaged A buzzer also sounds.  → Release the parking brake.

Warning message	Details/Actions
Check Anti-lock Brake System  ABS  (U.S.A.)  Check Anti-lock Brake System  (Canada)	Indicates a malfunction in:  • The ABS; or  • The brake assist system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Check Vehicle Stability Control System	Indicates a malfunction in the VSC (Vehicle Stability Control) system.  → Have the vehicle inspected by your Toyota dealer.
Engine Coolant Temp is High	Indicates that the engine coolant temperature is too high A buzzer also sounds. → P. 492
Check Charging System	Indicates a malfunction in the vehicle's charging system.  → Immediately stop the vehicle in a safe place and contact your Toyota dealer. Continuing to drive the vehicle may be dangerous.
Dynamic Radar Cruise Sensor Needs Cleaning  (If equipped)	Indicates that the radar sensor is dirty or covered with ice A buzzer also sounds. → Clean the sensor.

Warning message	Details/Actions
Dynamic Radar Cruise Control Not Available  (If equipped)	Indicates that the dynamic radar cruise control system is unable to judge vehicle-to-vehicle distance  A buzzer also sounds.  → Switch driving mode to normal.  If the windshield wipers are on, turn them off or set them to a mode other than high speed wiper operation.
LDA Not Available  (If equipped)	Indicates that the LDA (Lane Departure Alert) system is suspended (The camera sensor temperature is higher than the operation temperature range)  A buzzer also sounds.  → Restart the LDA after driving for a while.
Blind Spot Monitor Not Available  (If equipped)	Indicates that a Blind Spot Monitor sensor or the surrounding area on the bumper is dirty or covered with ice A buzzer also sounds. → Clean the sensor and its surrounding area on the bumper.
Check Cruise Control System	Indicates a malfunction in:  • The cruise control system; or  • The dynamic radar cruise control system (if equipped)  Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.  A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Check LDA System  (If equipped)	Indicates a malfunction in the LDA (Lane Departure Alert) system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.

Warning message	Details/Actions
Check Pre-Collision System  OFF (Flashes) (If equipped)	Indicates a malfunction in the PCS (Pre-Collision system) A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Check Blind Spot Monitor System  (If equipped)	Indicates a malfunction in the BSM (Blind Spot Monitor) system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Low Oil Pressure	Indicates abnormal engine oil pressure A buzzer also sounds.  → Immediately stop the vehicle in a safe place and contact your Toyota dealer.
LDA System is Unavailable Below Approx. 32 MPH (If equipped)	Indicates that the LDA (Lane Departure Alert) system cannot be used because the vehicle speed is lower than approximately 32 mph (50 km/h)  → Drive the vehicle at 32 mph (50 km/h) or higher.
Turn Headlights OFF  (Flashes)	Indicates that the engine switch is turned off or turned to ACCESSORY mode and the driver's door is opened while the lights are turned on A buzzer also sounds.  → Turn the lights off.

Warning message	Details/Actions
Moon Roof Open  (Flashes) (If equipped)	Indicates that the moon roof is not fully closed (with the engine switch off, and the driver's door open) A buzzer also sounds. → Close the moon roof.
Check Auto High Beam System  (If equipped)	Indicates a malfunction in the Automatic High Beam system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
(Vehicles with a tire inflation pressure display function)  (If equipped)	Indicates that the tire inflation pressure is low  → Check the tire inflation pressure, and adjust to the appropriate level.

Warning message	Details/Actions
(Vehicles with a tire inflation pressure display function)  (If equipped)	Indicates a malfunction in the tire pressure warning system  → Stop the vehicle in a safe place and turn the engine switch off then on again. If the tire pressure warning indicator flashes for 1 minute then illuminates, there is a malfunction in the system. Have the vehicle inspected at your Toyota dealer.
(Vehicles with a tire inflation pressure display function) (If equipped)	Indicates that the tire position information cannot be recognized  → Drive for a short while and check if the display updates.  If the radio wave conditions improve, the display may return to normal. If the tire pressure is still not displayed after driving for several minutes, stop the vehicle in a safe place, turn the engine switch off then on again, and start driving.  If the tire pressure is still not displayed even after repeating this process several times, have the vehicle inspected at your Toyota dealer.
Low Washer fluid	Indicates that the washer fluid level is low  → Add washer fluid.

Warning message	Details/Actions
Low Fuel Distance to Empty  Low Fuel Distance to Empty Please Refuel	Indicates that remaining fuel is approximately 2.6 gal. (9.7 L, 2.1 lmp. gal.) or less → Refuel the vehicle.
Traction Control OFF TRAC OFF	Indicates that the TRAC (Traction Control) system has been deactivated  → Turn the TRAC on. (→P. 215)
Maintenance Required Soon	Indicates that all maintenance according to the driven distance on the maintenance schedule* should be performed soon.  Comes on approximately 4500 miles (7200 km) after the massage has been reset.  → If necessary, perform maintenance.
Maintenance Required  (U.S.A. only)	Indicates that all maintenance is required to correspond to the driven distance on the maintenance schedule*.  Comes on approximately 5000 miles (8000 km) after the massage has been reset.  (The indicator will not work properly unless the massage has been reset.)  → Perform the necessary maintenance.  Please reset the massage after the maintenance is performed (→P. 381)

Warning message	Details/Actions
Pre-Collision Brake is Disabled Due to VSC OFF  OFF  (If equipped)	Indicates that, since the VSC (Vehicle Stability Control) system was turned off, the pre-collision brake system operation is stopped → Turn the VSC on. (→P. 216)
Pre-Collision System Temporarily Not Available  OFF (Flashes) (If equipped)	Indicates that the PCS (Pre-collision system) is not currently functional because the grille cover or the sensor is dirty  → Check the grille cover and the sensor and clean them if they are dirty.

<sup>\*:</sup> Refer to the separate "Scheduled Maintenance Guide" or "Owner's Manual Supplement" for the maintenance interval applicable to your vehicle.

■Warning message in dynamic radar cruise control mode (if equipped)

In the following situations, the warning message may not be displayed even if vehicle-to-vehicle distance decreases:

- When your vehicle and the vehicle ahead are traveling at the same speed or the vehicle ahead is traveling more quickly than your vehicle
- When the vehicle ahead is traveling at a very low speed
- Immediately after cruise control speed is set
- At the instant the accelerator pedal is depressed
- ■The LDA (Lane Departure Alert) lane departure warning function (if equipped)

In the following situations, a warning message will not be displayed even if a lane line is crossed.

- When the vehicle speed deviates from the operating range of the LDA system functions
- When the lane lines cannot be recognized
- ■When a tire is replaced with the spare tire

The compact spare tire is not equipped with a tire pressure warning valve and transmitter. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire.

■ Conditions that the tire pressure warning system may not function properly (vehicles with a tire pressure warning system)

→P. 408

■Warning buzzer

→P. 450

# Have the malfunction repaired immediately. (vehicles with a smart key system)

After taking the specified steps to correct the suspected problem, check that the warning message and light go off.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Con- tinu- ous	_	Shift to P Position  (Flashes)	The driver's door was opened when the shift lever was not in P and the engine switch was not turned off.  → Shift the shift lever to P.
Con- tinu- ous	Contin- uous	Shift to P Position  Key Not Detected  (Displayed alternately)  (Flashes)	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was not in P and the engine switch was not turned off.  → Shift the shift lever to P.  → Bring the electronic key back into the vehicle.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once 3 times	3 times	Key Not Detected	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was in P and the engine switch was not turned off.  → Turn the engine switch off. → Bring the electronic key back into the vehicle.
	(Flashes)	The electronic key was carried outside the vehicle and a door other than the driver's door was opened and closed while the engine switch was in a mode other than off.  → Bring the electronic key back into the vehicle.	
Once	Contin- uous	Turn Power OFF  Key Not Detected  (Displayed alternately)  (Flashes)	An attempt was made to exit the vehicle with the electronic key and lock the doors without first turning the engine switch off when the shift lever was in P. → Turn the engine switch off and lock the doors again.
Once	_	Key Not Detected  (Flashes)	The electronic key is not detected when an attempt is made to start the engine.  → Start the engine with the electronic key present.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
9 times		Key Not Detected	An attempt was made to drive when the electronic key was not inside the vehicle.  → Confirm that the electronic key is inside the vehicle.
_	Contin- uous	Key Detected in Vehicle	An attempt was made to lock the doors using the smart key system while the electronic key was still inside the vehicle.  → Retrieve the electronic key from the vehicle and lock the doors again.
Once	Contin- uous	Key Detected in Vehicle	An attempt was made to lock either front door by opening a door and putting the inside lock button into the lock position, then closing the door with the electronic key still inside the vehicle.  → Retrieve the electronic key from the vehicle and lock the doors again.
Once	_	Key Battery Low	The electronic key has a low battery.  → Replace the electronic key battery. (→P. 420)

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	_	Steering Lock ON  (Flashes)	The steering lock could not be released within 3 seconds of the engine switch being pressed.  → Press the engine switch while depressing the brake pedal and moving the steering wheel left and right.
Once	_	Smart Entry & Start System Check  (Flashes)	Indicates a malfunction in the smart key system  → Have the vehicle inspected by your Toyota dealer.
Once	_	Key Battery Low Engine Start: Press Brake Pedal, Push Engine Switch with Key  (Flashes)	<ul> <li>When the doors were unlocked with the mechanical key and then the engine switch was pressed, the electronic key could not be detected in the vehicle.</li> <li>The electronic key could not be detected in the vehicle even after the engine switch was pressed two consecutive times.</li> <li>→ Touch the electronic key to the engine switch while depressing the brake pedal.</li> </ul>
Once	_	Engine Start: Press Brake Pedal and Push Engine Switch  (Flashes)	Indicates that:  • With the engine switch off, the doors were unlocked and then the driver's door was opened and closed  • The engine switch was turned to ACCESSORY mode without starting the engine  → Press the engine switch while depressing the brake pedal.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	_	Shift to P Position to Start  (Flashes)	An attempt was made to start the engine with the shift lever in an incorrect position.  → Shift the shift lever to P and start the engine.
Once	_	Shift to P Position  (Flashes)	The engine switch has been turned off with the shift lever in a position other than P.  → Shift the shift lever to P.
Once	_	Turn Power OFF  (Flashes)	After the engine switch has been turned off with the shift lever in a position other than P, the shift lever has been shifted to P.  → Turn the engine switch off.
_	_	Powering OFF to Conserve Battery	Power was turned off due to the automatic power off function.  → Next time when starting the engine, increase the engine speed slightly and maintain that level for approximately 5 minutes to recharge the battery.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	_	Engine Start: Press Brake Pedal and Push Engine Switch  (Flashes)	During a engine starting procedure in the event that the electronic key was not functioning properly (→P. 486), the engine switch was touched with the electronic key.  → Press the engine switch within 10 seconds of the buzzer sounding.

### **■** Warning buzzer

→P. 450

## If you have a flat tire

Your vehicle is equipped with a spare tire. The flat tire can be replaced with the spare tire.

For details about tires: →P. 403

**MARNING** 

### If you have a flat tire


Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

#### Before jacking up the vehicle

- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P.
- Stop the engine.
- Turn on the emergency flashers. (→P. 438)

## Location of the spare tire, jack and tools



- 1 Luggage floor cover
- 4 Jack handle
- ② Wheel nut wrench
- ⑤ Jack

3 Spare tire

### **MARNING**

#### Using the tire jack

Observe the following precautions.

Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.


- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire.


Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.

- Put the jack properly in its jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start the engine or drive the vehicle while the vehicle is supported by the jack.
- Do not raise the vehicle while someone is inside.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- When lowering the vehicle, make sure that there is no-one near the vehicle. If there are people nearby, warn them vocally before lowering.


#### Taking out the jack

1 Lift up the hook of the luggage floor cover on the trunk floor.






3 Remove the jack.




## Taking out the spare tire


1 Lift up the hook of the luggage floor cover on the trunk floor.



2 Secure the luggage floor cover using the hook provided.




3 Remove the tool tray.



4 Loosen the center fastener that secures the spare tire.

When taking out or stowing the spare tire, make sure to firmly hold opposite ends of the tire.




## **MARNING**

#### ■When storing the spare tire

Be careful not to catch fingers or other body parts between the spare tire and the body of the vehicle.

## Replacing a flat tire

1 Chock the tires.





Flat tire		Wheel chock positions
Front	Left-hand side	Behind the rear right-hand side tire
FIOR	Right-hand side	Behind the rear left-hand side tire
Rear	Left-hand side	In front of the front right-hand side tire
	Right-hand side	In front of the front left-hand side tire

2 For vehicles with steel wheels, remove the wheel ornament using the wrench.

To protect the wheel ornament, place a rag between the wrench and the wheel ornament, as shown in the illustration.

3 Slightly loosen the wheel nuts (one turn).







When trouble arises

4 Turn the tire jack portion "A" by hand until the notch of the jack is in contact with the jack point.

The jack point guides are located under the rocker panel. They indicate the jack point positions.



5 Raise the vehicle until the tire is slightly raised off the ground.



6 Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.



#### **WARNING**


#### Replacing a flat tire

- Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven.
  - After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.
- Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.
  - Have the wheel nuts tightened with a torque wrench to 76 ft•lbf (103 N•m, 10.5 kgf•m) as soon as possible after changing wheels.
  - Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.
  - When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
  - If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Toyota dealer.
  - When installing the wheel nuts, be sure to install them with the tapered ends facing inward. (→P. 417)

#### Installing the spare tire


1 Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, causing the tire to come off.




2 Install the tire and loosely tighten each wheel nut by hand by approximately the same amount.

When replacing a steel wheel with a steel wheel, tighten the wheel nuts until the tapered portion comes into loose contact with the disc wheel seat.




When replacing an aluminum wheel with a steel wheel, tighten the wheel nuts until the tapered portion comes into loose contact with the disc wheel seat.




Tapered portion

3 Lower the vehicle.



4 Firmly tighten each wheel nut two or three times in the order shown in the illustration.

Tightening torque: 76 ft•lbf (103 N•m, 10.5 kgf•m)



5 Stow the flat tire, tire jack and all tools.

#### ■The compact spare tire

- The compact spare tire is identified by the label "TEMPORARY USE ONLY" on the tire sidewall.
  - Use the compact spare tire temporarily, and only in an emergency.
- Make sure to check the tire inflation pressure of the compact spare tire. (→P. 504)

# ■When using the compact spare tire (vehicles with a tire pressure warning system)

As the compact spare tire is not equipped with a tire pressure warning valve and transmitter, low inflation pressure of the spare tire will not be indicated by the tire pressure warning system. Also, if you replace the compact spare tire after the tire pressure warning light comes on, the light remains on.

#### ■If you have a flat front tire on a road covered with snow or ice

Install the compact spare tire on one of the rear wheels of the vehicle. Perform the following steps and fit tire chains to the front tires:

- 1 Replace a rear tire with the compact spare tire.
- 2 Replace the flat front tire with the tire removed from the rear of the vehicle.
- 3 Fit tire chains to the front tires.

## **MARNING**

#### When using the compact spare tire

- Remember that the compact spare tire provided is specifically designed for use with your vehicle. Do not use your compact spare tire on another vehicle.
- Do not use more than one compact spare tires simultaneously.
- Replace the compact spare tire with a standard tire as soon as possible.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.

#### When the compact spare tire is attached

The vehicle speed may not be correctly detected, and the following systems may not operate correctly:

- ABS & Brake assist
- VSC
- TRAC
- Cruise control (if equipped)
- Dynamic radar cruise control (if equipped)
- PCS (if equipped)
- EPS
- LDA (Lane Departure Alert) (if equipped)
- Rear view monitor system
- Navigation system (if equipped)

#### Speed limit when using the compact spare tire

Do not drive at speeds in excess of 50 mph (80 km/h) when a compact spare tire is installed on the vehicle.

The compact spare tire is not designed for driving at high speeds. Failure to observe this precaution may lead to an accident causing death or serious injury.

#### After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden braking.

#### NOTICE

Be careful when driving over bumps with the compact spare tire installed on the vehicle.

The vehicle becomes lower when driving with the compact spare tire compared to when driving with standard tires. Be careful when driving over uneven road surfaces.

Driving with tire chains and the compact spare tire

Do not fit tire chains to the compact spare tire.

Tire chains may damage the vehicle body and adversely affect driving performance.

When replacing the tires (vehicles with a tire pressure warning system)

When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Toyota dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.

To avoid damage to the tire pressure warning valves and transmitters (vehicles with a tire pressure warning system)

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire.  $(\rightarrow P. 404)$ 

## If the engine will not start

If the engine will not start even though correct starting procedures are being followed ( $\rightarrow$ P. 153, 155), consider each of the following points:

# The engine will not start even though the starter motor operates normally.

One of the following may be the cause of the problem:

- There may not be sufficient fuel in the vehicle's tank.
   Refuel the vehicle.
- The engine may be flooded.
   Try to restart the engine again following correct starting procedures.
   (→P. 153, 155)
- There may be a malfunction in the engine immobilizer system.
   (→P. 67)

The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

- The battery may be discharged. (→P. 488)
- The battery terminal connections may be loose or corroded.

# The starter motor does not turn over (vehicles with a smart key system)

The engine starting system may be malfunctioning due to an electrical problem such as electronic key battery depletion or a blown fuse. However, an interim measure is available to start the engine.  $(\rightarrow P. 483)$ 

### The starter motor does not turn over, the interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- One or both of the battery terminals may be disconnected.
- The battery may be discharged. (→P. 488)
- There may be a malfunction in the steering lock system (vehicles with a smart key system).

Contact your Toyota dealer if the problem cannot be repaired, or if repair procedures are unknown.

#### **Emergency start function (vehicles with a smart key system)**

When the engine does not start, the following steps can be used as an interim measure to start the engine if the engine switch is functioning normally:

- 1 Set the parking brake.
- 2 Shift the shift lever to P.
- 3 Turn the engine switch to ACCESSORY mode.
- 4 Press and hold the engine switch for about 15 seconds while depressing the brake pedal firmly.

Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

## If the shift lever cannot be shifted from P

If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system (a system to prevent accidental operation of the shift lever). Have the vehicle inspected by your Toyota dealer immediately.


The following steps may be used as an emergency measure to ensure that the shift lever can be shifted:

- 1 Set the parking brake.
- 2 Vehicles without a smart key system: Turn the engine switch to the "ACC" position.

Vehicles with a smart key system: Turn the engine switch to ACCESSORY mode.


- 3 Depress the brake pedal.
- 4 Pry the cover up with a flathead screwdriver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.



5 Press the shift lock override button.

The shift lever can be shifted while the button is pressed.




If communication between the electronic key and vehicle is interrupted ( $\rightarrow$ P. 115) or the electronic key cannot be used because the battery is depleted, the smart key system and wireless remote control cannot be used. In such cases, the doors can be opened and the engine can be started by following the procedure below.

### Locking and unlocking the doors

Using the mechanical key ( $\rightarrow$ P. 94) in order to perform the following operations (driver's door only):

- 1 Locks all doors
- ② Closes the windows and moon roof (turn and hold)\*
- (3) Unlocks the door



Turning the key rearward unlocks the driver's door. Turning the key once again unlocks the other doors.

- (4) Opens the windows and moon roof (turn and hold)\*
- \*: This setting must be customized at your Toyota dealer.

8


When trouble arises

#### Starting the engine

- 1 Ensure that the shift lever is in P and firmly depress the brake pedal.
- 2 Touch the Toyota emblem side of the electronic key to the engine switch.

When the electronic key is detected, a buzzer sounds and the engine switch will turn to IGNITION ON mode.

When the smart key system is deactivated in customization setting, the engine switch will turn to ACCESSORY mode.



3 Firmly depress the brake pedal and check that on the multi-information display.



is displayed

4 Press the engine switch.

In the event that the engine still cannot be started, contact your Toyota dealer.

#### ■ Stopping the engine

Shift the shift lever to P and press the engine switch as you normally do when stopping the engine.

#### ■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. (→P. 420)

#### ■ Changing engine switch modes

Release the brake pedal and press the engine switch in step 3 above. The engine does not start and modes will be changed each time the switch is pressed. ( $\rightarrow$ P. 156)

#### ■When the electronic key does not work properly

- Make sure that the smart key system has not been deactivated in the customization setting. If it is off, turn the function on. (Customizable features →P. 523)
- Check if battery-saving mode is set. If it is set, cancel the function. (→P. 114)



#### ♠ WARNING

#### When using the mechanical key and operating the power windows or moon roof (if equipped)

Operate the power window or moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or moon roof. Also, do not allow children to operate the mechanical key. It is possible for children and other passengers to get caught in the power window or moon roof.

## If the vehicle battery is discharged


The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can also call your Toyota dealer or a qualified repair shop.


If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your vehicle by following the steps below.


1 Vehicles with an alarm: Confirm that the electronic key (vehicles with a smart key system) or master key (vehicles without a smart key system) is being carried.

When connecting the jumper (or booster) cables, depending on the situation, the alarm may activate and doors locked.  $(\rightarrow P. 70)$ 




3 Vehicles with 3.5 L V6 (2GR-FE) engine, remove the engine cover.






4 Connect the jumper cables according to the following procedure:



▶ 2.5 L 4-cylinder (2AR-FE) engine



- ① Connect a positive jumper cable clamp to the positive (+) battery terminal on your vehicle.
- ② Connect the clamp on the other end of the positive cable to the positive (+) battery terminal on the second vehicle.
- ③ Connect a negative cable clamp to the negative (-) battery terminal on the second vehicle.
- 4 Connect the clamp at the other end of the negative cable to a solid, stationary, unpainted metallic point away from the battery and any moving parts, as shown in the illustration.

- 5 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- 6 Vehicles with a smart key system: Open and close any of the doors of your vehicle with the engine switch off.
- Vehicles without a smart key system:

  Maintain the engine speed of the second vehicle and turn the engine switch to the "ON" position, then start the vehicle's engine.

Vehicles with a smart key system:

Maintain the engine speed of the second vehicle and turn the engine switch to IGNITION ON mode, then start the vehicle's engine.

8 Once the vehicle's engine has started, remove the jumper cables in the exact reverse order from which they were connected.

Once the engine starts, have the vehicle inspected at your Toyota dealer as soon as possible.

#### ■ Starting the engine when the battery is discharged

The engine cannot be started by push-starting.

#### ■ To prevent battery discharge

- Turn off the headlights and the audio system while the engine is off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

#### ■ Charging the battery

The electricity stored in the battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to start. (The battery recharges automatically during driving.)

#### ■When recharging or replacing the battery

- Vehicles with a smart key system: In some cases, it may not be possible to unlock the doors using the smart key system when the battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.
- Vehicles with a smart key system: The engine may not start on the first attempt after the battery has recharged but will start normally after the second attempt. This is not a malfunction.

**WARNING** 

battery, turn the engine switch off.

Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery:

Vehicles with a smart key system: The engine switch mode is memorized by the vehicle. When the battery is reconnected, the system will return to the mode it was in before the battery was discharged. Before disconnecting the

If you are unsure what mode the engine switch was in before the battery dis-

charged, be especially careful when reconnecting the battery.

- Make sure each jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- Do not allow the other end of the jumper cable connected to the "+" terminal to come into contact with any other parts or metal surfaces in the area, such as brackets or unpainted metal.
- Do not allow the + and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the battery.

#### **Battery precautions**

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery:

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention. Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the battery.



♠ NOTICE

#### When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fan or engine drive belt.

When trouble arises

## If your vehicle overheats

#### The following may indicate that your vehicle is overheating.

- The needle of the engine coolant temperature gauge (→P. 77) enters the red zone or a loss of engine power is experienced. (For example, the vehicle speed does not increase.)
- "Engine Coolant Temp is High" is shown on the multi-information display.
- Steam comes out from under the hood.

#### **Correction procedures**


- 1 Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the engine.
- 2 If you see steam:
  Carefully lift the hood after the steam subsides.
  If you do not see steam:


Carefully lift the hood.

- 3 After the engine has cooled down sufficiently, inspect the hoses and radiator core (radiator) for any leaks.
  - (1) Radiator
  - 2 Cooling fans

If a large amount of coolant leaks, immediately contact your Toyota dealer.


- The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir.
  - (1) Reservoir
  - (2) "F" line
  - (3) "L" line
  - (4) Radiator cap





5 Add engine coolant if necessary.

Water can be used in an emergency if engine coolant is unavailable.



6 Start the engine and turn the air conditioning system on to check that the radiator cooling fans operate and to check for coolant leaks from the radiator or hoses.

The fans operate when the air conditioning system is turned on immediately after a cold start. Confirm that the fans are operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly. (The fans may not operate in freezing temperatures.)

7 If the fans are not operating:

Stop the engine immediately and contact your Toyota dealer.

If the fans are operating:

Have the vehicle inspected at the nearest Toyota dealer.

## **MARNING**

#### When inspecting under the hood of your vehicle

Observe the following precautions.

Failure to do so may result in serious injury such as burns.

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot.
- Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fan and belts.
- Do not loosen the coolant reservoir cap while the engine and radiator are hot.

Serious injury, such as burns, may result from hot coolant and steam released under pressure.



#### **NOTICE**

#### When adding engine coolant

Wait until the engine has cooled down before adding engine coolant. When adding coolant, do so slowly. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

#### ■ To prevent damage to the cooling system

Observe the following precautions:

- Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
- Do not use any coolant additives.

## If the vehicle becomes stuck

Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt or snow:

- 1 Stop the engine. Set the parking brake and shift the shift lever to P.
- Remove the mud, snow or sand from around the front wheels.
- 3 Place wood, stones or some other material under the front wheels to help provide traction.
- 4 Restart the engine.
- 5 Shift the shift lever to D or R and release the parking brake. Then, while exercising caution, depress the accelerator pedal.

#### ■When it is difficult to free the vehicle

Press 🐰 to turn off TRAC.



#### **MARNING**

#### When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

#### When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident resulting in death or serious injury.



#### **NOTICE**

#### ■ To avoid damaging the transmission and other components

- Avoid spinning the front wheels and depressing the accelerator pedal more than necessary.
- If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

9

9-1.	Specifications		
	Maintenance data		
	(fuel, oil level, etc.) 498		
	Fuel information 507		
	Tire information 510		
9-2.	Customization		
	Customizable features 523		
9-3.	Items to initialize		
	Items to initialize 532		

# Maintenance data (fuel, oil level, etc.)

## Dimensions and weights

Overall length		190.9 in. (4850 mm)
Overall width		71.7 in. (1820 mm)
Overall height*1		57.9 in. (1470 mm)
Wheelbase		109.3 in. (2775 mm)
Trood	Front	62.4 in. (1585 mm)*2 62.8 in. (1595 mm)*3
Tread	Rear	62.0 in. (1575 mm)*2 62.4 in. (1585 mm)*3
Vehicle capacity weight (occupants + luggage)		905 lb. (410 kg)

<sup>\*1:</sup> Unladen vehicles

<sup>\*2:</sup> P215/55R17 and P225/45R18 tires


<sup>\*3:</sup> P205/65R16 tires

#### Vehicle identification


#### ■ Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.

This number is stamped on the top left of the instrument panel.



This number is also on the Certification Label.



#### **■** Engine number

The engine number is stamped on the engine block as shown.

▶ 2.5 L 4-cylinder (2AR-FE) ▶ 3.5 L V6 (2GR-FE) engine engine





\_

Vehicle specifications

## Engine

Model	2AR-FE	2GR-FE
Туре	4-cylinder in line, 4-cycle, gasoline	6-cylinder V type, 4-cycle, gasoline
Bore and stroke	3.54 × 3.86 in. (90.0 × 98.0 mm)	3.70 × 3.27 in. (94.0 × 83.0 mm)
Displacement	152.2 cu. in. (2494 cm <sup>3</sup> )	210.9 cu. in. (3456 cm <sup>3</sup> )
Drive belt tension	Automatic adjustment	
Valve clearance	live clearance Automatic adjustment	

## Fuel

Fuel type	Unleaded gasoline only
Octane rating	87 (Research Octane Number 91) or higher
Fuel tank capacity (Reference)	17.0 gal. (64.35 L, 14.2 lmp. gal.)

## Lubrication system

Oil capacity (Drain and refill — reference*)	
With filter	▶ 2.5 L 4-cylinder (2AR-FE) engine
	4.6 qt. (4.4 L, 3.9 lmp. qt.) ▶ 3.5 L V6 (2GR-FE) engine
Without filter	6.4 qt. (6.1 L, 5.4 Imp. qt.) ▶ 2.5 L 4-cylinder (2AR-FE) engine
	4.2 qt. (4.0 L, 3.5 lmp. qt.) ▶ 3.5 L V6 (2GR-FE) engine
	6.0 qt. (5.7 L, 5.0 Imp. qt.)

<sup>\*:</sup> The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.


"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: ILSAC GF-5 multigrade engine oil

Recommended viscosity: SAE 0W-20

SAE 0W-20 is the best choice for good fuel economy and good starting in cold weather.

If SAE 0W-20 is not available, SAE 5W-20 oil may be used. However, it must be replaced with SAE 0W-20 at the next oil change.




Oil viscosity (0W-20 is explained here as an example):

- The 0W in 0W-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in 0W-20 indicates the viscosity characteristic of the oil when the
  oil is at high temperature. An oil with a higher viscosity (one with a higher
  value) may be better suited if the vehicle is operated at high speeds, or
  under extreme load conditions.

How to read oil container label:

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is added to some oil containers to help you select the oil you should use.



9

## Cooling system

Capacity (Reference)	▶ 2.5 L 4-cylinder (2AR-FE) engine 7.7 qt. (7.3 L, 6.4 Imp. qt.) ▶ 3.5 L V6 (2GR-FE) engine 9.6 qt. (9.1 L, 8.0 Imp. qt.)
Coolant type	Use either of the following:

## Ignition system

Spark plug	
Make	▶ 2.5 L 4-cylinder (2AR-FE) engine
	DENSO SK16HR11
	▶ 3.5 L V6 (2GR-FE) engine
	DENSO FK20HR11
Gap	0.043 in. (1.1 mm)



#### ♠ NOTICE

## ■Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust spark plug gap.

## Electrical system

Battery	
Open voltage at 68°F (20°C):	12.6 — 12.8 V Fully charged 12.2 — 12.4 V Half charged 11.8 — 12.0 V Discharged (Voltage checked 20 minutes after the engine and all the lights turned off)
Charging rates	5 A max.

#### Automatic transaxle

Fluid capacity*	6.9 qt. (6.5 L, 5.7 Imp. qt.)
Fluid type	Toyota Genuine ATF WS

<sup>\*:</sup> The fluid capacity is a reference quantity. If replacement is necessary, contact your Toyota dealer.



#### **NOTICE**

#### ■Transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may cause deterioration in shift quality, locking up of the transmission accompanied by vibration and, ultimately, damage to the vehicle's transmission.

#### **Brakes**

Pedal clearance*1	3.8 in. (96 mm)
Pedal free play	0.04 — 0.24 in. (1 — 6 mm)
Brake pad wear limit	0.04 in. (1.0 mm)
Parking brake lining wear limit	0.04 in. (1.0 mm)
Parking brake pedal travel*2	7 — 10 clicks
Fluid type	SAE J1703 or FMVSS No.116 DOT 3

<sup>\*1:</sup> Minimum pedal clearance when depressed with a force of 112 lbf (500 N, 51 kgf) while the engine is running

#### Steering

Free play	Less than 1.2 in. (30 mm)
-----------	---------------------------

<sup>\*2:</sup> Parking brake pedal travel when depressed with a force of 67 lbf (300 N, 31 kgf).

## Tires and wheels

## ▶ Type A

Tire size	P205/65R16 94S, T155/70D17 110M
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Rear: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Spare: 60 psi (420 kPa, 4.2 kgf/cm² or bar) Driving at high speeds (above 100 mph [160 km/h]) (in countries where such speeds are permitted by law) Add 3 psi (20 kPa, 0.2 kgf/cm² or bar) to the front tires and rear tires. Never exceed the maximum cold tire inflation pressure indicated on the tire sidewall.
Wheel size	16 $\times$ 7J, 17 $\times$ 4 T (compact spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

## ▶ Type B

Tire size	P215/55R17 93V, T155/70D17 110M
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Rear: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Spare: 60 psi (420 kPa, 4.2 kgf/cm² or bar) Driving at high speeds (above 100 mph [160 km/h]) (in countries where such speeds are permitted by law) Add 6 psi (40 kPa, 0.4 kgf/cm² or bar) to the front tires and rear tires. Never exceed the maximum cold tire inflation pressure indicated on the tire sidewall.
Wheel size	$17 \times 7 \text{ J}, 17 \times 4 \text{ T (compact spare)}$
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

## ▶ Type C

Tire size	P225/45R18 91V, T155/70D17 110M
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front: 33 psi (230 kPa, 2.3 kgf/cm² or bar) Rear: 33 psi (230 kPa, 2.3 kgf/cm² or bar) Spare: 60 psi (420 kPa, 4.2 kgf/cm² or bar) Driving at high speeds (above 100 mph [160 km/h]) (in countries where such speeds are permitted by law) Add 6 psi (40 kPa, 0.4 kgf/cm² or bar) to the front tires and rear tires. Never exceed the maximum cold tire inflation pressure indicated on the tire sidewall.
Wheel size	$18 \times 7.5 \text{ J}, 17 \times 4 \text{ T (compact spare)}$
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

## Light bulbs\*1

	Light bulbs	Bulb No.	W	Туре
	Headlights Low beam (halogen bulbs)*2 High beam (halogen bulbs)*2	9005	55 60	A B
	Front side marker lights	W5W	5	С
Exterior	Front turn signal/ parking lights (bulb type)*2	7444NA	28/8	D
	Rear turn signal lights	WY21W	21	D
	Stop/tail/rear side maker lights	7443	21/5	С
	License plate lights	W5W	5	С
	Back-up lights	921	16	С
	Front interior/ personal lights*2	_	5	С
	Rear interior/ personal lights*2	_	8	С
Interior	Interior light*2	_	8	Е
	Door courtesy lights	168	5	С
	Vanity lights*2	_	8	С
	Trunk light	194	3.8	С

A: H11 halogen bulbs

B: HB3 halogen bulbs

C: Wedge base bulbs (clear)

D: Wedge base bulbs (amber)

E: Double end bulbs

<sup>\*1:</sup> Light bulbs not listed in this table are LED bulbs.

<sup>\*2:</sup> If equipped

## **Fuel information**

You must only use unleaded gasoline.

Select octane rating 87 (Research Octane Number 91) or higher. Use of unleaded gasoline with an octane rating lower than 87 may result in engine knocking. Persistent knocking can lead to engine damage.

At minimum, the gasoline you use should meet the specifications of ASTM D4814 in the U.S.A..

#### ■ Gasoline quality

In very few cases, driveability problems may be caused by the brand of gasoline you are using. If driveability problems persist, try changing the brand of gasoline. If this does not correct the problem, consult your Toyota dealer.

#### ■ Gasoline quality standards

- Automotive manufacturers in the U.S.A., Europe and Japan have developed a specification for fuel quality called the World-Wide Fuel Charter (WWFC), which is expected to be applied worldwide.
- The WWFC consists of four categories that are based on required emission levels. In the U.S., category 4 has been adopted.
- The WWFC improves air quality by lowering emissions in vehicle fleets, and improves customer satisfaction through better performance.

#### ■ Recommendation of the use of gasoline containing detergent additives

- Toyota recommends the use of gasoline that contains detergent additives to avoid the build-up of engine deposits.
- All gasoline sold in the U.S.A. contains minimum detergent additives to clean and/or keep clean intake systems, per EPA's lowest additives concentration program.
- Toyota strongly recommends the use of Top Tier Detergent Gasoline. For more information on Top Tier Detergent Gasoline and a list of marketers, please go to the official website www.toptiergas.com.

#### ■ Recommendation of the use of low emissions gasoline


Gasolines containing oxygenates such as ethers and ethanol, as well as reformulated gasolines, are available in some cities. These fuels are typically acceptable for use, providing they meet other fuel requirements.

Toyota recommends these fuels, since the formulations allow for reduced vehicle emissions.

#### ■ Non-recommendation of the use of blended gasoline

Use only gasoline containing up to 15% ethanol.

DO NOT use any flex-fuel or gasoline that could contain more than 15% ethanol, including from any pump labeled E30, E50, E85 (which are only some examples of fuel containing more than 15% ethanol).



- If you use gasohol in your vehicle, be sure that it has an octane rating no lower than 87.
- Toyota does not recommend the use of gasoline containing methanol.

#### ■ Non-recommendation of the use of gasoline containing MMT

Some gasoline contains an octane enhancing additive called MMT (Methylcy-clopentadienyl Manganese Tricarbonyl).

Toyota does not recommend the use of gasoline that contains MMT. If fuel containing MMT is used, your emission control system may be adversely affected.

The malfunction indicator lamp on the instrument cluster may come on. If this happens, contact your Toyota dealer for service.

#### ■ If your engine knocks

- Consult your Toyota dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

## 

#### Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Do not use leaded gasoline.
   Leaded gasoline can cause damage to your vehicle's three-way catalytic converters causing the emission control system to malfunction.
- Do not use gasohol other than the type previously stated.
   Other gasohol may cause fuel system damage or vehicle performance problems.
- Using unleaded gasoline with an octane number or rating lower than the level previously stated will cause persistent heavy knocking.
   At worst, this will lead to engine damage.

#### Fuel-related poor driveability

If poor driveability (poor hot starting, vaporization, engine knocking, etc.) is encountered after using a different type of fuel, discontinue the use of that type of fuel.


#### When refueling with gasohol

Take care not to spill gasohol. It can damage your vehicle's paint.


## **Tire information**

## **Typical tire symbols**

#### ▶ Full-size tire



## ▶ Compact spare tire



- 1 Tire size (→P. 513)
- (2) DOT and Tire Identification Number (TIN)(→P. 512)
- (3) Uniform tire quality grading

For details, see "Uniform Tire Quality Grading" that follows.

- (4) Location of treadwear indicators(→P. 403)
- (5) Tire ply composition and materials

Plies are layers of rubber-coated parallel cords. Cords are the strands which form the plies in a tire.

(6) Radial tires or bias-ply tires

A radial tire has "RADIAL" on the sidewall. A tire not marked "RADIAL" is a bias-ply tire.

(7) TUBELESS or TUBE TYPE

A tubeless tire does not have a tube and air is directly put into the tire. A tube type tire has a tube inside the tire and the tube maintains the air pressure.

- (8) Load limit at maximum cold tire inflation pressure (→P. 517)
- (9) Maximum cold tire inflation pressure (→P. 517)

This means the pressure to which a tire may be inflated.

(10) Summer tires or all season tires (→P. 407)

An all season tire has "M+S" on the sidewall. A tire not marked "M+S" is a summer tire.


(1) "TEMPORARY USE ONLY"


A compact spare tire is identified by the phrase "TEMPORARY USE ONLY" molded on its sidewall. This tire is designed for temporary emergency use only.

#### Typical DOT and Tire Identification Number (TIN)

▶ Type A

▶ Type B





- 1 DOT symbol\*
- 2 Tire Identification Number (TIN)
- ③ Tire manufacturer's identification mark
- (4) Tire size code
- (5) Manufacturer's optional tire type code (3 or 4 letters)
- 6 Manufacturing week
- (7) Manufacturing year
- (8) Manufacturer's code
  - \*: The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.

#### Tire size


#### ■ Typical tire size information


The illustration indicates typical tire size.

- 1 Tire use (P = Passenger car, T = Temporary use)
- ② Section width (millimeters)
- ③ Aspect ratio(tire height to section width)
- (4) Tire construction code (R = Radial, D = Diagonal)
- (5) Wheel diameter (inches)
- 6 Load index(2 digits or 3 digits)
- 7) Speed symbol (alphabet with one letter)

#### **■ Tire dimensions**


- (1) Section width
- (2) Tire height
- (3) Wheel diameter





## Tire section names

- 1 Bead
- ② Sidewall
- ③ Shoulder
- 4 Tread
- ⑤ Belt
- 6 Inner liner
- 7 Reinforcing rubber
- 8 Carcass
- Rim lines
- 10 Bead wires
- 11) Chafer



### Uniform Tire Quality Grading

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Toyota vehicles with information on uniform tire quality grading.

Your Toyota dealer will help answer any questions you may have as you read this information.

#### ■ DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

#### ■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1 - 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use. Performance may differ significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### ■ Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

#### ■ Temperature A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

Grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grades of a tire assume that it is properly inflated and not overloaded.

Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

## Glossary of tire terminology

Tire related term	Meaning
Cold tire inflation pressure	Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition
Maximum inflation pressure	The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire
Recommended inflation pressure	Cold tire inflation pressure recommended by a manufacturer
Accessory weight	The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not)
Curb weight	The weight of a motor vehicle with standard equipment, including the maximum capacity of fuel, oil and coolant, and if so equipped, air conditioning and additional weight optional engine
Maximum loaded vehi- cle weight	The sum of: (a) Curb weight (b) Accessory weight (c) Vehicle capacity weight (d) Production options weight
Normal occupant weight	150 lb. (68 kg) times the number of occupants specified in the second column of Table 1* that follows
Occupant distribution	Distribution of occupants in a vehicle as specified in the third column of Table 1* below

Tire related term	Meaning
Production options weight	The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim
Rim	A metal support for a tire or a tire and tube assembly upon which the tire beads are seated
Rim diameter (Wheel diameter)	Nominal diameter of the bead seat
Rim size designation	Rim diameter and width
Rim type designation	The industry manufacturer's designation for a rim by style or code
Rim width	Nominal distance between rim flanges
Vehicle capacity weight (Total load capacity)	The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity
Vehicle maximum load on the tire	The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight, and dividing by two
Vehicle normal load on the tire	The load on an individual tire that is determined by distributing to each axle its share of curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table 1* below), and dividing by two
Weather side	The surface area of the rim not covered by the inflated tire
Bead	The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim
Bead separation	A breakdown of the bond between components in the bead

Tire related term	Meaning
Bias ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread
Carcass	The tire structure, except tread and sidewall rubber which, when inflated, bears the load
Chunking	The breaking away of pieces of the tread or sidewall
Cord	The strands forming the plies in the tire
Cord separation	The parting of cords from adjacent rubber compounds
Cracking	Any parting within the tread, sidewall, or inner- liner of the tire extending to cord material
СТ	A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire
Extra load tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Groove	The space between two adjacent tread ribs
Innerliner	The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire
Innerliner separation	The parting of the innerliner from cord material in the carcass
Intended outboard sidewall	<ul> <li>(a) The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or</li> <li>(b) The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle</li> </ul>

Tire related term	Meaning
Light truck (LT) tire	A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles
Load rating	The maximum load that a tire is rated to carry for a given inflation pressure
Maximum load rating	The load rating for a tire at the maximum permissible inflation pressure for that tire
Maximum permissible inflation pressure	The maximum cold inflation pressure to which a tire may be inflated
Measuring rim	The rim on which a tire is fitted for physical dimension requirements
Open splice	Any parting at any junction of tread, sidewall, or innerliner that extends to cord material
Outer diameter	The overall diameter of an inflated new tire
Overall width	The linear distance between the exteriors of the sidewalls of an inflated tire, including ele- vations due to labeling, decorations, or protec- tive bands or ribs
Passenger car tire	A tire intended for use on passenger cars, multipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less.
Ply	A layer of rubber-coated parallel cords
Ply separation	A parting of rubber compound between adjacent plies
Pneumatic tire	A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load
Radial ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread
Reinforced tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire

Tire related term	Meaning
Section width	The linear distance between the exteriors of the sidewalls of an inflated tire, excluding ele- vations due to labeling, decoration, or protec- tive bands
Sidewall	That portion of a tire between the tread and bead
Sidewall separation	The parting of the rubber compound from the cord material in the sidewall
Snow tire	A tire that attains a traction index equal to or greater than 110, compared to the ASTM E-1136 Standard Reference Test Tire, when using the snow traction test as described in ASTM F-1805-00, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and
	which is marked with an Alpine Symbol ( 🔬 ) on at least one sidewall
Test rim	The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire
Tread	That portion of a tire that comes into contact with the road
Tread rib	A tread section running circumferentially around a tire
Tread separation	Pulling away of the tread from the tire carcass
Treadwear indicators (TWI)	The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread
Wheel-holding fixture	The fixture used to hold the wheel and tire assembly securely during testing

<sup>\*:</sup> Table 1 — Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capacity, Number of occupants	Vehicle normal load, Number of occupants	Occupant distribution in a normally loaded vehicle
2 through 4	2	2 in front
5 through 10	3	2 in front, 1 in second seat
11 through 15	5	2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat
16 through 20	7	2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat

## **Customizable features**

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. The settings of these features can be changed by using the meter control switches, the audio system screen or at your Toyota dealer.

#### Customizing vehicle features

- Changing by using the Entune Audio\*1
  - 1 Press the "SETUP" button.
  - 2 Select "Vehicle" on the "Setup" screen.

Various setting can be changed. Refer to the list of settings that can be changed for details.

- Changing by using the Entune Audio Plus\*<sup>2</sup> or Entune Premium Audio\*<sup>2</sup>
  - 1 Press the "APPS" button.
  - 2 Select "Setup" on the "Apps" screen and select "Vehicle".

Various setting can be changed. Refer to the list of settings that can be changed for details.

<sup>\*1:</sup> Audio system with "CAR" button

<sup>\*2:</sup> Audio system with "APPS" button

#### Customizable features

Some function settings are changed simultaneously with other functions being customized. Contact your Toyota dealer for further details. Definition of symbols: O = Available, — = Not available

#### ■ Gauges, meters and multi-information display (→P. 77, 81)

- ① Settings that can be changed on the Entune Audio screen
- 2 Settings that can be changed by the meter control switches
- 3 Settings that can be changed by your Toyota dealer

Function*1	Default setting	Customized set- ting	1	2	3
Language*2	English	French	0	0	
Language	English	Spanish	O		_
		km (km/L)	0		
	miles (MPG US)	km (L/100 km)		0	_
Units*2		miles (MPG CAN)			
	°F	°C	_	0	_
Eco Driving Indicator Light	Off	On (Self-lighting)	_	0	_
Drive information 1	Digital speedom- eter			0	
Drive information 1	Distance to empty			O	
Drive information 2	Average fuel economy (after reset)	6 of the following items: →P. 83	_	0	_
	Current fuel economy				
Drive information 3	Trip distance (after reset)		_	0	_
	Trip elapsed time				
Pop-up display	On	Off	—	0	_

Function*1	Default setting	Customized set- ting	1	2	3
		Blue			
Accent color	Light blue	Orange	0	0	_
		Yellow			
Speed limit display*3	On with the speed limit caution indicator (yellow) enabled	On with the speed limit caution indicator (yellow) not enabled	_	0	0
		Off			
Maintenance system initialization*4	Off	On	_	0	_

<sup>\*1:</sup> For details about each function: →P. 84
\*2: The default setting varies according to country.
\*3: Speed limit display may not be available for some regions.
\*4: U.S.A. only

- 1 Settings that can be changed using the Entune Audio
- ② Settings that can be changed using the Entune Audio Plus or Entune Premium Audio
- ③ Settings that can be changed by your Toyota dealer Definition of symbols: O = Available, — = Not available

## **■** Door lock (→P. 99, 107, 485)

Function	Default setting	Customized set- ting	1	2	3
Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step.		0	0
	Chiffing the chiff	Off			
Automatic door lock	Shifting the shift lever to position other than P	Vehicle speed reaches a certain level.	0	0	Ο
	Chiffing the shift	Off			
Automatic door unlock	Shifting the shift lever to P	Driver's door is opened	0	Ο	0
Locking/unlocking of the trunk when all doors are locked/unlocked	On	Off	_	_	0

Function	Default setting	Customized set- ting	1	2	3
Operation signal (Emergency flashers)	On	Off	_	0	0
Operation signal (Buzzer)	On	Off	_	_	О
Operation buzzer volume	Level 5	Off to level 7	0	0	0
Time elapsed before automatic door lock		Off			
function is activated if	60 seconds	30 seconds	_	0	О
door is not opened after being unlocked		120 seconds			
Open door warning buzzer	On	Off	_	_	0

<sup>\*:</sup> If equipped

## ■ Smart key system\* (→P. 99, 107, 112)

Function	Default setting	Customized set- ting	1	2	3
Smart key system	On	Off	_	_	0
Number of permissible times of continuous smart lock	Twice	Unlimited	_	_	0

<sup>\*:</sup> If equipped

## ■ Wireless remote control (→P. 92, 99, 107)

Function	Default setting	Customized set- ting	1	2	3
Wireless remote control	On	Off	_	_	О
Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	0	0	0
	Press and hold (short)	One short press			
Trunk unlooking opera		Push twice			
Trunk unlocking operation		Press and hold (long)	_	_	0
		Off			
Panic function	On	Off	_	_	0

## ■ Power window (driver's door) and moon roof\* (→P. 131, 134)

Function	Default setting	Customized set- ting	1	2	3
Key linked operation	Off	On	_	_	0
Wireless remote control linked opening	Off	On	_	_	0
Key linked closing	Off	On	_	_	О
Wireless remote control linked opening buzzer	On	Off	_	_	0

<sup>\*:</sup> If equipped

## ■ Moon roof\* (→P. 134)

Function	Default setting	Customized set- ting	1	2	3
Linked operation of com- ponents when door key is used	Slide only	Tilt only	_		0
Linked operation of com- ponents when wireless remote control is used	Slide only	Tilt only	_		0

<sup>\*:</sup> If equipped

Function	Default setting	Customized set- ting	1	2	3
The number of times the		Off*2			
turn signal lights flash automatically when the turn signal lever is moved to the first posi- tion during a lane change*1	3	4 to 7		_	0

<sup>\*1:</sup> After flashing the turn signal lights when turning left or right while this function is off and the turn signal lever is moved to the first position in the direction of the flashing light, the turn signal lights can be selected to be flashing or off.

#### ■ Automatic light control system (→P. 166)

Function	Default setting	Customized set- ting	1	2	3
Light sensor sensitivity	Level 3	Level 1 to 5	0	0	0
Time elapsed before headlights automatically turn off after doors are closed	30 seconds	Off			
		60 seconds	0	0	0
		90 seconds			

#### ■ Lights (→P. 166, 170)

Function	Default setting	Customized set- ting	1	2	3
Daytime running light system (except Canada)	On	Off	0	0	0
Automatic high beam*	On	Off	_	0	0

<sup>\*:</sup> If equipped

<e

<sup>\*2:</sup> The turn signal lights will be off if the turn signal lever is moved to the first position in the direction of flashing light.

## ■ Automatic air conditioning system\* (→P. 331)

Function	Default setting	Customized set- ting	1	2	3
A/C auto switch operation	Auto	Manual	_	0	0

<sup>\*:</sup> If equipped

## ■ Illumination (→P. 339)

Function	Default setting	Customized set- ting	1	2	3
Time elapsed before	7.5 seconds	0	0	0	
lights turn off	13 seconds	30 seconds			
Operation when the doors are unlocked	On	Off	_	_	0
Vehicles without smart key system: Operation after the engine switch turned to the "LOCK" position Vehicles with smart key system: Operation after the engine switch turned off	On	Off	_	_	0
Operation when you approach the vehicle with the electronic key on your person*	On	Off	_	_	0

<sup>\*:</sup> Vehicles with a smart key system

## ■ Seat belt reminder (→P. 447)

Function	Default setting	Customized set- ting	1	2	3
Vehicle speed linked seat belt reminder buzzer	On	Off	_		0

**MARNING** 

#### During customization

As the engine needs to be running during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



#### During customization

To prevent battery discharge, ensure that the engine is running while customizing features.

## Items to initialize

The following items must be initialized for normal system operation after such cases as maintenance being performed on the vehicle:

Item	When to initialize	Reference
Message indicating maintenance is required (U.S.A. only)	After the maintenance is performed	P. 381
	When changing the tire inflation pressure by changing traveling speed or load weight, etc.	P. 405

## For owners

10

Reporting safety defects	
for U.S. owners	534
Seat belt instructions	
for Canadian owners	
(in French)	535
SRS airbag instructions	
for Canadian owners	
(in French)	537

## Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-800-331-4331).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <a href="http://www.safercar.gov">http://www.safercar.gov</a>; or write to: Administrator, NHTSA, 1200 New Jersey Ave, S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <a href="http://www.safercar.gov">http://www.safercar.gov</a>.

# Seat belt instructions for Canadian owners (in French)

The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.

#### Utilisation correcte des ceintures de sécurité

- Déroulez la sangle diagonale de telle sorte qu'elle passe bien sur l'épaule, sans pour autant être en contact avec le cou ou glisser de l'épaule.
- Placez la sangle abdominale le plus bas possible sur les hanches.



- Réglez la position du dossier de siège. Asseyez-vous le dos droit et calez-vous bien dans le siège.
- Ne vrillez pas la ceinture de sécurité.

#### Entretien et soin

#### ■ Ceintures de sécurité

Nettoyez avec un chiffon ou une éponge humectée d'eau savonneuse tiède. Vérifiez régulièrement que les ceintures ne sont pas effilochées, entaillées ou exagérément usées.

10

For owne


#### AVERTISSEMENT

#### Dommage et usure de la ceinture de sécurité

Inspectez la ceinture de sécurité périodiquement. Vérifiez si elles ne sont pas entaillées, effilochées et que leurs ancrages ne sont pas desserrés. N'utilisez pas une ceinture de sécurité défectueuse avant qu'elle ne soit remplacée. Une ceinture de sécurité défectueuse n'apporte aucune garantie de protection de l'occupant en cas de blessures graves, voire mortelles.

The following is a French explanation of SRS airbag instructions extracted from the SRS airbag section in this manual.

See the SRS airbag section for more detailed SRS airbag instructions in English.



#### Coussins gonflables frontaux SRS

- ① Coussin gonflable conducteur/coussin gonflable du passager avant SRS
  - Participent à la protection de la tête et du thorax du conducteur et du passager avant contre les chocs contre les éléments de l'habitacle
- ② Coussins gonflables de genoux SRS

  Participent à la protection du conducteur et du passager avant


10

For owne

#### Coussins gonflables latéraux et rideaux SRS

- ③ Coussins gonflables latéraux avant SRS Participent à la protection du torse des occupants de siège avant
- (4) Coussins gonflables latéraux arrière SRS Participent à la protection du torse des occupants des sièges latéraux arrière
- (5) Coussins gonflables rideaux SRS
  - Participent principalement à la protection de la tête des occupants des sièges latéraux
  - Peut contribuer à empêcher les occupants d'être éjectés du véhicule en cas de tonneau

#### Composants du système de coussins gonflables SRS



- (1) Capteurs d'impact avant
- ② Système de classification de l'occupant du siège passager avant (ECU et capteurs)
- 3 Coussins gonflables de genoux
- (4) Capteurs d'impact latéral (portes avant)
- (5) Capteurs d'impact latéral (avant)
- 6 Coussin gonflable passager avant
- 7 Coussins gonflables latéraux avant
- (8) Coussins gonflables rideaux

- ① Témoins indicateurs "AIR BAG ON" et "AIR BAG OFF"
- (11) Témoin d'avertissement SRS
- ① Contact de boucle de ceinture de sécurité du passager avant
- (3) Ensemble de capteurs de coussins gonflables
- (4) Capteurs d'impact latéral (arrière)
- (15) Coussin gonflable conducteur
- (16) Contact de boucle de ceinture de sécurité conducteur
- (17) Prétensionneurs de ceintures de sécurité et limiteurs de force

10

For owne

Votre véhicule est équipé de COUSSINS GONFLABLES INTELLI-GENTS conçus selon les normes de sécurité américaines applicables aux véhicules à moteur (FMVSS208). L'ensemble de capteurs de coussins gonflables (ECU) régule le déploiement des coussins gonflables sur la base des informations qu'il reçoit des capteurs, etc., indiqués ci-dessus dans le schéma illustrant les composants du système. Parmi ces informations figurent la gravité du choc et l'occupation du véhicule par les passagers. Le déploiement rapide des coussins gonflables est obtenu au moyen d'une réaction chimique dans les dispositifs pyrotechniques, qui produit un gaz inoffensif permettant d'amortir le mouvement des occupants.

#### Précautions relatives aux coussins gonflables SRS

Respectez les précautions suivantes concernant les coussins gonflables SRS.

Le non-respect de ces précautions peut occasionner des blessures graves, voire mortelles.

- Le conducteur et tous les passagers du véhicule doivent porter correctement leur ceinture de sécurité.
  - Les coussins gonflables SRS sont des dispositifs supplémentaires à utiliser avec les ceintures de sécurité.
- Le coussin gonflable conducteur SRS se déploie avec une force considérable, pouvant occasionner des blessures graves, voire mortelles, si le conducteur se trouve très près du coussin gonflable. L'autorité fédérale chargée de la sécurité routière aux États-Unis (NHTSA) conseille:

La zone à risque du coussin gonflable conducteur se situant dans les premiers 2 à 3 in. (50 à 75 mm) de déploiement,vous placer à 10 in. (250 mm) de votre coussin gonflable conducteur vous garantit une marge de sécurité suffisante. Cette distance est à mesurer entre le centre du volant et le sternum. Si vous êtes assis à moins de 10 in. (250 mm), vous pouvez changer votre position de conduite de plusieurs façons:

- Reculez votre siège le plus possible, de manière à pouvoir encore atteindre confortablement les pédales.
- Inclinez légèrement le dossier du siège.

  Pien que les véhicules gient une est
  - Bien que les véhicules aient une conception différente, un grand nombre de conducteurs peuvent s'asseoir à une distance de 10 in. (250 mm), même avec le siège conducteur complètement avancé, simplement en inclinant un peu le dossier de siège. Si vous avez des difficultés à voir la route après avoir incliné le dossier de votre siège, utilisez un coussin ferme et antidérapant pour vous rehausser ou remontez le siège si votre véhicule est équipé de cette fonction.
- Si votre volant est réglable, inclinez-le vers le bas. Cela a pour effet d'orienter le coussin gonflable en direction de votre poitrine plutôt que de votre tête et de votre cou.

Réglez votre siège selon les recommandations de la NHTSA ci-dessus, tout en conservant le contrôle des pédales, du volant et la vue des commandes du tableau de bord.

10

For owne

### ■Précautions relatives aux coussins gonflables SRS

Si vous attachez une rallonge de ceinture de sécurité aux boucles de ceinture de sécurité avant, sans l'attacher au pêne de la ceinture de sécurité, les coussins gonflables frontaux SRS déterminent que le conducteur et le passager avant ont attaché leur ceinture de sécurité, bien que la ceinture de sécurité ne soit pas attachée. Dans ce cas, les coussins gonflables frontaux SRS peuvent ne pas se déployer correctement en cas de collision, pouvant occasionner des blessures graves, voire mortelles. Veillez à porter la ceinture de sécurité avec la rallonge de ceinture de sécurité.




- Le coussin gonflable passager avant SRS se déploie également avec une force considérable, pouvant occasionner des blessures graves, voire mortelles, si le passager avant se trouve très près du coussin gonflable. Le siège du passager avant doit être éloigné le plus possible du coussin gonflable en réglant le dossier de siège de façon à ce que le passager avant soit assis bien droit dans le siège.
- Les nourrissons et les enfants qui ne sont pas correctement assis et/ou attachés peuvent être grièvement blessés ou tués par le déploiement d'un coussin gonflable. Un nourrisson ou un enfant trop petit pour utiliser une ceinture de sécurité doit être correctement attaché au moyen d'un siège de sécurité enfant. Toyota recommande vivement d'installer tous les nourrissons et enfants sur les sièges arrière du véhicule et de prévoir pour eux des systèmes de retenue adaptés. Les sièges arrière sont plus sûrs pour les nourrissons et les enfants que le siège du passager avant. (→P. 539)

### ■Précautions relatives aux coussins gonflables SRS

Ne vous asseyez pas sur le bord du siège et ne vous appuyez pas contre la planche de bord.



- Ne laissez pas un enfant rester debout devant le coussin gonflable passager avant SRS ou s'asseoir sur les genoux du passager avant.
- Ne laissez pas les occupants des sièges avant voyager avec un objet sur les genoux.
- Ne vous appuyez pas contre la porte, le rail latéral de toit ou les montants avant, latéraux et arrière.






• Ne laissez personne s'agenouiller sur le siège passager en appui contre la porte ou sortir la tête ou les mains à l'extérieur du véhicule.



### ■Précautions relatives aux coussins gonflables SRS

Ne fixez rien et ne posez rien sur des emplacements tels que la planche de bord, la garniture du volant et la partie inférieure du tableau de bord.

Ces éléments peuvent se transformer en projectiles lorsque les coussins gonflables conducteur, passager avant et genoux SRS se déploient.





 Véhicules sans système d'accès et de démarrage mains libres: Ne fixez pas d'objets lourds, pointus ou très durs, tels que des clés et des accessoires aux clés. Ces objets risquent d'entraver le déploiement du coussin gonflable de genoux du conducteur SRS ou d'être projetés vers le siège conducteur par la force de déploiement du coussin gonflable, constituant ainsi un danger potentiel.



Ne suspendez aucun cintre ou objet dur aux crochets à vêtements. Tous ces objets pourraient se transformer en projectiles et causer des blessures graves, voire mortelles en cas de déploiement des coussins gonflables rideaux SRS.




#### Précautions relatives aux coussins gonflables SRS

- Si un cache en vinyle est placé sur la zone où le coussin gonflable de genoux SRS se déploie, assurez-vous de le retirer.
- N'utilisez aucun accessoire de siège recouvrant les zones de déploiement des coussins gonflables latéraux SRS, car il risque de gêner le déploiement des coussins gonflables. De tels accessoires peuvent empêcher les coussins gonflables latéraux de fonctionner correctement, désactiver le système ou entraîner le déploiement accidentel des coussins gonflables latéraux, occasionnant des blessures graves, voire mortelles.
- Évitez de faire subir des chocs ou des pressions excessives aux parties renfermant les composants de coussins gonflables SRS. En effet, cela pourrait entraîner un dysfonctionnement des coussins gonflables SRS.
- Ne touchez aucun composant immédiatement après le déploiement (gonflage) des coussins gonflables SRS, car ils peuvent être chauds.
- Si vous avez des difficultés à respirer après le déploiement des coussins gonflables SRS, ouvrez une porte ou une vitre pour faire entrer de l'air frais, ou bien descendez du véhicule si cela ne présente pas de danger. Essuyez tout résidu dès que possible afin d'éviter d'éventuelles irritations de la peau.
- Si les parties renfermant les coussins gonflables SRS, comme les garnitures du volant et des montants avant et arrière, sont endommagées ou craquelées, faites-les remplacer par votre concessionnaire Toyota.
- Ne placez rien sur le siège du passager avant, comme un coussin par exemple. Cela a pour conséquence de répartir le poids du passager sur toute la surface du siège, ce qui empêche le capteur de détecter correctement le poids du passager. En conséquence, les coussins gonflables frontaux SRS du passager avant risquent de ne pas se déployer en cas de collision.

### Modification et mise au rebut des composants du système de coussins gonflables SRS

Ne mettez pas votre véhicule au rebut et ne procédez à aucune des modifications suivantes sans consulter votre concessionnaire Toyota. Les coussins gonflables SRS peuvent ne pas fonctionner correctement ou se déployer (se gonfler) accidentellement, provoquant la mort ou de graves blessures.

- Installation, dépose, démontage et réparation des coussins gonflables SRS
- Réparations, modifications, démontage ou remplacement du volant, du tableau de bord, de la planche de bord, des sièges ou de leur garnissage, des montants avant, latéraux et arrière ou des rails latéraux de toit
- Réparations ou modifications des ailes avant, du pare-chocs avant ou des flancs de l'habitacle
- Installation d'un protège-calandre (pare-buffle, pare-kangourou, etc.), de chasse-neige, de treuils, ou d'un porte-bagages de toit
- Modifications du système de suspension du véhicule
- Installation d'appareils électroniques tels que les émetteurs/récepteurs radios mobiles et les lecteurs CD
- Modifications de votre véhicule pour une personne atteinte d'un handicap physique



Vehicles with a Entune Premium Audio or Entune Audio Plus:

For details of equipment related to the Entune Premium Audio or Entune Audio Plus, such as the audio system, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

### What to do if... (Troubleshooting)

If you have a problem, check the following before contacting your Toyota dealer.

### The doors cannot be locked, unlocked, opened or closed



### You lose your keys

- If you lose your keys or mechanical keys, new genuine keys or mechanical keys can be made by your Toyota dealer. (→P. 95)
- If you lose your keys or electronic keys, the risk of vehicle theft increases significantly. Contact your Toyota dealer immediately. (→P. 98)



### The doors cannot be locked or unlocked

- Is the key battery weak or depleted? (→P. 420)
- Vehicles with a smart key system:
   Is the engine switch in IGNITION ON mode?
   When locking the doors, turn the engine switch off. (→P. 156)
- Vehicles with a smart key system:
   Is the electronic key left inside the vehicle?
   When locking the doors, make sure that you have the electronic key on your person.
- The function may not operate properly due to the condition of the radio wave. (→P. 115)



#### The rear door cannot be opened

• Is the child-protector lock set? The rear door cannot be opened from inside the vehicle when the lock is set. Open the rear door from outside and then unlock the child-protector lock. (→P. 103)



## The trunk lid is closed with the electronic key left inside (vehicles with a smart key system)

• The function to prevent the electronic key from being left inside the trunk will operate and you can open the trunk as usual. Take the key out from the trunk. (→P. 109)

### If you think something is wrong



## The engine does not start (vehicles without a smart key system)

- Is the shift lever in P? ( $\rightarrow$ P. 153)
- Is the steering wheel unlocked? (→P. 153)
- Is the battery discharged? (→P. 488)



## The engine does not start (vehicles with a smart key system)

- Did you press the engine switch while firmly depressing the brake pedal? (→P. 155)
- Is the shift lever in P? ( $\rightarrow$ P. 157)
- Is the electronic key anywhere detectable inside the vehicle?  $(\rightarrow P. 113)$
- Is the steering wheel unlocked? ( $\rightarrow$ P. 157)
- Is the electronic key battery weak or depleted?
  In this case, the engine can be started in a temporary way. (→P. 486)
- Is the battery discharged? (→P. 488)



### The shift lever cannot be shifted from P even if you depress the brake pedal

Vehicles without a smart key system:

Is the engine switch in the "ON" position?

If you cannot release the shift lever by depressing the brake pedal with the engine switch in the "ON" position. ( $\rightarrow$ P. 484)

Vehicles with a smart key system:

Is the engine switch in IGNITION ON mode?

If you cannot release the shift lever by depressing the brake pedal with the engine switch in IGNITION ON mode. (→P. 484)



### The steering wheel cannot be turned after the engine is stopped

Vehicles without a smart key system: It is locked to prevent theft of the vehicle if the key is pulled from the engine switch. (→P. 154)

Vehicles with a smart key system: It is locked automatically to prevent theft of the vehicle. ( $\rightarrow$ P. 157)



### The windows do not open or close by operating the power window switches

• Is the window lock switch pressed? The power window except for the one at the driver's seat cannot be operated if the window lock switch is pressed. (→P. 131)



### The engine switch is turned off automatically (vehicles with a smart key system)

• The auto power off function will be operated if the vehicle is left in ACCES-SORY or IGNITION ON mode (the engine is not running) for a period of time. (→P. 157)



### A warning buzzer sounds during driving

- The seat belt reminder light is flashing
   Are the driver and the front passenger wearing the seat belts? (→P. 447)
- The brake system warning light is on Is the parking brake released? (→P. 165)

Depending on the situation, other types of warning buzzer may also sound.  $(\rightarrow P. 446, 454)$ 



### A warning buzzer sounds when leaving the vehicle (vehicles with a smart key system)

• Is the electronic key left inside the vehicle or the moon roof open? Check the message on the multi-information display. (→P. 454)



## An alarm is activated and the horn sounds (vehicles with an alarm)

- Did anyone inside the vehicle open a door during setting the alarm? The sensor detects it and the alarm sounds. (→P. 69)
- Vehicles without a smart key system:

To stop the alarm, turn the engine switch to the "ON" position or start the engine.

Vehicles with a smart key system:

To stop the alarm, turn the engine switch to IGNITION ON mode or start the engine.



### A warning light turns on or a warning message or indicator is displayed

 When a warning light turns on or a warning message or indicator is displayed, refer to P. 446, 454.

### When a problem has occurred



### If you have a flat tire

 Stop the vehicle in a safe place and replace the flat tire with the spare tire. (→P. 470)



### The vehicle becomes stuck

Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P. 495)

### Alphabetical index

Α	
A/C326, 33	1
Air conditioning filter418	8
ABS	
(Anti-lock Brake System) 214	
Function21	4
Warning light446	6
Air conditioning filter418	8
Air conditioning	
system326, 33	
Air conditioning filter418	
Airbags34	
Airbag operating conditions 43	3
Airbag precautions for	
your child 31	
Airbag warning light446	
Correct driving posture 26	6
Curtain shield airbag operating	
conditions43	3
Curtain shield airbag	_
precautions40	0
Front passenger occupant	
classification system4	
General airbag precautions 3	
Locations of airbags34	4
Modification and	_
disposal of airbags42	2
Side airbag operating	^
conditions	
Side and system shield sixbage	1
Side and curtain shield airbags	2
operating conditions	3
Side and curtain shield airbags precautions3	_
SRS airbags3	
_	
Alarm 69	

Antennas	
(smart key system)	112
Anti-lock Brake System	
(ABS)	214
Function	214
Warning light	446
Armrest	
Assist grips <sub></sub>	356
Audio input*	245
Audio system*	240
Antenna	
Audio input	
AUX port/USB port	
Bluetooth <sup>®</sup> audio	288
CD player	261
iPod	
MP3/WMA disc	261
Optimal use	258
Portable music player	275
Radio	259
Steering wheel audio	
switch	244
USB memory	271
Automatic High Beam	170
Automatic light control	
system	166
Automatic transmission	. 160
If the shift lever	
cannot be shifted from P	484
Paddle shift switches	162
S mode	. 161
AUX port*	245
Auxiliary boxes	346

В
Back-up lights
Replacing light bulb433
Wattage506
Battery 400
Battery checking 400
If the vehicle has discharged
battery488
Preparing and checking
before winter234
Warning message456
Bluetooth <sup>®*</sup>
Audio system288
Hands-free system
(for cellular phone)289
Multimedia system 288, 289
Bottle holders 344
Brake
Fluid 503
Parking brake165
Warning light446
Brake assist214
Break-in tips141
Brightness control
Instrument panel light
control78
BSM (Blind Spot Monitor) 226
Blind Spot Monitor
function
Rear Cross Traffic Alert
function231

C
Care 374, 377
Aluminum wheels 375
Exterior 374
Interior 377
Seat belts378
Cargo capacity150
CD player* 261
Chains 235
Child restraint system 54
Booster seats, definition 55
Booster seats, installation 62
Convertible seats,
definition55
Convertible seats,
installation61
Front passenger occupant
classification system 47
Infant seats, definition55
Infant seats, installation 60
Installing CRS with LATCH
anchors59
Installing CRS with seat
belts60
Installing CRS with top tether
strap 63

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

Child safety 53
Airbag precautions37
Battery precautions 401, 491
Child restraint system54
How your child should wear
the seat belt30
Installing child restraints 58
Moon roof precautions137
Power window lock switch 131
Power window precautions 133
Rear door child-protectors 103
Removed electronic key
battery precautions423
Seat belt extender
precautions33
Seat belt precautions32
Seat heater precautions 337
Trunk precautions110
Child-protectors103
Cleaning 374, 377
Aluminum wheels374, 375
Aluminum wheels375 Exterior374
Aluminum wheels
Aluminum wheels
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353         Coat hooks       357
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353         Coat hooks       357         Compass       369
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353         Coat hooks       357         Compass       369         Condenser       398
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353         Coat hooks       357         Compass       369         Condenser       398         Console box       343
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353         Coat hooks       357         Compass       369         Condenser       398         Console box       343         Cooling system       397
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353         Coat hooks       357         Compass       369         Condenser       398         Console box       343         Cooling system       397         Engine overheating       492
Aluminum wheels       375         Exterior       374         Interior       377         Seat belts       378         Clock*       353         Coat hooks       357         Compass       369         Condenser       398         Console box       343         Cooling system       397         Engine overheating       492         Cruise control
Aluminum wheels

D
Daytime running light
system167
Defogger
Outside rear view
mirrors 327, 333
Rear window 327, 333
Windshield 327, 333
Dimensions 498
<b>Dinghy towing 152</b>
Display
Cruise control 181
Drive information 83
Dynamic radar cruise
control 186
LDA (Lane Departure
Alert)199
Multi-information display 81
Warning message 454
Do-it-yourself maintenance 388
Door courtesy lights
Location339
Wattage 506

Door lock
Doors99
Key100
Smart key system99
Wireless remote control99
Doors99
Automatic door locking
and unlocking systems 103
Door lock102
Door windows131
Open door warning 455
Open door warning buzzer 101
Outside rear view mirrors 129
Rear door child-protector 103
Driving140
Break-in tips141
Correct posture26
Procedures140
Winter drive tips234
Dynamic radar cruise
control186

E	
Eco Driving Indicator 79	
EDR (Event data recorder) 10	
Electric Power Steering	
(EPS)214	
Function214	
Warning light447	
Electronic key 92	
Battery-saving function 115	
If the electronic key does not	
operate properly485	
Replacing the battery420	
Emergency flashers 438	
Emergency, in case of	
If a warning buzzer	
sounds446	
If a warning light turns on 446	
If a warning message or	
indicator is displayed 454	
If the battery is discharged 488	
If the electronic key does not	
operate properly	
If the engine will not start 482 If the shift lever cannot be	
shifted from P	
If you have a flat tire 470 If you think something is	
,	
wrong444 If your vehicle becomes	
stuck495	
If your vehicle has to be	
stopped in an emergency 439	
If your vehicle needs to be	
towed441	
If your vehicle overheats 492	

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

Engine	500
Compartment	392
Engine switch 153,	155
Hood	
How to start the	
engine153,	155
Identification number	499
If the engine will not start	482
Ignition switch	
(engine switch) 153,	155
Overheating	492
Engine coolant	397
Capacity	
Checking	397
Preparing and checking	
before winter	234
Engine coolant temperature	
gauge	77
Engine immobilizer system	67
Engine oil	394
Capacity	500
Checking	394
Oil pressure warning	
message	458
Preparing and checking	
before winter	234

Engine switch	153, 155
Entune Audio*	240
Audio input	245
AUX port/USB port	245
Bluetooth® audio	288
CD player	261
iPod	267
MP3/WMA disc	261
Optimal use	258
Portable music player	275
Radio	259
Steering wheel audio	
switch	244
USB memory	271
Entune Audio Plus*	
Entune Premium Audio*	
EPS	
(Electric Power Steering	) 214
Function	214
Warning light	
Event data recorder (EDR	) 10

F	
Flat tire	470
Floor mats	24
Fluid	
Automatic transaxle	503
Brake	503
Washer	402
Front interior light	340
Wattage	506
Front passenger occupant	
classification system	
Front personal lights	340
Wattage	506
Front seats	
Adjustment	
Cleaning	
Correct driving posture	
Head restraints	
Seat heaters	
Front side marker lights	
Light switch	166
Replacing light bulbs	429
Wattage	506
Front turn signal lights	164
Replacing light bulbs	430
Turn signal lever	164
Wattage	506

Fuel178
Capacity500
Fuel gauge77
Fuel pump shut off system 445
Information507
Refueling 178
Type 500, 507
Warning light447
Warning message461
Fuel consumption87
Fuel filler door 178
Refueling 178
Fuel pump shut off system 445
Fuses 424

### 

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

н
Hands-free system
(for cellular phone)* 276, 289
Head restraints123
Headlights166
Automatic High Beam
system170
Light switch166
Replacing light
bulbs428, 429, 434
Wattage 506
Heaters
Outside rear view
mirrors 327, 333
Seat heaters337
Hood390
Hooks
Coat hooks357
Grocery bag hooks351
Retaining hooks (floor mat)24
Horn125

I/M test387
Identification499
Engine 499
Vehicle499
Ignition switch
(engine switch)153, 155
Illuminated entry system 341
Immobilizer system67
Indicators75
Initialization
Maintenance381
Moon roof136
Power windows132
Tire pressure
warning system 404
Inside rear view mirror 127
Instrument panel light
control78
Interior lights 340
Switch340
Wattage 506
J
Jack
Positioning the jack 391

 Moon roof
 135

 Power window
 132

Jam protection function

N.	
Keyless entry	
Smart key system99,	107
Wireless remote	
control99,	108
Keys	92
Battery-saving function	115
Electronic key	92
Engine switch 153,	155
If the electronic key does	
not operate properly	485
If you lose your keys	95
Key number plate	
Keyless entry	93
Mechanical key	94
Replacing the battery	420
Warning buzzer	.101
Wireless remote control	93
Knee airbags	34

L
Lane Departure Alert (LDA) 199
LATCH anchors 59
LDA (Lane Departure Alert) 199
Lever
Auxiliary catch lever390
Fuel filler door opener 178
Hood lock release lever 390
Internal trunk release lever 109
Shift lever 160
Tilt and telescopic steering
lock release lever 125
Trunk opener 107
Turn signal lever164
Wiper lever 176
License plate lights166
Light switch166
Replacing light bulbs 434
Wattage 506
Light bulbs
Replacing427
Wattage 506
Lights
Automatic High Beam
system170
Headlight switch 166
Illuminated entry system 341
Interior lights 340
Interior lights list339
Personal lights 340
Replacing light bulbs 427
Trunk light109
Turn signal lever164
Vanity lights352
Wattage 506
Load capacity 150
Lock steering column 125

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

M
Maintenance
Do-it-yourself maintenance 388
General maintenance 383
Maintenance data498
Maintenance
requirements380
Resetting the message
indicating maintenance
is required381
Malfunction indicator lamp 446
Manual air conditioning
system326
Master warning light447
Meter77
Indicators75
Indicators75 Instrument panel light
Indicators75
Indicators
Indicators
Indicators
Indicators
Indicators       75         Instrument panel light       78         control       78         Meters       77         Multi-information display       81         Warning lights       73         Warning message       454         Mirrors
Indicators       .75         Instrument panel light       .78         control       .78         Meters       .77         Multi-information display       .81         Warning lights       .73         Warning message       .454         Mirrors         Inside rear view mirror       .127
Indicators
Indicators
Indicators

Mobile Assistant*	. 323
Moon roof	. 134
Jam protection function	. 135
Operation	
MP3 disc*	. 261
Multi-information display	81
Audio system-linked	81
Customizing vehicle	
features	84
Drive information	83
Navigation system-linked	81
Settings display	84
Switching the display	82
Warning message	. 454
-	
N	

# Navigation system\* Noise from under vehicle .......... 8

0	
Odometer	77
Oil	
Engine oil5	00
Opener	
Fuel filler door1	80
Hood3	90
Trunk1	07
Outside rear view mirrors1	29
Adjusting and folding1	29
BSM (Blind spot monitor)2	26
Outside rear view mirror	
defoggers 327, 3	33
Outside temperature	
display	77
Overheating, Engine4	92

P	
Paddle shift switches 162	2
Parking brake16	5
Operation169	5
Parking brake engaged	
warning buzzer 446, 45	5
Parking brake engaged	
warning message 45	5
Warning light446	6
Parking lights16	6
Light switch166	6
Replacing light bulbs 430	0
Wattage 500	6
PCS	
(Pre-Collision System) 219	9
Function219	9
PCS switch219	9
Warning light44	7
Personal lights34	0
Wattage 500	6
Power outlet 35	5
Power steering	
(Electric power steering) 214	4
Warning light44	7
Power windows 13	1
Jam protection function 132	2
Operation13	1
Window lock switch 13	1
Pre-Collision System	
(PCS)219	9
Function219	9
PCS switch219	9
Warning light44	7

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

K	
Radar cruise control (dynamic	C
radar cruise control)	. 186
Radiator	
Radio <sup>*</sup>	. 259
Rear personal lights	. 340
Wattage	. 506
Rear seat	
Folding down	. 121
Rear side marker lights	. 166
Light switch	. 166
Replacing light bulbs	. 431
Wattage	. 506
Rear turn signal lights	. 164
Replacing light bulbs	. 431
Turn signal lever	
Wattage	. 506
Rear view mirror	
Inside rear view mirror	
Outside rear view mirrors	
Rear view monitor system*	
Rear window defogger 327,	333
Refueling	. 178
Capacity	
Fuel types	. 500
Opening the fuel tank cap	. 180
Replacing	
Electronic key battery	
Fuses	
Light bulbs	
Tires	. 470
Wireless remote control	
battery	. 420
Reporting safety defects	
for U.S. owners	. 534
Resetting the message	
indicating maintenance	
is required	381

Safety Connect 364
Seat belt reminder light 447
Seat belts 28
Adjusting the seat belt29
Automatic Locking
Retractor (ALR)30
Child restraint system
installation 60
Cleaning and maintaining
the seat belt 378
Emergency Locking Retractor
(ELR)30
How to wear your seat belt 28
How your child should wear
the seat belt30
Pregnant women, proper
seat belt use31
Reminder light and buzzer 447
Seat belt extender 30
Seat belt pretensioners 29
SRS warning light 446
Seat heaters 337
Seating capacity150
Seats119
Adjustment119
Adjustment precautions 120
Child seats/child restraint
system installation 58
Cleaning 377
Head restraints 123
Properly sitting in the seat 26
Seat heaters 337

Sensor
Automatic headlight
system167
Automatic High Beam
system175
Inside rear view mirror 128
LDA (Lane Departure
Alert)199
Radar sensor 194, 220, 224
Shift lever 160
Automatic transmission 160
If the shift lever cannot
be shifted from P484
S mode161
Shift lock system484
Side airbags35
Side marker lights166
Light switch166
Replacing light bulbs 429, 431
Wattage 506
Side mirrors129
Adjusting and folding 129
BSM (Blind Spot Monitor) 226
Smart key system112
Antenna location112
Entry functions 99, 107
Starting the engine155
Warning message464
Snow tires236
Spare tire470
Inflation pressure504
Storage location471

Spark plug	502
Specifications	498
Speech command system*	
Speedometer	77
Steering lock	
Column lock release	154
Warning message	467
Steering wheel	125
Adjustment	125
Audio remote control	
switches*	244
Meter control switches	82
Stop/tail lights	
Replacing light bulbs	431
Wattage	506
Storage feature	342
Stuck	
If the vehicle becomes	
stuck	495
Sun shade	
Roof	135
Sun visors	352

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

SWITCHES	
Audio remote control	
switches*	. 244
Automatic High Beam	
switch	. 170
BSM (Blind Spot Monitor)	
switch	
Compass switch	
Cruise control switch	
Door lock switches	. 102
Dynamic radar cruise	
control switch	
Emergency flasher switch	
Engine switch153,	155
Garage door opener	
switches	
Ignition switch 153,	155
LDA (Lane Departure Alert)	
switch	
Light switches	
Meter control switches	
Moon roof switches	. 134
Outside rear view mirror	400
switches	
Paddle shift switches	
PCS switch Power door lock switch	
Power window switches  Rear window and outside	. 131
rear view mirror	
defoggers switch 327,	222
Seat heater switches	
"SOS" button	
Steering switches 82, 244,	
Talk switch*	320
Telephone switches*	301
Tire pressure warning reset	. 50 1
switch	405
Vehicle-to-vehicle distance	. 400
button	186
VSC OFF switch	
Window lock switch	
Windshield wiper and	
washer switch	176
washer swiich	. I/D

Т	
Tachometer	77
Tail lights	166
Light switch	166
Replacing light bulbs	431
Wattage	506
Talk switch*	320
Talk switch* Telephone switches*	301
Theft deterrent system	
Alarm	69
Engine immobilizer system	67
Tire inflation pressure	413
Maintenance data	504
Warning light	448
Tire information	510
Glossary	517
Size	513
Tire identification number	512
Uniform Tire Quality	
Grading	515
Tire pressure warning	
system	404
Function	404
Initializing	404
Installing tire pressure	
warning valves and	
transmitters	404
Registering ID codes	405
Tire pressure warning reset	
switch	
Warning light	448
Warning message 459,	460

Tires	403
Chains	235
Checking4	403
If you have a flat tire	470
Inflation pressure	504
Information	510
Replacing	470
Rotating tires	403
Size	504
Snow tires	236
Spare tire	470
Tire pressure warning	
system4	404
Warning light	448
Warning message 459, 4	460
Tools	
Top tether strap	. 63
Total load capacity	150
Towing	
Dinghy towing	152
Emergency towing	441
Trailer towing	151
TRAC (Traction Control)	214
Traction Control (TRAC)	214
Trailer towing	151

Transmission 160
Automatic transmission 160
If the shift lever cannot be
shifted from P484
Paddle shift switches 162
S mode 161
Trip information78
Trip meters77
Trunk 107
Grocery bag hooks 351
Internal trunk release lever 109
Smart key system 107
Trunk light109
Trunk opener 107
Wireless remote control 108
Trunk light
Trunk light109
Wattage 506
Turn signal lights 164
Replacing light bulbs 430, 431
Turn signal lever164
Wattage 506

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

U	
USB port*	245
V	
Valet key	. 92
Vanity lights	352
Wattage	506
Vanity mirrors	352
Vehicle data recording	g
Vehicle identification	
number	499
Vehicle Stability Control	
(VSC)	214
Voice command system*	320
vsc	
(Vehicle Stability Control)	214

**
Warning buzzers
Brake system446
Downshifting163
Electric power steering
system447
Key reminder 154, 466
Open door 455
Open hood 455
Open moon roof 459
Open trunk 455
Parking brake 446, 455
Seat belt reminder 447
Warning lights 73
ABS 446
Brake system 446
Electric power steering
system447
Low fuel level447
Malfunction indicator lamp 446
Master warning light 447
Pre-collision system 447
Seat belt reminder light 447
Slip indicator 447
SRS 446
Tire pressure 448
Warning messages454
Washer 176
Checking 402
Preparing and checking
before winter 234
Switch176

Washing and waxing	. 374
Weight	. 498
Cargo capacity	. 150
Load limits	. 150
Vehicle capacity weight	. 498
Wheels	416
Replacing	416
Size	. 504
Window lock switch	. 131
Windows	. 131
Power windows	. 131
Rear window	
defogger 327,	333
Windshield wipers	. 176
Winter driving tips	. 234
Wireless remote control	93
Battery-Saving Function	. 115
Locking/Unlocking 99,	
Replacing the battery	.420
WMA disc*	

<sup>\*:</sup> For vehicles with a Entune Premium Audio or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

GAS STATION INFORMATION		
Auxiliary catch lever	Trunk opener	Fuel filler door
P. 390	P. 107	P. 178
CTYPIBJOT		CTYPIBJ019
Hood lock release lever	Fuel filler door opener	Tire inflation pressure
P. 390	P. 178	P. 504
Fuel tank capacity	17.0 gal. (64.35 L, 14.2 lm	on gal )
(Reference)	17.0 gai. (04.35 L, 14.2 IIIIp. gai.)	
Fuel type	P. 500, 507	
Cold tire inflation pressure		P. 504
Engine oil capacity (Drain and refill — reference)		P. 500
Engine oil type	"Toyota Genuine Motor Oil" or equivalent P. 500	