

MEGANE

vehicle user manual



Castrol, exclusive Renault partner



Benefit from cutting-edge technology born out of competition to ensure the performance and longevity of your Renault thanks to wide range of engine lubricants developed specially by Renault and Castrol.

Renault recommends 

[renault.fr](https://www.renault.fr)

Welcome to your new vehicle

This driver's handbook contains the information necessary:

- for you to familiarise yourself with your vehicle, to use it to its best advantage and to benefit fully from all the functions and the technical developments it incorporates.
- to ensure that it always gives the best performance by following the simple, but comprehensive advice concerning regular maintenance.
- to enable you to deal quickly with minor faults not requiring specialist attention.

It is well worth taking a few minutes to read this handbook to familiarise yourself with the information and guidelines it contains about the vehicle and its functions and new features. If certain points are still unclear, our Network technicians will be only too pleased to provide you with any additional information.

To help you, you will find the following symbols:



These appear in the vehicle and indicate that you should consult the manual for detailed information and/or limits on operations with respect to your vehicle's equipment.

➡ anywhere in the manual indicates a transfer to a page.



anywhere in the manual indicates a hazard, danger or a safety recommendation.

The descriptions of the models given in this handbook are based on the technical specifications at the time of writing. **This handbook covers all items of equipment** (both standard and optional) **available for these models but whether or not these are fitted to the vehicle depends on the version, options selected and the country where the vehicle is sold.** **This handbook may also contain information about items of equipment to be introduced later in the model year.** **The diagrams in the user manual are provided as examples.**

Enjoy driving your new vehicle.

Translated from French. Copying or translation, in part or in full, is forbidden unless prior written permission has been obtained from the car manufacturer.

EXTERIOR

Electric windows ➡ 3.28

Windscreen wipers ➡ 1.108 and ➡ 1.114

Demisting ➡ 3.5 and ➡ 3.8

Rear view mirrors
➡ 1.99

Key/Remote control ➡ 1.2

Map ➡ 1.6

Locking/unlocking the doors
➡ 1.14

Bodywork maintenance ➡ 4.15

Tyres ➡ 5.13

Lights: operation ➡ 1.102

Lights: replacement ➡ 5.16



Filling with fuel ➡ 1.116

PASSENGER COMPARTMENT

Adjusting your driving position ➔ 1.29

Passenger compartment storage, fittings ➔ 3.36

Rear bench seat ➔ 3.44
Rear headrests ➔ 3.42


Front seats ➔ 1.21 and ➔ 1.24
Front headrests ➔ 1.20

Child safety ➔ 1.43

Luggage compartment storage/fittings ➔ 3.54

48107

DRIVER'S POSITION



DRIVING AIDS

48101

ABS (anti-lock braking system)
ESC (electronic stability control)
Braking assistance
Hill start assistance ➔ 2.43

Speed limiter ➔ 2.85

Detection of road signs ➔ 2.81

Lane departure warning ➔ 2.49


Lane Keeping Assist ➔ 2.54

Active emergency braking
➔ 2.71

Blind spot warning ➔ 2.60

Safe distance alert ➔ 2.67

Stop and Start ➔ 2.8



Cruise control ➔ 2.89

Adaptive cruise control ➔ 2.94

Parking distance control ➔ 2.124

Reversing camera ➔ 2.130

Assisted parking ➔ 2.137

Tyre pressure monitoring system
➔ 2.32

SAFETY ON BOARD


Front Airbags ➡ 1.34

Inhibiting the front passenger airbag ➡ 1.58

Curtain Airbags ➡ 1.41


Side Airbags ➡ 1.41

Seat belts ➡ 1.29




IDENTIFYING A VEHICLE - LABELS

48102



THE ENGINE COMPARTMENT (routine maintenance)



BREAKDOWN RECOVERY

Replacing windscreen wiper blade(s) ➡ 1.108

Replacing headlight bulbs ➡ 5.16

Front towing point ➡ 5.39

Replacing the rear screen wiper blade ➡ 1.114

Replacing rear light bulbs ➡ 5.18

Rear towing point ➡ 5.39

Puncture:

Tools ➡ 5.8

Emergency spare wheel ➡ 5.2

Changing a wheel ➡ 5.11

Fuses ➡ 5.28

C O N T E N T S

Sections

Getting to know your vehicle

1

Driving

2

Your comfort

3

Maintenance

4

Practical advice

5

Technical specifications

6

Alphabetical index


7

Section 1: Getting to know your vehicle

Key, radio frequency remote control: general information, use, deadlocking	1.2
Card: general information, use, deadlocking	1.6
Locking and unlocking the doors	1.14
Opening and closing the doors	1.17
Automatic locking when driving	1.19
Headrests - Seats	1.20
Seat belts.	1.29
Additional methods of restraint:	1.34
in addition to the front seat belts	1.34
to the rear seat belts	1.40
side protection	1.41
Child safety: general information	1.43
choosing a child seat mounting	1.46
fitting a child seat, general information.	1.50
Child seats: attachment by seat belt or by ISOFIX system	1.52
deactivating, activating the front passenger airbag	1.58
Audible and visual signals	1.61
Driving position	1.62
instrument panel:	1.66
trip computer	1.84
vehicle settings customisation menu	1.92
Steering wheel.	1.95
Power-assisted steering	1.96
Clock and outdoor temperature	1.97
Rear view mirrors	1.99
Headlight beam adjustment.	1.101
Exterior lighting and signals.	1.102
Washers, wipers	1.108
Fuel tank (filling with fuel)	1.116
Reagent tank	1.119

KEY, RADIO FREQUENCY REMOTE CONTROL: general information (1/2)

40681



- 1 Locks all the opening elements.
- 2 Unlocks all the opening elements.
- 3 Ignition and front door key.
- 5 Locking/unlocking the boot only.

Remote control with switchblade key:

- 4 Locking/unlocking using the switchblade key. To release the insert from its housing, press button 4, it comes out automatically. Press button 4 and guide the insert back into its housing.

Advice

Avoid leaving the remote control in hot, cold or humid areas.

The key must not be used for any function other than those described in the handbook (removing the cap from a bottle, etc.).



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

KEY, RADIO FREQUENCY REMOTE CONTROL: general information (2/2)

Radio frequency remote control operating range

This varies according to the surroundings: take care not to lock or unlock the doors by inadvertently pressing the buttons on the remote control.

Note: if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the remote control) may affect the operation of the remote control.

Replacement and additional keys or remote controls.

You must only contact an approved dealer:

- If you need to replace a key it will be necessary to take the vehicle and all of its keys to an approved Dealer in order to initialise the system.
- Depending on the vehicle, you have the option of using up to four remote controls.

Remote control unit failure

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. These batteries have a service life of approximately two years.

How to change the battery ➡ 5.34.

RADIO FREQUENCY REMOTE CONTROL UNIT: use

The remote control **A** can be used to lock or unlock the doors and boot.

It is powered by a battery which can be replaced. ➔ 5.34.

Locking the doors

Press locking button **1**.

The side indicator lights and hazard warning lights flash **twice** to indicate that the doors have been **locked**.

Pressing the **1** button twice locks the vehicle and enables the closure of the front, rear windows and sunroof (depending on the vehicle).

Note: if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

Depending on the vehicle, the door mirrors fold in/out automatically when the vehicle is locked/unlocked
➔ 1.99.



Locking/unlocking only the boot

Press the button **3** to lock/unlock the boot only.

Unlocking the doors

Pressing button **2** unlocks the doors and tailgate.

Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.

Note: with the ignition on and the engine running ➔ 2.3, buttons on the remote control are not activated.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

RADIO FREQUENCY REMOTE CONTROL UNIT: deadlocking

40681



If the vehicle is equipped with a deadlocking function, this allows you to lock the opening elements and to prevent the doors from being unlocked using the interior handles (for example, by breaking the window and then trying to open the door from the inside).

To do this, press button **1** twice in quick succession.

Locking is confirmed by **two slow flashes** followed by **three quick flashes** of the hazard warning lights and side repeaters.


Depending on the vehicle, the door mirrors fold in automatically when the vehicle is locked ➡ 1.99.



Never use deadlocking if someone is still inside the vehicle.

CARD: general information (1/3)

39100



- 1 Unlocking the doors and tailgate.
- 2 Locking all doors and tailgate.
- 3 Locking/unlocking the boot only.
- 4 Switching on the lighting remotely.

The card is used for:

- locking/unlocking the doors and tailgate (doors, tailgate) and the fuel filler flap (see the following pages);
- switching on the vehicle lighting remotely (refer to the following pages);
- automatic remote closing of the electric windows ➔ 3.28 and, depending on the vehicle, the sunroof ➔ 3.30;
- starting the engine ➔ 2.5.

Battery life

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. Its service life is approximately two years: it should be replaced when the message “Keycard Battery Low” appears on the instrument panel ➔ 5.32.

Card operating range

This varies according to the surroundings. It is important to make sure when handling the card that you do not lock or unlock the doors by inadvertently pressing the buttons.

Note: if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the card) may disrupt its operation.

When the battery is flat, you can still lock/unlock and start your vehicle.
➔ 1.14 ➔ 2.5.

CARD: general information (2/3)

39100



Distance lighting function

Pressing button **4** switches on the dipped beam headlights and the exterior lighting for approximately 20 seconds. This can be used, for example, to identify the vehicle from a distance when parked in a car park.

Pressing and holding the **4** button for approximately two seconds activates the exterior lighting and a sound is emitted.

Note: Pressing button **4** again switches off the lighting.

Advice

Avoid leaving the card in hot, cold or humid areas.

Do not keep the card in a place where it could be bent or damaged accidentally, such as in a back pocket of a garment.

Replacement: need for an additional card

If you lose your card or require another, you can obtain one from an authorised dealer.

If a card is replaced, it will be necessary to take the vehicle **and all its cards** to an approved Dealer to initialise the system.

You may use up to four cards per vehicle.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

CARD: general information (3/3)

40303




Fitting a hand strap 7

Slide the rear casing **5** downwards while pressing on zone **A**.

Never insert screwdriver-type tools into the **6** opening.

57037



Insert the hand strap into the **8** component and pass the end of the strap through the buckle.

Position the strap at the **6** opening and close the cartridge.

Note: check that the diameter of the **7** strap cord fits the **6** opening.

“HANDS-FREE” CARD: use (1/4)



There are three ways to unlock/lock the vehicle:

- “hands-free”, when approaching and moving away from the vehicle;
- “hands-free”, using the **2** button on the **1** handle of one of the front doors;
- using the card in remote control mode.

Do not store the card anywhere it may come into contact with other electronic equipment (computer, phone etc.) as this could hinder its operation.

Deactivating/activating the “hands-free” mode

Depending on the vehicle, you can deactivate/activate:

- unlocking when approaching and locking when moving away from the vehicle;
- locking and unlocking by pressing on the buttons on the door handle.

You can also disable/activate the sound signal that is emitted upon locking when moving away from the vehicle ➔ 1.92.



Never leave your vehicle with the card inside.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

“HANDS-FREE” CARD: use (2/4)



48126

Hands-free unlocking, when approaching the vehicle;

With the card in access zone **3**, the vehicle will unlock. Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.

Depending on the vehicle, the door mirrors fold in/out automatically when the vehicle is locked/unlocked
➡ 1.99.



48042


Hands-free locking when moving away from the vehicle

With the card on you, doors and luggage compartment door closed, move away from the vehicle: it will lock automatically once you have left the access zone **3**.

Note: the distance at which the vehicle locks depends on the surroundings.

To indicate that the vehicle has been locked, the hazard warning lights **flash twice** and then **light up** for approximately four seconds, and a beep sounds in confirmation.

39100



If the card has been within the detection area **3** for approximately 15 minutes, remote locking is disabled. To lock the vehicle, press the **2** button on the **1** handle or the **5** button on the card.

The vehicle cannot be remotely locked if the card is within the area **4**.

“HANDS-FREE” CARD: use (3/4)



“Hands-free” unlocking/locking using button 2

With the card in zone **3** and the vehicle locked, press the button **2** on the handle **1** of one of the two front doors: the vehicle unlocks. Press the button **2** also unlocks all the doors and the tail-gate.

Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.

Pressing the **2** button again locks the vehicle.

To indicate that the vehicle has been locked, the hazard warning lights **flash twice** and then **light up** for approximately four seconds.

Special features of the unlocking system

Under certain circumstances, approach unlocking is deactivated:

- after eight days of no use of the vehicle;
- if the card remains close to the **3** area of the vehicle during approximately five minutes after the vehicle has been locked;
- after several passes in the vicinity of the **3** area of the vehicle and without the door being unlocked.

Press button **2** (front door or boot handle) or use the remote control card (refer to the following pages) to unlock the vehicle and reactivate the mode.




Special features relating to hands-free locking

After locking in “hands-free” mode, you have to wait approximately three seconds to be able to unlock the vehicle again. During these three seconds, the door handles can be tried to make sure that the vehicle is locked properly.

Note: if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

“HANDS-FREE” CARD: use (4/4)

39100



Using the card as a remote control

Unlocking with the card

Press button **7**.

Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.

The card buttons are deactivated when the engine is running.

Locking using the card

With the doors and boot closed, press button **5**: the vehicle locks.

To indicate that the vehicle has been locked, the hazard warning lights **flash twice** and then **light up** for approximately four seconds.

Pressing the **5** button twice locks the vehicle and enables the closure of the front, rear windows and sunroof (depending on the vehicle).

Note:

- the maximum distance at which the vehicle locks depends on the surroundings;
- if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.



48042

If, **while the engine is running**, a door is opened and closed, and the card is no longer in the zone **4**, the message “Keycard Not Detected” indicates that the card is not inside the vehicle. This will, for example, prevent you from driving away after dropping off a passenger who has kept the card on them.


The warning disappears when the card is detected again.

Locking/unlocking only the boot

Press the button **6** to lock/unlock the boot only.

CARD: deadlocking

39100



If the vehicle is equipped with a deadlocking function, this allows you to lock the opening elements and to prevent the doors from being unlocked using the interior handles (for example, by breaking the window and then trying to open the door from the inside).



Never use deadlocking if someone is still inside the vehicle.

To activate deadlocking

Press button **2** twice in quick succession.

Locking is confirmed by **two slow flashes** and **three quick flashes** of the hazard warning lights and side indicator lights.

Depending on the vehicle, the door mirrors fold in automatically when the vehicle is locked ➔ 1.99.

To deactivate deadlocking

Press the **1** button.

The hazard warning lights **flash once** to indicate that the doors have been unlocked.

LOCKING, UNLOCKING THE DOORS (1/3)

If the remote control or, depending on the vehicle, the card does not work

In some cases, the radio frequency remote control or the card may not work:

- card or radio frequency remote control battery worn or run flat, vehicle battery flat etc;
- use of appliances operating on the same frequency as the card (mobile phone, etc.);
- vehicle located in a high electromagnetic radiation zone.

It is then possible:

- depending on the vehicle, use the radio frequency remote control or the emergency key integrated in the card to unlock the front left-hand door;
- to lock each of the doors manually;
- to use the interior door locking/unlocking control (refer to the following pages).

40303



The card's built-in key

The integrated **2** key is used to lock or unlock the front left-hand door if the card does not work.


Access with key 2

Slide the rear casing **1** downwards while pressing on zone **A**.

39102




LOCKING, UNLOCKING THE DOORS (2/3)



Using the key integrated in the card

- Insert the tip of the key **2** into the notch **3** at the bottom of the cover **B** on the front left-hand door;
- Move it upwards to remove the cover **B**;
- Insert the key **2** into the lock and lock or unlock the front left-hand door.

Once you are inside the vehicle, put the key back in its casing in the card.



Vehicles with key/remote control

Using the key

Insert the key **5** into the lock **4** and lock or unlock the front left-hand door.




Locking the doors manually

Turn screw **6** with the door open (using the end of the key) and close the door.

This means that the doors are then locked from the outside.

The doors may then only be opened from the inside or by using the key in the front left-hand door.

LOCKING, UNLOCKING THE DOORS (3/3)



Interior locking/unlocking door control

Switch **7** controls the doors, the boot and the fuel filler flap simultaneously.

If a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

If transporting an object with the tailgate open, you can still lock the doors: **with the engine stopped**, press and hold switch **7** for more than five seconds to lock the other doors.

Locking the opening elements without the card or the key

For example, in the event of a discharged battery or the card or key temporarily not working etc.

With the engine switched off and a door or tailgate open, press and hold switch **7** for more than five seconds.

When the door is closed, all the doors and the tailgate will be locked.

Unlocking the vehicle from the outside is only possible with the card in the vehicle access zone or by using the key.

Door and tailgate status indicator

When the ignition is on, the indicator light integrated in switch **7** informs you of the status of the doors and tailgate:

- indicator light on, the doors and tailgate are locked;
- indicator light off, the doors and tailgate are unlocked.

When you lock the doors from the outside, the indicator light remains lit for a moment, and then goes out.



Never leave your vehicle with the key or card inside.



Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

OPENING AND CLOSING THE DOORS (1/2)




Opening the doors from the outside

With the doors unlocked or, depending on the vehicle, the card on you, hold the handle **1** and pull it towards you.



As a safety precaution, the doors should only be opened or closed when the vehicle is stationary.



Opening from the inside

Pull on the handle **2**.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

OPENING AND CLOSING THE DOORS (2/2)



Door/tailgate open buzzer

At a standstill, warning light **3** lights up on the instrument panel alongside warning light **4**, indicating the opening element(s) (door, boot) open or incorrectly closed.

Once the vehicle reaches a speed of approximately 12 mph (20 km/h), a warning light indicates if the door(s) or luggage compartment are open or not properly closed, along with the message "WARNING: Boot Open" or "WARNING: Door Open" and a beep will sound for around 40 seconds or until the door/luggage compartment is closed.

Lights-on reminder buzzer

A warning beep sounds when the driver's door is opened to warn you that the lights are still on.




Child safety

Move lever **5** and check from the inside that the doors are securely locked, to prevent the rear doors being opened from the inside.



As a safety precaution, the doors should only be opened or closed when the vehicle is stationary.

AUTOMATIC LOCKING WHEN DRIVING



Operating principle

After the vehicle is started, the system automatically locks the doors when you are driving at approximately 6 mph (10 km/h) and over.

The door can be unlocked:

- by pressing central door unlocking switch **2**.
- at a standstill, by opening a front door from inside the vehicle.

Note: if a door is opened or closed, it will automatically lock again when the vehicle reaches a speed of 6 mph (10 km/h).

Activating/deactivating the function

To switch it on: with the vehicle at a standstill and the engine running, press switch **2** until a beep sounds.

To deactivate: with the vehicle at a standstill and the engine running, press switch **2** until two beeps sound.

You can also activate/deactivate the function from the multimedia screen menu **1** ➔ 1.92.

Operating faults


If you experience an operating fault (no automatic locking, the indicator light incorporated in switch **2** does not light up when trying to lock the doors and boot, etc.), make sure that locking has not been deactivated by mistake and check that the doors and boot are properly closed. If they are correctly locked and the fault is still present, contact an authorised dealer.



Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

FRONT HEADRESTS



To raise the headrest

Pull the headrest upwards to the desired height. Check that the bonnet is correctly locked.

To lower the headrest

Press button **2** and guide the headrest down to the desired height. Check that the bonnet is correctly locked.

To adjust the angle of the headrest


If your vehicle is thus equipped, move the **A** section towards or away from you to the required position

To remove the headrest

Raise the headrest to its highest position (tilt the seatback backwards if necessary). Press button **2** and lift the headrest to release it.


To refit the headrest

Check that the headrest rods are clean **1**. The rod with a notch should be inserted into the slot **3** fitted with a locking button **2**. Insert the headrest rods into the holes (tilt the seatback backwards if necessary). Press the **2** button and push in the headrest as far as it will go, then adjust it to the desired height. Check that each rod **1** on the seatback is securely locked.



The headrest is an important safety component: ensure that it is in place and in the correct position. The distance between your head and the headrest and the distance between the head and section **A** should be as small as possible.

FRONT SEATS WITH MANUAL CONTROL (1/3)




Settings

To move the seat forwards or back

Lift handle **1** to release. Release the handle at the desired position and make sure that it is locked.

To raise or lower the seat base

Move lever **2** as many times as necessary upwards or downwards.



To tilt the seatback

Lift handle **3** and tilt the seatback to the desired position. Release the handle at the desired position and make sure that it is locked.


To adjust the seat's lumbar position

Depending on the vehicle:

- move the switch **4** forwards, backwards, up or down;

or

- lower the handle **5** to increase the support and lift it to decrease it.



For safety reasons, carry out any adjustments while the vehicle is stationary.

We would advise you not to recline the seatbacks too far to ensure that the effectiveness of the seat belts is not reduced.

Nothing should be placed on the floor (area in front of driver) as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.

FRONT SEATS WITH MANUAL CONTROL (2/3)




Table function

Depending on the vehicle, the passenger seatback may be folded down onto the seat base to create a table.

- Lower the headrest;
- move the seat back;
- lift the lever **3** and tilt the seatback forwards as far as possible;
- pull the handle **6** and fully lower the seatback.



For your safety, attach any transported objects when the seat is in the table position.

When using the passenger seat in table position, you must not use the two rear seats immediately behind it.



After making adjustments, make sure that the seatbacks are correctly locked in place.



When the front seatback is in the table position, you must deactivate the front passenger airbag ➔ 1.58.


Risk of serious injury caused by items resting on the seatback table which may be dislodged when the airbag is deployed.

The label (on the dashboard) and the markings (on the windscreen) remind you of these instructions.



For safety reasons, carry out any adjustments when the vehicle is not being driven.


FRONT SEATS WITH MANUAL CONTROL (3/3)



Repositioning the seat

Make sure that nothing prevents the seat from moving.

- Pull the handle **6** and raise the seat-back, ensuring that it locks firmly in place.
- Reposition the seat base.




Heated seats

With the ignition on:

- pressing the switch **7** on the required seat for the first time activates the heating system at maximum power. Both integrated switch warning lights come on;
- a second press decreases the heating to minimum power. One integrated warning light comes on;
- pressing for the third time turns the heating off.

DRIVER'S SEAT WITH ELECTRIC CONTROLS (1/2)




On vehicles that are equipped, the switch **1** can be used to access the “Seats” menu on the multimedia screen (see following pages).

Adjusting the seatback

To tilt the seatback, move the top of switch **2** forwards or backwards.

Adjusting the lumbar support on the driver's seat

Move the switch **3** forwards, backwards, up or down.



Adjusting the seat position

To move the seat forwards or back

Move switch **4** forwards or backwards.

To raise or lower the seat base


Move the back of switch **4** up or down.

To tilt the seat base

(depending on the vehicle)

Move the front of switch **4** upwards or downwards.

DRIVER'S SEAT WITH ELECTRIC CONTROLS (2/2)



Heated seats

With the ignition on:

- Pressing the switch **5** on the required seat for the first time activates the heating system on high. Both switch indicator lights are illuminated;
- pressing the switch for the second time changes the heating to low. Only one indicator light is illuminated;
- pressing for the third time turns the heating off.




For safety reasons, carry out any adjustments when the vehicle is not being driven.

We would advise you not to recline the seatbacks too far to ensure that the effectiveness of the seat belts is not reduced.

No object should be placed on the floor (in front of the driver). such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.

FRONT SEATS: Functions (1/3)



A number of seat functions are available from the multifunction screen, depending on the vehicle.

On equipped vehicles, the switch **1** provides direct access to the “Seats” menu on the multimedia screen.

Refer to the multimedia instructions for more information.



Message

You can activate the driver's seat massage function.

Refer to the multimedia instructions for information on accessing the settings.


Browse the “Driver” menu to:

- select the message type (Tonic, Relaxing or Lumbar);
- adjust the intensity (+ or -);
- adjust the speed (+ or -);
- reset the settings selected on the dropdown menu **2**;
- activate/deactivate the message seat (ON or OFF).

Note: the mode selected in the MULTI-SENSE menu may affect the configuration of the massage ➔ 3.2.

FRONT SEATS: Functions (2/3)

47563



Settings

Refer to the multimedia instructions for information on accessing the settings.

You can activate or deactivate the following elements:

- easy driver access;
- visual feedback of current movement.

Easy driver access

Press ON or OFF to activate or deactivate this function.

When this function is activated, the seat automatically moves back when the driver leaves the vehicle, and returns to its position when the start button is pressed.

FRONT SEATS: Functions (3/3)


Position

It is possible to store the driving position of the driver seat.

The driving position includes the settings for the seat base and seatback.

The driving position can be stored and recalled by pressing the buttons:

- hands-free card detected;
- when the driver's door is opened.




Storing your driving position

Adjust the driver's seat using switches **3**, **4** and **5** (refer to previous page).

Refer to the multimedia instructions for information on accessing the stored driving position.

The position of the driver is then stored.



Recalling the driving position

Refer to the multimedia instructions for information on recalling the driving position.

Note: recall of the stored driving position is interrupted if one of the seat adjustment buttons is pressed during recall.

When driving, it is not possible to recall a driving position.



For safety reasons, carry out any adjustments when the vehicle is stationary.

SEAT BELTS (1/5)

Always wear your seat belt when travelling in your vehicle. You must also comply with the legislation of the particular country you are in.

Make sure that the rear bench seat is locked in position correctly so that the rear seat belts will operate correctly. ➔ 3.44.



Incorrectly adjusted or twisted seat belts may cause injuries in the event of an accident.

Use one seat belt per person, whether child or adult.

Even pregnant women should wear a seat belt. In this case, ensure that the lap belt is not exerting too much pressure on the abdomen, but do not allow any slack.

Before starting, first adjust your driving position, then ask all occupants to adjust their seat belts to ensure optimum protection.

Adjusting your driving position

- **Sit well back in your seat** (having removed your coat or jacket etc.). This is essential to ensure your back is positioned correctly;
- **adjust the distance between the seat and the pedals.** Your seat should be as far back as possible while still allowing you to fully depress the pedals. The seatback should be adjusted so that your arms are slightly bent when you hold the steering wheel;
- **adjust the position of your headrest.** For maximum safety, your head must be as close as possible to the headrest;
- **adjust the height of the seat.** This adjustment allows you to select the seat position which offers you the best possible view;
- **adjust the position of the steering wheel.**



Adjusting the seat belts

Sit with your back firmly against the seatback.

Shoulder strap **1** should be as close as possible to the base of the neck but not on it.

Lap belt **2** should be worn flat over the thighs and against the pelvis.

The belt should be worn so that it is as close as possible to your body, i.e.: avoid wearing heavy clothing or keeping bulky objects under the belts, etc.

SEAT BELTS (2/5)



Locking

Unwind the belt **slowly and smoothly** and ensure that buckle **3** locks into catch **5** (check that it is locked by pulling on buckle **3**).

If the belt jams, allow it to return slightly before attempting to unwind it again. If your seat belt is completely jammed, pull slowly, but firmly, so that just over 3 cm unwinds. Allow it to return slightly before attempting to unwind it again. If there is still a problem, contact an approved dealer.



Driver's seat belt reminder and, depending on the vehicle, front passenger seat belt reminder

This appears on the central display when the ignition is switched on and if the driver's or front passenger's seat belt (as long as the passenger seat is occupied) is not fastened. Depending on the vehicle, if the seat is occupied and one of these seat belts is not fastened or becomes unfastened while the vehicle is moving at a speed over approximately 12 mph (20 km/h), the




warning light flashes and a beep sounds for approximately 120 seconds.

Note: an object placed on the passenger seat base may activate the warning light in some cases.

Unlocking

Press button **4** and the seat belt will be rewound by the inertia reel. Guide the belt.

SEAT BELTS (3/5)



Rear seat belt reminder (depending on vehicle)

The **6** graphic is displayed on the instrument panel when the ignition is switched on. This informs the driver of the fastening status of each of the rear seat belts every time:

- the ignition is switched on;
- opening a door;
- fastening or unfastening of a rear seat belt.

Understanding the graphic **6**:

- indicator green: seatbelt fastened;
- indicator red: seatbelt unfastened.

When the vehicle speed is below approximately 12 mph (20 km/h), the graphic **6** appears during approximately 60 seconds every time one of the rear seat belts is fastened or unfastened.


If one of the rear seat belts is unfastened during the journey, the



warning light flashes on the central display and a beep sounds for around 30 seconds when the vehicle speed reaches or exceeds 12 mph (20 km/h). In addition, the graphic **6** is displayed for at least 60 seconds and the indicator for the seat concerned changes to a red symbol.


Always make sure that the rear passengers are properly fastened and that the number of fastened seat belts indicated corresponds to the number of rear seats occupied.

SEAT BELTS (4/5)




Adjusting the height of the front seat belts

Use button 7 to adjust the seat belt height so that the shoulder strap is worn as shown previously. Press the 7 control and raise or lower the seat belt. Make sure that the seat belt is locked in position correctly after you have adjusted it.



Rear seat belts 8

The belts are locked, unlocked and adjusted in the same way as the front belts.



Check that the rear seat belts are positioned and operating correctly each time the rear bench seat is moved.

SEAT BELTS (5/5)

The following information applies to the vehicle's front and rear seat belts.



- No modification may be made to the component parts of the originally fitted restraint system: seat belts, seats and their mountings. For special operations (e.g. fitting child seats), contact an authorised dealer.
- Do not use devices which allow any slack in the belts (e.g. clothes pegs, clips, etc.): a seat belt which is worn too loosely may cause injury in the event of an accident.
- Never wear the shoulder strap under your arm or behind your back.
- Never use the same belt for more than one person and never hold a baby or child on your lap with your seat belt around them.
- The belt should never be twisted.
- Following an accident, have the seat belts checked and replaced if necessary. Always replace your seat belts as soon as they show any signs of wear.
- When positioning the rear bench seat, make sure that the seat belts and buckles are correctly positioned so that they can be used properly.
- Make sure that the buckle is inserted into the appropriate catch.
- Ensure that no objects are placed in the area around the seat belt catch as they could prevent it from being properly secured.
- Make sure the seat belt catch is properly positioned (it should not be hidden away, crushed or flattened by people or objects).

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (1/6)


Depending on the vehicle, they are composed of:

- **seat belt inertia reel pretensioners;**
- **central seat belt pretensioners;**
- **chest-level load limiter;**
- **airbags driver and passenger front.**

These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.

Depending on the severity of the impact, the system can trigger:

- seat belt locking;
- the seat belt inertia reel pretensioner (which engages to correct seat belt slack);
- the lap belt pretensioners to hold the occupant in his seat;
- the front airbag.



Pretensioners

The pretensioners hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

In the event of a severe frontal impact and if the ignition is switched on, the system may engage the following depending on the force of the impact:

- the seat belt inertia reel pretensioner **1** which instantly retracts the seat belt;
- the lap seat belt inertia reel pretensioner **2** on the front seats.



– Have the entire restraint system checked following an accident.

– No operation whatsoever is permitted on any part of the system (pretensioners, airbags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.

– Only qualified personnel from our Network may work on the airbags; otherwise the system may trigger accidentally and cause injury.

– The electric trigger system may only be tested by a specially trained technician using special equipment.

– When the vehicle is scrapped, contact an approved dealer for disposal of the pretensioner and airbags gas generators.

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (2/6)

Load limiter

Above a certain severity of impact, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.


driver and passenger front Airbags

Fitted to the driver and passenger sides.

The presence of this equipment is indicated by the word "airbag" on the steering wheel, dashboard (in the area of the airbag **A**) and, depending on the vehicle, a label on the lower section of the windscreen.


Each airbag system consists of:

- an airbag and gas generator fitted on the steering wheel for the driver and in the dashboard for the passenger;
- an electronic unit for system monitoring which controls the gas generator electrical trigger system;
- remote sensors;
- a single warning light  on the instrument panel.



The airbag system uses pyrotechnic principles. This explains why, when the airbag inflates, it will generate heat, produce smoke (this does not mean that a fire is about to start) and make a banging noise. In a situation where an airbag is required, it will inflate immediately and this may cause some minor, superficial grazing to the skin or other problems.

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (3/6)



Operation

This system is only operational when the ignition is switched on.

In a severe frontal impact, the airbags inflate rapidly, cushioning the impact of the driver's head and chest against the steering wheel and of the front passenger against the dashboard. The airbags then deflate immediately so that the passengers are not in any way hindered from leaving the vehicle.

Operating faults



This warning light comes on when the engine is started and then goes out after approximately three seconds.


If it does not come on when the ignition is switched on or if it stays on, there is a fault in the system.

Contact your approved Dealer as soon as possible.

Your protection will be reduced until this fault is rectified.

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (4/6)


44446



The following cases trigger the pretensioners or airbags.


In a frontal impact against a rigid (non-deformable) surface at an impact speed equal to or greater than **16 mph (25 km/h)**.

44448



In a frontal impact with another vehicle of an equivalent or higher category, with an impact area equal to or greater than 40%, where the speed of both vehicles is equal to or greater than **25 mph (40 km/h)**.

44452



In a side impact with another vehicle of an equivalent or higher category, at an impact speed equal to or greater than **31 mph (50 km/h)**.

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (5/6)



44449




In the following examples, the pretensioners or the airbags could operate:

- impact under vehicle such as pavement;
- potholes;
- drop or hard landing;
- stones;
- ...




44450




In the following examples, there is a risk that pretensioners or airbags may not be triggered:

- rear impact, however severe;
- the vehicle overturning;
- ...



44451



- side impact to the front or rear of the vehicle;
- frontal impact, under the tail of a lorry;
- frontal impact against an obstacle with a sharp angle;
- ...

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (6/6)

All of the warnings below are given so that the airbag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when it inflates.



Warnings concerning the driver's airbag

- Do not modify the steering wheel or the steering wheel boss.
- Do not cover the steering wheel boss under any circumstances.
- Do not attach any objects (badge, logo, clock, telephone holder, etc.) to the steering wheel boss.
- The steering wheel must not be removed (except by qualified personnel from our Network).
- Do not sit too close to the steering wheel when driving: sit with your arms slightly bent (see “Adjusting your driving position” ➔ 1.29). This will allow sufficient space for the air bag to deploy correctly and to be fully effective.

Warnings concerning the passenger airbag

- Do not attach or glue any objects (badge, logo, clock, telephone holder, etc.) to the dashboard on or near the airbag.
- Do not place anything between the dashboard and the passenger (pet, umbrella, walking stick, parcels, etc.).
- The passenger must not put his or her feet on the dashboard or seat as there is a risk that serious injuries may be sustained. In general, parts of the body should be kept away from the dashboard (knees, hands, head, etc.)
- The devices in addition to the front passenger seat belt should be reactivated as soon as a child seat is removed, to ensure the protection of the passenger in the event of an impact.

A REAR-FACING CHILD SEAT MUST NOT BE FITTED TO THE FRONT PASSENGER SEAT UNLESS THE RESTRAINT SYSTEMS IN ADDITION TO THE FRONT PASSENGER SEATBELT ARE DEACTIVATED ➔ 1.58.

METHODS OF RESTRAINT IN ADDITION TO THE REAR SEAT BELTS

Force limiter

Above a certain severity of impact, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.



- Have the entire restraint system checked following an accident.
- No operation whatsoever is permitted on any part of the system (air bags, electronic control units, wiring) and the system components must not be reused on any other vehicle, even if identical.
- Only qualified personnel from our Network may work on the air bags; otherwise the system may trigger accidentally and cause injury.

SIDE PROTECTION DEVICES

Side air bags

These air bags are fitted to the front seats and are activated at the sides of the seats (door side) to protect the occupants in the event of a severe side impact.

Curtain air bags

These are airbags fitted along the sides of the vehicle in the ceiling which trigger along the front and rear door side windows to protect the passengers in case of a severe side impact.

Depending on the vehicle, a marking on the windscreen informs you of the presence of additional means of restraint (airbags, pretensioners, etc.) in the passenger compartment.



Warning concerning the side air bag

- **Fitting seat covers:** seats equipped with an air bag require covers specifically designed for your vehicle. Contact an approved Dealer to find out if these covers are available. The use of any covers other than those designed for your vehicle (including those designed for another vehicle) may affect the operation of the air bags and reduce your protection.
- Do not place any accessories, objects or even pets between the seatback, the door and the internal fittings. Do not cover the seatback with any items such as clothes or accessories. This may prevent the air bag from operating correctly or cause injury when the air bag is deployed.
- No work or modification whatsoever may be carried out on the seat or internal fittings, except by qualified personnel from an approved dealer.

ADDITIONAL METHODS OF RESTRAINT

All of the warnings below are given so that the air bag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when the air bag inflates.



The air bag is designed to complement the action of the seat belt. Both the air bags and seat belts are integral parts of the same protection system. It is therefore essential to wear seat belts at all times. If seat belts are not worn, the occupants are exposed to the risk of serious injury in the event of an accident. It may also increase the risk of minor superficial injuries occurring when the air bag is deployed, although such minor injuries are always possible with air bags.

If the vehicle should overturn or suffer a rear impact, however severe, the pretensioners and air bags are not always triggered. Shocks to the underbody of the vehicle, e.g. from pavements, potholes or stones, can all trigger these systems.

- No work or modification **whatsoever** may be carried out on any part of the air bag system (air bags, pretensioners, computer, wiring harness, etc.), except by qualified personnel from an approved dealer.
- To ensure that the system is in good working order and to avoid accidental triggering of the system which may cause injury, only qualified Network personnel may work on the air bag system.
- As a safety precaution, have the air bag system checked if your vehicle has been involved in an accident, or is stolen or broken into.
- When selling or lending the vehicle, inform the user of these points and hand over this driver's handbook with the vehicle.
- When scrapping your vehicle, contact your approved dealer for disposal of the gas generator(s).

CHILD SAFETY: General information (1/2)

Carrying children

Please ensure that you comply with the legislation of your country.

Children, and adults, must be correctly seated and strapped in for all journeys. The children being carried in your vehicle are your responsibility.

A child is not a miniature adult. Children are at risk of specific injuries as their muscles and bones have not yet finished growing. The seat belt alone would not provide suitable protection. Use an approved child seat and ensure you use it correctly.



To prevent the doors being opened, use the "Child lock" feature. ➔ 1.17.



A collision at 31 mph (50 km/h) is the same as falling a distance of 10 metres.

Transporting a child without a restraint is the equivalent of allowing him or her to play on a fourth-floor balcony without railings.

Never travel with a child held in your arms.

In the event of an accident, you will not be able to keep hold of the child, even if you yourself are wearing a seat belt.

If your vehicle has been involved in a road accident, replace the child seat and have the seat belts and ISOFIX anchorage points checked.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

CHILD SAFETY: General information (2/2)

Using a child seat

The level of protection offered by the child seat depends on its ability to restrain your child and on its installation. Incorrect installation compromises the protection it offers the child in the event of harsh braking or an impact.

Before purchasing a child seat, check that it complies with the regulations for the country you are in and that it can be fitted in your vehicle. Consult an approved dealer to find out which seats are recommended for your vehicle.

The regulations on transporting children are specific to each country. The use of a child seat during transport depends on the age and/or the size and/or weight of the child.

For children who do not need to be transported in a child seat, make sure that the seat belt is correctly adjusted and fastened.

In all cases, you must comply with the regulations of the particular country you are in.

Before fitting a child seat, read the manual and respect its instructions. If you experience any difficulties during installation, contact the manufacturer of the equipment. Keep the instructions with the seat.

Set a good example by always fastening your seat belt and teaching your child:

- to strap themselves in correctly;
- to always get in and out of the car at the kerb, away from busy traffic.

Do not use a second-hand child seat or one without an instruction manual.

Check that there are no objects in the vicinity of the child seat which could impede its operation.



Never leave a child unattended in the vehicle.

Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. Avoid wearing bulky clothing which could cause the belts to slacken.

Never let your child put their head or arms out of the window.

Check that the child is in the correct position for the entire journey, especially if asleep.

CHILD SAFETY: choosing a child seat



31235

Rear-facing child seats

A baby's head is, proportionally, heavier than that of an adult and its neck is very fragile. Transport the child in this position for as long as possible (until the age of 2 at the very least). It supports both the head and the neck.

Choose a bucket type seat for best side protection and change it as soon as the child's head is higher than the shell.



38824

Forward-facing child seats

Up to 18 kg or 4 years, the child may travel on a forward-facing seat.

Choose your seat according to the child's size: their head and abdomen are the areas which must be most protected. A forward-facing child seat which is firmly attached to the vehicle will reduce the risk of impact to the head. Ensure your child travels in a forward-facing seat with a harness for as long as their size permits.

Choose a bucket type seat for optimum side protection.



31234

Booster cushions

From 15 kg or 4 years, the child can travel using a booster seat, which will enable the seat belt to be adapted to suit his/her size and shape. The booster seat cushion must be fitted with guides to position the seat belt on the child's thighs rather than the stomach. It is recommended that you use a seat-back fitted with a belt strap guide which can be adjusted in terms of height to position the seat belt in the centre of the shoulder. It must never rest on the neck or on the arm.

Choose a bucket type seat for optimum side protection.

CHILD SAFETY: choosing a child seat mounting (1/4)

There are two ways of attaching child seats: via the seat belt or using the ISOFIX system.

Attachment via the seat belt

The seat belt must be adjusted to ensure that it is effective in the event of harsh braking or an impact.

Ensure that the strap paths indicated by the child seat manufacturer are respected.

Always check that the seat belt is correctly fastened by pulling it up, then pulling it out fully whilst pressing on the child seat.

Check that the seat is correctly held by moving it from side to side and back to front: the seat should remain firmly fixed.

Check that the child seat has not been installed at an angle and that it is not resting against a window.



Do not use the child seat if it may unfasten the seat belt restraining it: the base of the seat must not rest on the buckle and/or catch of the seat belt.



The seat belt must never be twisted or the tension relieved. Never pass the shoulder strap under the arm or behind the back. Check that the seat belt has not been damaged by sharp edges. If the seat belt does not operate normally, it will not protect the child. Consult an approved dealer. Do not use this seat until the seat belt has been repaired.

CHILD SAFETY: choosing a child seat mounting (2/4)

Attachment using the ISOFIX system

Approved child seats ISOFIX are standardised in accordance with current regulations if any of the four cases below applies:

- ISOFIX universal 3-point forward-facing seat;
- ISOFIX semi-universal 2-point seat;
- Specific;
- i-Size Which has:
 - either a belt which attaches to the third ring of the seat concerned;
 - or a strut that rests on the vehicle floor, compatible with the approved seat i-Size, the role of which is to prevent the child seat from moving in the event of a collision.

In the latter three cases check that your child seat can be installed by consulting the list of compatible vehicles.

Attach the child seat with the ISOFIX locks, if these are provided. The ISOFIX system allows quick, easy, safe fitting.

The ISOFIX system consists of 2 rings and, in some cases, a third ring.




No modifications may be made to the component parts of the restraint system (ISOFIX seat belts, seats and their mountings) originally fitted.




Before using an ISOFIX child seat that you purchased for another vehicle, check that its installation is authorised. Consult the list of vehicles which can be fitted with the seat from the equipment manufacturer.

CHILD SAFETY: choosing a child seat mounting (3/4)



Attachment using the ISOFIX system

The two rings **1** are located between the seatback and the seat base of the seat and are identified by a marking. To position and lock the child seat on the rings **1**, insert the child seat mountings in the access guides **2**.



The third ring **3** or **4** is used to attach the upper strap on some seats ISOFIX.



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX system. Never fit a different type of child seat, seat belt or other objects to these anchorage points. Check that nothing is obstructing the anchorage points.

If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.

The rings are located on the rear seat-backs and indicated by the symbol .

In all cases, attach the strap hook to the corresponding ring **3** or **4** and place the seat in the desired position.

Pull the belt so that the back of the child seat comes into contact with the back of the vehicle seat.




Check that the seatback of the forward-facing child seat is in contact with the seatback of the vehicle seat. In this case, the child seat may not always rest on the seat base of the vehicle seat.



The child seat strap **must** be attached to the corresponding ring.


Do not use any other mounting point.

CHILD SAFETY: choosing a child seat mounting (4/4)



Attachment using the ISOFIX system
(4-door version)

The two rings **1** are located between the seatback and the seat base of the seat and are identified by a marking. To position and lock the child seat on the rings **1**, insert the child seat mountings in the access guides **2**.



The third ring **3** is used to attach the upper strap on some seats ISOFIX.

The rings are located behind the rear seats and indicated by the symbol

Attach the strap hook to the corresponding ring **3** and place the vehicle seat in the desired position.

Pull the belt so that the back of the child seat comes into contact with the back of the vehicle seat.



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX system. Never fit a different type of child seat, seat belt or other objects to these anchorage points. Check that nothing is obstructing the anchorage points.

If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.



Check that the seatback of the forward-facing child seat is in contact with the seatback of the vehicle seat. In this case, the child seat may not always rest on the seat base of the vehicle seat.



The child seat strap **must** be attached to the corresponding ring.

Do not use any other mounting point.

CHILD SAFETY: fitting a child seat, general information (1/2)

Some seats are not suitable for fitting child seats. The diagram on the following page shows you how to attach a child seat.



Fit the child seat in a rear seat wherever possible.

Make sure the child seat or the child's feet do not prevent the front seat from locking correctly. ➔ 1.21.

Check that when installing the child seat in the vehicle it is not at risk of coming loose from its base.

If you have to remove the headrest, check that it is correctly stored so that it does not come loose under harsh braking or impact.

Always attach the child seat to the vehicle even if it is not in use so that it does not come loose under harsh braking or impact.

The types of child seat indicated may not be available. Before using a different child seat, check with the manufacturer that it can be fitted.

In the front seat

The laws concerning children travelling in the front passenger seat differ in every country. Consult the legislation in force and follow the indications on the diagram on the following page.

Before fitting a child seat in this seat (if authorised):

- lower the seat belt as far as possible;
- move the seat as far back as possible;
- gently tilt the seatback away from vertical (approximately 25°);
- on equipped vehicles, raise the seat base as far as possible.

In all cases, when the vehicle is equipped with an adjustable headrest, fully raise the seat headrest so that it does not interfere with the child seat ➔ 1.20.

After installing the child seat, when this is possible, you can move the vehicle seat forward if necessary (so as to leave enough space in the rear seats for passengers or other child seats). For a rear-facing child seat, do not let it touch the dashboard or move it to the furthest forward position.

Do not change other settings after installing the child seat.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the airbag has been deactivated ➔ 1.58.

CHILD SAFETY: fitting a child seat, general information (2/2)

In the rear seat

A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.

For the safety of a child in the facing forwards, move the seat as far back as possible and move the seat in front of the child forward, remembering to move the seatback forwards to avoid contact between the seat and the child's legs.

Always remove the headrest from the rear seat on which the child seat is positioned. ➔ 3.42. If necessary, position the rear vehicle seat as far back as possible. This must be done before fitting the child seat.

Check that the child seat is resting against the back of the vehicle seat.



When fitting a child seat (Group 2 or 3 booster seat), check that the seat belts operate (wind) correctly:
➔ 1.29. If necessary, adjust the position of the vehicle seat.



Ensure that the child seat or the child's feet do not prevent the front seat from locking correctly. ➔ 1.21 or
➔ 3.44.



A child seat with floor supports must never be installed on the rear centre seat.

RISK OF DEATH OR SERIOUS INJURY.



Fit the child seat in a rear seat wherever possible.

To install an ISOFIX seat in this seat, detach the central seat belt by hand before engaging the bolts.

CHILD SEATS: attachment by seat belt (1/3)

The table below summarises the information already shown in the diagram on the following pages, to ensure the applicable regulations are respected.

Type of child seat	Weight of the child	Front passenger seat	Rear side seats	Rear centre seat
Carrycot fitted across the vehicle Group 0	< 10 kg	X	U (2)	X
Rear-facing shell seat Groups 0 or 0 +	< 10 kg and < 13 kg	U (1) (5)	U (3)	U (3)
Shell seat/rear-facing seat Groups 0+ and 1	< 13 kg and 9 to 18 kg	U (1) (5)	U (3)	U (3)
Forward-facing seat Group 1	9 to 18 kg	X	U (4)	U (4)
Booster seat Groups 2 and 3	15 to 25 kg and 22 to 36 kg	X	U (4)	X



(1) RISK OF DEATH OR SERIOUS INJURY: before fitting a child seat in the front passenger seat, make sure that the front passenger airbag has been deactivated. ➔ 1.58.

CHILD SEATS: attachment by seat belt (2/3)


X = Seat not suitable for fitting child seats of this type.

U = Seat which allows a child seat with “Universal” approval to be installed using a seat belt; check that it can be fitted.

- (2) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.
- (3) If necessary, position the vehicle seat as far back as possible. Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (4) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat. ➡ 3.42. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.
- (5) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

CHILD SEATS: attachment by seat belt (3/3)

Fitting diagram



48099



Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.



Seat not suitable for fitting child seats.

Child seat attached using the belt



Seat which allows a child seat with “Universal” approval to be attached by a seat belt.




RISK OF DEATH OR SERIOUS INJURY: before fitting a child seat in the front passenger seat, make sure that the front passenger airbag has been deactivated. ➔ 1.58.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

CHILD SEATS: attachment using the isofix system (1/3)

Fitting diagram



55184

Child seat fitted using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.



The rear seats are fitted with an anchorage point which allows a forward-facing ISOFIX child seat with universal approval to be attached. The anchorage points are located on the backs of the rear seats.



Seat which does not allow a child seat to be fitted.



RISK OF DEATH OR SERIOUS INJURY: before fitting a child seat in the front passenger seat, make sure that the front passenger airbag has been deactivated. ➔ 1.58.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

CHILD SEATS: attachment using the isofix system (2/3)

The table below summarises the information already shown on the diagram on the previous pages, to ensure the regulations in force are respected.

Type of child seat	Weight of the child	Seat size [Gabarit]	Front passenger seat	Rear side seats	Rear centre seat
Carrycot fitted across the vehicle Group 0	< 10 kg	F, G [L1, L2]	X	X	X
Rear-facing shell seat Groups 0 or 0 +	< 13 kg	E [R1]	X	IL (1)	X
Rear-facing seat Groups 0 + or 1	< 13 kg and 9 to 18 kg	C, D [R3, R2]	X	IL (1)	X
Forward-facing seat Group 1	9 to 18 kg	A, B, B1 [F3, F2, F2X]	X	IUF - IL (2)	X
Booster seat Groups 2 or 3	15 to 25 kg and 22 to 36 kg	[B2]	X	IUF - IL (2)	X

Seat i-Size			X	i-U	X
--------------------	--	--	---	-----	---



(1) RISK OF DEATH OR SERIOUS INJURY: before fitting a child seat in the front passenger seat, make sure that the front passenger airbag has been deactivated. ➡ 1.58.

CHILD SEATS: attachment using the isofix system (3/3)

X = Seat not suitable for fitting child seats ISOFIX.

IUF/IL = On equipped vehicles, seat which allows an approved “Universal/semi-universal” or “vehicle specific” child seat to be attached using the ISOFIX system; check that it can be fitted.


i-U = Suitable for the i-Size restraint devices in the “universal” forward-facing and backward-facing category.

- (1)** If necessary, position the vehicle seat as far back as possible. Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2)** In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat. ➡ 3.42. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

The size of the ISOFIX child seat is indicated by a letter:

- A, B and B1 [F3, F2, F2X]: for forward-facing seats in group 1 (9 to 18 kg);
- C and D [R3, R2]: shell seat or rear-facing seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- E [R1]: rear-facing shell seats in group 0 (less than 10 kg) or 0+ (less than 13 kg);
- F and G [L1, L2]: cots in group 0 (less than 10 kg);
- [B2]: boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

CHILD SAFETY: deactivating, activating AIRBAG front passenger (1/3)



Deactivating the front passenger airbag

Before installing a child seat on the front passenger seat:

- check that the child seat can be installed on this seat;
- You must **deactivate** the airbag in the case of a child seat that is facing backwards.



To deactivate the l'airbag: with the vehicle stationary and the ignition switched off, push and turn the lock 1 to the **OFF** position.

When the ignition is switched on, it is **essential** to check that the warning light  is illuminated on the display 2.

This light remains permanently lit to let you know that you can fit a child seat.



The passenger airbag may only be activated or deactivated when the **vehicle is stationary with the ignition off.**

If it is interfered with when the vehicle is being driven, indicator lights



and  will come on.


Switch the ignition off then on again to reset the air bag in accordance with the lock position.



DANGER

Since operation of the front passenger airbag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an **ACTIVATED** front **AIRBAG**. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.

CHILD SAFETY: deactivating, activating AIRBAG front passenger (2/3)



58034




The markings on the dashboard and labels **A** on each side of the passenger sun visor **3** (example: label shown above) remind you of these instructions.



DANGER

Since operation of the front passenger airbag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an **ACTIVATED front AIRBAG**. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.

CHILD SAFETY: deactivating, activating AIRBAG front passenger (3/3)



Activating the front passenger airbag

You should reactivate the airbag as soon as you remove the child seat from the front passenger seat to ensure the protection of the front passenger in the event of an impact.



To restart the airbag: vehicle stopped, ignition switched off, press and turn the lock to **1** position **ON**.

When the ignition is switched on, you **must** check that the  warning light is off and that the  warning light comes on the display **2** after each start-up for around 60 seconds.

The front passenger airbag is activated.

Operating faults

It is forbidden to fit a rear-facing child seat to the front passenger seat if the airbag activation/deactivation system is faulty.

Allowing any other passenger to sit in that seat is not recommended.

Contact your approved dealer as soon as possible.



The passenger airbag may only be activated or deactivated when the **vehicle is stationary with the ignition off**.


If it is interfered with when the vehicle is being driven, indicator lights



and  will come on.

Switch the ignition off then on again to reset the air bag in accordance with the lock position.

AUDIBLE AND VISUAL SIGNALS



Horn

Press the steering wheel boss **A** to activate the horn.

Headlight flasher


Pull stalk **1** towards you then release it to flash the headlights.

Direction indicators

Move the stalk **1** in the same direction as you want to move the steering wheel.

One-touch mode

Briefly shift the stalk **1** upwards or downwards, not exceeding the point of resistance, then release it: the stalk will return to its original position and the direction indicator light concerned will flash three times.




Hazard warning lights

Press switch **2**. This switch activates all four direction indicators and the side indicator lights simultaneously.

It must only be used in an emergency to warn drivers of other vehicles that you have had to stop in an area where stopping is prohibited or unexpected, or that you are obliged to drive under special conditions.

DRIVER'S POSITION, LEFT-HAND DRIVE (1/2)




48064

DRIVER'S POSITION, LEFT-HAND DRIVE (2/2)

The equipment fitted, described below, **DEPENDS ON THE VERSION AND COUNTRY.**

- | | | |
|--|--|---|
| <ul style="list-style-type: none">1 Air vents.2 Demister outlet.3 Stalk for:<ul style="list-style-type: none">– direction indicator lights;– exterior lights;– rear fog lights.4 Driver Airbag and horn location.5 Instrument panel.6 Head-up display.7 Controls for:<ul style="list-style-type: none">– on-board computer information read-out and vehicle settings customisation menu,– remote radio and navigation system.8 Steering column stalk for wind-screen and rear screen wash/wiper.9 Heating or air conditioning controls.10 Multimedia screen. | <ul style="list-style-type: none">11 Switches for:<ul style="list-style-type: none">– hazard warning lights;– electric door locking.12 Passenger Airbag location.13 Glove compartment14 Controls for:<ul style="list-style-type: none">– front seat heating;– ventilated front seats;– activation/deactivation, depending on the vehicle, of the ECO mode;– activation/deactivation of the parking distance control system;– activation/deactivation of the Stop and Start function;– lane departure warning.15 Accessories and multimedia sockets.16 Storage compartment/cup holder.17 Controls for:<ul style="list-style-type: none">– activating/deactivating the electronic parking brake;– activation/deactivation of the function AUTOHOLD.18 MULTI-SENSE or RS Drive control. | <ul style="list-style-type: none">19 Gearstick.20 Engine start/stop button (vehicles with card).21 Ignition switch (vehicles with key).22 Control for adjusting steering wheel height and reach.23 Main switch and controls for the Cruise control/speed limiter, adaptive cruise control and “Lane Centring” functions.24 Handbrake.25 Bonnet release control.26 Controls for:<ul style="list-style-type: none">– headlight beam height remote adjustment;– lighting rheostat for control instruments;– steering wheel heating;– luggage compartment lid release;– unlocking the fuel tank cover. |
|--|--|---|

DRIVING POSITION: RIGHT-HAND DRIVE (1/2)



48194

DRIVING POSITION: RIGHT-HAND DRIVE (2/2)

The equipment fitted, described below, **DEPENDS ON THE VERSION AND COUNTRY.**


- | | | |
|---|---|---|
| <ul style="list-style-type: none">1 Air vents.2 Demister outlet.3 Passenger Airbag location.4 Controls for:<ul style="list-style-type: none">– front seat heating;– ventilated front seats;– activation/deactivation, depending on the vehicle, of the ECO mode;– activation/deactivation of the parking distance control system;– activation/deactivation of the Stop and Start function;– lane departure warning.5 Heating or air conditioning controls.6 Multimedia screen.7 Stalk:<ul style="list-style-type: none">– direction indicator lights;– exterior lights;– rear fog lights. | <ul style="list-style-type: none">8 Main switch and controls for the Cruise control/speed limiter, adaptive cruise control and “Lane Centring” functions.9 Instrument panel.10 Driver Airbag and horn location.11 Controls for:<ul style="list-style-type: none">– on-board computer information read-out and vehicle settings customisation menu,– remote radio and navigation system.12 Steering column stalk for wind-screen and rear screen wash/wiper.13 Controls for:<ul style="list-style-type: none">– headlight beam height remote adjustment;– lighting rheostat for control instruments;– steering wheel heating;– luggage compartment lid release;– unlocking the fuel tank cover.14 Ignition switch (vehicles with key). | <ul style="list-style-type: none">15 Control for adjusting steering wheel height and reach.16 Engine start/stop button (vehicles with card).17 Switches for:<ul style="list-style-type: none">– hazard warning lights;– electric door locking.18 Gearstick.19 Storage compartment/cup holders.20 Controls for:<ul style="list-style-type: none">– activating/deactivating the electronic parking brake;– activation/deactivation of the function AUTOHOLD.21 MULTI-SENSE or RS Drive control.22 Accessories and multimedia sockets.23 Glove compartment24 Handbrake.25 Bonnet release control. |
|---|---|---|

WARNING LIGHTS (1/6)


The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**



Instrument panel A, B or C: this comes on when the driver's door is opened.



In some cases, the appearance of a warning light is accompanied by a message.



The **STOP** warning light requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Call an approved Dealer.



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.

Warning light  means you should drive **very carefully to an authorised dealer as soon as possible**. If you fail to follow this recommendation, you risk damaging your vehicle.

WARNING LIGHTS (2/6)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**



Side light warning light



Main beam headlight tell-tale



Dipped beam headlight tell-tale



Rear fog lights tell-tale



Automatic main beam headlight indicator light ➔ 1.102



Left-hand direction indicator tell-tale



Right-hand direction indicator tell-tale



Low fuel level warning light

It appears in yellow when the ignition or the engine is switched on then disappears after a few seconds or is displayed in white (depending on the vehicle). If it comes on orange while driving and is accompanied by a beep, fill up with fuel as soon as possible. There is only approximately 31 miles (50 km) worth of fuel left.



Warning light

If it appears in red during driving and is accompanied by the **STOP** indicator light, you must, for your safety, stop as soon as traffic conditions allow. Switch off the engine and do not restart it.

Call an approved Dealer.

If it appears in yellow during driving and is accompanied by the  warning light, visit an approved dealer as soon as possible. **Meanwhile, drive with care.** If you fail to follow this recommendation, you risk damaging your vehicle.



STOP light

This lights up when the ignition or engine is switched on and goes out as soon as the engine is running. It comes on with other warning lights and/or messages, and is accompanied by a beep.

It requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it.

Contact an approved Dealer.

WARNING LIGHTS (3/6)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**



Brake circuit fault warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

If it comes on during braking and is accompanied by the **STOP** warning light and a beep, it indicates that the fluid level in the circuit is low or that there is a braking system fault.

Stop as soon as traffic conditions allow and consult an approved dealer.



Battery charge warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

If it comes on on the road, accompanied by the **STOP** warning light and a beep, this indicates an overload or discharge in the electrical circuit.

Stop as soon as traffic conditions allow and contact an approved Dealer.



Oil pressure warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

If it comes on on the road, accompanied by the **STOP** warning light and a beep, stop immediately and cut the ignition.

Check the oil level. If the level is normal, the indicator light is being lit by something else.

Call an approved Dealer.



Variable power-assisted steering warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

If it comes on while driving, alongside the warning light **STOP**, this means there is a system fault.

Contact an authorised dealer.



Warning light

This lights up when the ignition or engine is switched on and goes out as soon as the engine is running. It can light up in conjunction with other warning lights and/or messages on the instrument panel.

It means you should **drive very carefully** to an approved Dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.



Anti-lock braking warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

If it lights up when you are driving, it indicates a fault in the anti-lock braking system.

Braking will then be as normal, without the ABS. Contact an approved Dealer as soon as possible.

WARNING LIGHTS (4/6)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**



Warning light for the electronic stability program (ESC) and traction control system

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

There are several reasons for the warning light to appear: ➔ 2.43.



Toxic Fume Filter System Warning Light

On vehicles that are equipped, this light comes on when the engine is started and, depending on the vehicle, when the ignition is switched off while the engine is in the standby phase ➔ 2.8 then it goes out.

- If it lights up continuously, consult your approved dealer as soon as possible;
- If it flashes, reduce the engine speed until the light stops flashing. Contact your approved Dealer as soon as possible ➔ 2.30.



Coolant temperature warning light

This lights up red when the ignition is switched on or the engine is started.

If it turns red, stop and let the engine idle for a minute or two.

The temperature should drop. Otherwise, stop the engine. Let the engine cool down before checking the coolant.

Contact an approved Dealer.



Indicator light/airbag

This warning light will be displayed on the instrument panel when the ignition is switched on or the engine is started, and will then go out after a few seconds.

If it does not come on when the ignition is switched on, or comes on when the engine is running, there is a fault in the system.

Contact your approved Dealer as soon as possible.



Preheating warning light (Diesel version)

This should come on when the ignition is switched on. It indicates that the heater plugs are in operation.

It goes out when preheating is complete. The engine can be started.



Gear change indicator

This lights up to advise you to change to a higher gear (arrow pointing upwards) or lower gear (arrow pointing downwards) ➔ 2.22.



“AUTOHOLD” system warning ➔ 2.21



Brake pedal warning light

This lights up when the brake pedal should be depressed ➔ 2.142.



Handbrake “on” or electronic parking brake warning ➔ 2.16 ➔ 2.17



Door status warning light

WARNING LIGHTS (5/6)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

	Engine standby warning light ➔ 2.8		Lane departure system warning light ➔ 2.49		Mode warning light ECO This comes on when ECO mode is activated ➔ 2.22.
	Unavailability of engine standby warning light ➔ 2.8		Lane Keeping Assist system warning light ➔ 2.54		Freewheel indicator light ➔ 2.22
	"Hands off steering wheel" detection warning light ➔ 2.54		(Depending on vehicle) Indicator of failure or unavailability of active emergency braking ➔ 2.71		Warning light for reagent level and faults in the exhaust gas reduction system. ➔ 1.119
	Tyre pressure monitoring system ➔ 2.32		Speed limiter warning lights ➔ 2.85		Particle filter system warning light ➔ 2.12 or ➔ 2.14
	Assisted parking brake fault light ➔ 2.137		Cruise control warning lights ➔ 2.89		
			Adaptive cruise control warning lights ➔ 2.94		

WARNING LIGHTS (6/6)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**



On display C



Passenger airbag ON

➔ 1.58




Passenger airbag OFF

➔ 1.58



Driver's seat belt reminder
and, depending on the vehicle,
front passenger seat belt reminder ➔ 1.29

DISPLAYS AND INDICATORS (1/9)



Engine oil level low warning

When the engine is started, the instrument panel display alerts you if the minimum oil level is reached. ➡ 4.4.

The first time the warning appears, it can be cleared by pressing **1** "OK".


Subsequent warnings will disappear automatically after around 30 seconds.

Instrument panel in miles

(option to switch to km/h)

Vehicles not fitted with a multimedia screen

- With the ignition off, press the **2** switch as many times as required to reach the vehicle tab **5**;
- press the **3** or **4** control repeatedly to access "Settings", then press **1** "OK";
- repeat the same operation to access "DASHBOARD", then "Units".



Vehicles fitted with a multimedia screen.

Please see the multimedia instructions for information on how to select the unit.

Note: in both cases, once the battery is switched off, the on-board computer automatically returns to the original unit of measurement.

To return to the previous mode, repeat the same operation.

Please refer to the multimedia instructions for more information.

DISPLAYS AND INDICATORS (2/9)



Instrument panel A

It lights up when the ignition is switched on. In some cases, the appearance of a warning light is accompanied by a message.

You can customise your instrument panel with the content and colours of your choice.

For vehicles fitted with a multimedia screen, refer to the equipment instructions.

For vehicles not fitted with a multimedia screen ➔ 1.92.



Speedometer 6

Depending on the style selected, the display varies.

Rev counter 7 (graduations x 1000)

This is displayed differently according to how the instrument panel is customised. Depending on the style selected, it may not be displayed.

Overspeed buzzer

Depending on the vehicle and country,

the  warning light is displayed and a beep sounds. This beep sounds as soon as the vehicle is travelling at over 75 mph (120 km/h). This warning light remains lit for as long as the vehicle is travelling at over 74 mph (120 km/h).

Total mileage recorder 8 ➔ 1.85

Trip computer 9 ➔ 1.81

Estimated mileage with remaining fuel 10

The value is displayed after driving 400 metres. ➔ 1.85.

DISPLAYS AND INDICATORS (3/9)



Multimedia information 11

Depending on the vehicle, you can display information from the multimedia screen (the compass, telephone, navigation etc.).

Please refer to the multimedia instructions for further information.

Driving style indicator 12 ➔ 2.22


Coolant temperature indicator 13

In normal use, indicator **13** should be before area **14**. Under "intensive" operating conditions, the needle may approach this zone. This is not serious unless the warning light **STOP** comes on accompanied by a message on the instrument panel and a beep.

Fuel gauge 15

If the level is at the minimum, the warning light  in the indicator appears in yellow, accompanied by a beep. Fill up as soon as possible.

DISPLAYS AND INDICATORS (4/9)




Instrument panel **B**

It lights up when the ignition is switched on. In some cases, the appearance of a warning light is accompanied by a message.

Depending on the vehicle, you can customise your instrument panel with the content and colours of your choice.

For vehicles fitted with a multimedia screen, refer to the equipment instructions.

For vehicles not fitted with a multimedia screen ➔ 1.92.




Coolant temperature indicator **16**

In normal use, indicator **16** should be before area **17**. Under "intensive" operating conditions, the needle may approach this zone. This is not serious unless the warning light **STOP** comes on accompanied by a message on the instrument panel and a beep.

Speedometer **18**

Depending on the style selected, the display varies.



Overspeed buzzer


Depending on the vehicle and country, the  warning light is displayed and a beep sounds. This sounds as soon as the vehicle exceeds 74 mph (120 km/h). The warning light remains on as long as the vehicle speed is over 74 mph (120 km/h).

Rev counter **19** (graduations x 1000)

This is displayed differently according to how the instrument panel is customised. Depending on the style selected, it may not be displayed.

Driving style indicator **20** ➔ 2.22.

DISPLAYS AND INDICATORS (5/9)



Multimedia information 21


Depending on the vehicle, you can display information from the multimedia screen (the compass, telephone, navigation, etc.). Please refer to the multimedia instructions for more information.

Estimated mileage with remaining fuel 22

The value is displayed after driving 400 metres. ➡ 1.85.

Total mileage recorder 23 ➡ 1.85


Trip computer 24 ➡ 1.81



Fuel gauge 25

If the level is at the minimum, the warning light  in the indicator appears in orange, accompanied by a beep. Fill up as soon as possible.

DISPLAYS AND INDICATORS (6/9)




Instrument panel C

It lights up when the ignition is switched on. In some cases, the appearance of a warning light is accompanied by a message.

Depending on the vehicle, you can customise your instrument panel with colours of your choice.

For vehicles fitted with a navigation system, refer to the handbook for the equipment.


For vehicle not fitted with a navigation system ➡ 1.92.



Rev counter 26 (graduations x 1000)

Coolant temperature indicator 28

In normal use, the indicator **28** should be before the red zone **27**. Under "intensive" operating conditions, the needle may approach this zone. This is not serious unless the warning light **STOP** comes on accompanied by a message on the instrument panel and a beep.



Trip computer 29

➡ 1.81

Estimated mileage with remaining fuel 30


The value is displayed after driving 400 metres.

➡ 1.85

Total mileage recorder 31

➡ 1.85

DISPLAYS AND INDICATORS (7/9)



Driving style indicator 32 ➔ 2.22



Speedometer 33


Overspeed buzzer

Depending on the vehicle and country, the  warning light is displayed and a beep sounds. This sounds as soon as the vehicle exceeds 74 mph (120 km/h). The warning light remains on as long as the vehicle speed is over 74 mph (120 km/h).

Fuel gauge 34

If the level is at the minimum, the warning light  in the indicator appears in orange, accompanied by a beep. Fill up as soon as possible.

DISPLAYS AND INDICATORS (8/9)



Head-up display 35

The display details driving and navigation information from the instrument panel and the multimedia screen.

If fitted to the vehicle, this comes on when the engine is started and is retracted when the engine is switched off.

Do not manually force the opening/closure of the head-up display.

You can adjust some settings from the multimedia screen.

Refer to the multimedia instructions.

Adjusting the display information height

Depending on your driving position, you can raise or lower the information on the display.

Adjusting the display brightness

You can adjust the brightness (day or night mode):

- **automatically:** the brightness will vary according to the exterior light level;
- **manually:** the brightness automatically switches with the activation/deactivation of the lights.

In both cases, the day mode varies based on the outdoor brightness.



For safety reasons, carry out any adjustments when the vehicle is stationary.

Good information visibility can be affected by:

- the seat position;
- the presence of an object placed on the opened display;
- the polarisation of some spectacle lenses;
- extreme weather conditions (rain, snow, very strong sunlight, etc.).



In the event of contradictory information between the table and head-up display/multimedia screen. Refer to the information displayed on the instrument panel.

DISPLAYS AND INDICATORS (9/9)

Operating faults

In the event of a malfunction (the display fails to open when the engine is started, or the display retracts, with the engine running, following an object impacting the display):

- stop and restart the engine;

or

- from the multimedia screen, change the display opening settings.


If there is still a problem, contact an authorised dealer.

With the display opened or closed, no object should be placed on it or in its housing.

Do not use solvents, detergents or an abrasive cloth to clean the display.

Only use a microfibre wipe.

TRIP COMPUTER: general information (1/4)





Trip computer **A**, **B** or **C**

Depending on the vehicle, this includes the following functions:

- distance travelled;
- journey settings;
- information messages;
- operating fault messages (connected to the  warning light);
- warning messages (connected to the  warning light);
- vehicle settings customisation menu
➔ 1.92.

All these functions are described on the following pages.



TRIP COMPUTER: general information (2/4)


A




Vehicle fitted with trip computer A

The functions are distributed in zones **5**, **6**, **7**, and **8**. The location of the zones differs depending on the style selected.

Press the **1** switch to browse between menus and select functions by repeatedly pressing the **2** or **3** switch, then if necessary use the **4** switch to confirm "OK".





TRIP COMPUTER: general information (3/4)



Vehicle fitted with trip computer **B**

The functions will be distributed in zones **5**, **6**, **7** and **8**.

Press the **1** switch to browse between menus and select functions by repeatedly pressing the **2** or **3** switch, then if necessary use the **4** switch to confirm "OK".



Vehicle fitted with trip computer **C**

Press the **1** switch as many times as required to reach the "Vehicle" tab.

Press repeatedly using the **2** or **3** control, then if necessary use the **4** switch to confirm "OK".

TRIP COMPUTER: general information (4/4)

Selections

(the display depends on the vehicle equipment and country)

- a) Trip log, operating faults and information message readout;
- b) current fuel consumption and average fuel consumption;
- c) trip mileage recorder and average speed;
- d) Reset the tyre pressure;
- e) set the time;
- f) distance before service;
 - Distance before service;
 - Mileage before oil change.
- g) Estimated range with remaining reagent.



Resetting the trip mileage recorder and journey parameters (reset button)

With one of the trip parameters selected as the display, press and hold the **4** switch "OK" until the display resets to zero.

Automatic resetting of the journey parameters

Resetting occurs automatically when the maximum value of any of the parameters is exceeded.

Interpreting some of the values displayed after resetting

The values showing average fuel consumption, range and average speed will become more stable and reliable the further you travel after pressing the reset button.

For the first few miles after pressing the reset key you will notice that the range increases as you travel. This range takes into account the average fuel consumption since the last time the reset button was pressed. However, average consumption can decrease when:

- the vehicle stops accelerating;
- the engine reaches its operating temperature (if the engine was cold when the reset key was pressed);
- when driving from an urban area onto the open road.

TRIP COMPUTER AND WARNING SYSTEM: journey parameters (1/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
	➡ a) Trip log. Successive display: – information messages (passenger airbag OFF etc.); – operating fault messages (Check injection etc.).
 7.4 L/100	➡ b) Current fuel consumption. This value is displayed after a speed of approximately 20 mph (30 km/h) is reached.
 5.8 L/100	➡ Average fuel consumption since the last reset. The value is displayed after having travelled at least 400 metres since the last reset.
 112,4 km	➡ c) Trip mileage recorder: distance travelled since the last reset.
 123.4 km/h	➡ Average speed since the last reset. The value is displayed after driving 400 metres.

TRIP COMPUTER AND WARNING SYSTEM: journey parameters (2/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
Tyre pressure init. long press	 d) Reset the tyre pressure. ↳ 2.32
16:30	 e) Setting the time. ↳ 1.97

TRIP COMPUTER AND WARNING SYSTEM: journey parameters (3/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
On-board computer with mileage-before-service message	
Service in 25 000 km/12 months Service due in 300 km / 24 days Service Required	f) Service distance. Mileage before service With the ignition on and engine not running, access the “Mileage before service” information. When the distance value approaches its limit, there are several possible scenarios: – If the range is less than 930 miles (1,500 km) or one month: the message “Service due” is displayed accompanied by the nearest term (distance or time); – range equal to 0 miles (0 km) or date of service reached: the message “Service Required” is displayed accompanied by the warning light . The vehicle requires a service as soon as possible.
Reset: to reset the distance before the next service, press and hold the OK button for approximately 10 seconds until the display shows the mileage before service permanently. Note: if a service is performed without changing the engine oil, only the mileage before the next service should be reset. In the event of an oil change, both the distance before the next service and the next oil change should be reset.	

TRIP COMPUTER AND WARNING SYSTEM: journey parameters (4/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
On-board computer with distance before next service message (cntd.)	
Oil change in 25 000 km/24 months Depending on the vehicle, the mileage before an oil change varies according to the driving style (frequent driving at low speed, door-to-door journeys, extensive use at idling speed, towing a trailer, etc.). The distance remaining until the next oil change can therefore decrease more quickly in some cases than the actual distance travelled. Reset: to reset the distance before the next service, press and hold the OK button for approximately 10 seconds until the display shows the mileage before oil change permanently. Note: if a service is performed without changing the engine oil, only the mileage before the next service should be reset. In the event of an oil change, both the distance before the next service and the next oil change should be reset.	f) Service distance. Mileage before service With the ignition on and the engine not running, access the mileage information to display the mileage before the next oil change.
Top Up AdBlue before 2400 km	 g) Estimated range with remaining reagent.

TRIP COMPUTER AND WARNING SYSTEM: information messages

These can help in the vehicle starting phase, or give information about a selection or a driving status. Examples of information messages are given in the following pages.

Examples of messages	Interpreting the display selected
“Parking Brake ON”	Indicates that the parking brake has been applied.
“Turn Steering Wheel + START”	Turn the steering wheel slightly whilst pressing the vehicle start button to unlock the steering column.
“Vehicle Checks in Progress”	Displayed with the ignition on when the vehicle is running self-diagnostics.

TRIP COMPUTER AND WARNING SYSTEM: operating fault messages

These appear with the  warning light and mean that you should drive very carefully to an authorised dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.

They disappear when the display selection key is pressed or after several seconds and are stored in the computer log. The  warning light stays on. Examples of operating fault messages are given in the following pages.

Examples of messages	Interpreting the display selected
“Clean Diesel Filter”	Indicates the presence of water in the diesel filter; contact an approved Dealer as soon as possible.
“Check vehicle”	Indicates a fault in one of the pedal sensors, battery management system or oil level sensor.
“WARNING: Check Airbag”	Indicates a fault in the restraint system in addition to the seat belts. In the event of an accident, it is possible that they may not be triggered.
“Check Anti- Pollution System”	– Indicates a fault in the vehicle’s particle filter system. – Indicates a fault in the emissions reduction system when it is accompanied by the  warning light. ➔ 1.119.


TRIP COMPUTER AND WARNING SYSTEM: warning message

These appear with the **STOP** warning light and require you to stop immediately, for your own safety, as soon as traffic conditions allow. Stop your engine and do not restart it. Contact an approved Dealer.

Examples of warning messages are given in the following pages. **Note:** the messages appear on the display either individually or alternately (when there are several messages to be displayed), and may be accompanied by a warning light and/or a beep.

Examples of messages	Interpreting the display selected
“WARNING: Engine Failure Risk”	Indicates an injection fault, the vehicle’s engine has overheated or there is a serious engine fault.
“WARNING: Braking System”	Indicates a fault in the braking system.
“WARNING: Electric System”	Indicates a fault in the vehicle battery charging circuit (alternator etc.).
“Puncture”	Indicates that at least one wheel is punctured or severely underinflated.

VEHICLE SETTINGS CUSTOMISATION MENU (1/3)



Depending on the vehicle equipment, this function allows you to activate/deactivate and adjust some of the vehicle's functions.

Vehicles fitted with a multimedia screen 1

Accessing the settings menu

Refer to the multimedia instructions for information on accessing the various settings.

Adjusting the settings

Select a menu then the function to be modified (the display depends on the vehicle equipment and country):

- a) "Driving":
 - Indicator volume.
- b) "Access":
 - Unlocking the driver's door;
 - Lock doors during driving;
 - Opening/closing in hands-free mode;
 - Remote locking/Approach unlocking;
 - Distance locking sound;
 - Silent mode;
 - Automatic locking.
- c) "Wiping and lighting":
 - Follow-me-home lighting;
 - Wiping in reverse;
 - Automatic front wiping;
 - Wipe after wash.

d) "Welcome":

- External welcome;
- Automatic fold-out of mirrors;
- Interior welcome;
- Courtesy light auto mode.

Depending on the function, select:

- "ON" or "OFF" to activate or deactivate,

or


- a duration to adjust the time the lights are switched on (e.g. for the "Follow-me-home lighting" function).

Please refer to the multimedia instructions for further information.



For safety reasons, carry out any adjustments when the vehicle is stationary.

VEHICLE SETTINGS CUSTOMISATION MENU (2/3)



Vehicles not fitted with a multimedia screen

Accessing the settings menu on display 2

With the vehicle stopped, press the **3** switch as many times as required to reach the "Vehicle" tab. Press repeatedly on the **4** or **5** switch to access the "Settings" menu, then confirm by pressing **6** "OK".

Adjusting the settings

Navigate using the **4** or **5** control to select the function to be modified and press **6** "OK" to confirm (display may vary according to vehicle equipment and country):

a) "DASHBOARD":

- Language;
- Unit;
- Style;
- Colour.

b) "VEHICLE":

- Rear windscreen wiping in reverse gear;
- Automatic windscreen wiping;
- Front/rear drip wiping function;
- External welcome;
- Free-wheel in ECO mode;
- Indicator volume.

c) "PARKING ASSIST":

- Beep sound volume;
- front obstacle detection;
- side obstacle detection;
- rear obstacle detection.

d) "DRIVING ASSIST":

- Lane departure warning sensitivity;
- Lane departure warning vibration;
- Lane keeping assist sensitivity;
- Blind spot warning;
- Fatigue warning;
- Active braking;
- Overspeed warning;
- Distance warning.

e) "LIGHTING":

- Courtesy light auto mode;
- Automatic follow-me-home lighting;
- Follow-me-home lighting: XX seconds.

f) "ACCESS":

- Lock doors during driving;
- Opening/closing in hands-free mode;
- Unlocking the driver's door only;
- Automatic re-locking;
- Silent locking;
- Automatic opening/closing;
- Automatic deployment of door mirrors.

g) "RESET".

VEHICLE SETTINGS CUSTOMISATION MENU (3/3)

☒ function activated


☐ function deactivated

Once a line has been selected, press **6** "OK" to adjust the function.

If you select either "PARKING ASSIST" then "VOLUME", or "DASHBOARD" then "LANGUAGE", you will have to make a further selection (sound volume of the parking distance control or instrument panel language). In this case, make your selection and confirm it by pressing **6** "OK", the selected value is


shown by a ☒ in front of the line.

To exit the menu, press the **4** or **5** switch to access "BACK" and confirm by pressing **6** "OK". It may be necessary to carry out this operation more than once.



The vehicle settings personalisation menu cannot be used when driving. At a speed exceeding 12 mph (20 km/h), the instrument panel display switches automatically back to trip computer and warning system mode.

STEERING WHEEL



Adjusting the steering wheel height and depth


Lower the lever **1** and position the steering wheel in the required position.

Then, raise the lever fully, beyond the point of resistance to lock the steering wheel.

Make sure that the steering wheel is correctly locked.



For safety reasons, only adjust the steering wheel when the vehicle is stationary.



Steering wheel heating (depending on the vehicle)

This function heats the steering wheel in areas **3** and **4**.

Operating principle

When the temperature is reached, the function regulates the temperature of the heated areas for approximately 30 minutes and then switches off automatically.

Activating the function

With the ignition on, press the switch **2**, the warning light integrated in the switch lights up.

Deactivating the function

- Automatic:

The function switches off automatically after the regulation phase of approximately 30 minutes. The switch **2** warning light stays on.

Note: If the function has switched off automatically, press the switch **2** twice to reactivate it.

If switch **2** is not pressed again, the function will be reactivated the next time the ignition is switched on.

- Manually:

To deactivate the function during the regulation phase, press the switch **2**. The indicator light in the switch **2** goes out.

POWER-ASSISTED STEERING

Never drive with an inadequately charged battery.

Variable power-assisted steering

The variable power assisted steering system is equipped with an electronic control system which alters the level of assistance to suit the vehicle speed.

Steering is made easier during parking manoeuvres (for added comfort) while the force needed to steer increases progressively as the speed rises (for enhanced safety at high speeds).

Special feature of Stop and Start

Depending on the vehicle, when the engine switches to standby, the steering assistance may no longer be operational. In this case it returns to its original state when the engine is restarted or when the speed moves above 0.62 mph (1 km/h) (hill, slope, etc.).

Note: the power-assisted steering depends on the driving mode selected in the “MULTI-SENSE” menu (➡ 3.2).


Never leave the steering wheel at full lock while stationary.

With the engine switched off, or if there is a system fault, it is still possible to turn the steering wheel. The force required will be greater.



Do not switch off the engine when driving downhill and, as a general rule, when driving (the power-assisted steering and brake cannot operate normally).


CLOCK AND EXTERIOR TEMPERATURE (1/2)



Vehicles fitted with a multimedia screen

The time and exterior temperature are displayed on the multimedia screen **1**.

Refer to the multimedia instructions.



Vehicles not fitted with a multimedia screen

Press the switch **2** as many times as required to reach the "Vehicle" tab.

Repeatedly press control **3** or **4** to set the **6** clock.

Press and hold switch **5** "OK" until the time display flashes.



Set the hour using control **3** or **4**, then press **5** "OK" to confirm.

Set the minutes using control **3** or **4**, then press **5** "OK" to confirm.

CLOCK AND EXTERIOR TEMPERATURE (2/2)

Depending on the vehicle, If the electrical supply is cut (battery disconnected, broken supply wire, etc.), the clock will automatically go back to the right time after a few minutes once the system is capable of receiving information GPS.

External temperature indicator

Special note:


When the external temperature is between -3°C and $+3^{\circ}\text{C}$, the $^{\circ}\text{C}$ figures flash (indicates risk of ice).



External temperature indicator

As ice formation is related to climatic exposure, local air humidity and temperature, the external temperature alone is not sufficient to detect ice.

REAR VIEW MIRRORS (1/2)



Exterior rear view mirrors

Adjustment

Select the rear view mirror using switch **2**, then use button **1** to adjust it to the desired position.

Heated door mirrors

Mirror de-icing is carried out at the same time as rear screen de-icing. ➔ 3.8.

Folding rear view mirrors

The door mirrors automatically fold in when the vehicle is locked (switch **3** in position **B**).

In any case, you can make the door mirrors fold in (switch **3** in position **C**) or fold out (switch **3** in position **A**).

Automatic mode is then deactivated. To reactivate it, set the switch **3** to position **B**.



Objects observed in the door mirror glass are actually closer than they appear. For your safety, take this into account in order to correctly assess the distance before any manoeuvre.

Welcome and goodbye function

Refer to the multimedia instructions to access the welcome and goodbye function.

Activate or deactivate the function by selecting (ON or OFF).


Depending on the selected choice, the door mirrors will fold out:

- when the ignition is next switched on (function deactivated);
- when the card is detected or the vehicle is unlocked (function activated).



For safety reasons, carry out any adjustments when the vehicle is not being driven.

REAR VIEW MIRRORS (2/2)



Interior rear view mirror

Rear view mirror with lever 4


When driving at night, to avoid being dazzled by the headlights of the vehicle behind, depress the little lever located behind rear view mirror 4.

Rear view mirror without lever 4

The rear-view mirror automatically darkens when you are being followed by a vehicle using main beam headlights or in very bright lighting.

The front passenger airbag activation/deactivation information is shown on the display 5 ➡ 1.58.

HEADLIGHT BEAM ADJUSTMENT



On vehicles fitted with this function, control **A** allows you to adjust the height of the beams according to the load.

Turn control **A** downwards to lower the headlights and upwards to raise them.


For vehicles not fitted with a control **A**, the headlight adjustment is automatic, depending on the vehicle load.

	Examples of positions for adjusting control A according to the load		
	5 doors	Estate	4 doors
Driver alone or with front passenger	0	0	0
All seats occupied	1	1	1
Driver with passengers and luggage (or load) reaching the maximum permissible all-up weight	3	3	3
Driver without passengers and luggage (or load) reaching the maximum permissible all-up weight	3 or 4*	4	4

* depending on the vehicle

The table below gives some examples. In all cases, adjust control **A** according to the vehicle load so that the road can be seen and other drivers are not dazzled.

EXTERIOR LIGHTING AND SIGNALS (1/6)




Side lights

Turn ring **2** until the symbol is opposite mark **3**.

This indicator light on the instrument panel comes on.

Daytime running lights function

The daytime running lights come on automatically with no action on stalk **1** when the engine is started, and they go off once the engine is switched off.



Dipped beam headlights

Manual operation

Turn ring **2** until the symbol is opposite mark **3**. This indicator light on the instrument panel comes on.


Automatic operation (depending on the vehicle)

Turn ring **2** until the **AUTO** symbol is opposite mark **3**: with the engine running, the dipped beam headlights switch on or off automatically depending on the brightness of the light outside, without any action on stalk **1**.

Depending on the vehicle, the dipped beam headlights will appear automatically after several sweeps of the wind-screen wiper blades.

EXTERIOR LIGHTING AND SIGNALS (2/6)

48038



Main beam headlights

With the engine running and the dipped beam headlights lit, push stalk **1**. This indicator light on the instrument panel comes on.

To return to the dipped headlight position, pull stalk **1** towards you again.

During deactivation of the main beam headlights, the dipped beam headlights return to their original position.



Automatic main beam headlights

Depending on the vehicle, this system switches the main beam headlights on and off automatically. It uses a camera located behind the interior rear-view mirror to detect vehicles that are being followed and those coming in the opposite direction.

The system may encounter difficulties under certain conditions, including:

- extreme weather conditions (rain, snow, fog, etc.);
- obstruction in front of the windscreen or camera;
- when a following or oncoming vehicle has weak or hidden lighting;
- incorrect settings for the front headlights;
- reflective systems;
- ...

The main beam headlights come on automatically if:


- exterior light is weak;
- no other vehicles or lighting are detected;
- the vehicle speed is above approximately 25 mph (40 km/h).

If any of the above conditions are not fulfilled, the system switches to dipped beam headlights.

Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).

EXTERIOR LIGHTING AND SIGNALS (3/6)

48038



Automatic main beam headlights (continued)

Activation/deactivation

To activate the automatic main beam headlights:

- turn the ring **2** until the **AUTO** symbol is opposite the mark **3**;
- push the stalk **1**.

Warning light  comes on the instrument panel.

To deactivate automatic main beam headlights:

- pull stalk **1**;
- or turn ring **2** to a position other than **AUTO**.

Warning light  goes out on the instrument panel.

Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation, etc.).

Operating faults

When the message “Check Automatic Lighting” appears on the instrument panel, the system is deactivated. Consult an approved dealer.



Using the portable navigation system at night in the windscreen area below the camera may disturb the operation of the “automatic main beam headlights” system (risk of reflection on the windscreen).



The “automatic main beam headlights” system should under no circumstances be used to replace driver attention and responsibility with regard to vehicle lighting and adapting to light, visibility and traffic conditions.

EXTERIOR LIGHTING AND SIGNALS (4/6)

48038



Switching off the lights

The lights will go out automatically when the engine is switched off, the driver's door is opened or the vehicle is locked. In this case, the next time the engine is started the lights will be switched back on according to the position of the ring 2.

Note: if the fog lights are lit, the lights are not switched off automatically.

Lights-on reminder buzzer

If the lights are on after the engine is switched off, a warning beep sounds when the driver's door is opened to warn you that the lights are still on.

Operating faults

When the message "WARNING: Check Lighting" with warning light 

is displayed and warning light  is displayed on the instrument panel, this indicates that there is a lighting fault.

Consult an authorised dealer.

Welcome and goodbye function

(depending on the vehicle)

Once the function is activated, the daytime running lights and the rear side lights will light up automatically upon detection of the card or when the vehicle is unlocked.

They switch off automatically:

- approximately one minute after lighting up;
 - when starting the engine based on the position of the lighting stalk;
- or
- upon locking the vehicle.


Activating/deactivating the function

For activation or deactivation of the external welcome, refer to the multimedia instructions.

Select "ON" or "OFF".

EXTERIOR LIGHTING AND SIGNALS (5/6)

48038



“See-me-home lighting” function

This function enables you to briefly switch on the side lights and dipped beam headlights (e.g. to provide light when opening a gate).


With the engine lights switched off, the 2 ring in **AUTO**, pull the lever 1 towards you: the side lights and dipped beam headlights will switch on for approximately 30 seconds along with the  and  warning lights on the instrument panel.

To increase this duration, you may pull the stalk up to four times (total time restricted to approximately two minutes). The message “Follow-me home for _ _” along with the time the lights will be on for is displayed on the instrument panel to confirm this action. You can then lock your vehicle.

To switch off the lights before they go out automatically, turn ring 2 to any position, then return it to position **AUTO**.

EXTERIOR LIGHTING AND SIGNALS (6/6)

48038



Front fog lights

Turn centre ring **4** on the stalk **1** until the symbol faces mark **3**, then release it.

Operation of the fog lights depends on the exterior lighting position selected, and an indicator light will light up on the instrument panel.



Rear fog lights

Turn centre ring **4** on the stalk until the symbol faces mark **3**, then release it.

Operation of the fog lights depends on the exterior lighting selected, and an indicator light will light up on the instrument panel.

Do not forget to switch off the fog lights when they are no longer needed, to avoid inconveniencing other road users.

Switching off the lights


Turn the centre ring **4** again until the **3** symbol is opposite the symbol for the fog lights. The corresponding indicator light on the instrument panel goes out.

The rear fog lights switch off when the exterior lights are switched off.

When driving in fog or snow, or when transporting objects which are higher than the roof, the headlights do not come on automatically.

Switching on the fog lights remains the responsibility of the driver: the indicator lights on the instrument panel inform you whether the fog lights are lit (indicator light on) or not (indicator light not on).

WINDSCREEN WASH, WIPE (1/6)



Vehicle fitted with intermittent windscreen wipers

A single sweep

A short push will trigger one sweep of the wipers.


B stop

C intermittent wiping

The wipers will pause for several seconds between sweeps. It is possible to change the time between sweeps by turning ring 2.

D slow continuous wiping

E fast continuous wiping



Special note

When driving the vehicle, the wiping speed slows down whenever the vehicle stops.

They will go from a fast continuous speed to a slow continuous speed. As soon as the vehicle moves, the wipers return to the speed that was initially selected.

If stalk 1 is operated, it overrides and cancels the automatic function.

Positions **A**, **C** and **D** are accessible with the ignition on. Position **E** is accessible only when the engine is running.

Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:


- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In all cases, replace it as soon as it begins to lose efficiency: approximately once a year. ➔ 5.37.

Precaution for using the wipers

- in freezing or snowy weather, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.

WINDSCREEN WASH, WIPE (2/6)



Vehicle fitted with front windscreen wiper rain sensor


The rain sensor is located on the windscreen, in front of the interior rear-view mirror.

A single sweep

A short push will trigger one sweep of the wipers.

B stop

48061



C automatic wiper function

When this position is selected, the system detects water on the windscreen and triggers the wipers at a suitable wiping speed. It is possible to change the triggering threshold and the time sweeps by turning ring 2:

- **F**: minimum sensitivity;
- **G**: maximum sensitivity.

The higher the sensitivity, the quicker the wipers will react and the faster the wipe.

When activating automatic wiping or when increasing sensitivity, one sweep of the blades is performed.

Note:

- the rain sensor is only intended as a driving aid. In the event of reduced visibility, the driver should manually activate the wipers. In foggy weather or during snowfalls, wiping is not automatically triggered and remains under the driver's control;
- in the event of temperatures below zero, automatic wiping is not activated when the vehicle is started. It is automatically activated as soon as the vehicle exceeds a certain speed (approximately 5 mph (8 km/h));
- do not activate automatic wiping in dry weather;
- fully de-ice the windscreen before activating automatic wiping;
- when washing the vehicle under a roller type car wash, return the ring **1** to the **B** position to deactivate automatic wiping.

WINDSCREEN WASH, WIPE (3/6)


Operating fault

In the event of a malfunction of the automatic wiping, the wiper is set to intermittent wiping.

Call an approved Dealer.

The operation of the rain sensor may be interrupted in the event of:

- damaged windscreen wipers; a film of water or traces left by a blade in the sensor's detection zone may increase the response time of the automatic wiper, or increase the wiping frequency;
- a windscreen with any chip or crack level with the sensor, or a windscreen covered in dust, dirt, insects, ice, the use of washing wax and water-repellent chemicals; the windscreen wiper will be less sensitive or may even not react at all.



D slow continuous wiping

E fast continuous wiping

Positions **A** and **D** are accessible with the ignition on.

Positions **C** and **E** are accessible only with the engine running.

Special note

When driving the vehicle, the wiping speed slows down whenever the vehicle stops.

For example, fast wiping speed will slow to normal wiping speed.

As soon as the vehicle moves off, wiping will return to the speed originally selected.

If stalk **1** is operated, it overrides and cancels the automatic function.

Precautions

- In the event of ice, check whether the blades are stuck to the windscreen before operating the wiping mechanism. If you activate the wipers while the blades are stuck down with ice, you may risk damaging both the blade and the wiper motor.
- Do not activate the wipers on a dry screen. This will lead to premature wear or damage to the blades.

WINDSCREEN WASH, WIPE (4/6)

Specific front wiper position (service position)

This position enables the blades to be lifted to remove them from the windscreen.

It may be useful to:

- to clean the blades;
- to release the blades from the windscreen in winter;
- replace the blades ➔ 5.37.

With the ignition on and the engine off, lower the windscreen wiper stalk fully (fast continuous wipe position). The wiper arms stop in a position away from the bonnet.

To return the blades to position, make sure they have been placed on the windscreen, then move the stalk to position **B** (stop) with the ignition on.

Before switching on the ignition, place the wipers on the windscreen. Otherwise, there may be a risk of damage to the bonnet or the wipers when they are switched on.

Note: after replacement, to reposition the blades correctly, make sure the blades are resting on the windscreen, switch on the ignition and activate the wiper control.

In the event of obstacles on the windscreen (dirt, snow, ice etc.), clean the windscreen (including the central area located behind the interior rear view mirror) before starting the wipers (risk of motor overheating).

If an object is preventing a blade from moving, it may stop functioning.


Remove the obstacle and reactivate the wiper using the wiper stalk.



Before any action involving the windscreen (washing the vehicle, de-icing, cleaning the windscreen, etc.) return stalk **1** to position **B** (stop).

Risk of injury and/or damage.

WINDSCREEN WASH, WIPE (5/6)



Windscreen washer

With the ignition on, pull stalk **1** then release.

A brief pull will trigger a single sweep of the wipers, in addition to the windscreen washer.

A longer pull will trigger three sweeps of the wipers followed, a few seconds later, by a fourth, in addition to the windscreen washer.


Note: in temperatures below zero, the washer liquid may freeze on the windscreen, reducing visibility. Heat the windscreen using the demister control before cleaning.



When working in the engine compartment, ensure that the windscreen wiper stalk is in position **B** (stop).

Risk of injury.

WINDSCREEN WASH, WIPE (6/6)



Headlight washers

Headlights on

On equipped vehicles, hold stalk **1** pulled towards you for about 2 seconds - the headlight washers and windscreen washers will be activated at the same time.

The headlight washers are also activated after three prolonged movements on the front windscreen washer control.

Note: to ensure the headlight washers operate correctly in winter, remove snow from the jet trims and de-ice the jet trims using an aerosol de-icer.

You are recommended to regularly remove dirt encrusted on the headlight glass.

When the minimum windscreen washer fluid level is reached, the headlight washer system may be deprimed.

Fill the windscreen washer fluid and then activate the windscreen washer, **with the engine running**, to reprime the system.




When working in the engine compartment, ensure that the windscreen wiper stalk is in position **B** (stop).

Risk of injury.

REAR SCREEN WASH, WIPE (1/2)

48061



Rear screen wiper

With the ignition on, rotate the ring **3** on the lever **1** until the symbol is opposite the reference point **2**:

- **stop;**
- **intermittent wiping.**
The blade will pause for several seconds between sweeps. Wiping frequency varies with vehicle speed;
- **slow continuous wiping.**

To stop the operation, pivot ring **3** again.

Note: when washing using a roller type car wash, return the ring **3** on the stalk **1** to the stop position to deactivate automatic wiping.
Follow usage recommendations.

Do not use the wiper arm to open or close the tailgate.



Before any action involving the rear screen (washing the vehicle, de-icing, cleaning, etc.) return stalk **1** to the stop position.

Risk of injury and/or damage.

Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:

- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In all cases, replace it as soon as it begins to lose efficiency: approximately once a year. ➡ 5.37.

Precautions for using the wipers

- In freezing or snowy weather, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.

REAR SCREEN WASH, WIPE (2/2)

Activation/deactivation of the rear screen wiper

Engaging reverse gear triggers intermittent wiping (if the front wipers are in operation). If your vehicle is equipped with a vehicle settings customisation menu, you can opt to activate or deactivate this function. ➡ 1.92.


For vehicles not fitted with a settings customisation menu, you can have this function deactivated by an authorised dealer.

In the event of obstacles present on the rear window (dirt, snow, etc.), the wiper will try to sweep away all the obstacles. If an obstacle prevents the blade from moving, it can be stopped. Remove the obstacle, wait for around 30 seconds and reactivate the wiper using the wiper stalk.

Precautions

- In the event of ice, check that the blades are not stuck to the wind-screen before operating the wipers. If you activate the wiper while the blade is blocked by ice, you risk damaging both the blade and the wiping motor.
- Do not operate the wipers on a dry screen. This will lead to the premature wear or damage to the blades.

48061




Rear screen wash/wipe

With the ignition on, push and hold stalk **1**, then release.

A longer action will trigger three sweeps of the wipers followed, a few seconds later, by a fourth, in addition to the wind-screen washer.

FUEL TANK (1/3)




Useable tank capacity:

- About **11 gallons (50 litres)** for petrol versions;
- about **10.78 gallons (49 litres)** for four door diesel versions;
- about **9.90 gallons (45 litres)** for five-door and estate diesel versions.

With the vehicle unlocked, to open cover **2**, press area **A** then release or, depending on the vehicle, press the control on the dashboard **1**. The cover **2** opens.

Valve **3** is integrated into the filler pipe.




For details on filling the fuel tank, refer to the information on “Filling with fuel” on the next page.

To close it, press on the fuel filler flap by hand, as far as it will go.



Never press valve **3** with your fingers.

Do not wash the filler area with a high-pressure washer.




Fuel grade

Use a high-grade fuel that complies with the legislation in force in each country and which **must** comply with the specifications given on the label on the cover **2**. ➔ 6.9.

Fuel types that conform to European standards with which the engines of vehicles sold in Europe are compatible: refer to the table ➔ 6.9.

FUEL TANK (2/3)



Diesel versions

It is **essential** to use diesel fuel that conforms with the information given on the label inside cover **2**.

Petrol versions

It is **essential** to use unleaded petrol. The octane rating (RON) must comply with the information given on the label on the cover **2**. ➔ 6.9.

Filling with fuel

With the ignition off, insert the nozzle to open valve **3** and insert it **fully** before turning it on to fill the fuel tank (risk of splashing).

Keep the nozzle in this position throughout the entire filling operation.

When the pump cuts out automatically at the end of the filling procedure, a maximum of two further filling attempts may be made, as there must be sufficient space in the fuel tank to allow for expansion.

Make sure that no water enters the fuel tank during filling. The valve **3** and its surround must remain clean.

Petrol versions

Using leaded petrol will damage the antipollution system and may lead to a loss of warranty. To ensure that the fuel tank is not filled with leaded petrol, the fuel tank filler neck consists of a restrictor fitted with a safety system which **only allows a nozzle for unleaded petrol to be used** (at the pump).



To fill up with fuel, the engine must be stopped (and not only on standby in the case of vehicles equipped with the Stop and Start function): you must switch off the ignition ➔ 2.4 ➔ 2.5.

Fire hazard.



Do not mix even small amounts of petrol (unleaded or E85) with diesel.

Do not use ethanol-based fuel if your vehicle is not compatible with this fuel.

Do **not** add reagent to the fuel – otherwise you risk damaging the engine ➔ 1.119.

If you wish to add an additive to the fuel, use a product approved by our Technical Department.

Consult an approved dealer.

FUEL TANK (3/3)

Running out of fuel on diesel versions

Vehicles with key/remote control

- Set the ignition key to the “**ON**” position **2** ➡ 2.3 and wait a few minutes before starting to enable the fuel circuit to be primed;
- turn the key to position “**START**”**3**. If the engine does not start, repeat the procedure.
- If the engine does not start after several attempts, please contact an authorised dealer.



Vehicles with card

With the card in the passenger compartment, press the start button **4** without pressing any of the pedals. Wait a few minutes before starting. This will enable the fuel circuit to be primed. If the engine does not start, repeat the procedure.

If the engine does not start after several attempts, please contact an authorised dealer.



No modifications whatsoever are permitted on any part of the fuel supply system (electronic units, wiring, fuel circuit, injectors, protective covers, etc.) as this may be dangerous (unless undertaken by qualified Network personnel).



Persistent smell of fuel

If you notice a persistent smell of fuel you should:

- stop the vehicle as soon as traffic conditions allow and switch off the ignition;
- switch on the hazard warning lights and ask your passengers to leave the vehicle and to keep away from traffic;
- contact an approved Dealer.

REAGENT TANK (1/4)

Please ensure that you comply with the legislation of your country. It is important to remember that failure to respect regulations in force could lead to legal action being taken against the vehicle owner.

Operating principle

The reagent is intended for diesel engines fitted with the SCR (selective catalytic reduction) system.

Using a reagent reduces the quantity of nitrogen oxides in exhaust gases.


Reagent consumption in real time depends on vehicle usage conditions, the equipment fitted, and driving style.

Reagent quality

Use **only reagents which conform to standard ISO 22241** and in accordance with the mark on the tank filler cap.



The reagent must not come into contact with eyes or skin. If it does, wash the affected area with plenty of cold water. If necessary, consult a doctor.



Filling

Capacity of the tank: 3.52 gal (16 litres) approximately.

With the ignition switched off, open the cover **A**, then unscrew the cap **1**.

Note: Ammonium hydroxide vapour may escape from the cap opening when the tank temperature is high.

To fill up with reagent, the engine must be stopped (and not only on standby in the case of vehicles equipped with the Stop and Start function): you must switch off the engine ignition ➔ 2.4 ➔ 2.5.



If the "XXX MILES (XXX KM) Failure Top up AdBlue" warning message appears, fill the reagent tank and refer to the filling instructions.

Risk of immobilisation of the vehicle.



Filler cap: this is specific.

If you have to replace it, make sure it is identical to the original cap. Contact an approved Dealer. Do not wash the filler area with a high pressure washer.

REAGENT TANK (2/4)

Filling (continued)

The tank can be filled at the pump. With the ignition off, insert the nozzle and insert it **fully** before turning it on to fill the fuel tank (risk of splashing). Keep the nozzle in this position throughout the entire filling operation.

When the pump cuts out automatically at the end of the filling procedure, a maximum of two further filling attempts may be made, as there must be sufficient space in the fuel tank to allow for expansion.

In other filling cases, it is essential to read the information shown on the reagent container (e.g. the can or bottle).

Precautions for use

When filling:

- **handle the reagent with care. They can damage clothes, shoes, body-work components etc.;**
- make sure that no water enters the fuel tank.

If the reagent overflows, or contaminates any paintwork, clean the affected area quickly with plenty of cold water and a soft cloth.

Note: If the reagent crystallises, use a soft sponge.

In extreme cold weather conditions

In frosty weather conditions, the reagent tank should be refilled when the



indicator and the message “Top up AdBlue before 1200 km” appear on the instrument panel.

Special cases

The reagent fluid freezes below about -10°C.

In these conditions, do not attempt filling when the fluid is frozen. In the event of needing to top up or fill the tank

with reagent ( on), park the vehicle in a hotter location if possible so that the reagent becomes liquid again. Otherwise, have a qualified professional top up or fill up with reagent fluid.

After filling the reagent tank, check that the cap and cover are closed, start the engine and **WAIT 10 seconds with the vehicle stationary, engine running** before setting off again.

If this operation is not carried out, the filling of the tank will not be taken into account automatically until after several dozens of minutes of driving.

The message “--- Top up AdBlue” and/or the warning lights will continue to appear until the filling has been taken into account by the system.



No work whatsoever is permitted on any part of the system. To prevent damage, only qualified personnel from our network may work on the system.

REAGENT TANK (3/4)

Maintenance/Range

The information displayed on the instrument panel may be accompanied by a beep.

Indicator lights	Message	What to do?
–	“Top Up AdBlue before 2400 km”	When the message is displayed when the ignition is switched on, you have less than 1,488 miles (2,400 km) range . Refill, or have an Approved Dealer refill the reagent in the tank.
 appears.	“Top up AdBlue before 1200 km”	When the message is displayed when the ignition is switched on, you have between 744 miles (1,200 km) and 496 miles (800 km) range . Refill, or have an Approved Dealer refill the reagent in the tank.
 appears.	“XXX MILES (XXX KM) Failure Top up AdBlue”	The message is displayed when the ignition is switched on and is repeated: – Approximately every 62 miles (100 km), you have between about 496 miles (800 km) and 124 miles (200 km) range; – Approximately every 31 miles (50 km), you have less than 124 miles (200 km) range. In any event, fill or have an Approved Dealer fill the reagent tank as soon as possible .
 flashes	“0 MILES (0 KM) Failure Top up AdBlue”	The engine will not start. To restart, you must fill the reagent tank yourself.

REAGENT TANK (4/4)

System fault

When the indicator lights light up, this may be accompanied by a beep.

Indicator lights	Message	Readings
 and  come on.	“Check anti-pollution system” “AdBlue quality to check” “AdBlue injection to check”	Indicates a fault in the system. Contact your approved dealer as soon as possible.
 and  come on.	“XXX MILES (XXX KM) Failure antipollution”	Indicates a system fault and that in less than 496 miles (800 km) it will become impossible to restart the vehicle. These warnings are repeated: – every 62 miles (100 km) until there are between 500 miles (800 km) and 124 miles (200 km) remaining until the vehicle cannot be restarted; – Every 31 miles (50 km) when there is less than 124 miles (200 km) left before the vehicle cannot be restarted. Contact your approved dealer as soon as possible.
 and  come on.	“0 KM Failure antipollution”	Indicates that after the ignition is switched off the vehicle will not restart. Call an approved Dealer.

Section 2: Driving

Running in	2.2
Ignition switch	2.3
Starting, stopping the engine.	2.4
Stop and start function.	2.8
Special features of petrol and diesel versions.	2.12
Gear lever, Handbrake	2.16
Electronic parking brake	2.17
“AUTOHOLD” function.	2.21
Driving advice, Eco-driving	2.22
Maintenance and antipollution advice	2.30
Environment	2.31
Tyre pressure warning and monitoring system	2.32
Driver correction devices and aids	2.43
Lane departure warning.	2.49
Lane keeping assist.	2.54
Blind spot warning	2.60
Safe distance alert.	2.67
Active emergency braking	2.71
Fatigue detection warning	2.79
Detection of road signs	2.81
Speed limiter	2.85
Cruise control	2.89
Adaptive cruise control	2.94
Highway and Traffic Jam Companion	2.108
Parking distance control	2.124
Reversing camera	2.130
Parking exit warning	2.133
Assisted parking	2.137
Automatic gearbox.	2.142
Emergency call	2.145

RUNNING IN

Petrol version

For the first **600 miles** (1,000 km), do not exceed 78 mph (130 km/h) in the highest gear, or 3,000 to 3,500 rpm.

You may only expect top performance from your vehicle after approximately **1,800 miles (3,000 km)**.

Note: for a new vehicle in the running-in phase: the coolant level may be higher than the “**MAXI**” mark on the tank, then drop to between the levels “**MINI**” and “**MAXI**”. This does not present a risk.

Service intervals: refer to the Maintenance Document for your vehicle.

Diesel version

For the first **930 miles (1,500 km)**, do not exceed 80 mph (130 km/h) in the highest gear, or 2,500 rpm.

After completing this mileage you may drive faster, although you may only expect top performance after approximately 3,600 miles (6,000 km).

During the running in period, do not accelerate hard while the engine is still cold and do not let the engine over-rev.

Note: for a new vehicle in the running-in phase: the coolant level may be higher than the “**MAXI**” mark on the tank, then drop to between the levels “**MINI**” and “**MAXI**”. This does not present a risk.

Service intervals: refer to the Maintenance Document for your vehicle.

IGNITION SWITCH: vehicle with key



Ignition switch

“LOCK 0 position

To lock: remove the key and turn the steering wheel until the steering column locks.

To unlock: turn the key and the steering wheel slightly.

“ON” 2 position

The ignition is switched on:

Accessories (radio etc.) can be used.

“START” 3 position

If the engine fails to start at the first attempt, the key must be turned back before the starter can be activated again. Release the key as soon as the engine starts.

Note: on diesel versions, several seconds may pass between turning the key and the engine starting to allow for engine preheating.

STARTING, STOPPING THE ENGINE: vehicle with key



Starting the engine

Petrol versions

- Activate the starter **without accelerating**;
- release the key as soon as the engine starts.



Never start your vehicle while freewheeling on a gradient. Risk of non-activation of power-assisted steering.

There is a risk of accidents.



Diesel versions

- Turn the ignition key to the “ON” position 2 and hold this position until the engine preheating light goes off;
- turn the key to the “START” position 3 **without depressing the accelerator pedal**;
- release the key as soon as the engine starts.

Special note: if starting the engine when the outdoor temperature is very low (below - 10 ° C): hold down the clutch pedal until the engine starts.



Never switch off the ignition before the vehicle has stopped completely. Once the engine has stopped, the brake servo, power-assisted steering, etc. and the passive safety devices such as air bags and pretensioners will no longer operate.

Stopping the engine

With the engine idling, turn the key back to the “LOCK” position 0.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

STARTING, STOPPING THE ENGINE: vehicle with card (1/3)




48042

Conditions for starting the engine

The card must be inserted in detection zone 1.

To start:

- vehicles with an automatic gearbox, place the lever in position **P**, depress the brake pedal and press button **2**;
- on vehicles with a manual gearbox, press the brake or clutch pedal and press button **2**. If a gear is engaged, also press the clutch pedal.



48043

Special features

- If one of starting conditions is not applied, the message “Press Brake + START” or “Press Clutch + Start” or “Select Gearbox Position “P” is displayed on the instrument panel;
- in some cases, it will be necessary to move the steering wheel whilst pressing the start button **2** to help unlock the steering column; the message “Turn Steering Wheel + START” will warn you of this;

“Hands-free” starting with the tailgate open

In this case, the card should not be located in the luggage compartment, to prevent the risk of loss.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

STARTING, STOPPING THE ENGINE: vehicle with card (2/3)




Accessories function

(switching on the ignition)

Once you have gained access to your vehicle, you may use some of its functions (radio, navigation, wipers, etc.).

To use the other functions, with the card in the passenger compartment, press the **2** button without pressing the pedals.



Operating faults

In certain cases, the hands-free card may not work:

- when the card battery is drained etc.
- near to appliances operating on the same frequency as the card (monitor, mobile phone, video game, etc.);
- vehicle located in a high electromagnetic radiation zone.

The message “Place card on zone + START” appears on the instrument panel.

Press the brake or clutch pedal, then place the card **3** (button side) during approximately two seconds on the placement area **4**.

Press the **2** button to start the vehicle. The message goes out.

STARTING, STOPPING THE ENGINE: vehicle with card (3/3)



Conditions for stopping the engine

The vehicle must stationary, with the lever positioned in **N** or **P** for vehicles with an automatic transmission.

With the card in the vehicle, press button **2**: the engine stops. The steering column is locked when the driver's door is opened or the vehicle is locked.

If the card is no longer in the passenger compartment or if the card's is worn out, when the vehicle is stationary and you try to switch the engine off, the message "Keycard absent : press/hold START" appears on the instrument panel: press button **2** for longer than three seconds. If the card is no longer in the passenger compartment, make sure you can retrieve it before pressing and holding the button. Without the hands-free card, you will not be able to restart the vehicle.

With the engine switched off, any accessories being used (radio, etc.) will continue to function for approximately 10 minutes.

When the driver's door is opened, the accessories stop working.



Never switch off the ignition before the vehicle has stopped completely. Once the engine has stopped, the brake servo, power-assisted steering, etc., and the passive safety devices such as the airbags and pretensioners will no longer operate.



When you leave your vehicle, especially if you have your card with you, check that the engine is completely switched off.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

FUNCTION STOP AND START (1/4)

This system enables a reduced fuel consumption and lower greenhouse gas emissions. The system is activated automatically when the vehicle is started. During driving, the system stops the engine (standby) when the vehicle comes to a stop or is moving at a slow speed (traffic jam, traffic lights etc.), depending on the vehicle.

Conditions for engine standby

The vehicle has set off from where it was parked;

For vehicles equipped with automatic gearboxes:

- the gearbox is in position **D**, **M** or **N**; and
- the brake pedal is depressed (sufficiently hard);

If the  warning light flashes while the vehicle is stopped and the message “Press brake pedal” appears on the instrument panel, this indicates that the brake pedal is not sufficiently pressed;

and

- the accelerator pedal is not depressed;

and

- when the vehicle speed is zero during approximately one second or, depending on the vehicle, as soon as the vehicle speed is below approximately 3 mph (5 km/h).

The engine remains on standby if position **P** is selected, or if position **N** is selected with the handbrake engaged and the brake pedal released.

For vehicles equipped with manual gearboxes:

- the gearbox is in neutral;

If the  warning light flashes while the vehicle is stopped and the message “Shift to neutral” appears on the instrument panel, this indicates that you need to shift the gear lever to neutral;

and

- the clutch pedal is released; and
- the vehicle speed is less than approximately 3 mph (5 km/h).

For all vehicles:

Warning light  on the instrument panel is lit when the engine is on standby.

The vehicle equipment remain operational while the engine is stopped.

When the engine switches to standby, the steering assistance may no longer be operational.

In this case it becomes operational again when the engine is no longer on standby or the speed exceeds approximately 1 mph (1 km/h) (downhill, slope etc.).



If the engine is put in standby, the electronic parking brake (depending on the vehicle) is not applied automatically.



Keep your vehicle stationary when the engine is on standby (shown by the warning light  on the instrument panel).



The engine **MUST** be stopped (not put in standby) before leaving the vehicle.
➔ 2.4 ➔ 2.5.

FUNCTION STOP AND START (2/4)

Preventing the engine from standing by

In certain situations, such as negotiating a crossroads for instance, it is possible (with the system activated) to keep the engine running so as to be ready to move off quickly.

For vehicles equipped with automatic gearboxes and when the engine standby is performed only when the vehicle stopped:

Keep the vehicle stationary without pressing too hard on the brake pedal.

For vehicles equipped with manual gearboxes:

Keep the clutch pedal pressed right down.



To fill up with fuel, the engine must be stopped (and not only on standby in the case of vehicles equipped with the Stop and Start function): you must switch off the ignition ➔ 2.4 ➔ 2.5.

Fire hazard.

Conditions for coming out of engine standby

For vehicles equipped with automatic gearboxes:

- when the driver's door is opened;
or
- when the driver's seat belt is unfastened;
or
- the brake pedal is released and position **D** or **M** engaged (depending on the vehicle);
or
- the brake pedal is released in gear position **N** with the handbrake off;
or
- the brake pedal is pressed again in gear position **P** or **N** engaged with the handbrake applied;
or
- the vehicle is in gear position **R**;
or
- the accelerator pedal is depressed;
or
- depending on the vehicle, in manual mode (**M**), the gear change paddles are activated ➔ 2.142.

"AUTOHOLD" function activated ➔ 2.21, the brake pedal may be released and the engine standby maintained.
Press the accelerator pedal to exit vehicle standby.

FUNCTION STOP AND START (3/4)

For vehicles equipped with manual gearboxes:

- when opening the driver's door, without any gear engaged and the clutch pedal released;

or

- when unfastening the driver's seat belt, without any gear engaged and the clutch pedal released;

or

- the gearbox is in neutral and the clutch pedal is slightly depressed;

or

- the engine is in gear and the clutch pedal is pressed right down.

Special note: depending on the vehicle, if you switch off the ignition when the engine is on standby, the warning

light  is displayed for a few seconds on the instrument panel.

For vehicles equipped with a manual gearbox:

the restart may be interrupted if the clutch pedal is released too quickly while a gear is engaged.

Conditions preventing the standby of the engine

Certain conditions prevent the system from using the engine standby function, including when:

- the driver's door is not closed;
- the driver's seatbelt is not fastened;
- reverse gear is engaged;
- the bonnet is not locked;
- the outdoor temperature is too low or too high;
- the battery is not sufficiently charged;
- the difference between the vehicle interior temperature and the automatic climate control instruction is too high;
- parking distance control is in operation;
- the altitude is too high;

- the gradient is too steep for vehicles fitted with an automatic gearbox;
- the "Clear view" function is activated ➔ 3.8;
- the engine temperature is too low;
- the emission control system is being regenerated;
- ...

Warning light  is displayed on the instrument panel. This notifies you that engine standby is not available.

The  warning light may appear along with a message on the instrument panel:

- "Optimising Battery Recharge" to prioritise battery charging;
- "Prioritising Thermal Comfort" to prioritise air conditioning;
- "Prioritising running engine" to prioritise engine operations.



Deactivate the Stop and Start function for any operation performed in the engine compartment.

FUNCTION STOP AND START (4/4)

Special feature of the automatic engine re-start


Under certain conditions, the engine can restart on its own in order to guarantee your safety and comfort. This can occur especially when:

- the outdoor temperature is too low or too high;
- the “Clear view” function is activated ➔ 3.8;
- the battery is not sufficiently charged;
- the vehicle speed is above 3 mph (5 km/h) (downhill slope, etc.);
- repeated pressing on the brake pedal or braking system requirement;
- ...

The  warning light is displayed on the instrument panel to notify you of automatic engine restarting.



The engine **MUST** be stopped (not put in standby) before leaving the vehicle.
➔ 2.4 ➔ 2.5.



The  warning light may appear along with a message on the instrument panel:

- “Optimising Battery Recharge” to prioritise battery charging;
- “Prioritising Thermal Comfort” to prioritise air conditioning;
- “Prioritising running engine” to prioritise engine operations.

Note: With the engine on standby, press switch **1** to automatically restart the engine.

Deactivating, activating the function

Press **1** to deactivate the function. The message “Stop & Start deactivated” appears on the instrument panel and the **1** switch warning light illuminates. Pressing again will reactivate the system. The message “Stop & Start Activated” appears on the instrument panel and the **1** switch warning light goes out.

The system is automatically reactivated each time the vehicle is started using the start button. ➔ 2.4 ➔ 2.5.

Operating faults

If the message “Check Stop & Start” appears on the instrument panel and the **1** switch warning light illuminates, this indicates that the system is deactivated.

Please consult an authorised dealer.

SPECIAL FEATURES OF PETROL VERSIONS (1/2)

The following operating conditions:

- driving for long periods when the low fuel level warning light is lit;
 - using leaded petrol;
 - using lubricant or fuel additives which are not approved,
- or operating faults such as:

- faulty ignition system, running out of fuel or disconnected spark plugs resulting in the engine misfiring or cutting out when driving;
- loss of power,

as they may cause the catalytic converter to overheat and thus reduce its efficiency, **or damage it irreparably and cause heat damage to the vehicle.**

If you notice any of the above operating faults, have the necessary repairs carried out as soon as possible by an approved Dealer.

These faults may be avoided by regularly taking your vehicle to an approved Dealer at the intervals specified in the Maintenance document.

Starting problems

To avoid damaging the catalytic converter or the starter, and to prevent premature wearing of the battery, **do not keep** trying to start the engine (using the start button, or by pushing or towing the vehicle) **without having identified and corrected the starting fault.**

If the fault cannot be identified, do not keep trying to start the engine, but contact an approved Dealer.



Do not park the vehicle or run the engine in locations where combustible substances or materials such as grass or leaves can come into contact with the hot exhaust system.

SPECIAL FEATURES OF PETROL VERSIONS (2/2)

Particle filter

The particle filter is used in the treatment of exhaust gases from petrol engines.

Depending on the vehicle, the warning

light  displayed on the instrument panel indicates that the filter is becoming clogged and requires cleaning. To

clean it, when the  warning light appears, and as traffic conditions and speed limits allow, drive at between about 31 mph (50 km/h) and 68 mph (110 km/h) until the light goes out.

After between approximately 5 and 20 minutes, the warning light should go out.

Note: the indicator light may go out after 20 minutes if the driving conditions required to clean the filter are not fully met.

If the vehicle is stopped before the warning light disappears you will have to restart the process from the beginning.

If the filter becomes saturated, the  warning light and, depending

on the vehicle, the  warning light will appear on the instrument panel, accompanied by the message "Check injection". In this case, please consult an Authorised Dealer.

If the **STOP** warning light and, depend-

ing on the vehicle, the  warning light appears, accompanied by the "Engine failure hazard" message, stop the vehicle, switch off the engine and contact an Approved Dealer.



Warning light **STOP** requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Contact an approved Dealer.

SPECIAL FEATURES OF DIESEL VERSIONS (1/2)

Diesel engine speed

Diesel engines are fitted with an injection pump **which prevents the engine speed being exceeded** irrespective of the gear selected.

If the message “Check Anti- Pollution System” is displayed along with warn-


ing lights  and , consult an authorised dealer immediately.

When driving, depending on the fuel grade used, it is possible that white smoke may be emitted.

This is due to the exhaust particle filter being cleaned automatically, and does not affect the way the vehicle runs.

Running out of fuel

After the tank has been filled following **a complete draining of fuel**, the fuel system must be reprimed: ➔ 1.116 before restarting the engine.



Engine smoke opacity label

You can find the information **1** on the label **A** stuck in the engine compartment or, depending on the vehicle, on the vehicle identification plate ➔ 6.2.

1 Diesel exhaust emissions.

Precautions to be taken in winter

To avoid any faults in icy weather:

- ensure that the battery is always fully charged;
- always keep the diesel tank relatively full to avoid water vapour condensing in it and accumulating at the bottom of the tank.



Do not park the vehicle or run the engine in locations where combustible substances or materials such as grass or leaves can come into contact with the hot exhaust system.

SPECIAL FEATURES OF DIESEL VERSIONS (2/2)

Particle filter

The particle filter is used in the treatment of exhaust gases from diesel engines.

Depending on the vehicle, the warning

light  displayed on the instrument panel indicates that the filter is becoming clogged and requires cleaning.

To do this, when the  warning light is displayed, continue driving according to traffic conditions and observe the speed limit until the warning lights disappears. If possible, do not let the engine speed drop below 2000 rpm.

The warning light should go out after 10 to 20 minutes. ➔ 1.72.

The display of the  on the instrument panel may be accompanied by an increase in engine speed and operation of the cooling system in order to clean the particle filter.

Note: the warning light may reappear if the driving conditions are not fully met with regard to cleaning the filter. If the vehicle is stopped or if the engine speed drops below 2,000 rpm before the warning light goes out, the operation may need to be repeated.

To facilitate the particle filter regeneration, carry out a long driving phase (at least 20 minutes) on main roads every 124 miles (200 km).

If the filter becomes saturated, the  warning light and, depending


on the vehicle, the  warning light will appear on the instrument panel, accompanied by the message “Check injection”. In this case, please consult an Authorised Dealer.

If the  warning light and, depending on the vehicle, the  warning light appears, accompanied by the “WARNING: Engine Failure Risk” message, stop the vehicle, switch off the engine and contact an Approved Dealer.



Warning light  requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Contact an approved Dealer.

GEAR LEVER, HANDBRAKE



Gear lever

Vehicles with manual gearbox: refer to the grid on the gear lever knob **1**.

Vehicles with an automatic gearbox:
➔ 2.142.

Selecting reverse gear

The reversing lights will come on as soon as reverse gear is selected with the ignition on.

Handbrake

To release:

Pull the lever **3** up slightly, press button **2** and then lower the lever to the floor.

The red warning light  on the instrument panel will remain on, accompanied by the message "Parking Brake ON" and a beep if you are driving with an incorrectly released handbrake.



An impact to the underside of the vehicle while manoeuvring (e.g.: striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g.: deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.

To apply:

Pull lever **3** upwards. Check that the vehicle is immobilised. The warning

light  on the instrument panel will come on.




Make sure that the handbrake is properly released when driving (red indicator light off), otherwise overheating, or even damage, may occur.



When stationary, and depending on the slope and/or vehicle load, it may be necessary to pull up the handbrake at least two extra notches and engage a gear (1st or reverse gear) for vehicles with a manual gearbox or position **P** for vehicles with an automatic gearbox.

ELECTRONIC PARKING BRAKE (1/4)




Assisted operation

Applying the electronic parking brake

With the vehicle stationary, the electronic parking brake can be used to immobilise the vehicle:

- by pressing the engine start/stop button 1 or by turning the ignition key 2 to the “ON” 2 position;



or

- when the driver's seat belt is unfastened;

or

- when the driver's door is opened;

or

- for vehicles fitted with an automatic gearbox, when position P is engaged.

In all other instances, for example **the engine has stalled or is in standby due to the Stop and Start function** ➔ 2.8, the electronic parking brake is not applied automatically.

Manual mode must be used.

For certain country-specific model versions, the assisted brake application function is not activated. Refer to the information on “Manual operation”.

To confirm that the electronic parking brake is applied, the message “Parking brake on” and warning light  on the instrument panel and warning light 4 on the switch 3 light up.

After the engine is switched off, indicator light 4 goes out several minutes after the assisted parking brake has been applied and indicator light  goes out when the vehicle is locked.



The electronic parking brake can be used to immobilise the vehicle. Before leaving the vehicle, check that the electronic parking brake is fully applied. Warning light 4 on switch 3 and warning light  on the instrument panel illuminate to show that the parking brake is applied but switch off when the doors are locked. Depending on the vehicle, a sticker is located on the upper section of the windscreen to remind you of this.


ELECTRONIC PARKING BRAKE (2/4)

Assisted operation (continued)

Note: in some situations (electronic parking brake failure, manual release of the parking brake, etc.), a beep sounds and the message “Apply parking brake” appears on the instrument panel to warn you that the electronic parking brake has been released.

- with the engine running: when the driver’s door is opened;
- with the engine switched off (eg. when the engine stalls): when a front door is opened.

In this case, pull and release switch **3** to apply the assisted parking brake.



Assisted release of the parking brake

The parking brake is released:

- once the vehicle starts to accelerate;
- or
- on vehicles equipped with an automatic gearbox, when shifting from **P** position.

Manual operation

You can apply the electronic parking brake manually.


Manually applying the electronic parking brake

Pull switch **3**: warning light **4** on the switch and the  warning light on the instrument panel light up.



The electronic parking brake can be used to immobilise the vehicle. Before leaving the vehicle, check that the electronic parking brake is fully applied. Warning light **4** on switch **3** and warning light  on the instrument panel illuminate to show that the parking brake is applied but switch off when the doors are locked. Depending on the vehicle, a sticker is located on the upper section of the windscreen to remind you of this.

ELECTRONIC PARKING BRAKE (3/4)




Manually releasing the electronic parking brake

Press switch **1** without pressing the pedals or, depending on the vehicle, turning the key **2** to the “ON” position **2** to switch on the ignition.

Press the brake pedal then press switch **3**: indicator light **4** on the switch

and indicator light **(P)** displayed on the instrument panel go out.



Brief stop

To apply the electronic parking brake manually (when stopping at a red light, or stopping when the engine is running, etc.): pull and release the switch **3**.

The brake is released as soon as the vehicle is started up again.

Special cases

To park on a slope or while towing a trailer, for example, pull switch **3** for a few seconds to gain the maximum braking.

To park the vehicle without applying the electronic parking brake (if there is a risk of freezing, for example):

- engage any gear or the **P** position: the drive wheels will be mechanically locked by the driveshaft;
- switch off the engine by pressing the engine start/stop button **1** or by turning the ignition key **2**;
- release the driver's seat belt;
- open the driver's door;
- manually release the electronic parking brake (please see the previously described information on “Manually releasing the electronic parking brake”).



If the driver's seat belt is unfastened before the vehicle has come to a complete standstill, ensure the parking brake has been properly

applied: warning light **(P)** on the instrument panel light up to confirm this.

Risk of loss of immobilisation.

ELECTRONIC PARKING BRAKE (4/4)



If the “WARNING: Electric System” or “Check battery” or “WARNING: Braking System” message appears, you must immobilise the vehicle by selecting first gear (on a manual gearbox), engaging **P** position (automatic gearbox) or by pulling the switch **3** for approximately 10 seconds.

If the conditions and the slope require it, chock the wheels of the vehicle.

Risk of loss of immobilisation of the vehicle.

Contact an authorised dealer.



Never leave your vehicle without moving the selector lever to position **P** and switching off the engine. This is because when the vehicle is stationary with the engine running and a gear engaged, the vehicle may begin to move.

There is a risk of accidents.

Versions with an automatic gearbox

For safety reasons, automatic release is deactivated when the driver's door is open or not shut properly and the engine is running (in order to prevent the vehicle from moving without the driver).

The “Release Parking Brake Manually” message appears on the instrument panel when the driver depresses the accelerator.



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.

Operating faults

- If there is a fault, the  warning light illuminates on the instrument panel accompanied by the “Check parking brake” message and, in

some cases, the  warning light.

Please contact an authorised dealer as soon as possible.

- If there is an assisted parking brake fault, the warning light  comes on, along with the message “Braking system fault”, a beep and, in some cases, the warning light .

This means that you must stop as soon as traffic conditions allow.



It is therefore essential to immobilise the vehicle by engaging first gear (manual gearbox) or position **P** (automatic gearbox). If the slope requires it, chock the vehicle.

“AUTOHOLD” FUNCTION

Vehicle stopped (e.g. at a red light, an intersection, a traffic jam, etc.), the function ensures braking force even when the driver releases the brake pedal. The braking force is released as soon as the driver accelerates sufficiently with a gear engaged.

Activation

Press the switch **3**.

The switch warning light **3** illuminates to confirm that the function is activated.

Deactivation

Press the brake pedal and **3** switch simultaneously.


The switch warning light **3** turns off, confirming that the function is deactivated.

If the braking force is maintained, the parking brake is applied automatically when:

- the driver exits the vehicle;

or

- the vehicle is immobilised for more than approximately three minutes.



Conditions for maintaining the braking force

The following conditions must be met:

- the seat belt for the driver is fastened;
- and
- the electronic parking brake is released;
- and
- the vehicle is not stationary on a very steep slope.

The maintained braking force is confirmed by the  warning light on the instrument panel.

Conditions for interrupting the braking force

The following conditions must be met:

- the driver accelerates sufficiently with a gear engaged;
- or
- the driver disables the function.

Warning light  goes out on the instrument panel.

Upon each start-up, the function continues the mode set at the time the engine was last switched off.



The electronic parking brake can be used to immobilise the vehicle. Before leaving the vehicle, check that the electronic parking brake is fully applied. Warning light **1** on

switch **2** and warning light  on the instrument panel illuminate to show that the parking brake is applied but switch off when the doors are locked. Depending on the vehicle, a sticker is located on the upper section of the windscreen to remind you of this.

DRIVING ADVICE, ECO-DRIVING (1/8)

Fuel consumption is accredited in accordance with a standard regulatory method.

Identical for all manufacturers, this enables vehicles to be compared with one another.

Consumption in real time depends on vehicle usage conditions, the equipment fitted and the user's driving style.

To optimise fuel consumption, please refer to the following advice.

Depending on the vehicle, you will have various functions which enable you to lower your fuel consumption:

- the rev counter;
- gear change indicator;
- the free-wheel function;
- the driving style indicator;
- Eco acceleration indicator;
- the journey record and eco-driving advice via the multimedia screen;
- ECO mode;
- the Stop and Start function ➔ 2.8.


Free-wheel function

On vehicles fitted with an automatic gearbox (depending on the vehicle), during deceleration phases (driver's foot fully off the accelerator pedal), switching to freewheeling (automatic neutral) decreases engine braking and allows you to move farther without accelerating in order to save fuel.

Warning light  appears on the instrument panel:

- in grey when the vehicle is not in free-wheel mode;
- in green or white, depending on the vehicle, when the vehicle is in free-wheel mode (automatic neutral).

DRIVING ADVICE, ECO-DRIVING (2/8)



On the instrument panel A, B or C

Depending on the vehicle, the information display can be organised and customised based on the instrument panel customisation style selected from the multimedia screen.



Gear change indicator 1


Depending on the vehicle, to obtain optimum consumption levels, a warning light on the instrument panel lets you know the best time to move up or down a gear:




shift up a gear;

downshift a gear.

If you regularly follow this indicator, you will reduce your vehicle's fuel consumption.



DRIVING ADVICE, ECO-DRIVING (3/8)





Driving style indicator 2

Informs you about the driving style adopted in real time. This is shown by indicator light 2.


The more petals displayed on 2, the more your driving is flexible and economical.

If you regularly monitor this indicator, you will reduce your vehicle's fuel consumption.

Please refer to the multimedia instructions for further information.



DRIVING ADVICE, ECO DRIVING (4/8)



Acceleration indicator Eco 3

This informs you in real time whether you are accelerating moderately or strongly.


This is shown by the 3 warning light:

- green: acceleration is moderate and correct;
- white: acceleration is too high;
- grey: acceleration is high.

Note: it is not possible to simultaneously display the driving style indicator 2 and the Eco acceleration indicator 3.



DRIVING ADVICE, ECO DRIVING (5/8)



On the multimedia screen

Journey record

Once the engine is switched off, you will see “Journey record” displayed on the multimedia screen **4**, enabling you to view information on your last journey.

This indicates:

- the general score;
- score evolution;
- distance without fuel consumption.

An overall rating from 0 to 100 is displayed to let you assess your eco driving performance.

The higher the rating, the lower the fuel consumption.

Eco advice is given to help improve your performance.

With your favourite journeys saved, you can compare your performance between trips and the performance of other vehicle users.

Please refer to the multimedia instructions for further information.


DRIVING ADVICE, ECO-DRIVING (6/8)

ECO mode

ECO mode is a function which optimises fuel consumption.

It affects certain driving operations (acceleration, shifting gears, cruise control, deceleration etc.).

Limiting acceleration enables low fuel consumption in urban and surrounding areas.



Activating the function

The function can be activated:

- by pressing switch **5**;
- by the central control **6** ➔ 3.2 ;
- from the multimedia screen (refer to the multimedia instructions).

The warning light **ECO** comes on on the instrument panel to confirm activation.

While driving, it is possible to exit the ECO mode temporarily in order to improve engine performance.

To do this, press the accelerator pedal firmly and fully.

ECO mode is reactivated when you take pressure off the accelerator pedal.

Disabling the function

Depending on the vehicle, the function can be deactivated either:

- by pressing switch **5**;
- by the central control **6** ➔ 3.2.

The warning light **ECO** goes out on the instrument panel to confirm deactivation.

DRIVING ADVICE, ECO-DRIVING (7/8)



Driving advice and ECO driving

Behaviour

- Drive carefully for the first few miles until the engine reaches its normal operating temperature, rather than let it warm up while the vehicle is stationary.

- High speeds significantly affect the vehicle's fuel consumption.

Examples (at a steady speed):

- reducing the speed from 80 mph (130 km/h) to 68 mph (110 km/h) approximately saves up to 20% of fuel approximately;
- reducing the speed from 56 mph (90 km/h) to 50 mph (80 km/h) approximately saves up to 10% of fuel approximately.
- Dynamic driving with a lot of frequent acceleration and braking is expensive on fuel in comparison to the time saved.
- Do not over rev the engine in the intermediate gears. You should always use the highest gear possible.
- Avoid sudden acceleration.
- Brake as little as possible. If you anticipate an obstacle or bend in advance, you may then simply release the accelerator pedal.

- Do not try to maintain the same speed up a hill, accelerate no more than you would on flat ground. Keep your foot in the same position on the accelerator pedal.
- Double declutching and accelerating before switching off are unnecessary in modern vehicles.
- Bad weather, flooded roads:



Do not drive through floods if the water is above the lower edge of the wheel rims.




Obstructions to the driver

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another.


There is a risk of wedging the pedals.

DRIVING ADVICE, ECO-DRIVING (8/8)



Tyres

- An underinflated tyre increases fuel consumption.
- To optimise fuel consumption, set the highest speed tyre pressure or the recommended pressure indicated on the edge of the driver's door ➔ 4.13.
- The use of non-recommended tyres can increase fuel consumption.



Advice on use

- Opt for ECO mode.
- Electricity consumes fuel – switch off all electrical components when they are not genuinely needed in order to save fuel. **However** (safety first), keep your lights on when the visibility is bad ("see and be seen").
- Use the air vents. Driving with the windows open at 60 mph (100 km/h) will increase fuel consumption by 4%.
- Never fill the fuel tank right to the brim to avoid overflow.

- In vehicles fitted with air conditioning, it is normal to observe an increase in fuel consumption (especially in urban conditions) when it is used. For vehicles fitted with manual air conditioning, switch off the system when it is not required.

Recommendations for reducing consumption and therefore helping to preserve the environment:

If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

- Do not leave an empty roof rack fitted to the vehicle.
- It is better to fit a trailer for bulky objects.
- When towing a caravan, fit a wind deflector and adjust it carefully.
- Avoid using the vehicle for door-to-door calls (short journeys with long waits in between) because in such conditions the engine never reaches its optimal operating temperature.

MAINTENANCE AND ANTIPOLLUTION ADVICE

Your vehicle complies with criteria for recycling and recovering vehicles at the end of their service life, which entered into force in 2015.

Some parts of your vehicle have therefore been designed to facilitate future recycling.

These parts are easy to remove so that they can be recovered and reprocessed by recycling companies.

By virtue of its design, moderate fuel consumption and initial settings, your vehicle also conforms to current antipollution regulations. The manufacturer is actively striving to reduce pollutant exhaust gas emissions and to save energy. But the fuel consumption of your vehicle and the level of pollutant exhaust gas emissions are also your responsibility. Ensure that it is maintained and used correctly.

Maintenance

It is important to remember that failure to respect antipollution regulations could lead to legal action being taken against the vehicle owner.

In addition, replacing engine, fuel supply system and exhaust components with parts other than those originally recommended by the manufacturer may alter your vehicle so that it no longer complies with anti-pollution regulations.

Have your vehicle adjusted and checked by an authorised dealer, in accordance with the instructions given in your maintenance schedule: they will have all the equipment necessary for ensuring that your vehicle is maintained to its original standard.

Engine adjustments

- **Spark plugs:** for optimum conditions of use, output and performance the specifications laid down by our Design Department must be strictly applied.
If the spark plugs have to be changed, use the make, type and gap specified for your vehicle's engine. Contact an authorised dealer for this.
- **Ignition and idle speed:** no adjustment is needed.

- **Air filter, fuel filter:** a choked element will reduce efficiency. It must be replaced.

Exhaust gas monitoring system

The exhaust gas monitoring system will detect any operating faults in the vehicle's antipollution system.

If this system malfunctions, toxic substances may be released into the atmosphere or damage may occur.



This warning light on the instrument panel will indicate if there are any faults in the system:

This lights up when the ignition is switched on and goes out when the engine is started.

- If it lights up continuously, consult an approved Dealer as soon as possible;
- If it flashes, reduce the engine speed until the light stops flashing. Contact an authorised dealer as soon as possible.



➔ 1.119

ENVIRONMENT

Your vehicle has been designed with respect for the **environment** in mind for its entire service life: during production, use and at the end of its life.

Manufacture

Your vehicle has been manufactured at a factory which complies with a policy to reduce the environmental impact on the surrounding areas (reduction of water and energy consumption, visual and noise pollution, atmospheric emissions and waste water; sorting and re-using waste).

Emissions

Your vehicle has been designed to emit fewer greenhouse gases (CO₂) while in use, and therefore to consume less fuel (e.g. 140 g/km, equivalent to 1494.6 mpg (5.3 l/100 km) for a diesel vehicle).

Our vehicles are also equipped with a particle filter system including a catalytic converter, an oxygen sensor and an active carbon filter (the latter prevents vapour from the fuel tank being released into the open air).

On certain diesel vehicles, this system also includes a particle filter to reduce the volume of soot particles emitted.

Please make your own contribution towards protecting the environment too

- Worn parts replaced in the course of routine vehicle maintenance (vehicle battery, oil filter, air filter, batteries, etc.) and oil containers (empty or filled with used oil) must be disposed of through specialist organisations.

- At the end of the vehicle's service life, it should be sent to approved centres to ensure that it is recycled.
- In all cases, comply with local legislation.

Recycling


Your vehicle is 85% recyclable and 95% recoverable.

To achieve these objectives, many of the vehicle components have been designed to enable them to be recycled. The materials and structures have been carefully designed to allow these components to be easily removed and reprocessed by specialist companies.

In order to preserve raw material resources, this vehicle incorporates numerous parts made from recycled plastics or renewable materials (vegetable or animal-derived materials such as cotton or wool).

TYRE PRESSURE LOSS WARNING (1/6)

43592



When fitted to the vehicle, this system notifies the driver if one or more tyres lose pressure.

The system can be identified by the **1** label in the vehicle.

47977




Operating principle

This system detects a loss of pressure in one of the tyres by measuring the wheel speed while driving.

The warning light  **2** comes on on the dashboard to alert the driver in the event of insufficient pressure (tyre deflated, punctured etc.).

48053



TYRE PRESSURE LOSS WARNING (2/6)

Operating conditions

The system should be reset with a pressure equal to that stated on the tyre pressure label (refer to the information on “Tyre Pressures” in section 4), otherwise it may not give a reliable warning in the event of significant pressure loss.

Resetting should always be carried out after checking the tyre pressure of all four tyres when cold.

In the following situations, the system risk coming into action late or not functioning correctly:

- system not reset after reinflation or any operation on the wheels;
- system badly reset: different inflation pressures from the recommended pressures;

- significant change in load or distribution of load on one side of the vehicle;
- sporty driving with strong acceleration;
- driving on snowy or slippery surface;
- driving with snow chains;
- fitting a single new tyre;
- use of tyres not approved by the network.

The sudden loss of pressure in a tyre (burst tyre, etc.) cannot be detected by the system.

Resetting the standard level for the tyre pressures

This should be done:

- after each re-inflation or resetting of tyre pressure;
- after changing a wheel;
- after changing wheels around.


Tyre pressures must correspond to the current usage of the vehicle (empty, carrying a load, motorway driving, etc.).



This function is an additional driving aid.

The function does not take the place of the driver. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver. Check the tyre pressures, including the emergency spare wheel, once a month.

TYRE PRESSURE LOSS WARNING (3/6)



Resetting procedure

Ignition on, **vehicle stopped**:

- repeatedly tap the **6** switch as many times as necessary to reach the “vehicle” tab ;
- briefly press the **3** or **4** switch to reach the “Tyre pressure init. long press” page;
- press and hold the **5** OK switch to launch the reset.

Hold down the **5** switch until the “Operation completed” message appears. You can now drive.

If the vehicle is equipped with a navigation system, the resetting procedure may also be carried out using the multimedia screen: please see the equipment instructions.

TYRE PRESSURE LOSS WARNING (4/6)

The table below shows the possible messages related to the tyre resetting procedure.

Steps	Messages	Readings
–	Tyre pressure init. at stop	The message is displayed during driving. If you want to reset the pressure of the four tyres, stop the vehicle.
1	Tyre pressure init. long press	To reset the pressure of the four tyres, with the vehicle stopped, press and hold the 5 OK switch to launch resetting until the “If pressure OK [hold on]” message is displayed.
2	If pressure OK [hold on]	The message flashes to indicate that the system has registered the resetting procedure. If all four tyres have been correctly adjusted to match the tyre pressure values recommended on the tyre pressure label ➡ 4.13, press and hold switch 5 OK until the message “Operation completed” appears.
3	Operation completed	The resetting procedure has been completed successfully. You can now drive.

TYRE PRESSURE LOSS WARNING (5/6)

Readjustment of tyre pressures

The pressure of the four tyres must be set when cold (refer to the label located on the edge of the driver's door).

If tyre pressures cannot be checked when the tyres are **cold**, the recommended pressures should be increased by **0.2 to 0.3 bar (3 PSI)**.

Never deflate a hot tyre.

After each reinflation or readjustment of the tyre pressure, launch the reinitialisation of the tyre pressure reference value.

Replacing wheels/tyres

Only use equipment approved by the network, otherwise the system risks late activation or incorrect operation.
➡ 5.13.


After each change of wheel/tyre, readjust the tyre pressure and launch the reset of the tyre pressure reference value.

Emergency spare wheel

If fitted on the vehicle, readjust the tyre pressure and launch the reinitialisation of the tyre pressure reference value.

Tyre repair product and inflation kit

Only use equipment approved by the brand network, or the system risks being activated late or not operating correctly. ➡ 5.5. After using the tyre inflation kit, readjust the tyre pressure and launch the resetting of the tyre pressure reference value.



Tyre pressure faults


The table on the following page lists the warning messages which appear on the instrument panel **7** when the system detects a tyre pressure fault.

TYRE PRESSURE LOSS WARNING (6/6)

The information on the instrument panel signals any potential tyre pressure faults (e.g. deflated or punctured tyre).

Indicator lights	Messages	Readings
	Inflate tyres and init.	This indicates that tyre under-inflation or puncture has been detected. Check and adjust the pressure of the four tyres when cold and reset the system.
	Check tyre press and init.	This indicates that the reset has been unsuccessful. Check and readjust the tyre pressure before re-launching the resetting procedure.
	Check tyre press and init.	This indicates that the last system reset was carried out over 6 months ago or over approximately 6,214 miles (10,000 km). Check and readjust the tyre pressure before re-launching another resetting procedure.
	Check TPW	This indicates a fault in the system. Consult an approved dealer.
	TPW not available	This indicates that an emergency spare wheel different in size to the other four wheels has been fitted to the vehicle. The system remains unavailable until a wheel identical in size to the other wheels has been fitted and the resetting procedure has been carried out.

TYRE PRESSURE MONITOR (1/5)



If the vehicle is equipped with the function, this system monitors the tyre pressure.

Operating principle

Each wheel (except for the emergency spare wheel) has a sensor in the inflation valve which periodically measures the tyre pressure.

The system displays the current pressures on the instrument panel **1** and alerts the driver in the event of insufficient pressure.

Resetting the standard level for the tyre pressures

This should be done:


- when the standard tyre pressure needs to be changed to adapt to usage conditions (empty, carrying a load, motorway driving, etc.);
- after swapping a wheel (however this practice is not recommended);
- after changing a wheel.

It should always be done after checking the tyre pressure of all four tyres when cold.

Tyre pressures must correspond to the current usage of the vehicle (empty, carrying a load, motorway driving, etc.).

If the vehicle is equipped with a navigation system, the resetting procedure may also be carried out using the multimedia screen: please see the equipment instructions.

TYRE PRESSURE MONITOR (2/5)



Resetting procedure

Ignition on, **vehicle stopped**:

- repeatedly tap the **5** switch as many times as necessary to reach the “vehicle” tab ;
- briefly press the **2** or **3** switch to reach the “Tyre Pressure” page;

- press and hold (around 3 seconds) the button **4** to launch the reset. The flashing tyres followed by the messages “Learning Tyre Pressures” and then “Tyres location in progress” indicates that the reset request for the tyre pressure reference value has been acknowledged.

Reset can take several minutes of driving.

If the resetting is followed by short trips, the message “Tyres location in progress” can remain displayed after successive restarts.

Note: the standard tyre pressure cannot be less than that recommended and indicated on the door frame.



For your safety, the warning light **STOP** requires you to stop immediately as soon as traffic conditions allow.

TYRE PRESSURE MONITOR (3/5)

The table below shows the possible messages related to the tyre resetting procedure.

Steps	Displays (depending on the vehicle)	Messages	Readings
1		Tyre pressure init. long press	With the ignition on and the vehicle stationary, start the resetting the pressure of all four tyres by pressing and holding the 4 OK switch.
2		Learning Tyre Pressures	The “---” quote marks in front of each wheel will flash to indicate that the system has registered the tyre pressure reset for all four wheels.
3		Tyres location in progress	The “---” quote marks in front of each wheel will remain lit. This system resets the tyre pressure of all four tyres. You can now drive. The message may remain displayed during short journeys. Note: during the reset, tyre pressure monitoring remains in operation.
4			The pressure value of the four tyres is displayed: the re-setting procedure is complete and successful.

TYRE PRESSURE MONITOR (4/5)

Readjustment of tyre pressures

The pressure of the four tyres must be set when cold (refer to the label located on the edge of the driver's door). If the tyre pressures cannot be checked when the tyres are cold, the recommended pressures should be increased by 0.2 to 0.3 bar (3 PSI). **Never deflate a hot tyre.**

Emergency spare wheel

If the vehicle is equipped with an emergency spare wheel, it will not have a sensor.



This function is an additional driving aid.

The function does not take the place of the driver. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver. Check the tyre pressures, including the emergency spare wheel, once a month.

Replacing wheels/tyres


This system requires specific equipment (wheels, tyres, hubcaps, etc.). ➔ 5.13.

Contact an approved Dealer to fit new tyres and to find out about available accessories compatible with the system and available from your dealer network: the use of any other accessory could affect the correct operation of the system or damage a sensor.



Changing a wheel

The system may take several minutes depending on use for the new wheel positions and pressures to be recognised; check the tyre pressures after all operations.



Tyre repair product and inflation kit

Because the valves are specially designed, only use equipment approved by the approved network. Please see the section on ➔ 5.5.

Tyre pressure faults

The table on the following page lists the warning messages which appear on the instrument panel **1** when the system detects a tyre pressure fault.

TYRE PRESSURE MONITOR (5/5)

The information on the instrument panel signals any potential tyre pressure faults (e.g. deflated or punctured tyre). For your safety, the warning light **STOP** requires you to stop immediately as soon as traffic conditions allow.

Indicator lights	Messages	Displays (depending on the vehicle)	Readings
	Adjust Tyre Pressure		The wheel and associated pressure value are displayed in yellow. This indicates that tyre under-inflation has been detected. Check and adjust the pressure of the four tyres then reset the system.
	Puncture		The wheel and associated pressure value are displayed in red. This indicates that the tyre concerned is punctured or severely underinflated. Adjust the pressure of the four tyres while cold and reset the system if the tyre is deflated. Replace the tyre (or have it replaced) if it is punctured.
	Check Tyre Pressure Sensors		A wheel is no longer displayed. This indicates that at least one wheel is not fitted with a sensor (e.g. emergency spare wheel) or that the sensor is faulty. Consult an approved dealer.
	Tyre Detection Failure		This indicates that the system has not been able to determine the pressure of each tyre. This may be caused by the use of a sensor not recommended by an approved dealer. The tyre pressure sensor monitoring system remains in operation.

DRIVER CORRECTION DEVICES AND AIDS (1/6)

Depending on the vehicle, this is composed of:

- **ABS (anti-lock braking system);**
- **ESC (electronic stability control) with understeer control and traction control;**
- **emergency brake assist;**
- **hill start assistance;**
- **rear wheel steering.**

Other driving assistance systems are detailed on the following pages.

ABS (anti-lock braking system)

Under heavy braking, the ABS prevents the wheels from locking, allowing the stopping distance to be managed and keeping control of the vehicle.

Under these circumstances, the vehicle can be steered to avoid an obstacle whilst braking. In addition, this system can increase stopping distances, particularly on roads with low surface grip (wet ground etc.).

You will feel a pulsation through the brake pedal each time the system is activated. The ABS does not in any way improve the vehicle's physical performance relating to the road surface and roadholding. It is still **essential** to follow the rules of good driving practice (such as driving at a safe distance from the vehicle in front etc.).

In an emergency, apply **firm and continuous pressure** to the brake pedal. There is no need to pump it repeatedly. The ABS will modulate the force applied in the braking system.



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions.

These functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

DRIVER CORRECTION DEVICES AND AIDS (2/6)

Operating faults:

-  and  lit up on the instrument panel accompanied by the messages “Check ABS”, “Check braking system” and “Check ESC”: this indicates that the ABS, the ESC and the emergency brake assist are disabled. **Braking is always enabled;**
- , ,  and **STOP** lit on the instrument panel accompanied by the message “Braking system fault”: **this indicates a fault with the braking system.**

In both cases, consult an approved dealer.



Warning light **STOP** requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Contact an approved Dealer.



Your braking systems are partially operational. However, it is **dangerous to brake suddenly** and it is essential to stop immediately, as soon as traffic conditions allow. Contact an approved dealer.

DRIVER CORRECTION DEVICES AND AIDS (3/6)

Electronic stability control ESC with understeer control and traction control

Electronic stability control ESC

This system helps you to keep control of the vehicle in critical driving conditions (avoiding an obstacle, loss of grip on a bend, etc.).

Operating principle

A sensor in the steering wheel detects the direction selected by the driver.

Other sensors throughout the vehicle measure the actual direction.

The system compares driver input to the actual trajectory of the vehicle and corrects the trajectory if necessary by controlling the braking of certain wheels and/or engine power. In the event that the system is engaged, indicator light



flashes on the instrument panel.

Understeer control

This system optimises the action of the ESC in the case of pronounced understeer (loss of front axle road holding).

Traction control

This system helps to limit wheelspin of the drive wheels and to control the vehicle when pulling away accelerating or decelerating.

Operating principle

Using the wheel sensors, the system measures and compares the speed of the drive wheels at all times and slows down their over-rotation. If a wheel is starting to slip, the system brakes automatically until the drive supplied becomes compatible with the level of grip under the wheel again.

The system also adjusts the engine speed to the grip available under the wheels, independently of the pressure exerted on the accelerator pedal.

In some situations (driving on very wet ground: snow, mud, etc. or driving with snow chains fitted), the system may reduce the engine output to limit wheelspin.

Operating faults

When the system detects an operating fault the message "Check ESC" and

warning light  and  appear on the instrument panel.

In this case, the ESC and traction control system are deactivated. Consult an authorised dealer.

DRIVER CORRECTION DEVICES AND AIDS (4/6)

Emergency brake assist

This system supplements the ABS and helps reduce vehicle stopping distances.

Operating principle

The system is for detecting an emergency braking situation. In this case, the braking assistance immediately develops maximum power and may trigger ABS regulation.

ABS braking is maintained as long as the brake pedal is applied.

Brake lights come on

Depending on the vehicle, these may flash in the event of sudden deceleration.

Braking anticipation

Depending on the vehicle, when you rapidly release the accelerator, the system anticipates the braking manoeuvre in order to reduce stopping distances.

Special cases

When using the cruise control:

- if you use the accelerator, when you release it, the system may be triggered;
- if you do not use the accelerator, the system will not be triggered.

Operating faults

When the system detects an operating fault the message “Check braking system” appears on the instrument panel along with the  warning light.

Consult an approved dealer.



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions.

These functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

DRIVER CORRECTION DEVICES AND AIDS (5/6)

Hill start assistance

Depending on the gradient of the incline, this system assists the driver when starting on a hill. It prevents the vehicle from rolling backwards by automatically applying the brakes when the driver lifts his/her foot off the brake pedal to depress the accelerator pedal.

System operation

It only operates when the gear lever is in a position other than neutral (other than **N** or **P** for automatic transmissions) and the vehicle is completely stationary (brake pedal depressed)

The system holds the vehicle for approximately **2 seconds**. The brakes are then released (the vehicle will move according to the slope).



The hill start assistance system cannot completely prevent the vehicle from rolling backwards in all situations (extremely steep gradients, etc.).

In all cases, the driver may depress the brake pedal to prevent the vehicle from rolling backwards.

The hill start assistance function should not be used for prolonged stops: use the brake pedal.

This function is not designed to immobilise the vehicle permanently.

If necessary, use the brake pedal to stop the vehicle.

The driver must remain particularly vigilant when driving on slippery or low-grip surfaces.

Risk of serious injury.

DRIVER CORRECTION DEVICES AND AIDS (6/6)

A

48108



Rear wheel steering

On equipped vehicles, this system, when the vehicle is being driven, steers the rear wheels according to driving conditions: at low speed this system offers manoeuvrability, at higher speeds it optimises stability.

When driving at low speeds, the rear wheels steer in the opposite direction to the front wheels (figure **A**) to increase the vehicle's manoeuvrability. This is used when driving in towns, on winding roads, during parking manoeuvres, etc.

B

48105



When driving at higher speeds, the rear wheels steer in the same direction as the front wheels (figure **B**) to optimise the vehicle's stability. This is useful when changing lanes or when cornering etc.

Note: the system configuration (responsiveness etc.) depends on the mode selected in the "MULTI-SENSE" menu ➔ 3.2.

Operating faults

- If the  warning light, together with the message "Check power steering", is displayed on the instrument panel: please contact an authorised dealer.
- If the warning light , together with the message "WARNING: Steering Fault", is displayed on the instrument panel, **this indicates a fault in the system.**




STOP requires you to stop as soon as traffic conditions allow. Contact an approved Dealer.

An impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g.: deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.

LANE DEPARTURE WARNING (1/5)



Using information from the **1** camera, the function warns the driver when a continuous or broken line is crossed or when approaching the roadside (divider, barrier, pavement, embankment, etc.) without the direction indicator lights being activated.


Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The lane departure warning function does not correct the vehicle's trajectory.

LANE DEPARTURE WARNING (2/5)



Activation/deactivation

To activate the function, press the **2** switch as many times as required to select “Lane Departure Warning” on the instrument panel. The “Lane departure warning on” message and “” warning light are displayed on the instrument panel.

To disable the function, press the **2** switch as many times as required to select “Lane departure warning off” (or, depending on the vehicle “Lane Keeping deactivated”) on the instrument panel. Warning light  goes out on the instrument panel.


Operation

When the function is activated, the  warning light and the left and right lines **3** are displayed in grey on the instrument panel.

The function is set to notify the driver if:

- speed is between approximately 43 mph (70 km/h) and 112 mph (180 km/h); and
- the  warning light and left/right line indicators **3** are coloured white.

The warning function is triggered if the vehicle breaches a line or approaches a roadside (divider, barrier, pavement, embankment, etc.) without the direction indicator lights being activated.



The function alerts the driver:

- by a vibration in the steering wheel; and
- the  warning light and **3** the indicator for the crossed line turn red.

Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

LANE DEPARTURE WARNING (3/5)

Temporarily not available

- Very fast lane departure;
- driving continuously on a line;
- four seconds approximately after changing lanes;
- tight bends;
- impaired visibility;
- activation of one of the direction indicator lights;
- strong acceleration;
- ...

When the function is not available, the



warning light and the left/right indicators turn to grey on the instrument panel.

Conditions for non-activation of the system

The system cannot be activated when:

- reverse gear is engaged;
- the field of vision of the camera is obstructed;
- the **STOP** warning light is displayed.


The  warning light and the left/right line indicators turn to grey on the instrument panel.

Settings

Vehicles fitted with a multimedia screen.


To access the multimedia screen function settings **4**, refer to the multimedia instructions:

- “Vibration”: adjust the steering wheel vibration level;



- “Alert”: adjust the line detection sensitivity level. To do this, select:
 - “Late”: line detected when crossing;
 - “Standard”: line detected on approach;
 - “Early”: line detected nearby.

LANE DEPARTURE WARNING (4/5)



Adjustments (continued)

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **5** as many times as required to reach the “Vehicle” tab;
- press the **6** or **7** control repeatedly to reach the “Settings” menu. Press the switch **8 OK**;

- press the **6** or **7** control repeatedly to reach the “DRIVING ASSIST” menu. Press the switch **8 OK**;
- press the **6** or **7** control repeatedly to reach the “Lane Departure Vibration” or “Lane Departure Sensitivity” menu. Press the switch **8 OK**;
- press the **6** or **7** control repeatedly to adjust the setting. Press **8 OK**.

Operating faults

In the event of a malfunction, the left and right line indicators (and, depending on display style, the  warning light) disappear or stay grey on the instrument panel.

In some cases, they are accompanied by the message “Front camera to check” or the  warning light on the instrument panel.

Consult an approved dealer.

LANE DEPARTURE WARNING (5/5)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

System servicing/repairs

- In the event of an impact, the camera alignment may be changed, and its operation may consequently be affected. Deactivate the function, then consult an authorised dealer.
- Any work in the area where the camera is located (repairs, replacements, windscreen modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance


Some conditions can disrupt or damage the operation of the system, for example:

- windscreen obscured (by dirt, ice, snow, condensation etc.);
- a complex environment (tunnel etc.);
- poor weather conditions (snow, hail, black ice etc.);
- poor visibility (night, fog etc.);
- the road markings are irregular or difficult to distinguish (e.g. partially erased, excessive spacing, distorted road surface) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding or undulating (tight bends etc.);
- closely following a vehicle travelling in the same lane.

Risk of false alarms or absence of warnings

LANE KEEPING ASSIST (1/6)

48137



Using information from the **1** camera, the function triggers corrective action on the vehicle steering system when a continuous or broken line is crossed or when approaching the roadside (divider, barrier, pavement, embankment, etc.) without the direction indicator lights being activated.


You can **retake control of the vehicle** at any time by operating the steering wheel.

Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

LANE KEEPING ASSIST (2/6)



Activation/deactivation

To activate the function, press the **2** switch as many times as required to select “Lane Keeping Assist” on the instrument panel.

The “Lane Keeping activated” message and “” warning light are displayed on the instrument panel.

When Lane Keeping Assist is activated, the “Lane Departure Warning” function is automatically activated. ➔ 2.49.


To disable the function, press the **2** switch as many times as required to select “Lane Keeping deactivated” on the instrument panel.

Warning light  goes out on the instrument panel.

Note: deactivating the “Lane Keeping Assist” function causes deactivation of the “Lane Departure Warning” function.

Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

LANE KEEPING ASSIST (3/6)



Operation

When the function is activated, the  warning light and the left and right lines **3** are displayed in grey on the instrument panel.

The function is set to operate when the vehicle speed is between approximately 43 mph (70 km/h) and 112 mph (180 km/h) and if the  warning light and **3** correction indicators are coloured white.

The function operates if the vehicle breaches a line or if the vehicle approaches the roadside (divider, barrier, pavement, embankment, etc.) without the direction indicator lights being activated.

In these cases:

- the function triggers an action on the vehicle's steering system to correct the vehicle trajectory;
- the warning light  and the indicator **3** on the side of the breached line turns to yellow on the instrument panel.

Note: on bends, the function allows for slightly cutting the bend.

If the corrective action on the steering system is not sufficient, the  warning light and **3** indicator on the side of the breached line turn to red on the instrument panel, accompanied by a vibration on the steering wheel.

Special cases

When using the function:

- If the system can no longer detect any action by the driver on the steering wheel, the  warning light appears in yellow on the instrument panel, accompanied by the message "Keep hands on steering wheel" and an audible warning.
- The audible warning is emitted along with the warning light and message until the driver takes control;
- if the system is active for too long, an audible warning is emitted along with flashing of the side indicators **3** on the side of the vehicle concerned until the driver takes control.

You can interrupt the trajectory correction at any time by moving the steering wheel.

LANE KEEPING ASSIST (4/6)

Temporarily not available

- Very fast lane departure;
- driving continuously on a line;
- four seconds approximately after changing lanes;
- tight bends;
- impaired visibility;
- activation of one of the direction indicator lights;
- strong acceleration;
- emergency braking;
- ...

If the function is unavailable, the  warning light and the left/right correction warning lights **3** appear in grey on the instrument panel.

Conditions for non-activation of the system

The system cannot be activated when:

- reverse gear is engaged;
- the field of vision of the camera is obstructed;
- the **STOP** warning light is displayed.


The  warning light and the left/right line warning lights are displayed in grey on the instrument panel.

Adjustment

Vehicles fitted with a multimedia screen.

To access the function settings from the multimedia screen **4** please refer to the multimedia instructions:


- “Vibration”: adjust the steering wheel vibration level;



- “Alert”: adjust the line detection sensitivity level. To do this, select:
 - “Late”: line detected when crossing;
 - “Standard”: line detected on approach;
 - “Early”: line detected nearby.

Please refer to the multimedia instructions for further information.

LANE KEEPING ASSIST (5/6)



Adjustments (continued)

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **5** as many times as required to reach the “Vehicle” tab;
- press the **6** or **7** control repeatedly to reach the “Settings” menu. Press the switch **8 OK**;

- press the **6** or **7** control repeatedly to reach the “DRIVING ASSIST” menu. Press the switch **8 OK**;
- press the **6** or **7** control repeatedly to reach the “Lane Keeping sensitivity=#” menu. Press the switch **8 OK**;
- press the **6** or **7** control repeatedly to adjust the setting. Press **8 OK**.

Operating faults

When the system detects an operating fault, the  warning light appears on the instrument panel along with the message “Front camera to check”.

Consult an approved dealer.

LANE KEEPING ASSIST (6/6)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

System servicing/repairs

- In the event of an impact, the camera alignment may be changed, and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the camera is located (repairs, replacements, windscreen modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance

Some conditions can disrupt or damage the operation of the system, for example:

- windscreen obscured (by dirt, ice, snow, condensation etc.);
- a complex environment (tunnel etc.);
- poor weather conditions (snow, rain, hail, black ice etc.);
- poor visibility (night, fog etc.);
- the road markings are irregular or difficult to distinguish (e.g. partially erased, excessive spacing, distorted road surface);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding or undulating (tight bends etc.);
- closely following a vehicle travelling in the same lane.

In this case, the “Lane Keeping Assist” may react incorrectly or not at all.


Risk of unwanted, incorrect correction or no correction of trajectory.

Deactivating the function

You must disable the function if:

- the area of the camera has been damaged (on the windscreen side or the interior rear-view mirror side);
- the road is slippery (snow, black ice, aquaplaning, gravel etc.) ;
- poor visibility (night, fog etc.);
- the windscreen is cracked or distorted (do not carry out windscreen repairs in this area; have it changed by an Authorised Dealer);
- the vehicle is towing a trailer or a caravan;
- the vehicle is entering an area with several surface markings (an area with road works etc.).

BLIND SPOT WARNING (1/7)




Using information from the sensors installed on each side of the rear bumper (area **C**), the function warns the driver:

- when another vehicle appears in the detection area **A**;


and/or

- when there is a risk of collision with a vehicle that is in area **B**, driving faster than you.

The function warns you when the vehicle is travelling at a speed above approximately 9 mph (15 km/h).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.



Special feature

Make sure that the radar area **C** is not obscured (by stickers, mud, snow etc.).

If a radar is obscured, the message “Side radars no visibility” will appear on the instrument panel. Clean the area where the sensors are located.

BLIND SPOT WARNING (2/7)




Activation/deactivation

Vehicles fitted with a multimedia screen 1

To activate or deactivate the function, refer to the multimedia instructions. Select "ON" or "OFF".

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **2** as many times as required to reach the "Vehicle" tab;



- press the **3** or **4** control repeatedly to reach the "Settings" menu. Press the switch **5 OK**;
- press the **3** or **4** control repeatedly to reach the "DRIVING ASSIST" menu. Press the switch **5 OK**;
- press the **3** or **4** control repeatedly to reach the "Blind spot alert" menu and press **5 OK**;

- press the switch **5 OK** again to activate or deactivate the function:




function activated



function deactivated

The system's detection range operates according to a standard lane width. When driving in a narrow lane, the function may warn you when a vehicle is detected further away than the nearest lane.


BLIND SPOT WARNING (3/7)



Indicator 6

An indicator light **6** is located on each rear view mirror **7**.

Note: clean the rear view mirrors **7** regularly so that the indicators **6** can be seen.




Operation

The function warns you when the speed of your vehicle exceeds approximately 9 mph (15 km/h):


- when another vehicle is in the blind spot area **A** and travelling in the same direction as your vehicle;
- when a vehicle approaches quickly from the rear in an adjacent lane within the range of detection area **B**.

If you overtake another vehicle, the indicator **6** will only come on if that vehicle remains for a long enough period in your vehicle's blind spot **A**.



The function does not notify the driver if the other vehicles are not moving.

BLIND SPOT WARNING (4/7)



Display D

First warning: **direction indicator not activated**, the **6** warning light indicates that a vehicle is detected in the blind spot area and/or that a vehicle is rapidly approaching from the rear in an adjacent lane.

When the engine is started, the system adopts the last status saved before the ignition was switched off (refer to the previous pages).

Display E

Direction indicator activated, the **6** warning light flashes when the function detects a vehicle in the blind spot warning area and/or a vehicle is rapidly approaching from the rear on the side towards which you will turn the wheel. If you cancel the direction indicator, the function will return to the initial warning (display **D**).

Conditions for non-function

- When driving on a road with tight bends;
- in reverse.

If the vehicle is equipped with a towbar recognised by the system, the “Trailer: blind spot alert off” message displayed on the instrument panel informs you that the function is not operational. For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.

BLIND SPOT WARNING (5/7)

Operating faults

If the system detects a fault, the message “Side radars to check” is displayed on the instrument panel. Consult an approved dealer.

Due to the presence of sensors behind the bumper, it is advisable to entrust any operation on the bumper (repair, replacement, paintwork, etc.) to a qualified professional.



- The system's detection range operates according to a standard lane width. If you are driving in wide traffic lanes, the system might not be able to detect a vehicle in the blind spot.
- The system might be disrupted momentarily if it is exposed to strong electromagnetic waves (as beneath high-tension power lines) or to very poor weather conditions (heavy rain, snow etc.). Remain aware of driving conditions.

There is a risk of accidents.

BLIND SPOT WARNING (6/7)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.

The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

System servicing/repairs

- In the event of an impact, radar alignment may be changed, and its operation will consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the radars are located (repairs, replacements, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

System disturbance

Some conditions can disturb or damage the operation of the system, such as:

- complex surroundings (metal bridges, tunnels, roads with barriers at the edge, etc.);
- poor weather conditions (snow, hail, black ice, etc.).

Risk of false alarms or absence of warnings

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

BLIND SPOT WARNING (7/7)



Limitation of the system operation

- The radar area should be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects moving close to the vehicle (motorcycles, bicycles, pedestrians, etc.) may not be recognised by the system.
- When turning into a bend, the radars may temporarily cease to detect vehicles in adjacent lanes.
- The function may warn you late when two other vehicles are approaching from the rear, side by side in the adjacent lanes (driving on a 3-lane road) and at a much higher speed than your vehicle.
- The system may not provide a warning when the other vehicles are travelling at a significantly different speed.
- If the vehicle is being overtaken by a long vehicle (e.g. heavy goods vehicle overtaking at a similar speed to the vehicle) the system may interrupt the warning before the end of the manoeuvre.
- The vehicle is travelling on a winding road.


Deactivating the function

You must disable the function if:

- the radar area has been damaged (rear bumper);
- the vehicle is fitted with a towbar that is not recognised by the system.

SAFE DISTANCE ALERT (1/4)

48207



Using the information from the radar **2** and camera **1**, this function informs the driver of the time interval between their vehicle and the vehicle in front so that a safe stopping distance between the two vehicles can be maintained.

The function is activated when the vehicle speed is between about 19 and 124 mph (30 and 200 km/h).

Location of the camera **1**

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).


Location of the radar **2**

Ensure that the radar area is not obstructed (by dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.


SAFE DISTANCE ALERT (2/4)



Activating/deactivating the function

Vehicles fitted with a multimedia screen 3

To activate or deactivate the function, refer to the multimedia instructions. Select "ON" or "OFF".



Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **4** as many times as required to reach the "Vehicle" tab;
- press the **5** or **6** control repeatedly to reach the "Settings" menu. Press the switch **7 OK**;
- press the **5** or **6** control repeatedly to reach the "DRIVING ASSIST" menu. Press the switch **7 OK**;

- press the **5** or **6** control repeatedly to reach the "Distance warning" menu. Press the switch **7 OK**;
- press the switch **7 OK** again to activate or deactivate the function:




function activated



function deactivated

Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

SAFE DISTANCE ALERT (3/4)



Operation

With the function activated, the **8** indicator is displayed on the instrument panel and informs the driver of the distance between their vehicle and the vehicle in front.

- **A** (grey): function not operational;
- **A** (green): no vehicle detected;
- **B** (green): the time interval is greater than or equal to around two seconds (distance between the two vehicles adapted to your speed);

- **C** (orange): the time interval falls between around 1 and 2 seconds (insufficient distance between the two vehicles);
- **D** (red): the time interval is less than or equal to around one second (very insufficient distance between the two vehicles).

If the interval between the two vehicles is less than approximately 0.5 seconds, the **8** indicator and the **D** display will flash in red on the instrument panel along with “-.- s”.

Under certain conditions, the time interval may not be displayed:

- while cornering;
- when changing lane;
- if the vehicle in front is sufficiently far or outside the range of the radar or camera.



The measurement is displayed for information: the system does not carry out any action on the vehicle.

This function is not designed for use in urban conditions or for a dynamic driving style (sudden cornering, acceleration, braking, etc.), but rather for stable driving conditions.

The function does not interact with the braking system.

The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

Any work carried out in the area where the radar or camera is located (repairs, replacements, windscreen and/or bumper modifications, etc.) must be carried out by a qualified professional.

SAFE DISTANCE ALERT (4/4)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work carried out in the area where the radar and/or camera is located (replacements, repairs, windscreen and/or bumper modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.


In the event of system disturbance

- obstruction of the windscreen or the bumper (by dirt, glass, snow, condensation, etc.);
- a complex environment (metal bridge, tunnel etc.);
- poor weather conditions (snow, hail, black ice etc.);
- poor visibility (night, fog etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area etc.) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding and undulating (tight bends etc.)

Risk of erroneous false alarms.

ACTIVE EMERGENCY BRAKING (1/8)

48207



The system uses information from the radar **2** and the camera **1** to determine the distance from your vehicle:

- from the vehicle ahead in the same lane;
- surrounding pedestrians and cyclists.

The system informs the driver if there is a risk of head-on collision to enable appropriate emergency manoeuvres (pressing the brake pedal and/or turning the steering wheel).

Depending on the reactivity of the driver, the system can assist with braking in order to limit damage or prevent a collision.

Location of the camera 1

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

Location of the radar 2

Ensure that the radar area is not obstructed (by dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).

This system can apply maximum braking to the vehicle until it is completely stationary if necessary.

For safety reasons, always wear your seat belt when travelling in your vehicle and make sure that it is loaded so that no items can be thrown forward and hit the occupants.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

ACTIVE EMERGENCY BRAKING (2/8)

Operation

Detection of vehicles

When driving, in the event of a risk of collision with the vehicle in front the system will:

- **warn of the risk of collision:** when the vehicle speed is between 4 mph (7 km/h) and 106 mph (170 km/h), the message “Brake” is displayed in red on the instrument panel **3** accompanied by an audible warning.

If the driver presses the brake pedal and the system still detects a risk of collision, the brake force is increased;

- **braking may be triggered:** when the vehicle is moving slower than approximately 75 mph (120 km/h), if the driver does not respond to the warning and a collision becomes imminent.



If the vehicle stopped as a result of active emergency braking, the driver must keep the vehicle stationary by applying the brake pedal.

Note: if the driver uses the vehicle controls (steering wheel, pedals, etc.) the system may delay certain operations or not activate.

Special features of warnings

Depending on the speed, the warning and braking may be activated simultaneously.

Special features of stationary vehicles

Stationary vehicles are detected when your vehicle is being driven at a speed between approximately 4 mph (7 km/h) and 50 mph (80 km/h). The system is not active and does not emit a warning for stationary vehicles when you exceed approximately 50 mph (80 km/h).

In the event of emergency manoeuvre, you can stop braking at any moment by:

- tapping the accelerator pedal;
- or
- turning the steering wheel as a collision avoidance manoeuvre.

ACTIVE EMERGENCY BRAKING (3/8)

Detection of pedestrians and cyclists


(depending on the vehicle)

When there is a risk of collision with a cyclist or pedestrian while the vehicle is moving, the system will:

- **warn of the risk of collision:** when the vehicle speed is between 4 mph (7 km/h) and 50 mph (80 km/h), the message “Brake” is displayed in red on the instrument panel **3** accompanied by an audible warning.

If the driver presses the brake pedal and the system still detects a risk of collision, the brake force is increased;

- **trigger braking:** if the driver does not respond to the warning and the collision becomes imminent.



If the vehicle stopped as a result of active emergency braking, the driver must keep the vehicle stationary by applying the brake pedal.

Note: if the driver uses the vehicle controls (steering wheel, pedals, etc.) the system may delay certain operations or not activate.


Special features of warnings

Depending on the speed, the warning and braking may be activated simultaneously.

In the event of emergency manoeuvre, you can stop braking at any moment by:

- tapping the accelerator pedal;
- or
- turning the steering wheel as a collision avoidance manoeuvre.

ACTIVE EMERGENCY BRAKING (4/8)




Activating or deactivating the system

Vehicles fitted with a multimedia screen 4

To activate or deactivate the function, please refer to the multimedia instructions.

Select "ON" or "OFF".



For vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch 5 as many times as required to reach the "Vehicle" tab;
- press the 6 or 7 control repeatedly to reach the "Settings" menu. Press the switch 8 OK;
- press the 6 or 7 control repeatedly to reach the "DRIVING ASSIST" menu. Press the switch 8 OK;

- press the 6 or 7 control repeatedly to reach the "Active braking" menu and press the 8 OK switch.

Press the switch 8 OK again to activate or deactivate the function:



function activated



function deactivated

Upon deactivation of the system, the



warning light illuminates or, de-

pending on the vehicle, the  warning light illuminates on the instrument panel.

This system is reactivated each time the ignition is switched on.

ACTIVE EMERGENCY BRAKING (5/8)

Temporarily not available

If the system detects a temporary fault the  warning light illuminates, or depending on the vehicle the  warning light illuminates on the instrument panel.

The possible causes are:

- the system is temporarily blinded (glare from the sun, dipped beam headlights, bad weather conditions etc.). The system will be operational again when visibility conditions are better;
- the system is temporarily interrupted (e.g. the windscreen or the front or rear bumper is obscured by dirt, mud, snow, condensation, etc.). In this case, park the vehicle and switch off the engine. Clean the windscreen and front bumper. When you next start the engine, the warning light and the message go out.

If this is not the case, this may arise from another cause; contact an Approved Dealer.

Operating faults

 and  or, depending on the vehicle,  illuminated on the instrument panel indicate that the system has detected an operating fault. Consult an approved dealer.

ACTIVE EMERGENCY BRAKING (6/8)



Active emergency braking

This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle. The triggering of this function may be delayed or prevented when the system detects clear signs of control of the vehicle by the driver (action on the steering wheel, pedals etc.).

The system cannot be activated:

- when the gearbox lever is in neutral or the clutch pedal has been depressed during approximately ten seconds;
- when the parking brake is activated;
- when the Electronic Stability Program (ESC) has started.

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the radar and/or camera is located (repairs, replacements, windscreen modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

ACTIVE EMERGENCY BRAKING (7/8)



System disturbance

Some conditions can disturb or damage the operation of the system, such as:

- a complex environment (metal bridge, tunnel etc.);
- poor weather conditions (snow, hail, black ice etc.);
- poor visibility (night, fog etc.);
- poor contrast between an object (vehicle, pedestrian etc.) and the surrounding area (e.g. pedestrian dressed in white located in a snowy area);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- obstruction of the windscreen or the radar area (by dirt, ice, snow, condensation etc.);
- ...

In these conditions, the system may not react, may warn the driver or may brake inadvertently.

Limitation of the system operation

- Each time the vehicle is started, the system carries out a calibration according to the vehicle surroundings and may be inactive for a length of time between approximately two and five minutes;
- a vehicle moving in the opposite direction will not trigger any alert or affect operation of the system;
- the radar and camera zones must be kept clean and free of any modifications in order to ensure the proper operation of the system;
- the system may not respond to small vehicles such as motorbikes as effectively as to other vehicles;
- the system may not operate properly when the road surface is slippery (rain, snow, black ice, etc.);
- to ensure correct operation, the system needs to distinguish the complete outline of the pedestrian. So the system cannot detect:
 - pedestrians in the darkness or in poor lighting conditions;
 - partially visible pedestrians:
 - pedestrians less than approximately 80 cm tall;
 - pedestrians carrying large objects;
 - ...

In these conditions, the system may not react, may warn the driver or may brake inadvertently.

ACTIVE EMERGENCY BRAKING (8/8)



Deactivating the function

You must disable the function if:

- the brake lights are not functioning;
- the area of the camera has been damaged (e.g. on the inside or outside of the windscreen);
- the front of the vehicle was damaged (impact, scratch on the radar, etc.);
- the vehicle is being towed (breakdowns);
- the windscreen is cracked or distorted (do not carry out windscreen repairs in this area; have it changed by an approved dealer);
- you are not driving on a paved road.

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

Halting the function

You can halt the active emergency braking function at any time by tapping the accelerator pedal or by turning the steering wheel in an avoidance manoeuvre.

FATIGUE DETECTION WARNING (1/2)

The fatigue detection warning is a function which is useful on monotonous roads (motorways, high-speed roads etc.).


It analyses driver behaviour and takes account of events to inform you of any risk of fatigue such as:

- steering wheel movement;
- driver actions on other devices (indicators, windscreen washer etc.);
- time spent driving without stopping;
- ...



This function is an additional driving aid in case of risk of fatigue. This function does not take the place of the driver.

Under no circumstances should this function replace the driver's care or responsibility whilst driving.



Activation/deactivation


Vehicles fitted with a multimedia screen 1

To activate or deactivate the function, refer to the multimedia instructions.

Select ON or OFF.

When the engine is started, the system remembers its position when the ignition was last switched off.

FATIGUE DETECTION WARNING (2/2)



Vehicles not fitted with a multimedia screen

- With the vehicle at a standstill, press and hold the switch **2 OK** to access the settings menu;
- repeatedly press the control **3** up or down until you reach the “Driving assistance” menu. Press the switch **2 OK**;

- repeatedly press the control **3** up or down until you reach the “Fatigue detection warning” menu, then press the switch **2 OK**.
- press the **2 OK** switch again to activate or deactivate the function.

Operation

The function is set to notify the driver if:

- the vehicle speed is greater than approximately 37.2 mph (60 km/h); and
- Approximately 15 minutes have passed since the deletion of the previous warning.

The function triggers an alert if the system detects repeated signs of fatigue in the driver at the steering wheel.

When a risk of fatigue is detected, the message “Fatigue warning have a break” is displayed on the instrument panel accompanied by a beep.

Press switch **2 OK** to delete the warning.

It is advisable to stop as soon as possible for a break.

Note:


- if the warning is not deleted by pressing switch **2 OK**, the beep repeats;
- the function may interpret certain driving styles as a sign of tiredness (sporty driving, incorrect driving etc.) or driving along a road which is in poor condition.

Operating faults

If the system detects a fault, the message “Check fatigue warning” is displayed on the instrument panel. Call an approved Dealer.

DETECTION OF ROAD SIGNS (1/4)

48137



The system detects speed limit signs on the side of the road and displays the speed limit on the instrument panel.

It mainly uses information taken from the camera **1**, attached to the windscreen behind the rear view mirror.

Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).

For vehicles which are equipped with it, the system also uses information from the navigation system.

Once the speed limiter is activated, you can adjust the speed limiter indication displayed by the system.

If the limit speed is exceeded, the display panel is modified to warn the driver.

For vehicles equipped with a navigation system and if the vehicle is travelling in a country where the speed units differ from those of the vehicle, the system displays the speed limit sign in the unit of the country, alongside the speed limit converted to the unit used by the vehicle's instrument panel.

For countries where the speed limit is reduced during rainy weather on some types of roads, on vehicles equipped with a navigation system, the system can modify the limited speed after a few seconds of wiping the windscreen.

Special situations

The system does not take into account exceptional speed limit measures, such as peak pollution days.

DETECTION OF ROAD SIGNS (2/4)




Activating/deactivating the system

Vehicles fitted with a multimedia screen 2

To activate or deactivate the function, refer to the multimedia instructions.

Select "ON" or "OFF".



With the function activated, depending on local regulations, you can activate the "Risk area display" option. The system will notify you of the distance separating you from this zone, and while you are travelling in the zone.

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **3** as many times as required to reach the "Vehicle" tab;

- press the **4** or **5** control repeatedly to reach the "Settings" menu and press **6 OK**;
- press the **4** or **5** control repeatedly to reach the "DRIVING ASSIST" menu and press **6 OK**;
- press the **4** or **5** control repeatedly to reach the "Speed alert" menu and press **6 OK**;
- press the **6 OK** switch to activate or deactivate the function:




function activated



function deactivated

DETECTION OF ROAD SIGNS (3/4)




If the speed limit is exceeded, the circle around the road sign symbol **7** flashes along with a sound signal to warn the driver (depending on the vehicle).

Operation

Warning lights

The function displays the following warning lights:

- **7** Speed limit road signs.
- **8** Additional road signs (start or end of “No overtaking” zone, slip road speed limit, speed in case of a caravan, speed limit with length of application, etc.).



Varying the limit speed

If the speed limit notification differs from the detected speed value, press and hold the following switches:

- **9** (RES/+) to increase the notification speed to the detected speed;
- **10** (SET/-) to reduce the notification speed to the detected speed.

DETECTION OF ROAD SIGNS (4/4)

Operating faults

The system cannot detect the speed limit if:

- the windscreen is not clean;
- the camera is blinded by the sun;
- there is insufficient visibility (night, fog etc.);
- the signs are not legible (snow, etc.) or are hidden (by another vehicle or by trees);
- the information taken from the navigation system is not up to date.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.

The system detects speed limit signs and does not detect other signs (e.g. entry/exit to/from urban areas, etc.).


The system may not detect all speed limit signs or may interpret them incorrectly.

The driver should not ignore signs that are not detected by the system and should, as a priority, comply with the traffic signage and the highway code.

In the event of poor visibility (fog, snow, frost, etc.), it is possible that the system may not indicate the correct speed to the driver.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.


SPEED LIMITER (1/4)



The speed limiter function helps you stay within the driving speed limit that you choose, known as the **limit speed**.

Depending on the vehicle, the speed limiter is linked with the “Hill Descent Control” function which uses the braking system to optimise downhill speed limitation.

The presence of the “Hill Descent Control” function can be identified by the presence of the **6** button.




Controls

- 1** Speed limiter On/Off switch.
- 2** Cruise control On/Off switch.
- 3** Switch to activate and decrease the limit speed (SET/-).
- 4** Switch to activate and increase the limit speed or to set the stored limit speed (RES/+).
- 5** Speed limiter function standby (with limited speed memory) (0).

You can link the speed limiter to the “Road sign detection” function.
➡ 2.81.


SPEED LIMITER (2/4)



Driving

When a limit speed has been set but not yet reached, driving is similar to driving a vehicle without the speed limiter function.

Once you have reached the stored speed, no effort on the accelerator pedal will allow you to exceed the programmed speed except in an emergency (refer to information on "Exceeding the limit speed").




Switching on

Press switch **1**. The **7** warning light appears in grey. The "Speed limiter ON" message appears on the instrument panel accompanied by dashes to indicate that the speed limiter function is in operation, waiting to store a limit speed.



To store the current speed, press the **4** switch (RES/+) or the **3** switch (SET/-): the limit speed replaces the dashes and, depending on the vehicle, the **7** warning light appears in white. The minimum stored speed is 20 mph (30 km/h).

SPEED LIMITER (3/4)



Varying the limit speed

The limit speed may be changed by pressing repeatedly or holding down:

- switch **4** (RES/+) to increase speed;
- switch **3** (SET/-) to reduce speed.

Exceeding the limit speed

It is possible to exceed the limit speed at any time. To do this: press the accelerator pedal **firmly and fully** (beyond the resistance point).

While the speed is being exceeded, the speed limiter flashes red on the instrument panel. Then, release the accelerator pedal: the speed limiter function will return as soon as you reach a speed lower than the memorised speed.



If the speed limiter is not available (after several attempts to activate), contact an approved dealer.

Limited speed cannot be maintained

When driving down a steep gradient, the system may not maintain the limit speed: the limit speed flashes in red on the instrument panel and an audible signal sounds at regular intervals to inform you of this situation.



Cruise control/speed limiter with Hill Descent Control:


the function may act on the braking system.

Cruise control/speed limiter without Hill Descent Control:

The function never interacts with the braking system.

Please note that you must always keep your feet close to the pedals in order to react in an emergency.

SPEED LIMITER (4/4)




Putting the function on standby

The speed limiter function is suspended when you press switch **5** (0). The limit speed is stored and displayed in grey on the instrument panel.

Recalling the limit speed

If a speed has been stored, it can be recalled by pressing the **4** switch.



When the speed limiter is set to standby, pressing the **3** switch re-activates the function without taking into account the memorised speed: the speed at which the vehicle is moving is taken into account.




Switching off the function

The speed limiter function is interrupted:

- when you press the **1** switch. In this case, the speed is no longer stored;
- when you press the **2** switch. In this case the cruise control is selected and there is no stored speed.

The warning light **7** disappears from the instrument panel to confirm that the function is no longer active.


CRUISE CONTROL (1/5)



The cruise control function helps you to maintain your driving speed at a speed that you choose, called the **cruising speed**.

This cruising speed may be set at any speed above 19 mph (30 km/h).

Depending on the vehicle, cruise control is linked with "Hill Descent Control" which uses the braking system to optimise downhill cruise control.



The presence of the "Hill Descent Control" function can be identified by the presence of the **6** button.

Controls

- 1 Cruise control On/Off switch.
- 2 Switch to activate and decrease cruising speed (**SET/-**).
- 3 Switch to activate and increase cruising speed or to recall the memorised cruising speed (**RES/+**).

4 Switch the function to standby (with cruising speed saved) (**0**).

5 Speed limiter On/Off switch.



This function is an additional driving aid.


It can under no circumstances replace the driver's responsibility to respect speed limits or to be vigilant.

The driver must always be in control of the vehicle.

Cruise control must not be used in heavy traffic, on winding or slippery roads (black ice, aquaplaning, gravel) and during bad weather (fog, rain, side winds etc.).

There is a risk of accidents.

CRUISE CONTROL (2/5)



Switching on

Press switch **1**.

The **7** warning light appears in grey.

The "Cruise control ON" message appears on the instrument panel accompanied by dashes to indicate that the cruise control function is in operation and waiting to memorise a cruising speed.



Activating cruise control

While the vehicle is moving a steady speed above approximately 19 mph (30 km/h), press the **2 (SET/-)** switch or the **3 (RES/+)** switch : the function is activated and the current speed is taken into account.

The cruising speed replaces the dashes. Cruise control is confirmed when the memorised speed and warning light appear in green **7**.

If you try to activate the function below 19 mph (30 km/h), the message "Invalid Speed" will be displayed and the function will remain inactive.




Driving

Once a cruising speed is registered and the cruise control function is active, you may lift your foot off the accelerator pedal.



Please note that you must keep your feet close to the pedals in order to react in an emergency.

CRUISE CONTROL (3/5)



Adjusting the cruising speed

The cruising speed may be changed by pressing the following repeatedly:

- the **2** switch (**SET/-**) to reduce the speed;
- the **3** switch (**RES/+**) to increase the speed.

Note: press and hold one of the switches to modify speed by successive increments.

Exceeding the cruising speed

The cruising speed may be exceeded at any time by depressing the accelerator pedal.

While it is being exceeded, the cruising speed flashes in red on the instrument panel.

Then, release the accelerator pedal: after a few seconds, the vehicle will automatically return to its set cruising speed.

Cruising speed cannot be maintained

When driving down a steep gradient, the system may be unable to maintain the cruising speed: the memorised speed will flash in red on the instrument panel and an audible signal sounds at regular intervals to inform you of this situation.



If the cruise control is no longer available (after several attempts to activate it), contact an Approved

Dealer.

Cruise control with cruising speed maintained during gear changing:

This function maintains the cruise control speed before and after a gear change, without any action required from the driver.




Cruise control/speed limiter with Hill Descent Control:

the function may take action on the braking system.

Cruise control/speed limiter without Hill Descent Control: the function does not affect the braking system.

Please note that you must always keep your feet close to the pedals in order to react in an emergency.

CRUISE CONTROL (4/5)



Putting the function on standby

The function is set to standby if you:

- **4** switch (0);
- the brake pedal;
- the clutch pedal for a prolonged period or upon prolonged neutral position on vehicles equipped with a manual gearbox;
- shifting to neutral position on vehicles equipped with an automatic gearbox.

The cruising speed is stored and displayed in grey on the instrument panel.



Returning to the cruising speed

If a speed is stored, it can be recalled, once you are sure that the road conditions are suitable (traffic, road surface, weather conditions, etc.).

Press the switch **3 (RES/+)** if the vehicle speed is above 19 mph (30 km/h).


When the speed is stored, cruise control activation is confirmed by the display in green of the cruising speed and, depending on the vehicle, the **7** warning light is displayed.



NB: if the speed previously stored is much higher than the current speed, the vehicle will accelerate more rapidly to reach this threshold.

When the cruise control is set to standby, pressing switch **2 (SET/-)** re-activates the cruise control function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.

CRUISE CONTROL (5/5)



Switching off the function

The cruise control function is interrupted:

- when you press the **1** switch. In this case, the speed is no longer stored;
- when you press the **5** switch. In this case the speed limiter is selected and there is no stored speed.



The warning light **7** disappears from the instrument panel to confirm that the function is no longer active.



Putting the cruise control on standby or switching it off does not cause a rapid reduction in speed: you must brake by depressing the brake pedal.

ADAPTIVE CRUISE CONTROL (1/14)

Based on information from a radar or camera, the adaptive cruise control function (or Stop and Go adaptive cruise control function on vehicles equipped with an automatic gearbox) enables you to maintain the speed selected (known as cruising speed) while keeping a following distance with the vehicle in front in the same lane.

On vehicles fitted with an automatic gearbox, if the vehicle in front stops, the Stop and Go adaptive cruise control function may apply the vehicle brakes to a full-stop before allowing the vehicle to move-on.

The system controls acceleration and deceleration of your vehicle using the engine and braking system.

The system's maximum range is approximately 150 metres.

This may vary according to the road conditions (ground relief, weather conditions, etc.)

According to conditions on the road (traffic, weather etc.), the "Adaptive cruise control" function can be activated:

- 0 mph (0 km/h) to 105 mph (170 km) on vehicles fitted with an automatic gearbox;
- 19 mph (30 km/h) to 105 mph (170 km) on vehicles fitted with a manual gearbox.

The function is indicated by the



Note:

- the driver must observe the maximum speed limit and safe distances in the country where they are driving;
- the adaptive cruise control can brake the vehicle up to a third of the braking capacity. Depending on the situation, the driver may need to brake harder.

The adaptive cruise control does not trigger an emergency stop and its braking capability is limited.



This function is an additional driving aid.

It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances or to be vigilant.

The driver must always be in control of the vehicle.


The driver must always adapt their speed according to the surroundings and traffic conditions.

The adaptive cruise control must only be used on a motorway (or multi-lane road with a central barrier).

The cruise control must not be used in heavy traffic, on winding or slippery roads (black ice, aquaplaning, gravel) or during bad weather (fog, rain, side winds etc.).

There is a risk of accidents.

ADAPTIVE CRUISE CONTROL (2/14)




Location of the camera 1

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).


Location of the radar 2

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).




Controls

- 3 Safe distance settings
- 4 Switch the function to standby (with cruising speed saved) (0).
- 5 Adaptive cruise control main stop/start switch .
- 6 Cruising speed activation, storage and decrease switch (**SET/-**).
- 7 Switch to activate and increase cruising speed or to recall the memorised cruising speed (**RES/+**).



The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

ADAPTIVE CRUISE CONTROL (3/14)



Displays

- 8** Adaptive cruise control warning light.
- 9** Vehicle in front.
- 10** Stored safe distance
- 11** Stored cruising speed.



Important: you should keep your feet near the pedals at all times to prepare for any event.

Switching on

Press switch **5**.

Warning light  appears in grey, and the message “Adaptive Cruise Ctl ON” appears on the instrument panel, accompanied by dashes to indicate that the cruise control function is activated and waiting to store a cruising speed.

This function cannot be activated when:

- the parking brake is applied;
- the Park Assist function is already activated ➔ 2.137.

The message “Adaptive Cruise Ctl unavailable” is displayed on the instrument panel.

Activating cruise control

When the vehicle is stationary (vehicles equipped with an automatic gearbox) or when the vehicle is moving at a steady speed (all vehicles), press the **6 (SET/-)** or **7 (RES/+)**: switch to activate the function and store the current speed.

The minimum cruising speed is 19 mph (30 km/h).

The cruising speed **11** replaces the dashes and cruise control is confirmed by the appearance of the cruising speed in green and warning light .

If you try to activate the function when the vehicle speed is over 105 mph (170 km/h) or below 19 mph (30 km/h) for vehicles fitted with a manual gearbox, the message “Invalid Speed” is displayed and the function is not activated.

Once a cruising speed is memorised and the cruise control function is active, you may lift your foot off the accelerator pedal.

Special feature on vehicles with an automatic gearbox: if the vehicle speed is below approximately 19 mph (30 km/h), the cruising speed will automatically be set to 19 mph (30 km/h). The vehicle will accelerate until it reaches the stored cruising speed.

ADAPTIVE CRUISE CONTROL (4/14)

Safe distance control activation


As soon as cruise control is activated, the default safe distance **10** is displayed in green on the instrument panel.

The default safe distance corresponds to approximately two seconds (see following pages).

If the system detects a vehicle in your lane, an outline of a vehicle **9** appears above the distance gauge **10** on the instrument panel.

Your vehicle adapts its speed to that of the vehicle in front and applies the brakes if necessary (the brake lights come on) in order to maintain the distance displayed on the instrument panel.


Note: the size of the **9** outline varies according to the distance separating you from the vehicle in front. The larger the outline, the closer the vehicle in front.



Setting the cruising speed

You can vary the speed by repeatedly pressing (for a small variation) or pressing and holding (for a larger variation) switch **6** or **7**:

- use the **(SET/-)** switch **6** to reduce the speed;
- use the **(RES/+)** switch **7** to increase the speed.



Adjusting the following distance

You can vary the safe distance from the vehicle in front at any time by pressing switch **3** repeatedly.

The horizontal distance gauge on the instrument panel indicates the various available safe distances:

- distance gauge **A**: long distance (corresponding to approximately 2.4 seconds);


Adjusting the safe distance (cont.)

- Note:** the distance must be set according to the traffic level, local regulation and weather conditions.

The safe distance is adjusted by default on the distance gauge **B**.



The distance gauge flashes if the distance between your vehicle and the vehicle in front is less than the safe distance selected: the Safe Distance Control function is no longer active.



If you wish to overtake the vehicle in front, activating the indicator will temporarily cancel the safe distance control and enable an acceleration speed sufficient to complete overtaking.

ADAPTIVE CRUISE CONTROL (6/14)

Stop and start

On vehicles fitted with an automatic gearbox, if the vehicle in front slows down, the system adapts its speed to a complete stop if necessary (in the event of a traffic jam). The vehicle stops a few metres from the vehicle in front. The Stop and Start function can put the engine on standby ➔ 2.8.

When the vehicle in front sets off again:

- if the stop does not exceed about three seconds, the vehicle sets off automatically without any action by the driver;
- if the stop exceeds about three seconds, you must apply the accelerator pedal or press button **7 (RES/+)** in order for the vehicle to set off again. The message “Press RES/+ or accelerate” appears on the instrument panel to confirm.

If the stop exceeds about three minutes, the electronic parking brake is automatically applied and the Stop and Go adaptive cruise control is deactivated.

The  warning light disappears to confirm that the function is deactivated.


Putting the function on standby

You can set the function to standby when:

- you press switch **4 (0)**;
- you apply the brake pedal while the vehicle is moving.

The function is deactivated by the system if:

- you set the automatic gearbox to **P** or **N**;
- you engage the reverse gear;
- you unbuckle the driver's seatbelt;
- you open one of the opening elements;
- you press the engine start/stop button;
- the slope is too steep;
- the vehicle speed is above 112 mph (180 km/h);
- certain driving aids and correction devices are triggered (active emergency braking, ABS, ESC etc.) ;



- when you press the clutch pedal for a prolonged period or upon prolonged neutral position on vehicles equipped with a manual gearbox.

In all circumstances, the standby is confirmed when the warning lights appear in grey and the message “Adaptive Cruise Ctl Disconnected” appears on the instrument panel.



Putting the adaptive cruise control in standby or switching it off does not cause a rapid reduction in speed: you must brake by applying the brake pedal if necessary.

ADAPTIVE CRUISE CONTROL (7/14)

Exit from standby

Based on the stored cruising speed

If a speed is stored, it can be recalled, once you are sure that the road conditions are suitable (traffic, road surface, weather conditions, etc.).

Press switch **7 (RES/+)** in the range of confirmed speeds.

When the stored speed is recalled, activation of the cruise control is confirmed by the illumination of the cruising speed in green.

Note: if the stored speed is higher than the current speed, the vehicle will accelerate to reach that speed.

Based on the current speed

When the cruise control is set to standby, pressing switch **6 (SET/-)** re-activates the cruise control function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.



“Take control of the vehicle” warnings

In some situations (e.g. coming upon a much slower vehicle, vehicle in front changing lanes quickly etc.), **the system may not have time to react.**

Depending on the situation, the system sounds a beep associated with:


- the orange alert **E** if the situation requires the driver’s attention;

or

- the red alert **F** accompanied by the message “Brake”, if the situation requires the driver’s immediate attention.

In all situations, react accordingly and perform the appropriate manoeuvres.

ADAPTIVE CRUISE CONTROL (8/14)



Switching off the function

The “Adaptive cruise control” function is deactivated when you press the switch **6**.

The warning light  disappears from the instrument panel to confirm that the function is no longer active.

Temporary unavailability

The radar is able to detect vehicles in front of your vehicle. The system cannot operate correctly if the radar detection area is obscured or if its signal is disrupted.

If the radar detection area is obstructed or the radar signal is disrupted, the message “Front radar no visibility” is displayed on the instrument panel and the “Adaptive cruise control” function is interrupted. The green warning light



disappears to confirm that the function has been automatically deactivated.

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).

Conditions in certain geographical areas may hinder the function, for example:

- arid zones, tunnels, long bridges or lightly used roads without road lines, without signs or trees nearby;
- a military or airport zone.

You must leave such areas in order for the function to work.

In all cases, if the message is not erased after the engine is restarted, please contact an authorised dealer.

Operating faults

If an “Adaptive cruise control” function operating fault is detected, the message “Check Adaptive Cruise control” appears on the instrument panel and the “Adaptive cruise control” function is deactivated.


If an operating fault is detected on one or more components of the system, the “Adaptive cruise control” function is interrupted.

The  warning light appears on the instrument panel along with, depending on the malfunction, one of the following messages:

- “Front camera to check”;
- “Front radar to check”;
- “Camera/Radar to check”;
- “Check vehicle”.

Consult an approved dealer.

ADAPTIVE CRUISE CONTROL (9/14)




Limitations of system operation

Vehicle detection

The system detects only vehicles (cars, trucks, motorbikes) that are moving in the same direction as your vehicle.

A vehicle turning into the same lane (e.g. **G**) will be taken into account by the system only once it enters the camera and radar detection areas.


The system may trigger abrupt or delayed braking.



The system cannot detect:

- vehicles arriving at intersections: slip road (e.g. **H**) etc;
- vehicles driving on the wrong side of the road or reversing towards you.

The adaptive cruise control must only be used on a motorway (or multi-lane road separated by a barrier).



Detection during cornering


When entering a corner or bend, the radar and/or camera may temporarily not be able to detect the vehicle in front (e.g. **J**).

The system may trigger an acceleration.

When exiting a bend, the system's detection of the vehicle in front may be disrupted or delayed.

The system may trigger abrupt or delayed braking.

ADAPTIVE CRUISE CONTROL (10/14)




Detection of vehicles in adjacent lanes

The system may detect vehicles driving on an adjacent lane when:

- you drive into a bend (e.g. **K**);
- you are driving on a road with narrow lanes;
- the speed of the vehicle on the adjacent lane is slower and if one of these vehicles is located too close to the lane of the other.

The system may incorrectly trigger vehicle slowing or braking.




Vehicles hidden due to variations in ground relief

The system will not detect vehicles hidden due to variations in ground relief or those located outside of the camera and radar detection areas when driving uphill or downhill.


Vehicles outside the camera and radar detection areas.

The system will react late or not at all if the detected vehicles are outside the camera and radar detection areas, particularly in the following cases:



- vehicles transporting long objects which exceed the line;
- the actual length of tall vehicles (e.g. **L**) outside the radar detection area (construction machine, agricultural equipment towing vehicle, etc.) ;
- vehicles insufficiently centred in the lane;
- narrow vehicles which are very close (e.g. **M**).

ADAPTIVE CRUISE CONTROL (11/14)



(N)


Stationary and slow moving vehicles

When your speed is over approximately 31 mph (50 km/h), **the system does not detect:**

- stationary vehicles (e.g. **N**);
- very slow moving vehicles.


When your speed is less than approximately 31 mph (50 km/h), **the system may not react or may react very late to:**

- stationary vehicles (e.g. **N**);
- very slow moving vehicles;



(P)

- vehicles in front **12** that change lane, discovering a stationary vehicle **13** (e.g. **P**);
- when the vehicle is stationary **14**, when you change lane (e.g. **Q**).




(Q)

Always be ready to take control of your vehicle when you come upon stationary or very slow moving vehicles (e.g. **N).**

The adaptive cruise control does not trigger an emergency stop and its braking capability is limited.

ADAPTIVE CRUISE CONTROL (12/14)




Non-detection of fixed obstacles and objects of a small size

The system cannot detect:

- pedestrians, bikes, scooters, etc. ;
- animals;
- fixed obstacles (toll barriers, walls, etc.) (e.g. **R**).

These are not taken into account by the system. They do not trigger any alert or reaction by the system.



Detection of vehicles moving into lane at high speed

If your vehicle is overtaken by another vehicle driving at high speed **15** (motorcycle, car, etc.) and the vehicle is temporarily between you and the vehicle in front **16**, **the system may trigger undue acceleration, slowing or braking.**

ADAPTIVE CRUISE CONTROL (13/14)



This function is an additional driving aid. It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances and to be vigilant.

The driver must always be in control of the vehicle.

The driver must always adapt their speed to the surroundings and driving conditions, regardless of system indications.

Except for lines delimiting lanes, traffic indicators (traffic lights, signs, pedestrian crossings etc.) are not recognised by the system. These do not trigger any alert or reaction by the system.

The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

The adaptive cruise control must only be used on a motorway (or multi-lane road separated by a barrier).

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the system and consult an authorised dealer.
- Any work in the proximity of the radar and/or camera (replacements, repairs, windscreen modifications, paintwork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

Deactivating the function

You must disable the function if:

- the vehicle is travelling on a windy road;
- the vehicle is being towed (breakdowns);
- the vehicle is towing a trailer or a caravan;
- the vehicle is being driven in a tunnel or close to a metallic structure;
- the vehicle arrives at a toll point, a roadwork area or on a narrow lane;
- the vehicle is being driven up or down a very steep slope;
- the visibility is poor (glaring sun, fog etc.);
- the vehicle is being driven on a slippery road surface (rain, snow, gravel, etc.);
- the weather conditions are poor (rain, snow, side winds, etc.);
- the radar area has been damaged (impacts etc.) ;
- the camera area has been damaged (e.g. on the inside or outside of the windscreen);
- the windscreen is cracked or distorted.

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.



In the event of system disturbance

Some conditions can disturb or damage the operation of the system, such as:

- the windscreen or bumper is obscured in the area of the radar (by dirt, ice, snow, condensation, number plate etc.);
- a complex environment (tunnel etc.);
- poor weather conditions (snow, heavy rain, hail, black ice, etc.);
- poor visibility (night, fog etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area etc.);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- narrow, winding or undulating road (tight bends etc.);
- a slower vehicle with a significant difference in speed;
- use of mats not adapted to the vehicle. On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

In these cases, the system may wrongly intervene.

Risk of unwanted braking or acceleration.

Many unforeseen situations may affect the system operation. Certain objects or vehicles that can appear in the camera or radar detection zone may be interpreted by the system incorrectly, possibly leading to inappropriate acceleration or braking.

You should always be attentive to sudden events that might occur while you are driving. Always keep your vehicle under control by keeping your feet near the pedals, so that you are ready to act in any event.

MOTORWAY AND TRAFFIC ASSISTANT (1/16)

The Motorway and Traffic Assistant is a driving aid system designed for use on long motorway journeys, where traffic is flowing or in jams.

Depending on the vehicle, this system comprises the **“Stop and Go Adaptive cruise control function”** ➡ 2.94 and the “Lane Centring” function.

When these two functions are activated simultaneously, the system allows the driver to:

- maintain vehicle speed based on a previously saved speed;
- adjust the distance between this vehicle and the vehicle in front;
- direct the vehicle to the centre of the lane.



Important: you should keep your feet near the pedals and your hands on the steering wheel at all times to prepare for any event.

The “Stop and Go adaptive cruise control” function

Based on information from a radar or camera, the Stop and Go adaptive cruise control function gives you the option of maintaining a selected speed, known as the cruising speed, while keeping a safe distance from the vehicle in front in the same lane.

If the vehicle in front stops, the Stop and Go adaptive cruise control may brake your vehicle to a complete stop before setting off again.

The system controls acceleration and deceleration of your vehicle using the engine and braking system.

The “Stop and Go adaptive cruise control” function can be activated from 0 to 105 mph (0 to 170 km/h) according to conditions on the road (traffic, weather, etc.).

It is represented by the following symbol



➡ 2.94.

Note:

- the driver must observe the maximum speed limit and safe distances in the country where they are driving;
- the Stop and Go adaptive cruise control can brake the vehicle up to a third of the braking capacity. Depending on the situation, the driver may need to brake harder.

The Stop and Go adaptive cruise control does not trigger an emergency stop and its braking capability is limited.

MOTORWAY AND TRAFFIC ASSISTANT (2/16)

The “Lane centring” function

Using information from a camera, the “Lane Centring” function manipulates the steering system to direct the vehicle to the middle of the lane. This function is only available while the Stop and Go adaptive cruise control is activated ➡ 2.94.

If the conditions allow it, the function is available between:

- 0 mph and 99 mph (0 and 160 km/h) approximately with a vehicle in front;

or

- 37 mph (60 km/h) et 99 mph (160 km/h) approximately without a vehicle in front.

The “Lane Centring” function is a comfort feature. It is represented by the

symbol .

Note: in the event of a sharp bend, the function's lateral retention capacities are limited and require the driver to take immediate action on the steering wheel.


Additional information

Depending on the vehicle, the “Motorway and Traffic Assistant” function may be used with other driving aid functions.

Please note that:

- activating the speed limiter causes deactivation of the system;
- the system cannot be activated when the “Park Assist” function is active;
- activation of the “Lane Centring” function leads to suspension of the “Lane Departure Warning” or “Lane Keep Assist” functions if these have been activated. They will be reactivated when the driver decides to stop the “Lane Centring” function.

MOTORWAY AND TRAFFIC ASSISTANT (3/16)



MOTORWAY AND TRAFFIC ASSISTANT (4/16)

Computer 1

Receives information from the radar and camera to determine the vehicle trajectory and speed (acceleration or braking). Amongst other things, it controls activation/deactivation of the system (door opening, etc.).

Camera 2

Detects markings on the ground and the position of vehicles on the various traffic lanes. It complements the information transmitted by the **6** radar.

Make sure the windscreen is not obscured (by dirt, mud, snow, etc.).

Electronic parking brake 3

Keeps the vehicle stationary under certain conditions.

Power-assisted steering 4

Operates the front wheels to assist the trajectory of your vehicle according to details transmitted by the **1** computer. It also enables detection of the driver's hands on the steering wheel.

Engine computer 5

It controls and directs the engine to carry out the required acceleration.

Radar 6

Calculates the distance between your vehicle and the vehicle in front.

The system's maximum range is approximately 150 metres. This may vary according to the road conditions (ground relief, weather conditions, etc.) Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).


Active vehicle control 7

This system provides information on vehicle dynamics to the computer **1** (speed, lateral acceleration etc.) and acts on the braking system to control deceleration and to keep the vehicle stationary.



The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

MOTORWAY AND TRAFFIC ASSISTANT (5/16)



49436

MOTORWAY AND TRAFFIC ASSISTANT (6/16)

Controls

- 8** Safe distance settings
- 9** Set active functions to standby (with cruising speed saved) (0).
- 10** Adaptive cruise control main stop/start switch .
- 11** "Lane Centring" function activation/deactivation switch .
- 12** Cruising speed activation, storage and decrease switch (SET/-).
- 13** Switch to activate and increase cruising speed or to recall the memorised cruising speed (RES/+).

Displays on the instrument panel

- 14** "Stop and Go adaptive cruise control" function warning light .
- 15** "Lane Centring" function warning light .
- 16** Vehicle in front.
- 17** Left-hand and right-hand line indicators.
- 18** Stored safe distance.
- 19** Stored cruising speed.
- 20** Hands off steering wheel detection warning light .

Steering wheel 21

The driver must always keep their hands on the steering wheel. If too much force is applied when turning the steering wheel, the "Lane Centring" function is put on standby so the driver can regain control of the vehicle.


Under certain conditions (sharp bends, etc.) a vibration may be triggered on the steering wheel to warn the driver that they must regain control of the vehicle.

If the driver does not handle the steering wheel (no hands are detected) the "Lane centring" function is deactivated after several alerts.

Head-up display 22

On equipped vehicles, some information is provided on the head-up display.


MOTORWAY AND TRAFFIC ASSISTANT (7/16)



Activating the “Lane Centring” function

Once the Stop and Go adaptive cruise control is activated ➔ 2.94, press button **11** to activate the “Lane Centring” function.

The “Lane centering activated” message appears on the instrument panel accompanied by the **15**  warning light and the  symbol to confirm that the function is activated.



Note: you must keep your hands on the driving wheel when using the “Lane Centring” function. The  symbol is displayed to confirm that the function is activated.

The warning light **15**  is displayed in green and the left-hand and right-hand line indicators **17** are displayed on the instrument panel to confirm that the function is activated and directing your vehicle to the centre of the lane.

Note: if you press button **11** when the Stop and Go adaptive cruise control is not activated, the message: “First activate Adapt. cruise ct” appears on the instrument panel.

MOTORWAY AND TRAFFIC ASSISTANT (8/16)

“Lane Centring” function on standby

The “Lane Centring” function is put on standby automatically when:

- the Stop and Go adaptive cruise control is put on standby ➡ 2.94;
- the system no longer detects the lines or only one line is detected in your lane;
- the lane is too narrow or too wide;
- the system does not detect any hands on the steering wheel;
- the bend is too sharp;
- the vehicle speed is over approximately 99 mph (160 km/h);
- the vehicle speed is below approximately 37 mph (60 km/h), without any vehicle in front;
- the vehicle touches or breaches a line;
- the system is temporarily disrupted (for example: camera obscured by dirt, mud, snow, condensation, etc.).

Certain actions carried out by the driver also suspend the “Lane Centring” function:


- activating the indicators;
- too much force is used when handling the steering wheel.

Standby of the function is confirmed by

the **15**  warning light and the left-hand and right-hand line indicators **17** appearing in grey on the instrument panel.



Important: you should keep your feet near the pedals and your hands on the steering wheel at all times to prepare for any event.



Once the conditions are met, the function again directs the vehicle to the centre of the lane. The **15**  warning light and left-hand and right-hand line indicators **17** are displayed in green on the instrument panel.

You can affect the **vehicle trajectory** at any point by turning the steering wheel.


MOTORWAY AND TRAFFIC ASSISTANT (9/16)



“Hands on steering wheel” alert

When the “Lane Centring” function no longer detects your hands on the steering wheel, several warning levels will be triggered:

- **after 15 seconds**, the message: “Keep hands on steering wheel” is shown in yellow on the instrument panel **23**;



- **after approximately 30 seconds**, the message: “Keep hands on steering wheel” appears on the instrument panel **23** and the warning light **20**



appears in red, accompanied by an audible signal of gradually increasing volume;

- **after approximately 45 seconds**, the audio sources go on standby, the audible signal sounds contin-

ually, the warning light **20**  is switched off and the message “Lane centering deactivated” appears in red on the instrument panel **23**: the **“Lane Centring” function is deactivated**.

Note: in some situations, the “Lane Centring” function may no longer detect your hands on the steering wheel and may sound a signal:

- the vehicle is moving along a long straight lane and the driver's hands are immobile on the steering wheel;
- the driver is holding the steering wheel very lightly;
- ...

If the “Lane Centring” function is deactivated due to the driver's hands not being detected on the steering wheel, the Stop and Go adaptive cruise control function continues to function.


In the first two alert levels, when the system again detects the presence of the driver's hands on the steering wheel, the system stops the alerts. The function continues to direct the vehicle to the centre of the lane.

MOTORWAY AND TRAFFIC ASSISTANT (10/16)



In the case of a sharp bend

In the case of a sharp bend, and depending on the vehicle speed, the function's side retaining capacities will be limited and require the driver to carry out immediate action on the steering wheel so that the function can continue to maintain the vehicle in the centre of the lane.




If the driver does not intervene, the function triggers the vibration of the steering wheel to signal that the vehicle is about to breach a line and that the driver needs to carry out immediate action.

The **15**  warning light and the left-hand or right-hand line indicator **17** appear in red on the instrument panel.

If the vehicle crosses a line completely and moves out of lane, the “Lane Centring” function is put on standby. Standby of the function is

confirmed by the **15**  warning light and the left-hand and right-hand line indicators **17** appearing in grey on the instrument panel.

MOTORWAY AND TRAFFIC ASSISTANT (11/16)



Deactivating the “Lane Centring” function

The “Lane Centring” function is deactivated when:

- you press the **11** switch. The function's deactivation is confirmed by the appearance of the “Lane centering deactivated” message on the instrument panel;

Note: pressing the **11** switch once deactivates the “Lane centring” function but does not affect operation of the Stop and Go adaptive cruise control function.

- the Stop and Go adaptive cruise control is deactivated ➔ 2.94;

Note: pressing the **10**  button once deactivates both the “Stop and Go adaptive cruise control” function and the “Lane Centring” function.

- the system will no longer detect the driver's hands on the steering wheel for a period over 45 seconds approximately.

The **15**  warning light and the left-hand and right-hand line indicators **17** disappear from the instrument panel.

MOTORWAY AND TRAFFIC ASSISTANT (12/16)

Temporary unavailability

The radar is able to detect vehicles in front of your vehicle. The system cannot operate correctly if the radar detection area is obscured or if its signal is disrupted.

If the radar detection area is obstructed or the radar signal is disrupted, the message “Front radar no visibility” is displayed on the instrument panel and the “Stop and Go adaptive cruise control” function is interrupted.

The green warning light  disappears to confirm that the function has been automatically deactivated.

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).

Conditions in certain geographical areas may hinder the function, for example:

- arid zones, tunnels, long bridges or lightly used roads without road lines, without signs or trees nearby;
- a military or airport zone.

You must leave such areas in order for the function to work.

In all cases, if the message is not erased after the engine is restarted, please contact an authorised dealer.

Operating faults

If a Lane Centring function operating fault is detected, the message “Check lane centering” is displayed on the instrument panel and the function is disabled.

The Stop and Go adaptive cruise control function remains in operation.

Consult an approved dealer.

If a “Stop and Go adaptive cruise control” function operating fault is detected, the “Check Adaptive Cruise control” message appears on the instrument panel and both the “Stop and Go adaptive cruise control” function and the “Lane Centring” function are interrupted.

Consult an approved dealer.

If an operating fault is detected on one or more components of the “Motorway and Traffic Assistant” system, the  warning light appears on the instrument panel, alongside, depending on the nature of the fault, the message:

- “Front camera to check”;
- “Front radar to check”;
- “Camera/Radar to check”;
- “Check vehicle”.

The two “Stop and Go adaptive cruise control” and “Lane Centring” functions are interrupted.

Consult an approved dealer.

MOTORWAY AND TRAFFIC ASSISTANT (13/16)



The “Motorway and Traffic Assistant” function is an additional driving aid. This system does not take the place of the driver.

Therefore, it can under no circumstances replace the driver’s responsibility to respect speed limits and safe distances and to be vigilant (the driver must always be ready to brake).

The driver must always be in control of the vehicle. The driver must always adapt their trajectory and speed according to the surroundings and traffic conditions.

The “Motorway and Traffic Assistant” uses the “Stop and Go adaptive cruise control” function and the “Lane Centring” function. It must only be used on a motorway or multi-lane road (separated by a barrier).

It must not be used in heavy traffic, on winding or slippery roads (black ice, aquaplaning, gravel) or during bad weather (fog, rain, side winds etc.).

There is a risk of accidents.

MOTORWAY AND TRAFFIC ASSISTANT (14/16)



The “Motorway and Traffic Assistant” function is an additional driving aid. It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances and to be vigilant.

The driver must always be in control of the vehicle.

The driver must always adapt their trajectory and speed according to the surroundings and driving conditions, regardless of system indications.

Except for lines delimiting lanes, traffic indicators (traffic lights, signs, pedestrian crossings, etc.) are not recognised by the system. These do not trigger any alert or reaction by the system.

The “Motorway and Traffic Assistant” uses the Stop and Go adaptive cruise control function and the Lane Centring function. The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

The Motorway and Traffic Assistant function must only be used on a motorway or multi-lane road separated by a barrier.

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the system and consult an authorised dealer.
- Any work in the proximity of the radar and/or camera (replacements, repairs, windscreen modifications, paintwork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.



Deactivating the system

You must deactivate the system if:

- the vehicle is travelling on a windy road;
- the vehicle is being towed (breakdowns);
- the vehicle is being driven with an emergency spare wheel;
- the vehicle is towing a trailer or a caravan;
- the vehicle is being driven in a tunnel or close to a metallic structure;
- the vehicle arrives at a toll point, a roadwork area or on a narrow lane;
- the vehicle is being driven up or down a very steep slope;
- the visibility is poor (glaring sun, fog etc.);
- the weather conditions are poor (rain, snow, side winds, etc.);
- the vehicle is being driven on a slippery road surface (rain, snow, gravel, etc.);
- the area of the camera has been damaged (e.g. on the inside or outside of the windscreen);
- the windscreen is cracked or distorted;
- the radar area has been damaged (impacts, etc.) ;

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.



Some conditions can disrupt or damage the operation of the system, for example:

- obstruction of the windscreen or the radar area (by dirt, ice, snow, condensation etc.) Frequently check the cleanliness and condition of the windscreen, front wiper blades and front bumper;
- a complex environment (tunnel etc.);
- poor weather conditions (snow, heavy rain, hail, black ice, etc.);
- poor visibility (night, fog etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area etc.) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- narrow, winding or undulating road (tight bends etc.);
- the tar lines detected as a line by the system;
- narrowing/widening lanes;
- road markings which are worn, lacking in contrast or very widely spaced from one another (lines partially erased etc);
- multiple markings on the road (roadworks area, slip roads connecting to adjacent motorways, hard shoulder etc.);
- a slower vehicle with a significant difference in speed;
- use of mats not adapted to the vehicle. On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

In these cases, the system may wrongly intervene.

– **Risk of unwanted braking or acceleration.**

– **Risk of unwanted, incorrect correction or no correction of trajectory.**

Many unforeseen situations may affect the system operation. Certain objects or vehicles that can appear in the camera or radar detection zone may be interpreted by the system incorrectly, possibly leading to inappropriate acceleration or braking.

You should always be attentive to sudden events that might occur while you are driving. Always maintain your vehicle under control by keeping your feet near the pedals and your hands on the steering wheel, so that you are ready to act in any event.

PARKING DISTANCE CONTROL (1/6)

Operating principle

Ultrasonic sensors in the rear bumper measure the distance between the vehicle and an obstacle.

This measurement is indicated by beeps which become more frequent the closer you come to the obstacle, until they become a continuous beep when the vehicle is approximately 20 to 30 centimetres from the obstacle.

The system detects obstacles to the front, the rear and the sides of the vehicle.

The parking distance control system is only activated when the vehicle is driven at a speed below approximately 6 mph (10 km/h).

The function does not take into account towing or carrying systems that are not recognised by the system.



48129

Location of the ultrasonic sensors 1

Ensure that the ultrasonic sensors indicated by the arrows **1** are not obscured (by dirt, mud, snow, a badly fitted/attached number plate, etc.), impacted, modified (including paintwork) or obstructed by any accessory fitted to the rear and/or, depending on the vehicle, to the front or sides of your vehicle.




This function is an additional aid that indicates the distance between the vehicle and an obstacle whilst reversing, using sound signals.

Under no circumstances should it replace the driver's care or responsibility whilst reversing.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post etc.) in the blind spot when manoeuvring.

PARKING DISTANCE CONTROL (2/6)



Note: the display 2 shows the vehicle surroundings and emits beeps.

It is necessary to travel a few metres before the side detection is activated.

If all areas have a grey background, the whole area around the vehicle is being monitored:

- **A:** analysis of the vehicle surroundings in progress;
- **B:** analysis of the vehicle surroundings carried out.



Operation

Most objects located less near the front, rear and sides of the vehicle are detected.

Depending on the distance of the obstacle, the frequency of the beep will increase when approaching it, and will become a solid beep at approximately 20 cm from obstacles to the sides and 30 cm from obstacles to the front or rear. Green, orange and red zones will be displayed on the display **C**.


Note: in the event of a change in trajectory during a manoeuvre, the risk of collision with an obstacles may be signalled late.



An impact to the underside of the vehicle while manoeuvring (e.g.: striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g.: deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.

PARKING DISTANCE CONTROL (3/6)




Detection of obstacles to the side

Depending on the direction of the wheels, the system determines the trajectory of the vehicle and notifies the driver of any risk or otherwise of a collision with an obstacle **3** to the side of the vehicle.

If a side obstacle is detected:

- the beeps become faster and then sound continuously as the obstacle gets nearer. Green, orange and red zones will be displayed on the display **D**;
- if there is no risk of collision, no beep will sound when approaching the obstacle. Green, orange and red zones will be displayed interspersed on the display **D**.

PARKING DISTANCE CONTROL (4/6)



Activation/deactivation

Vehicles fitted with a multimedia screen 4

To activate or deactivate the various zones covered by the ultrasonic detectors, please refer to the multimedia instructions.

Select "ON" or "OFF".

Vehicles not fitted with a multimedia screen

With the vehicle stopped, press the **6** switch to deactivate parking distance control. Warning light **5** in the switch lights up. Press again on the **6** switch to activate the function. The indicator light built into the **5** switch goes out.

Adjustment

Vehicles fitted with a multimedia screen 4

Depending on the vehicle, with the engine running, some settings can be adjusted from the multimedia screen **4**.


Please refer to the multimedia instructions for further information.

Parking distance control audio volume

Adjust the volume of Park Assist by pressing "+" or "-".

System sound

Enables the system sound to be chosen.




Deactivating the system sound

Activate or deactivate the parking distance control sound.

Note: if you deactivate the sound, you will no longer be notified with beeps when approaching an obstacle.

When the vehicle is being driven at a speed below approximately 6 mph (10 km/h), certain noises (motorcycle, lorry, pneumatic drill, etc.) may trigger the beeping sound of the parking distance control.

PARKING DISTANCE CONTROL (5/6)



Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the **7** switch as many times as required to reach the “Vehicle” tab;
- press the **8** or **9** control repeatedly to reach the “Settings” menu. Press the **10 OK** switch;
- press the **8** or **9** control repeatedly to reach the “PARKING ASSIST” menu. Press the **10 OK** switch;

- select “BIP VOLUME” to adjust the volume of the parking distance control using the **8** or **9** control.

Deactivating the parking distance control manually

- If towing, carrying or trailer equipment that is unrecognised by the system is present in front of the ultrasonic sensors;
- in the event of damage to the ultrasonic sensors.

Automatic deactivation of the parking distance control

The system deactivates:

- when the vehicle speed is above approximately 6 mph (10 km/h);
- depending on the model, when the vehicle is stationary for more than approximately 5 seconds and an obstacle is detected (such as when in a traffic jam, etc.);
- when the vehicle is in neutral on manual gearboxes, or in position **N** or **P** on automatic gearboxes;

- when an operating fault is detected.

Note: if the vehicle is fitted with a towbar recognised by the system, only the rear Park Assist is deactivated.

Operating faults

When the system detects an operating fault, a beep sounds for approximately 3 seconds each time reverse gear is selected and is accompanied by the message “Check parking sensor” shown on the instrument panel. Please consult an authorised dealer.



An impact to the underside of the vehicle while manoeuvring (e.g. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved dealer.

PARKING DISTANCE CONTROL (6/6)

System servicing/repairs

- In the event of an impact, the alignment of the sensors may be altered and their operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the sensors are located (repairs, replacements, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

System disturbance

Some conditions can disrupt or damage the operation of the system, for example:

- poor weather conditions (rain, snow, hail, black ice, etc.);
- in the event of exposure to strong electromagnetic waves (under high-voltage lines, etc.);
- some types of noise (motorcycle, lorry, pneumatic drill etc.);
- fitting an unsuitable towing ball or hook.

Risk of false alarms or absence of warnings

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

Limitation of the system operation

- The area around the sensors must be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects moving close to the vehicle (motorcycles, bicycles, pedestrians, etc.) may not be recognised by the system.
- The system may not detect objects that are too close to the vehicle.
- The system may not provide a warning when the other vehicles or objects are travelling at a significantly different speed.
- During a change in trajectory, during a manoeuvre, the system may report obstacles with a delay.
- When the vehicle is towing a trailer, the rear Park Assist system must be deactivated.

Deactivating the function

You must disable the function if:

- the area around the sensors has been damaged;
- the vehicle is equipped with a towing device that is not recognised by the system (ball, hook, adapter, etc.).

REVERSING CAMERA (1/3)



The **1** rear view camera is located on the luggage compartment lid.



Special feature

Make sure that the **1** camera is not obscured (by dirt, mud, snow, condensation etc.).



This function is an additional aid. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.


The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post etc.) in the blind spot when manoeuvring.

REVERSING CAMERA (2/3)



Operation

When reversing, the camera transmits a view of the surroundings to the rear of the vehicle to the screen **2** accompanied by one or two clearance gauges **3** et **4** (mobile and fixed). This system is initially used with the aid of several gauges (mobile for trajectory and fixed for distance). When the red zone is reached, use the bumper image to stop accurately.



Fixed clearance gauge 3

The fixed clearance gauge comprises coloured markers **A**, **B** and **C**, indicating the distance behind the vehicle:

- **A** (red) approximately 30 centimetres from the vehicle;
- **B** (yellow) approximately 70 centimetres from the vehicle;
- **C** (green) approximately 150 centimetres from the vehicle.

This gauge remains fixed and indicates the vehicle trajectory if the wheels are in line with the vehicle.

The frames are a representation projected onto flat ground; this information must not be taken into account when superimposed on a vertical object or an object on the ground.

4 moving guide line:

This is shown in blue on the multimedia screen **2**. It indicates the vehicle trajectory according to the position of the steering wheel.

Activating, deactivating the reversing camera

To activate or deactivate the function via the multimedia screen **2**, refer to the multimedia

instructions. Activate or deactivate the reversing camera and confirm your choice.

You can also adjust the camera image settings (brightness, contrast, etc.)


The screen shows a reverse mirror image.

Objects which appear on the edge of the screen may be deformed.

In very bright light (snow, vehicle in sunshine etc.), the camera vision may be adversely affected.

If the boot is open or poorly closed, the message "Boot open" appears and the camera display disappears.

REVERSING CAMERA (3/3)




Difference between the estimated distance and actual distance

Reversing towards a steep uphill slope

The fixed guidelines 3 show the distances as closer than they actually are.

The objects shown on the screen are actually further away on the slope.

For example, if the screen displays an object at **D**, the actual distance of the object is at **E**.




Reversing towards a steep downhill slope

The fixed guidelines 3 show the distances as further than they actually are.

Therefore, the objects shown on the screen are actually closer on the slope.

For example, if the screen displays an object at **G**, the actual distance of the object is at **F**.




Reversing towards a protruding object

Position **H** seems further than position **J** on the screen. However, position **H** is at the same distance as position **K**.

The trajectory indicated by the fixed and mobile guidelines do not take into account the height of the object. So there is a risk that the vehicle may collide with the object when reversing towards position **K**.

PARKING EXIT WARNING (1/4)

53873



Using information from the radars installed on each side of the rear bumper (area **A**), the system notifies the driver when another vehicle appears in the detection zone **B**.


The function is activated if:

- reverse gear is engaged;

and

- the vehicle is stationary or driving at a low speed.

49310




The system's detection capability depends on the vehicle's surroundings (static objects etc.), the condition of the bumper etc.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

49666




Special feature

Make sure that the radar area **A** is not obscured (by stickers, mud, snow etc.).

If a radar is obscured, the message "Side radars no visibility" will appear on the instrument panel. Clean the area where the sensors are located.


PARKING EXIT WARNING (2/4)



Activation/deactivation from the multimedia screen 1

To activate or deactivate the function, refer to the multimedia instructions.

Select "ON" or "OFF".




Operation

The function warns you if a vehicle is in area **B** and is approaching your vehicle.

The **2** indicator is displayed on the door mirrors **3** on both sides.

Note: clean the rear view mirrors **3** regularly so that the indicators **2** can be seen.



The **4** indicators on the multimedia screen show you on which side the approaching vehicle has been detected.

Note: clean the camera regularly so that it is not obscured.

Indicators **2** and **4** are accompanied by an audible signal when your vehicle is reversing.

PARKING EXIT WARNING (3/4)

Operating faults

If the system detects a fault, the message “Side radars to check” is displayed on the instrument panel. Consult an approved dealer.

Due to the presence of sensors behind the bumper, it is advisable to entrust any operation on the bumper (repair, replacement, paintwork, etc.) to a qualified professional.



Limitation of the system operation

- The radar area should be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects (motorcycles, bicycles, pedestrians etc.) moving towards to the vehicle may not be recognised by the system.

Deactivating the function

You must disable the function if:

- the radar area **A** has been damaged (rear bumper);
- the vehicle is fitted with a towbar that is not recognised by the system.

PARKING EXIT WARNING (4/4)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

System servicing/repairs

- In the event of a impact, the position of the radars may be changed, affecting the function. Deactivate the function and consult an authorised dealer.
- Any work in the area where the radars are located (repair, replacement, bodywork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

Deactivating the function

You must disable the function if:

- the radar area **A** has been damaged (rear bumper);
- the vehicle is fitted with a towbar that is not recognised by the system.

System disturbance

Some conditions can disturb or damage the operation of the system, such as:

- a complex environment (underground car park, steel structures etc.) ;
- poor weather conditions (snow, heavy rain, hail, black ice etc.).


Limitation of the system operation

- The radar area should be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects (motorcycles, bicycles, pedestrians etc.) moving towards to the vehicle may not be recognised by the system.

Risk of false alarms or absence of warnings

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

ASSISTED PARKING (1/5)




Using ultrasonic detectors as indicated by the **3** arrows installed in the vehicle bumpers, this function helps to find accessible parking spaces and assists in the parking manoeuvre.

Remove your hands from the steering wheel, you only control:

- the accelerator pedal;
- the brake pedal;
- the gear lever.


At any time, you can regain control by using the steering wheel.



Switching on

With the vehicle stationary or driving at less than approximately 19 mph (30 km/h):


- press switch **2**. The indicator light in switch **2** lights up and display **A** appears on the multimedia screen **1**;
- set the direction indicators to the side of the vehicle where you want to park.



Special features

Ensure that the ultrasonic sensors indicated by the arrows **3** are not obscured (by dirt, mud, snow, a badly fitted/attached number plate), impacted, modified (including paintwork) or obstructed by any accessory fitted to the front or rear of your vehicle.

ASSISTED PARKING (2/5)



Choice of manoeuvre

The system can perform four types of manoeuvres:

- parallel parking;
- perpendicular parking;
- angle parking;
- moving out of a parallel parking space.

From the **1** multimedia screen, select the manoeuvre to carry out.

Note: when starting the vehicle, or after having successfully completed parallel parking using the system, the default manoeuvre proposed by the system is assistance in exiting a parallel parking space. In other cases, the default manoeuvre can be set from the multimedia screen **1**. Please refer to the multimedia instructions for further information.

The system start up is accompanied by activation of the parking distance control and, on those vehicles equipped, the reversing camera to help the driver visualise the manoeuvre. ➡ 2.124, ➡ 2.130.

Operation

Parking

As long as the vehicle speed is less than 19 mph (30 km/h), the system searches for available parking spaces on the side of the vehicle chosen by the driver.

Note: if parking spaces are available on the other side of the vehicle, set the direction indicators to the other direction to enable the system to search for spaces.

Once a space has been found, it is displayed on the multimedia screen, indicated by a small letter “**P**”. Drive slowly, with the direction indicators activated on the side where the space is available, until the “Stop” message is displayed and a beep sounds.

ASSISTED PARKING (3/5)

The space is then indicated on the multimedia screen by a capital letter “P”.

- Stop the vehicle;
- select reverse gear.

The indicator light  lights up on the instrument panel and a beep sounds.

- Release the steering wheel;
- follow the instructions shown on the multifunction screen **1**.


Your speed should not exceed around 4 mph (7 km/h).

Once the warning light  on the instrument panel goes off and a beep sounds, the manoeuvre has been completed.



This function is an additional driving aid.

Therefore, it can under no circumstances replace the driver's vigilance and responsibility during manoeuvres (the driver must always be ready to brake).



Exiting a parallel parking space

- Briefly press the **2** switch;
- Select the “Exit parallel parking space” mode;
- activate the direction indicators on the side you wish to go out of;
- press and hold switch **2** (approx. two seconds).

The indicator light  lights up on the instrument panel and a beep sounds.

- Release the steering wheel;
- carry out manoeuvres at the front and rear by following the instructions shown on the multimedia screen **1** and using the parking distance control system alerts.


Your speed should not exceed around 4 mph (7 km/h).

Once the vehicle is in a position to exit the parking space, the  warning light disappears from the instrument panel and a sound signal and message appear on the multimedia screen **1** to confirm that the manoeuvre is complete.



When manoeuvring, the steering wheel may turn quickly: do not put your hands inside, and make sure that nothing is caught inside.

ASSISTED PARKING (4/5)



Suspending/Resuming the manoeuvre

The manoeuvre is suspended in the following circumstances:

- you take control of the wheel;
- the vehicle is stationary for too long;
- an obstacle in the direction of movement prevents the manoeuvre from being completed;
- the engine stops;
- a door or the luggage compartment is opened.

The switch warning light **2** goes out, the  warning light disappears from the instrument panel and an audible signal confirms that the manoeuvre has been suspended. The reason for suspending the manoeuvre will be displayed on the multimedia screen **1**.

Make sure:

- you have released the steering wheel;
 - that all doors and the boot are closed;
- and
- that no obstacles are in the way of the direction of movement;

and

- that the engine is started.

If the warning light on the **2** switch flashes, this indicates that the system is once again available to resume the manoeuvre.

To resume the manoeuvre, press and hold the **2** switch. The **2** switch warning

light appears and  warning light is displayed on the instrument panel.

Follow the instructions shown on the multimedia screen **1**.

Cancelling the manoeuvre

The manoeuvre is cancelled in the following cases:

- the vehicle speed has exceeded 4 mph (7 km/h);
- by pressing switch **2**;
- you have performed more than ten forwards/backwards movements in one manoeuvre;
- the parking distance control sensors are dirty or blocked;
- the vehicle wheels have skidded;
- the manoeuvre has been suspended for too long.

The **2** switch warning light and the

 warning light disappear from the instrument panel and a sound signal confirms that the manoeuvre has been cancelled. The reason for cancelling the manoeuvre will be displayed on the multimedia screen **1**.

ASSISTED PARKING (5/5)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle. Make sure that the manoeuvre complies with the applicable traffic regulations in your location.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, towing equipment, etc.) in the blind spot when manoeuvring.

System servicing/repairs

- In the event of an impact, the alignment of the sensors may be changed and their operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the sensors are located (repairs, replacements, exterior trim modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance

Certain conditions may disrupt or impair operation of the system, such as poor weather conditions (snow, hail, ice, etc.).

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

Risk of erroneous false alarms.

Limitations of the system operation

- The system cannot detect objects located in the sensor blind spots.
- Always visually check that the parking space proposed by the system is still available and contains no obstacles.
- The system should not be used when towing a trailer or when there is a towing or load carrying system on the vehicle or on surrounding vehicles.

AUTOMATIC TRANSMISSION (1/3)



Selector lever 1

P: park

R: reverse

N: Neutral

D: automatic mode

M: manual mode

+: upshifting gear

-: descending gear

The gear engaged is displayed on the instrument panel **B** and, depending on the vehicle, on the display **A**.

Note: press button **2** to go from position **D** or **N** to **R** or **P**.

40780




Operation

With the selection lever **1** in position **P**, switch on the ignition.

To move out of position **P**, you must depress the brake pedal before pressing the unlocking button **2**.

With your foot on the brake pedal (warning light  on the display goes out), move the lever out of position **P**.

Only engage D or R when the vehicle is stopped, with your foot on the brake and the accelerator pedal released.



AUTOMATIC TRANSMISSION (2/3)

Driving in automatic mode

Put lever **1** into position **D**.

In most road conditions you will encounter, you will not need to touch your lever again: the gears will change automatically at the right time and at the most suitable engine speed because the automatic system takes into account the vehicle load and road contour and adjusts itself to the particular driving style you have chosen.

Economical driving

When driving, always leave the lever in position **D**, keeping the accelerator pedal lightly depressed to ensure automatic gear changes at a lower engine speed.

Accelerating and overtaking

Depress the accelerator pedal firmly and fully (so that it goes beyond the kickdown point).

This will enable you to change down to the optimum gear within the engine range.

Driving in manual mode

With the selector lever in position **D**, move the lever to the left into the **M** position. Shifting the lever or the paddles repeatedly allows you to change gears manually:

- to move down through the gears, push the lever forwards;
- to move up through the gears, push the lever backwards.

The gear selected is displayed on the instrument panel.

Special cases

In certain driving conditions (resulting in, for example, engine protection, operation of the Electronic Stability Control programme: ESC etc.) the automated system may change the gear automatically. Likewise, to prevent incorrect manoeuvres, a gear change may be refused by the automatic system: in this case the gear display flashes for a few seconds as a warning.

Special circumstances

If the bends and road surface do not allow you to stay in automatic mode (e.g. in the mountains), we recommend that you change to manual mode. This will prevent the automatic gearbox from changing gears repeatedly when climbing, and permit engine braking on long descents.

When facing uphill, to remain stopped, do not keep your foot on the accelerator.

Risk of overheating the automatic gearbox.

AUTOMATIC TRANSMISSION (3/3)

Parking the vehicle

When the vehicle is stopped, move the lever to position **P** while keeping your foot on the brake pedal: the gearbox is in neutral and the drive wheels are mechanically locked by the driveshaft.

Apply the handbrake or, depending on the vehicle, ensure that the electronic parking brake is applied.

P position must only be engaged when the vehicle is stationary.



An impact to the underside of the vehicle while manoeuvring (e.g.: striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g.: deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.


Maintenance period

Refer to the maintenance document for your vehicle or consult an Approved Dealer to check whether the automatic gearbox requires scheduled maintenance.

If it does not need to be serviced, there is no need to top up the oil.

Operating faults

- **during driving, if the** “Check auto gearbox” message appears on the instrument panel, it indicates that there is a fault. Contact your approved Dealer as soon as possible;
- **when driving**, if the message “Gearbox overheating” appears on the instrument panel, stop as soon as possible to let the gearbox cool down and wait for the message to disappear;
- **troubleshooting on a vehicle with an automatic gearbox** ➔ 5.39.



When activated, in the event that the lever is stuck in **P**, depress the brake paddle. It is possible to free the lever manually. To do this, unclip the base of the lever, then insert a tool (rigid rod) into the slot **4** and press simultaneously on the button **2** in order to unclick the lever.

Contact an approved dealer as soon as possible.



For safety reasons, do not switch off the ignition before the vehicle has come to a complete standstill.

EMERGENCY CALL (1/3)

If the vehicle is equipped, the emergency call function can be used to call the emergency services (without charge) automatically or manually in the event of an accident or illness, reducing the time it takes for the emergency services to arrive.


Note: the emergency call operates:

- in countries covered by the associated telephone emergency services and infrastructure compatible with the system;
- depending on the network coverage in the geographical region where the vehicle is being driven.


If you use the emergency call function to report an accident which you have witnessed, this implies stopping where traffic conditions allow in order for the emergency services to locate your vehicle and therefore the location of the reported accident.

In all cases, comply with local legislation.

Use the emergency call only in the event of an emergency you are involved in, if you witness an accident or if you feel ill.



- 1** System operation warning light:
- green: operational (network available);
 - off: non-operational (network unavailable);
 - red: operating fault;
 - green flashing: call in progress.
- 2** Automatic mode warning light.
- 3** SOS button.
- 4** Microphone.
- 5** Speaker.



A call is always made as follows:

- the call is set up with the emergency services;
- send data related to the incident (vehicle identification plate, local time of the call, last positions, direction of the vehicle) ;
- voice communication with the emergency services;
- if necessary, emergency assistance is called.

Emergency call has two modes:


- automatic mode;
- Manual mode.

EMERGENCY CALL (2/3)

Automatic mode

If the automatic mode **2** warning light appears in green this confirms that the automatic system is activated.

The emergency call starts automatically in the event of an accident that has required the activation of the protective equipment (seat belt pretensioners, airbag etc.).



Manual mode

The emergency call is carried out by:

- pressing and holding the **3** button for at least 3 seconds;

or

- pressing the **3** button five times within ten seconds.

In the event of unintended operation, it is possible to cancel the call by pressing the **3** button for around two seconds, before the call is connected to the call centre.

Once a call is established, only the call centre can end the call.

Test mode

(depending on local laws)

Test mode is reserved exclusively for Approved Dealers to check that the emergency call feature is working properly.

To activate test mode:


- briefly press the **3** button three times;
- wait approximately 15 seconds;
- briefly press the **3** button three times.

Exit from test mode is automatic.



In the event of an accident, if the location and traffic conditions permit, stay close to the vehicle in order to be able answer the call centre quickly if necessary.

EMERGENCY CALL (3/3)



Operating faults

In some cases, the emergency call may not work (e.g. low battery).

If the system detects an operating fault, the **1** warning light illuminates in red for more than 30 minutes. Contact your approved Dealer as soon as possible;

The system operates with a dedicated battery. The battery service life is approximately four years (the **1** warning light lights up in red to warn you when approaching expiry).

Consult an approved dealer



To guarantee your safety and the proper operation of the system, any operation carried out on the battery (removal, disconnection, etc.) must be carried out by a qualified specialist.

Risk of serious burns or electric shocks.

You must respect the replacement intervals (without exceeding them) as stated in the maintenance document.

The battery is a specific type. Please ensure it is replaced with the same type.

Call an approved Dealer.

Without the emergency call feature, the system is not trackable and will not be under constant surveillance. Data is automatically and constantly erased, and the system stores only the last three positions of the vehicle.

According to local legislation, data is only sent in the event of an emergency call. Data sent to the call centre is treated according to the personal data protection laws applicable in the country where you are located. The system stores activity history data for 13 hours only.

The vehicle owner has the right of access to their data. They can request that the data be corrected, deleted or locked.



Section 3: Your comfort

Multi-Sense	3.2
Air Vents	3.3
Manual air conditioning, heating system	3.5
Automatic climate control	3.8
Air conditioning: information and advice on use	3.23
Outside air quality and deodorisation functions.	3.25
Multimedia equipment	3.26
Electric windows	3.28
Electric sunroof	3.30
Interior lighting	3.33
Sun visor, blinds	3.35
Passenger compartment storage/fittings.	3.36
Accessories socket	3.40
Ashtray	3.40
Cigarette lighter	3.40
Rear headrests	3.42
Rear bench seat	3.44
Luggage compartment.	3.46
Rear parcel shelf	3.50
Luggage cover.	3.51
Luggage net.	3.52
Luggage compartment storage space, fittings.	3.54
Transporting objects in the luggage compartment	3.59
Transporting objects: towbar	3.60
Roof bars	3.61

MULTI-SENSE

The MULTI-SENSE system enables you to choose between four driving modes that can be used to control: driving, ambient lighting, comfort and engine sound (depending on the vehicle):

- the Eco, Sport and Comfort modes are preconfigured and can be partially customised (ambient lighting etc.);
- the My Sense mode is customisable.

The drive modes affect the:

- power-assisted steering;
- Electronic Stability Program;
- the response of the engine and gearbox.

They also affect the:

- the lighting in the passenger compartment and of the instrument panel;
- the information on the instrument panel and multimedia screen;
- depending on the vehicle, the engine sound.

Sport mode

This mode enables an increased responsiveness from the engine and the gearbox. The steering is firmer.

Mode Eco

Eco mode focuses on energy saving. The steering is smooth, engine and gearbox management enable fuel consumption to be reduced ➔ 2.22.

My Sense mode


Using standard default vehicle settings, this mode can be used to manually configure driving, ambient lighting, comfort and engine sound (depending on the vehicle).

Mode Comfort

This mode favours smooth steering. The interior environment is softened. Depending on the vehicle, the driver's seat massage function is activated.

Any mode allows you to change the colour of the ambient lighting as well as the format of the information displayed in My Sense mode on the instrument panel and multimedia screen.

You can also reset to the default settings.



Accessing the menu

You can access MULTI-SENSE, depending on the vehicle:

- from the multimedia screen **1**;
- using the **2** switch.


Please refer to the multimedia instructions for further information.

Engine settings are specific to each of the driving modes and cannot be customised.


After the engine is switched off, the vehicle will always restart in My Sense mode.

AIR VENTS: air outlets (1/2)

48109



AIR VENTS: air outlets (2/2)



Front seats

Direction

Right/left direction

Move cursor **8**.


Up/down direction

Move cursor **8**.



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

There is a risk of damage or of fire.




Air flow

Turn control knob **9**:

to : maximum air flow;

to : closed.

To remove bad odours from your vehicles, only use the systems designed for this purpose. Consult an approved Dealer.



Rear seats

Right/left direction

Move cursor **11**.

Up/down direction

Move cursor **11**.


Air flow

Turn control knob **10**:

up: maximum flow;

down: closed.

MANUAL AIR CONDITIONING (1/3)



The controls

- 1 Adjustment of air temperature/"Clear View" function
- 2 De-icing/demisting of the rear screen and, depending on the vehicle, the rear view mirrors.
- 3 Air conditioning.
- 4 Air recirculation.
- 5 Adjusting air distribution in the passenger compartment.
- 6 Increase the fan speed.
- 7 Reduce the fan speed until the system switches off.

Indicators

The following indicators are displayed on the multimedia screen **A**:

- 8 Air temperature.
- 9 Active mode.
- 10 Fan speed.
- 11 Distribution of air in the passenger compartment.

Switching air conditioning on or off

The air conditioning is switched on (indicator light on) or off (indicator light off) using the control **3**.

The air conditioning system is used for:

- lowering the temperature inside the passenger compartment;
- eliminating condensation more quickly.



MANUAL AIR CONDITIONING (2/3)

Distribution of air in the passenger compartment

There are five air distribution options. Turn control **5** to choose the distribution option.

The air distribution is displayed on the multimedia screen.



The air flow is directed to the windscreen and the front side window demisting vents.



The air flow is distributed between all the air vents, the front side window demisting vents, the windscreen demisting vents and the footwells.




The air flow is directed mainly towards the footwells.



The air flow is directed towards the dashboard air vents, the front footwells and, depending on the vehicle, the second row footwells.



All the air flow is directed to the dashboard vents.



42411

Adjusting the air temperature

Turn control **1** to obtain the desired temperature. The more bars are displayed on the multimedia screen, the higher the temperature.


When the air conditioning system is used for long periods, it may begin to feel cold. To increase the temperature, turn control **1** to the right.

Rear screen de-icing/ demisting

With the engine running, press the control **2**. The operating tell-tale comes on.

This function permits rapid demisting/ de-icing of the rear screen and de-icing of the door mirrors (on equipped vehicles).

To exit this function, press the control **2** again. Demisting automatically stops.



Clear View function

Press the control **1**: the integrated indicator light in the button comes on.

This function quickly demists and de-ices the windscreen, the rear screen, the front side windows, and the door mirrors (depending on the vehicle). The air conditioning and rear screen de-icing functions must be activated.

Switching the air recirculation on

Press the control **4**: the integrated indicator light in the button comes on. Under these conditions, air is taken from the passenger compartment and is recirculated, with no air being taken from outside the vehicle. **Air recirculation operates as follows:**

- isolating the vehicle from the external atmosphere (driving in polluted areas, etc.);
- lowering the passenger compartment temperature as quickly as possible.

Varying the ventilation speed

You can adjust the fan speed by pressing the controls **6** or **7** to increase or reduce the fan speed.

The system is deactivated (OFF): the ventilation speed is zero (vehicle stationary). You may, however, feel a slight flow of air when the vehicle is moving.


Stopping the system

To switch-off the system, press control **7** several times until “OFF” appears on the multimedia screen.

You may, however, feel a slight flow of air when the vehicle is moving.

Prolonged use of air recirculation can lead to condensation forming on the side windows and windscreen, and discomfort due to the use of non-renewed air in the passenger compartment. We therefore advise you to return to normal mode (external air) as soon as the air recirculation function is no longer required, by pressing the control **4** again.

AUTOMATIC CLIMATE CONTROL: Control A (1/5)




The controls A

To access the automatic climate control settings from the multimedia screen **1**, refer to the multimedia instructions.

The presence of the controls detailed below will depend on the vehicle model.


- 2** Left and right programmed temperature adjustment.
- 3** Air recirculation.
- 4** Reduce the fan speed until the system switches off.
- 5** Increase the fan speed.
- 6, 14, 15** and **16** automatic modes



- 7** Short cut to the air conditioning page.
- 8** SYNC "Synchronisation" function.
- 9** De-icing/demisting of the rear screen and, depending on the vehicle, the rear view mirrors
- 10** "Clear View" function.
- 11** Air conditioning.
- 12** Additional air conditioning mode OFF
- 13** Fan speed display.
- 17, 18** and **19** Passenger compartment air distribution.
- 20** Additional air conditioning mode Auto
- 21** Additional Air Conditioning Manual Mode

Some buttons have a warning light indicating their operative state.

AUTOMATIC CLIMATE CONTROL: Control A (2/5)




Varying the ventilation speed

In automatic mode, the system uses the most suitable amount of air to reach and maintain the desired comfort level.

You can still adjust the fan speed by pressing switch **4** or **5**.

Note: the configuration of the air conditioning depends on the mode selected in the MULTI-SENSE menu ➔ 3.2.



Temperature adjustment

There are two types of settings:

- independent adjustment of the passenger compartment;
- adjustment in SYNC mode to synchronise the passenger's side and the driver's side.

SYNC function

Press the **8** button to enable uniform setting of the passenger compartment. The **8** button light will illuminate. Then use control **11**.

To deactivate the function, press the **8** button again or use the **2** control and adjust the right-hand side separately from the left-hand side.

The **2** button warning light switches off.


Note: the air conditioning configuration depends on the mode selected in the Multi-Sense menu ➔ 3.2.

The displayed temperature values show a comfort level.

When starting the engine, increasing or decreasing the value displayed will not allow the comfort level to be reached any more quickly. The system will always optimise the temperature increase or decrease (the ventilation system does not start instantly at maximum speed: it gradually increases). This may take several minutes.

Generally speaking, unless there is a particular reason not to, the dashboard air vents should remain open.


AUTOMATIC CLIMATE CONTROL: Control A (3/5)



Clear View function

This function quickly demists and de-ices the windscreen, the rear screen, the front side windows, and the door mirrors (depending on the vehicle). It imposes automatic operation of the air conditioning and rear screen de-icing and, depending on the vehicle, the windscreen electric de-icer.

Press switch **10**. The built-in indicator light comes on.



Press button **9** to switch off the heated rear screen function. The built-in indicator goes out.

To change the fan speed: press switch **4** or **5**.

To exit this function,

press either:

- switch **6**;
- switch **10** again;
- on button **14**, **15** or **16**.

Automatic mode

The automatic climate control system guarantees comfort in the passenger compartment and good visibility (except in the event of extreme conditions), while optimising consumption. The system controls the ventilation speed, air distribution, air recirculation, and starting and stopping the air conditioning and air temperature.


This mode consists of a choice of three programmes:

NORMAL: allows the selected comfort level to be best attained, depending on the exterior conditions. Press switch **6** or button **15**.

SOFT: reaches the desired comfort level more gently and silently. Press button **14**.

FAST: increases the flow of air in the passenger compartment. This mode is recommended in particular to optimise comfort in the rear seats. Press button **16**.

AUTOMATIC CLIMATE CONTROL: Control A (4/5)




Switching air conditioning on or off

In automatic mode, the system switches the air conditioning system on or off, depending on the climate conditions.

Press button **11** to:

- activate the air conditioning manually (the indicator light in the control **11** comes on);
- deactivate the air conditioning manually (the indicator light in the control **11** goes out);



Stopping the system

Press switch **4** repeatedly to stop the system.

Rear screen de-icing/demisting

Press switch **9**. The built-in indicator light comes on. This function enables rapid demisting or de-icing of the rear screen and de-icing of the rear view mirrors (on equipped vehicles).

To exit the function, press switch **9** again. Demisting automatically stops.

It is preferable to use one of the automatic programmes NORMAL, SOFT or FAST.

In automatic mode (switch indicator light **6** is lit), all air conditioning functions are controlled by the system.

You can still change the system's choice; in this case, the switch indicator light **6** goes out.

To return to automatic mode, press one of the programmes (**NORMAL 15**, **SOFT 14** or **FAST 16**) or switch **6**.


AUTOMATIC CLIMATE CONTROL: Control A (5/5)



Adjusting the distribution of air in the passenger compartment

Press buttons **17**, **18** and **19** to select the distribution mode desired (the air flow selected is displayed).

- 17** The air flow is mainly directed to the demisting vents for the windscreen and the side windows.
- 18** The air flow is mainly directed to the dashboard air vents.
- 19** The air flow is directed mainly towards the footwells.



Air recirculation

This function is managed automatically but you can also activate it manually.

Note:

- during recirculation, air is taken from the passenger compartment and is recycled, with no air being taken from outside the vehicle;
- air recirculation allows the external atmosphere to be cut off (when driving in polluted areas, etc.) and to cool the passenger compartment temperature more quickly.

Manual use

Press switch **3**. The indicator light in the switch **3** comes on.


Prolonged use of this position may lead to odours, caused by non-renewal of air, and the formation of condensation on the windows.

We therefore advise you to return to automatic mode as soon as air recirculation is no longer needed, by pressing switch **3**.

To exit the function, press switch **3** again.

The demisting/de-icing will still take priority over the air recirculation.

AUTOMATIC CLIMATE CONTROL: Control B (1/5)



The controls

(depending on the vehicle)

- 1 Adjusting the driver's side air temperature.
- 2 Air-conditioning activation control.
- 3 "Clear View" function.
- 4 Adjusting the ventilation fan speed.
- 5 Distribution of air in the passenger compartment.
- 6 Outside air quality.
- 7 **SYNC** "Synchronisation" function.
- 8 Adjusting the passenger's side air temperature.

- 9 Air recirculation.
- 10 **"FAST"** automatic mode.
- 11 **"AUTO"** automatic mode.
- 12 **"SOFT"** automatic mode.
- 13 De-icing/demisting of the rear screen and, depending on the vehicle, the rear view mirrors.

Any action on a button other than the **AUTO** button triggers deactivation of automatic mode.

Automatic mode

The automatic climate control system guarantees comfort in the passenger compartment and good visibility (except in the event of extreme conditions), while optimising consumption. The system controls the ventilation speed, air distribution, air recirculation, and starting and stopping the air conditioning and air temperature.

This mode consists of a choice of three programmes:

AUTO: allows the selected comfort level to be best attained, depending on the exterior conditions. Press button **11**.

SOFT: reaches the desired comfort level more gently and silently. Press button **12**.

FAST: increases the flow of air in the passenger compartment. This mode is recommended in particular to optimise comfort in the rear seats. Press button **10**.

AUTOMATIC CLIMATE CONTROL: Control B (2/5)

Adjusting the ventilation speed.


In automatic mode, the system uses the most suitable amount of air to reach and maintain the desired comfort level.

You can still adjust the ventilation speed by turning control **4** to increase or reduce the ventilation speed.

Adjusting the air temperature

Turn control **1** or control **8** according to the temperature required.

Turning the control to the right increases the temperature.



SYNC function

Press the **7** button to enable uniform setting of the passenger compartment. The **7** button light will illuminate.

To deactivate the function, press the **7** button again or use the **8** control and adjust the right-hand side separately from the left-hand side.

The **7** button warning light switches off.

Note: the air conditioning configuration depends on the mode selected in the Multi-Sense menu ➔ 3.2.

AUTOMATIC CLIMATE CONTROL: Control B (3/5)


Clear View function

Press the **3** button: the integrated indicator light comes on.

This function quickly demists and de-ices the windscreen, the rear screen, the front side windows, and the door mirrors (depending on the vehicle). It automatically activates the air conditioning and rear screen de-icing functions.

Press button **13** to stop the heated rear screen operating, and the integrated indicator goes out.

To exit this function, press button **3** or **11**.



Adjusting the distribution of air in the passenger compartment

Press the **5** control as many times as necessary to select the passenger compartment air distribution mode. **5** is displayed to indicate the distribution mode selected.



All the air is then directed to the windscreen and front side window demisting vents.



The air flow is distributed between front side window demisting vents, the windscreen demisting vents and the footwells.



The air flow is directed towards the dashboard air vents, the front footwells and, depending on the vehicle, the second row footwells.



The air flow is mainly directed to the dashboard air vents.



The air flow is directed mainly towards the footwells.

Some buttons have an operating tell-tale which indicates the operating status.

AUTOMATIC CLIMATE CONTROL: Control B (4/5)



Rear screen de-icing/demisting

Press the **13** button: the integrated indicator light comes on. This function enables rapid demisting or de-icing of the rear screen and de-icing of the rear view mirrors (on equipped vehicles).


To exit this function, press button **13** again. Demisting automatically stops.

Switching air conditioning on or off

In automatic mode, the system switches the air conditioning system on or off, depending on the climate conditions.


Press the **2** button to deactivate the air conditioning. The integrated indicator light goes off.

Fuel consumption increases when the air conditioning is being used (switch it off when it is not required).



Vehicles equipped with ECO mode (switch 14 or, depending on the vehicle, from the multimedia screen): when activated, ECO mode may reduce the performance of the automatic air conditioning. ➡ 2.22 ➡ 3.2.

AUTOMATIC CLIMATE CONTROL: Control B (5/5)



Air recirculation (isolation of the passenger compartment)

This function is managed automatically but you can also activate it manually. In this case, the operation is confirmed by a warning light on the button **9**.

Manual use

Press the **9** button: the integrated indicator light comes on.

Prolonged use of this position may lead to odours, caused by non-renewal of air, and the formation of condensation on the windows.


We therefore advise you to return to automatic mode as soon as air recirculation is no longer needed, by pressing button **9**.

Stopping the system

Turn the control **4** to “OFF” to stop the system. To start it, turn the control **4** again, then adjust the fan speed or press the button **11**.

The demisting/de-icing will still take priority over the air recirculation.

AUTOMATIC CLIMATE CONTROL: Control C (1/5)



C control

- 5 and 11 Left and right temperature indication adjustment.
- 6 De-icing/demisting of the rear screen and, depending on the vehicle, the door mirrors.
- 7 Passenger compartment air distribution.
- 8 “Automatic recirculation” function.
- 9 Air recirculation.

- 10 “Clear View” function.
- 12 and 18 Ventilation speeds.
- 13 SYNC “Synchronisation” function.
- 14, 15 and 16 Automatic modes.
- 17 Air conditioning.

Indicators

The following indicators are displayed on the screen 3:

- 1 Active mode, ventilation speed and air distribution in the passenger compartment (temporary display after pressing the associated controls).
- 2 Outside air temperature.
- 4 Air temperature, left and right.

Automatic mode

The automatic climate control system guarantees comfort in the passenger compartment and good visibility (except in the event of extreme conditions), while optimising consumption. The system controls the ventilation speed, air distribution, air recirculation, and starting and stopping the air conditioning and air temperature.

This mode consists of a choice of three programmes:

AUTO: allows the selected comfort level to be best attained, depending on the exterior conditions. Press the button 15.

SOFT: reaches the desired comfort level more gently and silently. Press the button 14.

FAST: increases the flow of air in the passenger compartment. This mode is recommended in particular to optimise comfort in the rear seats. Press the button 16.

Some buttons have a warning light indicating their operative state.

AUTOMATIC CLIMATE CONTROL: Control C (2/5)



Varying the ventilation speed

In automatic mode, the system uses the most suitable amount of air to reach and maintain the desired comfort level.

You will still be able to adjust the fan speed by pressing buttons **12** or **18**.

Temperature adjustment

There are two types of settings:

- independent adjustment of the passenger compartment;
- adjustment in SYNC mode to synchronise the passenger's and driver's settings.

Adjustment of the passenger compartment

Use control **11**.

SYNC function

Press the **13** button to activate. The **13** button warning light illuminates.

To deactivate the function, press the **13** button again or use the **5** control and adjust the right-hand side separately from the left-hand side.

The **13** button warning light switches off.

Note: the air conditioning configuration depends on the mode selected in the Multi-Sense menu ➔ 3.2.

To deactivate the function, press the **13** button again or use the **5** control and adjust the right-hand side separately from the left-hand side.

Note: the air conditioning configuration depends on the mode selected in the Multi-Sense menu ➔ 3.2.

The displayed temperature values show a comfort level.

When starting the engine, increasing or decreasing the value displayed will not allow the comfort level to be reached any more quickly. The system will always optimise the temperature increase or decrease (the ventilation system does not start instantly at maximum speed: it gradually increases). This may take several minutes.

Generally speaking, unless there is a particular reason not to, the dashboard air vents should remain open.

AUTOMATIC CLIMATE CONTROL: Control C (3/5)



Clear View function

This function quickly demists and de-ices the windscreen, the rear screen, the front side windows, and the door mirrors (depending on the vehicle). It imposes automatic operation of the air conditioning and rear screen de-icing and, depending on the vehicle, the windscreen electric de-icer.

Press button **10** – the integrated indicator light comes on.

Press button **6** to stop the heated rear screen operating, and the integrated indicator goes out.

To change the fan speed: press buttons **12** or **18**.

To exit this function, press either:

- again button **10**;
- one of the buttons **14**, **15** or **16**.

AUTOMATIC CLIMATE CONTROL: Control C (4/5)



Switching air conditioning on or off

In automatic mode, the system switches the air conditioning system on or off, depending on the climate conditions.

Press button **17** to:

- activate the air conditioning (the warning light in zone **1** illuminates).
- deactivate the air conditioning (the warning light in zone **1** goes out).

Stopping the system

To switch the system off, press button **12** repeatedly until the message **OFF** appears in zone **1**.

It is preferable to use one of the automatic programmes **AUTO, **SOFT** or **FAST**.**

In automatic mode (indicator light on button **14**, **15** or **16** lit), all air conditioning functions are controlled by the system.

You can still modify the system's choice; in this case, the indicator light on the button **14**, **15** or **16** goes out.

To return to automatic mode, press one of programmes **AUTO 15**, **SOFT 14** or **FAST 16**.

Rear screen de-icing/demisting

Press button **6** – the integrated indicator light comes on. This function enables rapid demisting or de-icing of the rear screen and de-icing of the door mirrors (on equipped vehicles).

To exit this function, press button **6** again. Demisting automatically stops.

AUTOMATIC CLIMATE CONTROL: Control C (5/5)



Adjusting the distribution of air in the passenger compartment

Press buttons **7** to select the desired distribution (a warning light is displayed in zone **1**):



The air flow is mainly directed to the demisting vents for the windscreen and the side windows.



The air flow is mainly directed to the dashboard air vents.



The air flow is directed mainly towards the footwells.

Air recirculation

This function is managed automatically but you can also activate it manually.

Note:

- during recirculation, air is taken from the passenger compartment and is recycled, with no air being taken from outside the vehicle;
- air recirculation allows the external atmosphere to be cut off (when driving in polluted areas, etc.) and to cool the passenger compartment temperature more quickly.

Automatic use

Press button **8** (a warning light comes on in zone **1**).

The demisting/de-icing will still take priority over the air recirculation.

Manual use

Press button **9** to force air recirculation.

Prolonged use of this position may lead to odours, caused by non-renewal of air, and the formation of condensation on the windows.

We advise you to return to automatic mode as soon as air recirculation is no longer needed, by pressing button **8** or button **9** again.

To exit this function, press button **8** or button **9** again.

AIR CONDITIONING: information and operating instructions (1/2)

Advice on use

In some situations (air conditioning off, air recirculation activated, ventilation speed at zero or low etc.), you may notice that condensation starts to form on the windows and windscreen.

If there is condensation, use the “**Clear View**” function to remove it, then use the air conditioning in automatic mode to stop it forming again.

Vehicles equipped with mode ECO

Once activated, ECO mode may reduce air conditioning performance. ➔ 2.22.



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

There is a risk of damage or of fire.

Fuel consumption

You will normally notice an increase in fuel consumption (especially in town) when the air conditioning is operating. For vehicles fitted with air conditioning with no automatic mode, switch off the system when it is not required.

Advice for reducing consumption and helping to preserve the environment

Drive with the air vents open and the windows closed. If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

Maintenance

Refer to the Maintenance Document for your vehicle for the inspection frequency.

Use the air conditioning system regularly, even in cold weather, running it at least once a month for approximately 5 minutes.

Operating faults

As a general rule, contact your approved dealer in the event of an operating fault.

– Reduction in de-icing, demisting or air conditioning performance.

This may be caused by the passenger compartment filter cartridge becoming clogged.

– No cold air is being produced.

Check that the controls are set correctly and that the fuses are sound. Otherwise, switch off the system.


Presence of water under the vehicle

After prolonged use of the air conditioning system, it is normal for water to be present under the vehicle. This is caused by condensation.



Do not open the refrigerant fluid circuit. The fluid may damage eyes or skin.

AIR CONDITIONING: information and operating instructions (2/2)



42430

The refrigerant fluid circuit (of which some components are hermetically sealed) may contain fluorinated greenhouse gases.

Depending on the vehicle, you will find the following information on label **A** affixed inside the engine compartment.

The presence and location of the information on label **A** depends on the vehicle.



Do not open the refrigerant circuit. The fluid may damage eyes or skin.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4

➔ 2.5.



Type of refrigerant fluid



Type of oil in the air conditioning circuit



Inflammable product



Consult the driver's handbook



Maintenance

x.xxx kg

Quantity of refrigerant fluid present in the vehicle.

GWP xxxxx

Global Warming Potential (CO2 equivalent).

CO2 eq
x.xx t

Quantity in weight and in CO2 equivalent.

OUTSIDE AIR QUALITY AND DEODORISATION FUNCTION




To access the function from the multimedia screen **1**, refer to the multimedia instructions.

Outside air quality

The quality of the air in the vehicle is shown via an explanatory text and an animation on the multimedia screen.

Please refer to the multimedia equipment instructions for further information.


MULTIMEDIA EQUIPMENT (1/2)



Multimedia settings

- 1 Multimedia screen;
- 2 Steering column controls;
- 3 Steering wheel controls;
- 4 Microphone.

Refer to the equipment instructions for information on how to operate this equipment.



Hands-free telephone integrated control

For equipped vehicles, use the steering wheel controls 3.




Using the telephone

We remind you of the need to conform to the legislation in force concerning the use of such equipment.




MULTIMEDIA EQUIPMENT (2/2)



Multimedia sockets 5

You can use the USB ports or, depending on the vehicle, the SD card reader to access the multimedia content of your accessories and the system update (please refer to the equipment instructions).

The various sources can be selected from the multimedia screen and from the steering column controls.



The sockets USB can also recharge accessories with a maximum power rating of 12 Watts (voltage: 5V) per socket, which have been approved by our Technical Department.

The JACK socket enables the radio to be used with an auxiliary cable.



Connect accessories with a maximum power of 12 watts only.

Fire hazard.



ELECTRIC WINDOWS (1/2)

Electric windows

These systems operate:

- with the engine running;
- with the ignition off until one of the front doors is opened (limited to approximately 12 minutes).
- with the engine off, front doors closed, after pressing the start button.

Press the window switch down or pull it up to lower or raise the window to the desired height: the rear windows do not open fully.



From the driver's seat, use switch:

- 1** for the driver's side;
- 2** for the front passenger side;
- 3** and **5** for the rear passenger windows.

From the passenger seats, use switch **6**.



Safety of rear occupants

The driver can prevent operation of the rear electric windows by pressing switch **4**. A confirmation message is displayed on the instrument panel.

Driver's responsibility

Never leave your vehicle with the card or key inside when there is a child, dependent adult or a pet in it, even for a short while. They may pose a risk to themselves or to others by starting the engine or activating equipment (such as the gear lever or electric windows). If any part of the body becomes trapped, reverse the direction of the window immediately by pressing the relevant switch.

Risk of serious injury.

Avoid resting any objects against a half-open window: there is a risk that the electric window could be damaged.

ELECTRIC WINDOWS (2/2)

One-touch mode

This mode works in addition to the operation of the electric windows described previously.

Briefly press or pull the window switch fully: the window is fully lowered or raised. Pressing the switch again stops the window moving.

Impossible to operate the one-touch electric window

The one-touch electric window is equipped with heat protection: if you press the switch for the window more than sixteen consecutive times it goes into protection mode (locking the window).

You can:

- use the electric window switch briefly and with intervals of approximately 30 seconds;
- with the engine running, the window will be unlocked after approximately 20 minutes of inaction on the electric window switch.

Note: if the window detects resistance when closing (e.g.: branch of a tree, etc.) it stops and then lowers again by a few centimetres.

Remote control window closing

(vehicles with 4 one-touch electric windows).

When you lock the doors from the outside, **press the locking button on the card twice in quick succession, or on the driver's door** in hands-free mode, and all the windows will close automatically (including the sunroof, if present). It is recommended that the user only operates the system when the vehicle can be seen clearly and no one is inside.

Operating faults

In case of a fault when closing a window, the system reverts to normal mode: pull the switch concerned up as often as necessary to fully close the window, then hold the switch (still on the closure side) for approximately one second, then lower and raise the window fully to reinitialise the system. If necessary, contact an approved Dealer.



Manual window winder controls


Turn handle 7.



When closing the windows, ensure that no part of the body (arm, hand, etc.) is protruding from the vehicle.


Risk of serious injury.

ELECTRIC SUNROOF (1/3)



To slide the curtain 1

- **To open:** push the handle **2** rearwards to move the blind to the desired position;
- **to close:** pull the handle **2** forwards to move the blind to the desired position.



To slide the sunroof

- **To tilt:** move the marked position **3** to position **A**;
- **to open:** move the marked position **3** to position **B**, **C** or **D** depending on the type of opening required;
- **to close:** move the marked position **3** to position **0**.



Driver's responsibility

Never leave an animal, child or non-autonomous adult alone in your vehicle, even for a short time.

The reason for this is that the child may endanger himself or others by starting the engine, activating equipment such as the window winders for example, or locking the doors.

If something gets trapped, reverse the direction of travel as soon as possible by turning button **4** fully to the right (position **D**).

Risk of serious injury.

ELECTRIC SUNROOF (2/3)

Closing the sunroof by remote control


If you **press twice on the card locking button in quick succession or on the driver's door locking button in hands-free mode**, all the windows and the sunroof will lock automatically.

It is recommended that the user only operates the system when the vehicle can be seen clearly and no one is inside.



If the vehicle is equipped with this function, this action will activate deadlocking.
➔ 1.5 or ➔ 1.13.

Check that there is no-one still inside the vehicle



Special features

Your vehicle is fitted with an anti-pinch facility: when the sunroof encounters resistance whilst closing (branch of a tree, etc.), it stops and then moves back a few centimetres.

After closing the sunroof by remote control, pressing button **4** allows the sunroof to return to its previous position.


The sunroof will not open when the temperature is below -20°C. However, it will still close.



When closing the sunroof, ensure that no part of the body (arm, hand, etc.) is protruding from the vehicle.

Risk of serious injury.

ELECTRIC SUNROOF (3/3)



Operating faults

If the sunroof will not close, move the marked position **3** to position **0** then press button **4** until the sunroof is completely closed: consult an approved dealer.

Important: during this operation, the sunroof anti-pinch function is deactivated. Contact your approved Dealer as soon as possible.

Precautions during use

– Vehicle with loaded roof bars.

As a general rule, if there is a load on the roof, use of the sunroof is not recommended.

Before using the sunroof, check the objects and/or accessories (bike racks, roof boxes, etc.) attached to the roof bars: they should be properly arranged and secured and should not interfere with the operation of the sunroof.

Contact an approved dealer for details of possible conversions;

- **check** that the sunroof is properly closed before leaving your vehicle;
- **clean** the seal every three months using products recommended by our Technical Department;
- **do not open** the sunroof immediately after it has rained or immediately after washing the vehicle.



Driver's responsibility

Never leave an animal, child or non-autonomous adult alone in your vehicle, even for a short time.

The reason for this is that the child may endanger himself or others by starting the engine, activating equipment such as the window winders for example, or locking the doors.

If something gets trapped, reverse the direction of travel as soon as possible by turning button **4** fully to the right (position **D**).

Risk of serious injury.

INTERIOR LIGHTING (1/2)




Map reading lights

Press switch **1** to get:

- permanent lighting;
- immediate switching off.

When the doors or boot are unlocked and opened, the reading and footwell lights come on temporarily.




Courtesy light

Press switch **3** for:

- permanent lighting;
- intermittent lighting, which comes on when a door is opened. It only switches off after a time delay and when the doors concerned have been closed correctly;
- lighting switches off immediately.

Map reading lights

Press switches **2** and **4**.



Note: on vehicles equipped with a multimedia system, from the multimedia screen (➔ 1.92) you can:


- deactivate/activate illumination of the courtesy lights upon opening of the luggage compartment doors;
- depending on the vehicle, change the colour of the ambient light (8 possible choices).

Glove box light 5

The light comes on when the cover is opened.

INTERIOR LIGHTING (2/2)


48157



Luggage compartment light 6

The light comes on when the luggage compartment is opened.

41179




48240



With the doors properly shut, locking or starting the engine makes the interior lights and the courtesy lights go out.

SUN VISOR, BLINDS




Front sun visor

Lower the sun visor **1** on the windscreen or unclip it and lower it over the side window.

Vanity mirror

Lift the cover **3**.

The light **2** switches on automatically.




Ticket holder **4**

Can be used to hold motorway toll tickets, maps, etc.



When driving, ensure the courtesy mirror cover is closed. Risk of injury.

PASSENGER COMPARTMENT STORAGE SPACE AND FITTINGS (1/4)



Door pockets 1


It can hold a bottle.



Passenger storage compartment

Pull handle 2 to open it.

The glove box can hold A4-sized documents, a bottle etc.



Sun blind storage compartment 3

This can be used for storing motorway tickets, cards, etc.




Ensure that no hard, heavy or pointed objects are placed in the “open” storage compartments in such a way that they may fall onto passengers during sudden turning or braking.



Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.


PASSENGER COMPARTMENT STORAGE SPACE AND FITTINGS (2/4)



Central storage compartment 5

A sliding system 6 holds maintains the cups.

Central storage compartment 4




Cup holders 7




When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged.

There is a risk of burning if hot liquid escapes.





Ensure that no hard, heavy or pointed objects are placed in the "open" storage compartments in such a way that they may fall onto passengers during sudden turning or braking.

PASSENGER COMPARTMENT STORAGE SPACE AND FITTINGS (3/4)



Central storage compartment 9

With the sliding armrest **8** in its rear-most position, raise it.



Grab handle 10

This offers support and can be held when the vehicle is being driven.

Do not use it for getting into or out of the vehicle.

Clothes hooks 11



Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.


PASSENGER COMPARTMENT STORAGE SPACE AND FITTINGS (4/4)



Rear door storage compartment 12



Ensure that no hard, heavy or pointed objects are placed in the “open” storage compartments in such a way that they may fall onto passengers during sudden turning or braking.



Front seat storage pockets 13

Rear central storage compartment 14



Rear armrest with cup holder


Lower armrest 15.



When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged.

There is a risk of burning if hot liquid escapes.


ASHTRAY, CIGARETTE LIGHTER, ACCESSORIES SOCKET (1/2)



Cigarette lighter 1

With the ignition on, push in cigar lighter **1**, it will spring back with a click when it is ready. Pull it out to use. After use, replace it without pushing it all the way in.

If your vehicle is not fitted with a cigar lighter and an ashtray, these can be obtained from an authorised dealer.



Ashtray 3

It can be housed in either position **2**.

To open, lift the cover. To empty, pull the ashtray towards you and it will be released from its housing **2**.





Connect accessories with a maximum power of 120 watts (12 V) only.

When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.

Fire hazard.

ASHTRAY, CIGARETTE LIGHTER, ACCESSORIES SOCKET (2/2)



Accessories sockets 4

You can use the one of sockets **4**. They are provided for connecting accessories approved by our Technical Department.




Connect accessories with a maximum power of 120 watts (12 V) only.

When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.

Fire hazard.

REAR HEADRESTS (1/2)




Position for using the central headrest A

Lift the headrest fully until it locks.

Check that the bonnet is correctly locked.




The headrest is a safety component; check that it is fitted and in the correct position.



Centre seat headrest B storage position

Press the button **1** and lower the headrest completely.

Set the headrest at the lowest position or tilted forwards for storage only: do not set it in this position when the seat is occupied or if the child seat is fitted.



To remove a headrest


Raise the headrest as far as it will go, then press button **1** and remove the headrest.

To refit a headrest

Insert the rods in the holes, press the button **1** and lower the headrest.

Check that the bonnet is correctly locked.

REAR HEADRESTS (2/2)





Storage position for the side headrests

Press the button **1** and, depending on the vehicle:


- fully lower (movement **A**) the headrest **2**;

or

- lower and tilt (movement **B**) the headrest **3** fully forwards.



REAR BENCH SEAT (1/2)




To manually fold down the seatbacks

Ensure that the front seats are far enough forward.

Raise the side headrests to the highest position and lower the central headrest fully.

Depending on the vehicle, put the seat belt in the belt guide **2** to avoid damaging it, or buckle it its own unit. This will prevent the seat belt becoming trapped when the seat is returned to its position for use. In all cases, check that the seat belts are operating correctly.



Pull the control **1** and lower the seatback **A**.

To replace the seatback, proceed in the reverse order to removal. Refit the seatback and click it back into place.



For safety reasons, carry out any adjustments when the vehicle is not being driven.



The configuration of the two-seat bench with the small seatback **B** pulled down, does not allow the central seat to be used as it would be impossible to buckle the seat belt (belt buckles inaccessible).




When refitting the seat-back, make sure it is correctly locked in place.

If seat covers are fitted, make sure these do not prevent the seatback latch from locking in. Make sure that the seat belts are positioned correctly. Reposition the headrests.



When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).

REAR BENCH SEAT (2/2)



To automatically fold down the seatbacks (flat position)

(Estate version)

From the boot, pulling the control **3** enables you to automatically unlock the rear bench seatbacks to get a flat floor.

Conditions of use

- Vehicle stationary;
- luggage compartment lid open;
- rear seat belts locked.

Operating faults

If all user conditions have been fulfilled and the folding action still fails to operate, please contact an authorised dealer.



When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).


LUGGAGE COMPARTMENT: 4 DOOR VERSION (1/3)

Conditions of use

- Immobilise the vehicle.
- If there is any ice or snow preventing the luggage compartment door from opening, this ice or snow must be removed to free the luggage compartment door.
- In the event that the battery is discharged or if it is changed, the luggage compartment must be closed (manually if necessary) to restart the luggage compartment door motor.

Depending on the vehicle, there are various ways to unlock and operate the luggage compartment lid:

- using the locking/unlocking button on the remote control key ➔ 1.4;
- using the locking/unlocking button on the card ➔ 1.9;
- via the external boot lid control;
- using the hands-free function;
- using the dashboard control.



As a safety precaution, the doors should only be opened or closed when the vehicle is stationary.

Risk of injury.



Ensure that nobody is close to the moving parts when opening/closing the boot lid.

Risk of injury.



Manual controls


To open

Depending on the vehicle, press the dashboard control **1** or the button **2**, the tailgate opens automatically.

Note: ensure that the surrounding space is sufficient to permit operation of the boot lid before you open it.

When opening or closing the luggage compartment lid, ensure that nothing obstructs the manoeuvre.

LUGGAGE COMPARTMENT: 4-DOOR VERSION (2/3)



To close

Lower the boot lid using the handle inside the boot to assist you.



Using the hands-free function

The hands-free function enables access to the luggage compartment when you have your hands full.

Ensure that the card is approximately one metre away in the central area of the rear bumper of the vehicle (area **B**).

With the ignition off, stand approximately 45 centimetres from the vehicle's rear bumper and move your foot forwards and backwards in area **A**.

The sensor detects the approach and then the removal of your foot and triggers the opening of the boot lid.

Do not keep your foot in the air.

Perform the movement without stopping and without touching the rear bumper.



Disable the "hands-free" function before you:

- wash the vehicle in a roller-type car wash;
- wash the vehicle by hand;
- handle the towbar;
- ...

Risk of accidental opening of the luggage compartment lid which may cause injury.

LUGGAGE COMPARTMENT: 4-DOOR VERSION (3/3)

Activation/deactivation of the hands-free function

To activate or deactivate the function, refer to the multimedia instructions.

Select “ON” or “OFF”.

Usage features of the hands-free function

- The hands-free function is no longer available after a few days of lack of movement of the vehicle, or after around 15 minutes if the vehicle is unlocked. To reactivate it, use the unlocking button on the card.
- The hands-free function is only available if the vehicle is stationary and the engine is switched off (and not on standby with the Stop and start function).
- The ‘hands-free’ feature may not work if the vehicle is equipped with a towbar or is in an area of high electromagnetic radiation.

User precautions

- Before opening the tailgate, ensure that the surrounding space is sufficient to permit operation of the tailgate. Otherwise, stop the movement of the boot lid before it makes contact.
- The system may experience temporary difficulties if one of the sensors integrated in the rear of the bumper is obscured (by dirt, mud, snow, gritting salt, etc.). Clean the sensors. If there is still a problem, contact an approved dealer.

Note: in very cold weather conditions, the automatic opening may not work if the tailgate seals are frozen.



The attachment of any carrying device (bike rack, luggage box etc.) resting on the luggage compartment lid is prohibited.

To install a carrying device on your vehicle, contact an Approved Dealer.




41399

Opening the doors manually from the inside

If it is impossible to unlock the tailgate, it can be done manually from inside:

- access the luggage compartment by folding forward the seatback(s) of the rear bench seat;
- insert a flat-blade screwdriver or similar under the carpet above the mechanism **3** and slide the unit as shown in the illustration;
- push the boot lid to open it.

LUGGAGE COMPARTMENT: 5-DOOR VERSION




To open

Press button **1** and lift the tailgate.

To close

Lower the tailgate using the handles **2** inside the tailgate to help you.



Opening manually from inside the vehicle

Special note:


If it is impossible to unlock the tailgate, it can be done manually from inside:

- access the luggage compartment by folding forward the seatback(s) of the rear bench seat;
- insert a pencil or similar object in recess **3** and slide the unit as shown in the illustration;
- push the tailgate to open it.



The attaching of any carrying device (bike rack, luggage box, etc.) resting on the luggage compartment lid is prohibited. To install a carrying device on your vehicle, contact an Approved Dealer.

REAR PARCEL SHELF



Removal

Unhook the two cords **1** (tailgate side).




Unclip the rear parcel shelf **2** and pull it towards you.

To refit it, proceed in reverse order to removal.



Do not place any heavy or hard object on the parcel shelf. These may pose a risk to the vehicle occupants if the driver has to brake suddenly or if the vehicle is involved in an accident.


LUGGAGE COMPARTMENT COVER



To remove the flexible section of the luggage compartment cover 2

Press handle **1** to release the pins from their mounting points located on each side of the luggage compartment.

Allow the luggage cover to roll up.




Removing/refitting the luggage cover 2

Slide section **3** (movement **A**) and lift the right-hand side (movement **B**) of the roller at the same time.

Then lift the left-hand side of the roller and then remove the assembly.

To refit the luggage cover, carry out this procedure in reverse.



Luggage compartment cover storage 2

Lift section **4** of the luggage compartment floor.

Pivot the luggage cover so that the handle **1** is visible and towards the front of the vehicle.

Store the luggage cover, handle **1** forwards, firstly by inserting the left-hand side into its housing, then insert the right-hand side (movement **C**) by sliding section **3** (movement **A**).

Close the luggage compartment floor.



Do not place any heavy or solid objects on the luggage cover. These may pose a risk to the vehicle occupants if the driver has to brake suddenly or if the vehicle is involved in an accident.

LUGGAGE NET (1/2)



Depending on the vehicle, this may be used when transporting animals or luggage to isolate them from the passenger section.


It can be positioned:

- behind the rear seats **A**;
- behind the front seats **B**.



The luggage net is designed to retain a maximum weight of 10 kg.


Risk of injury.



Fitting the luggage net behind the front seats

Inside the vehicle on each side:

- lower cover **1** to gain access to the anchoring points for the top part of the luggage net;
- insert the top rod of net **2** into the anchoring points;




- if using the net for the first time, to access the anchorage points **4** located under the carpet, contact an Approved Dealer;
- attach the two hooks **5** for the net straps **3** to the anchoring points **4**;
- adjust the net strap **3** so that it is taut.



Do not install the luggage net in this position when a passenger is occupying a rear seat.


LUGGAGE NET (2/2)



Fitting the luggage net behind the rear seats


Inside the vehicle on each side:

- lift cover **6** to access the luggage net upper mounting rail;
- insert upper rod **7** for the net into the rail;




– fix the net belt hook **9** onto the anchoring points **10**;

– adjust net strap **8** so that it is taut. The seatbacks must not touch the luggage net.




BOOT STORAGE SPACE AND FITTINGS (1/5)



Storage under the carpet


To gain access to this, lift the boot carpet **1** using the tab **2**.



The false floor can be attached using the hook **4** in the housing **3**.

Always place objects being transported so that the heaviest items are resting against the back of the rear bench seat.

BOOT STORAGE SPACE AND FITTINGS (2/5)




Mobile floor

(Estate version)

It is made up of two independent parts, **A** and **B**.


When the rear seats are folded down, this position provides a flat floor.



Storage position

This enables more space for storage in the luggage compartment:

- Remove part **B** then part **A** of the mobile floor;
- place part **A** then part **B** under the supports **5** and **6**.




Separation position

This enables you to compartmentalise the boot into two separate spaces.


Slide your fingers under the spaces **7**.

Maximum load allowed on the mobile floor when flat: 50 kg evenly distributed.

BOOT STORAGE SPACE AND FITTINGS (3/5)




Lift part **C** into the vertical position until it locks.




Storage under floor

To access it, lift part **B** of the mobile floor using the handle **8**, then place it on part **A**.





Lift part **A** using handle **10** and place it on the lugs **9**.

BOOT STORAGE SPACE AND FITTINGS (4/5)



Anchorage points

Attachment points **11**.




Always position the heaviest items directly on the floor. Use the lashing points **11** on the boot floor, if these are fitted to the vehicle. The luggage should be loaded in such a way that no items will be thrown forward and strike the occupants if the driver has to brake suddenly. Fasten the rear seat belts, even if the seats are not occupied.

If your vehicle is not equipped with anchorage points, you can get them from an authorised dealer.


Always place objects being transported so that the heaviest items are resting against the back of the rear bench seat.

BOOT STORAGE SPACE AND FITTINGS (5/5)



Bag hooks 12

Maximum weight per hook: 5 kg.



Storage compartment 13 (Estate version)

TRANSPORTING OBJECTS IN THE LUGGAGE COMPARTMENT


Always position the objects transported so that the largest surface is against:

- The rear bench seatback, for normal loading (example **A**);
- The front seatbacks with the rear seatbacks folded down, as is the case for maximum loads (example **B**).



Ensure that the objects being transported are evenly distributed throughout the loading area.

If you have to place objects on the folded seatback, it is necessary that you lower the headrests before folding the seatback so that it can be folded as flat as possible against the seat.



Always position the heaviest items directly on the floor.

Use the lashing points **1** on the boot floor, if these are fitted to the vehicle.

The luggage should be loaded in such a way that no items will be thrown forward and strike the occupants if the driver has to brake suddenly.

Fasten the rear seat belts, even if the seats are not occupied.

TRANSPORTING OBJECTS towbar

Permissible nose weight, maximum permissible towing weight braked and unbraked: ➔ 6.12.

Choice and fitting of towing equipment


Maximum weight of towing equipment:

- 36 kg (5-door version);
- 37 kg (4-seater and estate versions).

It is not permitted to fit a mechanical towing device (ball, hook, etc.) that is removable without tools or retractable if it cannot be easily removed or repositioned when not in use.

For fitting and conditions of use, refer to the equipment's fitting instructions.

Please keep these instructions with the rest of the vehicle documentation.



A: 896 mm maximum (5-door version).


A: 1,120 mm maximum (Estate version).

A: 1,127 mm maximum (4-door version).



Do not touch the exhaust system.


Risk of burns.




Any towing device must not obstruct any lighting component or the number plate when not in use. Mechanical towing devices (ball, hook, etc.) which can be removed without tools or which are retractable must be removed or repositioned when they are not in use.

In all cases, you must comply with the regulations of the particular country you are in.

ROOF BARS (1/2)




Access to the mounting points



Vehicles not fitted with longitudinal roof bars

Open the doors to access the mounting points **1**.



For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.

Refer to the fitting instructions for information on how to fit roof bars and conditions of use.


Please keep these instructions with the rest of the vehicle documentation.

Maximum permissible load on roof rack: ➔ 6.12.



If original roof bars, approved by our Technical Department, are supplied with screws, only use these screws for attaching the roof bars to the vehicle.

ROOF BARS (2/2)



Vehicles fitted with longitudinal roof bars

The attachment inserts **3** are located on the longitudinal roof bars **2**.

Precautions during use

Handling the tailgate

Before handling the tailgate, check the objects and/or accessories (bike rack, roof box, etc.) fitted to the roof bars: these must be correctly positioned and secured, so as not to hinder the operation of the tailgate.



The attaching of any carrying device (bike rack, luggage box, etc.) resting on the luggage compartment lid is prohibited. To install a carrying device on your vehicle, contact an Approved Dealer.

Section 4: Maintenance

Bonnet	4.2
Engine oil level: general information	4.4
Engine oil level: topping up and filling	4.5
Oil change	4.7
Levels:	4.8
engine coolant	4.8
brake fluid	4.9
windscreen washer reservoir	4.10
Filters	4.10
Battery	4.11
Tyre Pressure	4.13
Bodywork maintenance	4.15
Interior trim maintenance	4.18

BONNET (1/2)



To open, pull handle **1**, located on the left-hand side of the dashboard.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4

➔ 2.5.



Unlocking the bonnet catch

To unlock, push tab **3** at the same time as opening the bonnet.

Opening the bonnet

Lift the bonnet, guiding it up, and it will rest in position with the help of two struts **2**.



Do not press down on the bonnet: there is a risk that the bonnet may accidentally close.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

Risk of injury.



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may

come on at any moment. The  label in the engine compartment reminds you of this.

Risk of injury.

BONNET (2/2)

Closing the bonnet

Check that nothing has been left in the engine compartment.

To close the bonnet again, hold the bonnet in the middle and guide it down, allowing a 30 cm gap before it is closed, then release it. It will latch automatically under its own weight.



After any procedure in the engine compartment, make sure that you do not forget anything (cloth, tools, etc.).

These may damage the engine or cause a fire.



Ensure that the bonnet is properly locked.

Check that nothing is preventing the catch from locking (gravel, cloth, etc.).



In the event of even a slight impact involving the radiator grille or bonnet, have the bonnet lock checked by an authorised dealer as soon as possible.

ENGINE OIL LEVEL: general information

It is normal for an engine to use oil for lubrication and cooling of moving parts and it is normal to top up the level between oil changes.

However, contact your approved Dealer if more than 0.5 litres is being consumed every 600 miles (1,000 km) after the running in period.


Oil change frequency: check the oil level from time to time and certainly before any long journey to avoid the risk of damaging your engine.

Reading the oil level

The oil level should be read with the vehicle on level ground, after the engine has been switched off for some time.

The dipstick must be used to read the exact oil level and make sure that the maximum level has not been exceeded (risk of engine damage).

Depending on the vehicle, the instrument panel display only alerts the driver when the oil level is at its minimum.



- Remove the dipstick and wipe with a clean, lint-free cloth;
- push the dipstick in as far as it will go (for vehicles equipped with a “cap-type dipstick” **C**, screw the cap in as far as it will go);
- take out the dipstick again;
- read the level: it should never fall below the “**MINI**” mark **A** and never exceed the “**MAXI**” **B** mark.

Once the operation has been completed, ensure that the dipstick is pushed in as far as it will go or that the “cap-type dipstick” is completely screwed in.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4

➔ 2.5.



Adding engine oil

Use a funnel or protect the filling neck area to avoid engine oil escaping onto a hot part of the engine compartment or a sensitive part (e.g. electrical components).

Fire hazard.




Exceeding the maximum engine oil level

Under no circumstances should maximum filling level **B** be exceeded: this could damage the engine and the anti-pollution system.

If the level exceeds the maximum level, **do not start your vehicle** and contact an authorised dealer.

ENGINE OIL LEVEL: topping up, filling, draining (1/3)




Topping up/Filling

The vehicle must be parked on level ground and the engine should be cold (for instance, before the engine is started up for the first time in the day).




Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4

➔ 2.5.



- Unscrew cap **1**;
- top up the level (as a guide, the capacity between the “mini” and the “maxi” reading on the dipstick **2** is between 0.33 and 0.44 gallons (1.5 and 2 litres) depending on the engine);
- wait for approximately 20 minutes to allow the oil to flow into the engine;
- check the level using the dipstick **2** (as described above).

Once the operation has been completed, ensure that the dipstick is pushed in as far as it will go or that the “cap-type dipstick” is completely screwed in.



Do not exceed the “**maxi**” level and do not forget to refit the cap **1** and the dipstick **2**.




Adding engine oil

Use a funnel or protect the filling neck area to avoid engine oil escaping onto a hot part of the engine compartment or a sensitive part (e.g. electrical components).

Fire hazard.

ENGINE OIL LEVEL: topping up, filling, draining (2/3)




Topping up/Filling

The vehicle must be parked on level ground and the engine should be cold (for instance, before the engine is started up for the first time in the day).



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4

➔ 2.5.



- Unscrew cap **1**;
- top up the level (as a guide, the capacity between the “mini” and the “maxi” reading on the dipstick **2** is between 0.33 and 0.44 gallons (1.5 and 2 litres) depending on the engine);
- wait for approximately 20 minutes to allow the oil to flow into the engine;
- check the level using the dipstick **2** (as described above).

Once the operation has been completed, ensure that the dipstick is pushed in as far as it will go or that the “cap-type dipstick” is completely screwed in.

Do not exceed the “**maxi**” level and do not forget to refit the cap **1** and the dipstick **2**.



Adding engine oil

Use a funnel or protect the filling neck area to avoid engine oil escaping onto a hot part of the engine compartment or a sensitive part (e.g. electrical components).

Fire hazard.

ENGINE OIL LEVEL: topping up, filling, draining (3/3)

Oil change

Service interval: refer to the maintenance document for your vehicle.

Oil change capacity

Please refer to the maintenance document for your vehicle, or contact an authorised dealer.

Always check the engine oil level using the dipstick, as explained previously (it should never fall below the minimum level, or be over the maximum level on the dipstick).



Exceeding the maximum engine oil level

Under no circumstances should the maximum filling level be exceeded: this could damage the engine and the emission control system.

If the level exceeds the maximum level, **do not start your vehicle** and contact an authorised dealer.

Engine oil grade

Refer to the maintenance document for your vehicle.

Consult your approved Dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

Risk of injury.



Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  warning light in the engine compartment reminds you of this.

Risk of injury.



Filling and/or checking the oil level: when topping up or checking the oil level, ensure that no oil leaks onto the engine components.

Do not forget to properly close the cap and refit the dipstick to prevent any oil spatter on hot engine components.

Fire hazard.




Never run the engine in an enclosed space as exhaust gases are poisonous.



Engine oil change: if you are changing the oil when the engine is hot, be careful not to scald yourself if the oil overflows.

LEVELS, FILTERS (1/3)

48183



Coolant level

With the engine switched off and on level ground, the level **when cold** must be between the "MINI" and "MAXI" marks on coolant reservoir **1**.

Top this level up **when cold** before it reaches the MIN mark.

Checking intervals

Check the coolant level regularly (very severe damage is likely to be caused to the engine if it runs out of coolant).

If the level needs to be topped up, only use products approved by our Technical Department which ensure:

- protection against freezing;
- anticorrosion protection of the cooling system.

If there is an abnormal or repeated drop in the fluid level, please consult an authorised dealer.



No operations should be carried out on the cooling circuit when the engine is hot.

Risk of burns.

Replacement intervals

Refer to the Maintenance Document for your vehicle.



Please note when working close to the engine that it may be hot. The engine cooling fan may also start



at any moment. The warning light in the engine compartment reminds you of this.


Risk of injury.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4

➔ 2.5.

LEVELS, FILTERS (2/3)



Brake fluid level

This should be checked frequently, and any time you notice even the slightest loss in braking efficiency.

The level should be read with the engine switched off and on level ground.

Level 2

It is normal for the level to drop as the linings become worn, but it should never drop below the “**MINI**” warning line.

If you wish to check the disc and drum wear yourself, you should obtain the document explaining the checking procedure from our network or from the manufacturer's website.

If there is an abnormal or repeated drop in the fluid level, consult an approved dealer.



Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  warning light in the engine compartment reminds you of this.

Risk of injury.

Topping up

After any operation on the hydraulic circuit, a specialist must replace the fluid.

Only use fluids approved by our Technical Department (and taken from a sealed container).

Replacement intervals


Refer to the Maintenance Document for your vehicle.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4

➔ 2.5.

LEVELS, FILTERS (3/3)



Windscreen washer reservoir

Topping up

With the engine switched off, open cap **3**, fill until you can see the fluid, then refit the cap.

Note: Regularly check the reservoir level by topping up the liquid before taking a trip.

Liquid

Windscreen washer fluid. In winter, use anti-freeze product. Use products recommended by an authorised dealer.

Note: do not use pure water (risk of damage to the priming pump, limescale building up on the pump and the jets).

Jets


To adjust the windscreen washer jets, please consult an authorised dealer.

Filters

The replacement of filter elements (air filter, passenger compartment filter, diesel filter, etc.) is scheduled in the maintenance operations for your vehicle.

Replacement intervals for filter elements: refer to the Maintenance Document for your vehicle.

BATTERY (1/2)



Battery **1** does not require any maintenance. **You should not open it or add any fluid.**

Depending on the vehicle, a system continuously checks the battery charge status. If this decreases, the message "Battery low start engine" is displayed on the instrument panel. In this case, start the engine. The message will go off.

The charge status of your battery can decrease especially if you use your vehicle:

- for short journeys;
- for driving in town;
- when the temperature drops;
- after extended use of energy-consuming devices (radio, etc.) with the engine switched off.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.4



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may



start at any moment. The warning light in the engine compartment reminds you of this.

Risk of injury.

BATTERY (2/2)



Label A

Observe the indications on the battery:

- **2** Naked flames and smoking are forbidden;
- **3** eye protection required;
- **4** keep away from children;
- **5** explosive materials;
- **6** refer to the handbook;
- **7** corrosive materials.

Replacing the battery



For your own safety and for the proper operation of the vehicle's electrical equipment (lights, windscreen wipers, ABS, etc.), any intervention on the battery (removal, disconnection, etc.) must categorically be performed by a specialist professional.

Risk of serious burns or electric shocks.

You must respect the replacement intervals (without exceeding them) as stated in the maintenance document.

The battery is a **specific type**: ensure that it is replaced by the same type.

Call an approved Dealer.


TYRE PRESSURE (1/2)



Label A

Open the door to read it.
Tyre pressures should be checked when the tyres are cold.

If the tyre pressures cannot be checked when the tyres are **cold**, increase the pressures from **0.2 to 0.3 bar** (or **3 PSI**).
Never deflate a hot tyre.



B: dimension of the tyres fitted to the vehicle.

C: intended driving speed.

D : recommended pressure for optimising fuel consumption.

NB: driving comfort may be altered.

E: front tyre pressure.

F: rear tyre pressure.

G: tyre pressure for the emergency spare wheel.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel. ➔ 2.32.



Vehicle used fully laden (Maximum Permissible All-up Weight) and towing a trailer

The maximum speed must be limited to **62 mph (100 km/h)** and the tyre pressure increased by **0.2 bar (3 psi)** ➔ 6.12.

Risk of tyre blowouts.

TYRE PRESSURES (2/2)

Tyre safety and use of snow chains:

➡ 5.13 to learn the maintenance conditions and the conditions for fitting chains to different versions of the vehicle.



For your safety, please respect the speed limit.

When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

They must: either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an authorised dealer.

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

Risk of loss of control of the vehicle.

BODYWORK MAINTENANCE (1/3)

A well-maintained vehicle will last longer.

It is therefore recommended to maintain the exterior of the vehicle regularly.

Your vehicle has been treated with very effective anti-corrosion products. It is nevertheless subject to various outside influences.

Corrosive agents in the atmosphere

- atmospheric pollution (built-up and industrial areas);
- saline atmospheres (near the sea, particularly in hot weather);
- seasonal and damp weather conditions (e.g. road salt in winter, water from road cleaners, etc.).

Minor impacts

Abrasive action

Dust and sand in the air, mud, road grit thrown up by other vehicles, etc.

You should take a number of minor precautions in order to safeguard your vehicle against such risks.

You should

Wash your car frequently, **with the engine off**, with cleaning products recommended by the manufacturer (never use abrasive products).

Rinse thoroughly beforehand with a jet:

- spots of tree resin and industrial grime;
- mud in the wheel arches and underneath the body which forms damp patches;
- **bird droppings**, which cause a chemical reaction with the paint that **rapidly discolours paintwork and may even cause the paint to peel off**;
wash the vehicle **immediately** to remove these marks since it is impossible to remove them by polishing;
- salt, particularly in the wheel arches and underneath the body after driving in areas where the roads have been gritted.

Remove any plant matter (resin, leaves, etc.) from the vehicle regularly.

Respect local regulations about washing vehicles (e.g. do not wash your vehicle on a public highway).

Observe the vehicle stopping distances when driving on gravelled surfaces to prevent paint damage.

Repair, or have repaired quickly, areas where the paint has been damaged, to prevent corrosion spreading.

Remember to visit the body shop periodically in order to maintain your anti-corrosion warranty.

Refer to the maintenance document.

If mechanical components, hinges, etc. have been cleaned, they must be protected again by spraying with products approved by our Technical Department.

We have selected special products to care for your vehicle and you can obtain these from the manufacturer's accessory outlets.

BODYWORK MAINTENANCE (2/3)

What you should not do

Wash the vehicle in bright sunlight or freezing temperatures.

Do not scrape off mud or dirt without pre-wetting.

Allow dirt to accumulate on the exterior.

Allow rust to form following minor impacts.

Do not use solvents not approved by our Technical Department to remove stains as this could damage the paintwork.

Do not drive in snow or muddy conditions without washing the vehicle, particularly under the wheel arches and body.



Degrease or clean using high-pressure cleaning equipment or by spraying on products not approved by our Technical Department:

- mechanical components (e.g.: engine compartment);
- the wheels (e.g. braking system components such as brake callipers);
- underbody;
- parts with hinges (e.g.: inside the doors);
- painted plastic external fittings (e.g.: bumpers).

Doing this could give rise to corrosion or operational faults.

BODYWORK MAINTENANCE (3/3)

Vehicles with a matte paint finish

This type of paint requires certain precautions.

You should do the following

Wash the vehicle by hand using plenty of water, using a soft cloth or a gentle sponge.

Do not do the following

Use wax-based products (polishing).

Rub too hard.

Wash the vehicle in a roller-type car wash.

Attach stickers to the paintwork (risk of leaving marks).



Wash the vehicle using a high-pressure cleaning device.

Using a roller type car wash

Return the wiper stalk to the park position ➡ 1.108.

Check the mounting of external accessories, additional lights and rear view mirrors, and ensure that the wiper blades are secured with adhesive tape.

Remove the radio aerial mast if your vehicle is fitted with this equipment.

Remember to remove the tape and refit the antenna after washing.

Cleaning the headlights, sensors and cameras

Use a soft cloth or cotton wool.

If this is not sufficient, moisten the cloth with soapy water, always rinsing with a soft cloth or cotton wool.

Finally, carefully dry off with a soft dry cloth.

Do not use cleaning products containing alcohol or utensils (e.g.: a scraper).

Cleaning stickers, decorative films, etc.

You should do the following

Use a soft cloth or cotton wool.

Moisten it slightly with soapy water then always wipe clean with a soft cloth or cotton wool.

Finally, carefully dry off with a soft dry cloth.

Do not do the following

Use alcohol-based cleaning products.

Use utensils (e.g.: scraper).

Rub too hard.



Wash the area using a high-pressure cleaning device.

INTERIOR TRIM MAINTENANCE (1/2)

A well-maintained vehicle will last longer. It is therefore recommended to maintain the interior of the vehicle regularly.

A stain should always be dealt with swiftly.

Whatever type of stain is on the trim, use **cold** (or warm) **soapy water with natural soap**.

Detergents (washing-up liquid, powdered products, alcohol-based products) should not be used.

Use a soft cloth.

Rinse and wipe up excess water.

Multimedia screen

Maintenance of the screen may depend on the type of multimedia equipment. Please refer to the multimedia instructions for further information.

Glass instrument panel

(e.g. instrument panel, clock, exterior temperature display etc.)

Use a soft cloth (or cotton wool).

If this does not clean them properly, use a soft cloth (or cotton wool) slightly moistened with soapy water and then wipe clean with another soft damp cloth or cotton wool.

Finally, **carefully** dry off with a soft dry cloth.

Do not use products containing alcohol and/or spray fluids on the area.

Seat belts

These must be kept clean.

Use products selected by our Technical Department (Approved outlets) or warm, soapy water and a sponge and wipe with a dry cloth.

Detergents or dyes must not be used under any circumstances.

Textiles (seats, door trim, etc)

Vacuum-clean the textiles **regularly**.

Liquid stain

Use soapy water.

Dab lightly (never rub) with a soft cloth, rinse and remove the excess.

Solid or pasty stain

Carefully remove the excess solid or pasty material **immediately** with a spatula (working from the edges to the centre to avoid spreading the stain).

Clean as for a liquid stain.

Special instructions for sweets or chewing gum

Put an ice cube on the stain to solidify it, then proceed as for a solid stain.

For further recommendations for maintaining the interior, and/or for any unsatisfactory results, please see an authorised dealer.

INTERIOR TRIM MAINTENANCE (2/2)

Removal/replacing removable equipment originally fitted in the vehicle

If you need to remove equipment in order to clean the passenger compartment (for example, mats), always ensure that they are correctly refitted and are the right way around (the driver's mat should be fitted on the driver's side, etc.) and fit them with the components supplied with the equipment (for example, the driver mat should always be fixed using the pre-fitted mounting components).

With the vehicle stationary, always ensure that nothing will impede driving (anything obstructing the pedals, heel wedged by the mat etc.).

You should not:

Position objects such as deodorants, scents etc. near air vents as this could damage your dashboard trim.



Using high-pressure cleaning equipment or sprays inside the passenger compartment:

without careful use, this equipment could impair the correct functioning of the electrical or electronic components in the vehicle, or have other detrimental effects.



Section 5: Practical advice

Puncture, Emergency spare wheel	5.2
Tyre inflation kit	5.5
Tools	5.8
Wheel trim	5.10
Changing a wheel	5.11
Tyres (tyre and wheel safety, use in winter)	5.13
Headlights (changing bulbs)	5.16
Rear lights and side lights (replacing bulbs)	5.18
Interior lighting: changing bulbs.	5.25
Fuses.	5.28
Battery	5.30
Card: battery	5.32
Radio frequency remote control: batteries.	5.34
Accessories	5.36
Wipers (replacing blades)	5.37
Towing: breakdown	5.39
Operating faults	5.41

PUNCTURE, EMERGENCY SPARE WHEEL (1/3)

In case of puncture

Depending on the vehicle, a tyre inflation kit or emergency spare wheel is provided (refer to the following pages).

Special note

The tyre pressure monitor function does not check the emergency spare wheel (the wheel replaced by the emergency spare wheel disappears from the instrument panel display) ➔ 2.32.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.




If the emergency spare wheel has been stored for several years, have it checked by your Dealer to ensure that it is safe to use.

Vehicles fitted with an emergency spare wheel smaller than the four other wheels:

- Never fit more than one emergency spare wheel to the same vehicle.
- As the punctured wheel is wider than the emergency spare wheel, the vehicle's ground clearance is reduced.
- Replace the emergency spare wheel as soon as possible with a wheel with the same dimensions as the original.
- When this is fitted to the vehicle, which must only be a temporary measure, the driving speed must not exceed the speed indicated on the label on the wheel.
- Fitting an emergency spare wheel may alter the way the vehicle usually runs. Avoid sudden acceleration or deceleration and reduce your speed when cornering.
- If you need to use snow chains, fit the emergency spare wheel to the rear axle and check the tyre pressure.

PUNCTURE, EMERGENCY SPARE WHEEL (2/3)




Emergency spare wheel 3

This is located in the luggage compartment.

Remove the subwoofer 7, refit it and reconnect it in the same position again. Handle it carefully. If not, this could impair the correct functioning of the subwoofer.


It is not recommended to replace and reconnect the subwoofer if a tyre is punctured: this may cause damage to the subwoofer.



Vehicle not fitted with a subwoofer

To access it:

- open the boot;
- lift the luggage compartment carpet 1 using tab 2 (or the handle, depending on the vehicle);
- unscrew the central mounting 6 located under the jack 4;
- remove the tool kit 5;
- remove the emergency spare wheel.




Vehicle fitted with a subwoofer

To access it:

- open the boot;
- lift the luggage compartment carpet 1 using tab 2 (or the handle, depending on the vehicle);
- unscrew the central mounting 6 located under the jack 4;
- remove the tool kit 5;
- disconnect the power cable of the subwoofer 7;
- remove the subwoofer;
- remove the emergency spare wheel.

PUNCTURE, EMERGENCY SPARE WHEEL (3/3)



Emergency spare wheel 11

It is located under the vehicle.

To get to it:

- in the luggage compartment, lift the cover 9 from the luggage compartment carpet;
- remove blanking cover;
- only use the wheel brace 8 (using a different tool could damage the mechanism) to unscrew fully the nut anti-clockwise (movement A), and the wheel will lower to the ground;



- under the vehicle, lift then push (movement B) the handle 10 to lower the wheel carrier on the ground;
- pull the wheel 11 towards you, a plastic guide located under the wheel makes it easy to move;
- remove the plastic guide from the wheel before fitting it to the vehicle.



Do not touch the exhaust system.

Risk of burns.

To refit the wheel carrier:

- use the wheelbrace 8 to screw fully the nut clockwise (reverse movement A);
- make sure you lock the wheel carrier in place;
- refit the blanking cover, then the cover 9.

Note: 4-door version vehicle, store the punctured wheel in the boot.



Make sure that the wheel carrier is always locked, with or without the emergency spare wheel inside.

There is a risk of accidents.



When the emergency spare wheel is located underneath the vehicle, it is vital to take the emergency spare wheel out before lifting the vehicle.

Risk of injury.

TYRE PRESSURE KIT (1/3)

32788



The kit repairs tyres when tread **A** has been damaged by objects smaller than 4 mm. It cannot repair all types of puncture, such as cuts larger than 4 mm, or cuts in tyre sidewall **B**.

Ensure also that the wheel rim is in good condition.

Do not pull out the foreign body causing the puncture if it is still in the tyre.



Do not attempt to use the inflation kit if the tyre has been damaged as a result of driving with a puncture.

You should therefore carefully check the condition of the tyre sidewalls before any operation.

Driving with underinflated, flat or punctured tyres can be dangerous and may make the tyre impossible to repair.

This repair is temporary

A tyre which has been punctured should always be inspected (and repaired, where possible) as soon as possible by a specialist.

When taking a tyre which has been repaired using this kit to be replaced, you must inform the specialist.

When driving, vibration may be felt due to the presence of the repair product injected into the tyre.



The kit is only approved for inflating the tyres of the vehicle originally equipped with the kit.

It must never be used to inflate the tyres of another vehicle, or any other inflatable object (rubber ring, rubber boat, etc.).

Avoid spillage on skin when handling the repair product bottle. If droplets do leak out, rinse them off with plenty of water.


Keep the repair kit away from children.

Do not dispose of the empty bottle in the countryside. Return it to your approved dealer or to a recycling organisation.

The bottle has a limited service life which is indicated on its label. Check the expiry date.

Contact an approved dealer to replace the inflation tube and repair product bottle.

TYRE PRESSURE KIT (2/3)



In the event of a puncture, use the kit located in the luggage compartment or underneath the luggage compartment floor (depending on the vehicle). ➔ 3.54.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel. ➔ 2.32.

Engine running, handbrake applied:

- Connect the compressor hose **4** to the container inlet **9**;
- remove the cap from the container inflation adapter **3**;
- unscrew the valve cap on the relevant wheel and screw on the container's inflation adapter **3**;
- disconnect any accessories previously connected to the vehicle's accessories sockets;
- the end piece **7** **must** be plugged in to the vehicle accessories socket;
- press the **5** switch to inflate the tyre to the recommended pressure ➔ 4.13;
- after a maximum of **15** minutes, stop inflating and read the pressure (on pressure gauge **6**).

Note: While the container empties (approx. 30 secs), the pressure gauge **6** briefly shows pressure up to 6 bar, then the pressure drops.

- Adjust the pressure: to increase it, continue inflation with the kit; to reduce it, press button **8**.




Before using the kit, park the vehicle at a sufficient distance from traffic, switch on the hazard warning lights, apply the parking brake, ask all passengers to leave the vehicle and keep them away from traffic.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

TYRE PRESSURE KIT (3/3)



If a minimum pressure of 1.8 bar is not reached after 15 minutes, repair is not possible; do not drive the vehicle but contact an approved dealer.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and may lead to pressure loss.

Always use valve caps identical to those fitted originally and tighten them fully.

Once the tyre is correctly inflated, remove the kit:

- Slowly unscrew the inflation adapter **3** to prevent any repair product from escaping and store the container in plastic packaging to prevent the product from leaking.
- Affix the driving recommendation label (located under the container) to the dashboard where the driver can see it.
- Put the kit away.
- At the end of this initial inflation operation, air will still escape from the tyre. You must drive a short distance in order to seal the hole.
- Start immediately and drive at between 12 and 40 mph (20 and 60 km/h) in order to distribute the product evenly in the tyre and, after driving for 2 miles (3 km), stop and check the pressure.
- If the pressure is greater than 1.3 bar but less than the recommended pressure, re-adjust it (refer to the label affixed to the edge of the driver's door), otherwise contact an approved dealer: repair is not possible.

Precautions when using the kit

The kit should not be operated for more than 15 consecutive minutes.




Nothing should be placed around the driver's feet as such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.



Following repair with the kit, do not travel further than 120 miles (200 km). In addition, reduce your speed and under no circumstances exceed 48 mph (80 km/h). The sticker, which you must affix in a prominent position on the dashboard, reminds you of this.

Depending on the country or local legislation, a tyre repaired with the inflation kit may need to be replaced.


TOOLS (1/2)



Tool kit

(depending on vehicle)

To access the tool kit **1**, raise the luggage compartment carpet and/or mobile floor ➔ 3.54.





Tool box


(depending on vehicle)

To access the tool box, unlock the mounting(s) **2** by one quarter of a turn, then remove the flap **3**.

The tool box is held in place by a strap.



TOOLS (2/2)




The presence of the tools depends on the vehicle.

Jack 5

On vehicles equipped with a tool kit, push towards the front of the vehicle the **4** clip on the tool kit and remove the jack.

Fold the jack correctly before refitting it in its housing (ensure that the wheel-brace **6** is correctly positioned).



Hubcap tool 7

This tool is used to remove the wheel trims.

Screw guide 8

For tightening/loosening wheel bolts on vehicles fitted with alloy wheels

Towing hitch 9

→ 5.39

Wheelbrace 10

Locks or unlocks the wheel bolts and tow eye **9**.




Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, check that all the tools are correctly clipped into the tool kit, then position it correctly in its housing: risk of injury.

If wheel bolts are supplied in the tool kit, only use these bolts for the emergency spare wheel: refer to the label affixed to the emergency spare wheel.

The jack is designed for wheel changing purposes only. Under no circumstances should it be used for carrying out repairs underneath the vehicle or to gain access to the underside of the vehicle.

HUBCAP

48119



Remove using the hubcap tool **1** (located in the tool kit) by connecting the hook in the recess provided next to the valve **2** (to attach the metal clip).


To refit it, align it with valve **2**. Push the retaining hooks in fully, starting with side **A** near the valve, followed by **B** and **C**, finishing at **D** opposite the valve.

Note: if you are using anti-theft bolts
➔ 5.11.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, check that all the tools are correctly clipped into the tool kit, then position it correctly in its housing: risk of injury.

CHANGING A WHEEL (1/2)



Switch on the hazard warning lights.

Keep the vehicle away from traffic and on a level surface where it will not slip.

Apply the parking brake and engage a gear (first or reverse, or **P** for automatic transmissions).

Ask all the passengers to leave the vehicle and keep them away from traffic.



When the emergency spare wheel is located underneath the vehicle, it is vital to take the emergency spare wheel out before lifting the vehicle.

Risk of injury.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

Vehicles equipped with a jack and wheelbrace

If necessary, remove the wheel trim.

Use the wheelbrace **2** to slacken off the wheel bolts. Position it so as to be able to push from above.

Place the jack **3** horizontally; the jack head **must** be lined up with the sill closest to the wheel concerned, as shown by an arrow **1**.

Crank up the jack by hand at first to align the base plate (which should be inclined further inwards than the jack head).

Turn the wheelbrace until the wheel lifts off the ground.

CHANGING A WHEEL (2/2)

Undo the bolts and take off the wheel.

Fit the emergency spare wheel onto the hub and rotate it until the mounting holes in the wheel coincide with those of the hub.

If bolts are supplied with the emergency spare wheel, only use these bolts for the emergency spare wheel. Tighten the bolts, checking that the wheel is correctly positioned on its hub and unscrew the jack.

With the wheel on the ground, tighten the bolts fully and have the tightness of the bolts checked and the emergency spare wheel pressure checked as soon as possible.

Note: 4-door version vehicle, when the emergency spare wheel is located underneath the vehicle, place the punctured wheel in the boot.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel. ➔ 2.32.

Anti-theft bolt

If you use anti-theft bolts, fit these nearest the valve (wheel embellisher may not be able to fit).



If you have a puncture, replace the wheel as soon as possible.

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist.

TYRES (1/3)

The tyres are the only contact between the vehicle and the road, so it is essential to keep them in good condition.

You must make sure that your tyres conform to local road traffic regulations.



Maintaining the tyres

The tyres must be in good condition and the tread form must have sufficient depth; tyres approved by our Technical Department have tread wear indicators **1** which are **indicators moulded into the tread at several points**.

When the tread has worn down to the wear warning strips, **these strips will become visible 2**: it is then necessary to replace your tyres because the tread rubber is now **only 1.6 mm deep at most, resulting in poor road holding on wet roads**.

An overloaded vehicle, long journeys by motorway, particularly in very hot weather, or continual driving on poorly surfaced minor roads will lead to more rapid tyre wear and affect safety.



Incidents which occur when driving, such as striking the kerb, may damage the tyres and wheel rims, and could also lead to misalignment of the front or rear axle geometry. In this case, have the condition of these checked by an approved dealer.

TYRES (2/3)

Tyre pressures

Adhere to the tyre pressures (including the emergency spare wheel). The tyre pressures should be checked at least once a month and additionally before any long journey (refer to the label affixed to the edge of the driver's door).



Incorrect tyre pressures

lead to abnormal tyre wear and unusually hot running. These are factors which may seriously affect safety and lead to:

- poor road holding,
- risk of bursting or tread separation.

The pressure depends on the load and the speed of use. Adjust the pressure according to the conditions of use (refer to the label affixed to the edge of the driver's door).

The pressures should be checked cold: ignore higher pressures which may be reached in hot weather or following a high speed journey.

If the tyre pressures cannot be checked when the tyres are **cold**, increase the pressures from **0.2 to 0.3 bar (or 3 PSI)**.

Never deflate a hot tyre.

Special note

Depending on the vehicle, there may be an adapter which needs to be positioned on the valve before air is added.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and lead to pressure loss.

Always use valve caps identical to those fitted originally and tighten them fully.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel. ➔ 2.32.

Emergency spare wheel

➔ 5.2, ➔ 5.11.

Changing wheels around

This practice is not recommended.

TYRES (3/3)

Fitting new tyres



For your safety, please respect the speed limit.

When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

They must: either have a load capacity and a speed capacity at least equal to the original tyres, or correspond to those recommended by your authorised dealer.

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

Risk of loss of control of the vehicle.

In all cases, we would recommend that you contact an authorised dealer who will be able to advise you on the choice of equipment which is most suitable for your vehicle.

Use in winter

Snow or Winter tyres

We would recommend that these be fitted to all **four wheels** to ensure that your vehicle retains maximum adhesion. **Warning:** These tyres sometimes have a specific direction of rotation and a maximum speed index which may be lower than the maximum speed of your vehicle.



Snow chains may only be fitted to tyres of the same size as those originally fitted to **your vehicle**.



17" wheels and larger cannot be fitted with chains.

If you wish to use **special equipment**, please consult an authorised dealer.

Studded tyres

This type of equipment may only be used for a limited period and as laid down by local legislation. It is necessary to observe the speed specified by current legislation.

These tyres must, at a minimum, be fitted to the two front wheels.

Chains

For safety reasons, fitting snow chains to the rear axle is strictly forbidden.

Chains cannot be fitted to tyres which are larger than those originally fitted to the vehicle.



Changing a wheel

As the tyre pressure monitor may take several minutes to correctly determine the positions of the wheels and the pressure values after driving, check the tyre pressures following any operation.

FRONT HEADLIGHTS: replacing the bulbs (1/2)



Any operation on (or modification to) the electrical system must be performed by an approved dealer since an incorrect connection might damage the electrical equipment (harness, components and in particular the alternator). In addition, your Dealer has all the parts required for fitting these units.



The bulbs are under pressure and can break when replaced.


Risk of injury.



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may

start at any moment. The  warning light in the engine compartment reminds you of this.

Risk of injury.



Vehicles with LED headlights

Daytime running lights/side lights/direction indicators 1

Please see an authorised dealer.

Main beam headlights 2

Please see an authorised dealer.

Dipped beam headlights 3

Please see an authorised dealer.


Front fog lights 4

Please see an authorised dealer.

Additional lights

If you wish to fit fog lights to your vehicle, please see an authorised dealer.

FRONT HEADLIGHTS: replacing the bulbs (2/2)



Vehicles with Halogen headlights


Daytime running lights/side lights/direction indicators 7

Please see an authorised dealer.

Halogen dipped beam headlight 6

To change the bulb:

- open the bonnet;
- remove cover **B**;
- Turn the bulb holder a quarter turn **11**;
- remove the bulb.



Halogen main beam headlight 5

To change the bulb:


- open the bonnet;
- remove cover **A**;
- pull the bulb holder **10**;
- remove the bulb.

Type of bulbs 5 and 6: H7.

It is **essential** to use anti-U.V. 55W bulbs so as not to damage the plastic on the headlights.

Do not touch the bulb glass. Hold it by its base.

When the bulb has been changed, make sure you refit the cover correctly.



Front fog lights 8


- Access the bulb holder via the underneath of the vehicle;
- unclip the access flap **9**;
- turn the bulb holder a quarter turn;
- remove the bulb.

Type of bulb: H16.

Once the bulb has been replaced, check that it is properly secured.

To comply with local legislation, or as a precaution, you can obtain an emergency kit containing a set of spare bulbs and fuses from an approved dealer.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (1/7)



5-door version

Brake/side lights 1


Consult an approved dealer

Side lights 2

Consult an approved dealer.

Reversing light 3

Consult an approved dealer.



Direction indicators 4

Consult an approved dealer.

High level brake light 5

Consult an approved dealer.

Rear fog lights 6 or 7

The front bumper needs to be removed; consult an authorised dealer.


Bulb type: P21W.



The bulbs are under pressure and can break when replaced.


Risk of injury.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (2/7)



Number plate lights 8


Consult an approved dealer.



Side repeaters 9 and welcome lighting 10

The wing mirror needs to be removed; consult an authorised dealer.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (3/7)



Estate version

Brake/side lights 1

Consult an approved dealer

Side lights 2

Consult an approved dealer.

Reversing light 3

Consult an approved dealer.



Direction indicators 4

Consult an approved dealer.

High level brake light 5

Consult an approved dealer.

Rear fog lights 6 or 7

The front bumper needs to be removed; consult an authorised dealer.


Bulb type: P21W.



The bulbs are under pressure and can break when replaced.


Risk of injury.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (4/7)



Number plate lights 8


Consult an approved dealer.



Side repeaters 9 and welcome lighting 10

The wing mirror needs to be removed; consult an authorised dealer.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (5/7)




48237

4-door version

Side light 3

Consult an approved dealer.



41417

Access to the bulb holders 6 and 7


Open the boot, remove the cover 4 to access the screw 5 and undo it.

Remove the rear lights unit.

Direction indicator light 2

Turn bulb holder 7 a quarter of a turn and take out the bulb.

Bulb type: PY21W.



41420

Brake light 1

Turn bulb holder 6 a quarter of a turn and take out the bulb.


Bulb type: P21W.

Refit the bulb holder and push the unit in fully until it locks in place.

Check that the light is properly locked in position.


Tighten the screw 5 and reposition the cover 4.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (6/7)



Reversing light

From the boot, unclip the cover on the interior trim of the boot lid **8** using a screwdriver or similar tool.




Turn bulb holder **9** a quarter of a turn and take out the bulb.

Bulb type: W16W.

Refitting

To refit, proceed in the reverse order, taking care not to damage the wiring.



High level brake light **10**

Consult an approved dealer.

Rear fog lights **11**

The front bumper needs to be removed; consult an authorised dealer.


Bulb type: P21W.



The bulbs are under pressure and can break when replaced.

Risk of injury.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (7/7)




Number plate lights with conventional bulbs 12

(depending on vehicle)

- Unclip the light **12** using a tool such as a flat-blade screwdriver;
- remove the light cover to gain access to the bulb.


Bulb type: W5W.



LED number plate lights 13

(depending on vehicle)

Consult an approved dealer



Side repeaters 14 and welcome lighting 15

The wing mirror needs to be removed; consult an authorised dealer.



The bulbs are under pressure and can break when replaced.


Risk of injury.

INTERIOR LIGHTING: changing bulbs (1/3)



Map reading lights 1

Please consult an authorised dealer.




Courtesy light 2

Please consult an authorised dealer.

Ambient lighting

Please consult an authorised dealer.

INTERIOR LIGHTING: changing bulbs (2/3)



Glove box light 3

Please consult an authorised dealer.



Luggage compartment light 4 (four-door version)



Unclip the light by pressing the tab with a flat-blade screwdriver or similar.

Disconnect the light.

Remove the bonnet 5

Access the bulb.


Bulb type: W5W.



The bulbs are under pressure and can break when replaced.

Risk of injury.

INTERIOR LIGHTING: changing bulbs (3/3)





Luggage compartment light 6 (five-seater and estate versions)

Unclip the light by pressing the tab with a flat-blade screwdriver or similar.

Disconnect the light.

Access the bulb.


Bulb type: W5W.



The bulbs are under pressure and can break when replaced.

Risk of injury.

FUSES (1/2)



Fuse box

If any electrical component does not work, check the condition of the fuses.

Unclip the access flap **A**.

In accordance with local legislation or as a precautionary measure:

obtain an emergency kit containing a set of spare bulbs and fuses from an approved Dealer.

Use the fuse allocation label on the back of flap **A** to identify the fuses.


Certain fuses should only be replaced by a qualified professional. These fuses are not listed on the label.

Only change the fuses represented on the label.



Check the fuse in question and **replace it**, if necessary, **by a fuse of the same rating**.

If a fuse is fitted where the rating is too high, it may cause the electrical circuit to overheat (risk of fire) in the event of an item of equipment using an excessive amount of current.



Tweezers 1

Remove the fuse using tweezers **1**, located at the back of flap **A**.

To remove the fuse from the tweezers, slide the fuse to the side.

It is not advisable to use the free fuse locations.

FUSES (2/2)

Allocation of fuses

(the presence of certain fuses depends on the vehicle equipment level)

Symbol	Allocation
	Windscreen washer
	Multimedia accessories socket, multimedia screen
	Front and rear second row accessories socket
	Horn
	Towbar socket
	Heated rear view mirrors
	Brake lights, passenger compartment central unit
	Passenger compartment centre unit, rear wiper, rear fog light
	Direction indicator lights, hazard warning lights, high level brake lights
	Luggage compartment/Third row accessories socket
	Electric window (not one-touch)

BATTERY: troubleshooting (1/2)

To avoid all risk of sparks:

- Ensure that any consumers (courtesy lights, etc.) are switched off before disconnecting or reconnecting the battery;
- when charging, stop the charger before connecting or disconnecting the battery;
- to avoid creating a short circuit between the terminals, do not place metal objects on the battery;
- always wait at least one minute after the engine has been switched off before disconnecting a battery;
- make sure that you reconnect the battery terminals after refitting.

Connecting a battery charger

The battery charger must be compatible with a battery with nominal voltage of 12 volts.

Do not disconnect the battery when the engine is running. **Follow the instructions given by the manufacturer of the battery charger you are using.**



Special procedures may be required to charge some batteries. Contact your authorised dealer.

Avoid all risk of sparks which may cause an immediate explosion, and charge the battery in a well ventilated area.

Risk of serious injury.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➡ 2.4

➡ 2.5.



Handle the battery with care as it contains sulphuric acid, which must not come into contact with eyes or skin. If it does, wash the affected area with plenty of cold water. If necessary, consult a doctor.

Keep naked flames, red hot objects and sparks away from the battery components as there is a **risk of explosion**.

Please note when working close to the engine that it may be hot. The engine cooling fan may also start at

any moment. The  label in the engine compartment reminds you of this.

Risk of injury.

BATTERY: troubleshooting (2/2)


Starting the vehicle using the battery from another vehicle

If you have to use the battery from another vehicle to start, obtain suitable jump leads (with a large cross section) from an approved dealer or, if you already have jump leads, ensure that they are in perfect condition.

The two batteries must have an identical nominal voltage of 12 volts. The battery supplying the current should have a capacity (amp-hours, Ah) which is at least the same as that of the discharged battery.

Ensure that there is no risk of contact between the two vehicles (risk of short circuiting when the positive terminals are connected) and that the discharged battery is properly connected. Switch off your vehicle ignition.

Lift the red cover on box **1** located behind the battery.




Connect the positive cable **A** to **support 3 (+)** located under the box cover **1**, then to **terminal 5 (+)** of the battery supplying the current.

Connect the negative cable **B** to **terminal 4 (-)** of the battery supplying the current then to the **metal cable 2 (-)** of the discharged battery.

Start the engine of the vehicle supplying the current and run it at a moderate speed.

If your vehicle's engine does not start immediately, switch off the ignition and wait a few seconds before repeating the operation.



With the engine running, disconnect cables **A** and **B** in the reverse order (**2 - 4 - 5 - 3**).



Check that there is no contact between leads **A** and **B** and that the positive lead **A** is not touching any metal parts on the vehicle supplying the current.

Risk of injury and/or damage to the vehicle.

CARD: battery (1/2)



Replacing the battery

When the message “Keycard Battery Low” appears on the instrument panel, replace the battery in the card:

- slide the rear casing **1** downwards while pressing on zone **A**;
- remove the battery cover **2**;
- remove the battery by pressing on one side and lifting the other;
- replace it according to the direction and template shown inside the cover.



When refitting, proceed in the reverse order, then press one of the buttons on the card four times, close to the vehicle: the message will disappear.

Check that the cover is clipped shut.

Note: Do not touch the electronic circuit or contacts on the card when replacing the battery.

The batteries are available from approved Dealers, and their service life approximately two years. Check that there is no dye on the battery: risk of an incorrect electrical contact.



If they need to be replaced, be sure to use the same or equivalent type of battery (consult an Approved Dealer).



When replacing:
– make sure that the batteries are correctly inserted.

There is a risk of explosion.

- if the flap does not close correctly, do not use and keep out of reach of children.

CARD: battery (2/2)

Operating faults

If the battery is too weak to ensure correct operation, you will still be able to start and lock/unlock the vehicle

➡ 1.14.

26913



Do not throw away your used batteries; give them to an organisation responsible for collecting and recycling batteries.



Precautions relating to batteries:

- keep (new or used) batteries out of reach of children;
- not to swallow the batteries.

Risk of chemical burns which may led to death.

- if ingested or inserted into any part of the body, consult a doctor as soon as possible.

RADIO FREQUENCY REMOTE CONTROL: batteries (1/2)

40080




Replacing the battery

Open the case at slot **1** using a flat-blade screwdriver or similar, and replace the battery **2**, observing the polarity shown on the back of the cover.



If they need to be replaced, be sure to use the same or equivalent type of battery (consult an Approved Dealer).

40081



Note: It is not advisable to touch the electronic circuit in the key cover when replacing the battery.

When refitting, ensure that the cover is correctly clipped on and the screw tightened.

The batteries are available from approved Dealers, and their service life approximately two years.

Check that there is no dye on the battery: risk of an incorrect electrical contact.

RADIO FREQUENCY REMOTE CONTROL: batteries (2/2)

Operating faults

If the battery is too weak to ensure correct operation, you will still be able to start and lock/unlock the vehicle

➡ 1.14.

26913



Do not throw away your used batteries; give them to an organisation responsible for collecting and recycling batteries.



When replacing:

- make sure that the batteries are correctly inserted.

Risk of explosion.

- if the flap does not close correctly, do not use and keep out of reach of children.



Precautions relating to batteries:

- keep (new or used) batteries out of reach of children;
- not to swallow the batteries.

Risk of chemical burns which may cause death;

- if ingested or inserted into any part of the body, consult a doctor as soon as possible.

ACCESSORIES



Electrical and electronic accessories

Before installing this type of accessory (particularly for transmitters/receivers: frequency bandwidth, power level, position of the aerial, etc.), make sure it is compatible with your vehicle. You can get advice from an authorised dealer.

Before connecting an accessory to a socket, please ensure that you do not exceed the maximum power authorised for the socket ➡ 3.26 ➡ 3.40. **Fire hazard.**

No work may be carried out on the vehicle's electrical or radio circuits, except by authorised dealers: an incorrectly connected system may result in damage being caused to the electrical equipment and/or the components connected to it.

If the vehicle is fitted with any aftermarket electrical equipment, make sure that the installation is correctly protected by a fuse. Establish the rating and position of this fuse.

Using the diagnostic socket

The use of electronic accessories on the diagnostic socket may cause serious disturbance to the vehicle's electronic systems. For your safety we recommend that you use only electronic accessories approved by the manufacturer, consult an Approved Dealer. **Serious accident risk.**

Fitting aftermarket accessories


If you wish to install accessories on the vehicle: please contact an authorised dealer. Also, to ensure the correct operation of your vehicle, and to avoid any risk to your safety, we recommend that you use only accessories specifically designed for your vehicle, which are the only accessories for which the manufacturer will provide a warranty.

If you are using an anti-theft device, only attach it to the brake pedal.

Obstructions to the driver

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

WIPER BLADES: REPLACEMENT (1/2)



25516

Replacing windscreen wiper blades 1

With the ignition on and engine switched off, lower the windscreen wiper stalk completely: they stop slightly away from the bonnet. Lift wiper arm **3**, pull tab **2** (movement **A**) and push the blade upwards.

To refit

Slide the blade along the arm until it clips on. Make sure that the blade is correctly locked in position. Return the windscreen wiper stalk to the park position.

Check the condition of the wiper blades. You are responsible for their service life:

- clean the blades, windscreen and rear screen regularly with soapy water;
- do not use them when the windscreen or rear screen are dry;
- free them from the windscreen or rear screen when they have not been used for a long time.




– In frosty weather, make sure that the wiper blades are not stuck by ice (to avoid the risk of the motor overheating).

- Check the condition of the wiper blades.

Replace the wiper blades as soon as they begin to lose efficiency (approximately once a year).

Whilst changing the blade, take care not to drop the arm onto the window after it has been removed as this may break the window.

WIPER BLADES: REPLACEMENT (2/2)



Rear screen wiper blade 4

Stalk in stop position (deactivated):

- Lift wiper arm **6**;
- pivot blade **4** until some resistance is met (movement **C**);
- depending on the vehicle, press tab **5**, then remove the blade by pulling it (movement **B**).

To refit

To refit the wiper blade, proceed in reverse order to removal. Make sure that the blade is correctly locked in position.



Before changing the rear wiper blade, make sure the stalk is in the stop position (deactivated).

Risk of injury.

TOWING: breakdown recovery (1/2)

Before towing, put the gearbox in neutral, unlock the steering column and release the parking brake.

For vehicles fitted with an automatic gearbox, if it is not possible to put the gear lever into position **N**, please consult an authorised dealer.

Steering column unlocking

Insert the key into the ignition or press the engine start button for **two seconds** with the card on you (depending on the vehicle).

Reposition the lever to neutral (position **N** for vehicles fitted with an automatic gearbox).

The column is unlocked, the accessory functions are supplied: the vehicle lights can be used (indicators, brake lights etc.). At night the vehicle must have its lights on.

Depending on the vehicle, once you have finished towing, press the engine start button twice (risk of running down the battery).

The speed specified by current legislation for towing must always be observed. If you are driving the towing vehicle, do not exceed the permissible towing weight for your vehicle. ➡ 6.12.

Towing a vehicle with an automatic gearbox


Transport the vehicle on a trailer or tow it with the front wheels off the ground.

In exceptional circumstances, you may tow it with all four wheels on the ground, only in a forward gear, with the gear in neutral position **N** over a maximum distance of 50 miles and not exceeding a speed of 15 mph (25 km/h).



Do not remove the key from the ignition switch, or leave the card in the vehicle during towing (depending on the vehicle).

Risk of the steering column locking.



If the lever is stuck in **P**, even though you are depressing the brake pedal, the lever can be released manually.


To do this, unclip the base of the lever, then insert a tool (with a hard rod to it) into the slot **1** and press the button **2** at the same time in order to unlock the lever.

Contact an authorised dealer as soon as possible.



When the engine is stopped, steering and braking assistance are no longer provided.

TOWING: breakdown recovery (2/2)




Only use the front 3 and rear 6 towing points
(never use the drive shafts or any other part of the vehicle)

These towing points may only be used for towing: never use them for lifting the vehicle directly or indirectly.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking.



Access to towing points

Front towing point 3

Press zone **A** and keep depressed while pulling zone **B** to open flap **4**.

Rear towing point 6

Press zone **C** and keep depressed while pulling zone **D** to open flap **7**.

Screw in the tow eye **5** by hand as far as possible.

Use only the **5** towing eye ➔ 5.8.



Ensure that the towing eye is bolted correctly.

Risk of losing the towed object.



– Use a rigid towing bar. If a rope or cable is used (where the law allows this), the vehicle being towed must be able to brake.

- A vehicle must not be towed if it is not fit to be driven.
- Avoid accelerating or braking suddenly when towing, as this may result in damage being caused to the vehicle.
- When towing a vehicle, it is advisable not to exceed **30 mph (50 km/h)**.

OPERATING FAULTS (1/8)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved Dealer as soon as possible.

Using the card	POSSIBLE CAUSES	WHAT TO DO
The card does not lock or unlock the doors.	Card battery is flat.	Replace the battery or have it replaced. You will still be able to lock/unlock and start your vehicle. ➔ 1.14 and ➔ 2.4 or ➔ 2.5.
	Use of appliances operating on the same frequency as the card (mobile phone, etc.).	Stop using the devices or use the key provided. ➔ 1.14.
	Vehicle located in a high electromagnetic radiation zone. Vehicle battery flat.	Use the key that is built into the card ➔ 1.14.
	The vehicle is started.	With the engine running, the card's locking/unlocking device is blocked. Turn off the ignition.
The message "Place the card near the START button" appears on the instrument panel.	The card battery is flat or the card is out of synch.	Check the card battery status or place the card in the placement area ➔ 2.5 provided for this purpose, then press the "START" button.

OPERATING FAULTS (2/8)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved Dealer as soon as possible.

Using the card	POSSIBLE CAUSES	WHAT TO DO
	Desynchronisation of the card.	Unlock the driver's door by inserting the key integrated in the card into the door lock ➡ 1.14 then place the card in the placement area ➡ 2.5 and press the “ START ” button to synchronise the card.

OPERATING FAULTS (3/8)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved dealer as soon as possible.

Using the remote control	POSSIBLE CAUSES	ACTION REQUIRED
The remote control does not lock or unlock the doors.	The remote control battery is flat.	Use the emergency key.
	Use of appliances operating on the same frequency as the remote control (mobile phone, etc.).	Stop using the devices or use the key.
	Vehicle located in a high electromagnetic radiation zone. Discharged battery.	Replace the battery or have it replaced. You will still be able to lock, unlock, and start your vehicle. ➡ 1.14 and ➡ 2.4 or ➡ 2.5.
	The vehicle is started.	With the engine running, the key's locking/unlocking device is blocked. Turn off the ignition.
	Desynchronisation of the remote control.	Unlock the driver's door using the key in the door lock, then start the engine to synchronise the remote control.

OPERATING FAULTS (4/8)

The starter is activated	POSSIBLE CAUSES	WHAT TO DO
The instrument panel indicator lights are weak or fail to light up and the starter does not turn.	Battery terminals not tight, battery terminals disconnected or oxidised.	Retighten or reconnect the terminals, or clean them if they are oxidised.
	Discharged battery or not operational.	Connect another battery to the faulty battery. ➡ 5.30 or replace the battery if necessary. Do not push the vehicle if the steering column is locked.
	Faulty circuit.	Consult an approved dealer.
The engine will not start.	Starting conditions are not fulfilled.	➡ 2.4 or ➡ 2.5.
	The card does not work.	➡ 2.4 or ➡ 2.5.
With the vehicle stationary, engine cold, the engine's idle speed is high.	Petrol version, this is not necessarily a fault. This may be caused by the increase in the engine temperature.	The engine's idle speed should decrease after about one minute. Otherwise, this may be caused by another fault. Call an approved Dealer.
The engine cannot be switched off.	Card not detected.	➡ 2.4 or ➡ 2.5.
	Electronic fault.	Press the starter button quickly five times.
The steering column remains locked.	Steering wheel locked.	Move the steering wheel whilst pressing the engine start button (or, depending on the vehicle, operating the ignition key) ➡ 2.4.
	Faulty circuit.	Consult an approved dealer.

OPERATING FAULTS (5/8)

On the road	POSSIBLE CAUSES	WHAT TO DO
Vibrations.	Tyres not inflated to correct pressures, incorrectly balanced or damaged.	Check the tyre pressures: if this is not the problem, have them checked by an approved Dealer.
White smoke from the exhaust.	In the diesel version, this is necessarily a fault. Smoke may be caused by particle filter regeneration.	➡ 2.14.
Smoke under the bonnet.	Short-circuit or cooling system leak.	Stop, switch off the ignition, stand away from the vehicle and contact an approved dealer.
The oil pressure warning light comes on:		
while cornering or braking;	The level is too low.	Top up the engine oil ➡ 4.5.
is slow to go out or remains lit up under acceleration.	Loss of oil pressure.	Stop the vehicle and contact an approved Dealer.

OPERATING FAULTS (6/8)

On the road	POSSIBLE CAUSES	WHAT TO DO
Steering becomes heavy.	Assistance overheating. Fault with the electric assistance motor. Fault in the assistance system.	Drive carefully at reduced speed, be aware of the level of force in the steering wheel needed to turn the wheels. Consult an approved dealer
The engine is overheating. The coolant temperature indicator is in the warning zone and warning light STOP comes on.	Engine cooling fan not working.	Stop the vehicle, switch off the engine and contact an approved dealer.
	Coolant leaks.	Check the coolant reservoir: it should contain fluid. If there is no coolant, consult an approved dealer as soon as possible.
Coolant boiling in the coolant reservoir.	Mechanical fault: damaged cylinder head gasket.	Stop the engine. Contact an approved dealer.



Radiator: If there is a significant lack of coolant, remember that it must never be topped up using cold coolant while the engine is very warm. After any procedure on the vehicle which has involved even partial draining of the cooling system, it must be refilled with a new mixture prepared in the correct proportions. Reminder: only products approved by our Technical Department may be used for this purpose.

OPERATING FAULTS (7/8)

Electrical equipment	POSSIBLE CAUSES	WHAT TO DO
The wipers do not work.	Wiper blades stuck.	Free the blades before using the wipers.
	Faulty electrical circuit.	Consult an approved dealer.
	Fuse damaged.	Replace the fuse or have it replaced ➡ 5.28.
The wiper does not stop.	Faulty electrical controls.	Consult an approved dealer.
Direction indicators flashing more quickly.	Blown bulb.	➡ 5.16 or ➡ 5.18.
The direction indicators do not work.	Faulty electrical circuit or control.	Consult an approved dealer.
	Fuse damaged.	Replace the fuse or have it replaced ➡ 5.28.
The lights do not come on or go off.	Faulty electrical circuit or control.	Consult an approved dealer.
	Fuse damaged.	Replace the fuse or have it replaced ➡ 5.28.



OPERATING FAULTS (8/8)

Electrical equipment	POSSIBLE CAUSES	WHAT TO DO
Traces of condensation in the lights and headlights.	Traces of condensation may be a natural phenomenon caused by variations in temperature and humidity. In this case, the traces will disappear slowly once the lights are switched on.	
The front seat belt reminder light comes on when the seat belts are fastened.	An object is stuck between the floor and the seat and is disrupting the operation of the sensor.	Remove all objects from underneath the front seats.

Section 6: Technical specifications

Vehicle identification plates	6.2
Technical Information for the emergency services	6.3
Engine identification	6.4
Dimensions	6.6
Engine specifications	6.9
Weights	6.12
Towing weights	6.12
Replacement parts and repairs	6.13
Service sheets	6.14
Anticorrosion check	6.20

48148




The presence and location of the information depends on the vehicle.

- 1 Manufacturer name.
- 2 EC design number or approval number.
- 3 Identification number.


Depending on the vehicle, this information is also given on marking *B*.

- 4 MMAC (Maximum permissible all-up weight).
- 5 MTR (Gross train weight: vehicle fully loaded, with trailer).
- 6 MMTA (Maximum Permissible Weight) front axle.
- 7 MMTA rear axle.
- 8 Reserved for related or additional entries.
- 9 Diesel exhaust emissions.
Depending on the vehicle, this information is not indicated on the manufacturer's plate but on the engine smoke opacity label ➡ 2.14.
- 10 Paint reference (colour code).




TECHNICAL INFORMATION FOR THE EMERGENCY SERVICES

57275



57276




The QR Code on the **A** label allows emergency workers using a tablet or smartphone to immediately access the technical information useful for working on the vehicle in the event of an accident.

Ensure that the **A** label is always visible and present on the windscreen as well as the rear screen.

Any modification or damage would prevent access to the information.

ENGINE IDENTIFICATION (1/2)

33293




Please quote the engine identification information in area A in all correspondence or orders.

(Location varies depending on engine)


- 1 Engine type.
- 2 Engine suffix.
- 3 Engine serial number.

48186




1.0 TCe

41046




1.6 16v

44377



1.3 TCe


48179



1.8 TCe

ENGINE IDENTIFICATION (2/2)

33293




Please quote the engine identification information in area A in all correspondence or orders.

(Location varies depending on engine)

- 1** Engine type.
- 2** Engine suffix.
- 3** Engine serial number.


40989



DIMENSIONS (in metres) (1/3)

Five-door version

48188




* Unladen

DIMENSIONS (in metres) (2/3)

Estate versions

48191




* Unladen

DIMENSIONS (in metres) (3/3)

Four-door version

48242



* Unladen

ENGINE SPECIFICATIONS (1/3)

Versions	1.0 TCe	1.3 TCe	1.6 16V	1.8 TCe	1.5 dCi
Engine type (see engine plate)	H5D Turbo	H5H Turbo	H4M	M5P Turbo	K9K
Cubic capacity (cc)	999	1333	1598	1798	1461
Type of fuel Octane rating	Petrol You must use unleaded petrol with the octane rating stated on the label inside the fuel filler flap. ➡ 1.116.			Diesel The label located in the fuel filler flap indicates the authorised fuels.	

ENGINE SPECIFICATIONS (2/3)

Versions	1.0 TCe	1.3 TCe	1.6 16V	1.8 TCe	1.5 dCi
Engine type (see engine plate)	H5D Turbo	H5H Turbo	H4M	M5P Turbo	K9K
Cubic capacity (cc)	999	1333	1598	1798	1461
Fuel types that meet European standards and are compatible with the engines of vehicles sold in Europe (in any other case, contact an Approved Dealer).	E5 Unleaded petrol compliant with standard EN 228 contains up to 5% ethanol in volume.			B7 Diesel fuel compliant with standard EN 590 contains up to 7% fatty acid methyl ester in volume.	
	E10 Unleaded petrol compliant with standard EN 228 contains up to 10% ethanol in volume.			B10 Diesel fuel compliant with standard EN 16734 contains up to 10% fatty acid methyl ester in volume.	
				XTL Diesel fuel compliant with standard EN 15940 contains up to 7% acid methyl ester in volume.	

ENGINE SPECIFICATIONS (3/3)

Versions	1.0 TCe	1.3 TCe	1.6 16V	1.8 TCe	1.5 dCi
Engine type (see engine plate)	H5D Turbo	H5H Turbo	H4M	M5P Turbo	K9K
Cubic capacity (cc)	999	1333	1598	1798	1461
Spark plugs	Only use the spark plugs specified for your vehicle's engine. The type should be marked on a label affixed inside the engine compartment. If it is not then contact an approved Dealer. Fitting spark plugs which are not to specification may damage the engine.				

WEIGHTS (in kg)

The weights indicated are for a basic vehicle without options: they may vary depending on your vehicle's equipment. Consult an approved Dealer.

	Five door	Estate	Four-door
Maximum Authorised Mass (MMAC) Maximum permissible weight (MMTA) Gross Train Weight (MTR)	Weights indicated on the vehicle identification plate ➡ 6.2		
Braked Trailer Weight*	found by calculating: MTR - MMAC		
Unbraked Trailer Weight*	635	660	655
Permissible nose weight*	75	75	75
Maximum permissible load on roof	80 kg (including the carrying device)		

* Towing weight (Towing a caravan, boat, etc.)

Towing is prohibited when the MTR - MMAC calculation is equal to zero, or when the MTR is equal to zero (or is not listed) on the identification plate.

- It is important to respect local towing regulations in force, specifically those set out in the Highway Code. Contact an approved Dealer for any modifications to towing equipment.
- When towing, under no circumstances may **the total train weight (vehicle + trailer) be exceeded**. However the following is permitted:
 - rear axle MMTA exceeded by no more than 15%,
 - maximum MMAC exceeded by no more than 10% or 100 kg (whichever is reached first).In either case, the maximum speed of the towing assembly must not exceed 60 mph (100 km/h) and the tyre pressure must be increased by 0.2 bar (3 PSI).
- The engine output and climbing capability are reduced with altitude. We recommend that the maximum load be reduced by 10% at an altitude of 1,000 metres and by an additional 10% for each 1,000 metres thereafter.

REPLACEMENT PARTS AND REPAIRS

Original parts are based on strict specifications and are subject to highly-specialised tests. Therefore, they are of at least the same level of quality as the parts fitted originally.

If you always fit genuine replacement parts to your vehicle, you will ensure that it performs well. Furthermore, repairs carried out within the manufacturer's Network using original parts are guaranteed according to the conditions set out on the reverse of the repair order.

SERVICE SHEETS (1/6)

VIN:

Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		

SERVICE SHEETS (2/6)

VIN:

Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		

SERVICE SHEETS (3/6)

VIN:

Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		

SERVICE SHEETS (4/6)

VIN:

Date: Miles (Km):		Invoice number:	Comments/miscellaneous
Type of operation: Service ☐ ☐		Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page			
Date: Miles (Km):		Invoice number:	Comments/miscellaneous
Type of operation: Service ☐ ☐		Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page			
Date: Miles (Km):		Invoice number:	Comments/miscellaneous
Type of operation: Service ☐ ☐		Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page			

SERVICE SHEETS (5/6)

VIN:

Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		
Date: Miles (Km): Invoice number:		Comments/miscellaneous
Type of operation: Service ☐ ☐	Stamp	
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page		

SERVICE SHEETS (6/6)




VIN:

Date:		Miles (Km):		Invoice number:		Comments/miscellaneous	
Type of operation: Service ☐ ☐		Stamp					
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page							
Date:		Miles (Km):		Invoice number:		Comments/miscellaneous	
Type of operation: Service ☐ ☐		Stamp					
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page							
Date:		Miles (Km):		Invoice number:		Comments/miscellaneous	
Type of operation: Service ☐ ☐		Stamp					
Anti-corrosion check: OK ☐ Not OK* ☐ *See specific page							

ANTICORROSION CHECK (1/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

Corrosion repair operation to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		

ANTICORROSION CHECK (2/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

Corrosion repair operation to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		

ANTICORROSION CHECK (3/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

Corrosion repair operation to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		

ANTICORROSION CHECK (4/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

Corrosion repair operation to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		

ANTICORROSION CHECK (5/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

Corrosion repair operation to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		

ANTICORROSION CHECK (6/6)

If the continuation of the warranty is subject to repair, it is indicated below.

VIN:

Corrosion repair operation to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		
Repair to be carried out:		Stamp
Date of repair:		



ALPHABETICAL INDEX (1/9)

A

ABS 1.68, 2.43 → 2.48
access
 vehicle 0.3, 1.9 → 1.12
accessories 2.5 → 2.7, 5.36
accessories socket 3.27, 3.40 – 3.41
adaptive cruise control 1.70, 2.94 → 2.107
AdBlue 1.119 → 1.122
additional methods of restraint
 side protection 1.41
 to the front seat belts 1.34 → 1.39
 to the rear seat belts 1.40
additional methods of restraint 1.34 → 1.39, 1.42
additional tank capacity 1.84, 1.88
additive (reagent) 1.119 → 1.122
adjusting your driving position 1.21 → 1.25, 1.28 → 1.33, 1.103
advice on antipollution 1.90, 2.30
air bag
 activating the front passenger air bags... 1.52, 1.55 → 1.60
 air bag 1.34 → 1.42, 1.52 → 1.60, 1.69, 1.71, 1.90
 air conditioning 3.3 → 3.24
 air vents 3.3 – 3.4
airbag
 front passenger airbag deactivation 1.55 → 1.57
airbags 0.7, 1.34 → 1.39, 1.52 → 1.60, 1.69, 1.90
anti-corrosion check 6.20 → 6.25
anti-corrosion protection 4.15
anti-lock braking system: ABS 2.43 → 2.48
antipollution
 advice 1.69, 2.30
armrest
 front 3.38
 rear 3.39
ashtray 3.40 – 3.41

assisted parking 1.70, 2.124 → 2.132, 2.137 → 2.141
audible and visual signals 1.61
AUTO mode 1.102 → 1.104
Autohold 2.21
automatic gearbox (use) 2.16, 2.20, 2.142 → 2.144
automatic gearbox selector lever 2.142 → 2.144
automatic locking of the doors while driving 1.19

B

batteries 5.32 – 5.33
battery
 breakdown recovery 5.30 – 5.31
 maintenance 4.11 – 4.12
 replacement 4.11 – 4.12
battery 0.9, 1.68, 4.11 – 4.12, 5.30 – 5.31
battery (remote control) 5.34 – 5.35
beep 1.91
blind spot warning signal 2.60 → 2.66
blind spot: warning signal 2.60 → 2.66
bonnet 4.2 – 4.3
brake 2.21
brake fluid 1.68, 4.9
brakes
 brake fluid level 1.68
 electronic parking brake 1.69
breakdown recovery 0.10, 5.39 – 5.40
bulbs
 changing 5.16 → 5.27

C

card: battery 5.32 – 5.33
catalytic converter 2.12 → 2.15
central door locking 1.2 – 1.3, 1.5 → 1.16, 1.19, 1.92 – 1.93
changing a bulb 5.16 → 5.27

ALPHABETICAL INDEX (2/9)

changing a wheel..... 5.11 – 5.12, 5.15
changing gear..... 2.16, 2.22 → 2.29, 2.142 → 2.144
child restraint/seat 1.43 – 1.44, 1.46 → 1.57
child safety 0.4, 1.6, 1.9, 1.18, 1.39, 1.43 – 1.44, 1.46 → 1.60, 3.28 → 3.32
child seats..... 1.43 – 1.44, 1.46 → 1.57
children 0.4, 1.43 – 1.44, 1.52 → 1.60
children (safety)..... 1.6, 1.18, 3.28 → 3.32
cigar lighter..... 3.40 – 3.41
cleaning:
 inside the vehicle 4.18 – 4.19
clock
 setting 1.84, 1.86
clock 1.97 – 1.98
closing the doors 1.6 → 1.12, 1.14 → 1.19
configuration menu..... 1.92 → 1.94
control instruments 1.66 → 1.84, 1.97 – 1.98
controls
 doors/opening elements 1.9 → 1.12
 steering wheel control..... 3.26
controls 0.5, 1.62 → 1.65, 2.85 → 2.107
coolant..... 1.69, 1.74 – 1.75, 1.77, 4.8
courtesy light 3.33 – 3.34, 5.25 → 5.27
courtesy mirrors..... 3.35, 5.25 → 5.27
cruise control 1.70, 2.89 → 2.93
cruise control-speed limiter..... 2.85 → 2.93
customised vehicle settings 1.92 → 1.94
customising the vehicle settings 1.92 → 1.94

D

dashboard..... 0.5, 1.62 → 1.65
daytime running lights..... 1.6 → 1.8, 1.93, 1.102 → 1.107
deadlocking the doors 1.5, 1.13

deflector
 luggage net..... 3.52 – 3.53
de-icing
 rear screen..... 3.8 → 3.12
de-icing/de-misting
 rear view mirrors 3.13 → 3.17
 rear window 3.13 → 3.17
 windscreen..... 3.8 → 3.17
 demisting
 rear screen..... 3.5 → 3.12
 windscreen..... 3.5 → 3.12
 deodourisation 3.25

diesel

 special features of diesel versions 1.69
diesel 1.69
dimensions 6.6 → 6.8
dipstick..... 4.4
display 1.66 → 1.80, 1.74 → 1.80, 3.26
doors..... 1.17 → 1.19, 1.69, 1.92 – 1.93
doors/tailgate..... 1.4, 1.6 → 1.16, 1.19
driver assistance..... 0.6, 2.43 → 2.107, 2.124 → 2.141, 2.145 → 2.147, 3.2
driver's position 0.5, 1.62 → 1.71
driving 0.6, 1.92 – 1.93, 2.2 → 2.7, 2.12 → 2.15, 2.17 → 2.29, 2.32 → 2.37, 2.43 → 2.80, 2.85 → 2.107, 2.124 → 2.147, 3.2
driving aids
 adaptive cruise control..... 2.94 → 2.107
driving aids 0.6, 1.93 – 1.94, 2.49 → 2.141, 2.145 → 2.147, 3.2
driving position
 settings 0.4, 1.29 → 1.33, 1.95
driving recommendations 2.22 → 2.29

E

ECO driving 1.70, 2.22 → 2.29

ALPHABETICAL INDEX (3/9)

ECO mode 2.22 → 2.29, 3.16, 3.23
electric beam height adjustment 1.101
electric windows 3.28 – 3.29
electronic parking brake 1.69, 2.17 → 2.21
Electronic Stability Control: ESC 2.43 → 2.48
electronic stability control: ESC 2.43 → 2.48
emergency active braking 1.70, 2.71 → 2.78
emergency brake assist 2.43 → 2.48
emergency braking 2.43 → 2.48, 2.71 → 2.78
emergency call 2.145 → 2.147
emergency key 1.6 → 1.8
emergency spare wheel 5.2 → 5.4, 5.14
engine
 technical specifications 6.9 → 6.11
engine coolant 1.69, 1.74 – 1.75, 1.77, 4.8
engine identification 0.8, 6.4
engine oil 1.68, 4.4 → 4.7
engine oil capacity 4.5 → 4.7
engine oil grade 4.5 → 4.7
engine oil level 1.72, 4.4 → 4.7
engine specifications 6.4 – 6.5, 6.9 → 6.11
engine standby 1.70, 2.8 → 2.11
engine start/stop button 2.5 → 2.7
environment 2.31
equipment
 fitting 3.60
equipment 3.60
ESC: electronic stability control 1.69, 2.43 → 2.48
exhaust 1.70
exterior air quality 3.25
external temperature 1.97 – 1.98

F

fatigue detection warning 2.79 – 2.80

faults

 operating faults 2.12 → 2.15, 2.20, 2.44 → 2.48, 2.52,
 2.64, 2.75, 2.80, 2.84, 2.101, 2.128, 2.135, 2.144, 2.147,
 3.29, 3.32, 5.33, 5.35, 5.41 → 5.48
 file 1.21, 1.24
filling with reagent 1.119 → 1.122
filter
 air filter 4.10
 diesel filter 1.90, 4.10
 oil filter 4.5 → 4.7, 4.10
 particle filter 1.70, 2.13 → 2.15
 passenger compartment filter 4.10
fittings 3.36 → 3.39
freewheel 1.70, 2.24
front passenger air bag deactivation 1.58 → 1.60
front seat
 driver's position memory 1.28
front seat adjustment 1.21 → 1.28
front seats
 adjustment 1.21 → 1.29
 with electric controls 1.24
fuel
 advice on fuel 2.22 → 2.29
 capacity 1.116
 consumption 2.22 → 2.29
 filling 1.67, 1.116 → 1.118
 quality 1.116 → 1.118
fuel consumption 1.84, 2.22 → 2.29, 3.23
fuel economy 2.22 → 2.29
fuel filler cap 0.3, 1.116
fuel level 1.66 → 1.71, 1.73 – 1.74, 1.76, 1.78, 1.116 → 1.118
fuel repriming 1.118, 2.14 – 2.15
fuel tank
 capacity 1.116 → 1.118

ALPHABETICAL INDEX (4/9)

fuel tank capacity 1.116 → 1.118
fuses 0.10, 5.28 – 5.29

G

gear lever 2.16, 2.142 → 2.144
grab handle 3.38

H

handbrake 2.16 → 2.20
handsfree 3.47 – 3.48
hands-free telephone integrated control 3.26 – 3.27
«hands-free» card: battery 5.32 – 5.33
hazard warning lights signal 1.61
headlight beam adjustment 1.101
headlight flashers 1.61
headlight washer 1.113
headrest 3.42 – 3.43
head-up display 1.79 – 1.80
heated seats 1.23, 1.25
heated steering wheel 1.95
heated windscreen 3.8 → 3.22
heating and air conditioning system 3.5 → 3.23
heating system 3.5 → 3.24
Hill Start Assist 2.43 → 2.48
hooks
 bag hooks 3.54 → 3.58
 for towing 3.52 → 3.58
 horn 1.61
horn:
 flash 1.61
 sounding the horn 1.61
hubcap tool 5.8 → 5.10

I

ignition switch 2.3, 2.17 → 2.20
indicator lights 5.18 → 5.24
indicators
 driving style 1.74 – 1.75, 1.78
 exterior temperature 1.98
indicators 1.61, 2.60 → 2.66, 5.16 → 5.24
indicators:
 direction indicators 1.61
 instrument panel 1.66 → 1.80, 1.74 → 1.84, 1.121 – 1.122,
 2.8 → 2.11, 2.13 → 2.30, 2.32 → 2.37
 information and general advice
 welcome aboard your vehicle 0.1
instrument panel
0.5, 1.66 → 1.80, 1.74 → 1.80, 1.77, 1.81 → 1.91, 1.93 – 1.94,
2.8 → 2.11, 2.16 → 2.30, 2.32 → 2.37
instrument panel messages 1.81 → 1.91, 2.8 → 2.11,
2.13 – 2.15, 2.17 → 2.20, 2.32 → 2.37
interior lighting:
 changing bulbs 5.25 → 5.27
interior trim
 maintenance 4.18 – 4.19
Isofix 1.46 → 1.49, 1.55 → 1.57

J

jack 5.8 – 5.9, 5.11 – 5.12

K

keys
 replacing the battery 5.32 → 5.35
 keys 1.2 → 1.5

L

lane centring 2.114 → 2.123

ALPHABETICAL INDEX (5/9)

lane departure warning.....	1.70, 2.49 → 2.59
Lane Keeping Assist.....	2.54 → 2.59
lane keeping: assistance	2.54 → 2.59
level information	
fuel	1.76
levels	0.9, 4.8 → 4.10
levels:	
brake fluid	4.9
coolant	4.8
engine oil	4.4 → 4.7
windscreen washer reservoir	4.10
lifting the vehicle	
changing a wheel.....	5.11 – 5.12
lighting	
glovebox	3.33 – 3.34
interior.....	3.33 – 3.34
luggage compartment	3.33 – 3.34
lighting:	
exterior.....	0.3, 1.7, 1.61, 1.101 → 1.107
instrument panel	1.102 → 1.107
interior.....	5.25 → 5.27
see-me-home.....	1.92 – 1.93, 1.106
lights	
adjustment	1.101
changing bulbs.....	5.16 – 5.17
front.....	5.16 – 5.17
lights:	
adjusting	1.101
adjustment of headlight beam height.....	1.101
brake lights	5.18 → 5.24
daytime running lights.....	1.105
dipped beam headlights.....	1.67, 1.102 – 1.103, 1.105 – 1.106, 5.16 – 5.17
direction indicator lights	1.67

direction indicators.....	1.61, 5.16 → 5.24
fog lights	1.67, 1.102 → 1.107, 5.16 → 5.24
hazard warning	1.61
main beam headlights.....	1.67, 1.102 → 1.104, 5.16 – 5.17
number plate lights	5.18 → 5.24
reversing lights.....	5.18 → 5.24
side lights.....	1.67, 1.102, 1.106, 5.16 → 5.24
lights-on warning buzzer.....	1.105
load permitted on the roof.....	6.12
locking	1.30 → 1.33
locking the doors	1.4, 1.6 → 1.19, 1.92 – 1.93
luggage compartment.....	3.51 → 3.53
luggage compartment cover.....	3.51
luggage compartment floor.....	3.51
luggage compartment lighting	
changing bulbs.....	5.25 → 5.27
luggage retaining net.....	3.52 – 3.53
lumbar: seat adjustment	1.21, 1.24

M

maintenance.....	2.30, 3.23
maintenance:	
bodywork	4.15 → 4.17
interior trim.....	4.18 – 4.19
mechanical.....	4.2 → 4.7, 4.11 – 4.12, 6.14 → 6.19
mileage before service.....	1.84, 1.87 – 1.88
map	
battery.....	5.32 – 5.33
hands-free.....	1.9 → 1.12
use	1.6 → 1.12
map reading lights	3.33 – 3.34, 5.25 → 5.27
massage: seat massage.....	1.26
menu for customising the vehicle settings.....	1.81 → 1.84, 1.92 → 1.94

ALPHABETICAL INDEX (6/9)

methods of restraint in addition to the seat belts...1.34 → 1.42
mileage before service 1.84, 1.87 – 1.88
mobile floor.....3.54 → 3.58
Motorway and Traffic assistant.....2.108 → 2.123
multimedia (equipment)..... 3.26 – 3.27
multimedia equipment 1.92, 1.97 – 1.98, 1.105, 3.26 – 3.27
Multi-Sense..... 1.96, 3.2

N

navigation 3.26 – 3.27
navigation system..... 3.26 – 3.27

O

oil change4.4 → 4.7
opening the doors.....1.14 → 1.19
opening/closing
 bonnet..... 4.2 – 4.3
opening/closing
 bonnet..... 4.2 – 4.3
opening/closing
 doors.....1.9 → 1.12
 sunroof.....3.30 → 3.32
opening/closing
 sunroof.....3.30 → 3.32
operating faults..... 1.19, 1.36, 1.60,
1.66 → 1.71, 1.80 → 1.84, 1.90 – 1.91, 1.104 – 1.105, 1.110,
2.5 → 2.7, 2.11 → 2.15, 2.20, 2.44 → 2.48, 2.52, 2.58, 2.64,
2.75, 2.80, 2.84, 2.101, 2.128, 2.135, 2.144, 2.147, 3.23, 3.29,
3.32, 5.33, 5.35, 5.41 → 5.48
operation.....2.142 → 2.144
overspeed buzzer..... 1.73, 1.75, 1.78
overspeed warning2.81 → 2.88

P

paint
 maintenance4.15 → 4.17
parking assistance: assisted parking.....2.124 → 2.132,
2.137 → 2.141
parking brake.....1.89, 2.17 → 2.21
parking distance control.....1.93 – 1.94, 2.124 → 2.132,
2.137 → 2.141
pedestrian detection2.71 → 2.78
power-assisted steering..... 1.96
precautions during use1.108 → 1.113
pretensioners.....1.34 → 1.39
puncture
 emergency spare wheel.....5.2 → 5.4
 tyres5.2 → 5.4
puncture.....0.10, 1.91, 5.2 → 5.9, 5.11 – 5.12

Q

QR Code 0.8, 6.3

R

radio..... 3.26 – 3.27
radio frequency remote control/key
 battery5.34 – 5.35
 use1.2 → 1.4
 range with fuel 1.73, 1.76 – 1.77
reading lights 3.33 – 3.34
reagent 1.70
reagent (tank)1.119 → 1.122
reagent quality1.119 → 1.122
reagent tank.....1.119 → 1.122
reagent tank cap.....1.119 → 1.122
reagent tank capacity1.119 → 1.122
rear bench seat.....1.46 → 1.49, 3.44 – 3.45

ALPHABETICAL INDEX (7/9)

rear drive wheels	2.43 → 2.48
rear parcel shelf.....	3.50 – 3.51
Rear Power Sunblind.....	3.35
rear screen de-icing/demisting	3.10, 3.13 → 3.22
rear seats	
functions	3.44 – 3.45
rear seats.....	1.32, 1.46 → 1.49
rear view camera	2.130 → 2.132
rear view mirrors.....	0.3, 1.99 – 1.100
remote control	
batteries	5.34 – 5.35
remote control	1.9 → 1.12
remote control door locking	
batteries	5.34 – 5.35
remote control door locking unit	1.2 → 1.4
RENAULT card	
use	1.13
replacement	
tyres	5.15
replacement parts.....	6.13
reverse gear	
selecting.....	2.16, 2.133 → 2.136, 2.142 → 2.144
reversing sensor	2.124 → 2.129, 2.133 → 2.136
roof bars	3.61 – 3.62
roof rack	
roof bars.....	3.61 – 3.62
running in.....	2.2 – 2.3

S

safety distance warning	2.67 → 2.70
safety distances.....	2.67 → 2.70
SCR: selective catalytic reduction	1.119 → 1.122
screen	
fold-away screen.....	1.79

navigation display	1.73, 1.75, 3.26 – 3.27
navigation screen.....	1.73, 1.75, 3.26 – 3.27
screen wash/wipe	1.114 – 1.115
screens	
multimedia screen.....	2.57, 2.60 → 2.66, 2.68, 2.74, 2.79 – 2.80, 2.82, 2.127 → 2.129, 2.134, 3.2, 3.8 → 3.12, 3.16, 3.26
seat base	1.21, 1.24
seat belt pretensioners	
front seat belt	1.34 → 1.39
seat belt pretensioners	1.34 → 1.39
seat belts ...	0.7, 1.29 → 1.39, 1.46 → 1.49, 1.52 → 1.57, 1.71
seats	
driver seat with position memory	1.28
driver: adjustment of driving position	1.28
seats	0.4
service sheets.....	6.14 → 6.19
settings	
configuration menu	1.92 → 1.94
settings	1.92 → 1.94
sign detection: overspeed warning	2.81 → 2.84
signals and lights	1.61, 1.101 → 1.107
special features of diesel versions.....	2.14 – 2.15
special features of petrol vehicles	2.12 – 2.13
speed	
gear change indicator	1.69
overspeed warning	1.75, 1.78
speed limiter	1.70, 2.85 → 2.88
starting.....	1.89
starting the engine	2.3 → 2.11
steering wheel	
adjustment	1.95
Stop & Start.....	1.70, 1.96, 1.117, 2.8 → 2.11, 2.22 → 2.29
Stop & Start function.....	2.8 → 2.11, 2.17 → 2.20, 2.22 → 2.29

ALPHABETICAL INDEX (8/9)

stopping the engine 2.4 → 2.7, 2.17 → 2.20
storage compartment.....3.36 → 3.39
storage compartments.....3.36 → 3.39, 3.54 → 3.58
storage/organisation
 luggage compartment3.54 → 3.58
storage/organisation 0.4
sun visor 3.35
sunroof.....3.30 → 3.32
switching on the vehicle ignition 2.3 – 2.4, 2.6

T

tailgate 1.2 – 1.3, 1.6 → 1.8, 1.16, 1.18, 3.46 → 3.59
tank
 Brake fluid 4.9
 Coolant 4.8
tanks and reservoirs:
 windscreen washer 4.10
technical specifications 6.6 → 6.13
telephone 3.26 – 3.27
temperature regulation 3.8 → 3.24
tool kit 5.8 – 5.9
towing
 breakdown 5.39 – 5.40
 towing equipment..... 3.59 – 3.60
towing 0.10, 3.60, 5.39 – 5.40
towing a caravan 3.59 – 3.60, 6.12
towing hitch..... 5.8 – 5.9, 5.39 – 5.40
towing rings 3.52 → 3.59
towing weights..... 6.12
traction control.....2.43 → 2.48
traction control: ASR.....2.43 → 2.48
transporting children 1.43 – 1.44, 1.46 → 1.57
transporting objects
 in the luggage compartment 3.59

luggage net 3.52 – 3.53
 on the roof..... 6.12
trims..... 5.10
trip computer and warning system..... 1.66 → 1.71, 1.73,
 1.76 – 1.77, 1.81 → 1.91, 1.93
tyre inflation kit..... 2.32 → 2.42, 5.2 → 5.7
tyre pressure...0.8, 1.84, 1.86, 2.29, 2.32 → 2.42, 4.13 – 4.14,
 5.2 → 5.7, 5.12, 5.14
tyre pressure loss warning..... 2.32 → 2.37
tyre pressure monitor..... 1.70, 2.38 → 2.42, 4.13 – 4.14, 5.6,
 5.12, 5.14
tyre pressures 2.32 → 2.42, 4.13 – 4.14, 5.5 → 5.7
tyres
 chains 5.15
 replacement 5.15
 snow tyres 5.15
 studded tyres 5.15
 tyre pressure monitoring system..... 2.38 → 2.42
tyres..... 0.3, 2.29, 2.32 → 2.42, 4.13 – 4.14, 5.13 → 5.15

U

unlocking the doors 1.6 → 1.12, 1.14 → 1.16, 1.19

V

variable power-assisted steering 1.68, 1.96
vehicle detection..... 2.71 → 2.78, 2.133 → 2.136
vehicle identification 0.8
vehicle identification plates..... 0.8, 6.2
vehicle range 1.73, 1.76 – 1.77
ventilation
 ventilation..... 3.3 – 3.4
ventilation 3.3 → 3.24

ALPHABETICAL INDEX (9/9)

W

warning

assisted parking	2.133 → 2.136
warning buzzer	1.17, 1.61
warning lights	1.66 → 1.91
washing	4.15 → 4.17
weights	6.12
welcome aboard your vehicle	0.1
wheelbrace	5.8 – 5.9, 5.11 – 5.12
wheels (safety)	5.13 → 5.15
windows	0.3
windscreen	3.8 → 3.22
windscreen de-icing/demisting	3.10, 3.18 → 3.22
windscreen washer.1.108 → 1.113, 1.112, 1.114 – 1.115, 4.10	
windscreen washer/wiper	1.92 – 1.93, 1.108 → 1.113
wiper blades	0.10, 1.108, 1.111, 5.37 – 5.38
wipers	
blades	1.108, 1.111, 1.114 – 1.115, 5.37 – 5.38
wipers	1.108 → 1.115





RENAULT S.A.S. SOCIÉTÉ PAR ACTIONS SIMPLIFIÉE AU CAPITAL DE 533 941 113 € / 122-122 BIS, AVENUE DU GENERAL LECLERC
92100 BOULOGNE-BILLANCOURT R.C.S. NANTERRE 780 129 987 — SIRET 780 129 987 03591 / renaultgroup.com

NU 1338-7 - 99 91 037 69S - 10/2022 - Edition anglaise



9 99 1037 69S

WM