

KANGOO E-Tech

100% electric

vehicle user manual



Welcome to your new electric vehicle

This driver's handbook contains the information necessary:

- for you to familiarise yourself with your vehicle, to use it to its best advantage and to benefit fully from the all the functions and the technical developments it incorporates.
- to ensure that it always gives the best performance by following the simple, but comprehensive advice concerning regular maintenance.
- to enable you to deal quickly with minor faults not requiring specialist attention.

It is well worth taking a few minutes to read this handbook to familiarise yourself with the information and guidelines it contains about the vehicle and its functions and new features. If certain points are still unclear, our Network technicians will be only too pleased to provide you with any additional information.

To help you, you will find the following symbols:



and



These appear in the vehicle and indicate that you should consult the manual for detailed information and/or limits on operations with respect to your vehicle's equipment.

→ anywhere in the manual indicates a transfer to a page.



anywhere in the manual indicates a hazard, danger or a safety recommendation.


The descriptions of the models given in this handbook are based on the technical specifications at the time of writing. **This handbook covers all items of equipment** (both standard and optional) **available for these models** but whether or not these are fitted to the vehicle depends on the version, options selected and the country where the vehicle is sold. This handbook may also contain information about items of equipment to be introduced later in the model year. The diagrams in the user manual are provided as examples.

Enjoy driving your new vehicle.

Translated from French. Copying or translation, in part or in full, is forbidden unless prior written permission has been obtained from the car manufacturer.

EXTERIOR

57985



PASSENGER COMPARTMENT

Adjusting your driving position ➔ 1.69

Front seats ➔ 1.60

Front headrests ➔ 1.59

Child safety ➔ 1.88

Passenger compartment storage/fitting ➔ 3.28


Rear headrests ➔ 3.38

Rear seats ➔ 3.41 ➔ 3.44


Transporting objects in the luggage compartment ➔ 3.70

Rear parcel shelf ➔ 3.62

Luggage cover ➔ 3.63



DRIVER'S POSITION



DRIVING AIDS

ABS (anti-lock braking system)

ESC (electronic stability control)

Braking assistance

Detection of road signs ➔ 2.78

Hill start assistance


Driver assistance with a trailer

Speed limiter ➔ 2.82

Traction control - Extended grip

➔ 2.28

Advanced safety ➔ 2.59



Lane departure warning ➔ 2.34

Lane Keeping Assist ➔ 2.39

Blind spot warning ➔ 2.45

Safe distance alert ➔ 2.55

Fatigue detection warning ➔ 2.76

Cruise control ➔ 2.86

Stop and Go adaptive cruise control ➔ 2.91

Parking distance control ➔ 2.121

Reversing camera ➔ 2.129

Camera rear view ➔ 1.170

Assisted parking ➔ 2.133

Tyre pressure monitoring system ➔ 2.23

SAFETY ON BOARD

Front Airbags ➔ 1.79

Inhibiting the front passenger airbag ➔ 1.131

57992

Curtain Airbags ➔ 1.86

Side Airbags ➔ 1.86

Seat belts ➔ 1.69

IDENTIFYING A VEHICLE - LABELS

57986

Technical information
for emergency services
→ 6.3

Vehicle identification
plate → 6.2

Review of a vehicle identification
number → 6.2



Engine identification → 6.4

Tyre pressure labels → 2.23 → 4.8




THE ENGINE COMPARTMENT (routine maintenance)

57990

Coolant level ➔ 4.4

Windscreen washer fluid
➔ 4.4

Opening the bonnet ➔ 4.2



Brake fluid ➔ 4.4

“400 V” electric
circuits ➔ 1.2

Secondary “12 V”
battery ➔ 4.6

BREAKDOWN RECOVERY

57989


Replacing windscreen wiper
blade(s) ➔ 5.38



Replacing headlight bulbs
➔ 5.16

Front towing point ➔ 5.40

Replacing the rear screen
wiper blade ➔ 5.38



Replacing rear light bulbs
➔ 5.18

Rear towing point ➔ 5.40



Puncture:
Tools ➔ 5.8
Emergency spare
wheel ➔ 5.2
Changing a wheel
➔ 5.11



Fuses ➔ 5.35

0.10

C O N T E N T S

Sections

Getting to know your vehicle

1

Driving

2

Your comfort

3

Maintenance

4

Practical advice

5

Technical specifications

6

Alphabetical index

7


0.12

Section 1: Getting to know your vehicle

| | |
|--|-------|
| Electric vehicle: presentation, important recommendations, charging, programming | 1.2 |
| Key, radio frequency remote control: general information, use, deadlocking | 1.24 |
| Card: general information, use, deadlocking | 1.29 |
| Digital key | 1.45 |
| Opening and closing the doors | 1.49 |
| Locking, unlocking the opening elements | 1.55 |
| Automatic locking when driving | 1.58 |
| Headrests, front seats | 1.59 |
| Seat belts. | 1.69 |
| Additional methods of restraint | 1.79 |
| at the front, rear, side seat belts. | 1.79 |
| Child safety: general information. | 1.88 |
| choosing a child seat mounting | 1.91 |
| fitting a child seat, general information. | 1.94 |
| Child seats: attachment by seat belt or by Isofix system. | 1.96 |
| deactivating, activating the front passenger airbag | 1.131 |
| Driving position | 1.134 |
| Warning lights | 1.138 |
| Instrument panel | 1.138 |
| displays and indicators, trip computer | 1.142 |
| vehicle settings customisation menu | 1.159 |
| Clock and outdoor temperature. | 1.162 |
| Steering wheel, Power-assisted steering | 1.164 |
| Rear view mirrors | 1.166 |
| Camera rear view | 1.170 |
| Audible and visual signals | 1.174 |
| Exterior lighting and signals. | 1.175 |
| Headlight beam adjustment. | 1.181 |
| Washers, wipers | 1.183 |

ELECTRIC VEHICLE: introduction (1/6)

57929




- 1** Electric charging connection
- 2** Electric motor
- 3** Secondary 12V battery
- 4** 400 V traction battery
- 5** Orange "400 V" electrical power cables

ELECTRIC VEHICLE: introduction (2/6)

Electric vehicles have special features, but operate in a similar manner to conventional vehicles.

The main difference in electric vehicles is the exclusive use of electric energy instead of fuel, as used in conventional vehicles.

We therefore recommend that you read these instructions describing your electric vehicle carefully.



57859

Connected services (depending on the vehicle)

Your electric vehicle has connected services that provide information and/or control:

- your vehicle's charging status with low battery warning;
- the traction battery charging programming, based on certain choices on offer;
- remaining vehicle range;
- ...

You can access these services by:

- external digital devices (mobile telephones 7, tablets 8 etc.);
- the vehicle multimedia screen 6.

For more information, refer to the multimedia equipment instructions or contact an Approved Dealer.

You can subscribe to a connected service or extend it at any time by consulting an authorised dealer.

ELECTRIC VEHICLE: introduction (3/6)

Batteries

Your electric vehicle has two types of battery:

- a 400V traction battery;
- secondary 12 V battery.

400 V traction battery

This battery stores the energy necessary to operate the motor in your electric vehicle properly. As with any battery, it discharges after use, and must be regularly recharged.

You do not have to wait until the traction battery hits the reserve level in order to recharge it.

Charging times vary depending on the type of specific wall unit socket or public terminal you connect to.


Your vehicle range will depend on the charge level of the traction battery, and also on your driving style ➔ 2.20.

Secondary 12V battery

The second battery on your vehicle is a secondary 12 V battery: this supplies the energy required to operate vehicle equipment (lights, windscreen wipers, ABS, etc).


ELECTRIC VEHICLE: introduction (4/6)

A



The **A** symbol denotes the electrical elements of your vehicle which may present health risks.

33436



“400 volt” electrical circuit

The 400 V electrical circuit is denoted by orange cables **9** and parts bearing the  symbol.




The vehicle drive system in an electric vehicle uses a direct voltage of approximately 400 volts.

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.

All interventions or modifications to the 400V electrical system (components, cables, connectors, traction battery) are strictly prohibited due to the risks they present to your safety. Please contact an authorised dealer.

The risk of serious burns or electric shocks can lead to death.

ELECTRIC VEHICLE: introduction (5/6)



The access flap **10** is reserved exclusively for approved dealers.

Do not open it and ensure that the access flap **10** is always accessible.

Driving

As with a vehicle fitted with an automatic gearbox, you will have to get used to not using your left foot, and not using this foot to brake.

When driving, if you lift your foot off the accelerator pedal or depress the brake pedal, the motor generates electrical current during deceleration, and this energy is used to brake the vehicle and recharge the traction battery ➔ 2.16.

Special feature:

After a maximum charge of the battery and during the first few miles of using the vehicle, the engine brake will be temporarily reduced. Please adapt your driving style appropriately.



The engine brake should under no circumstances be used as a substitute for the brake pedal.

Bad weather, flooded roads:



Do not drive through floods if the depth of water is above the lower edge of the wheel rims.



Obstructions to the driver

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another.

There is a risk of wedging the pedals.

ELECTRIC VEHICLE: introduction (6/6)

Noise

Electric vehicles are particularly quiet. You will not yet necessarily be used to it, and neither will other road users. It is difficult for them to hear the vehicle when it is moving.

As the motor is silent, you will hear noises that you are not used to hearing (aerodynamic noises, tyre noise, etc.).

Each time the ignition is switched off, the ventilation will be switched off after about ten seconds.

Pedestrian horn

The pedestrian horn enables you to warn others of your presence – especially pedestrians and cyclists.

When the engine is started, the pedestrian horn is activated automatically. The sound is triggered when the vehicle speed is between about 1 and 19 mph (1 and 30 km/h).

Please refer to the multimedia instructions for further information.

In the event of a fault with the pedestrian horn, the message **“Failure Outside sound”** is displayed on the instrument panel. Consult an approved dealer.



Your electric vehicle is silent. Before leaving it, with your foot on the brake, stop the engine.

RISK OF SERIOUS INJURY.

IMPORTANT RECOMMENDATIONS



Please read these instructions carefully. Failure to follow these instructions may lead to a **risk of fire, serious injury or electric shock which may present a risk to life**.

In the event of an accident or impact

In the event of an accident or an impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture), this may damage the electric circuit or the traction battery.

Have the vehicle checked by an authorised dealer.

Never touch the “400 volt” components or orange cables which are exposed and visible inside or outside the vehicle.

In the event of serious damage to the traction battery, leaks may occur:

- never touch the liquids (fluids, etc.) coming from the traction battery;
- in the event of contact with the body, wash the affected area with plenty of water and consult a doctor as soon as possible.

In the event of an impact, even slight, against the charging flap and/or valve, have them checked by an authorised dealer as soon as possible.

In the event of fire

In the event of fire, make everyone evacuate the vehicle immediately and contact the emergency services, informing them that this is an electric vehicle.

Only use extinguishing agents ABC or BC that are permitted for use with electrical fires. Do not use water or other extinguishing agents.

In the event of damage to the electrical circuit, please call an authorised dealer.

All towing operations ➔ 5.40.

Washing the vehicle

Never wash the engine compartment, the charging connection or the traction battery with a high-pressure jet.

This risks damaging the electric circuit.

Never wash the vehicle while it is charging.

Never wash the charging lead while the vehicle is charging.

Never clean the charging lead while the lead is not connected, in order to prevent corrosion of the charging pins.

Risk of electric shock and a risk to life.

ELECTRIC VEHICLE: charging (1/13)


Charging schematic diagram

1 Specific wall socket or recharging terminal

2 Charging cord

3 Electric charging connection

57902



If you have any questions regarding the equipment needed for charging, please ask an authorised dealer.



Important recommendations for charging your vehicle

Please read these instructions carefully. Failure to follow these instructions may lead to a risk of fire, serious injury or electric shocks which could result in death.

Charging

Do not do anything to the vehicle during charging (washing, working in the engine compartment, etc.).

In the event of the presence of water, signs of corrosion or foreign bodies in the charging cord connector or in the vehicle charging socket, do not charge the vehicle. Fire hazard.

Do not attempt to touch the cord contacts, the domestic socket or the vehicle charging socket, or introduce objects into them.

Never plug the charging cord into an adapter, multiple socket or extension lead.

The use of generators is prohibited.

Do not remove or change the vehicle charging socket or the charging cord. Fire hazard.

Do not modify or perform any action on the installation during charging.


In the event of an impact, even slight, against the charging socket or valve, have them checked by an authorised dealer as soon as possible.

Take care of the cord: do not tread on it, immerse it in water or pull on it or let anything knock against it.

Check regularly that the charging lead is in good condition.

In the event of damage to the charging lead (corrosion, browning, cuts, etc.), to the unit or to the vehicle's electrical charging socket, do not use them. Please see an authorised dealer to replace them.

In the event of non-activation of the charging flap locking mechanism and/or unlocking of the vehicle's electric charging socket, please contact an approved dealer.




Charging cord **A**

This lead is specific to your vehicle and designed for connecting to wall sockets or public terminals to enable standard charging of the traction battery.

We recommend that you use a charging cord that enables a standard charge to charge the traction battery.

Each charging lead is stored in the luggage compartment of the vehicle
➔ 3.69.




Charging cord **B**

This cord allows:

- standard charge, on a socket used only for the vehicle (16 A charge);
- occasional charging using a domestic socket (8 A, 10 A charging), for example when you are not at home.

Sockets must be fitted as stated in the instructions in the instructions supplied with the charging cord **B**.



Always read the charging cord instructions **carefully** before using it **B**.

Never leave the socket hanging by the cord. Use the hooks **C** to attach it.

If a charging cable malfunctions during the charging process (red warning light on the unit **D**), stop charging immediately. Please refer to cord instructions.



Important recommendations for charging your vehicle

Please read these instructions carefully. Failure to follow these instructions may lead to a risk of fire, serious injury or electric shocks which could result in death.

Choice of charging cord

The standard charging cords supplied with the vehicle have been designed specifically for this vehicle. It is designed to protect you against the risks of electric shock that can lead to death or fire.

Do not use with the charging leads of previous vehicles as they are not adapted. For safety reasons, the use of a charging cord not recommended by the manufacturer is strictly forbidden. Failure to follow this instruction can lead to risks of fire or electric shock that can prove fatal. For information on a charging cord suited to your vehicle, please consult an authorised dealer.

Using the charging lead **B**

Please read the instructions that come with the charging cord carefully to learn about precautions you must take when using the product and the technical specifications required when fitting the socket.

Installation

Power supply systems

Only use charging terminals which conform to the IEC 61851-1 standard and connecting points protected by:

- a type A 30 mA residual differential current system specific to the socket used;
- an overcurrent protection device;
- protection against overvoltage relating to lightning in exposed areas (IEC 62305-4).

Wall socket

Have a special wall socket installed by a qualified professional.

In the case of domestic charging

Have a qualified professional check that each socket to which you will connect the charging cord complies with the standards and regulations in force in your country and that it complies with the specifications described previously in the information on "Power supply systems".

ELECTRIC VEHICLE: charging (5/13)



Charging types that conform to European standards

Alternating current (AC)

If the information is displayed on the vehicle charging flap, follow the instructions below.

Before plugging in a charging lead, check that:

- the colour and one of the letters of the inlet socket **4** correspond to the colour and one of the letters on the end **5** of the lead;
- the colour and one of the letters of the inlet socket **3** correspond to the colour and one of the letters on the end **6** of the lead.



| Charging type | Alternating current (AC) | | | |
|---|-------------------------------------|--|---------------------------|--|
| Connection | Charging terminal 4/Charging lead 5 | | Vehicle 3/Charging lead 6 | |
| Charging types that conform to European standards (for all other cases, please consult an approved dealer). | | | | |


ELECTRIC VEHICLE: charging (6/13)

Charging types that conform to European standards (continued)


Direct current (DC)

If the information is displayed on the vehicle charging flap, follow the instructions below.

Before plugging in a charging lead, make sure that the colour and one of the letters of the inlet socket **3** correspond to the colour and one of the letters on the end **6** of the charging lead.




58904



| | | | | | |
|---|---------------------------|---|---|---|---|
| Charging type | Direct current (DC) | | | | |
| Connection | Vehicle 3/Charging lead 6 | | | | |
| Charging types that conform to European standards (for all other cases, please consult an approved dealer). | K | L | M | N | O |

ELECTRIC VEHICLE: charging (7/13)



Electric charging connection 3

Note: If in a snowy environment, remove snow from the vehicle charging area before plugging in or disconnecting. Snow in the socket may block the insertion of the charging cord plug.

The vehicle is equipped with two charging connections located at the front of the vehicle (depending on the vehicle):

- **E** socket for charging up to 22 kW;
- **F** socket for direct current charging.

Note: on vehicles fitted with an 11 kW charger, connecting the charging cable to the **E** socket and to a 22 kW recharging terminal will enable the vehicle to be charged at a maximum of 11 kW.

Precautions

Avoid charging and parking your vehicle in extreme temperatures (hot or cold).

Under extreme conditions, charging may take several minutes before starting (time required for the traction battery to cool down or warm up).

When the vehicle is parked for more than seven days in temperatures below about -25°C, charging the traction battery can become impossible.

If the vehicle is parked for more than three months with near zero charge, it may become impossible to charge the battery.

To preserve the service life of your traction battery, avoid parking the vehicle for more than one month with high charge, especially when the weather is very hot.

Energy level availability depends on the battery temperature. It may therefore vary between the time the vehicle is stopped and restarted, depending on whether the battery is cold or warm.

ELECTRIC VEHICLE: charging (8/13)

Precautions (continued)

In anticipation of arrival and parking in cold conditions (minus temperatures), if the battery charge level is below approximately 30%, the vehicle must be recharged within approximately four hours after the vehicle is parked.

When arriving in a cold location, the battery temperature will drop and approach the exterior temperature.

In such a situation, the battery's useful capacity (available energy level) may be reduced significantly to the extent that it will not be possible to start the vehicle again.

Note: the useful capacity will be recovered during the next journey if the battery temperature increases sufficiently.


Favour charging the traction battery after driving and/or in mild temperatures. Otherwise, charging may take a longer period of time or even become impossible.

Advice

- In high temperatures, try to park and recharge the vehicle in a shaded/covered location;
- charging can be performed in the rain or snow;
- activating the air-conditioning increases the charging time required.

In the absence of any protection against overvoltage, we recommend that you do not recharge the vehicle in stormy weather (lightning, etc.).


ELECTRIC VEHICLE: charging (9/13)



Recharging the traction battery

Vehicle stationary, ignition off:

- take the charging cord located in the boot of your vehicle;
- press the switch **6** or, depending on the vehicle, press the electric charging socket unlocking button on the card ➔ 1.29, to unlock the charging flap **10**;
- open valve **8**;
- plug in the end of the cord to the power supply;



- grab the handle **9**;
- plug in the vehicle cord. The warning light **7** flashes in yellow;
- after you hear a locking click, check that the charging cord is properly plugged in. To check the locking, pull gently on the handle **9**.

Do not use the charging flap **10** to suspend the charging cord **2** while recharging the vehicle.

The charging cord is automatically locked with the vehicle. This will make it impossible to unplug the cord from your vehicle.

During charging, the warning light **7** flashes in blue.

For direct current charging (**DC**), the length of the charging cable between your vehicle and the charging terminal must not exceed **30 metres**.

If there is any doubt about the length of the cable, consult the owner of the **DC** charging terminal.

Make sure you fully uncoil the charging cord to limit its heating.




Do not use an extension lead, multiple socket or adapter.

Fire hazard.

ELECTRIC VEHICLE: charging (10/13)

When charging starts, the following information is displayed on the instrument panel:

- the energy level on the battery warning light **11**;
- the battery refill rate;
- an estimate of the remaining charging time (this is not displayed after about 95% charge);
- depending on the vehicle, the warning light **12** indicates that the vehicle is connected to a power supply;
- your vehicle range will vary according to the charge level.





The traction battery charging time depends on the amount of energy remaining and the power delivered by the charging terminal. The information is displayed on the instrument panel during charging ➔ 1.142.

Note: under certain conditions, the actual charging time may be longer than the charging time displayed on the instrument panel. This depends on:

- the quality of the electrical network;
- the initial charge level;
- the exterior temperature is too cold;
- ...

In the event of a problem with the charging cable, we recommend that you replace it with a cable that is identical to the original. Consult an approved dealer.





The display on the instrument panel disappears after a few seconds. It reappears when the doors are unlocked.

Once charging is complete, the warning light 7 appears continuously in green.

You do not need to wait until the charge is at reserve levels to recharge your vehicle.



Operating faults

When the warning light 7 flashes in red:

- disconnect the cable 2 from the socket 3 and from the power supply according to the procedure described on the following page;
- re-connect the cable 2 to the same supply source or to one nearby.

If the 7 warning light continues to flash in red, contact an approved dealer.

ELECTRIC VEHICLE: charging (12/13)



Precautions to take when removing from the socket

It is imperative to follow the unplugging steps in order.

- Press the switch **6** or, depending on the vehicle, press the electric charging socket unlocking button on the card ➔ 1.29, to unlock the charging flap and release the charging cable **2** from the vehicle;
- grab the handle **9**;

Note: immediately after a long charge of the traction battery, the cable may be hot. Please use the handles.


In the event of an unexpected charging interruption (charging fault, faulty recharging terminal, etc.), disconnect the cable **2** and ensure that the charging flap is properly closed and locked **10** before attempting to recharge or before starting the vehicle.

After pressing the charging cable unlocking button, you have 30 seconds to unplug it before it locks again.



To avoid disturbing the charging monitoring system, do not install any antistatic strip to the vehicle.


ELECTRIC VEHICLE: charging (13/13)



Label 13


The label **13** located on the charging flap **10** displays details on how the charging operation is indicated by the status of the warning light **7**:

- flash in yellow: the lead is plugged into the vehicle and the system carries out its checks;
- flashing in blue: charging is in progress;
- illuminated continuously in blue: charge programming is activated;
- illuminated continuously in green: the vehicle is fully charged;
- flashing in red: operating fault.



The label **13** located on the right-hand side reminds you of the following instructions:

- do not wash the charging flap using a high-pressure water jet;
- with the vehicle stationary, the valve and the charging flap can be open;
- when the vehicle is being driven, the valve and the charging flap must be closed;
- open the flap to connect the charging lead;
- close the flap again once disconnected;



- connect to a domestic socket, an alternating current charging terminal or a direct current charging terminal;
- for any information on charging, please consult your vehicle user manual.

Label 14

Depending on the vehicle, one of the **14** labels is located on the charging flap **10**.

ELECTRIC VEHICLE: programming charging (1/2)




Charging programming

With the vehicle stationary and the engine on, from the "Settings" menu on the multimedia screen **1**, select the "Vehicle" tab. Use the "EV programming" menu to configure charging for your vehicle.

When the programming is confirmed, the indicator light  lights up on the instrument panel.

Note: charging will start if the engine is shut down and the vehicle is connected to a power supply and access is authorised.




"Immediate charging" 2

With the vehicle connected to a power supply, charging starts.

Area **A** informs you that "Immediate charging" is activated.

Please refer to the multimedia instructions for further information.



"Postponed charging" 3

You can programme the start time for charging.


Press "Edit" **4** to open the settings to set the start time for charging.

Set the start time for charging then press "Save" to confirm.

Area **B** shows the time programmed for charging to start.

With the vehicle connected to a power source and the engine switched off, charging starts at the scheduled time.

ELECTRIC VEHICLE: programming charging (2/2)



"Program" 5

You can save several programmed charging times per week.

Select the programme time **6** that you wish to change to access the settings.

You can disable one of your saved programmes by pressing "OFF".

Set the charging start and end times as well as the days to which these times will apply. Press "Save" to confirm.

Note: if the start and end times are identical, charging time is 24 hours. You can't confirm a charging programme if you don't select a day of the week.

Programmed times are displayed in area **C**.

With the vehicle connected to a power source and the engine switched off, charging starts at the scheduled time.



For safety reasons, carry out these operations when the vehicle is stationary.

KEY, RADIO FREQUENCY REMOTE CONTROL: general information (1/2)

A



55142

B



55143

Depending on the vehicle, there are two types of keys, key **A** or key **B**.

Key, Remote control **A**

- 1 Locks all the opening elements.
- 2 Unlocks all the opening elements.
- 3 Driver's door and ignition key.
- 4 Locking/unlocking using the switch-blade key. To release the insert from its housing, press button **4**, it comes out automatically. Press button **4** and guide the insert back into its housing.
- 5 Unlocking/locking the luggage compartment only.

Key, Remote control **B**

- 1 Locks all the opening elements.
- 6 Unlocking all the opening elements, in Access mode, or unlocking the front doors, in Secure mode.
- 3 Driver's door and ignition key.

4 Locking/unlocking using the switch-blade key. To release the insert from its housing, press button **4**, it comes out automatically. Press button **4** and guide the insert back into its housing.

7 Unlocking the sliding side doors and the rear hinged doors.

Remote control **B**

There are two ways to use the remote control: **Access mode** and **Secure mode**.

To switch between the remote control user modes, use the "Access" menu from the trip computer or, depending on the vehicle, from the multimedia screen. The default mode is **Access mode**.

KEY, RADIO FREQUENCY REMOTE CONTROL: general information (2/2)

Radio frequency remote control operating range

This varies according to the surroundings: take care not to lock or unlock the doors by inadvertently pressing the buttons on the remote control.

Note: if any opening element (door or luggage compartment) is open or not properly shut, locking is unsuccessful and the hazard warning lights and side indicator lights do not flash.

Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the remote control) may affect the operation of the remote control.

The key must not be used for any function other than those described in the handbook (removing the cap from a bottle, etc.).

Replacement and additional keys or remote controls.

You must only contact an approved dealer:

- If you need to replace a key it will be necessary to take the vehicle and all of its keys to an approved Dealer in order to initialise the system.
- Depending on the vehicle, you have the option of using up to four remote controls.

Remote control unit failure

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. These batteries have a service life of approximately two years.

How to change the battery ➔ 5.29.

Advice

Avoid leaving the remote control in hot, cold or humid areas.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

RADIO FREQUENCY REMOTE CONTROL: use (1/2)

Remote control **A** or, depending on the vehicle, remote control **B** locks or unlocks the doors. It is powered by a battery which can be replaced. ➔ 5.29.

Locking the doors

Press locking button **1**.

The hazard lights and side repeaters **flash twice** to indicate that the doors have **locked** and, on some vehicles, the door mirrors fold in automatically.

Note: if any opening element (door or luggage compartment) is open or not properly shut, locking is unsuccessful and the hazard warning lights and side indicator lights do not flash.

Unlocking/locking the luggage compartment only

Using the remote control **A**, press button **3** to unlock/lock the luggage compartment door only.



Unlocking the rear area

Using the remote control **B**, press button **5** to unlock the sliding side doors and the rear hinged doors.

Unlocking the doors

The hazard lights and side repeaters **flash once** to indicate that the doors have **unlocked** and, on some vehicles, the door mirrors fold out automatically.

Remote control **A**

Press button **2** to unlock all the opening elements.

Remote control **B**

Press button **4** once to:

- unlock all the opening elements, in **Access mode**;
- unlock the front doors, in **Secure mode**.

Remote control **B**

There are two ways to use the remote control: **Access mode** and **Secure mode**.

To switch between the remote control user modes, use the “Access” menu from the trip computer or, depending on the vehicle, from the multimedia screen. The default mode is **Access mode**.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

While the engine is on, the buttons on remote control **A** or, depending on the vehicle, on remote control **B** are inactive.

Depending on the vehicle, the door mirrors fold in/out automatically when the vehicle is locked/unlocked
► 1.166.

RADIO FREQUENCY REMOTE CONTROL UNIT: deadlocking



To activate deadlocking

Press button **1** twice in quick succession.

Locking is confirmed by **two slow flashes** and **three quick flashes** of the hazard warning lights and side indicator lights.

Depending on the vehicle, the door mirrors fold in automatically when the vehicle is locked ➔ 1.166.

To deactivate deadlocking

Press the **2** button.

The hazard warning lights **flash once** to indicate that the doors have been unlocked.


Special feature: deadlocking is not possible if the hazard warning lights or the side lights are on.




Never use deadlocking if someone is still inside the vehicle.

CARD: general information (1/4)

57899



57900



Depending on the vehicle, there are two types of cards, card **A** or card **B**.

A card

- 1 Unlocking the doors and tailgate.
- 2 Locking all doors and tailgate.
- 3 Unlocking/locking the luggage compartment only or, depending on the vehicle, unlocking the rear area (sliding side doors and rear hinged doors).
- 4 Unlocking the electric charging socket.

B card

- 4 Unlocking the electric charging socket.
- 5 Unlocking all the front doors in Secure mode, or unlocking all the opening elements in Access mode.
- 2 Locks all the opening elements.
- 6 Unlocking the rear area (sliding side doors and rear hinged doors).

B card

There are two ways to use the card: **Access mode** and **Secure mode**.

To switch between the card user modes, use the “Access” menu from the trip computer or, depending on the vehicle, from the multimedia screen. The default mode is **Secure mode**.

Depending on the vehicle, you may have a digital key that offers all the functions of the card.

However, if a card has been left inside the vehicle and the doors have been locked with a digital key, all of the card's functions will be inhibited.

For more information ➔ 1.45

CARD: general information (2/4)

The card is used for:

- locking/unlocking the opening elements (doors, luggage compartment) and the electrical charging socket;

card operating range

This varies according to the environment: take care not to accidentally lock or unlock the vehicle by inadvertently pressing the buttons on the card.

Note: if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the card) may disrupt its operation.

Advice

Avoid leaving the card in hot, cold or humid areas.

Keep the card with you.

Do not keep the card in a place where it could be bent or damaged accidentally, such as in a back pocket of a garment.

Battery life

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. Its service life is approximately two years: it should be replaced when the message "Keycard Battery Low" appears on the instrument panel ➔ 5.31.

When the battery is flat, you can still lock/unlock and start your vehicle.
➔ 1.55 ➔ 2.3.

Replacement: need for an additional card

If you lose your card or require another, you can obtain one from an authorised dealer.

If a card is replaced, it will be necessary to take the vehicle **and all its cards** to an approved Dealer to initialise the system.

You may use up to four cards per vehicle.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

CARD: general information (4/4)

40303




Fitting a strap 9

Slide the rear casing **7** downwards while pressing on zone **C**.

Never insert screwdriver-type tools into the **8** opening.

57037



Insert the hand strap into the **10** component and pass the end of the strap through the buckle.

Position the hand strap at the opening **8** and close the cartridge.

Note: check that the diameter of the hand strap cord **9** will fit the opening **8**.

“HANDS-FREE” CARD: use (1/11)

A card

There are three ways to unlock/lock the vehicle:

- “hands-free”, when approaching and moving away from the vehicle;
- in “hands free” mode, depending on the vehicle, using button **2** on the door handle **1**;
- using the card in remote control mode.

Deactivating/activating the «hands-free» mode

Depending on the vehicle, from the trip computer or the multimedia screen you can deactivate/activate the following:

- unlocking when approaching the vehicle;
- locking when moving away from the vehicle;
- the “hands-free” locking and unlocking completely.

You can also disable/activate the sound signal that is emitted upon locking when moving away from the vehicle ➔ 1.159.




Never leave your vehicle with the card inside.

57899



55168



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

“HANDS-FREE” CARD: use (2/11)

53963



Hands-free unlocking, when approaching the vehicle;

With the card in access zone 3, the vehicle will unlock. Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.

Depending on the vehicle, the door mirrors fold in/out automatically when the vehicle is locked/unlocked
➔ 1.166.

53962



Hands-free locking when moving away from the vehicle

With the card on you, doors and luggage compartment door closed, move away from the vehicle: it will lock automatically once you have left the access zone 4.

Note: the distance at which the vehicle locks depends on the surroundings.

To indicate that the vehicle has been locked, the hazard warning lights **flash twice** and then **light up** for approximately four seconds, and a beep sounds in confirmation.


55939



The vehicle cannot be remotely locked if the card is within the area 5.

“HANDS-FREE” CARD: use (3/11)

57899



If the card has been within the detection area **4** for approximately 15 minutes, remote locking is disabled.

To lock the vehicle, press the **6** button on the card or, depending on the vehicle, press the **2** button on the handle **1**.

Do not store the card anywhere it may come into contact with other electronic equipment (computer, phone etc.) as this could hinder its operation.



“Hands-free” unlocking/locking using button **2** (depending on the vehicle)

With the card in zone **3** and the vehicle locked, press button **2** on the door handle **1** to unlock the vehicle.

Pressing the tailgate button once unlocks the entire vehicle and opens the tailgate.

The hazard lights and side repeaters **flash once** to indicate that the doors have unlocked and, on some vehicles, the door mirrors fold out automatically.


53963



With the vehicle unlocked, press button **2** once to lock the vehicle.

The hazard warning lights **flash twice** to indicate that the vehicle is locked and, depending on the vehicle, the door mirrors automatically fold in.

“HANDS-FREE” CARD: use (4/11)



Special features of the unlocking system

After eight days of non-use, approach unlocking is disabled.

Use the card in remote control mode (see following pages) or, depending on the vehicle, press the **2** button (on front door handle) to unlock the vehicle and reactivate “hands-free” mode.


Special features relating to “hands-free” locking

After locking in “hands-free” mode, you have to wait approximately three seconds before being able to unlock the vehicle again. During these three seconds, the door handles can be tried to make sure that the vehicle is locked properly.

Note: if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

“HANDS-FREE” CARD: use (5/11)

57899



Using the card as a remote control A

Unlocking with the card

Press button 7.

The hazard lights and side repeaters **flash once** to indicate that the doors have unlocked and, on some vehicles, the door mirrors fold out automatically.

The card buttons are deactivated when the engine is running.

Locking using the card

With the doors and boot closed, press button 6: the vehicle locks.

The hazard warning lights **flash twice** to indicate that the vehicle is locked and, depending on the vehicle, the door mirrors automatically fold in.

Note:

- the maximum distance at which the vehicle locks depends on the surroundings;
- if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

Unlocking/locking the boot only or, depending on the vehicle, unlocking the rear area

Press the 8 button to unlock/lock the boot only or, depending on the vehicle, to unlock the rear area.

55939



If, **while the engine is running**, a door is opened and closed, and the card is no longer in the zone 5, the message Keycard Not Detected indicates that the card is not inside the vehicle. This will, for example, prevent you from driving away after dropping off a passenger who has kept the card on them.

The warning disappears when the card is detected again.

“HANDS-FREE” CARD: use (6/11)

B card

Unlocking the vehicle

There are two ways to unlock the vehicle:

- in “hands-free” mode, using the buttons on the door handles;
- using the card in remote control mode.

Locking the vehicle

There are four ways to lock the vehicle:

- in “hands-free” mode, when moving away from the vehicle;
- in “hands-free” mode, using the button **9** on one of the front door handles;
- in “hands-free” mode, using the button **10** on the handle of one of the sliding side doors or using the button **11** on the rear hinged door;
- using the card in remote control mode.


Do not store the card anywhere it may come into contact with other electronic equipment (computer, phone etc.) as this could hinder its operation.

57900

(B)



56432



55114



“HANDS-FREE” CARD: use (7/11)


55433




“Hands-free” unlocking

With the card in the access zone 12:

- press the **9** button on the handle of one of the front doors to unlock the front doors in secure mode, or all the opening elements in access mode;
- press the **10** button on the handle of one of the sliding side doors or, on the **11** button of the rear hinged door to unlock the rear area in secure mode or all the opening elements in access mode.



The hazard lights and side repeaters **flash once** to indicate that the doors have unlocked and, on some vehicles, the door mirrors fold out automatically.



Note: “hands-free” unlocking will not work if the card is not present within the detection zone **12** of the button pressed.

55114

“HANDS-FREE” CARD: use (8/11)

55433



“Hands-free” locking

With the vehicle unlocked, all the opening elements closed, press button **9**, **10** or **11** once to lock all the opening elements.

55432



Secure mode

If one of the front doors is open, press the **9**, **10** or **11** button to lock the rear area.

If one of the opening elements in the rear area is open, press the **9**, **10** or **11** button to lock the front doors.

Access mode

If a door or the boot is open or not properly shut, locking using the **9**, **10** or **11** button is not carried out.

55114



The hazard warning lights **flash twice** to indicate that the vehicle is locked and, depending on the vehicle, the door mirrors automatically fold in.

Note: “hands-free” locking will not work if the card is not present within the detection zone **12** of the button pressed.

Special features relating to “hands-free” locking

After locking in hands-free mode, you have to wait approximately three seconds before being able to unlock the vehicle again.

“HANDS-FREE” CARD: use (9/11)

56784




Hands-free locking when moving away from the vehicle

With the card on you, doors and luggage compartment door closed, move away from the vehicle: it will lock automatically once you have left the access zone **13**.

Note: the distance at which the vehicle locks depends on the surroundings.

To indicate that the vehicle has been locked, the hazard warning lights **flash twice** and then **light up** for approximately four seconds, and a beep sounds in confirmation.

57900



If the card has been within the detection area **13** for approximately 15 minutes, remote locking is disabled. To lock the vehicle, press button **14** on the card.

55945




The vehicle cannot be remotely locked if the card is within the area **15**.

Note: if an opening element is open or not properly shut, “hands-free” locking when moving away from the vehicle is not carried out. The hazard warning lights and indicator lights do not flash.

“HANDS-FREE” CARD: use (10/11)

57900



Using the card as a remote control **B**

There are two modes of use: **Secure mode** and **Access mode**.

To switch between the card user modes, use the “Access” menu from the trip computer or, depending on the vehicle, from the multimedia screen.

The default mode is **Secure mode**.

The card buttons are deactivated when the engine is running.

Unlocking with the card

Press button **16** to unlock the sliding side doors and the rear hinged doors.

Secure mode

Press button **17** to unlock the front doors.

Access mode

Press button **17** to unlock all the opening elements.

The hazard lights and side repeaters **flash once** to indicate that the doors have unlocked and, on some vehicles, the door mirrors fold out automatically.

Locking using the card

With all the opening elements closed, press the **14** button: the vehicle locks.

The hazard warning lights **flash twice** to indicate that the vehicle is locked and, depending on the vehicle, the door mirrors automatically fold in.

Note:

- the maximum distance at which the vehicle locks depends on the surroundings;
- if a door or the boot is open or not properly shut, locking using the **14** button is not carried out. A beep sounds and the hazard warning lights and side repeaters do not flash.

“HANDS-FREE” CARD: use (11/11)

56785



If, **while the engine is running**, a door is opened and closed, and the card is no longer in the zone **18**, the message “Keycard Not Detected” indicates that the card is not inside the vehicle. This will, for example, prevent you from driving away after dropping off a passenger who has kept the card on them.

The warning disappears when the card is detected again.



Never leave your vehicle with the card inside.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.


They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

“HANDS-FREE” CARD: DEADLOCKING

57899



If the vehicle is equipped with a deadlocking function, this allows you to lock the opening elements and to prevent the doors from being unlocked using the interior handles (for example, by breaking the window and then trying to open the door from the inside).

57900



To activate deadlocking

Press button 2 twice in quick succession.

Locking is confirmed by **two slow flashes** and **three quick flashes** of the hazard warning lights and indicator lights.

Depending on the vehicle, the door mirrors fold in automatically when the vehicle is locked ➔ 1.166.

To deactivate deadlocking

Press the 1 button.

The hazard warning lights **flash once** to indicate that the doors have been unlocked.



Never use deadlocking if someone is still inside the vehicle.

DIGITAL KEY (1/4)

Depending on the country and subscription, you can install a digital key for your vehicle on your smartphone.

The digital key contains the rights required to lock/unlock and start your vehicle using a smartphone.

Thus, your smartphone replaces your card.

General information

The installation, administration and transmission of the digital keys are carried out using the manufacturer's app.

Once the manufacturer's application is installed on your smartphone and the subscription is activated, the digital key must be activated from the manufacturer's application.

Operating conditions

Activate Bluetooth® on your smartphone then open the manufacturer's application to access the various digital key functions (see following pages).

Note: the smartphone must be sufficiently charged in order to use a digital key. In the event of a low charge level, the "Low smartphone battery" message appears on the instrument panel.

The digital key's operational reach will depend on your smartphone's Bluetooth® connection.

Lending a digital key

From the manufacturer's app, access the "Share Virtual Key" menu and fill in the information for the occasional user. After validation, a confirmation email will be sent to the user.

Note: the manufacturer's application must have been previously downloaded and installed by the occasional user.

Revoking a digital key

The user can individually revoke a digital key. Once a digital key has been revoked, the user can activate a new key.

For more information, please see the manufacturer's application.

DIGITAL KEY (2/4)

Activation/deactivation from the multimedia screen

It is possible to deactivate and reactivate the “Digital key” function so that the vehicle does not communicate with any digital key.

Refer to the multimedia instructions.

Locking/unlocking the doors and luggage compartment, deadlocking, remote lighting


The first time the vehicle is unlocked or started using a new digital key or a new smartphone, it will take several seconds for the vehicle to identify the digital key installed on your smartphone.

From your smartphone, with Bluetooth® activated, open the manufacturer's application and discover the various functions available for your digital key. They are identical to those of your card.

These functions are:

- locking/unlocking all the opening elements: please see “Hands-free card: use” ➔ 1.33;
- locking/unlocking the luggage compartment (depending on the vehicle): please see “Hands-free card: use” ➔ 1.33;
- deadlocking (depending on the vehicle): please see “Hands-free card: deadlocking” ➔ 1.44;
- remote sounding of the horn (allows you to identify the vehicle from afar or when parked in a crowded car park, for example);
- starting/stopping the engine: please see “Starting, stopping the engine” ➔ 2.2 ➔ 2.3.

DIGITAL KEY (3/4)



To start/stop the engine, the system checks that the smartphone is present in the **1** placement area before allowing the engine to be started.

For more information, please refer to the information on "Starting, stopping the engine" ➔ 2.2 ➔ 2.3.

The smartphone must remain in the vehicle throughout the journey.

Starting, stopping the engine

Upon first use and each time a new smartphone is used, it is necessary to calibrate your digital key with your vehicle.

To do this, activate Bluetooth® on your smartphone then follow the procedure from the manufacturer's application.

When calibrating, the smartphone must be placed in the **1** placement area.

It is necessary to place the smartphone in the placement area in order to start and stop the engine and when calibrating.



If the smartphone is no longer in the passenger compartment when you try to switch the engine off, a message is displayed on the instrument panel: press and hold the engine start/stop button for more than two seconds **2**.

If the smartphone is no longer in the passenger compartment, make sure you can retrieve it before pressing and holding. Without a smartphone or card, you will not be able to start the vehicle again.

DIGITAL KEY (4/4)

Special features of the digital key

- For the digital key to remain active, the smartphone concerned must be connected to the Internet (via WI-FI or mobile network) at least once every 48 hours. Otherwise, connect your smartphone to the internet for a few minutes so that the digital key can be reactivated.
- If a card has been left inside the vehicle and the doors have been locked with the digital key, all of the card's functions will be inhibited. The card's functions will remain inactive until the engine is started again. In this case, to start the engine you will need to use either the digital key or a card other than that left inside the vehicle.

When the engine is started or stopped, the smartphone should always be sufficiently charged in order to use the digital key.

OPENING AND CLOSING THE DOORS (1/6)




Front doors

Opening from the outside

With the doors unlocked or, depending on the vehicle, the card on you, hold the handle 1 and pull it towards you.



As a safety precaution, the doors should only be opened or closed when the vehicle is stationary.



Opening from the inside

Unlock the door and pull handle 2.

Door/tailgate open buzzer

When the vehicle is stationary, the warning light appears on the instrument panel accompanied by a warning light indicating which of the opening elements (door(s), luggage compartment) are open or incorrectly closed.

Once the vehicle reaches a speed of approximately 6 mph (10 km/h), a warning light indicates if the door(s) or luggage compartment are open or not properly closed, along with the message “WARNING: Boot Open” or “WARNING: Door Open” and a beep will sound for around 40 seconds or until the door/luggage compartment is closed.

Lights-on reminder buzzer

If you have switched off the ignition and left the lights switched on, a reminder buzzer will sound when a door is opened.

Special note

Depending on the vehicle, accessories (e.g. radio) stop working either when the engine is switched off or when the doors are locked, or when the driver's door is opened.


OPENING AND CLOSING THE DOORS (2/6)



Sliding side door

Opening the doors from the outside

Unlock the door and pull handle **3**, then slide the door towards the rear of the vehicle until it locks in position. To unlock the doors ➔ 1.26 ➔ 1.33.



Child safety

(depending on the vehicle)

To make it impossible for the sliding side doors to be opened from the inside, use the key to turn the lock **4** (position **B**) and close the door.

Check from the inside that all the doors are locked. The door can only be opened from the outside of the vehicle.

To open the sliding side doors from the inside, turn the lock **4** (position **A**) using the key.




Recommendations concerning the sliding side door

The following precautions must be taken when opening and closing the doors or any other opening element:

- Check that nobody, no animal or object is at risk of being harmed when you perform this manoeuvre.
- Never use anything but the handles on the inside and outside of the door to operate it.
- Take care when both opening and closing the door.
- Caution: when the vehicle is parked on a slope, open the door with care until it is fully open and latches into its locking position;
- Before moving off, always ensure that the sliding door is properly closed.
- Do not use the lower support as a step.

OPENING AND CLOSING THE DOORS (3/6)




Sliding side door (continued)

Opening from the inside

With the door unlocked, pull the handle 6 or, depending on the vehicle, activate the control 8, then slide the door towards the rear of the vehicle until it locks into the open position.

Closing from the inside

Push handle 5 towards the front of the vehicle until the door is completely closed.




Manual locking


With the button 7 in the unlocked position, turn it towards the front of the vehicle (movement C).

Manual unlocking

With the button 7 in the locked position, turn it towards the rear of the vehicle (movement D).



OPENING AND CLOSING THE DOORS (4/6)




Rear hinged doors

Opening the large door from the outside

Unlock the door and pull handle 9. To unlock the doors ➔ 1.26 ➔ 1.33.

Before opening the rear hinged doors, ensure that there is enough space around to allow the doors to be opened.



Opening the large door from the inside

Depending on the vehicle, activate control 10.




Do not leave the hinged rear doors open in case of strong winds.

Risk of injury.



For your safety, check that all the vehicle's doors are properly closed before starting the engine.

OPENING AND CLOSING THE DOORS (5/6)



Rear hinged doors (continued)

Opening the small door


Move the lever 11 to open the small door.



Driving with the small door open

While the small door is open, close the large door.

After use, open the large door using handle 9 and close the small door before closing the large door.



Opening the doors to the maximum position

For each door, press lever 12 to release the door check strap. Open the door as far as possible.

Closing manually from the outside

First close the small door and then close the large door.

Move the doors until the door check strap is fully engaged on the door striker plate. Make sure that the door check strap is properly engaged before closing the hinged doors.



If the vehicle is parked on the hard shoulder and a luggage compartment door is open, the rear lights may be obscured.

You should make other road-users aware of your vehicle by using a warning triangle or other equipment specified by the road traffic regulations of the country concerned.

OPENING AND CLOSING THE DOORS (6/6)



Tailgate


Opening

Unlock the door, press button **13** and lift the tailgate. To unlock the doors, ➔ 1.26 ➔ 1.33.

Closing

Lower the tailgate using the closure strap **14**.

When the tailgate reaches shoulder height, gently push it shut.



Opening manually from the inside

If it is not possible to unlock the tailgate, it can be unlocked manually from the inside.

Insert a pencil or similar object into cavity **15**, slide the assembly as shown in the diagram and push the tailgate to open it.

Before opening the tailgate, ensure that there is sufficient space around to allow the tailgate to open.



For your safety, check that all the vehicle's doors are properly closed before starting the engine.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

LOCKING, UNLOCKING THE DOORS (1/3)

If the remote control or, depending on the vehicle, the card does not work

In some cases, the radio frequency remote control or the card may not work:

- card or radio frequency remote control battery worn or run flat, vehicle battery flat etc;
- use of appliances operating on the same frequency as the card (mobile phone, etc.);
- the vehicle is located in a high electromagnetic radiation zone;
- vehicle locked using a digital key ➔ 1.45.

It is then possible:

- to use the radio frequency remote control or the emergency key integrated in the card (depending on the vehicle) to unlock the driver's door;
- to use the interior door locking/unlocking control (refer to the following pages);
- to use the digital key, depending on the vehicle ➔ 1.45.

40303



The card's built-in key

The 2 integrated key can be used to lock or unlock the driver's door when the card is not working.


Access with key 2

Slide the rear casing 1 downwards while pressing on zone A.

45673




LOCKING, UNLOCKING THE DOORS (2/3)



Using the key integrated in the card

- Pull handle 3;
- press the cover **B** on the driver's door down;
- insert the end of the key **2** in the notch **4** at the bottom of the cover **B**;
- rotate it upwards to remove the cover **B**;
- insert the key **2** into the lock of the driver's door, lock or unlock.

Once you are inside the vehicle, put the key back in its casing in the card.



Vehicles with key/remote control

Using the key

- Pull handle 3;
- press the cover **B** on the driver's door down;
- insert the end of the key **5** in the notch **4** at the bottom of the cover **B**;
- rotate it upwards to remove the cover **B**;
- insert the key **5** into the lock of the driver's door, lock or unlock.




Manually locking the front passenger door

Turn screw **6** with the door open (using the end of the key) and close the door.

This means that the doors are then locked from the outside.

The doors may then only be opened from the inside or by using the key in the driver's door.

LOCKING, UNLOCKING THE DOORS (3/3)



Interior locking/unlocking door control

Switch 7 simultaneously controls the doors and the tailgate.

If a door or the tailgate is open or not closed properly, the doors and tailgate lock/unlock quickly.

If transporting an object with the tailgate open, you can still lock the doors: with the engine stopped, press and hold switch 7 to lock the other doors.

Door and tailgate status indicator

When the ignition is on, the 7 switch warning light indicates the locking status of the opening elements:

- indicator light on, the doors and tailgate are locked;
- indicator light off, the doors and tailgate are unlocked.

When you lock the doors, the indicator light remains lit and then goes out.

Locking the opening elements without the card or the key

For example, in the event of a discharged battery or the card or key temporarily not working etc.

With the ignition switched off and a door or tailgate open, press and hold the 7 switch for more than five seconds.

When the door is closed, all the doors and the tailgate will be locked.

Note: unlocking the vehicle from the outside is only possible with the card in the vehicle's access zone or using the key.




Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.



Never leave your vehicle with the key or card inside.

AUTOMATIC LOCKING WHEN DRIVING



Operating principle

After the vehicle is started, the system automatically locks the doors when you are driving at approximately 6 mph (10 km/h) and over.

The door can be unlocked:

- by pressing the central door locking switch 1;
- at a standstill, by opening a front door from inside the vehicle.

NB: if a door is opened or closed, it will automatically lock again when the vehicle reaches a speed of 6 mph (10 km/h).

Activating/deactivating the function

To activate it: with the vehicle stationary and the engine on, press the switch 1 until a beep sounds.

To deactivate it: with the vehicle stationary and the engine on, press the switch 1 until you hear two beeps.

The function can also be activated and deactivated via the multimedia screen (depending on the vehicle). ➔ 1.159.

Operating faults

If you experience an operating fault (no central locking, the indicator light 1 does not light up when trying to lock the doors and luggage compartment etc.), make sure that central locking has not been deactivated by mistake and check that the doors and luggage compartment are properly closed. If they are properly closed, contact an approved dealer.




Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

FRONT HEADRESTS

56786



To raise the headrest

Pull the headrest upwards to the desired height. Check that it is correctly locked.

To lower the headrest

Press button 3 and guide the headrest down to the desired height. Check that the bonnet is correctly locked.

To raise the headrest


Raise it to its highest position (tilt the seatback backwards if necessary). Press button 3 and lift the headrest to release it.

To refit the headrest

Check that the headrest rods are clean 2.


Insert the headrest rods into the holes 1 (tilt the seatback backwards if necessary). Lower the headrest until it locks and press button 3 to adjust to the desired height. Check that each rod 2 on the seatback is securely locked.

26342



The headrest is important for safety. Ensure that it is in place and in the correct position: the top of the headrest should be as close as possible to the top of the head and there must be a minimal distance between the head and the headrest A.

FRONT SEATS (1/7)



To move forwards or backwards

Depending on the seat, lift the bar **1** or handle **4** to release the seat. Release the handle at the desired position and make sure that it is locked.


Adjusting the height of the driver's seat

Move lever **3** as many times as necessary:

- upwards to raise the seat,
- downwards to lower the seat.

To tilt the seatback

Depending on the seat, raise the lever **2** and tilt the seatback until it reaches the position required.



To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts. When moving the seat, make sure that nothing interferes with the moving parts and their locking.



For safety reasons, carry out any adjustments when the vehicle is not being driven.


We would advise you not to recline the seatbacks too far to ensure that the effectiveness of the seat belts is not reduced.

Nothing should be placed on the floor (area in front of driver) as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.

FRONT SEATS (2/7)




Central armrest 5
(depending on the vehicle)



To adjust the seat's lumbar position

Lower handle **6** to increase the support and lift it to decrease it.



Version with front bench seat for two

Depending on the vehicle, the central seatbacks may be folded down.

To fold down the seatback

Pull the **7** tab to unlock the seatback and lower the seatback **A**.

When lowering, tilt the headrest so that it is positioned under the centre console.

To raise the seatback

Lift the seat back and click it into place. Check that the bonnet is correctly locked.


FRONT SEATS (3/7)



Estate version flat position

Depending on the vehicle, the seatback on the passenger side may be folded down onto the seat base to create a flat position.


- Deactivate the front passenger airbag ➔ 1.131;
- hold handle **4** and move the seat as far back as possible;
- hold the top of the seatback to lower it;



- pull the lever **2** and pull the seatback down and forwards. While lowering, tilt the headrest **8** to position it under the dashboard;
- press on the seat base to ensure that it is correctly positioned on the floor;
- make sure that there is nothing which will prevent the seat from moving;
- the seat locks automatically. Check that the bonnet is correctly locked.




The label **B** on the seat base reminds you of these instructions.



Maximum weight on the seat in the flat position: 80 kg, with the weight evenly distributed.

The label **B** on the seat base reminds you of these instructions.

FRONT SEATS (4/7)



Repositioning the seat

Make sure that nothing prevents the seat from moving.

- Pull lever **2** and lift the seatback, ensuring it is correctly locked;
- reposition the seat base, placing your hand on the front of the seat base.

When the rear bench seat is folded down, move the front seats carefully.

Remember to reactivate the front passenger airbag before a passenger occupies the seat ➔ 1.131.



Put your hand on the front of the seat base when repositioning it.


Risk of trapping.



When the front seatback is in the flat position, you must deactivate the front passenger airbag.

Risk of serious injury if the airbag is deployed while objects are resting on the seatback in flat position.


FRONT SEATS (5/7)



Van version flat position

The seatback on the passenger side may be folded down onto the seat base to create a flat position.

- Deactivate the front passenger airbag ➔ 1.131;
- check that the floor is clear of any objects;
- unlock the seat base by lifting the handle **10** and move the seat forwards, onto the floor (movement **D**) by taking it by the rear section **C**;



- press on the seat base to ensure that it is correctly positioned on the floor. There is a risk the seatback being scratched if it is incorrectly positioned;
- remove the headrest **9** from the seat;
- store the headrest **9** in its housing under the seat base;
- unlock the seatback by lifting handle **10** again and position it horizontally (movement **E**).

F




The label **F** on the side of the seat base reminds you of these instructions.



Do not use the headrest housing **9** to store any other objects.

Risk of damage to the seat wiring.

FRONT SEATS (6/7)



The **11** rings located on each side of the front passenger seat can be used to secure the load placed on the seat in the flat-floor position.



For your safety, fasten down any objects transported with the seat in flat-floor position.

G

55964



Maximum weight on the seat in the flat position: 80 kg, with the weight evenly distributed.

Maximum height limit for objects on the seat in flat-floor position: 50 cm.

The label **G** on the side of the seat base reminds you of these instructions.

To put the seat back in the comfort position, proceed in the reverse order. Check that the headrest is positioned correctly.


Remember to reactivate the front passenger airbag before a passenger occupies the seat ➔ 1.131.



When the front seatback is in the flat position, you must deactivate the front passenger airbag.

Risk of serious injury if the airbag is deployed while objects are resting on the seatback in flat position.

The label **F** on the side of the seat base reminds you of these instructions.



Operating faults

When an operating fault is detected, the warning light of the **12** switch for the seat concerned switches-off after approximately five seconds.


Consult an approved dealer.

Heated seats

With the ignition on:


- pressing the switch **12** on the required seat for the first time activates the heating system on high. Both integrated switch warning lights come on;
- pressing the switch for the second time changes the heating to low. One integrated warning light comes on;
- pressing for the third time turns the heating off.

SWIVELLING PARTITION (1/2)



To rotate the partition

- Deactivate the front passenger airbag ➔ 1.131;
- place the seat in the flat position ➔ 1.60;
- unlock the swivelling section of the partition by lifting catches **1** and **2**;
- before turning the mobile section, ensure that the **1** and **2** catches are in the unlocked position;



- pivot the moving section 90 degrees, lock it at point **3** and lower the catch **2**. Ensure that the catch is locked correctly **2**.



The swivelling section must always be locked when the vehicle is driven.


Risk of injury.

When handling, ensure that the seat belt does not become damaged.



For your safety, fasten down any objects transported with the seat in flat-floor position.

SWIVELLING PARTITION (2/2)



Note: before returning the swivelling section to its initial position, check that the locking points 5 are clean.



When using the pivoted partition, the protective net 4 must not be removed or disassembled, even partially.

Risk of injury due to the projection of objects from the rear load area during braking.

SEAT BELTS (1/10)

Always wear your seat belt when travelling in your vehicle. You must also comply with the legislation of the particular country you are in.

Before starting, first adjust your driving position, then ask all occupants to adjust their seat belts to ensure optimum protection.

Adjusting your driving position

- Sit well back in your seat** (having removed your coat or jacket etc.). This is essential to ensure that your back is positioned correctly;
- adjust the distance between the seat and the pedals.** Your seat should be as far back as possible while still allowing you to fully depress the pedals. The seatback should be adjusted so that your arms are slightly bent when you hold the steering wheel;
- adjust the position of your headrest.** For maximum safety, your head must be as close as possible to the headrest;
- adjust the height of the seat.** This adjustment allows you to select the seat position which offers you the best possible view;
- adjust the position of the steering wheel.**

Make sure that the rear seats are locked in position properly so that the rear seat belts will operate efficiently ➔ 3.41 ➔ 3.44.



Incorrectly adjusted or twisted seat belts may cause injuries in the event of an accident.

Use one seat belt per person, whether child or adult.

Even pregnant women should wear a seat belt. In this case, ensure that the lap belt is not exerting too much pressure on the abdomen, but do not allow any slack.

SEAT BELTS (2/10)



Adjusting the seat belts

For correct adjustment and positioning of the seat belts at all seats:

- adjust the seats (seat base position and seatback angle, if applicable);
- sit with your back firmly against the seatback;

- move the shoulder strap **1** as close as possible to the base of the neck without it actually resting against it (if necessary, adjust the height of the seat belt if available) and make sure that the shoulder strap **1** is in contact with the shoulder;
- position the lap strap **2** so that it lies flat on the thighs and against the pelvis.

The seat belt must be worn as close to the body as possible. e.g. avoid wearing heavy clothing, keeping bulky objects under the belts, etc.

Locking

Unwind the belt **slowly and smoothly** and ensure that buckle **3** locks into catch **5** (check that it is locked by pulling on buckle **3**).

If the belt jams, allow it to return slightly before attempting to unwind it again.


If your seat belt is completely jammed, pull slowly, but firmly, so that just over 3 cm unwinds. Allow it to return slightly before attempting to unwind it again.

If there is still a problem, contact an approved dealer.

Unlocking

Press button **4** and the seat belt will be rewound by the inertia reel. Guide the belt.

SEAT BELTS (3/10)



Driver's seat belt reminder and, depending on the vehicle, front passengers' seat belt reminder

This appears on the central display **A** when the vehicle ignition is switched on and if the driver's and/or front passenger's seat belt(s) (if the passenger seat is occupied) is not fastened.

Depending on the vehicle, if the seat is occupied and one of these seat belts is not fastened or becomes unfastened while the vehicle is moving at a speed over approximately 12 mph (20 km/h),

the warning light  flashes and a beep sounds for approximately 120 seconds.

Note: an object placed on the passenger seat may activate the warning light in some cases, depending on the vehicle.

SEAT BELTS (4/10)

Rear seat belt reminder, standard chassis version (depending on the vehicle)

The **6** or **7** graphic is displayed on the instrument panel when the vehicle ignition is switched on. This informs the driver of the fastening status of each of the rear seat belts every time:

- opening a door;
- a rear seat belt is fastened/unfastened.

Reading the **6** or **7** graphic, depending on the vehicle:


- indicator green: seatbelt fastened;
- indicator red: seatbelt unfastened.

When the vehicle speed is below approximately 12 mph (20 km/h), the graphic **6** or **7** appears during approximately 60 seconds every time one of the rear seat belts is fastened or unfastened.



When the vehicle speed reaches or exceeds 12 mph (20 km/h), if one of the rear seat belts is unfastened during the journey:

- the warning light  flashes on the central display;
- and
- a beep sounds for around 30 seconds;
- and
- the **6** or **7** graphic is displayed for at least 60 seconds and the symbol for the seat concerned changes to red.



Always make sure that the rear passengers are properly fastened in and that the number of seat belts indicated corresponds to the number of rear seats occupied.

SEAT BELTS (5/10)

Rear seat belt reminder, long chassis version

(depending on the vehicle)

The **8** or **9** graphic is displayed on the instrument panel when the vehicle ignition is switched on. This informs the driver of the fastening status of each of the rear seat belts every time:

- opening a door;
- a rear seat belt is fastened/unfastened;
- a seat is removed/refitted ➔ 3.44.

Reading the **8** or **9** graphic, depending on the vehicle:

- indicator green: seatbelt fastened;
- indicator in red: the seat is occupied and the seat belt is not fastened;
- grey symbol: seat not occupied;
- white cross: the seat has been removed from the vehicle or has not been electrically reconnected to the vehicle or there is a fault with the seat's connection to the vehicle ➔ 3.44.



The  warning light on the central display also appears when the ignition is switched on, if a rear seat is occupied and the seat belt is not fastened.

When the vehicle speed is less than approximately 12 mph (20 km/h), the

 warning light on the central display appears if a rear seat is occupied and the seat belt is not fastened. It is accompanied by the **8** or **9** graphic which appears for approximately 60 seconds each time one of the rear seat belts is fastened or unfastened.

When the vehicle speed exceeds 12 mph (20 km/h), if one of the rear seat belts is unfastened or becomes unfastened during the journey:

- the warning light  flashes on the central display;
- and
- a beep sounds for around 120 seconds;
- and
- the **8** or **9** graphic is displayed for approximately 180 seconds and the symbol for the seat concerned changes to red.

SEAT BELTS (6/10)

Rear seat belt reminder, long chassis version

(continued)

Always make sure that the rear passengers are properly fastened in and that the number of seat belts indicated corresponds to the number of rear seats occupied.

Note: in some cases the alerts may be activated if an object is placed on one of the rear seats, depending on the vehicle.



If one or more rear seats are not connected to the vehicle, the "Rear seat disconnected" message is displayed on the instrument panel for approximately five seconds:

- when the ignition is switched on, if at least one of the seats is not connected;
- with the ignition on, when a seat is disconnected.

Each of the disconnected seats is indicated by a white cross on the **10** or **11** graphic.

If a seat is shown on the **10** or **11** graphic by a white cross while it is present in the vehicle,

When refitting a seat in the vehicle, be sure to reconnect the seat connector. If this is not the case, the seat belt buckle information will not be indicated in the visual **10** or, depending on the vehicle, **11**.



The seat connector must be reconnected according to the refitting procedure of the seat ➔ 3.44.

If it continues to be displayed, consult an approved dealer.

If there is a fault with the seat's connection to the vehicle, the "Check seat connection" message is displayed on the instrument panel accompanied by the **10** or **11** graphic with a white cross

and the warning light .

Consult an approved dealer.

SEAT BELTS (7/10)



Adjusting the height of the front seat belts

Press the button **12** to adjust the seat belt height so that the shoulder strap is worn as shown previously. Press button **12** and raise or lower the seat belt. Make sure that the seat belt is locked in position correctly after you have adjusted it.



"Open Sesame" version front passenger seat belt

Slowly unwind belt **13**.

Fasten the sliding buckle **14** into the catch **15**.



Version with front bench seat for two

In normal use conditions, fasten the centre seat belt when no one is seated there.


SEAT BELTS (8/10)



Rear side seat belts 16

(standard chassis version)

The belts are fastened, unfastened and adjusted in the same way as the front belts.



Rear centre seat belt

(standard chassis version)

Unwind belt 17 slowly from its housing 18.

Click buckle 21 into black catch 22.

Insert the last buckle 20 into the red catch 19.

To store the seat belt, guide it into the housing 18 and attach the buckle 21 to the magnet B.

 Check that the rear seat belts are positioned and operating correctly each time the rear seats are moved.


SEAT BELTS (9/10)



Second-row rear side seat belts 23 (long chassis version)

The belts are fastened, unfastened and adjusted in the same way as the front belts.

Rear seat functions ➔ 3.44.




Second row rear centre seat belt (long chassis version)

Unwind belt 25 slowly from its housing 24.

Click buckle 26 into black catch 27.

Insert the last buckle 29 into the red catch 28.

To store the seat belt, guide it into the housing 24 and, depending on the vehicle, attach the buckle 26 to the magnet **C**.



Third-row rear seat belts 30 (long chassis version)

The belts are fastened, unfastened and adjusted in the same way as the front belts.



Check that the rear seat belts are positioned and operating correctly each time the rear seats are moved.

SEAT BELTS (10/10)

The following information applies to the vehicle's front and rear seat belts.



- No modification may be made to the component parts of the restraint system – belts and seats and their mountings – fitted originally. For special operations (e.g. fitting child seats) please contact an approved dealer.
- Do not use devices which give any slack in the belts (e.g. clothes pegs, clips, etc.), as a seat belt which is worn too loosely risks causing injury in the event of an accident.
- Never wear the shoulder strap under your arm or behind your back.
- Never use the same belt for more than one person and never hold a baby or child on your lap with your seat belt around them.
- The belt should never be twisted.
- Following an accident, have the seat belts checked and replaced if necessary. Always replace your seat belts as soon as they show any signs of wear.
- When the rear bench seat is being put back, make sure that the seat belts and buckles are correctly positioned so that they can be used properly.
- Make sure that the buckle is inserted into the appropriate catch.
- Ensure that no objects are placed in the area around the seat belt catch as they could prevent it from being properly secured.
- Make sure the seat belt catch is properly positioned (it should not be hidden away, crushed or flattened by people or objects).

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (1/6)


Depending on the vehicle, they will consist of:

- **seat belt inertia reel pretensioners;**
- **lap seat belt pretensioners;**
- **chest force limiters;**
- **airbags driver and passenger front.**

These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.

Depending on the severity of the impact, the system can trigger:

- the seat belt locking;
- the seat belt inertia reel pretensioner (which engages to correct seat belt slack);
- lap seat belt pretensioners to hold the occupant in their seat;
- the front airbag.



Pretensioners

The pretensioners hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

In the event of a severe frontal impact and if the ignition is switched on, the system may engage the following depending on the force of the impact:

- the seat belt inertia reel pretensioner **1** which instantly retracts the seat belt;
- the lap seat belt inertia reel pretensioner **2** on the front seats.



- Have the entire restraint system checked following an accident.
- No operation whatsoever is permitted on any part of the system (pretensioners, airbags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.
- Only qualified personnel from our Network may work on the airbags; otherwise the system may trigger accidentally and cause injury.
- The electric trigger system may only be tested by a specially trained technician using special equipment.
- When the vehicle is scrapped, contact an approved dealer for disposal of the pretensioner and airbags gas generators.

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (2/6)

Load limiter

Above a certain severity of impact, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.

Driver and passenger front Airbags

Fitted to the driver and passenger sides.

A symbol on the lower section of the windscreen indicates if this equipment is present (depending on the vehicle).

Each airbag system consists of:

- an airbag and gas generator fitted on the steering wheel for the driver and in the dashboard for the passenger;
- an electronic unit for monitoring the system controlling the gas generator electrical trigger;
- remote sensors;
- a single warning light  on the instrument panel.



The airbag system uses pyrotechnic principles. This explains why, when the airbag inflates, it will generate heat, produce smoke (this does not mean that a fire is about to start) and make a banging noise. In a situation where an airbag is required, it will inflate immediately and this may cause some minor, superficial grazing to the skin or other problems.

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (3/6)



Operating faults

 This warning light comes on when the engine is started and then goes out after approximately three seconds.

If it does not come on when the ignition is switched on or if it stays on, there is a fault in the system.

Contact your approved Dealer as soon as possible.


Your protection will be reduced until this fault is rectified.

Operation


This system is only operational when the ignition is switched on.

In a severe frontal impact, the airbags inflate rapidly, cushioning the impact of the driver's head and chest against the steering wheel and of the front passenger against the dashboard. The air bags then deflate immediately so that the passengers are not in any way hindered from leaving the vehicle.


METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (4/6)



44446



44448



44452

The following conditions will trigger the pretensioners or airbags.

In a frontal impact against a rigid (non-deformable) surface at an impact speed equal to or greater than **16 mph (25 km/h)**.


In a frontal impact with another vehicle of an equivalent or higher category, with an impact area equal to or greater than 40%, where the speed of both vehicles is equal to or greater than **25 mph (40 km/h)**.

In a side impact with another vehicle of an equivalent or higher category, at an impact speed equal to or greater than **31 mph (50 km/h)**.


METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (5/6)



44449



44450



44451

In the following examples, the pretensioners or the airbags could operate:

- impact under vehicle such as pavement;
- potholes;
- drop or hard landing;
- stones;
- ...

In the following examples, there is a risk that pretensioners or airbags may not be triggered:

- rear impact, however severe;
- the vehicle overturning;

- side impact, affecting the front of the vehicle;
- frontal impact, under the tail of a lorry;
- frontal impact against an obstacle with a sharp angle;
- ...

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (6/6)

All of the warnings below are given so that the airbag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when it inflates.



Warnings concerning the driver's airbag

- Do not modify the steering wheel or the steering wheel boss.
- Do not cover the steering wheel boss under any circumstances.
- Do not attach any objects (badge, logo, clock, telephone holder, etc.) to the steering wheel boss.
- The steering wheel must not be removed (except by qualified personnel from our Network).
- Do not sit too close to the steering wheel when driving: sit with your arms slightly bent (see "Adjusting your driving position" ➔ 1.69). This will allow sufficient space for the airbag to deploy correctly and be fully effective.

Warnings concerning the passenger airbag

- Do not attach or glue any objects (badge, logo, clock, telephone holder, etc.) to the dashboard on or near the **airbag**.
- Do not place anything between the dashboard and the passenger (pet, umbrella, walking stick, parcels, etc.).
- The passenger must not put his or her feet on the dashboard or seat as there is a risk that serious injuries may occur. In general, parts of the body should be kept away from the dashboard (knees, hands, head, etc.).
- The devices in addition to the front passenger seat belt should be reactivated as soon as a child seat is removed, to ensure the protection of the passenger in the event of an impact.

A REAR-FACING CHILD SEAT MUST NOT BE FITTED TO THE FRONT PASSENGER SEAT UNLESS THE RESTRAINT SYSTEMS IN ADDITION TO THE FRONT PASSENGER SEATBELT ARE DEACTIVATED ➔ 1.131.

METHODS OF RESTRAINT IN ADDITION TO THE REAR SEAT BELTS

Depending on the vehicle, they will consist of:

- **side seat belt inertia reel pretensioners;**
- **chest force limiters.**


These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.

Depending on the severity of the impact, the system can trigger:

- the seat belt locking;
- the seat belt inertia reel pretensioner (which engages to correct seat belt slack).

Force limiter

Above a certain severity of impact, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.



Side seat belt pretensioners

The pretensioners hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

With the ignition on, following a significant frontal impact and depending on the severity of the impact, the system may trigger the seat belt inertia reel pretensioner **1**, which instantly retracts the seat belt.



- Have the entire restraint system checked following an accident.
- No operation whatsoever is permitted on any part of the system (pretensioners, airbags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.
- Only qualified personnel from our Network may work on the airbags; otherwise the system may trigger accidentally and cause injury.
- The electric trigger system may only be tested by a specially trained technician using special equipment.
- When the vehicle is scrapped, contact an approved dealer for disposal of the pretensioner and airbags gas generators.

SIDE PROTECTION DEVICES

Side Airbag

This airbag may be fitted to each of the front seats and is activated at the sides of the seats (door side) to protect the occupants in the event of a severe side impact.

Curtain Airbag

This is an airbag fitted (depending on the vehicle) along the upper sides of the vehicle – they inflate along the front and rear door side windows to protect the passengers in the event of a severe side impact.



Warning relating to the side airbag

- **Fitting seat covers:** seats equipped with an airbag require covers specifically designed for your vehicle. Contact an approved dealer to find out if these covers are available. The use of any covers other than those designed for your vehicle (including those designed for another vehicle) may affect the operation of the airbag and reduce your protection.
- Do not place any accessories, objects or even pets between the seatback, the door and the internal fittings. Do not cover the seatback with any items such as clothes or accessories. This may prevent the air bag from operating correctly or cause injury when the airbag is deployed.
- No work or modification whatsoever may be carried out on the seat or internal fittings, except by qualified personnel from an approved Dealer.
- This airbag operates through slits in the front seatbacks (door side): never insert any objects in these slits.

ADDITIONAL METHODS OF RESTRAINT

All of the warnings below are given so that the airbag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when it inflates.



The airbag is designed to complement the action of the seat belt. Both the airbag and the seat belt are integral parts of the same protection system. It is therefore essential to wear seat belts at all times. If seat belts are not worn, the occupants are exposed to the risk of serious injury in the event of an accident. It may also increase the risk of minor superficial injuries occurring when the airbag is deployed, although such minor injuries are always possible with airbags.

If the vehicle should overturn or in the event of a rear impact, however severe, the pretensioners and airbags are not always triggered. Impacts to the underside of the vehicle, e.g. from pavements, potholes or stones, can all trigger these systems.

- No work or modification **whatsoever** may be carried out on any part of the airbag system (airbags, pretensioners, computer, wiring harness, etc.), except by qualified Network personnel.
- To ensure that the system is in good working order and to avoid accidental triggering of the system which may cause injury, only qualified Network personnel may work on the airbag system.
- As a safety precaution, have the airbag system checked if your vehicle has been involved in an accident, or is stolen or broken into.
- When selling or lending the vehicle, inform the user of these points and hand over this handbook with the vehicle.
- When scrapping your vehicle, contact your approved Dealer for disposal of the gas generator(s).

CHILD SAFETY: General information (1/2)

Carrying children

Please ensure that you comply with the legislation of your country.

Children, and adults, must be correctly seated and strapped in for all journeys. The children being carried in your vehicle are your responsibility.

A child is not a miniature adult. Children are at risk of specific injuries as their muscles and bones have not yet finished growing. The seat belt alone would not provide suitable protection. Use an approved child seat and ensure you use it correctly.



To prevent the sliding side doors from being opened, use the "Child lock" feature
→ 1.49.



A collision at 31 mph (50 km/h) is the same as falling a distance of 10 metres. Transporting a child without a restraint is the equivalent of allowing him or her to play on a fourth-floor balcony without railings.

Never travel with a child held in your arms. In the event of an accident, you will not be able to keep hold of the child, even if you yourself are wearing a seat belt.

If your vehicle has been involved in a road accident, replace the child seat and have the seat belts and ISOFIX anchorage points checked.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

CHILD SAFETY: General information (2/2)

Using a child seat

The level of protection offered by the child seat depends on its ability to restrain your child and on its installation. Incorrect installation compromises the protection it offers the child in the event of harsh braking or an impact.

Before purchasing a child seat, check that it complies with the regulations for the country you are in and that it can be fitted in your vehicle. Consult an approved dealer to find out which seats are recommended for your vehicle.

The regulations on transporting children are specific to each country.

The use of a child seat during transport depends on the age and/or the size and/or weight of the child.

For children who do not need to be transported to a child seat, make sure that the seat belt is correctly adjusted and fastened.

In all cases, you must comply with the regulations of the particular country you are in.

Before fitting a child seat, read the manual and respect its instructions. If you experience any difficulties during installation, contact the manufacturer of the equipment. Keep the instructions with the seat.

Set a good example by always fastening your seat belt and teaching your child:

- to strap themselves in correctly;
- to always get in and out of the car at the kerb, away from busy traffic.

Do not use a second-hand child seat or one without an instruction manual.

Check that there are no objects in the vicinity of the child seat which could impede its operation.



Never leave a child unattended in the vehicle.

Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. Avoid wearing bulky clothing which could cause the belts to slacken ➔ 1.69.

Never let your child put their head or arms out of the window.

Check that the child is in the correct position for the entire journey, especially if asleep.

CHILD SAFETY: choosing a child seat



31235



38824



31234

Rear-facing child seats

A baby's head is, proportionally, heavier than that of an adult and its neck is very fragile. Transport the child in this position for as long as possible (until the age of 2 at the very least). It supports both the head and the neck.

Choose a bucket type seat for best side protection and change it as soon as the child's head is higher than the shell.

Forward-facing child seats

Up to 18 kg or 4 years, the child may travel on a forward-facing seat.

Choose your seat according the child's size: their head and abdomen are the areas which must be most protected. A forward-facing child seat which is firmly attached to the vehicle will reduce the risk of impact to the head. Ensure your child travels in a forward-facing seat with a harness for as long as their size permits.

Choose a bucket type seat for optimum side protection.

Booster cushions

From 15 kg or 4 years, the child can travel using a booster seat, which will enable the seat belt to be adapted to suit his size and shape. The booster seat cushion must be fitted with guides to position the seat belt on the child's thighs rather than the stomach. It is recommended that you use a seat-back which can be adjusted in terms of height to position the seat belt in the centre of the shoulder. It must never rest on the neck or on the arm.

Choose a bucket type seat for optimum side protection.

CHILD SAFETY: choosing a child seat mounting (1/3)

There are two ways of attaching child seats: via the seat belt or using the ISOFIX system.

Attachment via the seat belt

The seat belt must be adjusted to ensure that it is effective in the event of harsh braking or an impact.

Ensure that the strap paths indicated by the child seat manufacturer are respected.

Always check that the seat belt is correctly fastened by pulling it up, then pulling it out fully whilst pressing on the child seat.

Check that the seat is correctly held by moving it from side to side and back to front: the seat should remain firmly fixed.

Check that the child seat has not been installed at an angle and that it is not resting against a window.



Do not use the child seat if it may unfasten the seat belt restraining it: the base of the seat must not rest on the buckle and/or catch of the seat belt.



The seat belt must never be twisted or the tension relieved. Never pass the shoulder strap under the arm or behind the back. Check that the seat belt has not been damaged by sharp edges. If the seat belt does not operate normally, it will not protect the child. Consult an approved dealer. Do not use this seat until the seat belt has been repaired.

CHILD SAFETY: choosing a child seat mounting (2/3)

Attachment using the ISOFIX system


Approved child seats ISOFIX are standardised in accordance with current regulations if any of the four cases below applies:

- ISOFIX universal 3-point forward-facing seat;
- ISOFIX semi-universal 2-point seat;
- specific;
- i-Size which has either:
 - a strap which attaches to the third ring of the seat concerned;
 - or a strut that rests on the vehicle floor, compatible with the approved seat i-Size, the role of which is to prevent the child seat from moving in the event of a collision.

In the latter three cases check that your child seat can be installed by consulting the list of compatible vehicles.

Attach the child seat with the ISOFIX locks, if these are provided. The ISOFIX system allows quick, easy, safe fitting.

The ISOFIX system consists of 2 rings and, in some cases, a third ring.



58085



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX system. Never fit a different type of child seat, seat belt or other objects to these anchorage points.

Check that nothing is obstructing the anchorage points.

If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.

The two rings **1** are located between the seatback and the seat base of the seat and are identified by a




No modifications may be made to the component parts of the restraint system (seat belts, ISOFIX and seats and their mountings) originally fitted.



Before using an ISOFIX child seat that you purchased for another vehicle, check that its installation is authorised. Consult the list of vehicles which can be fitted with the seat from the equipment manufacturer.

CHILD SAFETY: choosing a child seat mounting (3/3)




Attachment using the ISOFIX system (continued)

The third ring **4** is used to attach the upper strap **2** on some child seats.

Rear seats

The upper strap **2** should be positioned between the seatback and the rear parcel shelf. To do so, remove the rear parcel shelf ➔ 3.62.

Attach the **3** hook on one of the **4** rings marked with the  symbol.



Front passenger seat

If the front passenger seat is equipped, attach the hook **3** of the upper strap **2** on the ring **4** marked by the  symbol.

All seats

Pull the upper strap **2** so that the back of the child seat comes into contact with the back of the vehicle seat.



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX system. Never fit a different type of child seat, seat belt or other objects to these anchorage points. Check that nothing is obstructing the anchorage points.

If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.



Check that the seatback of the forward-facing child seat is in contact with the back of the vehicle seat. In this case, the child seat may not always rest on the base of the vehicle seat.

CHILD SAFETY: fitting a child seat: general information (1/2)

Some seats are not suitable for fitting child seats. The diagram on the following page shows you how to attach a child seat.



Fit the child seat in a rear seat wherever possible.

Make sure the child seat or the child's feet do not prevent the front seat from locking correctly ➔ 1.60.

Check that when installing the child seat in the vehicle it is not at risk of coming loose from its base.

If you have to remove the headrest, check that it is correctly stored so that it does not come loose under harsh braking or impact.

Always attach the child seat to the vehicle even if it is not in use so that it does not come loose under harsh braking or impact.

The types of child seat indicated may not be available. Before using a different child seat, check with the manufacturer that it can be fitted.

In the front seat

The laws concerning children travelling in the front passenger seat differ in every country. Consult the legislation in force and follow the indications on the diagram on the following page.

Before fitting a child seat in this seat (if authorised):

- lower the seat belt as far as possible;
- move the seat as far back as possible;
- gently tilt the seatback away from vertical (approximately 25°);
- on equipped vehicles, raise the seat base as far as possible.

Always fully raise the seat headrest so that it does not interfere with the child seat ➔ 1.59.

After installing the child seat, when this is possible, you can move the vehicle seat forward if necessary (so as to leave enough space in the rear seats for passengers or other child seats). For a rear-facing child seat, do not let it touch the dashboard or move it to the furthest forward position.

Do not change other settings after installing the child seat.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated. ➔ 1.131.

CHILD SAFETY: fitting a child seat: general information (2/2)

In the rear side seat

A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.

For the safety of the child in the forward-facing position:

- move the relevant seat backwards as far as possible;
- move the seat in front of the child forwards, and set the position of the seatback to avoid contact between the seat and the child's legs.



Fitting a seat ISOFIX in the rear-left seat means the middle seat cannot be used. The central seat belt will no longer be either accessible or useable.

Always remove the headrest from the rear seat on which the child seat is positioned. ➔ 3.38. If necessary, position the rear seat as far back as possible. This must be done before fitting the child seat. Check that the child seat is resting against the back of the rear seat.

In rear centre seat

Check that the belt is suitable for securing your child seat. Consult an approved dealer.



Ensure that the child seat or the child's feet do not prevent the front seat from locking correctly. ➔ 3.44.



An ISOFIX or a child seat with a floor support must never be installed on the rear centre seat.


RISK OF DEATH OR SERIOUS INJURY.



Fit the child seat in a rear seat wherever possible. To install an ISOFIX seat in this seat, unbuckle the seat belt by hand before engaging the bolts.

CHILD SEATS: attachment by seat belt (1/20)

“Open Sesame” van version



Child seat attached using the belt

UF Seat enabling **only a forward-facing seat** with “Universal” approval to be fitted.

 Seat not suitable for fitting child seats.

 Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

55942



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69.

If necessary, adjust the seat position accordingly.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat.

CHILD SEATS: attachment by seat belt (2/20)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| "Open Sesame" van version | | | |
|--|----------------------------|--|---|
| Type of child seat | Weight of the child | Front passenger seat | |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated (1) |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | X |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | X |
| Forward-facing seat Group 1 | 9 to 18 kg | UF (2) | X |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | UF (2) | X |

Refer to the "Child safety equipment" booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

UF= Seat which enables **only a forward-facing seat** with "Universal" approval to be fitted: check if it can be fitted.

(2) Depending on the vehicle, raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).



(1) **RISK OF DEATH OR SERIOUS INJURY:** never install a rear-facing child seat on the front passenger seat.

CHILD SEATS: attachment by seat belt (3/20)

Van version with foldable passenger seat



61843

Child seat attached using the belt

U Seat which allows a child seat with "Universal" approval to be attached by a seat belt.

 Seat not suitable for fitting child seats.

 Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

B2: Seat enabling a child seat with "B2" approval to be attached by seat belt.

B3: Seat enabling a child seat with "B3" approval to be attached by seat belt.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. ➔ 1.69.

If necessary, adjust the seat position accordingly.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated. ➔ 1.131.

CHILD SEATS: attachment by seat belt (4/20)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| Van version with foldable passenger seat | | | |
|--|----------------------------|--|---|
| Type of child seat | Weight of the child | Front passenger seat | |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated (2) |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | U (2) |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | U (2) |
| Forward-facing seat Group 1 | 9 to 18 kg | U (1) | X |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | U / B2 / B3 | X |

Refer to the "Child safety equipment" booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

U = Seat allowing a child seat with "Universal" approval to be attached by the seat belt; check that it can be fitted.

B2 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

B3 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).



(1) RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat if the vehicle is equipped with a passenger airbag that cannot be deactivated.

(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (5/20)

Van version with unfoldable passenger seat



61843

Child seat attached using the belt

U Seat which allows a child seat with "Universal" approval to be attached by a seat belt.

 Seat not suitable for fitting child seats.

 Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

B2: Seat enabling a child seat with "B2" approval to be attached by seat belt.

B3: Seat enabling a child seat with "B3" approval to be attached by seat belt.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. ➔ 1.69.

If necessary, adjust the seat position accordingly.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated. ➔ 1.131.

CHILD SEATS: attachment by seat belt (6/20)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| Van version with unfoldable passenger seat | | | |
|--|----------------------------|--|---|
| Type of child seat | Weight of the child | Front passenger seat | |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | U (2) (3) |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | U (2) (3) |
| Forward-facing seat Group 1 | 9 to 18 kg | U (3) | X |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | U / B2 / B3 (3) | X |

Refer to the "Child safety equipment" booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

U = Seat allowing a child seat with "Universal" approval to be attached by the seat belt; check that it can be fitted.

(3) Depending on the vehicle, raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

B2 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

B3 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).




(1) RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat if the vehicle is equipped with a passenger airbag that cannot be deactivated.

(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (7/20)

Van version with three front seats



Child seat attached using the belt

U Seat which allows a child seat with "Universal" approval to be attached by a seat belt.

 Seat not suitable for fitting child seats.

 Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

55042



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. ➔ 1.69.

If necessary, adjust the seat position accordingly.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated. ➔ 1.131.

CHILD SEATS: attachment by seat belt (8/20)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| Van version with three front seats | | | | |
|--|----------------------------|--|---|------------------------------|
| Type of child seat | Weight of the child | Side front passenger seat | | Central front passenger seat |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated | |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | U (2) | X |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | U (2) | X |
| Forward-facing seat Group 1 | 9 to 18 kg | U | X | X |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | U | X | X |

Refer to the “Child safety equipment” booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

U = Seat allowing a child seat with “Universal” approval to be attached by the seat belt; check that it can be fitted.



(1) RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat if the vehicle is equipped with a passenger airbag that cannot be deactivated.

(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (9/20)

The table below summarises the information already shown on the diagram on the following pages, to ensure the applicable regulations are respected.

| Estate version with unfoldable front passenger seat (standard chassis) | | | | | |
|--|----------------------------|--|---|------------|-------------|
| Type of child seat | Weight of the child | Front passenger seat | | Rear seats | |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated (2) (3) | Side seats | Centre seat |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X | U (4) | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | U | U (5) | U (5) (7) |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | U | U (5) | U (5) (7) |
| Forward-facing seat Group 1 | 9 to 18 kg | U (3) | X | U (6) | U (6) (7) |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | U / B2 / B3 (3) | X | U / B2 (6) | U (6) |



(1) RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat if the vehicle is equipped with a passenger airbag that cannot be deactivated.

(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (10/20)

Refer to the “Child safety equipment” booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

U = Seat allowing a child seat with “Universal” approval to be attached by the seat belt; check that it can be fitted.

B2 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

B3 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

(3) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

(4) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(5) In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.


(6) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat. ➔ 3.38. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.



(7) **RISK OF DEATH OR SERIOUS INJURY:** a child seat with a floor support must never be fitted on the rear centre seat.

CHILD SEATS: attachment by seat belt (11/20)

Estate version with unfoldable front passenger seat (standard chassis)



61844

Child seat attached using the belt

U Seat which allows a child seat with "Universal" approval to be attached by a seat belt.

✗ Seat not suitable for fitting child seats.

✗ Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

B2: Seat enabling a child seat with "B2" approval to be attached by seat belt.

B3: Seat enabling a child seat with "B3" approval to be attached by seat belt.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. ➔ 1.69.

If necessary, adjust the seat position accordingly.




Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated. ➔ 1.131.

CHILD SEATS: attachment by seat belt (12/20)

Estate version with foldable front passenger seat (standard chassis)



61844

Child seat attached using the belt

U Seat which allows a child seat with "Universal" approval to be attached by a seat belt.

 Seat not suitable for fitting child seats.

 Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

B2: Seat enabling a child seat with "B2" approval to be attached by seat belt.

B3: Seat enabling a child seat with "B3" approval to be attached by seat belt.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. ➔ 1.69.

If necessary, adjust the seat position accordingly.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated. ➔ 1.131.

CHILD SEATS: attachment by seat belt (13/20)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| Estate version with foldable front passenger seat (standard chassis) | | | | | |
|--|----------------------------|--|---|----------------|-------------|
| Type of child seat | Weight of the child | Front passenger seat | | Rear seats | |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated (2) (3) | Side seats (8) | Centre seat |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X | U (4) | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | U | U (5) | U (5) (7) |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | U | U (5) | U (5) (7) |
| Forward-facing seat Group 1 | 9 to 18 kg | U (3) | X | U (6) | U (6) (7) |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | U / B2 / B3 (3) | X | U / B2 (6) | U (6) |



(1) RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat if the vehicle is equipped with a passenger airbag that cannot be deactivated.

(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (14/20)

Refer to the “Child safety equipment” booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

U = Seat allowing a child seat with “Universal” approval to be attached by the seat belt; check that it can be fitted.

B2 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

B3 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

(3) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 15°).

(4) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(5) In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

(6) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat. ➔ 3.38. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.



(7) **RISK OF DEATH OR SERIOUS INJURY:** a child seat with a floor support must never be fitted on the rear centre seat.

(8) **RISK OF DEATH OR SERIOUS INJURY:** it is forbidden to fit a child seat behind a folded front seat.

CHILD SEATS: attachment by seat belt (15/20)

The table below summarises the information already shown on the diagram on the following pages, to ensure the applicable regulations are respected.

| Estate version with unfoldable front passenger seat (long chassis) | | | | | | |
|--|----------------------------|--|---|-----------------------|-------------|----------------------|
| Type of child seat | Weight of the child | Front passenger seat | | Second row rear seats | | Third row rear seats |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated (2) (3) | Side seats | Centre seat | |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X | U (4) | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | U | U (5) | U (5) (7) | X |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | U | U (5) | U (5) (7) | X |
| Forward-facing seat Group 1 | 9 to 18 kg | U (3) | X | U (6) | U (6) (7) | X |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | U / B2 / B3 (3) | X | U / B2 (6) | U (6) | U / B2 (6) |



(1) RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat if the vehicle is equipped with a passenger airbag that cannot be deactivated.

(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (16/20)

Refer to the “Child safety equipment” booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

U = Seat allowing a child seat with “Universal” approval to be attached by the seat belt; check that it can be fitted.

B2 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

B3 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

(3) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

(4) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(5) In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

(6) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat ➔ 3.38. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.



(7) **RISK OF DEATH OR SERIOUS INJURY:** a child seat with a floor support must never be fitted on the rear centre seat.

CHILD SEATS: attachment by seat belt (17/20)

Estate version with unfoldable front passenger seat (long chassis)



61850

Child seat attached using the belt

U Seat which allows a child seat with "Universal" approval to be attached by a seat belt.

✗ Seat not suitable for fitting child seats.

✗ Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

B2: Seat enabling a child seat with "B2" approval to be attached by seat belt.

B3: Seat enabling a child seat with "B3" approval to be attached by seat belt.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69.

If necessary, adjust the seat position accordingly.



Using a child safety system which is not approved for this vehicle will not properly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (18/20)

Estate version with foldable front passenger seat (long chassis)



Child seat attached using the belt

U Seat which allows a child seat with "Universal" approval to be attached by a seat belt.

 Seat not suitable for fitting child seats.

 Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

B2: Seat enabling a child seat with "B2" approval to be attached by seat belt.

B3: Seat enabling a child seat with "B3" approval to be attached by seat belt.

61850



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69.

If necessary, adjust the seat position accordingly.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat in this seat, make sure that the front passenger airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (19/20)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| Estate version with foldable front passenger seat (long chassis) | | | | | | |
|--|----------------------------|--|---|-----------------------|-------------|----------------------|
| Type of child seat | Weight of the child | Front passenger seat | | Second row rear seats | | Third row rear seats |
| | | airbag activated on passenger side (1) | without passenger airbag or with it deactivated (2) (3) | Side seats (8) | Centre seat | |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | X | X | U (4) | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | X | U | U (5) | U (5) (7) | X |
| Shell seat/rear-facing seat Groups 0+ and 1 | < 13 kg 9 to 18 kg | X | U | U (5) | U (5) (7) | X |
| Forward-facing seat Group 1 | 9 to 18 kg | U (3) | X | U (6) | U (6) (7) | X |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | U / B2 / B3 (3) | X | U / B2 (6) | U (6) | U / B2 (6) |



(1) RISK OF DEATH OR SERIOUS INJURY: never install a rear-facing child seat on the front passenger seat if the vehicle is equipped with a passenger airbag that cannot be deactivated.

(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: attachment by seat belt (20/20)

Refer to the “Child safety equipment” booklet (available from the network) to choose a seat suited to your child and recommended for your vehicle.

X = Seat not suitable for fitting child seats of this type.

U = Seat allowing a child seat with “Universal” approval to be attached by the seat belt; check that it can be fitted.

B2 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

B3 = Booster seats in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

(3) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 15°).

(4) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(5) In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

(6) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat ➔ 1.131. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.



(7) **RISK OF DEATH OR SERIOUS INJURY:** a child seat with a floor support must never be fitted on the rear centre seat.

(8) **RISK OF DEATH OR SERIOUS INJURY:** it is forbidden to fit a child seat behind a folded front seat.

CHILD SEATS: fitted using the ISOFIX SYSTEM (1/15)

The table below summarises the information already shown on the diagram on the following pages, to ensure the applicable regulations are respected.

| Van version with front passenger seat equipped with ISOFIX system | | | | | |
|---|----------------------------|-----------------------------|----------------------------|------------------------------------|------------|
| Type of child seat | | Weight of the child | Size of ISOFIX seat [Size] | Front passenger seat | |
| | | | | airbag activated on passenger side | |
| Front passenger seat | | Front passenger seat | | Front passenger seat | |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | L1 [F], L2 [G] | | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | R1 [E] | | X | IL (1) (2) |
| Shell seat/ rear-facing seat | Group 0 + | < 13 kg | R3 [C] | X | IL (1) (2) |
| | Group 1 | 9 to 18 kg | R2 [D], R2X [D] | X | IL (1) (2) |
| Forward-facing seat Group 1 | 9 to 18 kg | F3 [A], F2 [B], F2X [B1] | IUF - IL (1) | X | |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | B2, B3 | IUF - IL (1) | X | |
| Seat i-Size | | | i-UF (1) | i-U (1) (2) | |

CHILD SEATS: fitted using the ISOFIX SYSTEM (2/15)

X = Seat not suitable for fitting child seats of this type.

IUF/IL = On equipped vehicles, seat which allows a child seat with "Universal/Semi-universal or vehicle-specific" approval to be fitted using the ISOFIX system; check that it can be fitted.

i-U = Suitable for "universal" front-facing and rear-facing i-Size restraint devices.

i-UF = Suitable only for "universal" front-facing and rear-facing i-Size restraint devices.

(1) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

The size of the ISOFIX child seat is indicated by a letter:

- **F3 [A], F2 [B], F2X [B1]**: for forward-facing seats in group 1 (9 to 18 kg);
- **R3 [C], R2 [D], R2X [D]**: rear-facing seats or shell seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- **R1 [E]**: rear-facing shell seats in group 0 (less than 10 kg) or 0+ (less than 13 kg);
- **L1 [F], L2 [G]**: carrycots in group 0 (less than 10 kg);
- **B2, B3**: boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).



(2) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated.²

CHILD SEATS: fitted using the ISOFIX SYSTEM (3/15)

Van version with front passenger seat equipped with ISOFIX system



59561



Seat which does not allow a child seat to be fitted.



Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.

Child seat fitted using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.

The anchorage point  is located on the back of the front passenger seat.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69.


If necessary, adjust the seat position accordingly.



RISK OF DEATH OR SERIOUS INJURY: before fitting a rear facing child seat on the front passenger seat, check that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: fitted using the ISOFIX SYSTEM (4/15)

Estate version with front passenger seat equipped with ISOFIX system (standard chassis)



59562



Seat which does not allow a child seat to be fitted.



Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

Child seat fitted using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.

 The rear side seats are equipped with an anchorage point allowing a forward-facing ISOFIX child seat with "Universal" approval to be attached. The anchoring points  are located on the passenger seatback for the front seat and on the luggage compartment floor for the rear seats.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69.

If necessary, adjust the seat position accordingly.



RISK OF DEATH OR SERIOUS INJURY:

before fitting a rear facing child seat on the front passenger seat, check that the airbag has been deactivated ➔ 1.131.



Fit the child seat in a rear seat wherever possible.

To install an ISOFIX seat in this seat, detach the central seat belt by hand before engaging the bolts.

CHILD SEATS: fitted using the ISOFIX SYSTEM (5/15)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| Estate version with front passenger seat equipped with ISOFIX system (standard chassis) | | | | | | |
|---|----------------------------|----------------------------|------------------------------------|---|------------------|-------------|
| Type of child seat | Weight of the child | Size of ISOFIX seat [Size] | Front passenger seat | | Rear seats | |
| | | | airbag activated on passenger side | without passenger airbag or with it deactivated | Side seats | Centre seat |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | L1 [F], L2 [G] | X | X | IL (1) | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | R1 [E] | X | IL (2) (5) | IL (3) | X |
| Shell seat/ rear-facing seat | Group 0 + | < 13 kg | R3 [C] | X | IL (2) (5) | IL (3) |
| | Group 1 | 9 to 18 kg | R2 [D], R2X [D] | X | IL (2) (5) | IL (3) |
| Forward-facing seat Group 1 | 9 to 18 kg | F3 [A], F2 [B], F2X [B1] | IUF - IL (2) | X | IUF - IL (3) (4) | X |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | B2 | IUF - IL (2) | X | IUF - IL (3) (4) | X |
| | | B3 | IUF - IL (2) | X | X | X |
| Seat i-Size | | | i-UF (2) | i-U (2) (5) | i-U | X |

CHILD SEATS: fitted using the ISOFIX SYSTEM (6/15)

X = Seat not suitable for fitting child seats of this type.

IUF/IL = On equipped vehicles, seat which allows a child seat with "Universal/Semi-universal or vehicle-specific" approval to be fitted using the ISOFIX system; check that it can be fitted.

i-U = Suitable for "universal" front-facing and rear-facing i-Size restraint devices.

i-UF = Suitable only for "universal" front-facing and rear-facing i-Size restraint devices.

(1) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(2) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

(3) If necessary, position the vehicle seat as far back as possible. In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

(4) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat ➔ 3.38. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

The size of the ISOFIX child seat is indicated by a letter:

- **F3 [A], F2 [B], F2X [B1]**: for forward-facing seats in group 1 (9 to 18 kg);
- **R3 [C], R2 [D], R2X [D]**: rear-facing seats or shell seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- **R1 [E]**: rear-facing shell seats in group 0 (less than 10 kg) or 0+ (less than 13 kg);
- **L1 [F], L2 [G]**: carrycots in group 0 (less than 10 kg);
- **B2, B3**: boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).



(5) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated. ➔ 1.131.

CHILD SEATS: fitted using the ISOFIX SYSTEM (7/15)

The table below summarises the information already shown on the diagram on the following pages, to ensure the applicable regulations are respected.

| Estate version with front passenger seat not equipped with ISOFIX system (standard chassis) | | | | | | |
|---|-----------|---------------------|----------------------------|----------------------|------------------|-------------|
| Type of child seat | | Weight of the child | Size of ISOFIX seat [Size] | Front passenger seat | Rear seats | |
| | | | | | Side seats (4) | Centre seat |
| Carrycot fitted across the vehicle Group 0 | | < 10 kg | L1 [F], L2 [G] | X | IL (1) | X |
| Rear-facing shell seat Groups 0 or 0 + | | < 13 kg | R1 [E] | X | IL (2) | X |
| Shell seat/ rear-facing seat | Group 0 + | < 13 kg | R3 [C] | X | IL (2) | X |
| | Group 1 | 9 to 18 kg | R2 [D], R2X [D] | X | IL (2) | X |
| Forward-facing seat Group 1 | | 9 to 18 kg | F3 [A], F2 [B], F2X [B1] | X | IUF - IL (2) (3) | X |
| Booster seat Groups 2 and 3 | | 15 to 25 kg | B2 | X | IUF - IL (2) (3) | X |
| | | 22 to 36 kg | B3 | X | X | X |
| Seat i-Size | | | | X | i-U | X |

CHILD SEATS: fitted using the ISOFIX SYSTEM (8/15)

X = Seat not suitable for fitting child seats of this type.

IUF/IL = On equipped vehicles, seat which allows a child seat with "Universal/Semi-universal or vehicle-specific" approval to be fitted using the ISOFIX system; check that it can be fitted.

i-U = Suitable for "universal" front-facing and rear-facing i-Size restraint devices.

i-UF = Suitable only for "universal" front-facing and rear-facing i-Size restraint devices.

(1) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(2) If necessary, position the vehicle seat as far back as possible. In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

(3) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat. ➔ 3.38. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

The size of the ISOFIX child seat is indicated by a letter:


- **F3 [A], F2 [B], F2X [B1]**: for forward-facing seats in group 1 (9 to 18 kg);
- **R3 [C], R2 [D], R2X [D]**: rear-facing seats or shell seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- **R1 [E]**: rear-facing shell seats in group 0 (less than 10 kg) or 0+ (less than 13 kg);
- **L1 [F], L2 [G]**: carrycots in group 0 (less than 10 kg);
- **B2, B3**: boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).



(4) RISK OF DEATH OR SERIOUS INJURY: it is forbidden to fit a child seat behind a folded front seat.

CHILD SEATS: fitted using the ISOFIX SYSTEM (9/15)

Estate version with front passenger seat not equipped with ISOFIX system (standard chassis)



59563

Child seat fitted using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.

The rear side seats are equipped with an anchorage point allowing a forward-facing ISOFIX child seat with "Universal" approval to be attached. The anchorage points are located on the boot floor for the rear seats.



Seat which does not allow a child seat to be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.




Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69. If necessary, adjust the seat position accordingly.



To install a seat ISOFIX, detach the central seat belt by hand before engaging the bolts.

CHILD SEATS: fitted using the ISOFIX SYSTEM (10/15)

Estate version with front passenger seat equipped with ISOFIX system (long chassis)



61071



Seat which does not allow a child seat to be fitted.



Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

Child seat fitted using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.

The rear side seats are equipped with an anchorage point allowing a forward-facing ISOFIX child seat with "Universal" approval to be attached. The anchoring points are located on the passenger seatback for the front seat and on the luggage compartment floor for the rear seats.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69.

If necessary, adjust the seat position accordingly.



RISK OF DEATH OR SERIOUS INJURY:

before fitting a rear facing child seat on the front passenger seat, check that the airbag has been deactivated ➔ 1.131.



Fit the child seat in a rear seat wherever possible.

To install an ISOFIX seat in this seat, detach the central seat belt by hand before engaging the bolts.

CHILD SEATS: fitted using the ISOFIX SYSTEM (11/15)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

| Estate version with front passenger seat equipped with ISOFIX system (long chassis) | | | | | | | |
|---|----------------------------|-----------------------------|------------------------------------|---|-----------------------|-------------|----------------------|
| Type of child seat | Weight of the child | Size of ISOFIX seat [Size] | Front passenger seat | | Second row rear seats | | Third row rear seats |
| | | | airbag activated on passenger side | without passenger airbag or with it deactivated | Side seats | Centre seat | |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | L1 [F], L2 [G] | X | X | IL (1) | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | R1 [E] | X | IL (2) (5) | IL (3) | X | IL (3) |
| Shell seat/ rear-facing seat | Group 0 + | < 13 kg | R3 [C] | X | IL (2) (5) | IL (3) | X |
| | Group 1 | 9 to 18 kg | R2 [D], R2X [D] | X | IL (2) (5) | IL (3) | X |
| Forward-facing seat Group 1 | 9 to 18 kg | F3 [A], F2 [B], F2X [B1] | IUF - IL (2) | X | IUF - IL (3) (4) | X | IUF - IL (3) (4) |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | B2 | IUF - IL (2) | X | IUF - IL (3) (4) | X | IUF - IL (3) (4) |
| | | B3 | IUF - IL (2) | X | X | X | X |
| Seat i-Size | | | i-UF (2) | i-U (2) (5) | i-U | X | i-U |

CHILD SEATS: fitted using the ISOFIX SYSTEM (12/15)

X = Seat not suitable for fitting child seats of this type.

IUF/IL = On equipped vehicles, seat which allows a child seat with "Universal/Semi-universal or vehicle-specific" approval to be fitted using the ISOFIX system; check that it can be fitted.

i-U = Suitable for "universal" front-facing and rear-facing i-Size restraint devices.

i-UF = Suitable only for "universal" front-facing and rear-facing i-Size restraint devices.

(1) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(2) Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

(3) If necessary, position the vehicle seat as far back as possible. In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

(4) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat ➔ 3.38. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

The size of the ISOFIX child seat is indicated by a letter:

- **F3 [A], F2 [B], F2X [B1]**: for forward-facing seats in group 1 (9 to 18 kg);
- **R3 [C], R2 [D], R2X [D]**: rear-facing seats or shell seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- **R1 [E]**: rear-facing shell seats of group 0 (below 10 kg) or 0+ (below 13 kg);
- **L1 [F], L2 [G]**: carrycots in group 0 (less than 10 kg);
- **B2, B3**: boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).



(5) RISK OF DEATH OR SERIOUS INJURY: before fitting a rear-facing child seat on the front passenger seat, ensure that the airbag has been deactivated ➔ 1.131.

CHILD SEATS: fitted using the ISOFIX SYSTEM (13/15)

The table below summarises the information already shown on the diagram on the following pages, to ensure the applicable regulations are respected.

| Estate version with front passenger seat not equipped with ISOFIX system (long chassis) | | | | | | |
|---|----------------------------|-----------------------------|----------------------|-----------------------|-------------|----------------------|
| Type of child seat | Weight of the child | Size of ISOFIX seat [Size] | Front passenger seat | Second row rear seats | | Third row rear seats |
| | | | | Side seats (4) | Centre seat | |
| Carrycot fitted across the vehicle Group 0 | < 10 kg | L1 [F], L2 [G] | X | IL (1) | X | X |
| Rear-facing shell seat Groups 0 or 0 + | < 13 kg | R1 [E] | X | IL (2) | X | IL (2) |
| Shell seat/ rear-facing seat | Group 0 + | R3 [C] | X | IL (2) | X | IL (2) |
| | Group 1 | 9 to 18 kg | R2 [D], R2X [D] | X | IL (2) | X |
| Forward-facing seat Group 1 | 9 to 18 kg | F3 [A], F2 [B], F2X [B1] | X | IUF - IL (2) (3) | X | IUF - IL (2) (3) |
| Booster seat Groups 2 and 3 | 15 to 25 kg 22 to 36 kg | B2 | X | IUF - IL (2) (3) | X | IUF - IL (2) (3) |
| | | B3 | X | X | X | X |
| Seat i-Size | | | X | i-U | X | i-U |

CHILD SEATS: fitted using the ISOFIX SYSTEM (14/15)

X = Seat not suitable for fitting child seats of this type.

IUF/IL = On equipped vehicles, seat which allows a child seat with "Universal/Semi-universal or vehicle-specific" approval to be fitted using the ISOFIX system; check that it can be fitted.

i-U = Suitable for "universal" front-facing and rear-facing i-Size restraint devices.

i-UF = Suitable only for "universal" front-facing and rear-facing i-Size restraint devices.

(1) A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

(2) If necessary, position the vehicle seat as far back as possible. In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

(3) In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat ➔ 3.38. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

The size of the ISOFIX child seat is indicated by a letter:

- **F3 [A], F2 [B], F2X [B1]**: for forward-facing seats in group 1 (9 to 18 kg);
- **R3 [C], R2 [D], R2X [D]**: rear-facing seats or shell seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- **R1 [E]**: rear-facing shell seats of group 0 (below 10 kg) or 0+ (below 13 kg);
- **L1 [F], L2 [G]**: carrycots in group 0 (less than 10 kg);
- **B2, B3**: boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).



(4) RISK OF DEATH OR SERIOUS INJURY: it is forbidden to fit a child seat behind a folded front seat.

CHILD SEATS: fitted using the ISOFIX SYSTEM (15/15)

Estate version with front passenger seat not equipped with ISOFIX system (long chassis)



61072

Child seat fitted using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.

 The rear side seats are equipped with an anchorage point allowing a forward-facing ISOFIX child seat with "Universal" approval to be attached. The anchorage points  are located on the boot floor for the rear seats.



Seat which does not allow a child seat to be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.




Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted ➔ 1.69. If necessary, adjust the seat position accordingly.



To install a seat ISOFIX, detach the central seat belt by hand before engaging the bolts.


CHILD SAFETY: deactivating, activating AIRBAG front passenger (1/3)



Deactivating the front passenger airbag (depending on the vehicle)

Before installing a child seat on the front passenger seat:

- check that the child seat can be installed on this seat;
- it is essential to deactivate the airbag for a rear-facing child seat.



To deactivate the airbag: with the vehicle stationary and the ignition switched off, push and turn lock 1 to the OFF position.

When the ignition is switched on, it is essential to check that the warning light  is illuminated on the display 2.

This light remains permanently lit to let you know that you can fit a child seat.



The passenger airbag may only be activated or deactivated when the **vehicle is stationary with the ignition off**.

If it is interfered with when the vehicle is being driven, indicator lights



and  will come on.


Switch the ignition off then on again to reset the airbag in accordance with the lock position.



DANGER

Since operation of the front passenger airbag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an ACTIVATED front AIRBAG. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.

CHILD SAFETY: deactivating, activating AIRBAG front passenger (2/3)




The markings on the dashboard and labels **A** on each side of the passenger sun visor **3** (example: label shown above) remind you of these instructions.



DANGER


Since operation of the front passenger airbag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an ACTIVATED front **AIRBAG**. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.

CHILD SAFETY: deactivating, activating AIRBAG front passenger (3/3)



Activating the front passenger airbag (depending on the vehicle)

You should reactivate the airbag as soon as you remove the child seat from the front passenger seat to ensure the protection of the front passenger in the event of an impact.



To restart the airbag: vehicle stopped, ignition switched off, press and turn the lock to 1 position ON.

When the ignition is switched on, you

must check that the  warning light is off and that the  warning light comes on the display 2 after each start-up for around 60 seconds.

The front passenger airbag is activated.

Operating faults

It is forbidden to fit a rear-facing child seat to the front passenger seat if the airbag activation/deactivation system is faulty.

Allowing any other passenger to sit in that seat is not recommended.

Contact your approved dealer as soon as possible.



The passenger airbag may only be activated or deactivated when the **vehicle is stationary with the ignition off**.


If it is interfered with when the vehicle is being driven, indicator lights



and  will come on.

Switch the ignition off then on again to reset the airbag in accordance with the lock position.

DRIVING POSITION: LEFT-HAND DRIVE (1/2)




DRIVING POSITION: LEFT-HAND DRIVE (2/2)

The equipment fitted, described below, DEPENDS ON THE VERSION AND COUNTRY.

- 1 Side air vent.
- 2 Stalk for:
 - direction indicator lights;
 - exterior lights;
 - fog lights.
- 3 Dashboard storage compartment sockets USB and accessories socket.
- 4 Instrument panel.
- 5 Driver airbag and horn location.
- 6 Controls for:
 - on-board computer information read-out and vehicle settings customisation menu,
 - remote radio and navigation system.
- 7 Steering column stalk for windscreen and rear screen wash/wiper.
- 8 Dashboard central storage compartment.
- 9 Centre air vents.
- 10 Multimedia screen.
- 11 Heating or air conditioning controls.
- 12 Passenger airbag location.
- 13 Glovebox.
- 14 Controls for:
 - front seat heating;
 - activation/deactivation of ECO mode;
 - activation/deactivation of the driving mode;
 - hazard warning lights;
 - electric door locking;
 - activation/deactivation of the parking distance control;
 - Park Assist.
- 15 Storage compartment.
- 16 Electronic parking brake.
- 17 Gearstick.
- 18 Smartphone induction charging area.
- 19 Handbrake.
- 20 Accessories socket.
- 21 Engine start/stop button.
- 22 Radio remote control.
- 23 Ignition switch.
- 24 Control for adjusting steering wheel height and reach.
- 25 Storage compartment and fuse box.
- 26 Bonnet release control.
- 27 Switch for:
 - lighting rheostat for control instruments;
 - headlight beam height remote adjustment;
 - activation/deactivation of Lane Keeping Assist/Lane Departure Warning;
 - activation/deactivation of ESC;
 - activation/deactivation of the traction control - Extended grip;
 - activation/deactivation of the steering wheel heating;
 - activation/deactivation of the electric heated windscreens function;
 - activation/deactivation of the "Vehicle data confidentiality" mode;
 - unlocking of the charging flap.
- 28 Main switch and controls for cruise control/speed limiter and Stop and Go adaptive cruise control.

DRIVING POSITION, RIGHT-HAND DRIVE (1/2)




DRIVER'S POSITION, RIGHT-HAND DRIVE (2/2)

The equipment fitted, described below, DEPENDS ON THE VERSION AND COUNTRY.

| | | |
|--|---|--|
| <ul style="list-style-type: none">1 Side air vent.2 Passenger airbag location.3 Heating or air conditioning controls.4 Centre air vents.5 Multimedia screen.6 Dashboard central storage compartment.7 Steering column stalk for windscreen and rear screen wash/wiper.8 Controls for:<ul style="list-style-type: none">– on-board computer information read-out and vehicle settings customisation menu,– remote radio and navigation system.9 Driver airbag and horn location.10 Dashboard storage compartment sockets USB and accessories socket.11 Instrument panel.12 Stalk:<ul style="list-style-type: none">– direction indicator lights;– exterior lights;– fog lights. | <ul style="list-style-type: none">13 Main switch and controls for cruise control/speed limiter and Stop and Go adaptive cruise control.14 Switch for:<ul style="list-style-type: none">– lighting rheostat for control instruments;– headlight beam height remote adjustment;– activation/deactivation of Lane Keeping Assist/Lane Departure Warning;– activation/deactivation of ESC;– activation/deactivation of the traction control - Extended grip;– activation/deactivation of the steering wheel heating;– activation/deactivation of the electric heated windscreen function;– activation/deactivation of the "Vehicle data confidentiality" mode;– unlocking of the charging flap.15 Storage compartment and fuse flap. | <ul style="list-style-type: none">16 Bonnet release control.17 Radio remote control.18 Ignition switch.19 Control for adjusting steering wheel height and reach.20 Engine start/stop button.21 Accessories socket.22 Handbrake.23 Smartphone induction charging area.24 Gearstick.25 Electronic parking brake.26 Storage compartment.27 Controls for:<ul style="list-style-type: none">– front seat heating;– activation/deactivation of ECO mode;– activation/deactivation of the driving mode;– hazard warning lights;– electric door locking;– activation/deactivation of the parking distance control;– Park Assist.28 Glovebox |
|--|---|--|


WARNING LIGHTS (1/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.



Instrument panel A or B: lights up when the ignition is switched on. Press or lift the **1** switch as many times as required to adjust the intensity.

Warning light  means you should drive **very carefully to an authorised dealer as soon as possible**. If you fail to follow this recommendation, you risk damaging your vehicle.



In some cases, the appearance of a warning light is accompanied by a message on the instrument panel.



For your safety, the warning light **STOP** requires you to stop immediately as soon as traffic conditions allow. Switch off the engine and do not restart it. Call an approved Dealer.



Side light tell-tale light



Dipped beam headlight tell-tale light



Main beam headlight tell-tale light



Automatic main beam headlight indicator light ➔ 1.175



Front fog light tell-tale



Rear fog light tell-tale light



Left-hand direction indicator tell-tale light



Right-hand direction indicator tell-tale light



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.

WARNING LIGHTS (2/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.



Indicator light Airbag

This comes on when the ignition is switched on and goes out after a few seconds.

If it does not light up when the ignition is switched on, or if it lights up when the engine is running, it indicates a fault in the system.

Contact your approved Dealer as soon as possible.



Handbrake "on" or electronic parking brake warning light ➔ 2.11 ➔ 2.12



Front seat belt reminder warning light

It lights up on the central display when the engine is started then, if the driver's seat belt is not fastened when the vehicle reaches a speed of approximately 12 mph (20 km/h), the light flashes and a beep sounds for about 120 seconds ➔ 1.69.



Door status warning light ➔ 1.49



Urgent stop warning light

This lights up when the ignition is switched on and goes out as soon as the engine is started. It comes on with other warning lights and/or messages, and is accompanied by a beep.

It requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it.

Contact an approved Dealer.



Warning light

This lights up when the ignition is switched on and goes out as soon as the engine is started. It can light up in conjunction with other warning lights and/or messages on the instrument panel.

It means you should **drive very carefully** to an approved dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.



Warning light

If it appears in red during driving and is accompanied by the **STOP** indicator light, you must, for your safety, stop as soon as traffic conditions allow. Switch off the engine and do not restart it.

Call an approved Dealer.

If it appears in yellow during driving and is accompanied by the **key** warning light, visit an approved dealer as soon as possible. **Meanwhile, drive with care.** If you fail to follow this recommendation, you risk damaging your vehicle.



Cruise control and speed limiter indicator lights ➔ 2.82 ➔ 2.86



Adaptive cruise control warning light Stop and Go ➔ 2.91

WARNING LIGHTS (3/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.



Electrotechnical system warning light

It appears when the temperature of the electrical assembly is too high. Stop the vehicle without switching off the ignition. The temperature should lower and the warning light should disappear. If this is not the case, please consult an Authorised Dealer.

The warning light may be accompanied by a reduction in vehicle performance.



Electrotechnical system fault warning light

If it comes on, this indicates an electro-technical fault related to the electrical assembly (traction battery and electric motor). Contact your approved Dealer straight away.



Electric motor fault warning light

When it comes on, this indicates a fault with the electrotechnical system linked to the electric motor. Contact your approved Dealer straight away.



Traction battery gauge indicator light

This lights up in yellow when the traction battery charge level has reached the reserve threshold ➔ 1.142.



Traction battery fault warning light

If it appears, accompanied by the  warning light, this indicates a fault related to the operation of the traction battery. Contact your approved Dealer straight away.



Limited performance warning light

This appears when the traction battery temporarily does not deliver its nominal power. During this period, vehicle performance is reduced.

Opt for a smoother driving style until the warning light disappears.



“Lane Centring” function warning light ➔ 2.105



Secondary 12 V battery charge warning light

If it comes on, accompanied by the  warning light and a beep, this means that the electrical circuit is overcharged or discharged ➔ 1.9.



ECO function indicator light

This lights up when ECO mode is activated ➔ 2.16 ➔ 2.20.



Charging cord plugged in warning light

This comes on when the charging lead is plugged into the vehicle ➔ 1.9.



Overspeed warning light ➔ 000



(Depending on the vehicle) Advanced Safety warning light, fault light or not available ➔ 2.59



Charging programme indicator lights ➔ 1.22



Warning lights for air conditioning programming ➔ 3.13

WARNING LIGHTS (4/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.



Anti-lock braking warning light

This lights up when the ignition is switched on and goes out after a few seconds.

If it does not go out after the ignition is switched on, or lights up when driving, there is a fault with the ABS. Braking will then be as normal, without the ABS. Contact your approved Dealer straight away.



Warning light for the electronic stability program (ESC) and traction control system

There are several reasons for the warning light to appear: ➤ 2.28.



Warning light for non-availability of the electronic stability program (ESC) and traction control system



Tyre under-inflation warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds ➤ 2.23.



Variable power assisted steering warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

If it comes on while driving, alongside the warning light **STOP**, this means there is a system fault.

Contact an authorised dealer.



Lane departure system warning light ➤ 2.34



Lane Keeping Assist system warning light ➤ 2.39



Hands off steering wheel detection warning light ➤ 2.39



Brake circuit fault warning light

If it comes on during braking and is accompanied by the **STOP** warning light and a beep, it indicates that the fluid level in the circuit is low or that there is a braking system fault. Stop as soon as traffic conditions allow and consult an approved dealer.



On display C



Passenger Airbag ON
➤ 1.131




Passenger Airbag OFF
➤ 1.131



Seat belt reminder warning lights
➤ 1.67.

DISPLAYS AND INDICATORS (1/7)




Instrument panel in miles

(option to switch to km/h)

Vehicles not fitted with a multimedia screen

- With the ignition off, press the **1** switch as many times as required to reach the vehicle tab **5**;
- press **2** or **3** repeatedly to access "Settings", then press **4** "OK";
- repeat the same operation to access "DASHBOARD", then "Units".




Vehicles fitted with a multimedia screen.

With the vehicle stationary and the engine on, from the multimedia screen, select the "Settings" menu, the "System" tab, then "Units".

Note: in both cases, once the battery is switched off, the on-board computer automatically returns to the original unit of measurement.

To return to the previous mode, repeat the same operation.

Please refer to the multimedia instructions for more information.



To use certain driving aid functions, it is necessary to change the unit of measurement on the instrument panel in order to obtain the correct information when driving in a country where the speed units differ from those set as default on your vehicle.



For safety reasons, change these settings while the vehicle is stationary.

DISPLAYS AND INDICATORS (2/7)



Instrument panel A


lights up when the driver's door is opened. In some cases, the appearance of a warning light is accompanied by a message.

Depending on the vehicle, you can customise your instrument panel with the content and colours of your choice.

For vehicles fitted with a multimedia screen, refer to the equipment instructions.

For vehicles not fitted with a multimedia screen ➔ 1.159.

Speedometer 6



Overspeed buzzer

Depending on the vehicle and country,

the warning light is displayed and a beep sounds. This beep sounds as soon as the vehicle is travelling at over 75 mph (120 km/h).

This warning light remains lit for as long as the vehicle is travelling at over 74 mph (120 km/h).

Multimedia information 7

Depending on the vehicle, you can display information from the multimedia screen (the compass, telephone, navigation etc.).

Please refer to the multimedia instructions for further information.

Message indicating vehicle ready for driving 8

The “READY” message appears when the engine starts and disappears when the vehicle speed exceeds 3 mph (5 km/h).

Power meter 9 ➔ 2.16

Driving style indicator 10 ➔ 2.16

Total mileage recorder 11 ➔ 1.152

Trip computer 12 ➔ 1.149

Estimated range 13.

DISPLAYS AND INDICATORS (3/7)



Remaining charge time 15

Traction battery charge rate 16

Opening element warning light 17

Shows when a door, the tailgate or charging flap is open or not closed properly.

Charge level 18

The gauge indicates the level of energy remaining.

Charging cable “Plugged In”

warning light 19

(depending on the vehicle)

This comes on when the charging cord is plugged into the vehicle.

Reserve threshold

When the traction battery charge level reaches approximately 12%, the gauge and indicator light 14  appear in yellow, accompanied by a beep. To optimise your range \rightarrow 2.20.

Immobilisation threshold imminent

When the charge level reaches approximately 6%, a beep sounds again and the gauge illuminates in red.

When the charge level reaches 5%, the range value is no longer displayed.

DISPLAYS AND INDICATORS (4/7)




Instrument panel **B**

lights up when the driver's door is opened. In some cases, the appearance of a warning light is accompanied by a message.

Depending on the vehicle, you can customise your instrument panel with the content and colours of your choice.

For vehicles fitted with a multimedia screen, refer to the equipment instructions.

For vehicles not fitted with a multimedia screen ➔ 1.159.



Charge level 20


The gauge indicates the level of energy remaining.

Reserve threshold

When the traction battery charge level reaches approximately 12%, the gauge

and the 21 warning light appear in yellow, accompanied by a beep.

To optimise your range ➔ 2.20.




Immobilisation threshold imminent

When the charge level reaches approximately 6%, a beep sounds again and the gauge illuminates in red.


When the charge level reaches 5%, the range value is no longer displayed.

DISPLAYS AND INDICATORS (5/7)



Message indicating vehicle ready for driving 22

The “READY” message appears when the engine starts and disappears when the vehicle speed exceeds 3 mph (5 km/h).



Multimedia information 23

Depending on the vehicle, you can display information from the multimedia screen (the compass, telephone, navigation etc.).

Please refer to the multimedia instructions for further information.


DISPLAYS AND INDICATORS (6/7)



Driving style indicator 24 ➔ 2.16

Estimated range 25.


Total mileage recorder 26 ➔ 1.152



Remaining charge time 27

Traction battery charge rate 28

Trip computer 29 ➔ 1.149



Opening element warning light 30

Shows when a door, the tailgate or charging flap is open or not closed properly.

DISPLAYS AND INDICATORS (7/7)



Speedometer 31 and, depending on the vehicle, 33

Read your speed using the approved speedometer only **31**.

The indicator **33** is provided as an indication.

Available power level 32

The gauge indicates the engine power level that is currently available. This level may vary between "min" and "max" according to the external temperature conditions as well as the battery power available.




The "max" level represents the full capacity of the engine to deliver its maximum power.

Overspeed buzzer

Depending on the vehicle and country, the  warning light is displayed and a beep sounds. This beep sounds as soon as the vehicle is travelling at over 75 mph (120 km/h).

This warning light remains lit for as long as the vehicle is travelling at over 74 mph (120 km/h).

TRIP COMPUTER: general information (1/3)



Trip computer and warning system A or B

Depending on the vehicle, this includes the following functions:

- distance travelled;
- journey settings;
- information messages;
- operating fault messages (connected to the  warning light);
- warning messages (connected to the **STOP** warning light);
- vehicle settings customisation menu
→ 000.


All these functions are described on the following pages.




Vehicle fitted with trip computer A

The functions are distributed in zones **5**, **6**, **7**, and **8**. The location of the zones differs depending on the style selected.

Press the **1** switch to browse between menus and select functions by repeatedly pressing switch **2** or **3**, then if necessary use the **4** switch to confirm "OK".



TRIP COMPUTER: general information (2/3)



Vehicle fitted with trip computer **B**

Press the **1** switch as many times as required to reach the "Vehicle" tab.

Press repeatedly using the **2** or **3** control, then if necessary use the **4** switch to confirm "OK".

Selections

(the display depends on the vehicle equipment and country)


From the vehicle tab:

- a) journey settings:
 - average energy consumption since the last reset and current energy consumption;
 - distance travelled since the last reset and average speed.
- b) reset the tyre pressure;
- c) time (depending on the vehicle);
- d) service interval;
- e) only when stationary, vehicle settings customisation menu ➔ 1.159.

From the message tab:

- f) trip log, operating faults and information message readout.

TRIP COMPUTER: general information (3/3)



Resetting the journey parameters (reset button)

With one of the trip parameters selected as the display, press and hold the **4** switch "OK" until the display resets to zero.

Automatic resetting of the journey parameters

Resetting occurs automatically when the maximum value of any of the parameters is exceeded.

Reading energy consumption values

Some vehicle equipment items consume energy: the energy consumed by the vehicle may therefore differ from the energy consumed on the electric counter.

Interpreting some of the values displayed after resetting

Average energy consumption and speed are all the more stable and meaningful the greater the distance travelled since the last reset.

Resetting the estimated range

After a full recharge of the traction battery, you can select two types of resetting: manual or automatic.

Manual reset

Select one of the trip settings, press and hold switch **4** OK to reset the range.

Automatic reset

The range is automatically reset at the end of a full recharge of the traction battery to a value calculated based on the energy consumption since the last reset.

Some on-board computer information appears on the navigation system display.

The trip settings mileage recorder is reset simultaneously in the on-board computer and the navigation system.


TRIP COMPUTER AND WARNING SYSTEM: journey parameters (1/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.

| Examples of selections | Interpreting the display selected |
|---|--|
| <p>Consumption</p> <p> + 13,4 kW</p> <p> 12,8 kWh/100</p> | <p>a) Trip settings.</p> <p>→ Current energy consumption.</p> <p>→ Average energy consumption. The value is displayed after having travelled at least 400 metres since the last reset.</p> |
| <p>Journey</p> <p>42,2 km/h</p> <p>1284,7 km</p> | <p>→ Average speed since the last reset. The value is displayed after driving 400 metres.</p> <p>→ Distance travelled since the last reset.</p> |

TRIP COMPUTER AND WARNING SYSTEM: journey parameters (2/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.

| Examples of selections | Interpreting the display selected |
|--|--|
|  | <p>→ b) Tyre pressure reset ➔ 2.23</p> |
|  | <p>→ c) Clock</p> |

TRIP COMPUTER AND WARNING SYSTEM: journey parameters (3/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.

| Examples of selections | Interpreting the display selected |
|---|---|
| <p>Service in 1,210 miles or 3 months</p> | <p>d) Service interval.</p> <p>Distance remaining until the next service (displayed in miles/kilometres), then when the service nears, several scenarios are possible:</p> <ul style="list-style-type: none">– range less than 930 miles (1,500 km) or one month: the message “Service Due in” is displayed accompanied by the distance or the time;– when a service is due, the message “Service Due in” is displayed accompanied by the nearest term (distance or time);– range equal to 0 miles (0 km) or date of service reached: the message “Service Required” is displayed accompanied by the warning light . <p>The vehicle requires a service as soon as possible.</p> |



Resetting the display after the service in accordance with the maintenance schedule.

The service interval must only be reset after a service which complies with the recommendations in the maintenance schedule.

Special note: To reset the service interval, press and hold one of the display reset buttons for approximately 10 seconds until the display shows the mileage permanently.

TRIP COMPUTER AND WARNING SYSTEM: journey parameters (4/4)

The display of information shown below DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.

| Examples of selections | Interpreting the display selected |
|--|--|
|  Settings (OK) |  e) Vehicle settings personalisation menu ➔ 1.159. |
|  Tailgate open |  f) Trip log. Successive display: – information messages; – operating fault messages. |

TRIP COMPUTER AND WARNING SYSTEM: information messages

These can help in the vehicle starting phase, or give information about a selection or a driving status. Examples of information messages are given in the following pages.

| Examples of messages | Interpreting the display selected |
|------------------------------------|--|
| “Disconnect cable to start” | Indicates that the charging cord is still plugged into the vehicle. |
| “Parking Brake ON” | Indicates that the parking brake has been applied. |
| “Check connections” | Unplug, then plug in the vehicle. If the message still shows, this may be caused by the external charging conditions or by the home installation. |
| “Power cut while charging” | Indicates an electrical fault while charging. Restart charging. If this does not work, have the electrical installation checked. |
| “Earth insulation not appropriate” | Indicates a fault in the earthing of the charging terminal ➔ 1.9: have the electrical system checked by a qualified professional. |

TRIP COMPUTER AND WARNING SYSTEM: operating fault messages

These appear with the  warning light and mean that you should drive very carefully to an authorised dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.

They disappear when the display selection key is pressed or after several seconds and are stored in the computer log. The  warning light stays on. Examples of operating fault messages are given in the following pages.

| Examples of messages | Interpreting the display selected |
|---------------------------------|--|
| «WARNING: Check Airbag» | Indicates a fault in the restraint system in addition to the seat belts. In the event of an accident, it is possible that they may not be triggered. |
| «Check vehicle» | Indicates a fault on one of the pedal sensors or in the 12 V battery management system. |
| «WARNING: Check Braking System» | Indicates wear or the need to check the braking system. |
| «Check Vehicle plug» | Indicates overheating at the vehicle-side charging socket. Wait for about 20 minutes and try again. If this does not work, contact an authorised dealer. |
| «Check Electric System» | Indicates a fault in the traction system. |
| “WARNING: Check SOS Call” | Indicates a fault in the emergency call system. |
| «Battery charging impossible» | Indicates a fault on the traction battery recharge system. |

TRIP COMPUTER AND WARNING SYSTEM: warning message

These appear with the **STOP** warning light and require you to stop immediately, for your own safety, as soon as traffic conditions allow. Stop your engine and do not restart it. Call an approved Dealer.

Examples of warning messages are given in the following pages. Note: the messages appear on the display either individually or alternately (when there are several messages to be displayed), and may be accompanied by a warning light and/or a beep.

| Examples of messages | Interpreting the display selected |
|---------------------------|---|
| «WARNING: Braking System» | Indicates a fault in the braking system. |
| «WARNING: Power Steering» | Indicates a fault in the steering. |
| «Electric motor failure» | Indicates that the vehicle is losing power. |
| “Electric System Failure” | Indicates a fault in the electric system. |
| “ Puncture “ | Indicates that at least one wheel is punctured or severely underinflated. |

VEHICLE SETTINGS CUSTOMISATION MENU (1/3)



Depending on the vehicle equipment, this function allows you to activate/deactivate and adjust some of the vehicle's functions.

Vehicles fitted with a multimedia screen 1

Accessing the settings menu

Refer to the various multimedia instructions for information on accessing the settings.

Adjusting the settings

Select a menu then the function to be modified (the display depends on the vehicle equipment and country):

a) "Driving":

- Indicator volume;

b) "Access":

- Release driver's door;
- Lock doors during driving;
- Opening/closing in "hands-free" mode;
- Remote locking/Approach unlocking;
- Distance locking sound;
- Silent mode;
- Automatic locking;

c) "Wiping and lighting":

- Follow-me-home lighting;
- Wiping in reverse;
- Automatic front wiping;
- Wiping after washing;

d) "Welcome":

- External welcome;
- Automatic fold-out of mirrors;
- Interior welcome;
- Courtesy light auto mode.

Depending on the function, select:


- "ON" or "OFF" to activate or deactivate,
- or
- a duration to adjust the time the lights are switched on (for the "Follow-me-home lighting" function for example).

Please refer to the multimedia instructions for further information.



For safety reasons, carry out any adjustments when the vehicle is not being driven.

VEHICLE SETTINGS CUSTOMISATION MENU (2/3)



Vehicles not fitted with a multimedia screen

Accessing the settings menu on display 2

With the vehicle stopped, press the **3** switch as many times as required to reach the "Vehicle" tab; Press repeatedly on the **4** or **5** switch to access the "Settings" menu, then confirm by pressing **6** "OK".

Adjusting the settings

Navigate using the **4** or **5** control to select the function to be modified and press **6** "OK" to confirm (display may vary according to vehicle equipment and country):

a) "DASHBOARD":

- Language;
- Unit;
- Style;
- Colour;

b) "VEHICLE":

- Rear windscreen wipping in reverse gear;
- Automatic windscreen wipping;
- Front/rear drip wiping function;
- External welcome;

c) "PARKING ASSIST":

- Beep sound volume;

d) "DRIVING ASSIST":

- Lane departure warning sound volume;
- Lane departure warning sensitivity;
- Lane departure warning vibration;
- Lane keeping assist sensitivity;
- Blind spot warning;
- Active braking sensitivity;
- Advanced safety;
- Overspeed warning;
- Distance warning;

e) "LIGHTING":

- Courtesy light auto mode;
- Automatic follow-me-home lighting;
- Follow-me-home lighting: XX seconds;

f) "ACCESS":

- Lock doors during driving;
- Opening/Closing in "hands-free" mode;
- Unlock the driver's door only;
- Automatic re-locking;
- Silent locking;
- Automatic opening/closing;
- Automatic fold-out of mirrors;

g) "RESET".



function activated



function deactivated

VEHICLE SETTINGS CUSTOMISATION MENU (3/3)



To exit the menu, press **4** or **5** to access "BACK" and confirm by pressing **6** "OK". It may be necessary to carry out this operation more than once.

Once a line has been selected, press **6** "OK" to adjust the function.

If you select either "PARKING ASSIST" then "VOLUME", or "DASHBOARD" then "LANGUAGE", you will have to make a further selection (sound volume of the parking distance control or instrument panel language). In this case, make your selection and confirm it by pressing "**6** OK", the selected value is shown by a in front of the line.

The vehicle settings personalisation menu cannot be used when driving. At a speed exceeding 12 mph (20 km/h), the instrument panel display switches automatically back to trip computer and warning system mode.


CLOCK AND EXTERIOR TEMPERATURE (1/2)



Vehicles fitted with a multimedia screen

The time and exterior temperature are displayed on the multimedia screen **1**.

Please refer to the multimedia instructions for further information.




Vehicles not fitted with a multimedia screen

Press the **2** switch as many times as required to reach the "Vehicle" tab.

Repeatedly press control **3** or **4** to set the **6** clock.

Press and hold switch **5** "OK" until the time display flashes.



Set the clock using control **3** or **4**, then press switch **5** "OK" to confirm.

Set the minutes using control **3** or **4**, then press switch **5** "OK" to confirm.

CLOCK AND EXTERIOR TEMPERATURE (2/2)




If the power supply is cut (battery disconnected, supply wire cut, etc.), the clock must be reset.

We recommend that you do not adjust these settings while driving.


Exterior temperature indicator 7

Special note:

When the external temperature is between -3°C and +3°C, the °C figures flash (indicates risk of ice).



STEERING-WHEEL, POWER-ASSISTED STEERING (1/2)



Adjusting the steering wheel height and depth


Lower the lever **1** and position the steering wheel in the required position.

Then, raise the lever fully, beyond the point of resistance to lock the steering wheel.

Make sure that the steering wheel is correctly locked.



For safety reasons, only adjust the steering wheel when the vehicle is stationary.



Steering wheel heating (depending on vehicle)

This function heats the steering wheel **2**.

Operating principle

When the temperature is reached, the function regulates the temperature of the heated areas for approximately 30 minutes and then switches off automatically.

Activating the function

With the ignition on, press switch **3**, the indicator light in the switch lights up.

Deactivating the function

- Automatic:

The function switches off automatically after the regulation phase of approximately 30 minutes. The indicator light in switch **3** goes out.

Note: if the function has switched off automatically, press the switch **3** twice to reactivate it.

If switch **3** is not pressed again, the function will be reactivated the next time the ignition is switched on.

- Manually:

To deactivate the function during the regulation phase, press the switch **3**. The indicator light in switch **3** goes out.

STEERING-WHEEL, POWER-ASSISTED STEERING (2/2)

Power-assisted steering

Never drive with an inadequately charged battery.

Variable power-assisted steering

The variable power assisted steering system is equipped with an electronic control system which alters the level of assistance to suit the vehicle speed.

Steering is made easier during parking manoeuvres (for added comfort) while the force needed to steer increases progressively as the speed rises (for enhanced safety at high speeds).




Never switch off the ignition when travelling down-hill, and avoid doing so in normal driving (assistance is not provided).

Never leave the steering wheel on full lock when the vehicle is stationary.

With the engine switched off, or if there is a system fault, it is still possible to turn the steering wheel. The force required will be greater.

A noise may be heard when the steering wheel is moved quickly. This is normal.

REAR VIEW MIRRORS (1/4)



Exterior rear view mirrors

Adjustment

Select the rear view mirror using switch **2**, then use button **1** to adjust it to the desired position.

Heated door mirrors

Mirror de-icing is carried out at the same time as rear screen de-icing.
→ 3.5 → 3.9.



For safety reasons, carry out any adjustments when the vehicle is not being driven.

Folding rear view mirrors (depending on the vehicle)

The door mirrors automatically fold in when the vehicle is locked (switch **3** in position **B**).

In any case, you can make the door mirrors fold in (switch **3** in position **C**) or fold out (switch **3** in position **A**). Automatic mode is then deactivated. To reactivate it, set the switch **3** to position **B**.

Welcome and goodbye function (depending on the vehicle)

Refer to the multimedia instructions to access the welcome and goodbye function.

Activate or deactivate the function by selecting (ON or OFF).

Depending on the selected choice, the door mirrors will fold out:

- when the ignition is next switched on (function deactivated);
- when the card is detected or the vehicle is unlocked (function activated).



Objects observed in the door mirror glass are actually closer than they appear. For your safety, take this into account in order to correctly assess the distance before any manoeuvre.



The driver's exterior rear view mirror may have two clearly defined zones. Zone **E** shows what can normally be seen in an ordinary rear view mirror. Zone **D** increases rear side visibility.


REAR VIEW MIRRORS (2/4)



Manually folding door mirrors

To fold down the door mirror, pull it towards the door window until you hear a mechanical click.

To return the door mirror to its operating position, proceed in the reverse order. Ensure that it is correctly locked in position.




Special case

When the rear view mirror has been manually deployed or folded back, it is possible to reset it to a usage position.

To do this, press the **3** switch. A mechanical tapping noise can be heard from the door mirror.

If a tapping noise cannot be heard, press once again on **3** switch until the tapping noise can be heard from the door mirror.



Interior rear view mirror

Its position can be adjusted.

Rear view mirror with lever 4

When driving at night, to avoid being dazzled by the headlights of the vehicle behind, depress the little lever located behind rear view mirror **4**.

Rear view mirror without lever 4

The rear view mirror automatically darkens when you are being followed by a vehicle which illuminates you or in very bright lighting.

REAR VIEW MIRRORS (3/4)



Camera rear view system screen

The screen **5** can be positioned left to right and upwards and downwards
➔ 1.170.

55071




The camera's field of vision does not cover the entire area behind the vehicle, particularly the blind spot area **F**.




For safety reasons, carry out any adjustments when the vehicle is not being driven.

REAR VIEW MIRRORS (4/4)



Wide angle rear view mirror 7 (depending on the vehicle)

Lower the sun visor **6** to access the special mirror to increase side vision when manoeuvring.




The various zones seen by the driver are:

- **G** in the wide-angle rear view mirror;
- **H** via the front passenger window;
- **I** in the exterior rear view mirror.

CAMERA REAR VIEW (1/4)



55070



55069

When the ignition is switched on, the **2** screen on the roof centre console displays the view behind the vehicle that is transmitted by the camera **1**.

Note: the screen **2** can be positioned left to right or top to bottom.

De-icing the rear camera

In cold weather, this function enables rapid electrical de-icing of the camera.

De-icing is carried out simultaneously with electrical rear view mirror de-icing
► 3.5 ► 3.9.

Make sure that the **1** camera is not obscured (by dirt, mud, snow, condensation etc.).




This function is an additional aid. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

CAMERA REAR VIEW (2/4)

55071



Operation

The camera's field of vision does not cover the entire area behind the vehicle, particularly the blind spot area **A**.




Switching off the function

The display switches off:

- at least two minutes after the ignition is switched off;
- immediately after locking the vehicle.

55072



Special features related to the reverse gear

When the reverse gear is engaged, the camera located on the rear-end door displays the area to the rear of the vehicle. ➔ 2.129.


Vehicles fitted with a multimedia screen 3

When the vehicle is reversing, consider the images transmitted by the rear view camera (multimedia screen) in addition to the information available through the rear view mirror as there remains a rear view blind spot **A** ➔ 2.129.

Objects which appear on the edge of screen **2** may be deformed.

In very bright light (snow, vehicle in sunshine, etc.), the camera view may be partially disturbed.

In low brightness or poor weather, the image on the screen may be distorted.



Adjusting the display and the camera

Press the **4** button once to access the settings menu.

Repeatedly press the **4** button to scroll through the setting options until you reach the desired setting option.

Use the **5 “-”** and **6 “+”** buttons to adjust or activate/deactivate the desired setting.

Selecting the settings:

- a) adjusting the brightness;
- b) adjusting the vertical viewing angle;
- c) adjusting the horizontal viewing angle;
- d) activating/deactivating automatic adjustment of the vertical angle according to the vehicle speed;
- e) depending on the vehicle, activating/deactivating the reversing camera display;
- f) reset, to reset the default settings.

Exit the settings menu:

- automatically after approximately five seconds and without pressing any buttons;
- or
- by pressing the **5 “-”** or **6 “+”** buttons on the “**X**” tab.

Note: the vertical angle will not be automatically adjusted according to the vehicle speed if the vertical viewing angle has been set to the maximum.


Each time the vehicle is started, the function returns to the settings saved at the last engine stop.




For safety reasons, carry out any adjustments while the vehicle is stationary.

Adjust the field of vision for the system and the door mirrors before driving the vehicle (especially after changing the vehicle load).


CAMERA REAR VIEW (4/4)



55689



55687



55688

Special feature


When the vehicle is reversing, on vehicles not equipped with the multimedia system, when the rear door is opened or incorrectly closed the warning light **B** appears on the display **7**.

Operating faults

If the system detects an operating fault, the warning light **C** appears on a black background on the screen **2** or, depending on the vehicle, on the display **7** for the reversing camera. This may be caused by a fault affecting the camera or screen (clearness, fixed image, delayed communication etc.).

If the warning light **C** continues to appear on a black background, please consult an approved dealer.

AUDIBLE AND VISUAL SIGNALS



Horn

Press the steering wheel boss **A** to activate the horn.

Headlight flasher


Pull stalk **1** towards you then release it to flash the headlights.

Direction indicators

Move the stalk **1** in the same direction as you want to move the steering wheel.

One-touch mode

Briefly shift the stalk **1** upwards or downwards, not exceeding the point of resistance, then release it: the stalk will return to its original position and the direction indicator light concerned will flash three times.




Hazard warning lights


Press switch **2**.

This switch activates all four direction indicators and the side indicator lights simultaneously. It must only be used in an emergency to warn drivers of other vehicles that you have had to stop in an area where stopping is prohibited or unexpected, or that you are obliged to drive under special conditions.

EXTERIOR LIGHTING AND SIGNALS (1/6)



55023



58144

Side lights

Turn ring **2** until the symbol is opposite mark **3**.

This indicator light on the instrument panel comes on.

Daytime running lights function

The daytime running lights come on automatically with no action on stalk **1** when the engine is started, and they go off once the engine is switched off.



Dipped beam headlights Manual operation

Turn ring **2** until the symbol is opposite mark **3**. This indicator light on the instrument panel comes on.


Automatic operation (depending on the vehicle)

Turn the ring **2** until the **AUTO** symbol is opposite the mark **3**: with the engine running, the dipped beam headlights switch on or off automatically depending on the brightness of the light outside, without any action on the stalk **1**.

Depending on the vehicle, the dipped beam headlights will appear automatically after several sweeps of the windscreen wiper blades.



Before driving at night, check that the electrical equipment is operating correctly and adjust the headlight beams (if your vehicle is not carrying its normal load). ➔ 1.181. As a general precaution, check that the lights are not obscured (by dirt, mud, snow or objects being transported).



55023

During deactivation of the main beam headlights, the dipped beam headlights return to their original position.



Automatic main beam headlights

Depending on the vehicle, this system switches the main beam headlights on and off automatically. It uses a camera located behind the interior rear-view mirror to detect vehicles that are being followed and those coming in the opposite direction.



Main beam headlights

With the engine running and the dipped beam headlights lit, push stalk **1**. This indicator light on the instrument panel comes on. To return to the dipped headlight position, pull stalk **1** towards you again.

“Raise lights during driving” function

(depending on the vehicle)

When the main beam headlights are activated, the “Raise lights during driving” function improves driver visibility by automatically raising the dipped beam headlight and the main beam headlights.

The main beam headlights come on automatically if:

- exterior light is weak;
- no other vehicles or lighting are detected;
- the vehicle speed is above approximately 25 mph (40 km/h).

If any of the above conditions are not fulfilled, the system switches to dipped beam headlights.

Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).

To activate automatic main beam headlights:

- turn the ring **2** until the **AUTO** symbol is opposite the mark **3**;
- push the stalk **1**.




Warning light  comes on the instrument panel.

The system may encounter difficulties under certain conditions, including:

- extreme weather conditions (rain, snow, fog, etc.);
- obstruction in front of the windscreen or camera;
- when a following or oncoming vehicle has weak or hidden lighting;
- incorrect settings for the front headlights;
- reflective systems;
- ...

EXTERIOR LIGHTING AND SIGNALS (3/6)



55023

Operating faults

When the message “Check Automatic Lighting” appears on the instrument panel, the system is deactivated. Consult an approved dealer.



Automatic main beam headlights (continued)

To deactivate automatic main beam headlights:

- turn ring 2 to a position other than **AUTO**;
- or
- pull the stalk 1.

Warning light goes out on the instrument panel.

Note: the main beam headlights will be activated upon deactivation of the automatic main beam headlights function.



Using the portable navigation system at night in the windscreen area below the camera may disturb the operation of the “automatic main beam headlights” system (risk of reflection on the windscreen).



The “automatic main beam headlights” system should under no circumstances be used to replace driver attention and responsibility with regard to vehicle lighting and adapting to light, visibility and traffic conditions.



55023

Welcome and goodbye function

(depending on the vehicle)

Once the function is activated, the daytime running lights and the rear side lights will light up automatically upon detection of the card or when the vehicle is unlocked.

They switch off automatically:

- approximately one minute after lighting up;
- when starting the engine based on the position of the lighting stalk;
- or
- upon locking the vehicle.

Activating/deactivating the function

For activation or deactivation of the external reception, refer to the multimedia manual.

Select “ON” or “OFF”.

Switching off the lights

The lights will go out automatically when the engine is switched off, the driver's door is opened or the vehicle is locked. In this case, the next time the engine is started the lights will be switched back on according to the position of the ring 2.

Note: if the fog lights are lit, the lights are not switched off automatically.

Lights-on reminder buzzer


If the lights are on after the engine is switched off, a warning beep sounds when the driver's door is opened to warn you that the lights are still on.

Operating faults

When the message “WARNING: Check Lighting” with warning light  is displayed and warning light  flashes on the instrument panel, this indicates that there is a lighting fault.

Consult an authorised dealer.

EXTERIOR LIGHTING AND SIGNALS (5/6)



55023

With the engine lights switched off, the 2 ring in **AUTO**, pull the lever **1** towards you: the side lights and dipped beam headlights will switch on for approximately 30 seconds along with the  and  warning lights on the instrument panel.


To increase this duration, you may pull the stalk up to four times (total time restricted to approximately two minutes). The message "Follow-me Home for ___" along with the time the lights will be on for is displayed on the instrument panel to confirm this action. You can then lock your vehicle.

To switch off the lights before they go out automatically, turn ring **2** to any position, then return it to position **AUTO**.

"See-me-home lighting" function

This function enables you to briefly switch on the side lights and dipped beam headlights (e.g. to provide light when opening a gate).

EXTERIOR LIGHTING AND SIGNALS (6/6)



55023

Front fog lights (depending on the vehicle)

Turn centre ring **4** on the stalk **1** until the symbol faces mark **3**, then release it.

Operation of the fog lights depends on the exterior lighting position selected, and an indicator light will light up on the instrument panel.

Rear fog lights

Turn centre ring **4** on the stalk until the symbol faces mark **3**, then release it.

Operation of the fog lights depends on the exterior lighting selected, and an indicator light will light up on the instrument panel.

Do not forget to switch off the fog lights when they are no longer needed, to avoid inconveniencing other road users.

Switching off the lights

Turn the centre ring **4** again until the **3** symbol is opposite the symbol for the fog lights. The corresponding indicator light on the instrument panel goes out.

The rear fog lights switch off when the exterior lights are switched off.

Cornering lights (depending on vehicle)

When driving in forward gear, with the vehicle speed below approximately 25 mph (40 km/h), whenever the dipped beam headlights are on: under certain conditions (the steering wheel at an angle, the indicator lights on etc.), when turning a corner one of the front fog lights will switch on to light the inside of the bend.


When reverse gear is engaged and the dipped beam headlights are on the two front fog lights illuminate automatically.

Note: when shifting from reverse gear into forward gear (for example during a parking manoeuvre), the two fog lights are activated until the vehicle exceeds approximately 6 mph (10 km/h).

When driving in fog or snow, or when transporting objects which are higher than the roof, the headlights do not come on automatically.

Switching on the fog lights remains the responsibility of the driver: the indicator lights on the instrument panel inform you whether the fog lights are lit (indicator light on) or not (indicator light not on).

HEADLIGHT BEAM ADJUSTMENT (1/2)



Switch **A** is used to adjust the height of the headlight beams according to the load.

With the dipped beam headlights lit, press or lift switch **A** as many times as is necessary to select the required position on the instrument panel.


Note: depending on the vehicle, when the engine is started, the position selected is displayed on the instrument panel for approximately 30 seconds and for 5 seconds each time switch **A** is pressed.

| Examples of positions for adjusting control A according to the load | | | | |
|--|--------------|------------------|-------------------------|-------------------------|
| Van version | | Estate versions | | |
| Standard chassis | Long chassis | Standard chassis | Long chassis (5-seater) | Long chassis (7-seater) |
| Driver alone or with front passenger | 0 | 0 | 0 | 0 |
| All seats occupied | - | - | 0 | 0 |
| Driver with passengers and luggage (or load) reaching the maximum permissible all-up weight | - | - | 1 | 1 |
| Driver without passengers and luggage (or load) reaching the maximum permissible all-up weight | 2 | 2 | 2 | 2 |

The table below gives some examples. In all cases, adjust control **A** according to the vehicle load so that the road can be seen and other drivers are not dazzled.

HEADLIGHT BEAM ADJUSTMENT (2/2)

When driving on the left in a lefthand drive vehicle (or vice versa), you must adjust your lights temporarily during your stay.



Temporary adjustment


Open the bonnet and identify the marking **B** next to one of the front headlight projectors.

Operating principle

Using a screwdriver or similar, turn the bolt **1** a half turn towards the - symbol to lower the beams.

Return to the original position once your trip is over: turn the bolt **1** by a half turn towards the + symbol to raise the beams.

WINDSCREEN WASH, WIPE (1/4)




Your vehicle is fitted with a front windscreen wiper equipped with a rain sensor

The rain sensor is located on the windscreen, in front of the interior rear-view mirror.

A single sweep

A short push will trigger one sweep of the wipers.

B stop



C automatic wiper function

When this position is selected, the system detects water on the windscreen and triggers the wipers at a suitable wiping speed. It is possible to change the triggering threshold and the time sweeps by turning ring 2:

- **F:** minimum sensitivity;
- **G:** maximum sensitivity.

The higher the sensitivity, the quicker the wipers will react and the faster the wipe.

When activating automatic wiping or when increasing sensitivity, one sweep of the blades is performed.

Note:

- the rain sensor is only intended as a driving aid. In the event of reduced visibility, the driver should manually activate the wipers. In foggy weather or during snowfalls, wiping is not automatically triggered and remains under the driver's control;
- in the event of temperatures below zero, automatic wiping is not activated when the vehicle is started. It is automatically activated as soon as the vehicle exceeds a certain speed (approximately 5 mph (8 km/h));
- do not activate automatic wiping in dry weather;
- fully de-ice the windscreen before activating automatic wiping;
- when washing the vehicle under a roller type car wash, return the ring 1 to the **B** position to deactivate automatic wiping.


WINDSCREEN WASH, WIPE (2/4)

Operating faults

In the event of a malfunction of the automatic wiping, the wiper is set to intermittent wiping. Contact an authorised dealer.

The operation of the rain sensor can be disturbed in the event of:

- damaged wiper blades; a screen of water or traces left by a blade in the sensor's detection zone may increase the response time of the automatic wiper, or increase the wiping frequency;
- a windscreens with any chip or crack level with the sensor, or a windscreens covered in dust, dirt, insects, ice, the use of washing wax and water-repellent chemicals; the automatic wiping will be less sensitive, or even unresponsive.



D slow continuous wiping

E fast continuous wiping

Special note

When driving the vehicle, the wiping speed slows down whenever the vehicle stops. For example, fast wiping speed will slow to normal wiping speed. As soon as the vehicle moves off, wiping will return to the speed originally selected.

If stalk 1 is operated, it overrides and cancels the automatic function.

Precautions

- In the event of ice, check whether the blades are stuck to the windscreens before operating the wiping mechanism. If you activate the wipers while the blades are stuck down with ice, you may risk damaging both the blade and the wiper motor.
- Do not activate the wipers on a dry screen. This will lead to premature wear or damage to the blades.

WINDSCREEN WASH, WIPE (3/4)

Specific front wiper position (service position)

This position enables the blades to be lifted to remove them from the windscreens.


This can be useful:

- to clean the blades;
- to release the blades from the windscreens in winter;
- to replace the blades ➔ 5.38.

With the ignition on and the engine off, lift the stalk **1** twice to position **A** (single sweep). The blades stop slightly away from the bonnet.

To return the blades to the lowered position, with the ignition on, ensure that the wipers have folded down onto the windscreens, then move the stalk **1** to position **A** (single sweep).

Before switching on the ignition, place the wipers on the windscreens. Otherwise, there may be a risk of damage to the bonnet or the wipers when they are switched on.




Before any action involving the windscreens (washing the vehicle, de-icing, cleaning the windscreens, etc.) return stalk **1** to position **B** (stop).

Risk of injury and/or damage.

In the event of obstacles on the windscreens (dirt, snow, ice etc.), clean the windscreens (including the central area located behind the interior rear view mirror) before starting the wipers (risk of motor overheating).

If an object is preventing a blade from moving, it may stop functioning. Remove the obstacle and reactivate the wiper using the wiper stalk.

WINDSCREEN WASH, WIPE (4/4)



Windscreen washer

With the ignition on, pull stalk 1 then release.

A longer pull will trigger, in addition to the windscreen washer, two sweeps of the wipers followed, a few seconds later, by a third.

On vehicles fitted with a multimedia screen, you can choose to activate or disable the third sweep of the blades.

→ 1.159

Note: in temperatures below zero, the washer liquid may freeze on the windscreen, reducing visibility. Heat the windscreen using the demister control before cleaning.

Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:

- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In all cases, replace it as soon as it begins to lose efficiency: approximately once a year. → 5.38.

Precaution for using the wipers


- In freezing or snowy weather conditions, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.



When working in the engine compartment, ensure that the windscreen wiper stalk is in position B (stop).

Risk of injury.

REAR SCREEN WASHER, WIPER (1/2)



55022

To stop the operation, pivot ring **3** again.

Note:

When washing using a roller type car wash, return the ring **3** on the stalk **1** to the stop position to deactivate automatic wiping.

Follow usage recommendations.



Rear screen wiper

With the ignition on, rotate the ring **3** on the lever **1** until the symbol is opposite the reference point **2**:

- **stop**;
- **intermittent wiping**;
The wipers will pause for several seconds between sweeps. Wiping frequency varies with vehicle speed;
- **slow continuous wiping**.

Do not use the wiper arm to open or close the tailgate.



Before any action involving the rear screen (washing the vehicle, de-icing, cleaning, etc.) return stalk **1** to the stop position.

Risk of injury and/or damage.

Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:

- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In all cases, replace it as soon as it begins to lose efficiency: approximately once a year. ➔ 5.38.

Precaution for using the wipers

- In freezing or snowy weather conditions, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.

REAR SCREEN WASHER, WIPER (2/2)

Activation/deactivation of the rear screen wiper

Engaging reverse gear triggers intermittent wiping (if the front wipers are in operation). If your vehicle is equipped with a vehicle settings customisation menu, you can opt to activate or deactivate this function. ➔ 1.159.

In the event of obstacles present on the rear window (dirt, snow, etc.), the wiper will try to sweep away all the obstacles. If an obstacle prevents the blade from moving, it can be stopped. Remove the obstacle, wait for around 30 seconds and reactivate the wiper using the wiper stalk.

Precautions

- In the event of ice, check that the blades are not stuck to the windscreen before operating the wipers. If you activate the wiper while the blade is blocked by ice, you risk damaging both the blade and the wiping motor.
- Do not operate the wipers on a dry screen. This will lead to the premature wear or damage to the blades.

55022



Rear screen wash/wipe

 With the ignition on, push and hold stalk 1, then release.


Holding the stalk for longer will trigger (in addition to the windscreen washer) two sweeps of the wipers followed, a few seconds later, by a third (drip wiping function).

When the stalk is released, it returns to the rear wipe position.

Section 2: Driving

| | |
|---|-------|
| Starting, stopping the engine | 2.2 |
| Gear control | 2.6 |
| Gear lever, Handbrake | 2.11 |
| Electronic parking brake | 2.12 |
| Eco-driving | 2.16 |
| Vehicle range: advice | 2.20 |
| Environment | 2.22 |
| Tyre pressure monitoring system | 2.23 |
| Driver correction devices and aids | 2.28 |
| Lane departure warning | 2.34 |
| Lane Keeping Assist | 2.39 |
| Blind spot warning | 2.45 |
| Safe distance alert | 2.55 |
| Advanced Safety | 2.59 |
| Fatigue detection warning | 2.76 |
| Detection of road signs | 2.78 |
| Speed limiter | 2.82 |
| Cruise control | 2.86 |
| Stop and Go adaptive cruise control | 2.91 |
| Highway and Traffic Jam Companion | 2.105 |
| Parking distance control | 2.121 |
| Reversing camera | 2.129 |
| Assisted parking | 2.133 |
| Overspeed function | 2.138 |
| Emergency call | 2.139 |
| “Vehicle data confidentiality” mode | 2.142 |

STARTING, STOPPING THE ENGINE: vehicle with key



**“Stop/steering lock applied”
position “LOCK” 0.**

To lock: remove the key and turn the steering wheel until the steering column locks.

To unlock: turn the key and the steering wheel slightly.

“On” position “ON” 2

The ignition is switched on: Any accessories (radio etc.) can be used.

“Start” position “START” 3

Starting the engine

- Press the brake pedal;
- position the gear lever to the position **P** only ;
- turn the key to the “**START**” position **3** then release it.

The “**READY**” message appears on the instrument panel, accompanied by a beep. As soon as the “**READY**” message stops flashing and the beep stops, the vehicle is ready to drive.



Driver’s responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.



Never switch off the ignition before the vehicle has stopped completely. Once the engine has stopped, the brake servo, power-assisted steering etc., and the passive safety devices such as the airbags and pretensioners will no longer operate.

The vehicle can only be started if the charging cord is unplugged from the vehicle.

STARTING, STOPPING THE ENGINE: vehicle with card (1/3)


55939



56785



57940



The card must be in detection zone **1** or, depending on the vehicle, in detection zone **2**.

To start:

- depress the brake pedal;
- press button **3**. The “READY” message appears on the instrument panel, accompanied by a beep.

The message disappears when the vehicle speed is above approximately 3.1 mph (5 km/h).

Special features

- If one of the starting conditions is not applied, the message “Press Brake + START” is displayed on the instrument panel;
- in some cases, it will be necessary to move the steering wheel whilst pressing the start button **3** to help unlock the steering column; the message “Turn Steering Wheel + START” will warn you of this;

Depending on the vehicle, you may have a digital key that offers all the functions of the card.

However, if a card has been left inside the vehicle and the doors have been locked with a digital key, all of the card's functions will be inhibited.

For more information ➔ 1.45

The vehicle can only be started if the charging cord is unplugged from the vehicle.

STARTING, STOPPING THE ENGINE: vehicle with card (2/3)



“Hands-free” starting with the tailgate open


In this case, the card should not be located in the luggage compartment, to prevent the risk of loss.

Accessories function

(switching on the ignition)

Once you have gained access to your vehicle, you may use some of its functions (radio, navigation, wipers, etc.).


To use the other functions, with the card in the passenger compartment, press the **3** button without pressing the pedals.



Operating faults

In certain cases, the hands-free card may not work:

- the card battery is flat, the secondary 12 V battery is discharged, etc.;
- near to appliances operating on the same frequency as the card (monitor, mobile phone, video game, etc.);
- vehicle located in a high electromagnetic radiation zone.



The message “Place card on zone + START” appears on the instrument panel.

Press the brake pedal, then place the card **5** (button side) on the placement area marked by the **4** symbol. Press the **3** button to start the vehicle. The message goes out.

STARTING, STOPPING THE ENGINE: vehicle with card (3/3)



Conditions for stopping the engine

The vehicle must be at a standstill.

With the card in the vehicle, press the button **3**: the engine is stopped, the “**READY**” message disappears from the instrument panel and the parking brake is applied. The steering column is locked when a door is opened or the vehicle is locked.

If the card is no longer in the passenger compartment or if the card's battery is flat, when the vehicle is stationary and you try to switch the engine off, the message “**Keycard absent : press/hold START**” appears on the instrument panel: press button **3** for longer than three seconds. If the card is no longer in the passenger compartment, make sure you can retrieve it before pressing and holding the button. Without the card, you will not be able to restart the vehicle.

With the engine switched off, any accessories being used (radio, etc.) will continue to function for approximately 10 minutes.

When the driver's door is opened, the accessories stop working.



Never switch off the ignition before the vehicle has stopped completely. Once the engine has stopped, the brake servo, power-assisted steering etc., and the passive safety devices such as the airbags and pretensioners will no longer operate.



When you leave your vehicle, especially if you have your card with you, check that the engine is completely switched off.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.


RISK OF DEATH OR SERIOUS INJURY.

GEAR CONTROL (1/5)



Selector lever 1

- P: park
- R: reverse
- N: neutral
- D: forward
- B: regeneration mode. Three levels of engine brake, **B1** (lowest) to **B3** (highest). **B2** is the default
- 2: gear or position display area



GEAR CONTROL (2/5)



Note:

- the selector lever **1** may exit position **P, R, N, D, B** if the key is in the “**ON**” position ➔ 2.2 or, for vehicles fitted with a “hands-free” card, in “Accessories function” mode ➔ 2.3;
- the selector lever **1** cannot switch from position **P** to another position if the key is in the “**LOCK**” position ➔ 2.2 and if the key is removed or, on vehicles equipped with a “hands-free” card, if the ignition is switched off ➔ 2.3.

Operation

With the gear lever **1** in **P** position, start the engine and the “**READY**” message is displayed on the instrument panel.

To exit **P** position, you must press the brake pedal (the  warning light is displayed).

With your foot on the brake pedal (warning light  on the display goes out), move the lever out of position **P**.

Only move the gear lever **1 to position **D** or **R** when the vehicle is stationary, with your foot on the brake and the accelerator pedal released.**

GEAR CONTROL (3/5)

Driving in mode D

Put the lever in position **D**. In most traffic conditions, you will not have to touch the gear lever.

To select reverse gear

With the vehicle stationary and the engine running, depress the brake pedal and move the lever to position **R**.

The reversing lights will switch on as soon as reverse gear is engaged (if the ignition is on) and also the reversing camera (depending on the vehicle)
→ 2.129.

Driving in mode B

By releasing the accelerator, the vehicle uses regenerative braking to slow down the vehicle. Thus the electric motor generates an electrical current which enables the traction battery to be recharged. You can use this mode to manually set the regenerative level higher (**B3**) or lower (**B1**).

Note: with position **D**, **B** or **R** engaged, when the vehicle is stationary, it sets off at a low speed as soon as you release the brake pedal (without pressing the accelerator pedal).

Moving from position D to B


Move the lever to position **D**, move the lever to the right to position **B**.

Position **D** corresponds to the regenerative level **B2**.

B2 is the default level.

To select level **B1**, push forwards. To select level **B3**, push backwards.

53565



The instrument panel display indicates the position **B** engaged along with the regenerative braking level.

In position **B**, regenerative braking may be reduced if the battery is cold and fully charged.

Moving from position B to D

With the lever in position **B**, move the lever to the left to position **D**.

GEAR CONTROL (4/5)

Parking the vehicle

When the vehicle is stationary, move the lever to position **P** while keeping your foot on the brake pedal: the reducer and drive wheels will be mechanically locked.

Note: with position **B** engaged (**B1**, **B2** or **B3**), you **must** shift the lever to position **D** before engaging position **P**.

Ensure that the electronic parking brake is engaged.

Special case

If parking on a slope, it is advisable to apply the parking brake **before** releasing the parking brake and engaging position **P**.



In the event of an impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture), this may result in damage to the vehicle (e.g.: twisted axle), the electrical circuit or the traction battery.

Do not touch the circuit elements or any fluids or liquids.

To prevent any risk of accident, have your vehicle checked by an authorised dealer.

Risk of serious injury or electric shock and risk to life.



The **N** position of the lever does not mechanically lock the drive wheels, make sure it is immobilised before leaving the vehicle.

P position must only be engaged when the vehicle is stationary.


GEAR CONTROL (5/5)

Operating faults

- **When driving**, if the “WARNING: Check Gearbox” message appears on the instrument panel, it indicates a fault.

Contact your approved Dealer as soon as possible;

- **When driving**, if the message “WARNING: Gearbox Overheating” appears on the instrument panel, stop as soon as possible to allow the gear control to cool down and wait for the message to disappear.



Vehicle repairs

➔ 5.40

When setting off, if the lever is stuck in **P** when you press the brake pedal (e.g. battery fault), it is possible to manually release the lever to unblock the drive wheels. To do this, unclip the base of the gaiter and press the **4** button while simultaneously pressing the **3** button on the lever to unlock the lever and shift to position **N**.

Contact an authorised dealer as soon as possible.



For safety reasons, do not switch off the ignition before the vehicle has come to a complete standstill.

GEAR LEVER, HANDBRAKE



Handbrake

To release:

Pull lever **2** up slightly, press button **1** and then lower the lever to the floor.

The warning light **((P))** on the instrument panel will go out.

The red warning light on the instrument panel will come on if you are driving with an incorrectly released handbrake.

To apply:

Pull lever **2** upwards. Check that the vehicle is immobilised. The warning light **((P))** on the instrument panel will come on.

The vehicle can only be started if the charging cord is unplugged from the vehicle.



In the event an impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture) this may result in damage to the vehicle (e.g.: twisted axle), the electrical circuit or the traction battery.

Do not touch the circuit elements or any fluids or liquids.

To prevent any risk of accident, have your vehicle checked by an authorised dealer.

Risk of serious injury or electric shock and risk to life.



Make sure that the handbrake is fully released when driving (red indicator light off), otherwise overheating, or even damage, may occur.



When stationary and depending on the slope and/or vehicle load, it may be necessary to pull up the handbrake at least two extra notches and move the gear lever to position **P**.

ELECTRONIC PARKING BRAKE (1/4)




Assisted operation

Applying the electronic parking brake

With the vehicle stationary, the electronic parking brake can be used to immobilise the vehicle:

- by pressing the engine start/stop button 1 or by turning the ignition key to the 2 “ON 2” position);
- or
- when the driver's seat belt is unfastened;
- or
- when the driver's door is opened;



or

- when position P is engaged.

In all other instances, e.g. if the engine stalls, the electronic parking brake is not applied automatically. Manual mode must be used. For certain country-specific model versions, the assisted brake application function is not activated. Refer to the information on “Manual operation”.

To confirm that the electronic parking brake is applied, the message “Parking

Brake ON” is displayed, the (P) warning light appears on the instrument panel and the 3 warning light appears on the 4 switch.

After the engine is switched off, indicator light 3 goes out several minutes after the assisted parking brake has

been applied and indicator light (P) goes out when the vehicle is locked.



Before leaving the vehicle, check that the electronic parking brake is fully applied. Warning light 3 on switch 4 and warning light (P) on the instrument panel light up to show that the parking brake is applied but go out when the doors are locked.

ELECTRONIC PARKING BRAKE (2/4)

Assisted operation (continued)


Note: in some situations (electronic parking brake failure, manual release of the parking brake, etc.), a beep sounds and the message "WARNING: Apply Parking Brake" appears on the instrument panel to warn you that the electronic parking brake has been released.

- with the engine running: when the driver's door is opened;
- with the engine switched off (e.g. when the engine stalls): when a front door is opened.

In this case, pull and release switch **4** to apply the assisted parking brake.

Assisted release of the parking brake

The parking brake is released as soon as the vehicle is started and acceleration begins, or when shifting out of gear lever position **P**.




Manual operation

You can apply the electronic parking brake manually.

Manually applying the electronic parking brake

Pull switch **4**. Warning light **3** and warning light **(P)** on the instrument panel light up.



Manually releasing the electronic parking brake


Press the switch **1** without pressing the brake pedals or turn the key **2** to the "ON 2" position to switch on the ignition. Press the brake pedal then press switch **4**: indicator light **3** on the switch

and indicator light **(P)** displayed on the instrument panel go out.



Before leaving the vehicle, check that the electronic parking brake is fully applied. Warning light **3** on switch **4** and warning light **(P)** on the instrument panel light up to show that the parking brake is applied but go out when the doors are locked.

ELECTRONIC PARKING BRAKE (3/4)



Brief stop

To apply the electronic parking brake manually (when stopping at a red light, or stopping when the engine is running, etc.): pull and release the switch **4**. The brake is released as soon as the vehicle is started up again.

Special cases

To park on a slope or while towing a trailer, for example, pull switch **4** for a few seconds to gain the maximum braking.

- manually release the electronic parking brake (please see the information on “Manually releasing the electronic parking brake” on the previous page);
- depending on the vehicle, the parking brake is applied automatically. You will have to release it manually.

To park the vehicle without applying the electronic parking brake (if there is a risk of freezing, for example):

- switch off the engine by pressing the engine start/stop button **1** or by turning the ignition key **2**;
- engage any gear or the **P** position: the drive wheels will be mechanically locked by the driveshaft;
- release the driver’s seat belt;
- open the driver’s door;

ELECTRONIC PARKING BRAKE (4/4)



If the "Electrical fault" or "Check battery" or "WARNING: Braking System" message appears, you must immobilise the vehicle by engaging position **P** or by pulling the switch **4** for approximately 10 seconds.

If the conditions and the slope require it, chock the wheels of the vehicle.

Risk of loss of immobilisation of the vehicle.

Call an approved Dealer.



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.

For safety reasons, automatic release is deactivated when the driver's door is open or not shut properly and the engine is running (in order to prevent the vehicle from moving without the driver). The "Release Parking Brake Manually" message appears on the instrument panel when the driver depresses the accelerator.



Never leave your vehicle without re-engaging **P** position and switching off the engine. This is because when the vehicle is stationary with the engine running and a gear engaged, the vehicle may begin to move if you accelerate.

There is a risk of accidents.

Operating faults

- If there is a fault, the warning light illuminates on the instrument panel accompanied by the "Check Parking Brake" message and, in some cases, the warning light. Contact your approved Dealer straight away.
- If there is an assisted parking brake fault, the warning light comes on, along with the message "WARNING: Braking System", a beep and, in some cases, the warning light .

This means that you must stop as soon as traffic conditions allow.



It is therefore essential to immobilise the vehicle by engaging position **P**. Depending on the slope, chock the vehicle.

DRIVING ADVICE, ECO DRIVING (1/4)

Range is accredited according to a standard regulatory method. Identical for all manufacturers, this enables vehicles to be compared with one another.

Range in real time depends on vehicle usage conditions, equipment fitted and the user's driving style. To optimise range, please refer to the following advice.

Depending on the versions, you will be provided with functions which enable you to lower energy consumption:

- on the instrument panel:
 - the power meter;
 - the driving style indicator;
- on the multimedia screen:
 - data relating to your energy consumption;
 - an energy consumption graph;
 - scores based on your driving style;
 - ECO driving advice;
 - a route planner;
 - an ECO driving mode.



Power meter

(on the instrument panel)

The power meter gives the driver a real-time view of the vehicle's energy recovery or consumption.

Blue “Energy recovery” A usage zone

When driving, if you lift your foot off the accelerator pedal or apply the brake, the motor generates electrical current during deceleration, and this energy is used to slow down the vehicle and recharge the traction battery.

Optimum use zone 0

Indicates nil consumption.


Green “recommended consumption” B usage zone

The traction battery supplies the electrical energy required for the motor to move the vehicle.

“Consumption not recommended” white use zone C

Indicates high energy consumption.

DRIVING ADVICE, ECO DRIVING (2/4)



Driving style indicator 1 (depending on the vehicle)

Informs you about the driving style adopted in real time. This is shown by indicator light 1.

The more petals displayed on 1, the more your driving is flexible and economical.

If you regularly monitor this indicator, you will reduce your vehicle's fuel consumption.

Please refer to the multimedia instructions for further information.

DRIVING ADVICE, ECO DRIVING (3/4)



An overall rating from 0 to 100 is displayed to let you assess your eco driving performance. The higher the rating, the lower the energy consumption.

Eco advice is given to help improve your performance.

With your favourite journeys saved, you can compare your performance between trips and the performance of other vehicle users.

On the multimedia screen

Journey record

Once the engine is switched off, you will see "Journey record" displayed on the multimedia screen 2, enabling you to view information on your last journey.

This indicates:

- the general score;
- score evolution;
- distance without fuel consumption.

Please refer to the multimedia instructions for further information.

DRIVING ADVICE, ECO DRIVING (4/4)

ECO mode

ECO mode is a function which optimises energy consumption.

ECO mode enables you to limit the power and maximum speed.

Limiting acceleration enables low fuel consumption in urban and surrounding areas.


Activating the function

The function can be activated by pressing switch **3**.

The warning light **Eco** comes on on the instrument panel to confirm activation.

While driving, it is possible to leave the ECO mode temporarily in order to improve engine performance.

To do this, press the accelerator pedal firmly and fully.



ECO mode is reactivated when you take pressure off the accelerator pedal.

Disabling the function

The function can be deactivated by pressing switch **3**.

The warning light **Eco** goes out on the instrument panel to confirm deactivation.

With ECO mode on, the vehicle speed is limited to approximately 68 mph (110 km/h).

VEHICLE RANGE: recommendations (1/2)

In real usage, the range of an electric vehicle may vary depending on several factors over which you have partial control, which may make a considerable difference to the vehicle range.

These factors are:

- speed and driving style;
- type of road;
- heating level;
- tyres;
- use of electrical accessories;
- vehicle loading.

Furthermore, activating ECO mode enables the vehicle to automatically take charge of all energy consumers (engine power etc.) to reduce their consumption to the fullest possible extent ➔ 2.16.

34630



Speed and driving style

Driving at high speed will significantly reduce your vehicle's range.

Examples (at a steady speed):

- reducing the speed from approximately 80 mph (130 km/h) to 68 mph (110 km/h) allows you to save up to around 20% of fuel range;
- reducing your speed from approximately 56 mph (90 km/h) to 50 mph (80 km/h) allows you to save up to around 10% of fuel range.

A "sporty" driving style reduces your vehicle range: opt for a "lighter" driving style.

Advice:

- drive at a constant speed;
- keep an eye on the tools available for viewing road conditions (charge meter, current consumption, journey record, etc.) ➔ 2.16;
- adapt your driving style to avoid excessive energy consumption;
- favour power recovery: anticipate traffic changes by lifting your foot off the accelerator pedal or by braking gradually.

VEHICLE RANGE: recommendations (2/2)

57944



Road type

Do not try to maintain the same speed up a hill; accelerate no more than you would on the level. Keep your foot in the same position on the accelerator pedal.

34629



Heating levels


The use of heating or air-conditioning reduces vehicle range.

To maintain your vehicle range, you are recommended to select "programming" mode before using the vehicle ➔ 3.13.

Vehicle loading

Avoid pointlessly overloading your vehicle.

33395



Tyres

An under-inflated tyre increases energy consumption. Comply with the specified tyre pressures for your vehicle. When driving, use tyres made by the same manufacturer, with the same dimensions, type and structure as the original tyres. The use of non-regulation tyres significantly reduces vehicle range ➔ 4.8.

ENVIRONMENT

Your vehicle has been designed with respect for the **environment** in mind for its entire service life: during production, use and at the end of its life.

Manufacture

Your vehicle has been manufactured at an industrial site which uses a progress policy to reduce environmental impacts on rivers and natural areas (reduction of water and energy consumption, visual and noise pollution, atmospheric emissions and waste water, sorting and reusing waste).

Please make your own contribution towards protecting the environment too.

- Parts and vehicles at the end of their life must not be thrown away. They must be handed to a legal entity that complies with environmental standards.
- Worn parts replaced in the course of routine vehicle maintenance (vehicle battery, batteries, etc.) must be disposed of through dedicated collection points.
- To optimise the recycling of your vehicle at the end of its life, you can contact an authorised dealer or visit the manufacturer's website to be directed to collection points that guarantee respect for the environment complying with local laws.

Recycling

Your vehicle is 85% recyclable and 95% recoverable.

To achieve these objectives, many of the vehicle components have been designed to enable them to be recycled.


The materials and structures have been carefully designed to:

- allow these components to be easily removed and reprocessed by specialist companies;
- promote a circular economy (re-use, recycling, recovery, etc.)

This is particularly true for electrified vehicle batteries.

In order to preserve raw material resources, your vehicle also includes many parts made from recycled plastics or renewable materials.

TYRE PRESSURE MONITOR (1/5)



If the vehicle is equipped with the function, this system monitors the tyre pressure.

Operating principle

Each wheel (except for the emergency spare wheel) has a sensor in the inflation valve which periodically measures the tyre pressure.

The system displays the current pressures on the instrument panel **1** and alerts the driver in the event of insufficient pressure.

Resetting the standard level for the tyre pressures

This should be done:

- when the standard tyre pressure needs to be changed to adapt to usage conditions (empty, carrying a load, motorway driving, etc.);
- after swapping a wheel (however this practice is not recommended);
- after changing a wheel.


It should always be done after checking the tyre pressure of all four tyres when cold.

Tyre pressures must correspond to the current usage of the vehicle (empty, carrying a load, motorway driving, etc.).

If the wheels are swapped, the system must be reinitialised. Consult an approved dealer.

If the vehicle is equipped with a navigation system, depending on the vehicle, the reset procedure may also be carried out using the multimedia screen: please see the equipment instructions.

TYRE PRESSURE MONITOR (2/5)



Resetting procedure via the instrument panel 1

Ignition on, **vehicle stopped**:


- repeatedly tap the **5** switch as many times as necessary to reach the “**ve-
hicle**” tab ;
- briefly press the **2** or **3** switch to reach the “**Tyre Pressure**” page;

– press and hold (around 3 seconds) the button **4** to launch the reset. The flashing tyres followed by the messages “**Learning Tyre Pressures**” and then “**Tyres location in progress**” indicates that the reset request for the tyre pressure reference value has been acknowledged.

Reset can take several minutes of driving.

If the resetting is followed by short trips, the message “**Tyres location in progress**” can remain displayed after successive restarts.

Note: the standard tyre pressure cannot be less than that recommended and indicated on the door frame.



Resetting procedure via the multimedia screen 6

Please refer to the multimedia instructions for further information.



For your safety, the warning light  requires you to stop immediately as soon as traffic conditions allow.

TYRE PRESSURE MONITOR (3/5)

The table below shows the possible messages related to the tyre resetting procedure.

| Steps | Displays (depending on the vehicle) | Messages | Readings |
|-------|---|--------------------------------|--|
| 1 |  | Tyre pressure init. long press | With the ignition on and the vehicle stationary, start the resetting the pressure of all four tyres by pressing and holding the 4 OK switch. |
| 2 |  | Learning Tyre Pressures | The “---” quote marks in front of each wheel will flash to indicate that the system has registered the tyre pressure reset for all four wheels. |
| 3 |  | Tyres location in progress | <p>The “---” quote marks in front of each wheel will remain lit. This system resets the tyre pressure of all four tyres. You can now drive. The message may remain displayed during short journeys.</p> <p>Note: during the reset, tyre pressure monitoring remains in operation.</p> |
| 4 |  | | The pressure value of the four tyres is displayed: the resetting procedure is complete and successful. |

TYRE PRESSURE MONITOR (4/5)

Readjustment of tyre pressures

The pressure of the four tyres must be set when cold (refer to the label located on the edge of the driver's door). If the tyre pressures cannot be checked when the tyres are cold, the recommended pressures should be increased by 0.2 to 0.3 bar (3 PSI).

Never deflate a hot tyre.

Emergency spare wheel

If the vehicle is equipped with an emergency spare wheel, it will not have a sensor.



This function is an additional driving aid.


The function does not take the place of the driver. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver. Check the tyre pressures, including the emergency spare wheel, once a month.

Replacing wheels/tyres

This system requires specific equipment (wheels, tyres, hubcaps, etc.).

► 5.13.

Contact an approved Dealer to fit new tyres and to find out about available accessories compatible with the system and available from your dealer network: the use of any other accessory could affect the correct operation of the system or damage a sensor.



Tyre repair product and inflation kit

Because the valves are specially designed, only use equipment approved by the approved network. Please see the section on ► 5.4.



Changing a wheel

The system may take several minutes depending on use for the new wheel positions and pressures to be recognised; check the tyre pressures after all operations.

Tyre pressure faults

The table on the following page lists the warning messages which appear on the instrument panel 1 when the system detects a tyre pressure fault.

TYRE PRESSURE MONITOR (5/5)

The information on the instrument panel signals any potential tyre pressure faults (e.g. deflated or punctured tyre). For your safety, the warning light  requires you to stop immediately as soon as traffic conditions allow.

| Indicator lights | Messages | Displays (depending on the vehicle) | Readings |
|---|-----------------------------|---|---|
|  | Adjust Tyre Pressure |  | The wheel and associated pressure value are displayed in yellow. This indicates that tyre under-inflation has been detected. Check and adjust the pressure of the four tyres then reset the system. |
|  | Puncture |  | The wheel and associated pressure value are displayed in red. This indicates that the tyre concerned is punctured or severely underinflated. Adjust the pressure of the four tyres while cold and reset the system if the tyre is deflated. Replace the tyre (or have it replaced) if it is punctured. |
|  | Check Tyre Pressure Sensors |  | A wheel is no longer displayed. This indicates that at least one wheel is not fitted with a sensor (e.g. emergency spare wheel) or that the sensor is faulty. Consult an approved dealer. |
|  | Tyre Detection Failure |  | This indicates that the system has not been able to determine the pressure of each tyre. This may be caused by the use of a sensor not recommended by an approved dealer. The tyre pressure sensor monitoring system remains in operation. |

DRIVING CORRECTION DEVICES AND AIDS (1/6)

Depending on the vehicle, this is composed of:

- anti-lock braking system (ABS);
- electronic stability program (ESC) with understeer control and traction control;
- emergency brake assist;
- hill start assist;
- driver assistance with a trailer;
- traction control - “Extended grip”.

Other driving assistance systems are detailed on the following pages.



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions.

These functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

DRIVING CORRECTION DEVICES AND AIDS (2/6)

Anti-lock braking system (ABS)

Under heavy braking, the ABS prevents the wheels from locking, allowing the stopping distance to be managed and keeping control of the vehicle.

Under these circumstances, the vehicle can be steered to avoid an obstacle whilst braking. In addition, this system can increase stopping distances, particularly on roads with low surface grip (wet ground etc.).

You will feel a pulsation through the brake pedal each time the system is activated. The ABS does not in any way improve the vehicle's physical performance relating to the road surface and road-holding. It is still **essential** to follow the rules of good driving practice (such as driving at a safe distance from the vehicle in front etc.).

In an emergency, apply **firm and continuous pressure** to the brake pedal. There is no need to pump it repeatedly. The ABS will modulate the force applied in the braking system.

Operating faults:

-  and  lit up on the instrument panel accompanied by the messages "Check ABS", "WARNING: Check Braking System" and "Check ESC": this indicates that the ABS, the ESC and the emergency brake assist are disabled.

Braking is always enabled:

- , ,  and  lit on the instrument panel accompanied by the message "WARNING: Braking System": **this indicates a fault with the braking system.**

In both cases, please consult an Authorised Dealer.



Your braking systems are partially operational. However, **it is dangerous to brake suddenly** and it is essential to stop immediately, as soon as traffic conditions allow. Call an approved Dealer.

DRIVING CORRECTION DEVICES AND AIDS (3/6)

Electronic stability program (ESC) with understeer control and traction control

Electronic stability program ESC

This system helps you to keep control of the vehicle in critical driving conditions (avoiding an obstacle, loss of grip on a bend, etc.).

Operating principle

A sensor in the steering wheel detects the direction selected by the driver. Other sensors throughout the vehicle measure the actual direction.

The system compares driver input to the actual trajectory of the vehicle and corrects the trajectory if necessary by controlling the braking of certain wheels and/or engine power. In the event that

the system is triggered, the  warning light flashes on the instrument panel.

Understeer control

This system optimises the action of the ESC in the case of pronounced understeering (loss of front axle road holding).

Traction control

This system helps to limit wheelspin of the drive wheels and to control the vehicle when pulling away accelerating or decelerating.

Operating principle


Using the wheel sensors, the system measures and compares the speed of the drive wheels at all times and slows down their over-rotation. If a wheel is starting to slip, the system brakes automatically until the drive supplied becomes compatible with the level of grip under the wheel again.

The system also adjusts the engine speed to the grip available under the wheels, independently of the pressure exerted on the accelerator pedal.

In some situations (driving on very wet ground: snow, mud, etc. or driving with snow chains fitted), the system may reduce the engine output to limit wheel-spin.

Operating faults

When the system detects an operating fault the message "Check ESC" and warning light  and  appear on the instrument panel. In this case, the ESC and traction control system are deactivated. Consult an approved dealer.



Disabling the traction control system

In some situations (driving on very wet ground: snow, mud, etc. or driving with snow chains fitted), the system may reduce the engine output to limit wheel-slip. If this is not required, it is possible to deactivate the function by pressing switch 1.

In this case, the  warning light appears continuously on the instrument panel and, depending on the vehicle, is accompanied by the "Grip Extend Loose Surface ON" and/or "ESC OFF" message. This action deactivates the traction control but does not deactivate the electronic stability control.

The traction control system offers additional safety. It is recommended that you do not drive with the function disabled. Correct this as soon as possible by pressing the switch 1 again.

Note: traction control is automatically reactivated when the ignition is switched on.

Emergency brake assist

This system supplements the ABS and helps reduce vehicle stopping distances.

Operating principle

The system is for detecting an emergency braking situation. In this case, the braking system immediately develops maximum power and may trigger ABS regulation.

ABS braking is maintained as long as the brake pedal is applied.

Brake lights come on

Depending on the vehicle, these may flash in the event of sudden deceleration.

Braking anticipation

Depending on the vehicle, when you rapidly release the accelerator, the system anticipates the braking manoeuvre in order to reduce stopping distances.

Special cases

When using the cruise control:

- if you use the accelerator, when you release it, the system may be triggered;
- if you do not use the accelerator, the system will not be triggered.

Operating faults

When the system detects an operating fault the message "WARNING: Check Braking System" appears on the instrument panel along with the  warning light.

Consult an approved dealer.

DRIVING CORRECTION DEVICES AND AIDS (5/6)

Hill start assistance

Depending on the gradient of the incline, this system assists the driver when starting on a hill. It prevents the vehicle from rolling backwards by automatically applying the brakes when the driver lifts his/her foot off the brake pedal to depress the accelerator pedal.

System operation

It only operates when the gear lever is in a position other than neutral (other than **N** or **P**) and the vehicle is completely stationary (brake pedal depressed).

The system holds the vehicle for approximately **2 seconds**. The brakes are then gradually released (the vehicle will move according to the slope).



The hill start assistance system cannot completely prevent the vehicle from rolling backwards in all situations (extremely steep gradients etc.).

In all cases, the driver may depress the brake pedal to prevent the vehicle from rolling backwards.

The hill start assistance function should not be used for prolonged stops: use the brake pedal.

This function is not designed to immobilise the vehicle permanently.

If necessary, use the brake pedal to stop the vehicle.

The driver must remain particularly vigilant when driving on slippery or low-grip surfaces.

Risk of serious injury.

Driver assistance with a trailer

This system helps to maintain control over the vehicle while using a trailer. It detects shaking caused by towing a trailer under certain driving conditions.

Operating conditions

- The towbar must be approved by an authorised dealer;
- the harness must be approved by an authorised dealer;
- the towbar must be connected to the vehicle.

Operating principle

The function stabilises the vehicle by:

- asymmetric braking of the front wheels to reduce shaking caused by the trailer;
- braking of all four wheels and limitation on engine torque to reduce the vehicle speed until the shaking has stopped.

Warning light  flashes on the instrument panel to inform the driver.

DRIVING CORRECTION DEVICES AND AIDS (6/6)


Traction control - "Extended grip"

If fitted on the vehicle, grip control makes it easier to control the vehicle on low grip surfaces (soft ground, etc.).



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions.

The functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).



"Automatic" mode

When the vehicle starts, the message "Grip Extend Traction Control" is displayed on the instrument panel.

The default "Automatic" mode enables optimal use under normal road conditions (dry, wet, light snow, etc.).

"Automatic" mode uses traction control functions.

After the engine stops, the vehicle will always restart in "Automatic" mode.

"Soft ground" mode

Press switch 2: the  warning light appears on the instrument panel accompanied by the message "Grip Extend Loose Surface ON", followed by the message "ESC OFF". This position enables optimal usage on soft ground (mud, sand, dead leaves, etc.). In this position, engine speed is left under the driver's control.



Tyres

When they need to be replaced, only tyres of the same make, size, type and profile should be used.

Tyres fitted to the vehicle should either be identical to those fitted originally or conform to those recommended by your approved dealer.

LANE DEPARTURE WARNING (1/5)

55061



Using information from the camera 1, the function warns the driver if they cross a line (continuous or broken) without the direction indicator light being activated.


Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The lane departure warning function does not correct the vehicle's trajectory.

LANE DEPARTURE WARNING (2/5)



Activation/deactivation

To activate the function, press the 2 switch as many times as required to select "Lane Departure Warning" on the instrument panel. The "Lane depar-

ture warning on" message and "  " warning light are displayed on the instrument panel.

To disable the function, press the 2 switch as many times as required to select "Lane departure warning off" (or, depending on the vehicle, "Lane Keeping deactivated") on the instru-

ment panel. Warning light  goes out on the instrument panel.


Operation

When the function is activated, the  warning light and the left and right lines 3 are displayed in grey on the instrument panel.

The function is set to notify the driver if:

- the vehicle speed is greater than approximately 43 mph (70 km/h); and
- the  warning light and left/right line indicators 3 are coloured white.

The function triggers an alert if a line is crossed without the direction indicator being activated.



The function alerts the driver:

- by a vibration in the steering wheel; and
- the  warning light and 3 the indicator for the crossed line turn red.

Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

58027

LANE DEPARTURE WARNING (3/5)

Temporarily not available

- very fast lane departure;
- driving continuously on a line;
- four seconds approximately after changing lanes;
- tight bends;
- impaired visibility;
- activating the direction indicator lights;
- strong acceleration;
- changing the lane width;
- operation of the active emergency braking system;
- ...

When the function is not available, the



warning light and the left/right indicators turn to grey on the instrument panel.

Conditions for non-activation of the system

The system cannot be activated when:

- reverse gear is engaged;
- the field of vision of the camera is obstructed;
- the **STOP** warning light is displayed.


The  warning light and the left/right line indicators turn to grey on the instrument panel.

Adjustment

Vehicles fitted with a multimedia screen.

To access the multimedia screen function settings **4**, refer to the multimedia instructions:


- “VIBRATION”: adjust the steering wheel vibration level;



- “Alert”: adjust the line detection sensitivity level. To do this select:
 - “At the latest”: line detected when crossing;
 - “Standard”: line detected on approach;
 - “At the sooner”: line detected nearby.

Please refer to the multimedia instructions for further information.

LANE DEPARTURE WARNING (4/5)



Adjustments (continued)

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **5** as many times as required to reach the “Vehicle” tab;
- press the **6** or **7** control repeatedly to reach the “Settings” menu. Press the switch **8 OK**;

- press control **6** or **7** repeatedly to reach the DRIVING ASSIST menu. Press the switch **8 OK**;
- scroll repeatedly by pressing control **6** or **7** to access the Lane Departure Warning sensitivity or Lane Departure Warning vibration menu. Press the switch **8 OK**;
- press the **6** or **7** control repeatedly to adjust the setting. Press the **8 OK** button.

Operating faults

In the event of a malfunction, the left and right line indicators (and, depending on display style, the  warning light) disappear or stay grey on the instrument panel.

In some cases, they are accompanied by the message “Check Front camera” or the  warning light on the instrument panel.

Consult an approved dealer.

LANE DEPARTURE WARNING (5/5)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

System servicing/repairs

- In the event of an impact, the camera alignment may be changed, and its operation may consequently be affected. Deactivate the function, then consult an authorised dealer.
- Any work in the area where the camera is located (repairs, replacements, windscreens modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance

Some conditions can disturb or damage the operation of the system, such as:

- windscreens obscured (by dirt, ice, snow, condensation etc.);
- a complex environment (tunnel etc.);
- poor weather conditions (snow, rain, hail, black ice etc.) ;
- poor visibility (night, fog etc.);
- the road markings are irregular or difficult to distinguish (e.g. partially erased, excessive spacing, distorted road surface) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding or undulating (tight bends etc.);
- closely following a vehicle travelling in the same lane.

Risk of false alarms or absence of warnings

LANE KEEPING ASSIST (1/6)

55061



Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).


Using information from the camera 1, the function triggers a corrective action on the vehicle steering system if a line (continuous or broken) is crossed without the direction indicator lights being activated.

You can **retake control of the vehicle** at any time by operating the steering wheel.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

LANE KEEPING ASSIST (2/6)



To disable the function, press the **2** switch as many times as required to select "Lane Keeping deactivated" on the instrument panel.

Warning light  goes out on the instrument panel.

Note: deactivating the "Lane Keeping Assist" function causes deactivation of the "Lane Departure Warning" function.

Activation/deactivation


To activate the function, press the **2** switch as many times as required to select "Lane Keeping Assist" on the instrument panel.

The "Lane Keeping activated" message and  warning light are displayed on the instrument panel.

When Lane Keeping Assist is activated, the "Lane Departure Warning" function is automatically activated. ➔ 2.34.

Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

LANE KEEPING ASSIST (3/6)



Operation

When the function is activated, the  warning light and the left and right lines **3** are displayed in grey on the instrument panel.

The function is set to operate when the vehicle speed is over 43 mph

(70 km/h) and if the  warning light and **3** correction indicators are coloured white.

The function is triggered if the vehicle crosses a line without the direction indicator lights being activated.

In these cases:

- the function triggers an action on the vehicle's steering system to correct the vehicle trajectory;
- the warning light  and the indicator **3** on the side of the breached line turns to yellow on the instrument panel.

Note: on bends, the function allows for slightly cutting the bend.

If the corrective action on the steering system is not sufficient, the  warning light and **3** indicator on the side of the breached line turn to red on the instrument panel, accompanied by a vibration on the steering wheel.

Special cases

When using the function:

- if the system no longer detects any action by the driver on the steering wheel, the  warning light appears in yellow on the instrument panel, accompanied by the message "Keep hands on steering wheel" and an audible warning;
- if the steering system corrective action is active for too long, an audible warning is emitted and the indicator light **3** on the side of the line concerned flashes until the driver takes control.

You can interrupt the trajectory correction at any time by moving the steering wheel.

LANE KEEPING ASSIST (4/6)

Temporarily not available

- very fast lane departure;
- driving continuously on a line;
- four seconds approximately after changing lanes;
- tight bends;
- impaired visibility;
- activating the direction indicator light;
- strong acceleration;
- emergency braking;
- changing the lane width;
- operation of the active emergency braking system;
- ...

If the function is unavailable, the  warning light and the left/right correction warning lights **3** appear in grey on the instrument panel.

Conditions for non-activation of the system

The system cannot be activated when:

- reverse gear is engaged;
- the field of vision of the camera is obstructed;
- the  warning light is displayed.

The  warning light and the left/right line warning lights are displayed in grey on the instrument panel.


If the vehicle is equipped with a towbar that is recognised by the system, the message "Trailer: side radars OFF" is displayed to inform you that the Lane Keep Assist system is not operational.

Adjustment

Vehicles fitted with a multimedia screen.

To access the multimedia screen function settings **4**, refer to the multimedia instructions:


- "VIBRATION": adjust steering wheel vibration for the "Lane Departure Warning" function;



- "Alert": adjust the line detection sensitivity level. To do this select:
 - "At the latest": line detected when crossing;
 - "Standard": line detected on approach;
 - "At the sooner": line detected nearby.

Please refer to the multimedia instructions for further information.

LANE KEEPING ASSIST (5/6)



- press the **6** or **7** control repeatedly to reach the “DRIVING ASSIST” menu. Press the switch **8 OK**;
- scroll repeatedly by pressing **6** or **7** to reach the “Lane Keeping Assist sensitivity” menu. Press the switch **8 OK**;
- scroll repeatedly pressing control **6** or **7** to adjust the setting. Press the **8 OK** button.

Adjustments (continued)

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **5** as many times as required to reach the “Vehicle” tab;
- press the **6** or **7** control repeatedly to reach the “Settings” menu. Press the switch **8 OK**;

Operating faults

When the system detects an operating fault, the  warning light lights up on the instrument panel, with the message “Check Front camera”.

Consult an approved dealer.

LANE KEEPING ASSIST (6/6)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

System servicing/repairs

- In the event of an impact, the camera alignment may be changed, and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the camera is located (repairs, replacements, windscreens modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance

Some conditions can disturb or damage the operation of the system, such as:

- windscreens obscured (by dirt, ice, snow, condensation etc.);
- a complex environment (tunnel etc.);
- poor weather conditions (snow, rain, hail, black ice etc.) ;
- poor visibility (night, fog etc.);
- the road markings are irregular or difficult to distinguish (e.g. partially erased, excessive spacing, distorted road surface) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding or undulating (tight bends etc.);
- closely following a vehicle travelling in the same lane.

In this case, the "Lane Keeping Assist" may react incorrectly or not at all.



Risk of unwanted, incorrect correction or no correction of trajectory.

Deactivating the function

You must disable the function if:

- the area of the camera has been damaged (on the windscreens side or the interior rear-view mirror side);
- the road is slippery (snow, black ice, aquaplaning, gravel etc.) ;
- the windscreens are cracked or distorted (do not carry out windscreens repairs in this area; have it changed by an Authorised Dealer);
- the vehicle is connected to a towbar that is not recognised by the system;
- the vehicle is entering an area with several surface markings (an area with road works etc.).

BLIND SPOT WARNING (1/10)



Depending on the vehicle, there are two types of blind spot warning system:

- **System A:** uses information from ultrasonic sensors fitted in the vehicle bumpers. **When activated, the system A can be identified by indicator light 1 flashing each time the engine starts;**
- **System B:** uses information from the radars fitted on each side of the rear bumper. **When activated, the system B can be identified by indicator light 1 not flashing each time the engine starts.**

A system

Using information from the ultrasonic sensors indicated by the arrows 2, that are fitted in the vehicle bumpers, the system notifies the driver when another vehicle appears in the detection zone C.

The system is activated when the vehicle speed is between approximately 18 mph (30 km/h) and 80 mph (130 km/h).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

BLIND SPOT WARNING (2/10)




A system (continued)

Special feature

Ensure that the ultrasonic sensors installed in the vehicle bumpers are not obscured (by dirt, mud, snow etc.).


If one of the sensors is obscured, the message "Side radars no visibility" will appear on the instrument panel. Clean the ultrasonic sensor zones.

55928



58024

55057



Indicator 1

An indicator light **1** is located on each rear view mirror **3**.

Note: clean the rear view mirrors **3** regularly so that the indicators **1** can be seen.

Operation

The function alerts you if your vehicle speed is between approximately 18 mph (30 km/h) and 80 mph (130 km/h) while another vehicle is in the blind spot **C** and moving in the same direction as your vehicle.

If you overtake another vehicle, the indicator **1** will only come on if that vehicle remains for a long enough period in your vehicle's blind spot **C**.

BLIND SPOT WARNING (3/10)

①

55950

D



E



Display E

Direction indicator activated, the **1** warning light flashes when the function detects a vehicle in the blind spot warning area and/or a vehicle is rapidly approaching from the rear on the side towards which you will turn the wheel. If you cancel the direction indicator, the function will return to the initial warning (display **D**).

A system (continued)

Display D


First warning: **when the direction indicator is not activated**, the **1** warning light signals that a vehicle is detected in the blind spot.

Conditions for non-function

- When driving on a road with tight bends;
- in reverse;
- speed below 18 mph (30 km/h);
- speed above 80 mph (130 km/h).

If the vehicle is equipped with a towbar recognised by the system, the “Trailer: side radars OFF” message displayed on the instrument panel informs you that the function is not operational. For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.

BLIND SPOT WARNING (4/10)




B system

Using information from the sensors installed on each side of the rear bumper (area **G**), the function warns the driver:

- when another vehicle appears in the detection area **C**;
- and/or
- when there is a risk of collision with a vehicle that is in area **F**, driving faster than you.

The function warns you when the vehicle is travelling at a speed above approximately 9 mph (15 km/h).



55306



55925

Special feature


Ensure that the **G** area around the radars on each side of the rear bumper are not obstructed (by dirt, mud, snow etc.)

If a radar is obscured, the message "Side radars no visibility" will appear on the instrument panel. Clean the radar area.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

BLIND SPOT WARNING (5/10)




B system (continued)

Indicator 1

An indicator light **1** is located on each rear view mirror **3**.


Note: clean the rear view mirrors **3** regularly so that the indicators **1** can be seen.



Operation

The function warns you when the speed of your vehicle is over 9 mph (15 km/h):

- when another vehicle is in the blind spot area **C** and travelling in the same direction as your vehicle;
- when a vehicle approaches quickly from the rear in an adjacent lane within the range of detection area **F**.



If you overtake another vehicle, the indicator **1** will only come on if that vehicle remains for a long enough period in your vehicle's blind spot **C**.

The function does not notify the driver if the other vehicles are not moving.

BLIND SPOT WARNING (6/10)

1

55950

D



E



Display E

Direction indicator activated, the **1** warning light flashes when the function detects a vehicle in the blind spot warning area and/or a vehicle is rapidly approaching from the rear on the side towards which you will turn the wheel. If you cancel the direction indicator, the function will return to the initial warning (display **D**).

Conditions for non-function

- When driving on a road with tight bends;
- in reverse.

If the vehicle is equipped with a towbar recognised by the system, the "Trailer: side radars OFF" message displayed on the instrument panel informs you that the function is not operational. For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.


B system

(continued)

Display D

First warning: **direction indicator not activated**, the **1** warning light indicates that a vehicle is detected in the blind spot area and/or that a vehicle is rapidly approaching from the rear in an adjacent lane.

BLIND SPOT WARNING (7/10)



Systems A and B

Activation/deactivation

Vehicles fitted with a multimedia screen 4

To activate or deactivate the function, refer to the multimedia instructions.

Select "ON" or "OFF".

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **5** as many times as required to reach the "Vehicle" tab;
- press the **6** or **7** control repeatedly to reach the "Settings" menu. Press the switch **8 OK**;

- press the **6** or **7** control repeatedly to reach the "DRIVING ASSIST" menu. Press the switch **8 OK**;
- press the **6** or **7** control repeatedly to reach the "Blind spot alert" menu and press the **8 OK** switch;
- press the switch **8 OK** again to activate or deactivate the function:



function activated



function deactivated

When the engine is started, the system recalls the last position stored before the ignition was switched off.

The system's detection range operates according to a standard lane width. When driving in a narrow lane, the function can warn you when a vehicle is detected beyond the adjacent lane.

BLIND SPOT WARNING (8/10)

Systems A and B

(continued)

Operating faults

If the system detects a fault, the message "Check Side radars" is displayed on the instrument panel. Consult an approved dealer.

Due to the presence of radars or ultrasonic sensors (depending on the vehicle) behind the bumper, it is advisable to entrust any operation on the bumper (repair, replacement, paintwork etc.) to a qualified professional.



- The system's detection range operates according to a standard lane width. If you are driving in wide traffic lanes, the system might not be able to detect a vehicle in the blind spot.
- The system might be disrupted momentarily if it is exposed to strong electromagnetic waves (as beneath high-tension power lines) or to very poor weather conditions (heavy rain, snow etc.). Remain aware of driving conditions.

There is a risk of accidents.

BLIND SPOT WARNING (9/10)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.

The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

System servicing/repairs

- In the event of an impact, the alignment of the radars or ultrasonic sensors (depending on the vehicle) may be altered and their operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work (repairs, replacements etc.) in the area where the radars or ultrasonic sensors (depending on the vehicle) are located must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

System disturbance

Some conditions can disturb or damage the operation of the system, such as:

- complex surroundings (metal bridges, tunnels, roads with barriers at the edge, etc.);
- poor weather conditions (snow, hail, black ice, etc.).

Risk of false alarms or absence of warnings

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

BLIND SPOT WARNING (10/10)



Limitation of the system operation

- The radars or ultrasonic sensors area (depending on the vehicle) should be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects moving close to the vehicle (motorcycles, bicycles, pedestrians, etc.) may not be recognised by the system.
- When turning into a bend, the radars or ultrasonic sensors (depending on the vehicle) may temporarily cease to detect vehicles in adjacent lanes.
- The function may warn you late if two other vehicles are approaching from the rear, driving side by side in the adjacent lanes (i.e. driving on a 3-lane road) at a much higher speed than your vehicle.
- The system may not provide a warning when the other vehicles are travelling at a significantly different speed.
- If the vehicle is being overtaken by a long vehicle (e.g. heavy goods vehicle overtaking at a similar speed to the vehicle) the system may interrupt the warning before the end of the manoeuvre.
- The vehicle is travelling on a winding road.

Deactivating the function

You must disable the function if:

- There has been damage in the area where the radars or ultrasonic sensors (depending on the vehicle) are located;
- the vehicle is fitted with a towbar that is not recognised by the system.

SAFE DISTANCE ALERT (1/4)



Using the information from the radar **2** and camera **1**, this function informs the driver of the time interval between their vehicle and the vehicle in front so that a safe stopping distance between the two vehicles can be maintained.

The function is activated when the vehicle is travelling at a speed above approximately 19 mph (30 km/h).

Location of the camera 1

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

Location of the front radar 2

Ensure that the radar area is not obstructed (by dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

SAFE DISTANCE ALERT (2/4)




Activating/deactivating the function

Vehicles fitted with a multimedia screen 3

To activate or deactivate the function, refer to the multimedia instructions.

Select "ON" or "OFF".



Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **4** as many times as required to reach the "Vehicle" tab;
- press the **5** or **6** control repeatedly to reach the "Settings" menu. Press the switch **7 OK**;
- press the **5** or **6** control repeatedly to reach the "DRIVING ASSIST" menu. Press the switch **7 OK**;

– press the **5** or **6** control repeatedly to reach the "Distance warning" menu. Press the switch **7 OK**;

– Press the switch **7 OK** again to activate or deactivate the function:




function activated



function deactivated

Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

SAFE DISTANCE ALERT (3/4)



39301

- **C** (orange): the time interval falls between around 1 and 2 seconds (insufficient distance between the two vehicles);
- **D** (red): the time interval is less than or equal to around one second (very insufficient distance between the two vehicles).

If the interval between the two vehicles is less than approximately 0.5 seconds, the **8** indicator and the **D** display will flash in red on the instrument panel along with “-.- s”.

Under certain conditions, the time interval may not be displayed:

- while cornering;
- when changing lane;
- if the vehicle in front is sufficiently far or outside the range of the radar or camera.

Operation

With the function activated, the **8** indicator is displayed on the instrument panel and informs the driver of the distance between their vehicle and the vehicle in front.

- **A** (grey): function not operational;
- **A** (green): no vehicle detected;
- **B** (green): the time interval is greater than or equal to around two seconds (distance between the two vehicles adapted to your speed);



The measurement is displayed for information: the system does not carry out any action on the vehicle.

This function is not designed for use in urban conditions or for a dynamic driving style (sudden cornering, acceleration, braking, etc.), but rather for stable driving conditions.

The function does not interact with the braking system.

The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

Any work carried out in the area where the radar or camera is located (repairs, replacements, windscreen and/or bumper modifications, etc.) must be carried out by a qualified professional.

SAFE DISTANCE ALERT (4/4)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work carried out in the area where the radar and/or camera is located (replacements, repairs, windscreen and/or bumper modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance

- obstruction of the windscreen or the bumper (by dirt, glass, snow, condensation, etc.);
- a complex environment (metal bridge, tunnel etc.);
- poor weather conditions (snow, hail, black ice etc.);
- poor visibility (night, fog etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area etc.) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding and undulating (tight bends etc.)

Risk of erroneous false alarms.

ADVANCED SAFETY (1/17)

The “Advanced Security” system consists of:

- active emergency braking;
- and
- Emergency Lane Keep Assist.

The “Advanced Safety” system uses information from the camera **1**, front radar **2** and side radars **3**.

55133



Location of the camera 1

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

Location of the front radar 2


Ensure that the radar area is not obstructed (by dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).



This system provides an additional driving aid.

This system is not, under any circumstances, intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

55925



Location of the side radars 3

Ensure that the radar area is not obstructed (by dirt, mud, snow etc.), impacted or modified (including paintwork etc.).

Depending on the sensitivity setting selected, the “Lane Keep Assist” function may be used prior to operation of the “Advanced Safety” system.


ADVANCED SAFETY (2/17)



Activating, deactivating the system from the multimedia screen 4
(depending on the vehicle)

To activate or deactivate the function, refer to the multimedia instructions.

Select "ON" or "OFF".



Activating, deactivating the system from the trip computer 5

- With the vehicle stopped, press the switch **6** as many times as required to reach the "Vehicle" tab;
- press the **7** or **8** control repeatedly to reach the "Settings" menu. Press the switch **9 OK**;
- press the **7** or **8** control repeatedly to reach the "DRIVING ASSIST" menu. Press the switch **9 OK**;

- press the **7** or **8** control repeatedly to reach the "Advanced Safety" menu and press **9 OK**.

Press the switch **9 OK** again to activate or deactivate the function:



function activated



function deactivated

Upon deactivation of the system, the



warning light illuminates or, depending on the vehicle, the warning light illuminates in yellow on the instrument panel.

When the system is activated, the warning light disappears.

This system is reactivated each time the ignition is switched on.



Active emergency braking

The system uses information from the radar **2** and the camera **1**, to determine the distance from your vehicle:

- from the vehicle ahead in the same lane;
- or
- from any oncoming vehicles in the context of a manoeuvre to change direction;
- or
- surrounding pedestrians and cyclists.

The system informs the driver if there is a risk of head-on collision to enable appropriate emergency manoeuvres (pressing the brake pedal and/or turning the steering wheel).

Depending on the reactivity of the driver, the system can assist with braking in order to limit damage or prevent a collision.



This function is an additional driving aid.

This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

This system can apply maximum braking to the vehicle until it is completely stationary if necessary.

For safety reasons, always wear your seat belt when travelling in your vehicle and make sure that it is loaded so that no items can be thrown forward and hit the occupants.

Active emergency braking

(continued)

Detection of vehicles

If driving at a speed over 5 mph (8 km/h) and there is a risk of collision with the vehicle in front, with an oncoming vehicle in the context of a manoeuvre to change direction, or with a stationary vehicle, the system:


- warns you of a collision risk:**

the  red warning light, or, depending on the vehicle, the display **10** and the message "Brake" appear on the instrument panel, accompanied by a beep.

If the driver presses the brake pedal and the system still detects a risk of collision, the braking force may be increased if it is not sufficient to prevent the collision.

- may trigger braking:**

if the driver fails to react following the alert and collision becomes imminent.



If active emergency braking has caused the vehicle to stop, the vehicle is kept stationary for a short time. Beyond this time limit, the vehicle must be held stationary by the driver keeping their foot on the brake pedal.

Note: if the driver uses the vehicle controls (steering wheel, pedals, etc.) the system may delay certain operations or not activate.

In the event of emergency manoeuvre, you can stop braking at any moment by:

- tapping the accelerator pedal;
- or
- turning the steering wheel as a collision avoidance manoeuvre.


Active emergency braking (continued)

Special features of oncoming vehicles in the context of a manoeuvre to change direction

When you wish to change direction (e.g. A), oncoming vehicles travelling at approximately 18 mph (30 km/h) to 35 mph (55 km/h) are detected by the system when:

- your vehicle is travelling at a speed between approximately 5 mph (8 km/h) to 12 mph (20 km/h);
- you have activated the direction indicator light.

The system is otherwise inactive and does not trigger an alert.



53577

Special features of stationary vehicles

Stationary vehicles are detected when your vehicle is being driven at a speed between approximately 5 mph (8 km/h) and 62 mph (100 km/h). The system is not active and does not emit a warning for stationary vehicles when your vehicle speed exceeds approximately 62 mph (100 km/h).

Special features of warnings

Depending on the speed, the warning and braking may be activated simultaneously.



This function is an additional driving aid.

This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

Active emergency braking

(continued)

Detection of pedestrians and cyclists

When driving at a speed between approximately 5 mph (8 km/h) and 53 mph (86 km/h), if there is a risk of collision with a cyclist or pedestrian, the system:


- warns you of a collision risk:**

the  red warning light, or, depending on the vehicle, the display **10** and the message "Brake" appear on the instrument panel, accompanied by a beep.

If the driver presses the brake pedal and the system still detects a risk of collision, the braking force may be increased if it is not sufficient to prevent the collision.

- may trigger braking:**

if the driver fails to react following the alert and collision becomes imminent.



If active emergency braking has caused the vehicle to stop, the vehicle is kept stationary for a short time. Beyond this time limit, the vehicle must be held stationary by the driver keeping their foot on the brake pedal.

Note: if the driver uses the vehicle controls (steering wheel, pedals, etc.) the system may delay certain operations or not activate.

Special features related to stationary cyclists and pedestrians

The system does not detect stationary cyclists and pedestrians.

In this case, the system is inactive and does not trigger a warning.

In the event of emergency manoeuvre, you can stop braking at any moment by:

- tapping the accelerator pedal;
- or
- turning the steering wheel as a collision avoidance manoeuvre.


Active emergency braking (continued)

Settings for vehicles equipped with a multimedia screen

To access the multimedia screen function settings **4**, refer to the multimedia instructions:


- “Alert”: adjust the alert sensitivity level. To do this select:
 - “At the latest”;
 - “Standard”;
 - “At the sooner”.

Please refer to the multimedia instructions for further information.



Settings for vehicles not equipped with a multimedia screen

- With the vehicle stopped, press the switch **6** as many times as required to reach the “Vehicle” tab;
- press the **7** or **8** control repeatedly to reach the “Settings” menu. Press the switch **9 OK**;



- press control **7** or **8** repeatedly to reach the DRIVING ASSIST menu. Press the switch **8 OK**;
- scroll repeatedly by pressing control **7** or **8** to reach the “Active braking sensitivity” menu. Press the switch **9 OK**;
- press the **7** or **8** control repeatedly to adjust the setting. Press the **9 OK** button.

Active emergency braking

(continued)

Temporarily not available

If the system detects a temporary fault, the  warning light illuminates, or

depending on the vehicle, the warning light illuminates in yellow on the instrument panel.

The possible causes are:

- the system is temporarily blinded (glare from the sun, dipped beam headlights, bad weather conditions etc.). The system will be operational again when visibility conditions are better;
- the system is temporarily interrupted (e.g. the windscreen or the front or rear bumper is obscured by dirt, mud, snow, condensation, etc.). In this case, park the vehicle and switch off the engine. Clean the windscreen and front bumper. The next time the engine is started, after five or ten minutes of driving, the warning light and the message disappear.

If this is not the case, this may arise from another cause; contact an Approved Dealer.

Operating faults

When the function detects an operating fault, the warning lights  and

or, depending on the vehicle,
 and , appear in yellow on the instrument panel accompanied by the message "Check Front camera" or "Front radar to check" or "Check Camera/Radar".

Consult an approved dealer.



Active emergency braking

This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle. The triggering of this function may be delayed or prevented when the system detects clear signs of control of the vehicle by the driver (action on the steering wheel, pedals etc.).

The system cannot be activated:

- if the gear control is in neutral position;
- when the parking brake has been activated for approximately ten seconds.

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the radar and/or camera is located (repairs, replacements, windscreen modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.



System disturbance

Some conditions can disturb or damage the operation of the system, such as:

- a complex environment (metal bridge, tunnel etc.);
- poor weather conditions (snow, hail, black ice etc.);
- poor visibility (night, fog etc.);
- poor contrast between the object (vehicle, pedestrian etc.) and the surrounding area (e.g. pedestrian dressed in white located in a snowy area etc.);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- windscreen obscured (by dirt, ice, snow, condensation etc.);
- ...

In these conditions, the system may not react, may warn the driver or may brake inadvertently.

Limitation of the system operation

- Each time the vehicle is started, the system carries out a calibration according to the vehicle surroundings and may be inactive for a length of time between approximately two to five minutes of driving;
- An oncoming vehicle will not trigger any warning or system action if the conditions in the paragraph “Special features of oncoming vehicles in the context of a manoeuvre to change direction” are not met (see previous pages);
- The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system;
- the system may not respond to small vehicles such as motorbikes as effectively as to other vehicles;
- the system may not operate properly when the road surface is slippery (rain, snow, black ice, etc.);
- to ensure correct operation, the system needs to distinguish the complete outline of the pedestrian. So the system cannot detect:
 - pedestrians in the darkness or in poor lighting conditions;
 - partially visible pedestrians;
 - pedestrians less than approximately 80 cm tall;
 - pedestrians carrying large objects;
 - ...

In these conditions, the system may not react or may brake inadvertently.



Deactivating the function

You must disable the function if:

- the area of the camera has been damaged (e.g. on the inside or outside of the windscreen);
- the front of the vehicle was damaged (impact, distortion, scratch on the radar etc.);
- the vehicle is being towed (breakdowns);
- the windscreen is cracked or distorted (do not carry out windscreen repairs in this area; have it changed by an approved dealer);
- you are not driving on a paved road.

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.


Halting the function

You can halt the active braking function at any time by tapping the accelerator pedal or by turning the steering wheel in a collision avoidance manoeuvre.



Emergency Lane Keep Assist

Using information from the camera 1, the function triggers corrective action on the vehicle steering system when approaching the roadside (divider, barrier, pavement, embankment etc.) without the direction indicator light having been activated.



Using information from the radar 2 and the camera 1, the function triggers corrective action on the vehicle steering system in the event of a risk of collision with a vehicle coming from the opposite direction in the adjacent lane, without the direction indicator having been activated.

Depending on the vehicle, using information from the radars 3 and the camera 1, the function triggers corrective action on the vehicle steering system in the event of a risk of collision with a vehicle moving at the same speed or at a higher speed, if within the detection area of the rear radars.

You can **retake control of the vehicle** at any time by operating the steering wheel.



This system provides an additional driving aid.


This system is not, under any circumstances, intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

Emergency Lane Keep Assist (continued)

Roadside detection

When driving at a speed over 43 mph (70 km/h), when approaching the roadside (on the ground, barrier, pavement, embankment, etc.), without the direction indicator having been activated, the system:

- **warns you of a collision risk:**
the  warning light appears in red or, depending on the vehicle, the **11** display appears on the instrument panel accompanied by a beep; and
- **triggers corrective action on the steering system.**



Special feature

In the event the function operates repeatedly when approaching the roadside, if the system does not detect any

hands on the steering wheel, the  warning lights appear in yellow on the instrument panel.



This function is an additional driving aid.

This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

Emergency Lane Keep Assist (continued)



Detection of an oncoming vehicle

When driving at a speed between approximately 43 mph (70 km/h) and 68 mph (110 km/h), if there is a risk of collision with a vehicle coming from the opposite direction in an adjacent lane and within the detection zone **B**, without the direction indicator having been activated, the system:

- **warns you of a collision risk:**

the  warning light appears in red or, depending on the vehicle, the **11** display appears on the instrument panel accompanied by a beep; and


- **triggers corrective action on the steering system.**



55696

You can interrupt the trajectory correction at any time by moving the steering wheel.

 This function is an additional driving aid.
This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.



55697

ADVANCED SAFETY (15/17)

Emergency Lane Keep Assist (continued)

Detection of a vehicle approaching from the rear

(depending on the vehicle)





While driving at a speed over 43 mph (70 km/h), if a line (continuous or broken) is crossed while there is a risk of collision with a vehicle located in the blind spot **C** and it is moving in the same direction as your vehicle or with a vehicle that is rapidly approaching from behind or in an adjacent lane that is in the detection area **D**, the system:

- **warns you of the risk of collision:** the warning light **12** flashes and the

 warning light appears in red, or, depending on the vehicle, the **13** display lights up on the instrument panel accompanied by a beep;

and

- **triggers corrective action on the steering system.**



Emergency Lane Keep Assist (continued)

Temporarily not available:

- very fast lane departure;
- driving continuously on a line;
- approximately four seconds after changing lanes;
- tight bends;
- impaired visibility;
- activating the direction indicator light;
- strong acceleration;
- emergency braking;
- changing the lane width;
- operation of the active emergency braking system.
- ...

Depending on the vehicle, if one of the side radars is obscured the message "Check Side radars" will appear on the instrument panel.

Conditions for non-activation of the system

The system cannot be activated when:

- reverse gear is engaged;
- the field of vision of the camera is obstructed;
- the front radar is obscured;
- the rear radars are obscured;
- the **STOP** warning light is displayed.

If one of the side radars is obscured, the  warning light, or, depending on the vehicle, the  warning light appears in yellow accompanied by the message "Side radars no visibility". Clean the area where the sensors are located.

If the vehicle is equipped with a towbar that is recognised by the system, the

 warning light, or, depending on the vehicle, the  warning light appears in yellow accompanied by the message "Trailer: side radars OFF" to inform you that the Emergency Lane Keep Assist is not operational.

If the vehicle is towing a trailer or caravan, unexpected or unnecessary corrections may occur. In this case you can deactivate the "Advanced Security" function to avoid unexpected or unnecessary corrections.

Operating faults

When the function detects an operating fault, the  and  or, depending on the vehicle, the  and

 warning lights appear in yellow on the instrument panel accompanied by the message "Check Front camera" or "Front radar to check" or "Check Camera/Radar" or "Check Side radars".

Consult an approved dealer.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

System servicing/repairs

- In the event of an impact, the alignment of the camera or radar(s) may be altered and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the camera or radars are located (replacements, repairs, windscreens modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance

Some conditions can disturb or damage the operation of the system, such as:

- windscreens obscured (by dirt, ice, snow, condensation etc.);
- a complex environment (tunnel etc.);
- poor weather conditions (snow, rain, hail, black ice etc.) ;
- poor visibility (night, fog etc.);
- the road markings are irregular or difficult to distinguish (e.g. partially erased, excessive spacing, distorted road surface) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding or undulating (tight bends etc.);
- closely following a vehicle travelling in the same lane.

In this case, the "Advanced Safety" function may react incorrectly or not at all.

Risk of unwanted, incorrect correction or no correction of trajectory.

Deactivating the function

You must disable the function if:

- the camera area (on the windscreens side or the interior rear-view mirror side) or radar area(s) have been damaged;
- the windscreens is cracked or distorted (do not carry out windscreens repairs in this area; have it changed by an Authorised Dealer);
- the vehicle is being towed (breakdowns);
- you are not driving on a paved road.

FATIGUE DETECTION WARNING (1/2)

The fatigue detection warning is a function which is useful on monotonous roads (motorways, high-speed roads etc.).


It analyses driver behaviour and takes account of events to inform you of any risk of fatigue such as:

- steering wheel movement;
- driver actions on other devices (indicators, windscreen washer etc.);
- time spent driving without stopping;
- ...



This function is an additional driving aid in case of risk of fatigue. This function does not take the place of the driver.

Under no circumstances should this function replace the driver's care or responsibility whilst driving.



Activation/deactivation


Vehicles fitted with a multimedia screen 1

To activate or deactivate the function, refer to the multimedia instructions.

Select ON or OFF.

The function is activated by default every time the vehicle is started.

FATIGUE DETECTION WARNING (2/2)



Vehicles not fitted with a multimedia screen

- With the vehicle at a standstill, press and hold the switch **2 OK** to access the settings menu;
- repeatedly press the control **3** up or down until you reach the “Driving assistance” menu. Press the switch **2 OK**;

- repeatedly press the control **3** up or down until you reach the Fatigue detection warning menu, then press the switch **2 OK** .
- press the **2 OK** switch again to activate or deactivate the function.

Operation

The function is set to notify the driver if:

- the vehicle is driven for at least five minutes after each time the vehicle is stopped
- the vehicle speed is greater than approximately 40 mph (65 km/h); and
- approximately 10 minutes have passed since the deletion of the previous warning.

The function triggers an alert if the system detects repeated signs of fatigue in the driver at the steering wheel.

When a risk of fatigue is detected, the message “Fatigue warning have a break” is displayed on the instrument panel accompanied by a beep.

Press switch **2 OK** to delete the warning.

It is advisable to stop as soon as possible for a break.

Note:

- if the warning is not deleted by pressing switch **2 OK**, the beep repeats;
- the function may interpret certain driving styles as a sign of tiredness (sporty driving, incorrect driving etc.) or driving along a road which is in poor condition.

Operating faults

If the system detects a fault, the message “Check fatigue warning” is displayed on the instrument panel. Call an approved Dealer.

DETECTION OF ROAD SIGNS (1/4)

55061



The system detects speed limit signs on the side of the road and displays the speed limit on the instrument panel.

It mainly uses information taken from the camera 1, attached to the windscreen behind the rear view mirror.

Note: make sure the windscreen is not obscured (dirt, mud, snow, condensation etc.).

For vehicles which are equipped with it, the system also uses information from the navigation system.

Once the speed limiter is activated, you can adjust the speed limiter indication displayed by the system.

If the limit speed is exceeded, the display panel is modified to warn the driver.

For vehicles equipped with a navigation system and if the vehicle is travelling in a country where the speed units differ from those of the vehicle, the system displays the speed limit sign in the unit of the country, alongside the speed limit converted to the unit used by the vehicle's instrument panel.

Note: on vehicles not fitted with a navigation system and when driving in a country where the speed units differ from that of your vehicle, you can manually select the corresponding speed unit on the instrument panel (e.g. change from miles to kilometres) in order to obtain the appropriate information ➔ 1.142.

For countries where the speed limit is reduced during rainy weather on some types of roads, on vehicles equipped with a navigation system, the system can modify the limited speed after a few seconds of wiping the windscreen.

Special situations

The system does not take into account exceptional speed limit measures, such as peak pollution days.

DETECTION OF ROAD SIGNS (2/4)




Activating/deactivating the system

Vehicles fitted with a multimedia screen 2

To activate or deactivate the function, refer to the multimedia instructions.

Select "ON" or "OFF".



With the function activated, depending on local regulations, you can activate the "Display risk areas" option. The system will notify you of the distance separating you from this zone, and while you are travelling in the zone.

Vehicles not fitted with a multimedia screen

- With the vehicle stopped, press the switch **3** as many times as required to reach the "Vehicle" tab;
- press the **4** or **5** control repeatedly to reach the "Settings" menu. Press the switch **6 OK**;
- press the **4** or **5** control repeatedly to reach the "DRIVING ASSIST" menu. Press the switch **6 OK**;
- press the **4** or **5** control repeatedly to reach the "Speed alert" menu and press the **6 OK** switch;
- press the **6 OK** switch to activate or deactivate the function:




function activated;




function deactivated.

DETECTION OF ROAD SIGNS (3/4)



If the speed limit is exceeded, the circle around the panel flashes (7 warning light) along with a sound signal to warn the driver.



Operation

Warning lights

The function displays the following warning lights:

7 Speed limit road signs

8 Additional road signs (start or end of "No overtaking" zone, slip road speed limit, speed limit in case of a caravan, speed limit with length of application, etc.)

Varying the limit speed

If the Stop and Go adaptive cruise control, cruise control or speed limiter notification speed differs from the detected speed value, press and hold the following switches:

- 9 (RES+) to increase the notification speed to the detected speed;
- 10 (SET-) to reduce the notification speed to the detected speed.

DETECTION OF ROAD SIGNS (4/4)

Operating faults

The system cannot detect the speed limit if:

- the windscreen is not clean;
- the camera is blinded by the sun;
- there is insufficient visibility (night, fog etc.);
- the signs are not legible (snow, etc.) or are hidden (by another vehicle or by trees);
- the information taken from the navigation system is not up to date.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.

The system detects speed limit signs and does not detect other signs (e.g. entry/exit to/from urban areas, etc.).

The system may not detect all speed limit signs or may interpret them incorrectly.


The driver should not ignore signs that are not detected by the system and should, as a priority, comply with the traffic signage and the highway code.

In the event of poor visibility (fog, snow, frost, etc.), it is possible that the system may not indicate the correct speed to the driver.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.

SPEED LIMITER (1/4)

The speed limiter function controls the engine and braking system to help you not to exceed a driving speed that you have chosen, known as the **limit speed**.




Controls

- 1 Speed limiter On/Off switch.
- 2 Cruise control On/Off switch.
- 3 Switch to activate and decrease the limit speed (SET/-).
- 4 Switch to activate and increase the limit speed or to set the stored limit speed (RES/+).
- 5 Speed limiter function standby (with limited speed memory) (0).

You can link the speed limiter to the "Road sign detection" function.
➡ 2.78.


SPEED LIMITER (2/4)



Driving

When a limit speed has been set but not yet reached, driving is similar to driving a vehicle without the speed limiter function.

Once you have reached the stored speed, no effort on the accelerator pedal will allow you to exceed the programmed speed except in an emergency (refer to information on "Exceeding the limit speed").




Switching on

Press the switch 1. The 6 warning light appears in grey. The "Speed limiter ON" message appears on the instrument panel accompanied by dashes to indicate that the speed limiter function is in operation, waiting to store a limit speed.



To store the current speed, press the 4 switch (RES/+) or the 3 switch (SET/-): the limit speed replaces the dashes and, depending on the vehicle, the 6 warning light appears in white. The minimum stored speed is 19 mph (30 km/h).

SPEED LIMITER (3/4)



Varying the limit speed

The limit speed may be changed by pressing repeatedly or holding down:

- switch **4** (RES+) to increase speed;
- switch **3** (SET-) to reduce speed.

Exceeding the limit speed

It is possible to exceed the limit speed at any time. To do this: press the accelerator pedal **firmly and fully** (beyond the resistance point).

While the speed is being exceeded, the speed limiter flashes red on the instrument panel. Then, release the accelerator pedal: the speed limiter function will return as soon as you reach a speed lower than the memorised speed.

Limited speed cannot be maintained

If driving up or down a steep gradient, the system is unable to maintain the limited speed: the stored speed flashes red on the instrument panel and a beep sounds at regular intervals to inform you.

Temporarily not available

The system controls acceleration and deceleration of your vehicle using the engine and braking system. The system activates the brakes in order to maintain the set speed, the system applies limited braking. In the event of a steep descent, for example in a mountainous area, you must select a lower gear to benefit from engine braking.


To reduce the load imposed on the braking system and to prevent the brakes from overheating, the speed limiter function may be temporarily interrupted and the message "Check Speed Limiter" may appear. The message disappears when the function becomes available again.

If the message remains, contact an approved dealer.



If the speed limiter is not available (after several attempts to activate), contact an approved dealer.

SPEED LIMITER (4/4)



Putting the function on standby


The speed limiter function is suspended when you press switch 5 (0). The limit speed is stored and displayed in grey on the instrument panel.

Recalling the limit speed

If a speed has been stored, it can be recalled by pressing the 4 switch.



When the speed limiter is set to standby, pressing the 3 switch re-activates the function without taking into account the memorised speed: the speed at which the vehicle is moving is taken into account.



Switching off the function

The speed limiter function is interrupted:


- when you press the 1 switch. In this case, the speed is no longer stored;
- when you press the 2 switch. In this case the cruise control is selected and there is no stored speed.

The warning light 6 disappears from the instrument panel to confirm that the function is no longer active.

CRUISE CONTROL (1/5)

The cruise control function controls the engine and braking system to help you to maintain a driving speed that you have chosen, known as the **cruising speed**.

This cruising speed may be set at any speed above 19 mph (30 km/h).



58091

Controls

- 1 Cruise control On/Off switch.
- 2 Switch to activate and decrease cruising speed (SET/-).
- 3 Switch to activate and increase cruising speed or to recall the memorised cruising speed (RES/+).
- 4 Switch the function to standby (with cruising speed saved) (0).
- 5 Speed limiter On/Off switch.

You can link the cruise control function to the "Road sign detection" function ➔ 2.78.



This function is an additional driving aid.


It can under no circumstances replace the driver's responsibility to respect speed limits or to be vigilant.

The driver must always be in control of the vehicle.

Cruise control must not be used in heavy traffic, on winding or slippery roads (black ice, aquaplaning, gravel) and during bad weather (fog, rain, side winds etc.).

There is a risk of accidents.

CRUISE CONTROL (2/5)



Switching on

Press switch 1.

The **6** warning light appears in grey.

The "Cruise control ON" message appears on the instrument panel accompanied by dashes to indicate that the cruise control function is in operation and waiting to memorise a cruising speed.




Activating cruise control

While the vehicle is moving a steady speed above approximately 19 mph (30 km/h), press the **2** (SET/-) switch or the **3** (RES/+ switch: the function is activated and the current speed is taken into account.

The cruising speed replaces the dashes. Cruise control is confirmed when the memorised speed and warning light appear in green **6**.

If you try to activate the function below 19 mph (30 km/h), the message "Invalid Speed" will be displayed and the function will remain inactive.




Driving

Once a cruising speed is registered and the cruise control function is active, you may lift your foot off the accelerator pedal.



Please note that you must keep your feet close to the pedals in order to react in an emergency.



Adjusting the cruising speed

The cruising speed may be changed by pressing the following repeatedly:

- the **2** switch (SET/-) to reduce the speed;
- the **3** switch (RES/+) to increase the speed.

Note: press and hold one of the switches to modify speed by successive increments.

Exceeding the cruising speed

The cruising speed may be exceeded at any time by depressing the accelerator pedal.

While it is being exceeded, the cruising speed flashes in red on the instrument panel. Then, release the accelerator pedal: after a few seconds, the vehicle will automatically return to its set cruising speed.

Cruising speed cannot be maintained

If driving up or down a steep gradient, the system is unable to maintain the cruising speed: the stored speed is flashes red on the instrument panel to inform you of this situation.

Temporarily not available

The system controls acceleration and deceleration of your vehicle using the engine and braking system. The system activates the brakes in order to maintain the set speed, the system applies limited braking. In the event of a steep descent, for example in a mountainous area, you must select a lower gear to benefit from engine braking.


To reduce the load imposed on the braking system and to prevent the brakes from overheating, the cruise control function may be temporarily interrupted and the message "Check Cruise Control" may appear. The message disappears when the function becomes available again.

If the message remains, contact an approved dealer.



If the cruise control is no longer available (after several attempts to activate it), contact an Approved Dealer.

CRUISE CONTROL (4/5)



Putting the function on standby

The function is set to standby if you:

- **4** switch (0);
- the brake pedal;
- move to the neutral position.

The cruising speed is stored and displayed in grey on the instrument panel.



Returning to the cruising speed

If a speed is stored, it can be recalled, once you are sure that the road conditions are suitable (traffic, road surface, weather conditions, etc.). Press the switch **3** (RES+) if the vehicle speed is above 19 mph (30 km/h).



When the speed is stored, cruise control activation is confirmed by the display in green of the cruising speed and, depending on the vehicle, the **6** warning light is displayed.



NB: if the speed previously stored is much higher than the current speed, the vehicle will accelerate more rapidly to reach this threshold.

When the cruise control is set to standby, pressing switch **2** (SET/-) re-activates the cruise control function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.

CRUISE CONTROL (5/5)



Switching off the function

The cruise control function is interrupted:

- when you press the **1** switch. In this case, the speed is no longer stored;
- when you press the **5** switch. In this case the speed limiter is selected and there is no stored speed.

The warning light **6** disappears from the instrument panel to confirm that the function is no longer active.



Putting the cruise control on standby or switching it off does not cause a rapid reduction in speed: you must brake by depressing the brake pedal.

STOP AND GO ADAPTIVE CRUISE CONTROL (1/14)

Based on information from a radar or camera, the Stop and Go adaptive cruise control function gives you the option of maintaining a selected speed, known as the cruising speed, while keeping a safe distance from the vehicle in front in the same lane.

Depending on the vehicle, when the "Road sign detection" function is activated ➔ 2.78, the system can adjust your vehicle's speed according to the speed limit signs recognised by the camera.

If the vehicle in front stops, the Stop and Go adaptive cruise control may brake your vehicle to a complete stop before setting off again.

The system controls acceleration and deceleration of your vehicle using the engine and braking system.

The system's maximum range is approximately 150 m. This may vary according to the road conditions (ground relief, weather conditions, etc.).

According to conditions on the road (traffic, weather, etc.), the Stop and Go adaptive cruise control function can be activated:

- from 0 mph (0 km/h) to 84 mph (135 km/h).

The function is indicated by the  symbol.

Note:

- the driver must observe the maximum speed limit and safe distances in the country where they are driving;
- the Stop and Go adaptive cruise control can brake the vehicle up to a third of the braking capacity. Depending on the situation, the driver may need to brake harder.

The Stop and Go adaptive cruise control does not trigger an emergency stop and its braking capability is limited.



This function is an additional driving aid.

It can under no circumstances replace the driver's responsibility to respect speed limits or to be vigilant.

The driver must always be in control of the vehicle.

The driver must always adapt their speed according to the surroundings and traffic conditions.

The Stop and Go adaptive cruise control must only be used on a motorway (or multi-lane road separated by a barrier). The cruise control must not be used in heavy traffic, on winding or slippery roads (black ice, aquaplaning, gravel) or during bad weather (fog, rain, side winds etc.).

There is a risk of accidents.

STOP AND GO ADAPTIVE CRUISE CONTROL (2/14)




Location of the camera 1

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

Location of the radar 2

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted/attached front number plate), impacted, modified (including paintwork) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).




Controls

- 3 Safe distance settings
- 4 Switch the function to standby (with cruising speed saved) (0).
- 5 Stop and Go Adaptive cruise control main on/off switch .




The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.



- 6 Cruising speed activation, storage and decrease switch (SET/-).
- 7 Switch to activate and increase cruising speed or to recall the memorised cruising speed (RES/+).

You can link the cruise control function to the "Road sign detection" function ➔ 2.78.

STOP AND GO ADAPTIVE CRUISE CONTROL (3/14)



Displays

- 8 Stop and Go adaptive cruise control warning light.
- 9 Vehicle in front.
- 10 Stored safe distance
- 11 Stored cruising speed.



Important: you should keep your feet near the pedals at all times to prepare for any event.

Switching on

Press switch 5.

Warning light 8 appears in grey, and the message "Adaptive Cruise Ctl ON" appears on the instrument panel, accompanied by dashes to indicate that the cruise control function is activated and waiting to store a cruising speed.

This function cannot be activated when:

- the parking brake is applied;
- the Park Assist function is already activated → 2.133.

The message "Adaptive Cruise Ctl unavailable" is displayed on the instrument panel.

Activating cruise control

When the vehicle is stationary or moving at a steady speed (for all vehicles), press switch 6 (SET/-) or 7 (RES/+) to activate the function and store the current speed. The minimum cruising speed is 19 mph (30 km/h).

The cruising speed 11 replaces the dashes and the cruise control function is confirmed by the display of the cruising speed in green along with the 8 warning light. If you try to activate the function while the vehicle is moving at a speed over 84 mph (135 km/h), the message "Invalid Speed" is displayed and the function remains deactivated. Once a cruising speed is memorised and the cruise control function is active, you may lift your foot off the accelerator pedal.

If your vehicle speed is lower than about 19 mph (30 km/h), the function uses a default cruising speed of 19 mph (30 km/h). The vehicle will accelerate until it reaches the stored cruising speed.

STOP AND GO ADAPTIVE CRUISE CONTROL (4/14)


Safe distance control activation

As soon as cruise control is activated, the default safe distance **10** is displayed in green on the instrument panel. The default safe distance corresponds to approximately two seconds (see following pages).

If the system detects a vehicle in your lane, an outline of a vehicle **9** appears above the distance gauge **10** on the instrument panel.

Your vehicle adapts its speed to that of the vehicle in front and applies the brakes if necessary (the brake lights come on) in order to maintain the distance displayed on the instrument panel.


Note: the size of the **9** outline varies according to the distance separating you from the vehicle in front. The larger the outline, the closer the vehicle in front.



Setting the cruising speed

You can vary the speed by repeatedly pressing (for a small variation) or pressing and holding (for a larger variation) switch **6** or **7**:

- use the “SET/-” switch **6** to reduce the speed;
- use the “RES/+” switch **7** to increase the speed.



Adjusting the following distance

You can vary the safe distance from the vehicle in front at any time by pressing switch **3** repeatedly.

The horizontal distance gauge on the instrument panel indicates the various available safe distances:

- distance gauge **A**: long distance (corresponding to approximately 2.4 seconds);


STOP AND GO ADAPTIVE CRUISE CONTROL (5/14)

Adjusting the following distance (continued)

- distance gauge **B**: intermediate distance 2 (corresponding to approximately 2 seconds);
- distance gauge **C**: intermediate distance 1 (corresponding to approximately 1.6 seconds);
- distance gauge **D**: short distance (corresponding to approximately 1.2 seconds).

The selected distance gauge appears in green on the instrument panel. The other gauges remain in grey.

Note: the distance must be set according to the traffic level, local regulation and weather conditions.



Exceeding the cruising speed

The cruising speed may be exceeded at any time by applying the accelerator pedal.

If it is exceeded, the cruising speed **11** appears in red.

The distance gauge flashes if the distance between your vehicle and the vehicle in front is less than the safe distance selected: the Safe Distance Control function is no longer active.

Then, release the accelerator pedal: the cruise control and safe distance control will automatically resume the speed and distance instructions that you had previously selected.

Overtaking manoeuvre

If you wish to overtake the vehicle in front, activating the indicator will temporarily cancel the safe distance control and enable an acceleration speed sufficient to complete overtaking.

The safe distance is adjusted by default on the distance gauge **B**.

STOP AND GO ADAPTIVE CRUISE CONTROL (6/14)

Stop and start

If the vehicle in front slows down, the system adapts its speed, if necessary to a complete stop (e.g. in heavy traffic). The vehicle stops a few metres from the vehicle in front.

When the vehicle in front sets off again:

- if the stop does not exceed about three seconds, the vehicle sets off automatically without any action by the driver;
- if the stop exceeds about three seconds, you must apply the accelerator pedal or press button 7 (RES/+ in order for the vehicle to set off again. The message "Press RES/+ or accelerate" appears on the instrument panel to confirm.

If the stop exceeds about three minutes, the electronic parking brake is automatically applied and the Stop and Go adaptive cruise control is deactivated. The  warning light disappears to confirm that the function is deactivated.


Putting the function on standby

You can set the function to standby when:

- you press switch 4 (0);
- you apply the brake pedal while the vehicle is moving.

The function is deactivated by the system if:

- you put the gear control in P or N position;
- you engage the reverse gear;
- you unbuckle the driver's seatbelt;
- you open one of the opening elements;
- you press the engine start/stop button;
- the slope is too steep;
- the vehicle speed is above 84 mph (135 km/h);
- certain driving aids and correction devices are triggered (active emergency braking, ABS, ESC.).



58159

In all circumstances, the standby is confirmed when the warning lights appear in grey and the message "Adaptive Cruise Ctrl Disconnected" appears on the instrument panel.



Putting the Stop and Go adaptive cruise control in standby or switching it off does not cause a rapid reduction in speed: you must brake by applying the brake pedal if necessary.

STOP AND GO ADAPTIVE CRUISE CONTROL (7/14)

Exit from standby

Based on the stored cruising speed

If a speed is stored, it can be recalled, once you are sure that the road conditions are suitable (traffic, road surface, weather conditions, etc.). Press switch **7** (RES/+) in the range of confirmed speeds.

When the stored speed is recalled, activation of the cruise control is confirmed by the illumination of the cruising speed in green.

Note: if the stored speed is higher than the current speed, the vehicle will accelerate to reach that speed.

Based on the current speed

When the cruise control is set to standby, pressing switch **6** (SET/-) reactivates the cruise control function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.



Depending on the situation, the system sounds a beep associated with:


- the orange alert **E** if the situation requires the driver's attention;
- or
- the red alert **F** accompanied by the message "Brake", if the situation requires the driver's immediate attention.

In all situations, react accordingly and perform the appropriate manoeuvres.

"Take control of the vehicle" warnings

In some situations (e.g. coming upon a much slower vehicle, vehicle in front changing lanes quickly etc.), **the system may not have time to react.**

STOP AND GO ADAPTIVE CRUISE CONTROL (8/14)



If the radar detection area is obstructed or the radar signal is disrupted, the message "Front radar no visibility" is displayed on the instrument panel and the Stop and Go adaptive cruise control is interrupted. The green warning light  disappears to confirm that the function has been automatically deactivated.

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted/attached front number plate), impacted, modified (including paintwork) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).

Conditions in certain geographical areas may hinder the function, for example:

- arid zones, tunnels, long bridges or lightly used roads without road lines, without signs or trees nearby;
- a military or airport zone.

You must leave such areas in order for the function to work.

In all cases, if the message is not erased after the engine is restarted, please contact an authorised dealer.

Switching off the function

The Stop and Go adaptive cruise control function is deactivated when you press the **5** switch.

The warning light  disappears from the instrument panel to confirm that the function is no longer active.

Temporary unavailability

The radar is able to detect vehicles in front of your vehicle. The system cannot operate correctly if the radar detection area is obscured or if its signal is disrupted.

Operating faults

If a Stop and Go adaptive cruise control function operating fault is detected, the message "Check Adaptive Cruise control" appears on the instrument panel and the Stop and Go adaptive cruise control function is deactivated.


If an operating fault is detected on one or more components of the system, the Stop and Go adaptive cruise control function is deactivated.

The  warning light appears on the instrument panel along with, depending on the malfunction, one of the following messages:

- "Front camera to check";
- "Front radar to check";
- "Camera/Radar to check";
- "Check vehicle".

Consult an approved dealer.

STOP AND GO ADAPTIVE CRUISE CONTROL (9/14)



(G)


Limitations of system operation

Vehicle detection

The system detects only vehicles (cars, trucks, motorbikes) that are moving in the same direction as your vehicle.

A vehicle turning into the same lane (e.g. G) will be taken into account by the system only once it enters the camera and radar detection areas.

The system may trigger abrupt or delayed braking.



The system cannot detect:

- vehicles arriving at intersections: slip road (e.g. H) etc;
- vehicles driving on the wrong side of the road or reversing towards you.

The Stop and Go adaptive cruise control must only be used on a motorway (or multi-lane road with a central barrier).



(J)

Detection during cornering

When entering a corner or bend, the radar and/or camera may temporarily not be able to detect the vehicle in front (e.g. J).

The system may trigger an acceleration.


When exiting a bend, the system's detection of the vehicle in front may be disrupted or delayed.

The system may trigger abrupt or delayed braking.

57865

2.99

STOP AND GO ADAPTIVE CRUISE CONTROL (10/14)




Detection of vehicles in adjacent lanes

The system may detect vehicles driving on an adjacent lane when:

- you drive into a bend (e.g. **K**);
- you are driving on a road with narrow lanes;
- the speed of the vehicle on the adjacent lane is slower and if one of these vehicles is located too close to the lane of the other.

The system may incorrectly trigger vehicle slowing or braking.




Vehicles hidden due to variations in ground relief

The system will not detect vehicles hidden due to variations in ground relief or those located outside of the camera and radar detection areas when driving uphill or downhill.

Vehicles outside the camera and radar detection areas.


The system will react late or not at all if the detected vehicles are outside the camera and radar detection areas, particularly in the following cases:



- vehicles transporting long objects which exceed the line;
- the actual length of tall vehicles (e.g. **L**) outside the radar detection area (construction machine, agricultural equipment towing vehicle, etc.) ;
- vehicles insufficiently centred in the lane;
- narrow vehicles which are very close (e.g. **M**).

STOP AND GO ADAPTIVE CRUISE CONTROL (11/14)

57870



N

Stationary and slow moving vehicles


When your speed is over approximately 31 mph (50 km/h), **the system does not detect**:

- stationary vehicles (e.g. **N**);
- very slow moving vehicles.

When your speed is less than approximately 31 mph (50 km/h), **the system may not react or may react very late to**:

- stationary vehicles (e.g. **N**);
- very slow moving vehicles;

57871



P


13

- vehicles in front **12** which change lane, revealing a stationary vehicle **13** (e.g. **P**).

Always be ready to take control of your vehicle when you come upon stationary or very slow moving vehicles (e.g. **N).**

The Stop and Go adaptive cruise control does not trigger an emergency stop and its braking capability is limited.

STOP AND GO ADAPTIVE CRUISE CONTROL (12/14)




Non-detection of fixed obstacles and objects of a small size

The system cannot detect:

- pedestrians, bikes, scooters, etc. ;
- animals;
- fixed obstacles (toll barriers, walls, etc.) (e.g. **Q**).

These are not taken into account by the system. They do not trigger any alert or reaction by the system.



Detection of vehicles moving into lane at high speed

When your vehicle is overtaken by another vehicle driving at high speed **14** (motorcycle, car, etc.) (e.g. **R**) and that vehicle temporarily moves in between you and the vehicle in front **15**, the **system may trigger undue acceleration, slow down or braking.**

STOP AND GO ADAPTIVE CRUISE CONTROL (13/14)



This function is an additional driving aid. It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances and to be vigilant.

The driver must always be in control of the vehicle.

The driver must always adapt their speed to the surroundings and driving conditions, regardless of system indications. Except for lines delimiting lanes, traffic indicators (traffic lights, signs, pedestrian crossings etc.) are not recognised by the system. These do not trigger any alert or reaction by the system.

The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

Use the adaptive cruise control function Stop and Go only on a motorway (or a dual carriageway divided by a safety barrier).

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the system and consult an authorised dealer.
- Any work in the proximity of the radar and/or camera (replacements, repairs, windscreens modifications, paintwork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

Deactivating the function

You must disable the function if:

- the vehicle is travelling on a windy road;
- the vehicle is being towed (breakdowns);
- the vehicle is towing a trailer or a caravan;
- the vehicle is being driven in a tunnel or close to a metallic structure;
- the vehicle arrives at a toll point, a roadwork area or on a narrow lane;
- the vehicle is being driven up or down a very steep slope;
- the visibility is poor (glaring sun, fog etc.);
- the vehicle is being driven on a slippery road surface (rain, snow, gravel, etc.);
- the weather conditions are poor (rain, snow, side winds, etc.);
- the radar area has been damaged (impacts etc.);
- the camera area has been damaged (e.g. on the inside or outside of the windscreens);
- the windscreens are cracked or distorted.

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

STOP AND GO ADAPTIVE CRUISE CONTROL (14/14)



In the event of system disturbance

Some conditions can disturb or damage the operation of the system, such as:

- the windscreen or radar area is obscured (by dirt, ice, snow, condensation, number plate etc.);
- a complex environment (tunnel etc.);
- poor weather conditions (snow, heavy rain, hail, black ice, etc.);
- poor visibility (night, fog etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area etc.) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- narrow, winding or undulating road (tight bends etc.) ;
- a slower vehicle with a significant difference in speed;
- use of mats not adapted to the vehicle. On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

In these cases, the system may wrongly intervene.

Risk of unwanted braking or acceleration.

Many unforeseen situations may affect the system operation. Certain objects or vehicles that can appear in the camera or radar detection zone may be interpreted by the system incorrectly, possibly leading to inappropriate acceleration or braking.

You should always be attentive to sudden events that might occur while you are driving. Always keep your vehicle under control by keeping your feet near the pedals, so that you are ready to act in any event.

MOTORWAY AND TRAFFIC ASSISTANT (1/16)

The Motorway and Traffic Assistant is a driving aid system designed for use on long motorway journeys, where traffic is flowing or in jams.

Depending on the vehicle, this system comprises the **adaptive cruise control function Stop and Go** ➔ 2.91 and the "Lane Centring" function.

When these two functions are activated simultaneously, the system allows the driver to:

- maintain vehicle speed based on a previously saved speed;
- adjust the distance between this vehicle and the vehicle in front;
- direct the vehicle to the centre of the lane.

The Stop and Go adaptive cruise control function

Based on information from a radar or camera, the Stop and Go adaptive cruise control function gives you the option of maintaining a selected speed, known as the **cruising speed**, while keeping a safe distance from the vehicle in front in the same lane.

If the vehicle in front stops, the Stop and Go adaptive cruise control may brake your vehicle to a complete stop before setting off again.

The system controls acceleration and deceleration of your vehicle using the engine and braking system.

The Stop and Go adaptive cruise control function can be activated from 0 to 84 mph (0 to 135 km/h) according to conditions on the road (traffic, weather, etc.).

It is represented by the following symbol .

Note:

- the driver must observe the maximum speed limit and safe distances in the country where they are driving;
- the Stop and Go adaptive cruise control can brake the vehicle up to a third of the braking capacity. Depending on the situation, the driver may need to brake harder.



Important: you should keep your feet near the pedals and your hands on the steering wheel at all times to prepare for any event.

The Stop and Go adaptive cruise control does not trigger an emergency stop and its braking capability is limited.

The “Lane centring” function

Using information from a camera, the “Lane Centring” function manipulates the steering system to direct the vehicle to the middle of the lane. This function is only available while the Stop and Go adaptive cruise control is activated
→ 2.91.

If the conditions allow it, the function is available between:

- approximately 0 mph (0 km/h) and 84 mph (135 km/h) with a vehicle in front;
- or
- 37 mph (60 km/h) et 84 mph (135 km/h) approximately without a vehicle in front.

The “Lane Centring” function is a comfort feature. It is represented by the symbol .

Note: in the event of a sharp bend, the function's lateral retention capacities are limited and require the driver to take immediate action on the steering wheel.

Additional information


Depending on the vehicle, the “Motorway and Traffic Assistant” function may be used with other driving aid functions.

Please note that:

- activating the speed limiter causes deactivation of the system;
- the system cannot be activated when the “Park Assist” function is active;
- activation of the “Lane Centring” function leads to suspension of the “Lane Departure Warning” or “Lane Keep Assist” functions if these have been activated. They will be reactivated when the driver decides to stop the “Lane Centring” function.

MOTORWAY AND TRAFFIC ASSISTANT (3/16)

57860



MOTORWAY AND TRAFFIC ASSISTANT (4/16)

Computer 1

Receives information from the radar and camera to determine the vehicle trajectory and speed (acceleration or braking). Amongst other things, it controls the system activation/deactivation parameters (door opening, etc.).

Camera 2

Detects markings on the ground and the position of vehicles on the various traffic lanes. It complements the information transmitted by the 6 radar.

Make sure the windscreen is not obscured (by dirt, mud, snow, etc.).

Electronic parking brake 3

It the vehicle stationary under certain conditions.

Power-assisted steering 4

Operates the front wheels to assist the trajectory of your vehicle according to details transmitted by the 1 computer. It also enables detection of the driver's hands on the steering wheel.

Engine computer 5

It controls and directs the engine to carry out the required acceleration.

Radar 6

Calculates the distance between your vehicle and the vehicle in front.

The system's maximum range is approximately 150 m. This may vary according to the road conditions (ground relief, weather conditions, etc.)

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).


Active vehicle control 7

This system provides information on vehicle dynamics to the computer 1 (speed, lateral acceleration, etc.) and acts on the braking system to control deceleration and to keep the vehicle stationary.



The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

MOTORWAY AND TRAFFIC ASSISTANT (5/16)



58058

MOTORWAY AND TRAFFIC ASSISTANT (6/16)

Controls

- 8 Safe distance settings
- 9 Set active functions to standby (with cruising speed saved) (0).
- 10 Stop and Go Adaptive cruise control main stop/start switch .
- 11 "Lane Centring" function activation/deactivation switch .
- 12 Cruising speed activation, storage and decrease switch (SET/-).
- 13 Switch to activate and increase cruising speed or to recall the memorised cruising speed (RES/+).

Displays on the instrument panel


- 14 Stop and Go adaptive cruise control function warning light .
- 15 "Lane Centring" function warning light .
- 16 Vehicle in front.
- 17 Left-hand and right-hand line indicators.
- 18 Stored safe distance.
- 19 Stored cruising speed.
- 20 "Hands off steering wheel" detection warning light .

Steering wheel 21

The driver must always keep their hands on the steering wheel. If too much force is applied when turning the steering wheel, the "Lane Centring" function is put on standby so the driver can regain control of the vehicle.

Under certain conditions (sharp bends, etc.) a vibration may be triggered on the steering wheel to warn the driver that they must regain control of the vehicle.


If the driver does not handle the steering wheel (no hands are detected) the "Lane Centring" function is deactivated after several alerts.



Activating the “Lane Centring” function

Once the Stop and Go adaptive cruise control is activated → 2.91, press button 11 to activate the “Lane Centring” function. The message “Lane centering activated” appears on the instrument panel accompanied by the 15  warning light and the  symbol to confirm that the function is activated.

Note: you must keep your hands on the driving wheel when using the “Lane Centring” function. The  symbol is displayed to confirm that the function is activated.



The warning light 15  is displayed in green and the left-hand and right-hand line indicators 17 are displayed on the instrument panel to confirm that the function is activated and directing your vehicle to the centre of the lane.

Note: if you press button 11 when the Stop and Go adaptive cruise control is not activated, the message: “First activate Adapt. cruise ct” appears on the instrument panel.

MOTORWAY AND TRAFFIC ASSISTANT (8/16)

“Lane Centring” function on standby

The “Lane Centring” function is put on standby automatically when:

- the Stop and Go adaptive cruise control is put on standby ➔ 2.91;
- the system no longer detects the lines or only one line is detected in your lane;
- the lane is too narrow or too wide;
- the system does not detect any hands on the steering wheel;
- the bend is too sharp.


- the vehicle speed is over approximately 84 mph (135 km/h);
- the vehicle speed is below approximately 37 mph (60 km/h), without any vehicle in front;
- the vehicle touches or breaches a line;
- the system is temporarily disrupted (for example: camera obscured by dirt, mud, snow, condensation, etc.).

Certain actions carried out by the driver also suspend the “Lane Centring” function:

- activating the indicators;
- too much force is used when handling the steering wheel.

Standby of the function is confirmed by the **15**  warning light and the left-hand and right-hand line indicators **17** appearing in grey on the instrument panel.

56068



Once the conditions are met, the function again directs the vehicle to the centre of the lane. The **15**  warning light and left-hand and right-hand line indicators **17** are displayed in green on the instrument panel.



Important: you should keep your feet near the pedals and your hands on the steering wheel at all times to prepare for any event.

You can affect **the vehicle trajectory** at any point by turning the steering wheel.


58116



“Hands off steering wheel” detection warning

When the “Lane Centring” function no longer detects your hands on the steering wheel, several warning levels will be triggered:

- **after 15 seconds**, the message: “Keep hands on steering wheel” is shown in yellow on the instrument panel 22;



- **after approximately 30 seconds**, the message: “Keep hands on steering wheel” appears on the instrument panel 22 and the warning light 20  appears in red, accompanied by an audible signal of gradually increasing volume;
- **after approximately 45 seconds**, the audio sources go on standby, the audible signal sounds continually, the warning light 20  is switched off and the message “Lane centering deactivated” appears in red on the instrument panel 22: **the “Lane Centring” function is deactivated.**

Note: in some situations, the Lane Centring function may no longer detect your hands on the steering wheel and may sound a signal:

- the vehicle is moving along a long straight lane and the driver's hands are immobile on the steering wheel;
- the driver is holding the steering wheel very lightly;
- ...


If the “Lane Centring” function is deactivated due to the driver's hands not being detected on the steering wheel, the Stop and Go adaptive cruise control function continues to function.

In the first two alert levels, when the system again detects the presence of the driver's hands on the steering wheel, the system stops the alerts. The function continues to direct the vehicle to the centre of the lane.

MOTORWAY AND TRAFFIC ASSISTANT (10/16)



57862



58068


In the case of a sharp bend

In the case of a sharp bend, and depending on the vehicle speed, the function's side retaining capacities will be limited and require the driver to carry out immediate action on the steering wheel so that the function can continue to maintain the vehicle in the centre of the lane.

If the driver does not intervene, the function triggers the vibration of the steering wheel to signal that the vehicle is about to breach a line and that the driver needs to carry out immediate action.

The **15** warning light and the left-hand or right-hand line indicator **17** appear in red on the instrument panel.

If the vehicle crosses a line completely and moves out of lane, the “Lane Centring” function is put on standby. Standby of the function is confirmed by the **15** warning light and the left-hand and right-hand line indicators **17** appearing in grey on the instrument panel.



- the Stop and Go adaptive cruise control is deactivated ➔ 2.91.

Note: pressing the **10**  button once deactivates both the Stop and Go adaptive cruise control function and the “Lane Centring” function;

- the system will no longer detect the driver's hands on the steering wheel for a period over 45 seconds approximately.

The **15**  warning light and the left-hand and right-hand line indicators **17** disappear from the instrument panel.

Deactivating the “Lane Centring” function

The “Lane Centring” function is deactivated when:

- you press switch **11**. The function's deactivation is confirmed by the appearance of the message: “Lane centering deactivated” on the instrument panel.

Note: pressing the **11** switch once deactivates the “Lane Centring” function but does not affect operation of the Stop and Go adaptive cruise control function;

Temporary unavailability

The radar is able to detect vehicles in front of your vehicle. The system cannot operate correctly if the radar detection area is obscured or if its signal is disrupted.

If the radar detection area is obstructed or the radar signal is disrupted, the message "Front radar no visibility" is displayed on the instrument panel and the Stop and Go adaptive cruise control is interrupted. The green warning light  disappears to confirm that the function has been automatically deactivated.

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).

Conditions in certain geographical areas may hinder the function, for example:

- arid zones, tunnels, long bridges or lightly used roads without road lines, without signs or trees nearby;

- a military or airport zone.

You must leave such areas in order for the function to work.

In all cases, if the message is not erased after the engine is restarted, please contact an authorised dealer.

Operating faults

If a Lane Centring function operating fault is detected, the message "Lane centering to check" is displayed on the instrument panel and the function is disabled.

The Stop and Go adaptive cruise control function remains in operation.

Consult an approved dealer.

If a Stop and Go adaptive cruise control function operating fault is detected, the message "Check Adaptive Cruise control" appears on the instrument panel and both the Stop and Go adaptive cruise control and Lane Centring functions are suspended.

Consult an approved dealer.

If an operating fault is detected on one or more components of the "Motorway and Traffic Assistant" system, the  warning light appears on the instrument panel, alongside, depending on the nature of the fault, the message:

- "Front camera to check";
- "Front radar to check";
- "Camera/Radar to check";
- "Check vehicle".

The Stop and Go adaptive cruise control function and Lane Centring function are both suspended.

Consult an approved dealer.

MOTORWAY AND TRAFFIC ASSISTANT (13/16)



The “Motorway and Traffic Assistant” function is an additional driving aid. This system does not take the place of the driver.

Therefore, it can under no circumstances replace the driver's responsibility to respect speed limits and safe distances and to be vigilant (the driver must always be ready to brake).

The driver must always be in control of the vehicle. The driver must always adapt their trajectory and speed according to the surroundings and traffic conditions.

The “Motorway and Traffic Assistant” uses the Stop and Go adaptive cruise control function and the Lane Centring function. It must only be used on a motorway or multi-lane road (separated by a barrier).

It must not be used in heavy traffic, on winding or slippery roads (black ice, aquaplaning, gravel) or during bad weather (fog, rain, side winds etc.).

There is a risk of accidents.

MOTORWAY AND TRAFFIC ASSISTANT (14/16)



The “Motorway and Traffic Assistant” function is an additional driving aid. It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances and to be vigilant.

The driver must always be in control of the vehicle.

The driver must always adapt their trajectory and speed according to the surroundings and driving conditions, regardless of system indications.

Except for lines delimiting lanes, traffic indicators (traffic lights, traffic signs except for speed limit signs within the limits of the system's detection capacity, pedestrian crossings, etc.) are not recognised by the system. These do not trigger any alert or reaction by the system.

The “Motorway and Traffic Assistant” uses the Stop and Go adaptive cruise control function and the Lane Centring function. The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

The Motorway and Traffic Assistant function must only be used on a motorway or multi-lane road separated by a barrier.

System servicing/repairs

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the system and consult an authorised dealer.
- Any work in the proximity of the radar and/or camera (replacements, repairs, windscreens modifications, paintwork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.



Deactivating the system

You must deactivate the system if:

- the vehicle is travelling on a windy road;
- the vehicle is being towed (breakdowns);
- the vehicle is towing a trailer or a caravan;
- the vehicle is being driven in a tunnel or close to a metallic structure;
- the vehicle arrives at a toll point, a roadwork area or on a narrow lane;
- the vehicle is being driven up or down a very steep slope;
- the visibility is poor (glaring sun, fog etc.);
- the weather conditions are poor (rain, snow, side winds, etc.);
- the vehicle is being driven on a slippery road surface (rain, snow, gravel, etc.);
- the camera area has been damaged (e.g. interior or exterior windscreen area); the windscreen is cracked or distorted;
- the radar area has been damaged (impacts, etc.) ;
- the surface of the steering wheel is damaged or damp.

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.



Some conditions can disrupt or damage the operation of the system, for example:

- obstruction of the windscreen or the radar area (by dirt, ice, snow, condensation etc.) Frequently check the cleanliness and condition of the windscreen, front wiper blades and front bumper;
- a complex environment (tunnel etc.);
- poor weather conditions (snow, heavy rain, hail, black ice, etc.);
- poor visibility (night, fog etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area etc.) ;
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- narrow, winding or undulating road (tight bends etc.);
- the tar lines detected as a line by the system;
- narrowing/widening lanes;
- road markings which are worn, lacking in contrast or very widely spaced from one another (lines partially erased etc);
- multiple markings on the road (roadworks area, slip roads connecting to adjacent motorways, hard shoulder etc.);
- road signs that do not include an arrow, located in a motorway exit;
- an area with low connectivity that makes it impossible to geolocate the vehicle or maps that are not up-to-date;
- a slower vehicle with a significant difference in speed;
- use of mats not adapted to the vehicle. On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

In these cases, the system may wrongly intervene.

- **Risk of unwanted braking or acceleration.**
- **Risk of unwanted, incorrect correction or no correction of trajectory.**

Many unforeseen situations may affect the system operation. Certain objects or vehicles that can appear in the camera or radar detection zone may be interpreted by the system incorrectly, possibly leading to inappropriate acceleration or braking.

You should always be attentive to sudden events that might occur while you are driving. Always maintain your vehicle under control by keeping your feet near the pedals and your hands on the steering wheel, so that you are ready to act in any event.

PARKING DISTANCE CONTROL (1/8)

Operating principle

Ultrasonic sensors fitted in the bumpers measure the distance between the vehicle and an obstacle.

This measurement is indicated by beeps which become more frequent the closer you come to the obstacle, until they become a continuous beep when the vehicle is approximately 30 centimetres from the obstacle.

Depending on the vehicle, the system detects obstacles to the front, the rear and the sides of the vehicle.

The parking distance control system is only activated when the vehicle is driven at a speed below approximately 6 mph (10 km/h).

The function does not take into account towing or carrying systems that are not recognised by the system.



Location of the ultrasonic sensors 1

Ensure that the ultrasonic sensors indicated by the arrows 1 are not obscured (by dirt, mud, snow, a badly fitted/attached number plate), impacted, modified (including paintwork) or obstructed by any accessory fitted to the rear and/or, depending on the vehicle, to the front or sides of your vehicle.

55064




This function is an additional aid that uses sound signals to indicate the distance between the vehicle and an obstacle during reversing.

Under no circumstances should it replace the driver's care or responsibility whilst reversing.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

PARKING DISTANCE CONTROL (2/8)



Note: the display 2 shows the vehicle surroundings and emits beeps.

It is necessary to travel a few metres before the side detection is activated.

If all areas have a grey background, the whole area around the vehicle is being monitored:

- **A:** analysis of the vehicle surroundings in progress;
- **B:** analysis of the vehicle surroundings carried out.



Operation

Most objects located less near the front, rear and sides of the vehicle are detected.

Depending on the distance of the obstacle, the frequency of the beep will be higher while approaching it, and will become a continuous beep around 20 cm away for obstacles to the sides, and around 30 cm for obstacles to the front or rear. The green, orange (or yellow depending on the vehicle) and red zones will be shown on the display **C**.

Note: in the event of a change in trajectory during a manoeuvre, the risk of collision with an obstacle may be signalled late.




An impact to the under-side of the vehicle while manoeuvring (e.g. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved dealer.

PARKING DISTANCE CONTROL (3/8)

(D)



55067

If a side obstacle is detected:

- the beeps become faster and then sound continuously as the obstacle gets nearer. Green, orange and red zones will be displayed on the display **D**;
- if there is no risk of collision, no beep will sound when approaching the obstacle. Green, orange and red zones will be displayed interspersed on the display **D**.

Note: in the event of a change in trajectory during a manoeuvre, the risk of collision with an obstacle may be signalled late.

Detection of obstacles to the side

Depending on the direction of the wheels, the system determines the trajectory of the vehicle and notifies the driver of any risk or otherwise of a collision with an obstacle 3 to the side of the vehicle.

PARKING DISTANCE CONTROL (4/8)



Vehicles fitted with a multimedia screen

Activation/deactivation

To activate or deactivate the various zones covered by the ultrasonic detectors from the multimedia screen 4, refer to the multimedia instructions.

Select "ON" or "OFF".

When the engine is started, the system recalls the last position stored before the ignition was switched off.

Adjustment

Depending on the vehicle, while the engine is on some settings can be adjusted from the multimedia screen 4. Please refer to the multimedia instructions for further information.

Parking distance control audio volume

Adjust the volume of the parking distance control by pressing + or -.

System sound

Enables the system sound to be chosen.


Deactivating the system sound

Activate or deactivate the parking distance control sound.

Note: if you deactivate the sound, you will no longer be notified with beeps when approaching an obstacle.

When the vehicle is travelling at a speed below approximately 6 mph (10 km/h), some noises (motorcycle, lorry, pneumatic drill etc.) may trigger the beeping sound of the parking distance control.

PARKING DISTANCE CONTROL (5/8)




Vehicles not fitted with a multimedia screen

Activation/deactivation

With the vehicle stopped, press the **6** switch to deactivate parking distance control. Warning light **5** in the switch lights up. Press again on the **6** switch to activate the function. The indicator light built into the **5** switch goes out.

When the engine is started, the system recalls the last position stored before the ignition was switched off.



Special feature on vehicles fitted with front, rear and side Park Assist

You can also activate/deactivate the function from the instrument panel:

- with the vehicle stationary, press the **7** switch as many times as required to reach the “Vehicle” tab;
- press the **8** or **9** control repeatedly to reach the “Settings” menu. Press the switch **10 OK**;


- press the **8** or **9** control repeatedly to reach the “PARKING ASSIST” menu. Press the switch **10 OK**;
- select “ON” or “OFF” to activate or deactivate the function.

If the **6** button cannot be used to reactivate Park Assist, check that the function has not been deactivated on the instrument panel. To reactivate it, please refer to the paragraph entitled “Special feature on vehicles fitted with front, rear and side Park Assist”.



An impact to the under-side of the vehicle while manoeuvring (e.g. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved dealer.



Adjustment

- With the vehicle stopped, press the **7** switch as many times as required to reach the "Vehicle" tab;
- press the **8** or **9** control repeatedly to reach the "Settings" menu. Press the switch **10** OK;
- press the **8** or **9** control repeatedly to reach the "PARKING ASSIST" menu. Press the switch **10** OK;

- select "Beep volume" to adjust the volume of Park Assist using control **8** or **9**.

Automatic deactivation of the parking distance control

The system deactivates:

- when the vehicle speed is above approximately 6 mph (10 km/h);
- depending on the vehicle, when the vehicle is stationary for more than approximately three seconds and an obstacle is detected (such as when in a traffic jam etc.);
- when you are in **N** or **P** position;
- when an operating fault is detected.

Note: if the vehicle is fitted with a towbar recognised by the system, only the rear Park Assist is deactivated.

Deactivating the parking distance control manually

You must disable the function if:

- if towing, carrying or trailer equipment that is unrecognised by the system is present in front of the ultrasonic sensors;
- in the event of damage to the ultrasonic sensors.

Operating faults

When the system detects an operating fault, a beep sounds for approximately three seconds each time reverse gear is selected and is accompanied by the message "Check parking sensor" shown on the instrument panel. Consult an approved dealer.

PARKING DISTANCE CONTROL (7/8)

System servicing/repairs

- In the event of an impact, the alignment of the sensors may be altered and their operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the sensors are located (repairs, replacements, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

System disturbance

Some conditions can disrupt or damage the operation of the system, for example:

- poor weather conditions (rain, snow, hail, black ice, etc.);
- in the event of exposure to strong electromagnetic waves (under high-voltage lines, etc.);
- some types of noise (motorcycle, lorry, pneumatic drill etc.);
- fitting an unsuitable towing ball or hook.

Risk of false alarms or absence of warnings

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

Limitation of the system operation

- The area around the sensors must be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects moving close to the vehicle (motorcycles, bicycles, pedestrians, etc.) may not be recognised by the system.
- The system may not detect objects that are too close to the vehicle.
- The system may not provide a warning when the other vehicles or objects are travelling at a significantly different speed.
- During a change in trajectory during a manoeuvre, the system may report obstacles with a delay.
- When the vehicle is towing a trailer, the rear Park Assist system must be deactivated.

Deactivating the function

You must disable the function if:

- the area around the sensors has been damaged;
- the vehicle is equipped with a towing device that is not recognised by the system (ball, hook, adapter, etc.).

REVERSING CAMERA (1/4)




Operation

Depending on the vehicle, when the reverse gear is engaged, the camera 1 located on the tailgate or on the rear hinged door transmits a view of the surroundings behind the vehicle to:

- the multimedia screen 2, accompanied by one or two guidelines 5 and 6 (fixed and moving);
- or
- the rear view mirror 3, accompanied by a fixed guideline 5;
- or
- the camera rear view system screen 4, accompanied by a fixed guideline 5.

35987




55694



REVERSING CAMERA (2/4)

35987



This system uses several guidelines for its operation (mobile for trajectory and fixed for distance). When the red zone is reached, use the bumper image to stop accurately.

Fixed clearance gauge 5

The fixed clearance gauge comprises coloured markers **A**, **B** and **C** indicating the distance behind the vehicle:

- **A**(red) approximately 30 centimetres from the vehicle;
- **B**(yellow) approximately 70 centimetres from the vehicle;
- **C**(green) approximately 150 centimetres from the vehicle.

This gauge remains fixed and indicates the vehicle trajectory if the wheels are in line with the vehicle.

6 moving guide line:

This is shown in blue and indicates the vehicle trajectory in relation to the steering wheel position.

Special feature

Make sure that the camera is not obscured (by dirt, mud, snow, condensation etc.).



This function is an additional aid. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver. The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

REVERSING CAMERA (3/4)



Settings

While the engine is on, from the multimedia screen 2 you can add or remove the guides and adjust the camera image settings (brightness, contrast, etc.). Please refer to the multimedia instructions for further information.

Operating faults

When reverse gear is engaged, if the system detects an operating fault, a black screen is displayed temporarily on the multimedia screen 2.

This may be caused by a fault affecting the camera or screen (clearness, fixed image, delayed communication etc.).

If the temporary display of the black screen persists, please consult an approved dealer.

The screen shows a reverse mirror image.



The frames are a representation projected on a flat surface. This information is to not be taken into account when superimposed on a vertical object or an object on the ground.

Objects which appear on the edge of the screen may be deformed.

In very bright light (snow, vehicle in sunshine, etc.), the camera vision may be adversely affected.

If the luggage compartment is open or incorrectly closed, the message "WARNING: Boot Open" appears on the multimedia screen.

REVERSING CAMERA (4/4)





Difference between the estimated distance and actual distance

Reversing towards a steep uphill slope

The fixed guidelines 5 show the distances as closer than they actually are.

The objects shown on the screen are actually further away on the slope.

For example, if the screen displays an object at **D**, the actual distance of the object is at **E**.





Reversing towards a steep downhill slope

The fixed guidelines 5 show the distances as further than they actually are.

Therefore, the objects shown on the screen are actually closer on the slope.

For example, if the screen displays an object at **G**, the actual distance of the object is at **F**.




Reversing towards a protruding object

Position **H** seems further than position **J** on the screen. However, position **H** is at the same distance as position **K**.

The trajectory indicated by the fixed and mobile guidelines do not take into account the height of the object. So there is a risk that the vehicle may collide with the object when reversing towards position **K**.

ASSISTED PARKING (1/5)




Using ultrasonic detectors as indicated by the **3** arrows installed in the vehicle bumpers, this function helps to find accessible parking spaces and assists in the parking manoeuvre.

Remove your hands from the steering wheel, you only control:

- the accelerator pedal;
- the brake pedal;
- the gear lever.


At any time, you can regain control by using the steering wheel.



Switching on

With the engine on, the vehicle stationary or driving at less than approximately 19 mph (30 km/h):

- press switch **2**. The indicator light in switch **2** lights up and display **A** appears on the multimedia screen **1**.
- set the direction indicator to the side of the vehicle where you want to park.



Special features

Ensure that the ultrasonic sensors indicated by arrows **3** are not obscured (by dirt, mud, snow, etc.).

ASSISTED PARKING (2/5)



Choice of manoeuvre

The system can perform four types of manoeuvres:

- parallel parking;
- perpendicular parking;
- angle parking;
- moving out of a parallel parking space.

From the **1** multimedia screen, select the manoeuvre to carry out.

Note: when starting the vehicle, or after having successfully completed parallel parking using the system, the default manoeuvre proposed by the system is assistance in exiting a parallel parking space. In other cases, the default manoeuvre can be set from the multimedia screen **1**. Please refer to the multimedia instructions for further information.

Operation

Parking

As long as the vehicle speed is less than 19 mph (30 km/h), the system searches for available parking spaces on the side of the vehicle chosen by the driver.

Note: if parking spaces are available on the other side of the vehicle, set the direction indicator to the other direction to enable the system to search for spaces.

Once a space has been found, it is displayed on the multimedia screen, indicated by a small letter "P". Drive slowly, with the direction indicator activated on the side where the space is available, until the "Stop" message is displayed and a beep sounds.

The system start up is accompanied by activation of the parking distance control and, on those vehicles equipped, the reversing camera to help the driver visualise the manoeuvre. ➔ 2.121 and ➔ 2.129.

ASSISTED PARKING (3/5)

The space is then indicated on the multimedia screen by a capital letter "P".

- Stop the vehicle;
- select reverse gear.

The indicator light  lights up on the instrument panel and a beep sounds.

- Release the steering wheel;
- follow the instructions shown on the multifunction screen **1**.


Your speed should not exceed around 4 mph (7 km/h).

Once the warning light  on the instrument panel goes off and a beep sounds, the manoeuvre has been completed.



This function is an additional driving aid.

Therefore, it can under no circumstances replace the driver's vigilance and responsibility during manoeuvres (the driver must always be ready to brake).



- Release the steering wheel;
- carry out manoeuvres at the front and rear by following the instructions shown on the multimedia screen **1** and using the parking distance control system alerts.

Your speed should not exceed around 4 mph (7 km/h).

Once the vehicle is in a position to exit the parking space, the  warning light disappears from the instrument panel and a sound signal and message appear on the multimedia screen **1** to confirm that the manoeuvre is complete.

Exiting a parallel parking space


- Briefly press the **2** switch;
- Select the "Exit parallel parking space" mode;
- activate the direction indicator on the side you wish to go out of;
- press and hold switch **2** (approx. two seconds).

The indicator light  lights up on the instrument panel and a beep sounds.



When manoeuvring, the steering wheel may turn quickly: do not put your hands inside, and make sure that nothing is caught inside.

ASSISTED PARKING (4/5)



Suspending/Resuming the manoeuvre

The manoeuvre is suspended in the following circumstances:

- you take control of the wheel;
- the vehicle is stationary for more than one minute;
- an obstacle in the direction of movement prevents the manoeuvre from being completed;
- the engine stops;
- a door or the luggage compartment is opened.

The switch warning light **2** goes out, the **P**  warning light disappears from the instrument panel and an audible signal confirms that the manoeuvre has been suspended. The reason for suspending the manoeuvre will be displayed on the multimedia screen **1**.

Make sure:

- the vehicle is stationary;
- and
- you have released the steering wheel;
- and
- that all doors and the boot are closed;
- and
- that no obstacles are in the way of the direction of movement;
- and
- that the engine is started.

If the warning light on the **2** switch flashes, this indicates that the system is once again available to resume the manoeuvre.

To resume the manoeuvre, press and hold the **2** switch. The **2** switch warning light appears and **P**  is displayed on the instrument panel.

Follow the instructions shown on the multimedia screen **1**.

Cancelling the manoeuvre

The manoeuvre is cancelled in the following cases:

- the vehicle is too far from the desired parking space;
- the vehicle speed has exceeded 4 mph (7 km/h);
- by pressing switch **2** or by deactivating from the multimedia screen;
- you have performed more than 14 forwards/backwards movements in one manoeuvre;
- the parking distance control sensors are dirty or blocked;
- a fault in the Park Assist system;
- the vehicle wheels have skidded.

The **2** switch warning light and the

P  warning light disappear from the instrument panel and a sound signal confirms that the manoeuvre has been cancelled. The reason for cancelling the manoeuvre will be displayed on the multimedia screen **1**.

ASSISTED PARKING (5/5)



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle. Make sure that the manoeuvre complies with the applicable traffic regulations in your location.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, towing equipment, etc.) in the blind spot when manoeuvring.

System servicing/repairs

- In the event of an impact, the alignment of the sensors may be changed and their operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the sensors are located (repairs, replacements, exterior trim modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

In the event of system disturbance


Certain conditions may disrupt or impair operation of the system, such as poor weather conditions (snow, hail, ice, etc.). In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

Risk of erroneous false alarms.

Limitations of the system operation

- The system cannot detect objects located in the sensor blind spots.
- Always visually check that the parking space proposed by the system is still available and contains no obstacles.
- The system should not be used when towing a trailer or when there is a towing or load carrying system on the vehicle or on surrounding vehicles.

VEHICLE WITH OVERSPEED FUNCTION



The vehicle speed may be permanently set at a fixed value depending on the vehicle or on local legislation.

To adjust the value or activate/deactivate the function, consult an approved dealer.

In the event of statutory limits, depending on the vehicle, this function cannot be deactivated.

Label 1 attached to the dashboard shows the speed limit.

Special case: if your vehicle is fitted with the Cruise control/Speed limiter, fully pressing the accelerator pedal (beyond the kickdown point) will not enable you to exceed the overspeed function set speed. ➔ 2.82.

In exceptional circumstances (e.g. steep gradient), the overspeed function speed may be exceeded slightly as the function does not affect the braking system.



The function does not take the place of the driver. Under no circumstances should it replace observation of speed limits nor vigilance and responsibility on the part of the driver.

EMERGENCY CALL (1/3)

If the vehicle is equipped, the emergency call function can be used to call the emergency services (without charge) automatically or manually in the event of an accident or illness, reducing the time it takes for the emergency services to arrive.

Note: the emergency call operates:


- in countries covered by the associated telematics emergency services and infrastructure compatible with the system;
- depending on the coverage in the geographical region where the vehicle is being driven.

If you use the emergency call function to report an accident which you have witnessed, this implies stopping where traffic conditions allow in order for the emergency services to locate your vehicle and therefore the location of the reported accident.

In all cases, comply with local legislation.



In the event of an accident, if the location and traffic conditions permit, stay close to the vehicle in order to be able answer the call centre quickly if necessary.




1 System operation warning light:
– green: operational (network available);
– off: non-operational (network unavailable);
– red: operating fault;
– green flashing: call in progress.

2 Automatic mode warning light;

3 SOS button;

4 Microphone;

5 Speaker.



A call is always made as follows:

- the call is set up with the emergency services;
- send data related to the incident (vehicle identification plate, local time of the call, last positions, direction of the vehicle) ;
- voice communication with the emergency services;
- if necessary, emergency assistance is called.

Emergency call has two modes:

- automatic mode;
- Manual mode.


Use the emergency call only in the event of an emergency you are involved in, if you witness an accident or if you feel ill.

EMERGENCY CALL (2/3)

Automatic mode

If the automatic mode **2** warning light appears in green this confirms that the automatic system is activated.

The emergency call starts automatically in the event of an accident that has required the activation of the protective equipment (seat belt pretensioners, airbag etc.).



Manual mode

The emergency call is carried out by:

- pressing and holding the **3** button for at least three seconds;
- or
- pressing the **3** button five times within ten seconds.

In the event of unintended operation, it is possible to cancel the call by pressing the **3** button for around two seconds, before the call is connected to the call centre.

Once a call is established, only the call centre can end the call.

Test mode

(depending on local laws)


Test mode is reserved exclusively for Approved Dealers to check that the emergency call feature is working properly.

To activate test mode:

- briefly press the **3** button three times;
- wait approximately 15 seconds;
- briefly press the **3** button three times.

Exit from test mode is automatic.

EMERGENCY CALL (3/3)



Operating faults

In some cases, the emergency call may not work (e.g. low battery).

When the system detects an operating fault, the **1** warning light turns red for over 30 minutes; consult an Approved Dealer as soon as possible.

The system operates with a dedicated battery. The battery service life is approximately four years (the **1** warning light lights up in red to warn you when approaching expiry).

Consult an approved dealer



To guarantee your safety and the proper operation of the system, any operation carried out on the battery (removal, disconnection, etc.) must be carried out by a qualified specialist.

Risk of serious burns or electric shocks.

You must respect the replacement intervals (without exceeding them) as stated in the maintenance document.

The battery is a specific type. Please ensure it is replaced with the same type.


Call an approved Dealer.

Without the emergency call feature, the system is not trackable and will not be under constant surveillance. Data is automatically and constantly erased, and the system stores only the last three positions of the vehicle.

According to local legislation, data is only sent in the event of an emergency call. Data sent to the call centre is treated according to the personal data protection laws applicable in the country where you are located. The system stores activity history data for 13 hours only.

The vehicle owner has the right of access to their data. They can request that the data be corrected, deleted or locked.

“VEHICLE DATE CONFIDENTIALITY” MODE (1/2)



58166

Data collection

To ensure the operation of connected services, your vehicle (during charging or use, once the driver's door is opened) collects data concerning mainly the vehicle position and its operation status.

These data are of a personal nature. In accordance with the regulations in force on data protection, they are treated in a confidential manner with the consent of the vehicle user.

Vehicle not fitted with a multimedia screen

The collection of vehicle data may be temporarily suspended.

To enable privacy mode:

- press **1** to enable the privacy mode;
- the **1** switch warning light goes out.

The system does not allow the collection and downloading of the vehicle data.

The services will be disabled, except for the compulsory safety functions relating to the automatic emergency call in the event of an accident ➔ 2.139.

To disable privacy mode:

- press **1** again to deactivate the confidentiality mode;
- the **1** switch warning light comes on.

The system authorises the collection and downloading of the vehicle data.

Operating faults

When the system detects an operating fault, data sharing is deactivated and the **1** switch warning light is switched off.

Please consult an authorised dealer.

Each time the driver's door is opened, the privacy mode returns to the last configuration status saved before the vehicle was locked.

The manufacturer takes all the necessary precautions to ensure that your personal data is processed in total security.

“VEHICLE DATA CONFIDENTIALITY” MODE (2/2)



Vehicle fitted with a multimedia screen 2

Please refer to the multimedia instructions for further information.

Protection of your personal data


Your personal data is collected via your vehicle and processed by the manufacturer, members of its network and the other entities in the manufacturer's group.

For further information on data processing conditions and exercising your rights, please consult the manufacturer's personal data protection policy on the manufacturer's website.

Section 3: Your comfort


| | |
|---|------|
| Air vents | 3.2 |
| Manual air conditioning, heating system | 3.5 |
| Automatic climate control | 3.9 |
| Air conditioning: programming | 3.13 |
| Air conditioning: information and advice on use | 3.15 |
| Multimedia equipment | 3.18 |
| Electric windows | 3.21 |
| Interior lighting | 3.24 |
| Sun visor, mirrors, grab handle | 3.27 |
| Passenger compartment storage, fittings | 3.28 |
| Accessories socket | 3.36 |
| Rear headrests | 3.38 |
| Rear seats: standard chassis version | 3.41 |
| Rear seats: long chassis version | 3.44 |
| Rear parcel shelf | 3.62 |
| Luggage cover | 3.63 |
| Luggage net | 3.65 |
| Luggage compartment storage space and fittings | 3.69 |
| Transporting objects in the luggage compartment | 3.70 |
| Transporting objects: towbar | 3.74 |
| Roof bars | 3.75 |
| Roof anchorage points | 3.78 |

AIR VENTS: air outlets (1/3)



57936

AIR VENTS: air outlets (2/3)



Centre air vents 4


Air flow

To close: move the cursor **9** towards the outside of the vehicle up to the point of resistance.

To open: move the cursor **9** towards the inside of the vehicle.

Direction

Move the cursor **9** to the desired position.



Side air vents 2

Air flow

To close: move the cursor **10** towards the inside of the vehicle.

To open: move the cursor **10** towards the outside of the vehicle up to the point of resistance.

Direction

Move the cursor **10** to the desired position.

Do not attach any objects to the air vents (e.g. telephone mounting).


Risk of damage.



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

There is a risk of damage or of fire.

AIR VENTS: air outlets (3/3)



Air flow

Turn control knob **12**:
up: maximum flow;
down: closed.

Rear seats

(depending on vehicle)

Passenger footwell heater outlets **7**.

Rear console air vents **8**

(depending on vehicle)

Right/left direction


Move cursor **11**.

Up/down direction

Move cursor **11**.

MANUAL AIR CONDITIONING, HEATING (1/4)

58908



The controls

- 1 Adjusting the air temperature.
- 2 "Clear View" function.
- 3 Adjusting the ventilation fan speed.
- 4 Manual heating and/or air conditioning activation control.
- 5 Passenger compartment air distribution adjustment.
- 6 Air recirculation.
- 7 De-icing/demisting of the rear screen and, depending on the vehicle, the door mirrors.

Heating can only be used when the engine is running.

Adjusting the ventilation speed

Turn control **3** to one of the eight positions to adjust the power.

Position OFF

In this position:


- the manual heating and/or air conditioning stops automatically;
- the ventilation speed of air in the passenger compartment is zero;
- there is, however, a slight flow of air when the vehicle is moving.

This position should not normally be used.

Switching on

The heating can be switched on (indicator light off) or off (indicator light on) using button **4**.

MANUAL AIR CONDITIONING, HEATING (2/4)



58908

Adjusting the air temperature

Turn the control **1** to one of the eight positions to set the temperature. The further towards the red the slide is, the higher the temperature will be. The further towards the blue the slide is, the lower the temperature will be.

Use of the  position on the **5** control leads automatically to the air flowing out in order to prevent the risk of misting on the windscreens.

Adjusting the distribution of air in the passenger compartment

Turn control **5** to choose the distribution option.

 All the air is then directed to the windscreens and front side window demisting vents.

 The air flow is distributed between front side window demisting vents, the windscreens, the footwells and the footwells.



The air flow is directed towards the dashboard vents and towards the footwells.

The air flow is mainly directed to the dashboard air vents.

The air flow is directed mainly towards the footwells.


Rear screen de-icing/ demisting

Press the **7** button: the integrated indicator light comes on. This function enables rapid demisting/de-icing of the rear screen and the rear view mirrors (on equipped vehicles).

To exit this function, press button **7** again. Demisting automatically stops.

Recommendations

In the event of freezing, manually de-ice the windscreens using a scraper rather than the de-icing/demisting function in order to reduce your energy consumption.



Clear View function

Press the **2** button: the integrated indicator light comes on.

This system quickly demists and de-ices the windscreens and the front side windows. It requires automatic activation of the heating.

To exit this function, select the adjustment required (distribution, ventilation speed, temperature, air recirculation).

Switching the air recirculation on

Press button **6**: the integrated indicator light comes on. In these conditions, air is taken from the passenger compartment and is recycled, with no air being taken from outside the vehicle.

Air recirculation is for:

- isolating the vehicle from the external atmosphere (driving in polluted areas, etc.).

Stopping the system

Turn the control **3** to “OFF” to stop the system.

Prolonged use of air recirculation can lead to condensation forming on the side windows and windscreen, and discomfort due to the use of non-renewed air in the passenger compartment. We therefore advise you to return to normal mode (external air) as soon as the air recirculation function is no longer required, by pressing button **6** again.


Immediate activation of the heating

It is possible to carry out immediate starting of the air conditioning using a smartphone application, as long as:

- the bonnet is closed;
- the traction battery charge level is over 20%;
- the doors are closed and locked;
- the engine is stopped.

For further information, please contact an approved dealer.

MANUAL AIR CONDITIONING, HEATING (4/4)



Electric windscreen de-icer

(depending on vehicle)


With the engine on, press switch **8**
(the built-in warning light comes on).

This function de-ices/demists the wind-
screen (on equipped vehicles).

To exit the function, press the switch **8**
again.

Some buttons have an operating
tell-tale which indicates the operat-
ing status.

AUTOMATIC CLIMATE CONTROL (1/4)



53361

The controls

(depending on the vehicle)

- 1 Adjusting the ventilation fan speed.
- 2 "Clear View" function.
- 3 Adjusting the air temperature.
- 4 Automatic mode.
- 5 Air conditioning control.
- 6 Distribution of air in the passenger compartment.
- 7 Air recirculation.
- 8 De-icing/demisting of the rear screen and, depending on the vehicle, the rear view mirrors.

Automatic mode

The automatic climate control system guarantees comfort in the passenger compartment and good visibility (except in the event of extreme conditions), whilst optimising consumption. The system controls the ventilation speed, air distribution, air recirculation, and starting and stopping the air conditioning and air temperature.

AUTO: allows the selected comfort level to be best attained, depending on the exterior conditions. Press button **4**.

Adjusting the ventilation speed.

In automatic mode, the system uses the most suitable amount of air to reach and maintain the desired comfort level.

You can still adjust the ventilation speed by turning control **1** to increase or reduce the ventilation speed.

Adjusting the air temperature

Turn control **3** to obtain the desired temperature.

Turning the control to the right increases the temperature.

Special note: the highest and lowest settings enable the system to produce maximum hot or cold temperature levels ("16.5°C" and "25.5°C").

Any action on a button other than the **AUTO** button triggers deactivation of automatic mode.

AUTOMATIC CLIMATE CONTROL (2/4)


Clear View function

Press the **2** button: the integrated indicator light comes on.

This function quickly demists and de-ices the windscreen, the rear screen, the front side windows, and the exterior rear view mirrors (depending on the vehicle).

Press button **8** to stop the heated rear screen operating, and the integrated indicator goes out.

To exit this function, press button **2** or **4**.



53961

Adjusting the distribution of air in the passenger compartment

Turn control **6**. The integrated warning light in the button comes on.

 All the air is then directed to the windspeed and front side window demisting vents.

 The air flow is distributed between front side window demisting vents, the windspeed demisting vents and the footwells.



The air flow is directed towards the dashboard air vents, the front footwells and, depending on the vehicle, the second row footwells.



The air flow is mainly directed to the dashboard air vents.



The air flow is directed mainly towards the footwells.

Some buttons have an operating tell-tale which indicates the operating status.

AUTOMATIC CLIMATE CONTROL (3/4)



53361

Rear screen de-icing/ demisting

Press button **8** – the integrated indicator light comes on. This function enables rapid demisting or de-icing of the rear screen and de-icing of the door mirrors (on equipped vehicles).

To exit this function, press button **8** again. Demisting automatically stops.


Switching air conditioning on or off

In automatic mode, the system switches the air conditioning system on or off, depending on the climate conditions.

Press the button **5** to force the air conditioning to stop. The integrated warning light will go out.



**Do not open the refriger-
ant fluid circuit.** The fluid
may damage eyes or skin.



Electric windscreen de-icer


(depending on vehicle)

With the engine on, press switch **9** (the built-in warning light comes on).

This function de-ices/demists the windscreen (on equipped vehicles).

To exit the function, press switch **9** again.

AUTOMATIC CLIMATE CONTROL (4/4)



53961

Stopping the system

Turn the control 1 to "OFF" to stop the system. To start it, turn the control 1 again, then adjust the fan speed or press the button 4.

Air recirculation (isolation of the passenger compartment)

This function is managed automatically but you can also activate it manually. In this case, the operation is confirmed by a warning light on the button 7.

Manual use

Press the 7 button: the integrated indicator light comes on.

Prolonged use of this position may lead to odours, caused by non-renewal of air, and the formation of condensation on the windows.

To avoid this, air recirculation is disabled automatically after a certain time.

Using the demisting/de-icing function will disable the air recirculation.

Electric energy consumption increases when the air conditioning is being used (switch it off when it is not required).

AIR CONDITIONING: programming (1/2)




With the engine on and the vehicle stationary, from the multimedia screen 1 select the "Settings" menu, the "Vehicle" tab, the "EV programming" menu 2 then the "Climate" tab 4.

Programming the departure time

Press "Edit" 3 to access the comfort settings.

You may store multiple comfort programs.




You can activate/deactivate the saved programmes.

Select the time and date 5 for the schedule that you wish to change to access the settings.

Programmed times are displayed in area A.

Note: you can program the air conditioning using a smartphone application. Please refer to the multimedia instructions for further information.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

In hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

AIR CONDITIONING: programming (2/2)

Note:

- You can deactivate the comfort programs by pressing “OFF”;
- the minimum time period between each programme is two hours;
- depending on the vehicle, the selected temperature is displayed on the 2 menu.

“Programme” activation

The function launches before the time scheduled by the customer, so that the vehicle reaches a comfortable temperature by the time they arrive, if:

- the vehicle is connected to the electrical supply;
- the bonnet is closed;
- the traction battery charge level is over 20%;
- the doors are closed and locked;
- the engine is stopped.



Warning light  comes on the instrument panel.

Note: if your vehicle is not connected, your programme is reduced to 10 minutes in order to maintain vehicle range.

Immediate activation of the air-conditioning

It is possible to carry out immediate starting of the air conditioning using a smartphone application, as long as:

- the bonnet is closed;
- the traction battery charge level is over 20%;
- the doors are closed and locked;
- the engine is stopped.

Please refer to the multimedia instructions for further information.

Stopping the programmed air conditioning

The air conditioning stops automatically around ten minutes after the set end time.

However, the function can be deactivated if:

- the engine is running;
- the charging socket is disconnected;
- the traction battery charging level is lower than 20%;
- the bonnet is open.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

In hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

AIR CONDITIONING: information and operating instructions (1/3)

Advice on use

In some situations (air conditioning off, air recirculation activated, ventilation speed at zero or low, etc.) you may notice that condensation starts to form on the windows and windscreen.

If there is condensation, use the “**Clear View**” function to remove it, then use the air conditioning in automatic mode to stop it forming again.



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

There is a risk of damage or of fire.

Fuel consumption

You will normally notice an increase in fuel consumption (especially when driving in town) when the air conditioning is operating.

For vehicles fitted with air conditioning with no automatic mode, switch off the system when it is not required.

Advice for reducing consumption and helping to preserve the environment

Drive with the air vents open and the windows closed. If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

Maintenance

Refer to the Maintenance Document for your vehicle for the inspection frequency.

Use the air conditioning system regularly, even in cold weather, running it at least once a month for approximately 5 minutes.

Operating faults

As a general rule, contact your approved dealer in the event of an operating fault.

– **Reduction in de-icing, demisting or air conditioning performance.**

This may be caused by the passenger compartment filter cartridge becoming clogged.

– **No cold air is being produced.**

Check that the controls are set correctly and that the fuses are sound. Otherwise, switch off the system.

Presence of water under the vehicle

After prolonged use of the air conditioning system, it is normal for water to be present under the vehicle. This is caused by condensation.



Do not open the refrigerant fluid circuit. The fluid may damage eyes or skin.

AIR CONDITIONING: information and operating instructions (2/3)

The refrigerant fluid circuit (of which some components are hermetically sealed) may contain fluorinated greenhouse gases.



Do not open the refrigerant circuit. The fluid may damage eyes or skin.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.2 or

➔ 2.3.

Refrigerant fluid R-134a

Depending on the vehicle, you will find the following information on label **A** affixed inside the engine compartment.

The presence and location of the information on label **A** depends on the vehicle.



Type of refrigerant fluid



(XXX) Type of oil in the air conditioning circuit



Consult the driver's handbook



Maintenance

x.xxx kg


Quantity of refrigerant fluid present in the vehicle.

GWP xxxx


Global Warming Potential (CO₂ equivalent).

CO₂ eq x.xxx t

Quantity in weight and in CO₂ equivalent.



59951



59945

AIR CONDITIONING: information and operating instructions (3/3)

Refrigerant fluid R-1234yf

Depending on the vehicle, you will find the following information on label **B** affixed inside the engine compartment.

The presence and location of the information on label **B** depends on the vehicle.



Type of refrigerant fluid



(XXX) Type of oil in the air conditioning circuit



Inflammable product



Consult the driver's handbook



Maintenance

x.xxx kg

Quantity of refrigerant fluid present in the vehicle.

GWP xxxx

Global Warming Potential (CO₂ equivalent).

CO₂ eq
x.xxx t

Quantity in weight and in CO₂ equivalent.


59944



59952




MULTIMEDIA EQUIPMENT (1/3)



The location and operation of equipment may vary according to the vehicle.

- 1 USB sockets;
- 2 Multimedia screen;
- 3 Multimedia socket;
- 4 Steering column controls;
- 5 Radio.


Please refer to the multimedia instructions for further information.



Multimedia socket 3

You can use USB socket to access the multimedia content of your accessories. The various sources can be selected from the multimedia screen and from the steering column controls.

The USB ports can also be used to recharge accessories which have been approved by our Technical Department and have a maximum power rating of 12 Watts (5 V) per port.



Sockets USB 1




The sockets USB can only allow recharge accessories approved by the brand's Technical Services of power not exceeding 12 watts (voltage 5 V) per outlet.



Connect accessories with a maximum power of 12 watts only.

Fire hazard.

MULTIMEDIA EQUIPMENT (2/3)





Steering wheel controls 6

On those vehicles equipped, you can use the "hands-free" telephone 7 and voice recognition 8 controls.


Microphone 9
(depending on the vehicle)

Wireless charger - Induction charging 10
(depending on the vehicle)


► 3.28




MULTIMEDIA EQUIPMENT (3/3)



55814



55816



55815

Telephone holder 11

On equipped vehicles, open the storage compartment **A** and insert the phone holder into one of the locations **16** while pressing the button **14**.

To place your smartphone in the **12** holder:

- move the clips **15**;
- place your smartphone in the phone holder **12** while pressing the clips **15**;
- release the clips so that the smartphone is held firmly in place.



Make sure that the base of the telephone holder is correctly fitted and that the telephone is securely held in place in the telephone holder, so that it is not thrown onto the occupants during sudden turning or braking.



For safety reasons, carry out any adjustments when the vehicle is not being driven.

ELECTRIC WINDOWS (1/3)

Electric windows

These systems operate with the ignition on or off, until one of the front doors is opened (limited to about 3 minutes).


Press the switch for the window concerned to lower it to the desired height.

Lift the switch to raise the window to the desired height.

From the driver's seat

Operate the switches as follows:

- **1** for the driver's side;
- **2** for the front passenger side;
- depending on the vehicle, **3** and **5** for the rear passengers;
- **4** to lock the rear windows.



55160



Safety of rear occupants

The driver can prevent operation of the rear electric windows by pressing switch **4**. A confirmation message is displayed on the instrument panel.



Driver's responsibility


Never leave your vehicle with the card or key inside, with a child, adult who is not self-sufficient or a pet in the vehicle, even for a short while.

They may pose a risk to themselves or to others by starting the engine or activating equipment (such as the gear lever or electric windows).

If any part of the body becomes trapped, reverse the direction of the window immediately by pressing the relevant switch.


Risk of serious injury.

ELECTRIC WINDOWS (2/3)




From the front passenger seat

Press switch **6**.



From the rear seats

With the doors closed, press switch **7**.




Half-opening window

To half-open the window, turn handle **8** in the direction of the arrow, then lock it by pushing the handle. When closing it, check that it is properly locked.

Avoid resting any objects against a half-open window: there is a risk that the electric window winder could be damaged.

ELECTRIC WINDOWS (3/3)



One-touch electric window

The one-touch mode works in addition to the operation of the electric windows described previously.

It is fitted to the driver's window.

Briefly press or pull the switch **1** as far as it will go: the window will be fully raised or lowered.

Pressing the switch again while the window is moving will stop its movement.

Note: if the window detects resistance when closing (e.g. tree branch etc.), it stops and then lowers again by a few centimetres.

Operating faults

In case of a fault when closing a window, the system reverts to normal mode: pull the switch concerned up as often as necessary to fully close the window (the window will close gradually), hold the switch (still on the closing side) for one second then lower and raise the window fully to reinitialise the system.

If necessary, contact an approved Dealer.



When closing the windows, ensure that no part of the body (arm, hand, etc.) is protruding from the vehicle.

Risk of serious injury.

INTERIOR LIGHTING (1/3)



Front ceiling light 1

Press the **1** switch to activate:

- continuous lighting;
- or temporary lighting, controlled by opening one of the front doors, or by opening one of the four doors, depending on the vehicle. The light only goes out when the doors are correctly closed.
- no lighting.




Front reading lights 2 and 3


(depending on the vehicle)

Press the **2** switch or, depending on the vehicle, the **3** switch to activate:

- continuous lighting;
- or temporary lighting, controlled by opening one of the front doors, or by opening one of the four doors, depending on the vehicle. The light only goes out when the doors are correctly closed;
- no lighting.




INTERIOR LIGHTING (2/3)



Rear courtesy light (depending on the vehicle)

Press the **4** switch to activate:


- continuous lighting;
- or temporary lighting, controlled by opening one of the front doors, or by opening one of the four doors, depending on the vehicle. The light only goes out when the doors are correctly closed.
- no lighting.



Rear map reading lights (depending on the vehicle)

Press the **5** switch to activate:


- continuous lighting;
- or temporary lighting, controlled by opening one of the front doors, or by opening one of the four doors, depending on the vehicle. The light only goes out when the doors are correctly closed;
- no lighting.



Glove box light 6

Light **6** comes on when the cover is opened.


INTERIOR LIGHTING (3/3)



Luggage compartment light 7

Light 7 comes on when the luggage compartment is opened.

When the doors or luggage compartment are unlocked and opened the courtesy and footwell lights come on temporarily.



Rear interior light 8

Turning the switch 8 gives you:

- continuous lighting;
- or temporary lighting, controlled by opening one of the front doors, or by opening one of the four doors, depending on the vehicle. The light only goes out when the doors are correctly closed;
- or else the light definitively turned off.

Special features

Depending on the vehicle, remote unlocking of the doors triggers timed lighting of the passenger compartment. If one of the front or rear doors is opened, the period for which the light is switched on will start again.

Then the courtesy light and the luggage compartment light dim and go out.

The lighting timer will cut out for various reasons:

- if a door has been open for 15 minutes;
- if all the doors have been closed for 15 seconds or 5 minutes, depending on the vehicle;
- when the ignition is switched on.

SUN VISOR, MIRRORS, GRAB HANDLE



Front sun visor

Lower sun visor 2.

Courtesy mirrors

(depending on the vehicle)

Lift the cover 1.


Sun visor storage 3

This can be used for storing motorway tickets, cards, etc.



When driving, ensure the courtesy mirror cover is closed.



Risk of injury.



Child minder mirror 4

(depending on the vehicle)


The child minder mirror allows you to keep an eye on your child in the back seat. Pull downwards (movement A) to set it to its operating position.




Front 5 and rear 6 grab handles

These can be used for support by passengers while the vehicle is moving. Do not use them for getting into or out of the vehicle.

PASSENGER COMPARTMENT STORAGE, FITTINGS (1/8)



Front door storage compartments 1




Driver's dashboard upper storage compartment A

Press the button 2, place your hand in areas 3 and lift to open the storage compartment A.

It is recommended that you open the storage compartment only when the vehicle is stationary.



Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.




Open storage compartment 4



Check that the dashboard storage compartment A is correctly closed before driving the vehicle.

Risk of the driver's field of vision being obstructed if it inadvertently opens.


PASSENGER COMPARTMENT STORAGE, FITTINGS (2/8)



Storage compartment 5

Centre console storage compartment/Wireless charge - Induction charging 6

For more information on the induction charging zone, please refer to the multimedia instructions.



Dashboard storage 7




Storage compartment 8

Depending on the country and the subscription, the induction charging area 6 is also the placement area for smartphones equipped with a digital key ➔ 1.45



Ensure that no hard, heavy or pointed objects are placed in the "open" storage compartments in such a way that they may fall onto passengers during sudden turning, braking or in the event of an accident.


PASSENGER COMPARTMENT STORAGE, FITTINGS (3/8)



Cup holders 9

Depending on the vehicle, the cup holder may be equipped with retaining hooks to keep the cup in place.


This can be used to store a mobile ashtray, drink cans, etc.



Centre armrest storage compartment 11

Lift the armrest cover 10.

Centre console storage compartment 12



When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged.

There is a risk of injury if hot liquid escapes.

PASSENGER COMPARTMENT STORAGE, FITTINGS (4/8)



Front upper cab storage compartment 13

Do not use it for getting into or out of the vehicle and do not hang from it.

Do not place wet items or containers with liquid in them in the upper cab storage compartment.



Do not hang any heavy and/or sharp objects which may fall whilst driving.

Risk of injury.



Passenger storage drawer 14

If fitted on the vehicle, pull paddle 15 to open.

Glovebox

If fitted on the vehicle, pull paddle 16 to open.

Passenger storage compartment 17




PASSENGER COMPARTMENT STORAGE, FITTINGS (5/8)




Sliding side door storage compartment 18

Items stored in the sliding side door storage compartments should not stick out from the storage compartment, so as not to hamper the sliding of the door.



Storage compartment 19

Pass a hand in location 20 and pull to open the storage compartment 19.




Rear seat storage pockets 21


Rear parcel shelves 22

Raise them to their horizontal position.

Note: the maximum permissible load on the parcel shelf is 5 kg, evenly distributed.



PASSENGER COMPARTMENT STORAGE, FITTINGS (6/8)




Storage compartment 23 under front passenger seat (for vehicles fitted with front bench seat for two)


To get to it:

- pull the front of the bench seat cushion **C** as far as the stop;
- then, lift the rear section **B** of the cushion and pivot the seat base.

Maximum load weight allowed in the storage area 23: 10 kg.



To replace the seat, proceed in reverse:
– lift the bench seat cushion so as to position the rear section **B** of the cushion under the seatback;
– push down on the front of the cushion **C** so as to lock the seat base.
Check that the bonnet is correctly locked.



Parcel shelf 24, storage area 25, pen holder 26 and cup holder 27
(depending on the vehicle)


Lower the seatback **D** \rightarrow 1.60.
Depending on the vehicle, the cup holder may be equipped with retaining hooks to keep the cup in place. This can be used for storing a mobile ashtray, cup holder, etc.



When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged.

There is a risk of injury if hot liquid escapes.

PASSENGER COMPARTMENT STORAGE, FITTINGS (7/8)




Tray 24

To remove the parcel shelf, press control **28** (movement **E**) and raise the parcel shelf (movement **F**).

You can attach documents using the clamp **29**.

You can attach sticky notes to the dedicated area on the clamp **29**.




To refit the parcel shelf:

- insert the end **31** of the parcel shelf into the slot **30**;
- press the **28** control (movement **E**) and place the parcel shelf in the storage position;
- release the **28** control.

Note: make sure that you refit the parcel shelf properly and remove any items from the cup holder before raising the centre seatback. Check that the back of the centre seat is properly locked.

PASSENGER COMPARTMENT STORAGE, FITTINGS (8/8)



Flaps 32 at the feet of the second-row rear seats (for 7-seater vehicles)

These compartments can hold road maps, manuals, cloths, etc.






Clothes hooks 33

Depending on the vehicle, the hooks may be located on the ceiling behind the seats.

For safety reasons, these hooks may only be used to hang clothes.

Note: the maximum permitted load is 4 kg.

ACCESSORIES SOCKET (1/2)



Accessories sockets 1, 2, 3

Depending on the vehicle, they are provided to connect accessories approved by our Technical Department.






Connect accessories with a maximum power of 120 watts (12 V) only.

When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.

Fire hazard.

ACCESSORIES SOCKET (2/2)




Accessories sockets 4, 5, 6



Connect accessories with a maximum power of 120 watts (12 V) only. When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.

Fire hazard.

REAR HEADRESTS (1/3)



Standard chassis version (5-seater)

To raise it

Slide it to the required height.

To lower it

Pull it towards you and slide it to the required height.

To remove it

Raise the headrest then press tabs **1** to release it.




To refit it

Press tab **1** and insert the rods into the holes, with the notches facing forwards.

Storage position 2

Pull it towards you and lower it completely.




When the headrest is set at the lowest position, this is for storage only. It should not be in this position when a seat is occupied.



The headrest is a safety component; check that it is fitted and in the correct position.

REAR HEADRESTS (2/3)




Long chassis version (5-seater or 7-seater)

Position for use

Lift the headrest fully until it locks. Check that the bonnet is correctly locked.

To remove the headrest

Raise the headrest as far as it will go, then press button **3** or **4** and remove the headrest.



To replace it


Fit the rods into their housing and push down the headrest until it locks to set it to raised position.

Check that the bonnet is correctly locked.




The headrest is a safety component; check that it is fitted and in the correct position.

REAR HEADRESTS (3/3)




26342



Long chassis version (continued)

Storage position 5 or 6

Press button 7 or 8 and lower the headrest completely.




When the headrest is set at the lowest position, this is for storage only. It should not be in this position when a seat is occupied.



The headrest is a safety component; check that it is fitted and in the correct position.

REAR SEATS : Standard chassis version (1/3)



To move the seats forwards or backwards

Lift lever 1 to unlock the seat. Once in the desired position, release the lever and check that the seat is correctly locked.




When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).



To fold down the seatback (flat-floor position)

Seatback **A** or **B** may be folded down onto the seat base to create a flat-floor position:

- before handling, make sure that the front seats are far enough forward;
- make sure that no devices are connected to the accessories socket **5**;
- attach the seat belt to the hook **3** to avoid damaging it;
- remove the rear headrests **4**;
- move the seat backwards to lock it;



- pull the lever **2** of the seatback that you wish to fold down and lower it as far as possible.

Make sure the seat is correctly locked in position.


To raise the seatback

Make sure that the seat belt is correctly positioned. You **must** pull the handle **2**, then grab the seatback and raise it. Check that the bonnet is correctly locked.



For safety reasons, carry out any adjustments when the vehicle is not being driven.

REAR SEATS : Standard chassis version (2/3)



To access the luggage compartment

In some situations (for example, to allow access to the luggage compartment), you can tilt the seat **A** or **B**:

- move the seat forwards if necessary;
- lift the handle **6** and guide the seat forwards until it locks in place.

After use, the seat **must** be returned to its original position. Grab the seatback and fold it down.

Check that the bonnet is correctly locked.



Restriction of use

It is strictly forbidden to drive with a rear seat in the "tilted" position.



Check that the rear seat belts are positioned and operating correctly after each time the rear seats are handled.



For safety reasons, carry out any adjustments while the vehicle is stationary.

Before moving a rear seat forwards, ensure that the seat is not in the flat-floor position.

REAR SEATS : Standard chassis version (3/3)



When repositioning the seatback make sure that it is correctly locked into place.

If seat covers are fitted, make sure that these do not prevent the seatback from locking.

Make sure that the seat belts are positioned correctly.

Reposition the headrests.



When moving the rear seats:

- check that no one is near to any of the moving parts;
- check that there is sufficient space around the seat.

For safety reasons, carry out any adjustments when the vehicle is stationary.

REAR SEATS : long chassis version (1/18)





Second row rear seats

The rear seats are separate seats.

To move the seats forwards or backwards

Lift the lever **1** or, from the rear of the seat, pull the black strap **2** to unlock the seat.



Once in the desired position, release the lever **1** or handle **2** and check that the seat is correctly locked to the floor.




To tilt the seatback (comfort position)

Pull the strap **3** to unlock the seatback and tilt it to the desired position (three possible positions).

Release the strap once the seat is in the correct position **3** and ensure that the seatback is fully locked into position.





REAR SEATS : long chassis version (2/18)



To fold down a seatback (table position)

- Lower the headrest as far as it will go;
- pull the strap **3** or, from the rear of the side seat, push the handle **4** to unlock the seatback;
- fold down the seatback and release the strap **3** or the handle **4**;
- make sure you lock the seat back in place.




A table position can be created by folding the seatback (movement **A**) all the way down onto the seat base.

The seats can hold up to 80 kg in this position.



To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.

REAR SEATS : long chassis version (3/18)




To raise the seatback (table position)

- Pull the strap **3** or push the handle **4** to unlock the seatback;
- grab the seatback and raise it (movement **B**);
- check that it is correctly locked in place.



For safety reasons, carry out any adjustments while the vehicle is stationary.




To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.



When refitting the seatback, make sure it is correctly locked in place.

If seat covers are fitted, make sure these do not prevent the seatback latch from locking in. Make sure that the seat belts are positioned correctly. Reposition the headrests.

REAR SEATS : long chassis version (4/18)





Folding up a seat (folded position)

- Bring the front seats forward;
- make sure that no devices are connected to the accessories socket **5**;
- lower the headrest as far as it will go;
- move the seat as far back as possible towards the rear of the vehicle;
- fold down the seatback in the table position (movement **A**) by pulling on the strap **3** or by pushing the handle **4**;



- lift the handle **6** as far as it will go to unlock the seat, or pull the red strap **7** from the rear of the seat if you are sitting in a third-row seat;
- lift and guide the seat until it is vertical (movement **C**) in the folded position.

 To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.




REAR SEATS : long chassis version (5/18)



Restriction of use

⑧

61799





It is not permitted to drive with a seat folded down if a passenger is in another seat in the same row.

The label **8** located on the back of the seats reminds you of this.

Risk of injury.

REAR SEATS : long chassis version (6/18)



To reposition the seat

- Pull up the red strap 7 as far as it will go and lower the seat until it locks onto the floor (movement D);
- Make sure the seat is locked securely to the floor;
- Lift the seatback (movement B) by pulling the strap 3 or by pushing the handle 4.



For safety reasons, carry out any adjustments when the vehicle is not being driven.



When refitting the seat-back, make sure it is correctly locked in place.

If seat covers are fitted, make sure that these do not prevent the seatback from locking. Make sure that the seat belts are positioned correctly. Reposition the headrests.




To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.



When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).


REAR SEATS : long chassis version (7/18)




Third row rear seats

Accessing the third-row rear seats

- Move the second-row rear seat as far back as possible;
- Lower the seat headrest as far as it will go;
- Fold down the seatback (movement **A**);
- Lift the handle **6** as far as it will go to unlock the seat;



- Lift and guide the seat to the vertical position (movement **C**);
- Sit in the third-row rear seat.



To return the second-row seat to its original position:

- Pull the red strap **7** as far as it will go to return the seat to the table position (movement **D**);
- Make sure that the seat is locked securely to the floor;
- Lift the seatback by pulling on the strap **3** or by pushing the handle **4**.




When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).

When handling the seats, please guide them through the full movement.

REAR SEATS : long chassis version (8/18)



Restriction of use




Before moving a second-row seat forwards, ensure that the seat is in the table position.

The label **9** located on the back of the seats reminds you of this.



To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.


REAR SEATS : long chassis version (9/18)



To move the seats forwards or backwards

Lift the lever **10** or, from the rear of the seat, pull the black strap **11** to unlock the seat.


Once in the desired position, release the lever **10** or black handle **11** and check that the seat is correctly locked to the floor.



! When moving third row rear seats:

- Check that nobody is near any of the moving parts;
- Check that there is sufficient space around the seat;
- Check that nothing is obstructing the section of the boot reserved for storing the seat.

For safety reasons, carry out any adjustments when the vehicle is stationary.




To tilt the seatback (comfort position)

Pull the strap **12** to unlock the seatback and tilt it to the desired position (three possible positions).


Release the strap once the seat is in the correct position **12** and ensure that the seatback is fully locked into position.

REAR SEATS : long chassis version (10/18)




To fold down a seatback (table position)

- Lower the headrest as far as it will go;
- Pull the strap **12** or, from the rear of the seat, push the handle **13** to unlock the seatback;
- Fold down the seatback and release the strap **12** or the handle **13**;
- Make sure you lock the seat back in place.



! Make sure that the seatback is correctly locked. If necessary, remove any obstacles behind the seats. Repeat the procedure until the seat is correctly locked.





A table position can be created by folding the seatback (movement **E**) all the way down onto the seat base.

The seats can hold up to 80 kg in this position.

! To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.

REAR SEATS : long chassis version (11/18)



To raise the seatback (table position)

- Pull the strap **12** or push the handle **13** to unlock the seatback;
- Grab the seatback and raise it (movement **F**);
- Check that it is correctly locked in place.



For safety reasons, carry out any adjustments while the vehicle is stationary.




To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.



When refitting the seatback, make sure it is correctly locked in place.


If seat covers are fitted, make sure these do not prevent the seatback latch from locking in. Make sure that the seat belts are positioned correctly. Reposition the headrests.

REAR SEATS : long chassis version (12/18)




Folding up a seat (folded position)

- Push the second-row seats fully forward;
- Lower the headrest as far as it will go;
- Move the seat as far back as possible towards the rear of the vehicle using the black strap **11**;
- Fold down the back of the seat in the table position (movement **E**) using the handle **13**;



- Pull the red strap **14** from the rear of the seat to unlock it;
- Lift and guide the seat until it is vertical (movement **G**) in the folded position.

! When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).




When moving third row rear seats:

- Check that nobody is near any of the moving parts;
- Check that there is sufficient space around the seat;
- Check that nothing is obstructing the section of the boot reserved for storing the seat.

For safety reasons, carry out any adjustments when the vehicle is stationary.

REAR SEATS : long chassis version (13/18)




To reposition the seat

- Pull the red strap **14** as far as it will go and lower the seat (movement **H**) until it locks onto the floor;
- Make sure the seat is correctly locked in position;
- Lift the seatback (movement **F**) by pushing the handle **13**.



No person or animal should be on the third row rear seats if the luggage compartment cover is not removed.



When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).



When moving third row rear seats:

- Check that nobody is near any of the moving parts;
- Check that there is sufficient space around the seat;
- Check that nothing is obstructing the section of the boot reserved for storing the seat.

For safety reasons, carry out any adjustments when the vehicle is stationary.

REAR SEATS : long chassis version (14/18)

15



61798


Restriction of use



It is not permitted to drive with one of the seat backs or a second row seat folded down if a passenger is in one of the third row seats.


The label 15 located on the back of the seats reminds you of this.

Risk of injury.



16

61799




It is not permitted to drive with a seat folded down if a passenger is in another seat in the same row.

The label 16 located on the back of the seats reminds you of this.

Risk of injury.

REAR SEATS : long chassis version (15/18)




Second-row and third-row rear seats

To remove the seats

The second-row and third-row seats can be removed for transporting bulky objects. They are fitted with a connector to indicate the presence of the seat on the vehicle and/or the presence of a passenger on the seat and its belt ➔ 1.69.


- Fold the seat into the folded position, and remove the flap **20**;
- Disconnect the connector **17** by moving the red tab **19**;



- Press the area **18** around the connector and pull it at the same time to disconnect it;
- Ensure the disconnect by manipulating the connector without pulling the cable **21**;
- Attach the cable **21** from the connector to the clip **22**;
- Replace the flap **20**.



To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.



To remove the seat:

- Pull the release switch **23** indicated with a red marking and hold it to tilt the seat to 45°;
- Guide the seat to the table position.

You can then remove the unlocked seat from the vehicle.




For safety reasons, carry out any adjustments when the vehicle is not being driven.

The rear seat is heavy. For your own safety, please handle it carefully.

REAR SEATS : long chassis version (16/18)


24



59966



26



To install seats

Before fitting a seat, check that it is in the correct position in the vehicle.

The information can be found on the label 24 located on the back of the seat.


The seats must not be swapped.




When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).

- Attach the hooks 25 to the anchorage point 26 marked with an arrow 27 by gently lifting the back of the seat;
- Move the seat as far forward as possible (movement J);
- The release switch 23 locks, accompanied by a locking noise;
- Reconnect the connector 17.

61169




REAR SEATS : long chassis version (17/18)




To install seats (continued)

To connect the connector **17**:

- Remove the flap **20**;
- Unhook the cable **21** from the connector on the clip **22**;




- Plug in the connector **17** and lock the red tab **19**;
- Reposition the cable **21** in the carpet recess **28**;
- Replace the flap **20**.



When refitting a seat in the vehicle, be sure to reconnect the seat connector. If this is not the case, the seat belt buckle information will not be shown on the instrument panel ➔ 1.69.

REAR SEATS : long chassis version (18/18)



To install seats



(continued)

To place the seats in the position of use:

- Pull the red strap **29** as far as it will go;
- Lower the seat and guide it until it locks onto the floor (movement **K**).

Make sure the seat is correctly locked in position.

Raise the seatback (movement **L**).



After replacing the connector **17** and closing the flap **20**, it is essential to pull the red strap **29** before folding down the seat.

The label **30** located on the back of the seats reminds you of this.




When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).



To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts.

REAR PARCEL SHELF




The shelf is made up of two rigid sections.

There are two possible positions:

– top position **A**;

In this case, you can fold section **2** onto section **1** by lifting it as shown by the arrow.



– Storage position **B**.

To store the parcel shelf, slide it into the runner **3** behind the rear bench seat-back.



Do not place any heavy or hard object on the parcel shelf. These may pose a risk to the vehicle occupants if the driver has to brake suddenly or if the vehicle is involved in an accident.

LUGGAGE COMPARTMENT COVER (1/2)




To remove the flexible section of the luggage cover

On equipped vehicles, it can be installed in two positions:

- behind the second row seats (position **A**). In this case, the third row seats must either be in the table position, in the folded position or removed from the vehicle.
- behind the third row seats (position **B**).

Ensure that each strap **1** is securely fixed in its tab **2**.





Pull the handle **3** gently to release the pins **4** from their anchoring points **6** located on each side of the luggage compartment, then roll up the luggage cover **5**.




Guide the luggage cover onto the roller **5**.

To roll out the flexible section of the luggage cover, proceed in the reverse order.

It is prohibited to fit the luggage cover behind the second row seats if there are passengers on the third row seats.



LUGGAGE COMPARTMENT COVER (2/2)



Removing the luggage cover

Using the 3 handle, pivot the flexible section of the luggage cover 5 upwards (movement **C**) to access the 7 stops at the ends.

Push the right-hand stop 7 to the left (movement **D**) and lift the right-hand side (movement **E**) to remove the inertia reel from its housing.

Refitting the luggage compartment cover

Engage the left-hand side of the luggage cover 5, push the right-hand stop 7 towards the left and then lower the right-hand side of the inertia reel into its housing.



Do not place any heavy or solid objects on the luggage cover. These may pose a risk to the vehicle occupants if the driver has to brake suddenly or if the vehicle is involved in an accident.

Luggage compartment cover storage


You can store the luggage cover 5 directly on the floor.

Position the luggage cover roller 5 in the housing points 8.



No person or animal should be on the third row rear seats if the luggage compartment cover is not removed.

LUGGAGE NET (1/4)




On equipped vehicles, the luggage net can be used, when transporting animals or luggage, to separate them from the passenger section.

It is fitted behind the rear seats or behind the driver and front passenger seats.



The luggage net is designed to retain a maximum weight of 10 kg.


Risk of injury.



Fitting the luggage net behind the rear seats (standard chassis)

Inside the vehicle and on each side:

- Insert the top rod **4** of the net into the anchorage points **3** (the opening of the net **A** must be positioned on the right-hand side of the vehicle);
- pass the lower straps **5** of the net through the anchorage points **6**;
- then insert them into the **7** net locking system;




- adjust the net strap **5** so that it is taut.



The luggage net must not be used to attach objects.

Risk of injury.

LUGGAGE NET (2/4)




Fitting the luggage net behind the front seats (standard chassis)

Inside the vehicle and on each side:



- place the entire bench seat in the flat-floor position ➔ 3.44;



Do not install the luggage net in this position when a passenger is occupying a rear seat.



- lift the covers **2** to access the anchorage points **1**;
- insert the upper rod **4** of the net into the anchorage points **1**;
- remove the covers **8** to access the anchorage points **9**;
- pass the lower straps **5** of the net through the anchorage points **9**;
- then insert them into the **7** net locking system;
- adjust the strap **5** of the net so that it is taut (adjust the right-hand strap first).



LUGGAGE NET (3/4)




Fitting the luggage net behind the rear seats (long chassis)

It is fitted behind the second row rear seats.

Inside the vehicle and on each side:

- push the second row seats fully forward;
- place the third row seats in the folded position or remove them;
- insert the upper rod **11** of the net into the anchorage points **10**;





- attach the two hooks **13** for the net straps **12** to the anchorage points **14**;
- adjust the net strap **12** so that it is taut;
- adjust the position of the second row seats: ensure that the seatbacks do not touch the luggage net.



Do not install the luggage net in this position when a passenger is occupying a rear seat.

The label **A** located on the side of the separation net reminds you of these instructions.

LUGGAGE NET (4/4)



Fitting the luggage net behind the front seats (long chassis)


It is fitted behind the driver and front passenger seats.

Inside the vehicle and on each side:


- place the rear seats in the folded position or remove them;
- lift the covers **16** to access the anchorage points **15**;
- insert the upper rod **17** of the net into the anchorage points **15**;

- remove the covers **18** to access the anchorage points **19**;
- attach the two hooks **21** for the net straps **20** to the anchoring points **22**;
- adjust the net strap **20** so that it is taut;
- adjust the position of the front seats: ensure that the seatbacks do not touch the luggage net.

 The luggage net is designed to retain a maximum weight of 10 kg.
Risk of injury.




LUGGAGE COMPARTMENT STORAGE SPACE AND FITTINGS



Anchorage points

Attachment points 1.



Bag hooks 2


Maximum weight per hook: 5 kg.

Storage compartment A

Unclip the access flap 3.

Charging cable storage strap

Use the strap 4 to attach and store the cable once you have wound it up.



Cup holders 5

(depending on the vehicle)

Storage compartment 6

(depending on the vehicle)



Ensure that no hard, heavy or pointed objects are placed in the "open" storage compartments in such a way that they may fall onto passengers during sudden turning, braking or in the event of an accident.

TRANSPORTING OBJECTS IN THE LUGGAGE COMPARTMENT (1/4)

Always position the objects transported so that the largest surface is against:

- the rear bench seatback, for normal loading (example **A**);

55503



- the front seatbacks with the rear seatbacks folded down, as is the case for maximum loads (example **B**);

55825



- the front seatbacks when the second and/or third-row rear seats are in the folded position or removed from the vehicle ➔ 3.44 (example **C**).


61804



Ensure that the objects being transported are evenly distributed throughout the loading area.

If you have to place objects on the folded seat back, it is vital that you remove the headrests before folding the seat back so that it can be folded as flat as possible against the seat.

Heavy objects must not be transported on the rear seats when the seatbacks are folded into the table position.




55505



Always position the heaviest items directly on the floor. Use the lashing points **1** on the boot floor, if these are fitted to the vehicle. The luggage should be loaded in such a way that no items will be thrown forward and strike the occupants if the driver has to brake suddenly. Fasten the rear seat belts, even if the seats are not occupied.


TRANSPORTING OBJECTS IN THE LUGGAGE COMPARTMENT (2/4)



Transporting objects in the rear load area

Depending on the vehicle, rotating rings **2** and **3** can be used to prevent transported objects from moving. The number of rings and their locations may vary depending on the vehicle.

The sole purpose of these rings **2** is to prevent transported objects from moving. The objects must be secured to the mounting rings **3** on the vehicle floor beforehand.



31412

Special note for van version

Rotary rings 3:
 $F_{\text{max}} : 400 \text{ daN}$



For your safety, check that all the vehicle's doors are properly closed before starting the engine.






While driving with the right rear hinged door open, always secure transported loads. The left-hand door, which remains shut, should not be used to hold transported loads in place. Using the right rear hinged door open while driving should only be done in exceptional cases.

In any event, please refer to local legislation.

Risk of loads falling on the road surface.

TRANSPORTING OBJECTS IN THE LUGGAGE COMPARTMENT (3/4)



“Open Sesame” version

Depending on the width and length of objects carried in the rear load area, use the front passenger door and sliding side door openings.

To do this, pivot the partition 4. Please observe the procedure when pivoting the partition → 1.67.

Recess 8 and roof rack 7 (depending on the vehicle)


Depending on the length of the objects being transported in the rear load area, you can use the recess 8 or the roof rack 7.

Position for use

With the roof rack in the storage position, pull the lever 6 downwards to unlock the roof rack, then hold the roof rack bar 5 and pull it towards you until it locks (movement C).

The roof rack locks automatically. Check that the bonnet is correctly locked.


TRANSPORTING OBJECTS IN THE LUGGAGE COMPARTMENT (4/4)



Always secure the transported loads using the rings 9.

Make sure that you abide by the maximum authorised length and load weight.

Prepare any protections that may be required and adapt your driving to minimise the movement of the transported load and to avoid damaging the vehicle or the load.



Storage position

With the roof rack in the operating position, pull the handle 6 downwards to unlock the roof rack, hold the roof rack bar 5 and push it upwards until it locks (movement D).

The roof rack locks automatically. Check that the bonnet is correctly locked.

55665

Maximum permissible load weight on roof rack 7: 30 kg evenly distributed.

Maximum load length:

- standard chassis: 2 metres;
- long chassis: 2.5 metres.

When handling the roof rack, ensure that nobody is near the moving parts.

TRANSPORTING OBJECTS towbar

Permissible nose weight, maximum permissible towing weight braked and unbraked: \rightarrow 6.7.

Choice and fitting of towing equipment

Maximum weight of towing equipment:


- 7.3 kg on a vehicle with towing pre-equipment;
- 28.5 kg on a vehicle without towing pre-equipment.

It is not permitted to fit a mechanical towing device (ball, hook, etc.) that is removable without tools or retractable if it cannot be easily removed or repositioned when not in use.

For fitting and conditions of use, refer to the equipment's fitting instructions.

Please keep these instructions with the rest of the vehicle documentation.

24981



Dimension A (maximum)

Standard chassis
A = 935 mm.

Long chassis
A = 975 mm.

24982




Any towing device must not obstruct any lighting component or the number plate when not in use. Mechanical towing devices (ball, hook, etc.) which can be removed without tools and retractable objects must be removed or repositioned when they are not in use.

In all cases, you must comply with the regulations of the particular country you are in.

ROOF BARS (1/3)

55388



55389



(B)

55392



(C)

Modular roof bars

Before transporting a load on the modular roof bars, they must be set to their operating position:

- unclip the levers **1** (movement **A**);
- raise the bars sufficiently to allow them to be pivoted (figure **B**);
- lock the bars in the transverse position by clipping the levers **1** (figure **C**);
- check that they are correctly locked.

When handling, ensure that the bars do not touch the vehicle roof as they may scratch the roof.


 Make sure that the two roof bars are correctly positioned and locked.

It is strictly forbidden to place the modular roof bars in the transverse position (carrying position) when entering a roller-type car wash.

Maximum weight on each roof bar: 40 kg evenly distributed (80 kg over two roof bars).

ROOF BARS (2/3)

55390



To slide the bar

Roof bar **2** can be slid to move it closer to or further from the other bar (figure **D**).

There are two positions: centre or rear.

With the bar unlocked, pull it towards the front or the rear of the vehicle to slide it in rail **3**.

55391



Once you have chosen the position, pivot the bar and lock it in the transverse position (figure **E**).

Check that both bars are correctly locked in position.

When not using the bars in transverse position, refit the bars in longitudinal position in order to optimise fuel consumption and avoid air noise.



Check that the objects and/or accessories (bike rack, roof box, etc.) fitted to the roof bars are correctly positioned, evenly distributed and secured.

ROOF BARS (3/3)



Longitudinal roof bars

If fitted on the vehicle, you can transport luggage or additional equipment (bike racks, ski racks, etc):

- on a roof rack;
- on transverse roof bars which must in turn be attached to roof bars fitted lengthways **4**;
- directly onto the longitudinal roof bars.


For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer. Refer to the manufacturer's instructions for information on how to fit and operate the equipment.

Please keep these instructions with the rest of the vehicle documentation.

Maximum weight on each roof bar: 40 kg evenly distributed (80 kg over two roof bars).

It is forbidden to attach any carrying device on the roof for vehicles not originally fitted with longitudinal or modular roof bars.

ROOF ANCHORAGE POINTS



Unscrew the blanking covers **1** in order to access the mounting points.

55393
3.78

User precautions

Handling the tailgate

Before operating the tailgate, check the objects and/or accessories (bike rack, roof box, etc.) fitted on the roof bars: these must be correctly positioned and secured, and must not prevent the tailgate from operating correctly.

For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.

Refer to the fitting instructions for information on how to fit roof bars and conditions of use.

Please keep these instructions with the rest of the vehicle documentation.

Maximum permissible load on roof: 100 kg (including carrying devices).



If original roof bars, approved by our Technical Department, are supplied with screws, only use these screws for attaching the roof bars to the vehicle.

Section 4: Maintenance

| | |
|---------------------------------------|------|
| Bonnet | 4.2 |
| Levels | 4.4 |
| coolant | 4.4 |
| brake fluid | 4.5 |
| windscreen washer reservoir | 4.5 |
| Secondary 12 V battery | 4.6 |
| Tyre pressure | 4.8 |
| Bodywork maintenance | 4.10 |
| Interior trim maintenance | 4.13 |
| | 4.1 |

BONNET (1/2)




To open the bonnet, open a door and pull the **1** handle, located on the left-hand side of the dashboard.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.2
➔ 2.3.



Do not press down on the bonnet: there is a risk that the bonnet may accidentally close.



Opening the bonnet


To unlock, gently lift the bonnet and push tab **2** in the direction of arrow **A** to release the bonnet.

Lift the bonnet, guiding it up, and it will rest in position with the help of two struts **3**.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

Risk of injury.



After any procedure in the engine compartment, make sure that you do not forget anything (cloth, tools, etc.). These may damage the engine or cause a fire.

BONNET (2/2)

Closing the bonnet

Before closing the bonnet, make sure that nothing has been left in the engine compartment.

To close it again, hold the bonnet in the middle and lower it to 25 cm above the closed position, then release it. Ensure that the bonnet is properly closed. If it does not lock itself under its own weight, gently push it until it fully locks.



Ensure that the bonnet is properly locked. Check that nothing is preventing the catch from locking (gravel, cloth, etc.).



In the event of even a slight impact involving the radiator grille or bonnet, have the bonnet lock checked by an approved dealer as soon as possible.



The vehicle drive system in an electric vehicle uses a direct voltage of approximately “400 V”.

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.


Any intervention or modification on the vehicle’s “400 V” electrical system (components, cables, connectors, traction battery) is strictly prohibited.

Risk of serious injury and/or electric shock which may endanger life.

The engine cooling fan may also start at any moment. The  label in the engine compartment reminds you of this.

Risk of injury.

LEVELS (1/2)



Coolant

The level is checked with the engine switched off and on flat ground. The level **when cold** must be between the "MINI" and "MAXI" marks on the coolant reservoir 1.

Top this level up **when cold** before the "MINI" mark is reached.



Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.

Checking intervals

Check the coolant level regularly (very severe damage is likely to be caused to the engine if it runs out of coolant).

If the level needs to be topped up, only use products approved by our Technical Department which ensure:

- protection against freezing;
- anticorrosion protection of the cooling system.

Note: for a new vehicle in the running-in phase: the coolant level may be higher than the "MAXI" mark on the tank, then drop to between the "MINI" and "MAXI" marks. This does not present a risk.

Replacement intervals

Refer to the Maintenance Document for your vehicle.



The vehicle drive system in an electric vehicle uses a direct voltage of approximately "400 V".

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.

Any intervention or modification on the vehicle's "400 V" electrical system (components, cables, connectors, traction battery) is strictly prohibited.

Risk of serious injury and/or electric shock which may endanger life.

The engine cooling fan may also start at any moment. The  label in the engine compartment reminds you of this.


Risk of injury.



No operations should be carried out on the cooling circuit when the engine is hot.

Risk of burns.

LEVELS (2/2)



(O) Brake fluid

The level should be read with the engine switched off and on level ground. This should be checked frequently, and immediately if you notice even the slightest loss in braking efficiency.

Replacement intervals

Refer to the Maintenance Document for your vehicle.

If there is an abnormal or repeated drop in the fluid level, please consult an authorised dealer.


Topping up

After any operation on the hydraulic circuit, a specialist must replace the fluid. Only use fluids approved by our Technical Department (and taken from a sealed container).

Level 2

It is normal for the level to drop as the linings become worn, but it should never drop below the "MIN" warning line.

If you wish to check the disc wear yourself, you should obtain the document explaining the checking procedure from our network or from the manufacturer's website.



Windscreen washer reservoir

Topping up

Open cap 3, fill until you can see the fluid, then refit the cap.

Liquid

Screen wash product (product with antifreeze in winter).

Jets


Use a tool such as a needle to adjust the height of the windscreen washer jets.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

Risk of injury.

SECONDARY 12 V BATTERY (1/2)



58129

The secondary battery is a 12 V battery: this supplies the energy required to operate vehicle equipment (lights, windscreen wipers, audio system, etc) and certain safety systems, such as ABS.

You should not open it or add any fluid.

Maintenance/replacement

The charge status of the 12 volt battery **1** can decrease, especially if you use your vehicle:

- when the outside temperature drops;
- after extended use of energy-consuming devices with the engine switched off.



For your own safety and for the proper operation of the vehicle's electrical equipment (lights, windscreen wipers, ABS, etc.), any intervention on the secondary 12 V battery (removal, disconnection, etc.) must **categorically** be performed by a specialist professional.

Risk of serious burns or electric shocks.

Respect **categorically** the replacement intervals (without exceeding them) as stated in the maintenance document.

The battery is a specific type. Please ensure it is replaced with the same type.

Call an approved Dealer.



The vehicle drive system in an electric vehicle uses a direct voltage of approximately "400 V".

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.


Any intervention or modification on the vehicle's "400 V" electrical system (components, cables, connectors, traction battery) is strictly prohibited.

Risk of serious injury and/or electric shock which may endanger life.

The engine cooling fan may also start at any moment. The  label in the engine compartment reminds you of this.

Risk of injury.

SECONDARY 12 V BATTERY (2/2)



Label A

Observe the indications on the battery.

- 2 naked flames and smoking are forbidden;
- 3 eye protection required;
- 4 keep away from children;
- 5 explosive materials;
- 6 please consult the vehicle user manual;
- 7 corrosive substances.

Breakdown recovery

To avoid damaging your vehicle, do not recharge the secondary 12 V battery using:

- an external battery charger;
- a battery from another vehicle.

Please contact an Authorised Dealer.



Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.




Do not disconnect the secondary 12 V battery.

Risk of serious burns or electric shocks.

Do not use your electric vehicle to restart the 12 volt battery in another vehicle. The 12 volt electric power of an electric vehicle is not enough to perform such an operation.
Risk of damage to vehicle

TYRE PRESSURE (1/2)



Label A


Open the driver's door to read it.

Tyre pressures should be checked when the tyres are cold.

If the tyre pressures cannot be checked when the tyres are **cold**, increase the pressures from **0.2** to **0.3** bar (or **3 PSI**).

Never deflate a hot tyre.

55961



B: dimension of the tyres fitted to the vehicle.

C: scheduled driving speed or, depending on the vehicle, loading of the vehicle (passengers and luggage).

D: front tyre pressure.

E: rear tyre pressure.

F: tyre pressure for the emergency spare wheel.

G: emergency spare wheel dimensions.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel → 2.23.

TYRE PRESSURE (2/2)



Vehicles used fully laden (Maximum Permissible All-up Weight) and towing a trailer

The maximum speed must be limited to **62 mph (100 km/h)** and the tyre pressure increased by **0.2 bar (3 psi)** ➔ 6.7.

Risk of tyre blowouts.

Tyre safety and chain fitting: For information on servicing conditions and, depending on the vehicle version, the use of chains ➔ 5.13.



For your safety, please respect the speed limit.

When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

They must: either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an authorised dealer.

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

Risk of loss of control of the vehicle.

BODYWORK MAINTENANCE (1/3)

A well-maintained vehicle will last longer. It is therefore recommended to maintain the exterior of the vehicle regularly.

Your vehicle has been treated with very effective anti-corrosion products. It is nevertheless subject to various outside influences.

Corrosive agents in the atmosphere:

- atmospheric pollution (built-up and industrial areas);
- saline atmospheres (near the sea, particularly in hot weather);
- seasonal and damp weather conditions (e.g. road salt in winter, water from road cleaners, etc.).

Minor impacts

Abrasive action

Dust and sand in the air, mud, road grit thrown up by other vehicles, etc.

You should take a number of minor precautions in order to safeguard your vehicle against such risks.

You should

Wash your car frequently, **with the engine off**, with cleaning products recommended by our Technical Department (never use abrasive products). Rinse thoroughly beforehand with a jet:

- spots of tree resin and industrial grime;
- mud in the wheel arches and underneath the body which forms damp patches;
- **bird droppings**, which cause a chemical reaction with the paint that **rapidly discolours paintwork and may even cause the paint to peel off**;
wash the vehicle **immediately** to remove these marks since it is impossible to remove them by polishing;
- salt, particularly in the wheel arches and underneath the body after driving in areas where the roads have been gritted.

Withdraw the vegetable falls (resin, film etc.) from the vehicle regularly.

Observe the vehicle stopping distances when driving on gravelled surfaces to prevent paint damage.

Repair, or have repaired quickly, areas where the paint has been damaged, to prevent corrosion spreading.

Remember to visit the body shop periodically in order to maintain your anti-corrosion warranty. Refer to the Maintenance Document.

Respect local regulations about washing vehicles (e.g. do not wash your vehicle on a public highway).

If it is necessary to clean mechanical components, hinges, etc., spray them with products approved by our Technical Department to protect them after they have been cleaned.

We have selected special products to care for your vehicle and you can obtain these from the manufacturer's accessory outlets.

BODYWORK MAINTENANCE (2/3)

What you should not do

Wash the vehicle in bright sunlight or freezing temperatures.

Do not scrape off mud or dirt without pre-wetting.

Allow dirt to accumulate on the exterior.

Allow rust to form following minor impacts.

Do not use solvents not approved by our Technical Department to remove stains as this could damage the paintwork.

Do not drive in snow or muddy conditions without washing the vehicle, particularly under the wheel arches and body.



Degrease or clean using high-pressure cleaning equipment or by spraying on products not approved by our Technical Department:

- mechanical components (e.g.: engine compartment);
- the wheels (e.g. braking system components such as brake callipers);
- the underbody;
- the parts with hinges (e.g. inside the doors);
- the painted plastic external fittings (e.g. bumpers).

Doing this could give rise to corrosion or operational faults.



Washing the vehicle

Never wash the engine compartment, the charging connection or the traction battery with a high-pressure jet.

This risks damaging the electric circuit.

Never wash the vehicle while it is charging.

Risk of electric shock and a risk to life.

BODYWORK MAINTENANCE (3/3)

Vehicles with a matte paint finish

This type of paint requires certain precautions.

You should do the following

Wash the vehicle by hand using plenty of water, using a soft cloth or a gentle sponge.

Do not do the following

Use wax-based products (polishing).

Rub too hard.

Wash the vehicle in a roller-type car wash.

Attach stickers to the paintwork (risk of leaving marks).



Wash the vehicle using a high-pressure cleaning device.

Using a roller type car wash

Return the wiper stalk to the park position ➔ 1.183, ➔ 1.187. Check the mounting of external accessories, additional lights and rear view mirrors, and ensure that the wiper blades are secured with adhesive tape.

Remove the radio aerial mast if your vehicle is fitted with this equipment.

Remember to remove the tape and refit the antenna after washing.

Cleaning the headlights, sensors and cameras

Use a soft cloth or cotton wool. If this does not clean them properly, moisten the cloth with soapy water, then wipe clean using a soft damp cloth or cotton wool.

Finally, dry off carefully with a soft dry cloth.

Do not use cleaning products containing alcohol or utensils (e.g.: a scraper).

Cleaning stickers, decorative films, etc.

You should do the following

Use a soft cloth or cotton wool.

Moisten it with soapy water, then always wipe clean with a soft cloth or cotton wool.

Finally, carefully dry off with a soft dry cloth.

Do not do the following

Use alcohol-based cleaning products.

Use utensils (e.g. scraper).

Rub too hard.



Wash the area using a high-pressure cleaning device.

INTERIOR TRIM MAINTENANCE (1/2)

A well-maintained vehicle will last longer. It is therefore recommended to maintain the interior of the vehicle regularly.

A stain should always be dealt with swiftly.

Whatever type of stain is on the trim, use **cold** (or warm) **soapy water with natural soap**.

Detergents (washing-up liquid, powdered products, alcohol-based products) should not be used.

Use a soft cloth.

Rinse and soak up the excess.

Multimedia screen

Maintenance of the screen may depend on the type of multimedia equipment. Please refer to the multimedia instructions for further information.

Glass instrument panel

(e.g. instrument panel, clock, exterior temperature display, radio display, etc.)

Use a soft cloth (or cotton wool).

If this does not clean them properly, use a soft cloth (or cotton wool) slightly moistened with soapy water and then wipe clean with another soft damp cloth or cotton wool.

Finally, **carefully** dry off with a soft dry cloth.

Do not use products containing alcohol and/or spray fluids on the area.

Seat belts

These must be kept clean.

Use products selected by our Technical Department (approved outlets) or warm, soapy water and a sponge and wipe with a dry cloth.

Detergents or dyes must not be used under any circumstances.

Textiles (seats, door trim, etc)

Vacuum-clean the textiles **regularly**.

Liquid stain

Use soapy water.

Dab lightly (never rub) with a soft cloth, rinse and remove the excess.

Solid or pasty stain

Carefully remove the excess solid or pasty material **immediately** with a spatula (working from the edges to the centre to avoid spreading the stain).

Clean as for a liquid stain.

Special instructions for sweets or chewing gum

Put an ice cube on the stain to solidify it, then proceed as for a solid stain.

For further recommendations for maintaining the interior, and/or for any unsatisfactory results, please see an authorised dealer.

INTERIOR TRIM MAINTENANCE (2/2)

Removal/replacing removable equipment originally fitted in the vehicle

If you need to remove equipment in order to clean the passenger compartment (for example, mats), always ensure that they are correctly refitted and are the right way around (the driver's mat should be fitted on the driver's side etc.) and fit them with the components supplied with the equipment (for example, the driver mat should always be fixed using the pre-fitted mounting components).

With the vehicle stationary, always ensure that nothing will impede driving (anything obstructing the pedals, heel wedged by the mat etc.).

You should not:

Position objects such as deodorants, scents etc. near air vents as this could damage your dashboard trim.



Use high-pressure cleaning equipment or sprays inside the passenger compartment:

without careful use, this equipment could impair the correct functioning of the electrical or electronic components in the vehicle, or have other detrimental effects.

Section 5: Practical advice

| | |
|--|------|
| Puncture, emergency spare wheel | 5.2 |
| Tyre inflation kit | 5.4 |
| Tools | 5.8 |
| Wheel trims - wheel | 5.10 |
| Changing a wheel | 5.11 |
| Tyres (tyre and wheel safety, use in winter) | 5.13 |
| Headlights (changing bulbs) | 5.16 |
| Rear lights and side lights (replacing bulbs) | 5.18 |
| Interior lighting (changing bulbs) | 5.22 |
| Remote control key: battery | 5.29 |
| “Hands-free” card: battery | 5.31 |
| Fitting a radio | 5.33 |
| Installation and use of accessories: important recommendations | 5.34 |
| Fuses | 5.35 |
| Wiper blades: replacement | 5.38 |
| Towing | 5.40 |
| Operating faults | 5.43 |
| | 5.1 |


PUNCTURE, EMERGENCY SPARE WHEEL (1/2)

In case of puncture

Depending on the vehicle, either an emergency spare wheel or a tyre inflation kit is provided ➤ 5.4.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel ➤ 2.23.



Emergency spare wheel 2

This is stored in cage 4 under the floor at the rear of the vehicle.

To access the emergency spare wheel

- Open the boot lid;
- loosen the nut using the wheel-brace 1 ➤ 5.8;
- unhook the cradle, taking it by the handle 3;
- release the emergency spare wheel.

In some cases (rear puncture, vehicle loaded with towing equipment), it is necessary to raise the vehicle (using the lifting point nearest the wheel concerned) to access to the emergency spare wheel ➤ 5.11.




If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, make sure the tools are correctly positioned in their mountings: **not doing so presents a risk of injury.**

The jack is designed for wheel changing purposes only. Under no circumstances should it be used for carrying out repairs underneath the vehicle or to gain access to the underside of the vehicle.

PUNCTURE, EMERGENCY SPARE WHEEL (2/2)



56954

- attach the handle **3** by moving it slightly to the left, if necessary, to find the hook **5**;
- tighten the nut using the **1** key to refit and lock the assembly;
- check that it is correctly locked in place.

To store the wheel in the cage

- Make sure that you reposition the wheel **2** correctly in the cage, with the valve facing downwards;
- position the wheel as far to the right as possible and at the bottom of the cage **4** (movement **A**);
- ensure that the handle **3** located on the left-hand side is raised and mobile;
- lift the cage **4** by the handle **3** using your left hand, while holding down the wheel **2** at the bottom of the cage using your right hand;



If the emergency spare wheel has been stored for several years, have it checked by your Dealer to ensure that it is safe to use.

Vehicle fitted with an emergency spare wheel that differs from the other wheels:

- Never fit more than one emergency spare wheel to the same vehicle.
- The punctured wheel is wider than the emergency spare wheel, so the height of the vehicle ground clearance is reduced.
- Replace the emergency spare wheel as soon as possible with a wheel identical to the original one.
- When this is fitted to the vehicle, which must only be a temporary measure, the driving speed must not exceed the speed indicated on the label on the wheel.
- Fitting an emergency spare wheel may alter the way the vehicle usually runs. Avoid sudden acceleration or deceleration and reduce your speed when cornering.
- If you need to use snow chains, fit the emergency spare wheel to the rear axle and check the tyre pressure.

TYRE INFLATION KIT (1/4)

32788



The kit repairs tyres when tread **A** has been damaged by objects smaller than 4 mm. It cannot repair all types of puncture, such as cuts larger than 4 mm, or cuts in tyre sidewall **B**.

Ensure also that the wheel rim is in good condition.

Do not pull out the foreign body causing the puncture if it is still in the tyre.



Do not attempt to use the inflation kit if the tyre has been damaged as a result of driving with a puncture.

You should therefore carefully check the condition of the tyre sidewalls before any operation.

Driving with underinflated, flat or punctured tyres can be dangerous and may make the tyre impossible to repair.

This repair is temporary.

A tyre which has been punctured should always be inspected (and repaired, where possible) as soon as possible by a specialist.

When taking a tyre which has been repaired using this kit to be replaced, you must inform the specialist.

When driving, vibration may be felt due to the presence of the repair product injected into the tyre.



The kit is only approved for inflating the tyres of the vehicle originally equipped with the kit.

It must never be used to inflate the tyres of another vehicle, or any other inflatable object (rubber ring, rubber boat, etc.).

Avoid spillage on skin when handling the repair product bottle. If droplets do leak out, rinse them off with plenty of water.

Keep the repair kit away from children.

Do not dispose of the empty bottle in the countryside. Return it to your approved dealer or to a recycling organisation.

The bottle has a limited service life which is indicated on its label. Check the expiry date.

Contact an approved dealer to replace the inflation tube and repair product bottle.


TYRE INFLATION KIT (2/4)



Depending on the vehicle, in the event of a puncture use the kit located in the storage compartment under the flap **C** at the footwell of the front right-hand seat.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel ➔ 2.23.



With the engine running and hand-brake applied:

- Disconnect any accessories previously connected to the vehicle's accessories sockets;
- **refer to the information on the inflation kit compressor** located in the luggage compartment of the vehicle and follow the instructions;
- inflate the tyre to the recommended pressure ➔ 4.8 ;
- after a maximum of **15** minutes, stop inflating and read the pressure (on pressure gauge **2**).


Note: while the bottle is emptying (approximately 30 seconds), the pressure gauge **2** will briefly indicate a pressure of **6** bar, then the pressure drops;

- Adjust the pressure: to increase it, continue inflation with the kit. To reduce it, press the button **1**.



Before using this kit, park the vehicle at a sufficient distance from traffic, switch on the hazard warning lights, apply the handbrake, ask all passengers to leave the vehicle and keep them away from traffic.

TYRE PRESSURE KIT (3/4)



49261

If a minimum pressure of 1.8 bar is not reached after 15 minutes, repair is not possible; do not drive the vehicle but contact an approved dealer.



Nothing should be placed around the driver's feet as such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.

Once the tyre is correctly inflated, remove the kit: unclip the inflation adapter slowly from the container **3** to prevent any product spatter and store the container in plastic packaging to prevent product leaks.

- Affix the driving recommendation label (located under the container) to the dashboard where the driver can see it.
- Put the kit away.
- At the end of this initial inflation operation, air will still escape from the tyre. You must drive a short distance in order to seal the hole.
- Start immediately and drive at a speed between 12 to 37 mph (20 to 60 km/h) in order to distribute the product evenly in the tyre; after driving a distance of 2 miles (3 km), stop and check the pressure.
- If the pressure is higher than 1.3 bar but lower than the recommended pressure (refer to the label affixed to the edge of the driver's door), adjust it. Otherwise, contact an approved dealer: the tyre cannot be repaired.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, ensure that the inflation kit is correctly positioned in its support, position it correctly in its housing, attach the strap, then make sure that the inflation kit access flap is properly locked.

Risk of injury.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

TYRE INFLATION KIT (4/4)

Precautions when using the kit

The kit should not be operated for more than 15 consecutive minutes.

The container must be replaced after the first use even if liquid remains inside.




Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and may lead to pressure loss.
Always use valve caps identical to those fitted originally and tighten them fully.



Following repair with the kit, do not travel further than 120 miles (200 km). In addition, reduce your speed and under no circumstances exceed 48 mph (80 km/h). The sticker, which you must affix in a prominent position on the dashboard, reminds you of this.


Depending on the country or local legislation, a tyre repaired with the inflation kit may need to be replaced.

TOOLS (1/2)



Tool kit storage

The tool kit **1** is located under the flap at the footwell of the front right-hand seat.



Jack **2** or, depending on the vehicle, **3**

Fold it correctly before refitting it in its housing (ensure that the wheelbrace is correctly positioned **4**).

Hubcap tool **5**

This tool is used to remove the wheel trims.

Wheel bolt guide **6**

To finish loosening or starting to tighten the wheel bolts.

Towing hitch **7**


► 5.40

Wheelbrace **8**

Locks or unlocks the wheel bolts and tow ring **7**.

Depending on the vehicle, the wheelbrace can be used to raise or lower the jack **2**.

TOOLS (2/2)



55472

Storage position A in the tool kit 1

Reposition the tools in the casing and check that the assembly is correctly positioned (not doing so may result in noise).



Nothing should be placed around the driver's feet as such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, ensure that the tools are correctly placed in their support, positioned correctly in their housing, attach the strap **9**, then make sure that the tool kit access flap is properly locked.


Risk of injury.

If bolts are supplied with the emergency spare wheel, you must use these bolts only for the emergency spare wheel.

The jack is designed for wheel changing purposes only. Under no circumstances should it be used for carrying out repairs underneath the vehicle or to gain access to the underside of the vehicle.

WHEEL TRIMS - WHEEL

55473




Wheel trim with concealed wheel bolts

Remove the wheel trim using hubcap tool **1** (located in the tool kit) by engaging the hook in the opening near the valve **2**.

To refit it, align it with valve **2**. Push the retaining hooks in fully, starting with side **A** near the valve, followed by **B** and **C**, finishing at **D** opposite the valve.

55309




Wheel trim 3

Remove using hubcap tool **1** (located in the tool kit) by engaging the hook in the opening near the edge of the trim.

To refit, position the trim attachments facing the wheel attachments and press hard in the middle of the trim to clip it to the wheel.

55474



Central wheel trim with visible wheel bolts (Wheel trim **4**)


The bolts are directly accessible.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, check that all the tools are correctly clipped into the tool kit, then position them correctly in their housing.

Risk of injury.

CHANGING A WHEEL (1/2)



Vehicles equipped with a jack and wheelbrace

If necessary, remove the wheel trim.

Use the wheelbrace 3 to slacken off the wheel bolts. Position it so as to be able to push from above.

Position the jack 4 horizontally. The jack head **must** be positioned at the same level as the reinforced panel nearest to the wheel concerned.

Start cranking the jack by hand, positioning the jack support plate 1 in the slightly indented groove underneath the vehicle, located between the two notches 2.

Continue to crank the jack so that the baseplate is correctly positioned (it should be underneath the vehicle and aligned with the jack head).

Turn it a few times to lift the wheel off the ground.



Switch on the hazard warning lights.

Keep the vehicle away from traffic and on a level surface where it will not slip.

Apply the parking brake and set it to **P** position.

Ask all the passengers to leave the vehicle and keep them away from traffic.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

CHANGING A WHEEL (2/2)

Undo the bolts and take off the wheel.

Fit the emergency spare wheel on the central hub and turn it to locate the mounting holes in the wheel and the hub.

Tighten the bolts, checking that the wheel is correctly positioned on its hub.

Lower the jack.

With the wheel on the ground, tighten the bolts fully and have the tightness of the bolts checked and the emergency spare wheel pressure checked as soon as possible.



If you have a puncture, replace the wheel as soon as possible.

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel ➔ 2.23.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, ensure that the tools are correctly placed in their support, positioned correctly in their housing, attach the strap, then make sure that the tool kit access flap is properly locked.

Risk of injury.

The jack is designed for wheel changing purposes only. Under no circumstances should it be used for carrying out repairs underneath the vehicle or to gain access to the underside of the vehicle.

TYRES (1/3)

Tyre and wheel safety

The tyres are the only contact between the vehicle and the road, so it is essential to keep them in good condition.

You must make sure that your tyres conform to local road traffic regulations.

Maintaining the tyres

The tyres must be in good condition and the tread form must have sufficient depth; tyres approved by our Technical Department have wear warning strips **1** which are **indicators moulded into the tread at several points**.



Incidents which occur when driving, such as striking the kerb, may damage the tyres and wheel rims, and could also lead to misalignment of the front or rear axle geometry. In this case, have the condition of these checked by an approved dealer.



31546

When the tyre tread has been worn to the level of the warning strips, **they become visible 2**: it is then necessary to replace your tyres because the tread rubber is now only **1.6 mm deep at most, resulting in poor road holding on wet roads**.

An overloaded vehicle, long journeys by motorway, particularly in very hot weather, or continual driving on poorly surfaced minor roads will lead to more rapid tyre wear and affect safety.

Tyre pressures

Adhere to the tyre pressures (including the emergency spare wheel). The tyre pressures should be checked at least once a month and additionally before any long journey (refer to the label affixed to the edge of the driver's door).



Incorrect tyre pressures

lead to abnormal tyre wear and unusually hot running.

These are factors which may seriously affect safety and lead to:

- poor road holding;
- risk of bursting or tread separation.

The pressure depends on the load and the speed of use. Adjust the pressure according to the conditions of use (refer to the label affixed to the edge of the driver's door).

TYRES (2/3)

Pressures should be checked when the tyres are cold; ignore higher pressures which may be reached in hot weather or following a fast journey.

If tyre pressures cannot be checked when the tyres are **cold**, assume an increase of **0.2 to 0.3 bar** (or **3 PSI**).

Never deflate a hot tyre.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and lead to pressure loss.

Always use valve caps identical to those fitted originally and tighten them fully.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel, ➔ 2.23.

Emergency spare wheel

➔ 5.2, ➔ 5.11.

Changing wheels around

This practice is not recommended.

Fitting new tyres



For your safety, please respect the speed limit.

When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

They must either have a load capacity and speed rating at least equal to those of the original tyres, or be recommended by an authorised dealer.

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

Risk of loss of control of the vehicle.

TYRES (3/3)

Use in winter

Chains

For safety reasons, fitting snow chains to the rear axle is strictly forbidden.

Chains cannot be fitted to tyres which are larger than those originally fitted to the vehicle.

One-way tyres

An one-way tyre must only be fitted in one direction. You must observe this direction.

If an one-way tyre must be fitted in the opposite to its direction of rotation following a puncture, drive with caution, particularly on a wet road, because the tyre specifications will not be adapted.



Chains may only be fitted to tyres of the same size as those originally fitted to **your vehicle**.

Snow or Winter tyres

We would recommend that these be fitted to all **four wheels** to ensure that your vehicle retains maximum adhesion.

Warning: These tyres sometimes have a specific direction of rotation and a maximum speed index which may be lower than the maximum speed of your vehicle.

Studded tyres

This type of equipment may only be used for a limited period and as laid down by local legislation. It is necessary to observe the speed specified by current legislation.

These tyres must, at a minimum, be fitted to the two front wheels.




17" wheels cannot be fitted with chains.

If you wish to fit snow chains, you must use **special equipment**.


Consult an approved dealer

In all cases, we would recommend that you contact an approved Dealer who will be able to advise you on the choice of equipment which is most suitable for your vehicle.

HEADLIGHTS: changing bulbs (1/2)



55475



55499

Vehicles with halogen headlights

Dipped beam headlights

Remove cover **A**.

Tilt bulb holder **1** to release it and then replace the bulb.

Type of bulb: H7.

After replacing the bulb, please ensure that the lights are adjusted by a professional.



The bulbs are under pressure and can break when replaced.

Risk of injury.

Main beam headlights

Remove cover **B**.

Tilt bulb holder **2** to release it and then replace the bulb.

Type of bulb: H7.

Do not touch the bulb glass. Hold it by its base.

It is **essential** to use anti-U.V. 55W bulbs so as not to damage the plastic on the headlights. Mark the bulb's position before removal to ensure correct positioning when replacing.

When the bulb has been changed, make sure you refit the cover correctly.



The vehicle drive system in an electric vehicle uses a direct voltage of approximately "400 V".

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.


Any intervention or modification on the vehicle's "400 V" electrical system (components, cables, connectors, traction battery) is strictly prohibited.

Risk of serious injury and/or electric shock which may endanger life.

The engine cooling fan may also start at any moment. The  label in the engine compartment reminds you of this.

Risk of injury.

HEADLIGHTS: changing bulbs (2/2)




Daytime running lights, LED front side lights 3

Please see an authorised dealer.

LED direction indicator lights 4

Please see an authorised dealer.



LED headlights

Daytime running lights, LED front side lights 5

Please see an authorised dealer.

LED main beam headlights, dipped beam headlights 6

Please see an authorised dealer.

LED direction indicator lights 7

Please see an authorised dealer.



Before carrying out any operation in the engine compartment, you must switch off the ignition.

LED front fog lights 8


Please see an authorised dealer.



Any operation on (or modification to) the electrical system must be performed by an approved dealer since an incorrect connection might damage the electrical equipment (harness, components and in particular the alternator). In addition, your Dealer has all the parts required for fitting these units.

To comply with current legislation, or as a precaution, you can obtain an emergency kit from your approved dealer containing a set of spare bulbs and fuses.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (1/4)




Direction indicator lights, reversing lights, fog lights and brake lights

Undo bolt 1 to remove the light.



The bulbs are under pressure and can break when replaced.

Risk of injury.




Release the light assembly from outside the vehicle by pulling towards the rear.

Remove the bulb holder 3 by releasing clips 2.

Refitting

To refit, proceed in the reverse order, taking care not to damage the wiring, and fasten clips 2 on the bulb holder 3.



4 Brake light

Bulb type 4: P21W or, depending on the vehicle, PR21W.

5 Reversing light

Bulb type 5: W16W.

6 Indicator light


Bulb type 6: PY21W.

7 Fog light

Bulb type 7: P21W.

To comply with current legislation, or as a precaution, you can obtain an emergency kit from your approved dealer containing a set of spare bulbs and fuses.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (2/4)



LED side lights 8

Consult an approved dealer.


55444



High-level LED brake light 9

Consult an approved dealer.

55445



LED number plate lights 10

(depending on the vehicle)

Consult an approved Dealer.

55446

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (3/4)




Number plate light

Undo screw **11**.

Remove the light cover **12** to access the bulb.

Bulb type: W5W.



LED side repeaters **13**

Consult an approved dealer.



The bulbs are under pressure and may break when replaced.

Risk of injury.

REAR LIGHTS AND SIDE LIGHTS: replacing the bulbs (4/4)



Indicator lights 14

As the door mirror shell needs to be removed, **we advise you to have the bulb replaced by an approved dealer.**

To access the bulb:

- carefully unclip the door mirror shell **15** from its base **16** (movement **A**);
- disengage the bulb holder **17** using a flat-blade screwdriver or similar, levering at **C** (movement **B**);
- disengage and remove the bulb **18**.




Bulb type: WY5W.

To refit it, carry out the above operations in reverse order.

Make sure:

- that the bulb holder **17** is aligned correctly before inserting it into its housing;
- that the door mirror shell **15** clips properly onto its base **16**.

When disassembling and refitting, ensure that the wiring and the surrounding components are not damaged.



INTERIOR LIGHTING: changing bulbs (1/7)



Front ceiling light 1

- Unclip the lens **2** (using a tool such as a flat screwdriver), positioned at **A**;
- unclip and release the bulb holder **3** using the tabs **4**;
- remove the bulb concerned.


Type of bulb **5**: W5W.




Refitting

- Clip the lens **2** on to the bulb holder **3**;
- clip in the interior lights **1** until the unit clicks;
- ensure that the interior lights are properly positioned and locked into place.

 The bulbs are under pressure and can break when replaced.
Risk of injury.



INTERIOR LIGHTING: changing bulbs (2/7)



Front map reading lights 6

(depending on the vehicle)


- Unclip the lens 7 (using a tool such as a flat screwdriver), positioned at **B**;
- unclip and release the bulb holder 8 using the tabs 9;
- remove the bulb concerned.

Type of bulb 10: W5W.



Refitting

- Clip the lens 7 on to the bulb holder 8;
- clip in the reading spots block 6 until the unit clicks;
- make sure that the reading spots block is correctly positioned and locked into place.




INTERIOR LIGHTING: changing bulbs (3/7)



Front LED reading lights 11




Consult an approved dealer.



**Rear LED reading lights 12
and 13**

Consult an approved dealer.

INTERIOR LIGHTING: changing bulbs (4/7)



Rear reading spot 14

(depending on the vehicle)

- Unclip the lens 15 on (using a tool such as a flat screwdriver), positioned at C;
- unclip and release the bulb holder 16 using the tabs 17;
- remove the bulb concerned.

Type of bulb 18: W5W.

Refitting

- Clip the lens 15 on to the bulb holder 16;
- clip in the reading spots block 14 until the unit clicks;
- make sure that the reading spots block is correctly positioned and locked into place.




The bulbs are under pressure and can break when replaced.

Risk of injury.




INTERIOR LIGHTING: changing bulbs (5/7)



Glove box light 19

(depending on the vehicle)

Unclip light **19** using a flat-blade screwdriver or similar) by pressing on the tab **20** to move the light towards the inside of the unit.



Remove the bulb concerned.


Bulb type: W5W.



The bulbs are under pressure and can break when replaced.

Risk of injury.

INTERIOR LIGHTING: changing bulbs (6/7)




Luggage compartment light 21

Unclip light 21 (using a flat-blade screwdriver or similar), by pressing on tab 22 to move the light towards the inside of the luggage compartment.

Remove the bulb concerned.

Bulb type: W5W.



411352

Release the lens 23 and access the bulb 24.

Type of bulb 24: W5W.



The bulbs are under pressure and can break when replaced.

Risk of injury.

INTERIOR LIGHTING: changing bulbs (7/7)




Halogen rear light 25

Unclip the ceiling light diffuser using a flat blade screwdriver or similar.

Pull the bulb to remove it from its housing.

Bulb type: W6W

Replace the bulb and refit the lens.



LED rear light 26


Consult an approved dealer.

REMOTE CONTROL KEY: BATTERY: battery (1/2)



45856

40619



Replacing the battery

Open the case at slot 1 using a flat-blade screwdriver or similar, and replace the battery 2, observing the type and polarity shown on the back of the cover.



If they need to be replaced, be sure to use the same or equivalent type of battery (consult an Approved Dealer).

Note: It is not advisable to touch the electronic circuit in the key cover when replacing the battery.

When refitting, ensure that the cover is correctly clipped on and the screw tightened.

The batteries are available from approved Dealers, and their service life approximately two years.

Check that there is no dye on the battery: risk of an incorrect electrical contact.

REMOTE CONTROL KEY: BATTERY: battery (2/2)

Operating faults

If the battery is too weak to ensure correct operation, you will still be able to start and lock/unlock the vehicle
➔ 1.55.

26913



Do not throw away your used batteries; give them to an organisation responsible for collecting and recycling batteries.



When replacing:

- make sure that the batteries are correctly inserted.

Risk of explosion.

- if the flap does not close correctly, do not use and keep out of reach of children.



Precautions relating to batteries:

- keep (new or used) batteries out of reach of children;
- do not swallow batteries;

Risk of chemical burns which may lead to death.


- if ingested or inserted into any part of the body, consult a doctor as soon as possible.

“HANDS-FREE” CARD: battery (1/2)

40303



43532



Replacing the battery

When the message “Keycard Battery Low” appears on the instrument panel, replace the battery in the card:

- slide the rear casing **1** downwards while pressing on zone **A**;
- remove the battery cover **2**;
- remove the battery by pressing on one side and lifting the other;
- replace it according to the direction and template shown inside the cover.

When refitting, proceed in the reverse order, then press one of the buttons on the card four times, close to the vehicle: the next time the vehicle is started, the message will disappear.

Check that the cover is clipped shut.

Note: Do not touch the electronic circuit or contacts on the card when replacing the battery.

The batteries are available from approved Dealers, and their service life approximately two years. Check that there is no dye on the battery: risk of an incorrect electrical contact.



If they need to be replaced, be sure to use the same or equivalent type of battery (consult an Approved Dealer).



When replacing:

- make sure that the batteries are correctly inserted.

Risk of explosion.

- if the flap does not close correctly, do not use and keep out of reach of children.

“HANDS-FREE” CARD: battery (2/2)

Operating faults

If the battery is too weak to ensure correct operation, you will still be able to start and lock/unlock the vehicle
➔ 1.55.

26913



Do not throw away your used batteries; give them to an organisation responsible for collecting and recycling batteries.



Precautions relating to batteries:

- keep (new or used) batteries out of reach of children;
- do not swallow batteries;

Risk of chemical burns which may lead to death.


- if ingested or inserted into any part of the body, consult a doctor as soon as possible.

FITTING A RADIO



Radio location 1

Unclip the blanking cover. The connections: (+ aerial) and (– supply and speaker) are located behind it.



Front door speakers 2

To install any equipment, please consult an authorised dealer.

- In all cases, it is very important to follow the manufacturer's instructions carefully.
- The specifications of the brackets and wires (available from our network) vary depending on the equipment level of your vehicle and the type of radio.

Consult an approved Dealer to find out the correct part number.

- No work may be carried out on the vehicle's electrical or radio circuits, except by approved dealers: an incorrectly connected system may result in damage being caused to the electrical equipment and/or the components connected to it.

INSTALLATION AND USE OF ACCESSORIES: important recommendations



Electrical and electronic accessories

Before installing this type of accessory (particularly for transmitters/receivers: frequency bandwidth, power level, position of the aerial, etc.), make sure it is compatible with your vehicle. Contact an approved Dealer.

Before connecting an accessory to a socket, please ensure that you do not exceed the maximum power authorised for the socket ➔ 3.36 ➔ 3.18. **Fire hazard.**

Any work on the vehicle's electrical and/or electronic circuit must only be carried out by a qualified professional. Any incorrect connection and/or installation of electrical/electronic accessories not approved by the manufacturer may cause:

- damage to the electrical and/or electronic equipment;
- damage to the components connected to it;
- the collection and use of vehicle data;
- an invasion of privacy (modification, deletion or unwarranted access to personal data).

Risk of serious accidents. Risk of invasion of privacy.

If you have electrical equipment fitted in future, make sure that you are notified of the rating and position of the corresponding fuse.

Using the diagnostic socket

The use of electronic accessories on the diagnostic socket may cause serious disturbance to the vehicle's electronic systems and/or cause invasion of privacy (modification, deletion or unwarranted access to personal data). For your safety, we recommend that you only use electronic accessories approved by the manufacturer: consult an approved dealer. **Serious accident risk. Risk of invasion of privacy.**

Fitting aftermarket accessories


If you wish to install accessories on the vehicle: please contact an authorised dealer. Also, to ensure the correct operation of your vehicle, and to avoid any risk to your safety, we recommend that you use only accessories specifically designed for your vehicle, which are the only accessories for which the manufacturer will provide a warranty.

If you are using an anti-theft device, only attach it to the brake pedal.

Obstructions to the driver

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals**

FUSES (1/3)




Fuse boxes

If any electrical component does not work, check the condition of the fuses.

Fuses in the passenger compartment A

Place your hand in location **2** and pull to open the flap **1**.

Depending on the vehicle, to identify the fuses, refer to the fuse allocation label located at the back of the flap **1** and shown on the following pages.



Tweezers 3

Remove the fuse using the tweezers **3** on the back of the flap.

To remove the fuse from the tweezers, slide the fuse to the side.

It is not advisable to use the free fuse locations.

32868

To comply with current legislation, or as a precaution, you can obtain an emergency kit from your approved dealer containing a set of spare bulbs and fuses.



Check the fuse in question and **replace it**, if necessary, **by a fuse of the same rating**.

If a fuse is fitted with too high a rating, it may cause the electrical circuit to overheat (risk of fire) in the event of an item of equipment using an excessive amount of current.

FUSES (2/3)

Allocation of fuses

(the presence of certain fuse depends on the vehicle equipment level)


| Symbol | Allocation |
|---|--|
|  | Windscreen washer |
|  | Front headlights |
|  | Hazard warning lights |
|  | Horn |
|  | Towbar socket |
|  | Brake lights, passenger compartment central unit |
|  | Screen washer, rear lights |
|  | Direction indicators |
|  | Accessories socket |
|  | Electric windows |

Use the fuse allocation label in the storage compartment to identify the fuses.

Certain fuses should only be replaced by a qualified professional. These fuses are not listed on the label.

Only change the fuses represented on the label.

FUSES (3/3)



58118

Fuses in engine compartment **B**

Some functions are protected by fuses located in the engine compartment (unit **B**).

However, because of their reduced accessibility, **we advise you to have your fuses replaced by an approved Dealer.**



The vehicle drive system in an electric vehicle uses a direct voltage of approximately "400 V".

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.

Any intervention or modification on the vehicle's "400 V" electrical system (components, cables, connectors, traction battery) is strictly prohibited.

Risk of serious injury and/or electric shock which may endanger life.


The engine cooling fan may also start at any moment. The  label in the engine compartment reminds you of this.

Risk of injury.



Before carrying out any action in the engine compartment, you must switch off the ignition. ➔ 2.2 or ➔ 2.3.

WIPER BLADES: replacement (1/2)




Replacing the windscreen wiper blades 2

To replace the wipers, first put them in the service position **B**.

With the ignition on and the engine stopped:


- move the stalk twice in succession **1** to position **A** (single sweep): the wiper blades will stop in the service position **B** away from the bonnet;
- lift the wiper arm **3**;
- lower the **4** tab then remove the blade **2**.



To refit

To refit the wiper blade **2**, insert it in its housing in the arm **3**, then clip it until you hear a click. Make sure that the blade is correctly locked in position.


To return the blades to lowered position, make sure that the blades are folded down onto the windscreen then set the **1** stalk to position **A** (single sweep): the windscreen wiper blades will fold into the bonnet when the ignition is switched on.



Check the condition of the wiper blades. You are responsible for their service life:

- clean the blades, windscreen and rear screen regularly with soapy water;
- do not use them when the windscreen or rear screen are dry;
- free them from the windscreen or rear screen when they have not been used for a long time.

WIPER BLADES: replacement (2/2)



58141



58142

Rear screen wiper blade 5

Stalk in stop position (deactivated):

- lift the wiper arm **6**;
- turn the blade horizontally **5** (movement **C**) until it unclips;
- remove the blade by pulling it.

To refit

To refit the wiper blade, proceed in reverse order to removal. Make sure that the blade is correctly locked in position.

Check the condition of the wiper blades.

- clean the blades, windscreens and rear screen regularly with soapy water;
- do not use them when the windscreens or rear screen are dry;
- free them from the windscreens or rear screen when they have not been used for a long time.



– In frosty weather, make sure that the wiper blades are not stuck by ice (to avoid the risk of the motor overheating).

- Check the condition of the wiper blades. Replace the wiper blades as soon as they begin to lose efficiency (approximately once a year).

When changing the blade, when it has been removed, do not let the wiper arm fall against the window: risk of breaking the window.



Before changing the rear wiper blade, make sure the stalk is in the stop position (deactivated).

Risk of injury.

TOWING: breakdown (1/2)


Before any towing, including on a flatbed truck, put the gear control in **N** position, unlock the steering column and release the parking brake.

The speed specified by current legislation for towing must always be observed.

If you are driving the towing vehicle, do not exceed the permissible towing weight for your vehicle ➔ 6.7.

To carry out breakdown recovery on a flatbed or to tow the vehicle using a towing point (see the next page), observe the following instructions:

- Insert the key into the ignition and set to “**On**” “**ON**” position **2** or, depending on the vehicle, with the card in the passenger compartment, press the start button;
- Set the gear control to **N** position;
- The steering column unlocks. The accessories functions are supplied: you can use the vehicle lighting functions (hazard warning lights, brake lights, etc.). At night the vehicle lights must be on;



- Depending on the vehicle, after unlocking the steering column, press the engine start button for approximately two seconds;
- Depending on the vehicle, once you have finished towing, press and hold the engine start button for approximately two seconds (risk of running down the battery).

Choice of towing


It is strictly forbidden to tow the vehicle with the front wheels on the ground.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, ensure that the tools are correctly placed in their support, positioned correctly in their housing, attach the strap, then make sure that the tool kit access flap is properly locked.

Risk of injury.

TOWING: breakdown (2/2)




Only use the front 2 and rear 5 towing points (never use the driveshafts or any other part of the vehicle). These towing points may only be used for pulling. They must never be used for lifting the vehicle directly or indirectly.



Do not remove the key from the ignition switch, or leave the card in the vehicle during towing (depending on the vehicle).

Risk of the steering column locking.



Access to towing points

Front towing point 2

Unclip the cover 1 by passing the key integrated in the card in the notch **A**.

Rear towing point 5

Unclip the cover 4 by passing the key integrated in the card in the notch **B**.



Ensure that the towing eye is bolted correctly.

Risk of losing the towed object.

Tighten the towing hitch 3 fully: first by hand until it stops, then finish by locking it with the wheel brace or, depending on the vehicle, the lever.

Only use the towing hitch 3 and the wheelbrace or lever provided with the tools ➔ 5.8.



When the engine is stopped, steering and braking assistance are not operational.



– Use a rigid towing bar. If a rope or cable is used (where the law allows this), the vehicle being towed must be able to brake.

- A vehicle must not be towed if it is not fit to be driven.
- Avoid accelerating or braking suddenly when towing, as this may result in damage being caused to the vehicle.
- In all cases, it is advisable not to exceed **15.5 mph (25 km/h)**.

OPERATING FAULTS (1/7)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved dealer as soon as possible.

| FAULTS | POSSIBLE CAUSES | WHAT TO DO |
|---|--|--|
| Impossible to charge the traction battery. The charging flap warning light flashes red. | The outdoor temperature is lower than -26°C. No electrical current in the wall socket or poor connection of cable to domestic socket. | Recharge your vehicle in a more suitable environment. If necessary ➔ 5.40. Check your installation (circuit breaker, programmer, etc.). Check the connections (charging socket, etc.) ➔ 1.9. |
| | The cord is defective. | Please see an authorised dealer to replace it. |
| Impossible to charge the traction battery. The charging flap warning light flashes blue. | The charging cord is not correctly locked to the vehicle. | Plug the charging cable correctly in to the vehicle. ➔ 1.9. |
| The programmable air conditioning fails to work. | One of the usage conditions is not complied with (the traction battery is not charged, etc.). | ➔ 3.13. |

OPERATING FAULTS (2/7)

| Using the card | POSSIBLE CAUSES | WHAT TO DO |
|---|---|--|
| The card does not lock or unlock the doors. | Card battery is flat. | Replace the battery. You will still be able to lock/unlock and start your vehicle ➔ 1.55 and ➔ 2.2 or ➔ 2.3. |
| | Use of appliances operating on the same frequency as the card (mobile phone, etc.). | Stop using the devices or use the key provided ➔ 1.55. |
| | Vehicle located in a high electromagnetic radiation zone. Vehicle battery flat. | Use the key that is built into the card ➔ 1.55. |
| | The message "Place card on zone + START" appears on the instrument panel. | Place the card in the placement area ➔ 2.3 then press the START button. |
| | The vehicle is started. | While the engine is on, it is not possible to lock/unlock using the card. Turn off the ignition. |
| | Desynchronisation of the card. | Unlock the driver's door by inserting the key integrated in the card into the door lock ➔ 1.55 then place the card in the placement area ➔ 2.3 and press the START button to synchronise the card. |

OPERATING FAULTS (3/7)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved dealer as soon as possible.

| Using the remote control | POSSIBLE CAUSES | ACTION REQUIRED |
|---|---|---|
| The remote control does not lock or unlock the doors. | The remote control battery is flat. | Use the emergency key. |
| | Use of appliances operating on the same frequency as the remote control (mobile phone, etc.). | Stop using the devices or use the key. |
| | Vehicle located in a high electromagnetic radiation zone. Discharged battery. | Replace the battery. You will still be able to lock, unlock, and start your vehicle ➔ 1.55 and ➔ 2.2 or ➔ 2.3. |
| | The vehicle is started. | While the engine is on, it is not possible to lock/unlock using the key. Turn off the ignition. |
| | Desynchronisation of the remote control | Unlock the driver's door by inserting the key into the door lock ➔ 1.55, then start the engine to synchronise the remote control ➔ 2.3. |

OPERATING FAULTS (4/7)

| The starter is activated | POSSIBLE CAUSES | ACTION REQUIRED |
|-------------------------------------|---|--|
| The engine will not start. | Starting conditions are not fulfilled. | → 2.2 or → 000. |
| | The "hands-free" card does not work. | Place the card in the recess provided for this purpose on the centre console → 2.2 or → 2.3. |
| The engine cannot be switched off. | Card not detected. | Place the card in the recess provided for this purpose on the centre console. Press and hold the start button. |
| | Electronic fault. | Press the start button 3 times quickly or press and hold. |
| The steering column remains locked. | Steering wheel locked. | Move the steering wheel while pressing the engine start button (or, depending on the vehicle, operating the ignition key) → 2.2. |
| | Faulty electrical circuit. | Consult an approved dealer. |
| Steering becomes heavy. | Assistance overheating. | Drive carefully at reduced speed, be aware of the level of force in the steering wheel needed to turn the wheels. |
| | Fault with the electric assistance motor. Fault in the assistance system. | Consult an authorised dealer. |
| Vibrations. | Tyres not inflated to correct pressures, incorrectly balanced or damaged. | Check the tyre pressures; if this is not the cause, have their condition checked by an approved dealer. |

OPERATING FAULTS (5/7)

| On the road | POSSIBLE CAUSES | WHAT TO DO |
|---|---|---|
| The engine is overheating. The coolant temperature indicator is in the warning zone and warning light STOP comes on. | Engine cooling fan not working. | Stop the vehicle, switch off the engine and contact an approved dealer. |
| | Coolant leaks. | Check the coolant reservoir: it should contain fluid. If there is no coolant, consult an authorised dealer as soon as possible. |
| Coolant boiling in the coolant reservoir. | Mechanical fault: damaged cylinder head gasket. | Stop the engine. Contact an approved dealer. |
| The engine cooling fan starts to run after the ignition is switched off. | This is not necessarily a fault. The engine cooling fan group may start to run in order to regulate the engine temperature. This operation may last several minutes after the engine is switched off. | |
| | The engine cooling fan runs for more than 10 minutes after the engine is switched off. | Consult an approved dealer. |



Radiator: if there is a significant lack of coolant, remember that it must never be topped up using cold coolant when the engine is very hot. After any procedure on the vehicle which has involved even partial draining of the cooling system, it must be refilled with a new mixture prepared in the correct proportions. Reminder: only products approved by our Technical Department may be used for this purpose.

OPERATING FAULTS (6/7)

| Electrical equipment | POSSIBLE CAUSES | WHAT TO DO |
|---|---------------------------------------|---|
| The wipers do not work. | Wiper blades stuck. | Free the blades before using the wipers. |
| | Faulty electrical circuit. | Consult an approved dealer. |
| | Fuse damaged. | Replace the fuse or have it replaced ➔ 5.35. |
| The wiper does not stop. | Faulty electrical controls. | Consult an approved dealer. |
| Direction indicators flashing more quickly. | Faulty rear bulb. | ➔ 5.18. ➔ 1.55 |
| The direction indicators do not work. | Faulty electrical circuit or control. | Consult an approved dealer. |
| | Fuse damaged. | Replace the fuse or have it replaced ➔ 5.35. |
| The lights do not come on or go off. | Faulty electrical circuit or control. | Consult an approved dealer. |
| | Fuse damaged. | Replace the fuse or have it replaced ➔ 5.35. |




OPERATING FAULTS (7/7)

| Electrical equipment | POSSIBLE CAUSES | WHAT TO DO |
|---|--|---|
| Traces of condensation in the headlights or rear lights. | <p>Traces of condensation may be a natural phenomenon caused by variations in temperature and humidity.</p> <p>In this case, the traces will disappear slowly once the lights are switched on.</p> | |
| The front seat belt reminder light comes on when the seat belts are fastened. | An object is stuck between the floor and the seat and is disrupting the operation of the sensor. | Remove all objects from underneath the front seats. |

Section 6: Technical specifications

| | |
|--|------|
| Vehicle identification plate | 6.2 |
| Technical Information for the emergency services | 6.3 |
| Engine identification, engine specifications | 6.4 |
| Dimensions | 6.5 |
| Weights | 6.7 |
| Towing weights | 6.7 |
| Replacement parts and repairs | 6.8 |
| Service sheets | 6.9 |
| Anticorrosion check | 6.15 |
| | 6.1 |

VEHICLE IDENTIFICATION PLATES



The information shown on the vehicle identification plate should be quoted on all correspondence or orders.

The presence and location of the information depends on the vehicle.

Vehicle identification plate A

- 1 Manufacturer name.
- 2 EC design number or approval number.
- 3 Identification number.

Depending on the vehicle, this information is also given on marking B.

- 4 MMAC (Maximum permissible all-up weight).
- 5 MTR (Gross train weight: vehicle fully loaded, with trailer).
- 6 MMTA (Maximum Permissible Weight) front axle.
- 7 MMTA rear axle.
- 8 Reserved for related or additional entries.
- 9 Paint reference (colour code).

TECHNICAL INFORMATION FOR THE EMERGENCY SERVICES

57539



57540



The QR Code on the **A** label allows emergency workers using a tablet or smartphone to immediately access the technical information useful for working on the vehicle in the event of an accident.


Note: vehicles without rear windows have only the front label affixed.

Ensure that the **A** label is always visible and present on the windscreen as well as the rear screen.

Any modification or damage would prevent access to the information.

ENGINE IDENTIFICATION, ENGINE SPECIFICATION


33293



Please quote the engine identification information in area A in all correspondence or orders.

(Location varies depending on engine)




- 1 Engine type.
- 2 Engine suffix.
- 3 Engine serial number.



Engine specification

Engine type: 5AGEN3

DIMENSIONS (in metres) (1/2)



55400

6.5

DIMENSIONS (in metres) (2/2)

| | | “Standard chassis” | “Long chassis” |
|--------------------|-------------------------|--------------------|----------------|
| A | | 0,962 | |
| B | | 2,716 | |
| C | | 0,810 | |
| D | | 4,488 | |
| E | Door mirrors folded in | 1,919 | |
| | Door mirrors folded out | 2,159 | |
| F | | 1,570 to 1,585 | |
| G | | 1,590 to 1,610 | |
| H (unladen) | Estate version | 1,810 | |
| | Van version | 1,830 | |

| | | |
|-------------------------------|------|------|
| Turning circles between kerbs | 10,9 | 12,4 |
| Turning circles between walls | 11,2 | 13,1 |

Caution: if the vehicle is fitted with roof bars, the height must be increased by 0,052 m (the bars cannot be removed).

WEIGHTS (in kg)

The weights indicated for a basic vehicle without options: they vary depending on your vehicle's equipment. Consult your approved Dealer.

| Versions | Van version | | Estate versions | |
|--|---|------------------|-----------------|--|
| Standard chassis | Long chassis | Standard chassis | Long chassis | |
| Maximum Authorised Mass (MMAC) Maximum permissible weight (MMTA) Gross Train Weight (MTR) | Weights indicated on the vehicle identification plate ➔ 6.2 | | | |
| Braked Trailer Weight* | found by calculating: MTR - MMAC | | | |
| Unbraked Trailer Weight* | 750 kg | | | |
| Permissible nose weight* | 75 kg | | | |
| Maximum permissible load on roof | ➔ 3.75, ➔ 3.78 | | | |

* Towing weight (Towing a caravan, boat, etc.)

Towing is prohibited when the MTR-MMAC calculation is equal to zero, or when the MTR is equal to zero (or is not listed) on the identification plate.

- It is important to respect local towing regulations in force, specifically those set out in the Highway Code. Please contact your authorised dealer about adapting any towing equipment.
- When towing, under no circumstances may **the total train weight (vehicle + trailer) be exceeded**. However the following is permitted:
 - rear axle MMTA exceeded by no more than 15%,
 - maximum MMAC exceeded by no more than 10% or 100 kg (whichever is reached first).

In either case, the maximum speed of the vehicle and trailer must not exceed 50 mph (80 km/h) (van versions) or 62 mph (100 km/h) (estate versions) and the tyre pressure must be increased by 0.2 bar (3 PSI).

REPLACEMENT PARTS AND REPAIRS

Original parts are based on strict specifications and are subject to highly-specialised tests. Therefore, they are of at least the same level of quality as the parts fitted originally.

If you always fit genuine replacement parts to your vehicle, you will ensure that it performs well. Furthermore, repairs carried out within the manufacturer's Network using original parts are guaranteed according to the conditions set out on the reverse of the repair order.

SERVICE SHEETS (1/6)

VIN:

| Date: | Miles (Km): | Invoice number: | Comments/miscellaneous |
|--|-------------|-----------------|------------------------|
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |

SERVICE SHEETS (2/6)

VIN:

| Date: | Miles (Km): | Invoice number: | Comments/miscellaneous |
|--|-------------|-----------------|------------------------|
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |

SERVICE SHEETS (3/6)

VIN:

| Date: | Miles (Km): | Invoice number: | Comments/miscellaneous |
|--|-------------|-----------------|------------------------|
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |

SERVICE SHEETS (4/6)

VIN:

| Date: | Miles (Km): | Invoice number: | Comments/miscellaneous |
|--|-------------|-----------------|------------------------|
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |

SERVICE SHEETS (5/6)

VIN:

| Date: | Miles (Km): | Invoice number: | Comments/miscellaneous |
|--|-------------|-----------------|------------------------|
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |

SERVICE SHEETS (6/6)




VIN:

| Date: | Miles (Km): | Invoice number: | Comments/miscellaneous |
|--|-------------|-----------------|------------------------|
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anti-corrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page | | | |

ANTICORROSION CHECK (1/5)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

| | | |
|---|--|-------|
| Corrosion repair operation to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |

ANTICORROSION CHECK (2/5)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

| | | |
|---|--|-------|
| Corrosion repair operation to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |

ANTICORROSION CHECK (3/5)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

| | | |
|---|--|-------|
| Corrosion repair operation to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |

ANTICORROSION CHECK (4/5)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN:

| | | |
|---|--|-------|
| Corrosion repair operation to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |

ANTICORROSION CHECK (5/5)

If the continuation of the warranty is subject to repair, it is indicated below.

VIN:

| | | |
|---|--|-------|
| Corrosion repair operation to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |
| Repair to be carried out: |  | Stamp |
| Date of repair: | | |

ALPHABETICAL INDEX (1/8)

12

- 12 volt battery
 - maintenance 4.6 – 4.7
- 12 volt battery 1.2 → 1.7, 4.6 – 4.7

400

- «400 volt» electrical circuit 1.2 → 1.7

A

- ABS 1.140 – 1.141, 2.28 → 2.33
- access
 - vehicle 0.2, 1.24 → 1.43
 - accessories 2.4, 5.34
- accessories - installation 5.34
- accessories socket 3.18, 3.36 – 3.37
- adaptive cruise control 2.91 → 2.104
- additional methods of restraint
 - side protection 1.86
 - to the front seat belts 1.79 → 1.84
 - to the rear seat belts 1.85
- additional methods of restraint 1.87
- additional tank capacity 1.151
- additional tank filling 1.141
- adjusting your driving position 1.59 → 1.66, 1.69 → 1.78, 1.176, 3.38 → 3.40
- advanced safety 2.59 → 2.75

air bag

- activating the front passenger air bags 1.96, 1.131 → 1.133

- air bag 1.79 → 1.87, 1.94, 1.96 → 1.115, 1.118 → 1.133, 1.139

- air conditioning 3.2 → 3.12, 3.15 → 3.17

- air vents 3.2 → 3.4

airbag

- front passenger airbag activation 1.118 → 1.130

- front passenger airbag deactivation 1.131 → 1.133

- airbags 0.6

- anti-corrosion check 6.15 → 6.19

- anti-corrosion protection 4.10

- anti-lock braking system: ABS 2.28 → 2.33

armrest

- front 1.60 → 1.66, 3.30

- assisted parking 2.121 → 2.137

- audible and visual signals 1.174

- AUTO mode 1.175 → 1.177

- automatic locking of the doors while driving 1.58

B

- batteries 5.29 → 5.32

- battery 0.8, 1.139

- battery (remote control) 5.29 – 5.30

- blind spot warning signal 2.45 → 2.54

- blind spot: warning signal 2.45 → 2.54

- bonnet 4.2 – 4.3

- brake fluid 4.5

- breakdown recovery 0.9

- bulbs

- changing 5.16 → 5.21

C

- camera rear view 1.168, 1.170 → 1.173, 2.129 → 2.132

- card 1.29 → 1.43

- card: battery 5.31 – 5.32

- card: use 1.29 → 1.43

- central door locking 1.24 – 1.25, 1.28 → 1.43, 1.55 → 1.58, 1.159 – 1.160

- changing a bulb 5.16 → 5.21

ALPHABETICAL INDEX (2/8)

changing a wheel 5.11 – 5.12
changing gear 1.140, 2.6 → 2.11
charge programming 1.22 – 1.23
charging cord 1.9 → 1.23
charging flap 1.9 → 1.21
charging socket 1.2 → 1.7, 1.9 → 1.21
child minder mirror 3.27
child restraint/seat 1.88 – 1.89, 1.91 → 1.115, 1.118 → 1.130
child safety 0.3, 1.24 – 1.25, 1.44, 1.50, 1.84, 1.88 – 1.89, 1.91 → 1.115, 1.118 → 1.133, 3.21 → 3.23
child seats 1.88 – 1.89, 1.91 → 1.115, 1.118 → 1.130
children 0.3, 1.88 – 1.89, 1.94 → 1.115, 1.118 → 1.133, 3.21 → 3.23
cleaning:
 inside the vehicle 4.13 – 4.14
clock
 setting 1.151
clock 1.162 – 1.163
closing the doors 1.29 → 1.43, 1.49 → 1.58
configuration menu 1.159 → 1.161
connected services 1.3
control instruments 1.138 → 1.151
controls
 doors/opening elements 1.26 – 1.27
 steering wheel 3.18 → 3.20
controls 0.4, 1.134 → 1.137, 2.82, 2.86
coolant 4.4
courtesy light 3.24 → 3.26, 5.22 → 5.28
courtesy mirrors 3.27
cruise control 2.86 → 2.90
cruise control-speed limiter 2.82 → 2.90
cup holder 3.69
customised vehicle settings 1.159 → 1.161
customising the vehicle settings 1.159 → 1.161

D

dashboard 0.4, 1.134 → 1.137
daytime running lights 1.29 → 1.32, 1.160, 1.175 → 1.180
deadlocking the doors 1.28, 1.44
deflector
 luggage net 3.65 → 3.68
demisting
 rear screen 3.9 → 3.12
 windscreen 3.9 → 3.12
dimensions 6.5 – 6.6
display 1.138 → 1.148, 3.18
doors 1.49 → 1.54, 1.159 – 1.160
doors and tailgate 1.24 – 1.25, 1.33 → 1.43
doors/tailgate 1.26 – 1.27, 1.29 → 1.43, 1.55 → 1.58
driver assistance 0.5, 2.28, 2.34 → 2.104, 2.121 → 2.137, 2.139 → 2.141
driver's position 0.4, 1.134 → 1.141
driving 0.5, 1.159 – 1.160, 2.2 → 2.10, 2.12 → 2.21, 2.28 → 2.77, 2.82 → 2.90, 2.121 → 2.141
driving aids
 adaptive cruise control 2.91 → 2.104
driving aids 0.5, 1.160 – 1.161, 2.34 → 2.90, 2.105 → 2.137, 2.139 → 2.141
driving position
 settings 0.3, 1.69 → 1.78, 1.164 – 1.165
driving recommendations 2.16 – 2.17, 2.19 → 2.21

E

ECO driving 1.141, 2.16 → 2.19
ECO mode 2.16, 2.19, 3.15
«ECO» mode function 1.141
electric beam height adjustment 1.181 – 1.182
electric vehicle
 charging 1.9 → 1.21

ALPHABETICAL INDEX (3/8)

driving 1.6, 2.20 – 2.21
important guidelines 1.8
introduction 1.2 → 1.7
noise 1.7
vehicle range 2.20 – 2.21
electric windows 3.21 → 3.23
electronic parking brake 1.140, 2.12 → 2.15
electronic stability control: ESC 2.28 → 2.33
emergency active braking 2.59 → 2.75
emergency brake assist 2.28 → 2.33
emergency braking 2.28 → 2.33
emergency call 2.139 → 2.141
emergency key 1.29 → 1.32
emergency lane keep assist 2.59 → 2.75
emergency spare wheel 5.2 – 5.3
energy
 charge meter (function) 2.16
 «ECO» mode 1.141
 range 2.16
 recovery 2.16
 saving 2.16, 2.20
energy 2.16
energy consumption 1.142 → 1.151, 2.20 – 2.21, 3.15
energy recovery 2.20
energy saving 2.20 – 2.21
engine coolant 1.141
engine identification plates 0.7
engine specifications 6.4
engine start/stop button 2.3 → 2.5
environment 2.22
equipment
 fitting 3.74
equipment
 multimedia 5.33

ESC: electronic stability control 1.140, 2.28 → 2.33
Extended grip 2.33
external temperature 1.162 – 1.163

F

fatigue detection warning 2.76 – 2.77
faults
 operating faults 2.15, 2.29 → 2.33, 2.36 – 2.37, 2.42 – 2.43, 2.52, 2.74, 2.77, 2.81, 2.126, 2.141, 3.15, 5.35 → 5.37, 5.42 → 5.48
file 1.60 → 1.66
filter
 particle filter 1.141
fitting a radio 5.33
fittings 3.28 → 3.35
front seat adjustment 1.60 → 1.66
front seats
 adjustment 1.59 → 1.66, 1.69
fuses 0.9, 5.35 → 5.37

G

gear lever 2.6 → 2.11
grab handle 3.27
grip control 2.33

H

handbrake 2.11 – 2.12
hands-free telephone integrated control 3.18 → 3.20
«hands-free» card: battery 5.31 – 5.32
hazard warning lights signal 1.174
headlight beam adjustment 1.181 – 1.182
headrest

 rear 3.38 → 3.40
headrest 1.59, 3.38 → 3.40

ALPHABETICAL INDEX (4/8)

| | |
|--|-------------------|
| heated seats | 1.60 → 1.66 |
| heated windscreen | 3.9 → 3.12 |
| heating and air conditioning system | 3.9 → 3.12, 3.15 |
| heating system | 3.5 → 3.14 |
| heating, air conditioning: programming | 2.21, 3.13 – 3.14 |
| heating/air conditioning programming | 3.13 – 3.14 |
| Hill Start Assist..... | 2.28 → 2.33 |
| horn | 1.174 |
| horn: | |
| flash | 1.174 |
| hubcap tool..... | 5.8 → 5.10 |

I

| | |
|-----------------------------------|--|
| ignition switch | 2.2, 2.12 → 2.15 |
| indicators | |
| bulb replacement | 5.20 – 5.21 |
| exterior temperature | 1.162 – 1.163 |
| indicators | 1.174, 2.49, 5.16 → 5.21 |
| indicators: | |
| direction indicators | 1.174 |
| instrument panel | 1.138 → 1.151, 2.11 → 2.19 |
| information and general advice | |
| welcome aboard your vehicle | 0.1 |
| instrument panel | 0.4, 1.138 → 1.158, 1.160 – 1.161, 2.11 → 2.19 |
| instrument panel messages..... | 1.149 → 1.158, 2.12 → 2.15 |
| interior lighting: | |
| changing bulbs..... | 5.22 → 5.28 |
| interior trim | |
| maintenance | 4.13 – 4.14 |
| Isofix | 1.91 → 1.93, 1.95, 1.118 → 1.130 |

J

| | |
|------------|-----------------------------|
| jack | 5.3, 5.8 – 5.9, 5.11 – 5.12 |
|------------|-----------------------------|

K

| | |
|--------------------|-------------|
| key/remote control | |
| deadlocking..... | 1.28 |
| keys | 1.24 → 1.28 |

L

| | |
|--------------------------------|--------------------------|
| lane centring..... | 2.111 → 2.120 |
| lane departure warning..... | 2.34 → 2.44 |
| Lane Keeping Assist..... | 2.39 → 2.44, 2.59 → 2.75 |
| lane keeping: assistance | 2.39 → 2.44, 2.59 → 2.75 |
| level information | |

| | |
|------------------|-----|
| Brake fluid..... | 4.5 |
|------------------|-----|

| | |
|--------------|-----|
| levels | 0.8 |
|--------------|-----|

levels:

| | |
|----------------------------------|-----|
| coolant | 4.4 |
| windscreen washer reservoir..... | 4.5 |

lifting the vehicle

| | |
|-----------------------|-------------|
| changing a wheel..... | 5.11 – 5.12 |
|-----------------------|-------------|

lighting

| | |
|----------------|-------------|
| exterior | 0.2 |
| glovebox | 5.22 → 5.28 |

lighting:

| | |
|------------------------|----------------------|
| exterior | 1.174 → 1.182 |
| instrument panel | 1.175 → 1.180 |
| interior | 3.24 → 3.26 |
| see-me-home..... | 1.159 – 1.160, 1.179 |

lights

| | |
|---------------------|---------------|
| adjustment | 1.181 – 1.182 |
| changing bulbs..... | 5.16 – 5.17 |
| front..... | 5.16 – 5.17 |

lights:

| | |
|--|---------------|
| adjusting | 1.181 – 1.182 |
| adjustment of headlight beam height..... | 1.181 – 1.182 |
| brake lights | 5.18 → 5.21 |

ALPHABETICAL INDEX (5/8)

dipped beam headlights 1.139, 1.175 – 1.176, 1.178 – 1.179, 5.16 – 5.17
direction indicators 1.139, 1.174, 5.16 → 5.18
fog lights 1.139, 1.175 → 1.180, 1.180
hazard warning 1.174
main beam headlights 1.139, 1.175 → 1.177, 5.16
number plate lights 5.19 – 5.20
side lights 1.175, 1.179, 5.16 → 5.18
lights-on warning buzzer 1.49, 1.178
load permitted on the roof 6.7
locking 1.70 → 1.78
locking the doors 1.26 – 1.27, 1.29 → 1.43, 1.55 → 1.58, 1.159 – 1.160
locking/unlocking the opening elements
 map 1.29 → 1.32
locking/unlocking the opening elements 1.28
luggage compartment cover 3.63 – 3.64
luggage compartment lighting
 changing bulbs 5.22

M

maintenance 3.15
maintenance:

 bodywork 4.10 → 4.12
 interior trim 4.13 – 4.14
 mechanical 6.9 → 6.14
 mileage before service 1.151

map

 hands-free 1.33 → 1.43
map reading lights 3.24 → 3.26
menu for customising the vehicle settings 1.149, 1.159 → 1.161
methods of restraint in addition to the seat belts 1.79 → 1.87
mileage before service 1.151

Motorway and Traffic assistant 2.105 → 2.120
multimedia (equipment) 3.18 → 3.20
multimedia equipment 1.159, 1.178, 3.18 → 3.20

N

navigation 3.18 → 3.20
navigation system 3.18 → 3.20

O

opening the doors 1.49 → 1.58
opening/closing

 luggage compartment 1.26 – 1.27
operating faults
 card battery 5.31 – 5.32
 remote control batteries 5.29 – 5.30
operating faults 1.25, 1.58, 1.60 → 1.66, 1.81, 1.133, 1.138 → 1.141, 1.149, 1.151, 1.157, 1.177 – 1.178, 1.184, 2.4, 2.15, 2.29 → 2.33, 2.36 – 2.37, 2.42 – 2.43, 2.52, 2.74, 2.77, 2.81, 2.98, 2.126, 2.141, 3.15, 3.22, 5.35 → 5.37, 5.42 → 5.48
overspeed warning 2.78 → 2.82

P

paint

 maintenance 4.10 → 4.12
parking assistance: assisted parking 2.121 → 2.137
parking brake 2.12 → 2.15
parking distance control 1.160 – 1.161, 2.121 → 2.128, 2.126, 2.129 → 2.132

partition 1.67 – 1.68
power meter 1.143, 2.16
power-assisted steering 1.164
practical advice 2.20 – 2.21
precautions during use 1.183 → 1.186

ALPHABETICAL INDEX (6/8)

presentation of electric vehicle

 important guidelines 1.8

pretensioners 1.79 → 1.84

puncture 0.9, 5.2 → 5.9, 5.11 – 5.12

Q

QR Code 6.3

R

radio

 fitting a radio 5.33

radio 3.18 → 3.20

radio frequency remote control/key

 battery 5.29 – 5.30

 use 1.24 → 1.27

 range of the traction battery 2.16

rear bench seat 1.93, 1.95

rear parcel shelf 1.95, 3.62

rear seat 1.93

rear seats

 functions 3.44 → 3.61

rear seats 1.69 → 1.78, 3.38 → 3.61

rear view camera 2.129 → 2.132

rear view mirrors 0.2, 1.166 → 1.169

remote control

 card 1.29 → 1.32

 deadlocking 1.28

 map 1.29 → 1.32

remote control 1.33 → 1.43

remote control door locking unit 1.24 → 1.27

replacement

 remote control batteries 5.29 – 5.30

replacement parts 6.8

reverse gear

 selecting 2.6 → 2.11

 reversing sensor 2.121 → 2.128

roof bars 3.75 → 3.78

roof rack

 roof bars 3.75 → 3.78

S

safety distance warning 2.55 → 2.58

safety distances 2.55 → 2.58

screen

 navigation display 3.18 → 3.20

 navigation screen 3.18 → 3.20

screen wash/wipe

 replacing blades 1.185, 5.38 – 5.39

screen wash/wipe 1.186

screens

 multimedia screen 2.18,

 2.42 → 2.44, 2.51, 2.56, 2.74 → 2.77, 2.79, 2.124 – 2.125,

 2.129, 2.136, 3.18 → 3.20

 seat belt pretensioners

 front seat belt 1.79 → 1.84

seat belt pretensioners 1.85

seat belts

 seat belt height adjustment 1.75

 seat belt reminder warning light 1.71 → 1.78

seat belts 0.6, 1.69 → 1.84, 1.87, 1.91 → 1.93,

1.96 → 1.115, 1.118 → 1.130, 4.13

seats 0.3

service sheets 6.9 → 6.14

settings

 configuration menu 1.159 → 1.161

settings 1.159 → 1.161

side protection devices 1.85 – 1.86

ALPHABETICAL INDEX (7/8)

sign detection: overspeed warning 2.78 → 2.81
signals and lights 1.174 → 1.182
speakers
 location 5.33
speed control 2.6 → 2.10
speed limiter 2.82 → 2.85
starting the engine 2.2 → 2.5
steering wheel
 adjustment 1.164
steering wheel controls 3.18 → 3.20
stopping the engine 2.5, 2.12 → 2.15
storage compartment 3.28 → 3.35, 3.69
storage compartments 3.28 → 3.35
storage/organisation 0.3
sun visor 3.27
switching on the vehicle ignition 2.2 → 2.5

T

tailgate 1.24 – 1.25, 1.29 → 1.32, 1.54, 3.69 → 3.73
tank
 Brake fluid 4.5
 Coolant 4.4
tanks and reservoirs:
 windscreen washer 4.5
technical specifications 6.5 → 6.8
telephone 3.18 → 3.20
temperature regulation 3.5 → 3.12
tool kit 5.3, 5.8 → 5.10
tools 5.8 → 5.10
towing
 breakdown 5.40 – 5.41
 towing equipment 3.74
towing 0.9
towing a caravan 3.74, 6.7

towing hitch 5.8 – 5.9, 5.40 – 5.41
towing rings 3.69 → 3.73
towing weights 6.7
traction battery 1.2 → 1.7
traction battery charge 1.9 → 1.21
traction control 1.140, 2.28 → 2.33
Traction control - Extended grip 2.33
traction control system: ASR 2.28, 2.30
trailer driving assistance 2.32
transport

 objects in the luggage compartment 3.70 → 3.73
 transporting children 1.88 – 1.89, 1.91 → 1.115, 1.118 → 1.130

 transporting objects
 on the roof 6.7

trims 5.10
trip computer and warning system 1.138 → 1.141, 1.149 → 1.158, 1.160

tyre inflation kit 2.23 → 2.27, 5.2, 5.4 → 5.7
tyre pressure 0.7, 1.151, 2.23 → 2.27, 4.8 – 4.9, 5.2, 5.5, 5.7, 5.12, 5.14

tyre pressure loss warning 5.5

tyre pressure monitor 1.141, 2.23 → 2.27, 5.12

tyre pressures 2.23 → 2.27, 4.8 – 4.9, 5.4 → 5.7, 5.12, 5.14

tyres
 tyre pressure monitoring system 2.23 → 2.27

tyres 0.2, 2.23 → 2.27, 4.8 – 4.9, 5.13 → 5.15

U

unlocking the doors 1.29 → 1.43, 1.55 → 1.58
USB socket 3.18

V

variable power-assisted steering 1.164

ALPHABETICAL INDEX (8/8)

| | |
|--|-------------------|
| vehicle identification | 0.7 |
| vehicle identification number (VIN)..... | 0.7 |
| vehicle identification plates..... | 0.7, 6.2, 6.4 |
| vehicle range | 2.16, 2.20 – 2.21 |
| ventilation | |
| ventilation..... | 3.2 → 3.4 |
| ventilation | 3.2 → 3.12 |

W

| | |
|-------------------------------------|------------------------------|
| warning | |
| pedestrian sound warning..... | 1.7 |
| warning lights..... | 1.138 → 1.141, 1.149 → 1.151 |
| washing | 4.10 → 4.12 |
| weights | 6.7 |
| welcome aboard your vehicle | 0.1 |
| wheelbrace | 5.8 – 5.9, 5.11 – 5.12 |
| wheels (safety) | 5.13 → 5.15 |
| wide angle rear view mirror | 1.169 |
| windows..... | 0.2 |
| windscreen de-icing/demisting | 3.9 → 3.12 |
| windscreen washer..... | 1.183 → 1.188, 4.5 |
| windscreen washer/wiper | 1.159 – 1.160, 5.38 – 5.39 |
| wiper blades | 0.9, 1.186, 5.38 |
| wipers | 1.183 → 1.188, 1.188 |
| wireless charger | |
| induction recharging | 3.19 |



RENAULT S.A.S. SOCIÉTÉ PAR ACTIONS SIMPLIFIÉE AU CAPITAL DE 533 941 113 € / 122-122 BIS, AVENUE DU GÉNÉRAL LECLERC
92100 BOULOGNE-BILLANCOURT R.C.S. NANTERRE 780 129 987 — SIRET 780 129 987 03591 / renaultgroup.com

NU 1441-3 - 99 91 066 905 - 06/2023 - Edition anglaise

