California Proposition 65 Warning

WARNING: This product contains or emits chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.

Event Data Recorders

This vehicle is equipped with an event data recorder (EDR).

The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- · How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened:
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- . How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

The data belongs to the vehicle owner and may not be accessed by anyone else except as legally required or with the permission of the vehicle owner.

Service Diagnostic Recorders

This vehicle is equipped with service-related devices that record information about powertrain performance. The data can be used to verify emissions law requirements and/or help technicians diagnose and solve service problems. It may also be combined with data from other sources for research purposes, but it remains confidential.

California Perchlorate Contamination Prevention Act

The airbags, seat belt tensioners, and CR type batteries in this vehicle may contain perchlorate materials - special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate/

As you read this manual, you will find information that is preceded by a NOTICE symbol. This information is intended to help you avoid damage to your vehicle, other property, or the environment.

A Few Words About Safety

Your safety, and the safety of others, is very important. And operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining your vehicle. You must use your own good judgment.

You will find this important safety information in a variety of forms, including:

- Safety Labels on the vehicle.
- Safety Messages preceded by a safety alert symbol and one of three signal words: DANGER, WARNING, or CAUTION.
 These signal words mean:

ADANGER

You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

AWARNING

You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

ACAUTION

You CAN be HURT if you don't follow instructions.

- Safety Headings such as Important Safety Precautions.
- Safety Section such as Safe Driving.
- **Instructions** how to use this vehicle correctly and safely.

This entire book is filled with important safety information - please read it carefully.

This owner's manual should be considered a permanent part of the vehicle and should remain with the vehicle when it is sold

This owner's manual covers all models of your vehicle. You may find descriptions of equipment and features that are not on your particular model.

Images throughout this owner's manual (including the front cover) represent features and equipment that are available on some, but not all, models. Your particular model may not have some of these features

This owner's manual is for vehicles sold in the United States and Canada.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation.

≥ Safe Driving P. 29

For Safe Driving P. 30 Seat Belts P. 34 Airbags P. 41

▶ Instrument Panel P. 69

Indicators P. 70 Gauges and Displays P. 98

Controls P. 115

Clock P. 116 Locking and Unlocking the Doors P. 118

Opening and Closing the Moonroof* P. 139

Adjusting the Seats P. 161

Features P. 185

Audio System P. 186 Audio System Basic Operation P. 192, 215
Customized Features P. 298, 316 HomeLink® Universal Transceiver* P. 340

Driving P. 411

Before Driving P. 412 Towing a Trailer P. 417
Refueling P. 497 Fuel Economy P. 499

→ Maintenance P. 501

Before Performing Maintenance P. 502 Maintenance Minder™ P. 505 Checking and Maintaining Wiper Blades P. 535

Climate Control System Maintenance P. 549

Handling the Unexpected P. 555

Tools P. 556 If a Tire Goes Flat P. 557

Overheating P. 570 Indicator, Coming On/Blinking P. 572

▶ Information P. 581

Specifications P. 582 Identification Numbers P. 586
Emissions Testing P. 589 Warranty Coverages P. 591

Child Safety P. 54	Exhaust Gas Hazard P. 66	Safety Labels P. 67		Quick Refere
Clind Salety 1. 54	Exhiaust das Hazard 1. 00	Salety Labels 1. 07		
				Sa
				Instrum
Opening and Closing the Trunk P. 129 Operating the Switches Around the Steeri Interior Lights/Interior Convenience Items	2	Opening and Closing the Windows P. 136 Adjusting the Mirrors P. 159 Climate Control System P. 180		
			lh. I	_
Audio Error Messages P. 286 Bluetooth® HandsFreeLink® P. 343, 374	General Information on the Audio System Compass* P. 409	P. 291		
			llin.	
When Driving P. 421 Accessories and Modifications P. 500	Braking P. 479	Parking Your Vehicle P. 491		
			llinn.	
Maintenance Under the Hood P. 513 Checking and Maintaining Tires P. 537 Cleaning P. 550	Replacing Light Bulbs P. 529 Battery P. 546	Remote Transmitter Care P. 547	- antifff	Mai
				Handling the Ur
Engine Does Not Start P. 563 Fuses P. 576	Jump Starting P. 566 Emergency Towing P. 580	Shift Lever Does Not Move P. 569		lui.
				Int
Devices that Emit Radio Waves P. 587 Authorized Manuals P. 593	Reporting Safety Defects P. 588 Customer Service Information P. 594		, , , , , , , , , , , , , , , , , , ,	_

Contents

Reference Guide P. 4

Safe Driving P. 29

strument Panel P. 69

Controls P. 115

Features P. 185

Driving P. 411


Maintenance P. 501

lling the Unexpected P. 555


nformation P. 581

Index P. 598


Visual Index




^{*1:} Models with the smart entry system have an ENGINE START/STOP button instead of an ignition switch.




Visual Index





Visual Index



Eco Assist System CR441


Ambient Meter

 Changes color to reflect your driving style.

Green: Fuel efficient driving Light green: Moderate acceleration/ deceleration

White: Aggressive acceleration/ deceleration

• The ambient meter color changes in accordance with your brake or accelerator pedal operation.



ECON Mode Indicator -○ P. 81

Comes on when the **ECON** button is pressed.

Helps maximize fuel

economy.













Models with multi-information display

The message is displayed for a few seconds when the **ECON** button is pressed.


Safe Driving Care

Airbags (\$\)2.41

 Your vehicle is fitted with airbags to help protect you and your passengers during a moderate-to-severe collision.

Child Safety CP. 54

- All children 12 and younger should be seated in the rear seat.
- Smaller children should be properly restrained in a forward-facing child seat.
- Infants must be properly restrained in a rear-facing child seat.



Exhaust Gas Hazard P. 66

 Your vehicle emits dangerous exhaust gases that contain carbon monoxide. Do not run the engine in confined spaces where carbon monoxide gas can accumulate.

Seat Belts CARBA

- Fasten your seat belt and sit upright well back in the seat.
- Check that your passengers are wearing their seat belts correctly.

 Before driving, check that the front seats, head restraints, steering wheel, and mirrors have been properly adjusted.



Fasten your lap belt as low as possible.

Instrument Panel

Gauges (No. 1988) / Information Display * (No. 1999) / Multi-Information Display* ←>P. 102 / System Indicators ←>P. 70

System Indicators

Malfunction Indicator Lamp

Low Oil Pressure Indicator

Charging System Indicator

Vehicle Stability Assist (VSA®) System Indicator

₹ OFF VSA® OFF Indicator

Immobilizer System c==(##) Indicator

Smart Entry System -<u>!</u> Indicator*

STARTER SYSTEM

U.S. Starter System Indicator*

Canada


Electric Power Steering (EPS) System Indicator

Washer Level Indicator*

System Message Indicator*

Maintenance Minder Indicator*

Low Tire Pressure/ TPMS Indicator



Position Indicator **System Indicators**

ECON mode Indicator

Road Departure Mitigation (RDM) Indicator*

Collision Mitigation Braking System™ (CMBS™) Indicator*

LKAS Lane Keeping Assist System (LKAS) Indicator (Amber)*

Lane Keeping Assist System (**LKAS**) Indicator (White)*

Lights Indicators

≣(A)

≥00€ Lights On Indicator

High Beam Indicator

Fog Light Indicator*

Light Control Indicator*

Auto High-Beam Indicator (Green)*/ Auto High-Beam Indicator (Amber)*

System Indicators



Turn Signal and Hazard Warning Indicators



BRAKE U.S.

Parking Brake and Brake System (I) Indicator (Red)

Canada

BRAKE SYSTEM U.S.

Brake System Indicator (Amber)

Canada



Door and Trunk Open Indicator



Parking Sensor System Indicator*



Low Fuel Indicator



Seat Belt Reminder Indicator



Supplemental Restraint System Indicator



Adaptive Cruise Control (ACC) Indicator (Amber)*



Adaptive Cruise Control (ACC) Indicator (White)*



CRUISE MAIN Indicator*



CRUISE CONTROL Indicator*

Controls CRIES

Clock CNR 116

Models with two displays

The audio system receives signals from GPS satellites, updating the clock automatically.



- 1 Select , then select Settings.
- Select Clock/Info, then Clock Adjustment.
- Adjust the hours and minutes by selecting ▲ / ▼.
- 4 Select **OK** to set the time.

Models with one display



- **2** Rotate [♠] to change hour, then press [♠].
- **3** Rotate ^r to change minute, then press [∞].

ENGINE START/STOP Button* > 141

Press the button to change the vehicle's power mode.



Turn Signals CP 145

Turn Signal Control Lever



Lights CP. 145

Light Control Switches



Wipers and Washers

→P. 152

Wiper/Washer Control Lever

Adjustment Ring

- : Low Sensitivity*1
- 🗐 🛮: Lower speed, fewer sweeps*2
- +: High Sensitivity*1
- + M: Higher speed, more sweeps *2



OFF

AUTO*1: Wiper speed varies automatically **INT***2: Low speed with intermittent

LO: Low speed wipe **HI**: High speed wipe

- *1:Vehicle with auto wiper
- *2: Vehicle without auto wiper

Steering Wheel (CR) 158

 To adjust, pull the adjustment lever towards you, adjust to the desired position, then lock the lever back in place.



Unlocking the Doors from the Inside

◯ P. 126

• Pull either door inner handle to unlock and open it at the same time.



 Unlocking and opening the driver's door from the inner handle unlocks the passenger's door.

Trunk CR 129



Trunk Release —

- To unlock and open the trunk:
- Pull the trunk release
- Press the trunk release button on the remote transmitter or the smart entry remote.
- Press the trunk release button* on the trunk lid.

Power Door Mirrors

→P. 160

- With the ignition switch in ON II *1, move the selector switch to L or R.
- Push the appropriate edge of the adjustment switch to adjust the mirror.




Adjustment Switch

Power Windows P. 136

- With the ignition switch in ON II *1, open and close the power windows.
- If the power window lock button is in the off position, the passenger's window can be opened and closed with its own switch.
- If the power window lock button is in the on position (indicator on), the passenger's window switch is disabled.

Power Window Lock Button Indicator




*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Climate Control System →P. 180

- Press the **AUTO** button to activate the climate control system.
- Press the SOFF button to turn the system on or off.
- Press the button to defrost the windshield.

Models with navigation system

The climate control system is voice operable. P. 235




- Air flows from dashboard vents.
- Air flows from floor and dashboard vents.
- Air flows from floor vents.
- Air flows from floor and windshield defroster vents.

Features CRIES

Audio Remote Controls





- + / Button
 Press to adjust the volume up/down.
- SOURCE Button

Models with one display

FM→AM→CD→USB→iPod→ Bluetooth® Audio→Pandora®*→AUX

Models with two displays

FM→AM→SiriusXM®*→CD→USB→iPod→ Pandora®*→Bluetooth® Audio→Audio Apps

● **■**/ **▶** Button


Radio: Press to change the preset station.
Press and hold to select the next or
previous strong station.


CD/USB device:

Press to skip to the beginning of the next song or return to the beginning of the current song. Press and hold to change a folder.


Audio System P. 192,215

Models with one display → P. 192









Driving CRAID

Manual Transmission* ←>2,438 **Continuously Variable Transmission** (CVT)* CXP.430

- Shift to P and depress the brake pedal when starting the engine.
- Shifting





Depress the brake pedal and press the release button to move out of P.



Press the release button to move the shift lever.



Move the shift lever without pressing the release button.





Park

Turn off or start the engine. Transmission is locked.



Reverse

Used when reversing.



Neutral

Transmission is not locked.



Drive

- Normal driving.
- 7-speed mode can be used temporarily.



Drive (S)

- Better acceleration.
- Increased engine braking.
- Going up or down hills.
- 7-speed manual shift mode can be used.

7-Speed Manual Shift Mode When the shift lever is in S C P 432

 Allows you to manually shift the transmission up or down without removing your hands from the steering wheel.

M Indicator



Shift Indicator

Shift Down - Shift Up + Paddle Shifter Paddle Shifter





- Pulling a paddle shifter changes the mode from continuously variable transmission (CVT) to 7-speed manual shift mode.
- The M indicator and the selected speed number are displayed in the shift indicator.


When the shift lever is in D

 Pulling a paddle shifter temporarily changes the mode from continuously variable transmission (CVT) to 7-speed manual shift mode. The selected speed number is displayed in the shift indicator.



Automatic Transmission*

- Shift to P and depress the brake pedal when starting the engine.
- Shifting





Depress the brake pedal and press the release button to move out of P.



Press the release button to move the shift lever.



Move the shift lever without pressing the release button.





Turn off or start the engine. Transmission is locked.



Reverse

Used when reversing.



Neutral

Transmission is not locked.



Drive

Normal driving. D-paddle shift mode can be used



Drive (S)

Sequential shift mode can be used.

Paddle Shifters P. 436

• Paddle shifters allow you to shift gears much like a manual transmission (1st through 6th). This is useful for engine braking.



Gear Indicator

M Indicator —

Selected Gear Number

Position • D-paddle shift mode: The transmission will shift back to automatic mode once the system detects that the vehicle is cruising.

• Sequential shift mode: Holds the selected gear, and the **M** indicator comes on.

Shift Down ☐ Shift Up 🛨 Paddle Shifter Paddle Shifter





• The selected gear position is shown in the instrument panel.



VSA[®] OFF Button ← 27.472

- The vehicle stability assist (VSA®) system helps stabilize the vehicle during cornering, and helps maintain traction while accelerating on loose or slippery road surfaces.
- VSA® comes on automatically every time you start the engine.
- To turn VSA® on or off, press and hold the button until you hear a beep.

Cruise Control CR 442

- Cruise control allows you to maintain a set speed without keeping your foot on the accelerator pedal.
- To use cruise control, press the CRUISE*/
 MAIN* button, then press the -/SET
 button once you have achieved the
 desired speed (above 25 mph or 40 km/h).

Tire Pressure Monitoring System (TPMS) P. 475

- Detects a change in tire conditions and overall dimensions due to decrease in tire pressures.
- The TPMS is turned on automatically every time you start the engine.
- A calibration procedure must be performed when certain conditions arise.

Collision Mitigation Braking System™ (CMBS™) OFF Button*

◯ P. 483

- When a possible collision is likely unavoidable, the CMBS™ can help you to reduce the vehicle speed and the severity of the collision.
- To turn the CMBS[™] on or off, press and hold the button until you hear a beep.

Refueling P. 497

Fuel recommendation: Unleaded gasoline with a pump octane number 87 or

higher required

Fuel tank capacity: 17.2 US gal (65 L)


Push the fuel fill door release handle.



2 Turn the fuel fill cap slowly to remove the cap.



Place the cap in the holder on the fuel fill door.



Maintenance CZESOD

Under the Hood (>2.513)


- Check engine oil, engine coolant, and windshield washer fluid. Add when necessary.
- Check brake fluid and clutch* fluid.
- Check the battery condition monthly.
- Pull the hood release handle under the corner of the dashboard.



Locate the hood latch lever, pull the lever up, and lift up the hood.



When finished, close the hood and make sure it is firmly locked in place.



- Install snow tires for winter driving.

Check tire pressures regularly.

Handling the Unexpected CRESS

Flat Tire CREST

 Park in a safe location and replace the flat tire with the compact spare tire in the trunk.



Engine Won't Start

→P. 563


• If the battery is dead, jump start using a booster battery.



Indicators Come On


◯ P. 572

• Identify the indicator and consult the owner's manual.



Blown Fuse CR 576

 Check for a blown fuse if an electrical device does not operate.



Overheating > 570

 Park in a safe location. If you do not see steam under the hood, open the hood, and let the engine cool down.



Emergency Towing

→P. 580

 Call a professional towing service if you need to tow your vehicle.



What to Do If



Models without smart entry system

The ignition switch does not turn from 0 to 1. Why?

Models with smart entry system*1

The power mode does not change from VEHICLE OFF (LOCK) to ACCESSORY. Why?



• The steering wheel may be locked.

Models without smart entry system

 Try to turn the steering wheel left and right while turning the ignition key.

Models with smart entry system*1

 Move the steering wheel left and right while pressing the ENGINE START/STOP button at the same time.



Models without smart entry system The ignition switch does

not turn from 1 to 0 and 1 cannot remove the key.

Why?

Models with smart entry system*1


The power mode does not change from ACCESSORY to VEHICLE OFF (LOCK). Why?



The shift lever should be moved to P.




^{*1:}Except U.S. automatic transmission/CVT models






This can occur when the ABS activates, and does not indicate a problem. Apply firm, steady pressure on the brake pedal. Never pump the brake pedal.





If you do not open the doors within 30 seconds, the doors are relocked automatically for security.





The beeper sounds when:

- The key is left in the ignition switch*.
- The power mode* is in ACCESSORY.
- The exterior lights are left on.



Why does the beeper sound when I start driving?



The beeper sounds when:

- Driver and/or front passenger are not wearing their seat belts.
- The parking brake lever is not fully released.



Why do I hear a screeching sound when I apply the brake pedal?



The brake pads may need to be replaced. Have your vehicle inspected by a dealer.

Safe Driving

You can find many safety recommendations throughout this chapter, and throughout this manual.

For Safe Driving	
Important Safety Precautions	30
Your Vehicle's Safety Features	32
Safety CheckList	33
Seat Belts	
About Your Seat Belts	34
Fastening a Seat Belt	37
Seat Belt Inspection	40
Airbags	
Airbag System Components	4
Types of Airbags	44
Front Airbags (SRS)	44

Side Airbags	. 48			
Side Curtain Airbags	. 50			
Airbag System Indicators	. 51			
Airbag Care	. 53			
hild Safety				
Protecting Child Passengers	. 54			
Safety of Infants and Small Children	56			
Safety of Larger Children	. 64			
xhaust Gas Hazard				
Carbon Monoxide Gas	. 66			
afety Labels				
Label Locations	67			

For Safe Driving

The following pages explain your vehicle's safety features and how to use them properly. The safety precautions below are ones that we consider to be among the most important.

Important Safety Precautions

■ Always wear your seat belt

A seat belt is your best protection in all types of collisions. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, make sure you and your passengers always wear your seat belts, and wear them properly.

■ Restrain all children

Children ages 12 and under should ride properly restrained in a back seat, not the front seat. Infants and small children should be restrained in a child seat. Larger children should use a booster seat and a lap/shoulder seat belt until they can use the belt properly without a booster seat.

■ Be aware of airbag hazards

While airbags can save lives, they can cause serious or fatal injuries to occupants who sit too close to them, or are not properly restrained. Infants, young children, and short adults are at the greatest risk. Be sure to follow all instructions and warnings in this manual.

■ Don't drink and drive

Alcohol and driving don't mix. Even one drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. So don't drink and drive, and don't let your friends drink and drive, either.

Some states, provinces and territories prohibit the use of cell phones other than hands-free devices by the driver while driving.

■ Pay appropriate attention to the task of driving safely

Engaging in cell phone conversation or other activities that keep you from paying close attention to the road, other vehicles, and pedestrians could lead to a crash. Remember, situations can change quickly, and only you can decide when it is safe to divert some attention away from driving.


■ Control your speed

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

■ Keep your vehicle in safe condition

Having a tire blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of such problems, check your tire pressures and condition frequently, and perform all regularly scheduled maintenance.

Your Vehicle's Safety Features



The following checklist will help you take an active role in protecting yourself and your passengers.

∑Your Vehicle's Safety Features

Your vehicle is equipped with many features that work together to help protect you and your passengers during a crash.

Some features do not require any action on your part. These include a strong steel framework that forms a safety cage around the passenger compartment, front and rear crush zones, a collapsible steering column, and tensioners that tighten the front seat belts in a sufficient crash.

However, you and your passengers cannot take full advantage of these features unless you remain seated in the correct position and always wear your seat belts. In fact, some safety features can contribute to injuries if they are not used properly.

Safety CheckList

For the safety of you and your passengers, make a habit of checking these items each time before you drive.

• After everyone has entered the vehicle, be sure both doors are closed and locked. Locking the doors helps prevent an occupant from being ejected and an outsider from unexpectedly opening a door.

Locking/Unlocking the Doors from the Inside P. 126

• Adjust your seat to a position suitable for driving. Be sure the front seats are adjusted as far to the rear as possible while allowing the driver to control the vehicle. Sitting too close to a front airbag can result in serious or fatal injury in a crash.

Adjusting the Seats P. 161

• Adjust head restraints to the proper position. Head restraints are most effective when the center of the head restraint aligns with the center of your head. Taller persons should adjust their head restraint to the highest position.

Adjusting the Front and Rear Outer Head Restraint Positions P. 164

• Always wear your seat belt, and make sure you wear it properly. Confirm that any passengers are properly belted as well.

Fastening a Seat Belt P. 37

 Protect children by using seat belts or child seats according to a child's age, height and weight.


Child Safety P. 54

Safety CheckList


If the door and trunk open indicator is on, a door and/or the trunk is not completely closed. Close both doors and the trunk tightly until the indicator goes off.

Door and Trunk Open Indicator P. 77

Models with information display



Models with multi-information display



About Your Seat Belts

Seat belts are the single most effective safety device because they keep you connected to the vehicle so that you can take advantage of many built-in safety features. They also help keep you from being thrown against the inside of the vehicle, against other passengers, or out of the vehicle. When worn properly, seat belts also keep your body properly positioned in a crash so that you can take full advantage of the additional protection provided by the airbags.

In addition, seat belts help protect you in almost every type of crash, including:

- frontal impacts
- side impacts
- rear impacts
- rollovers

■ Lap/shoulder seat belts

All five seating positions are equipped with lap/shoulder seat belts with emergency locking retractors. In normal driving the retractor lets you move freely while keeping some tension on the belt. During a collision or sudden stop the retractor locks to restrain your body.

The rear seat belts also have a lockable retractor for use with child seats.

Installing a Child Seat with a Lap/Shoulder Seat Belt P. 61

■ About Your Seat Belts

AWARNING

Not wearing a seat belt properly increases the chance of serious injury or death in a crash, even though your vehicle has airbags.

Be sure you and your passengers always wear seat belts and wear them properly.

Seat belts cannot completely protect you in every crash. But in most cases, seat belts can reduce your risk of serious injury.

Most states and all Canadian provinces and territories require you to wear seat belts.


The emergency locking retractor may lock if you lean forward too quickly. Slower movements will allow the belt to extend fully without locking.

■ Proper use of seat belts

Follow these guidelines for proper use:

- All occupants should sit upright, well back in the seat, and remain in that position for the duration of the trip. Slouching and leaning reduce the effectiveness of the belt and can increase the chance of serious injury in a crash.
- Never place the shoulder part of a lap/shoulder seat belt under your arm or behind your back. This could cause very serious injuries in a crash.
- Two people should never use the same seat belt. If they do, they could be very seriously injured in a crash.
- Do not put any accessories on the seat belts. Devices intended to improve comfort or reposition the shoulder part of a seat belt can reduce the protective capability and increase the chance of serious injury in a crash.

■ Seat Belt Reminder



Your vehicle monitors front seat belt use. If the ignition switch is turned to ON \boxed{II}^{*1} before the driver's seat belt is fastened, the beeper will sound and the indicator will blink. If the driver does not fasten the belt before the beeper stops, the indicator will remain on.

The beeper will also periodically sound and the indicator will blink while driving until the driver's and front passenger's seat belts are fastened.

* Not available on all models

About Your Seat Belts

If a rear seat passenger moves around and extends the seat belt, the lockable retractor may activate. If this happens, release the retractor by unfastening the seat belt and allow the belt to retract completely. Then refasten the belt.

Seat Belt Reminder

The indicator will also come on if a front passenger does not fasten their seat belt within six seconds after the ignition switch is turned to ON [II]*1. When no one is sitting in the front passenger's seat, the indicator will not come on and the beeper will not sound. The indicator also may not come on and the beeper may not sound when the occupant is not heavy enough to trigger the weight sensor. Such occupants (e.g., infants and smaller children) should

be moved to the rear seat as a deploying front airbag

Protecting Child Passengers P. 54

likely will injure or kill them.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Automatic Seat Belt Tensioners

The front seats are equipped with automatic seat belt tensioners to enhance safety.

The tensioners automatically tighten the front seat belts during a moderate-tosevere frontal collision, sometimes even if the collision is not severe enough to inflate the front airbags.



■ Automatic Seat Belt Tensioners


The seat belt tensioners can only operate once. If a tensioner is activated, the SRS indicator will come on. Have a dealer replace the tensioner and thoroughly inspect the seat belt system as it may not offer protection in a subsequent crash.

During a moderate-to-severe side impact, the tensioner on that side of the vehicle also activates.


Fastening a Seat Belt

After adjusting a front seat to the proper position, and while sitting upright and well back in the seat:

Adjusting the Seats P. 161



1. Pull the seat belt out slowly.



- Insert the latch plate into the buckle, then tug on the belt to make sure the buckle is secure.
 - ► Make sure that the belt is not twisted or caught on anything.

>> Fastening a Seat Belt

No one should sit in a seat with an inoperative seat belt or one that does not appear to be working correctly. Using a seat belt that is not working properly may not protect the occupant in a crash. Have a dealer check the belt as soon as possible.

Never insert any foreign objects into the buckle or retractor mechanism.

Continued 37



- **3.** Position the lap part of the belt as low as possible across your hips, then pull up on the shoulder part of the belt so the lap part fits snugly. This lets your strong pelvic bones take the force of a crash and reduces the chance of internal injuries.
- **4.** If necessary, pull up on the belt again to remove any slack, then check that the belt rests across the center of your chest and over your shoulder. This spreads the forces of a crash over the strongest bones in your upper body.

>> Fastening a Seat Belt

AWARNING

Improperly positioning the seat belts can cause serious injury or death in a crash.


Make sure all seat belts are properly positioned before driving.

To release the belt, push the red **PRESS** button then guide the belt by hand until it has retracted completely.

When exiting the vehicle, be sure the belt is out of the way and will not get caught by closing the door.

Advice for Pregnant Women

If you are pregnant, the best way to protect yourself and your unborn child when driving or riding in a vehicle is to always wear a seat belt and keep the lap part of the belt as low as possible across the hips.



Each time you have a checkup, ask your doctor if it is okay for you to drive.

To reduce the risk of injuries to both you and your unborn child that can be caused by an inflating front airbag:

- When driving, sit upright and adjust the seat as far back as possible while allowing full control of the vehicle.
- When sitting in the front passenger's seat, adjust the seat as far back as possible.

Seat Belt Inspection

Regularly check the condition of your seat belts as follows:

- Pull each belt out fully, and look for frays, cuts, burns, and wear.
- Check that the latches work smoothly and the belts retract easily.
 - ▶ If a belt does not retract easily, cleaning the belt may correct the problem. Only use a mild soap and warm water. Do not use bleach or cleaning solvents. Make sure the belt is completely dry before allowing it to retract.

Any belt that is not in good condition or working properly will not provide proper protection and should be replaced as soon as possible.

A belt that has been worn during a crash may not provide the same level of protection in a subsequent crash. Have your seat belts inspected by a dealer after any collision.


Seat Belt Inspection

AWARNING

Not checking or maintaining seat belts can result in serious injury or death if the seat belts do not work properly when needed.

Check your seat belts regularly and have any problem corrected as soon as possible.

Airbag System Components



The front, front side, and side curtain airbags are deployed according to the direction and severity of impact. Both side curtain airbags are deployed in a rollover. The airbag system includes:

- Two SRS (Supplemental Restraint System) front airbags. The driver's airbag is stored in the center of the steering wheel; the front passenger's airbag is stored in the dashboard. Both are marked SRS AIRBAG.
- Two side airbags, one for the driver and one for a front passenger. The airbags are stored in the outer edges of the seatbacks. Both are marked SIDE AIRBAG.
- 3 Two side curtain airbags, one for each side of the vehicle. The airbags are stored in the ceiling, above the side windows. The front and rear pillars are marked SIDE CURTAIN AIRBAG.

- ♠ An electronic control unit that continually monitors and can record information about the sensors, the airbag activators, the seat belt tensioners, and driver and front passenger seat belt use when the ignition switch is in ON III*1.
- Automatic front seat belt tensioners. The driver's and front passenger's seat belts incorporate sensors that detect whether or not they are fastened.
- **6** A driver's seat position sensor. If the seat is too far forward, the airbag will inflate with less force.
- Weight sensors in the front passenger's seat. The front passenger's airbag will be turned off if the weight on the seat is 65 lbs (29 kg) or less (the weight of an infant or small child).

- Impact sensors that can detect a moderate-to-severe front or side impact.
- An indicator on the dashboard that alerts you that the front passenger's front airbag has been turned off.
- An indicator on the instrument panel that alerts you to a possible problem with your airbag system or seat belt tensioners.
- Safing Sensor
- A rollover sensor that can detect if your vehicle is about to roll over and signal the control unit to deploy both side curtain airbag.
- *1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Important Facts About Your Airbags

Airbags can pose serious hazards. To do their job, airbags must inflate with tremendous force. So, while airbags help save lives, they can cause burns, bruises, and other minor injuries, sometimes even fatal ones if occupants are not wearing their seat belts properly and sitting correctly.

What you should do: Always wear your seat belt properly, and sit upright and as far back from the steering wheel as possible while allowing full control of the vehicle. A front passenger should move their seat as far back from the dashboard as possible.

Remember, however, that no safety system can prevent all injuries or deaths that can occur in a severe crash, even when seat belts are properly worn and the airbags deploy.

Do not place hard or sharp objects between yourself and a front airbag. Carrying hard or sharp objects on your lap, or driving with a pipe or other sharp object in your mouth, can result in injuries if your front airbag inflates.

Do not attach or place objects on the front airbag covers. Objects on the covers marked **SRS AIRBAG** could interfere with the proper operation of the airbags or be propelled inside the vehicle and hurt someone if the airbags inflate.

Do not attempt to deactivate your airbags. Together, airbags and seat belts provide the best protection.

When driving, keep hands and arms out of the deployment path of the front airbag by holding each side of the steering wheel. Do not cross an arm over the airbag cover.

Types of Airbags

Your vehicle is equipped with three types of airbags:

- Front airbags: Airbags in front of the driver's and front passenger's seats.
- **Side airbags:** Airbags in the driver's and front passenger's seat-backs.
- **Side curtain airbags:** Airbags above the side windows.

Each is discussed in the following pages.

Front Airbags (SRS)

The front SRS airbags inflate in a moderate-to-severe frontal collision to help protect the head and chest of the driver and/or front passenger.

SRS (Supplemental Restraint System) indicates that the airbags are designed to supplement seat belts, not replace them. Seat belts are the occupant's primary restraint system.

Housing Locations

The front airbags are housed in the center of the steering wheel for the driver, and in the dashboard for the front passenger. Both airbags are marked **SRS AIRBAG**.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

∑Types of Airbags

The airbags can inflate whenever the ignition switch is in ON $[II]^{*1}$.

After an airbag inflates in a crash, you may see a small amount of smoke. This is from the combustion process of the inflator material and is not harmful. People with respiratory problems may experience some temporary discomfort. If this occurs, get out of the vehicle as soon as it is safe to do so.

Dual-Stage, Multiple-Threshold Front Airbags (SRS)

Your vehicle is equipped with dual-stage, multiplethreshold front airbags (SRS).

During a frontal crash severe enough to cause one or both front airbags to deploy, the airbags can inflate at different rates, depending on the severity of the crash, whether or not the seat belts are latched, and/ or other factors. Frontal airbags are designed to supplement the seat belts to help reduce the likelihood of head and chest injuries in frontal crashes.

Operation

Front airbags are designed to inflate during moderate-to-severe frontal collisions. When the vehicle decelerates suddenly, the sensors send information to the control unit which signals one or both front airbags to inflate.

A frontal collision can be either head-on or angled between two vehicles, or when a vehicle crashes into a stationary object, such as a concrete wall.

■ How the Front Airbags Work



While your seat belt restrains your torso, the front airbag provides supplemental protection for your head and chest.

The front airbags deflate immediately so that they won't interfere with the driver's visibility or the ability to steer or operate other controls.

The total time for inflation and deflation is so fast that most occupants are not aware that the airbags deployed until they see them lying in front of them.

Although the driver's and front passenger's airbags normally inflate within a split second of each other, it is possible for only one airbag to deploy. This can happen if the severity of a collision is at the margin, or threshold, that determines whether or not the airbags will deploy. In such cases, the seat belt will provide sufficient protection, and the supplemental protection offered by the airbag would be minimal.

Continued 45

■ When front airbags should not deploy

Minor frontal crashes: Front airbags were designed to supplement seat belts and help save lives, not to prevent minor scrapes, or even broken bones that might occur during a less than moderate-to-severe frontal crash.

Side impacts: Front airbags can provide protection when a sudden deceleration causes a driver or front passenger to move towards the front of the vehicle. Side airbags and side curtain airbags have been specifically designed to help reduce the severity of injuries that can occur during a moderate-to-severe side impact which can cause the driver or passenger to move towards the side of the vehicle.

Rear impacts: Head restraints and seat belts are your best protection during a rear impact. Front airbags cannot provide any significant protection and are not designed to deploy in such collisions.

Rollovers: Seat belts and, in vehicles equipped with a rollover sensor, side airbags and side curtain airbags offer the best protection in a rollover. Because front airbags could provide little if any protection, they are not designed to deploy during a rollover

■ When front airbags deploy with little or no visible damage


Because the airbag system senses sudden deceleration, a strong impact to the vehicle framework or suspension might cause one or more of the airbags to deploy. Examples include running into a curb, the edge of a hole, or other low fixed object that causes a sudden deceleration in the vehicle chassis. Since the impact is underneath the vehicle, damage may not be readily apparent.

■ When front airbags may not deploy, even though exterior damage appears severe

Since crushable body parts absorb crash energy during an impact, the amount of visible damage does not always indicate proper airbag operation. In fact, some collisions can result in severe damage but no airbag deployment because the airbags would not have been needed or would not have provided protection even if they had deployed.


Advanced Airbags

Your front airbags have advanced features to help reduce the likelihood of airbag related injuries to smaller occupants.



The driver's advanced front airbag system includes a seat position sensor.

If the seat is too far forward, the airbag inflates with less force, regardless of the severity of the impact.



The passenger's advanced front airbag system has weight sensors.

Although we recommend against carrying an infant or small child in front, if the sensors detect the weight of a child (up to about 65 lbs or 29 kg), the system will automatically turn off the passenger's front airbag.

■ Advanced Airbags

If there is a problem with the driver's seat position sensor, the SRS indicator will come on and the airbag will inflate with full (normal) force, regardless of the driver's seating position.

For both advanced front airbags to work properly:

- Do not spill any liquid on or under the seats.
- Do not put any object under the passenger's seat.
- Make sure any objects are positioned properly on the floor. Improperly positioned objects can interfere with the advanced airbag sensors.
- All occupants should sit upright and wear their seat belts properly.
- Do not place any cover over the passenger side dashboard.

Make sure the floor mat behind the front passenger's seat is hooked to the floor mat anchor. An improperly placed mat can interfere with the advanced airbag sensors.

Floor Mats P. 551

Side Airbags

The side airbags help protect the torso and pelvis of the driver or a front passenger during a moderate-to-severe side impact.


Housing Locations



The side airbags are housed in the outside edge of the driver's and passenger's seatbacks.

Both are marked **SIDE AIRBAG**.

Operation



When the sensors detect a moderate-tosevere side impact, the control unit signals the side airbag on the impact side to immediately inflate.

Side Airbags

Make sure you and your front seat passenger always sit upright. Leaning into the path of a side airbag can prevent the airbag from deploying properly and increases your risk of serious injury.

Do not attach accessories on or near the side airbags. They can interfere with the proper operation of the airbags, or hurt someone if an airbag inflates.

Do not cover or replace the front seat-back covers without consulting a dealer.
Improperly replacing or covering front seat-back covers can prevent your side airbags from properly

deploying during a side impact.

■ When a side airbag deploys with little or no visible damage

Because the airbag systems senses sudden acceleration, a strong impact to the side of the vehicle's framework can cause a side airbag to deploy. In such cases, there may be little or no damage, but the side impact sensors detected a severe enough impact to deploy the airbag.


■ When a side airbag may not deploy, even though visible damage appears severe

It is possible for a side airbag to not deploy during an impact that results in apparently severe damage. This can occur when the point of impact was towards the far front or rear of the vehicle, or when the vehicle's crushable body parts absorbed most of the crash energy. In either case, the side airbag would not have been needed nor provided protection even if it had deployed.

Side Curtain Airbags

The side curtain airbags help protect the heads of the driver and passengers in outer seating positions during a moderate-to-severe side impact. The side curtain airbags equipped in this vehicle are also designed to help reduce the likelihood of partial and complete ejection of vehicle occupants through side windows in crashes, particularly rollover crashes.

Housing Locations



The side curtain airbags are located in the ceiling above the side windows on both sides of the vehicle.

Operation



The side curtain airbag is designed to deploy in a rollover or a moderate-to-severe side impact.

Side Curtain Airbags

If the SRS control unit senses that your vehicle is about to rollover, it immediately deploys both side curtain airbags and activates both front seat belt tensioners.

If the impact is on the passenger's side, the passenger's side curtain airbag deploys even if there is no passenger in the passenger seat.

To get the best protection from the side curtain airbags, occupants should wear their seat belts properly and sit upright and well back in their seats.

Do not attach any objects to the side windows or roof pillars as they can interfere with the proper operation of the side curtain airbags.


■ When side curtain airbags deploy in a frontal collision

One or both side curtain airbags may inflate in a moderate-to-severe angled frontal collision.

Airbag System Indicators

If a problem occurs in the airbag system, the SRS indicator will come on and a message appears on the multi-information display*.

Supplemental Restraint System (SRS) Indicator



■ When the ignition switch is turned to ON II *1

The indicator comes on for a few seconds, then goes off. This tells you the system is working properly.

If the indicator comes on at any other time, or does not come on at all, have the system checked by a dealer as soon as possible. If you don't, your airbags and seat belt tensioners may not work properly when they are needed.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

* Not available on all models

Supplemental Restraint System (SRS) Indicator

AWARNING

Ignoring the SRS indicator can result in serious injury or death if the airbag systems or tensioners do not work properly.

Have your vehicle checked by a dealer as soon as possible if the SRS indicator alerts you to a possible problem.

Passenger Airbag Off Indicator



■ When the passenger airbag off indicator comes on

The indicator comes on to alert you that the passenger's front airbag has been turned off. This occurs when the front passenger's weight sensors detect 65 lbs (29 kg) or less, the weight of an infant or small child, on the seat.

Infants and small children should always ride properly restrained in a back seat.

Child Safety P. 54

Objects placed on the seat can also cause the indicator to come on.

If the front passenger seat is empty, the passenger's front airbag will not deploy and the indicator will not come on

▶ Passenger Airbag Off Indicator

If the indicator comes on with no front passenger and no objects on the passenger's seat, or with an adult riding there, something may be interfering with the weight sensors, such as:

- An object hanging on the seat or in the seat-back pocket.
- A child seat or other object pressing against the rear of the seat-back.
- A rear passenger pushing or pulling on the back of the front passenger's seat.
- The front seat or seat-back is forced back against an object on the seat or floor behind it.
- An object placed under the front passenger's seat.

If none of these conditions exist, have your vehicle checked by a dealer as soon as possible.

The passenger airbag off indicator may come on and goes off repeatedly if the total weight on the seat is near the airbag cutoff threshold.

Airbag Care

You do not need to, and should not, perform any maintenance on or replace any airbag system components yourself. However, you should have your vehicle inspected by a dealer in the following situations:

■ When the airbags have deployed

If an airbag has inflated, the control unit and other related parts must be replaced. Similarly, once an automatic seat belt tensioner has been activated, it must be replaced.

■ When the vehicle has been in a moderate-to-severe collision

Even if the airbags did not inflate, have your dealer inspect the following: the driver's seat position sensor, weight sensors in the passenger's seat, front seat belt tensioners, and each seat belt that was worn during the crash.

■ Do not remove or modify a front seat without consulting a dealer

This would likely disable the driver's seat position sensor or the weight sensors in the passenger's seat. If it is necessary to remove or modify a front seat to accommodate a person with disabilities, contact a Honda dealer, or for U.S. vehicles, American Honda Automobile Customer Service at 800-999-1009 and for Canadian vehicles, Honda Canada Customer Relations at 888-9-HONDA-9.

We recommend against the use of salvaged airbag system components, including the airbag, tensioners, sensors, and control unit.

Child Safety

Protecting Child Passengers

Each year, many children are injured or killed in vehicle crashes because they are either unrestrained or not properly restrained. In fact, vehicle accidents are the number one cause of death of children ages 12 and under.

To reduce the number of child deaths and injuries, every state, Canadian province and territory requires that infants and children be properly restrained when they ride in a vehicle.

Children should sit properly restrained in a rear seat. This is because:



- An inflating front or side airbag can injure or kill a child sitting in the front seat.
- A child in the front seat is more likely to interfere with the driver's ability to safely control the vehicle.
- Statistics show that children of all sizes and ages are safer when they are properly restrained in a rear seat.

AWARNING

Children who are unrestrained or improperly restrained can be seriously injured or killed in a crash.

Any child too small for a seat belt should be properly restrained in a child seat. A larger child should be properly restrained with a seat belt, using a booster seat if necessary.

The National Highway Traffic Safety Administration and Transport Canada recommend that all children ages 12 and under be properly restrained in a rear seat. Some states or provinces/territories have laws restricting where children may ride.

- Any child who is too small to wear a seat belt correctly must be restrained in an approved child seat that is properly secured to the vehicle using either the lap belt portion of the lap/shoulder belt or the lower anchors of the LATCH system.
- Never hold a child on your lap because it is impossible to protect them in the event of a collision.
- Never put a seat belt over yourself and a child. During a crash, the belt would likely press deep into the child and cause serious or fatal injuries.
- Never let two children use the same seat belt. Both children could be very seriously injured in a crash.
- Do not allow children to operate the doors, windows or seat adjustments.
- Do not leave children in the vehicle unattended, especially in hot weather when the inside of the vehicle can get hot enough to kill them. They could also activate vehicle controls causing it to move unexpectedly.

▶ Protecting Child Passengers

AWARNING

Allowing a child to play with a seat belt or wrap one around their neck can result in serious injury or death.

Instruct children not to play with any seat belt and make sure any unused seat belt a child can reach is buckled, fully retracted, and locked.

To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.


To remind you of the passenger's front airbag hazards and child safety, your vehicle has warning labels on the dashboard (U.S. models) and on the front visors. Please read and follow the instructions on these labels.

Safety Labels P. 67

Safety of Infants and Small Children

■ Protecting Infants

An infant must be properly restrained in a rear-facing, reclining child seat until the infant reaches the seat maker's weight or height limit for the seat, and the infant is at least one year old.



■ Positioning a rear-facing child seat Child seats must be placed and secured in a rear seating position.

When properly installed, a rear-facing child seat may prevent the driver or a front passenger from moving their seat all the way back, or from locking their seat-back in the desired position.

It can also interfere with proper operation of the passenger's advanced front airbag system.

Airbags P. 41

If this occurs, we recommend that you install the child seat directly behind the front passenger's seat, move the seat as far forward as needed, and leave it unoccupied. Or, you may wish to get a smaller rear-facing child seat.

▶ Protecting Infants

AWARNING

Placing a rear-facing child seat in the front seat can result in serious injury or death during a crash.

Always place a rear-facing child seat in the rear seat, not the front.

Rear-facing child seats should never be installed in a forward facing position.

Always refer to the child seat manufacturer's instructions before installation.

Protecting Smaller Children

If a child is at least one year old and within the weight range indicated by the child seat manufacturer, the child should be properly restrained in a firmly secured forward-facing child seat.



■ Forward-facing child seat placement We strongly recommend placing a forward-facing child seat in a rear seating position.

Placing a forward-facing child seat in the front seat can be hazardous, even with advanced front airbags that automatically turn the passenger's front airbag off. A rear seat is the safest place for a child.

AWARNING

Placing a forward-facing child seat in the front seat can result in serious injury or death if the front airbag inflates.

If you must place a forward-facing child seat in front, move the vehicle seat as far back as possible, and properly restrain the child.

Educate yourself about the laws and regulations regarding child seat use where you are driving, and follow the child seat manufacturer's instructions.

Many experts recommend use of a rear-facing seat for a child up to two years old if the child's height and weight are appropriate for a rear-facing seat.

Continued 57

Selecting a Child Seat

Most child seats are LATCH-compatible (Lower Anchors and Tethers for CHildren). Some have a rigid-type connector, while others have a flexible-type connector. Both are equally easy to use. Some existing and previously owned child seats can only be installed using the seat belt. Whichever type you choose, follow the child seat manufacturer's use and care instructions as well as the instructions in this manual. Proper installation is key to maximizing your child's safety.

In seating positions and vehicles not equipped with LATCH, a LATCH compatible child seat can be installed using the seat belt and a top tether for added security. This is because all child seats are required to be designed so that they can be secured with a lap belt or the lap part of a lap/shoulder belt. In addition, the child seat manufacturer may advise that a seat belt be used to attach a LATCH-compatible seat once a child reaches a specified weight. Please read the child seat owner's manual for proper installation instructions.

■ Important consideration when selecting a child seat

Make sure the child seat meets the following three requirements:

- The child seat is the correct type and size for the child.
- The child seat is the correct type for the seating position.
- The child seat is compliant with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.

Selecting a Child Seat

Installation of a LATCH-compatible child seat is simple.


LATCH-compatible child seats have been developed to simplify the installation process and reduce the likelihood of injuries caused by incorrect installation.


■ Installing a LATCH-Compatible Child Seat

A LATCH-compatible child seat can be installed in either of the two outer rear seats. A child seat is attached to the lower anchors with either the rigid or flexible type of connectors.




1. Locate the lower anchors under the marks





- **2.** Place the child seat on the vehicle seat then attach the child seat to the lower anchors according to the instructions that came with the child seat.
 - ➤ When installing the child seat, make sure that the lower anchors are not obstructed by the seat belt or any other object.

Continued 59



- **3.** Open the tether anchor cover behind the head restraint.
- **4.** Raise the head restraint to its highest position, then route the tether strap between the head restraint legs, and secure the tether strap hook onto the anchor.
- **5.** Tighten the tether strap as instructed by the child seat manufacturer.
- **6.** Make sure the child seat is firmly secured by rocking it forward and back and side to side; little movement should be felt.
- 7. Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.

For your child's safety, when using a child seat installed using the LATCH system, make sure that the seat is properly secured to the vehicle. A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.


■ Installing a Child Seat with a Lap/Shoulder Seat Belt



- **1.** Place the child seat on the vehicle seat
- 2. Route the seat belt through the child seat according to the seat manufacturer's instructions, and insert the latch plate into the buckle.
 - Insert the latch plate fully until it clicks.



A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.





- **3.** Slowly pull the shoulder part of the belt all the way out until it stops. This activates the lockable retractor.
- 4. Let the seat belt completely wind up into the retractor, then try to pull it out to make sure the retractor is locked.
 - If you are able to pull the shoulder belt out, the lockable retractor is not activated. Pull the seat belt all the way out, and repeat steps 2 - 4.
- **5.** Grab the shoulder part of the seat belt near the buckle, and pull up to remove any slack from the lap part of the belt.
 - ► When doing this, place your weight on the child seat and push it into the vehicle seat.



- **6.** Make sure the child seat is firmly secured by rocking it forward and back and side to side; little movement should be felt.
- **7.** Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.

≥ Installing a Child Seat with a Lap/Shoulder Seat Belt

To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.

Adding Security with a Tether

Tether Strap


Anchor

Anchor

Tether Strap

Hook

Hook



Outer Position

Center Position

A tether anchorage point is provided behind each rear seating position. A child seat that is installed with a seat belt and comes with a tether can use the tether for additional security.

1. Locate the appropriate tether anchorage point and lift the cover.



2. Raise the head restraint to its highest position, then route the tether strap through the head restraint legs.

Rear center seating position

- 2. Remove the head restraint.
 - Removing and Reinstalling the Head Restraints P. 165

All positions

- **3.** Secure the tether strap hook onto the anchor.
 - ► Make sure the strap is not twisted.
- **4.** Tighten the tether strap as instructed by the child seat manufacturer.

Rear center seating position

- **5.** Reinstall the head restraint.
 - ► Make sure to adjust the head restraint in its highest position.
 - Removing and Reinstalling the Head Restraints P. 165

■ Adding Security with a Tether

Since a tether can provide additional security to the lap/shoulder seat belt installation, we recommend using a tether whenever one is available.

Safety of Larger Children

■ Protecting Larger Children

The following pages give instructions on how to check proper seat belt fit, what kind of booster seat to use if one is needed, and important precautions for a child who must sit in front.

Checking Seat Belt Fit

When a child is too big for a child seat, secure the child in a rear seat using the lap/ shoulder seat belt. Have the child sit upright and all the way back, then answer the following questions.



■ Checklist

- Do the child's knees bend comfortably over the edge of the seat?
- Does the shoulder belt cross between the child's neck and arm?
- Is the lap part of the seat belt as low as possible, touching the child's thighs?
- Will the child be able to stay seated like this for the whole trip?

If you answer yes to all these questions, the child is ready to wear the lap/shoulder seat belt correctly. If you answer no to any question, the child needs to ride on a booster seat until the seat belt fits properly without a booster seat.

Safety of Larger Children

AWARNING

Allowing a child age 12 or under to sit in front can result in injury or death if the passenger's front airbag inflates.

If a larger child must ride in front, move the vehicle seat as far to the rear as possible, have the child sit up properly and wear the seat belt properly, using a booster seat if needed.

■ Booster Seats



If a lap/shoulder seat belt cannot be used properly, position the child in a booster seat in a rear seating position. For the child's safety, check that the child meets the booster seat manufacturer's recommendations.

■ Protecting Larger Children-Final Checks

Your vehicle has a rear seat where children can be properly restrained. If you ever have to carry a group of children, and a child must ride in front:

- Make sure you read and fully understand the instructions and safety information in this manual.
- Move the front passenger seat as far back as possible.
- Have the child sit upright and well back in the seat.
- Check that the seat belt is properly positioned so that the child is secure in the seat.

■ Monitoring child passengers

We strongly recommend that you keep an eye on child passengers. Even older, more mature children sometimes need to be reminded to fasten their seat belts and sit up properly.

■Booster Seats

When installing a booster seat, make sure to read the instructions that came with it, and install the seat accordingly.

There are high- and low-type booster seats. Choose a booster seat that allows the child to wear the seat belt correctly.

Some U.S. states and Canadian provinces and territories require children to use a booster seat until they reach a given age or weight (e.g. 6 years or 60 lbs). Be sure to check current laws in the state or province, or territory where you intend to drive.

Exhaust Gas Hazard

Carbon Monoxide Gas

The engine exhaust from this vehicle contains carbon monoxide, a colorless, odorless, and highly toxic gas. As long as you properly maintain your vehicle, carbon monoxide gas will not get into the interior.

■ Have the exhaust system inspected for leaks whenever

- The exhaust system is making an unusual noise.
- The exhaust system may have been damaged.
- The vehicle is raised for an oil change.

When you operate a vehicle with the trunk open, airflow can pull exhaust gas into the interior and create a hazardous condition. If you must drive with the trunk open, open both windows and set the climate control system as shown below.

- **1.** Select the fresh air mode.
- 2. Select the mode.
- 3. Set the fan speed to high.
- **4.** Set the temperature control to a comfortable setting.

Adjust the climate control system in the same manner if you sit in your parked vehicle with the engine running.

AWARNING

Carbon monoxide gas is toxic. Breathing it can cause unconsciousness and even kill you.

Avoid any enclosed areas or activities that expose you to carbon monoxide.

An enclosed area such as a garage can quickly fill up with carbon monoxide gas.


Do not run the engine with the garage door closed. Even when the garage door is open, drive out of the garage immediately after starting the engine.

Safety Labels

Label Locations

These labels are in the locations shown. They warn you of potential hazards that can cause serious injury or death. Read these labels carefully.

If a label comes off or becomes hard to read (except for the U.S. dashboard label which may be removed by the owner), contact a dealer for a replacement.



Instrument Panel

This chapter describes the buttons, indicators, and gauges that are used while driving.

ndicators	70					
Information Display Warning and						
Information Messages*	88					
Multi-Information Display Warning a	and					
Information Messages*	90					
Gauges and Displays						
Gauges	98					
Information Display*	99					
Multi-Information Display*	. 102					

* Not available on all models 69

Indicator	Name	On/Blinking	Explanation	Message*
U.S. BRAKE Canada (Red)	Parking Brake and Brake System Indicator (Red)	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off if the parking brake has been released. Comes on when the parking brake is applied, and goes off when it is released. Comes on when the brake fluid level is low. Comes on if there is a problem with the brake system. The beeper sounds and the indicator comes on if you drive with the parking brake not fully released. 	Comes on while driving - Make sure the parking brake is released. Check the brake fluid level. What to do when the indicator comes on while driving P. 574 Comes on along with the ABS indicator - Have your vehicle checked by a dealer. If the Brake System Indicator (Red) Comes On P. 574	WARNING: Brake Brake Fluid Low
BRAKE SYSTEM Canada (Amber)	Brake System Indicator (Amber)	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if there is a problem with a system related to braking other than the conventional brake system. 	Stays on constantly - Have your vehicle checked by a dealer.	Brake System Problem

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
7-7:	Low Oil Pressure Indicator	 Comes on when you turn the ignition switch to ON [II]*1, and goes off when the engine starts. Comes on when the engine oil pressure is low. 	• Comes on while driving - Immediately stop in a safe place. ▶ If the Low Oil Pressure Indicator Comes On P. 572	Engine Oil Low
۲	Malfunction Indicator Lamp	 Comes on when you turn the ignition switch to ON II *1, and goes off either when the engine starts or after several seconds if the engine did not start. If "readiness codes" have not been set, it blinks five times before it goes off. Comes on if there is a problem with the emissions control system. Blinks when a misfire in the engine's cylinders is detected. 	 Readiness codes are part of the on board diagnostics for the emissions control systems. ▶ Testing of Readiness Codes P. 589 Comes on while driving - Have your vehicle checked by a dealer. Blinks while driving - Stop in a safe place where there are no flammable objects. Stop the engine for 10 minutes or more, and wait for it to cool down. Then, take the vehicle to a dealer. ▶ If the Malfunction Indicator Lamp Comes On or Blinks P. 573 	Emissions System Problem
	Charging System Indicator	 Comes on when you turn the ignition switch to ON II *1, and goes off when the engine starts. Comes on when the battery is not charging. 	 Comes on while driving - Turn off the climate control system and rear defogger in order to reduce electricity consumption. ☑ If the Charging System Indicator Comes On P. 572 	Battery Charging Problem

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

* Not available on all models

Indicator	Name	On/Blinking	Explanation	Message*
Models with information display Models with multi-information display	Shift Lever Position Indicator*	Indicates the current shift lever position.	▶ Shifting P. 430 , 434	_

Continuously variable transmission (CVT) models						
Indicator	Name	On/Blinking	Explanation	Message*		
Models with information display Models with multi-information display	M (7-speed manual shift mode) Indicator/ Shift Indicator	• Comes on when 7-speed manual shift mode is applied.	▶ 7-Speed Manual Shift Mode P. 432	_		

Automatic t	ransmission models			
Indicator	Name	On/Blinking	Explanation	Message*
Models with information display Models with multi-information display	M (Sequential shift mode) Indicator/Gear Position Indicator	Comes on when manual sequential shift mode is applied.	▶ Sequential Shift Mode P. 436	_

^{*} Not available on all models

Indicator	Name	On/Blinking	Explanation	Message*
Models with information display Models with multi-information display	Transmission Indicator*	Blinks if the transmission system has a problem.	Blinks while driving - Avoid sudden starts and acceleration and have your vehicle checked by a dealer immediately.	Transmission System Problem
	Seat Belt Reminder Indicator	 Comes on and the beeper sounds if you are not wearing a seat belt when you turn the ignition switch to ON III *1. If the front passenger is not wearing a seat belt, the indicator comes on a few seconds later. Blinks while driving if either you or the front passenger has not fastened a seat belt. The beeper sounds and the indicator blinks at regular intervals. 	 The beeper stops and the indicator goes off when you and the front passenger fasten their seat belts. Stays on after you or the front passenger has fastened the seat belt - A detection error may have occurred in the sensor. Have your vehicle checked by a dealer. Seat Belt Reminder P. 35 	Fasten Seat Belt

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
	Low Fuel Indicator	 Comes on when the fuel reserve is running low (approximately 2.6 U.S. gal./9.7 Liter left). Blinks if there is a problem with the fuel gauge. 	 Comes on - Refuel your vehicle as soon as possible. Blinks - Have your vehicle checked by a dealer. 	Fuel Gauge System Problem
(ABS)	Anti-lock Brake System (ABS) Indicator	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. If it comes on at any other time, there is a problem with the ABS. 	 Stays on constantly - Have your vehicle checked by a dealer. With this indicator on, your vehicle still has normal braking ability but no anti-lock function. Anti-lock Brake System (ABS) P. 481 	Anti-Lock Brake System Problem
	Supplemental Restraint System Indicator	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if a problem with any of the following is detected: Supplemental restraint system Side airbag system Side curtain airbag system Seat belt tensioner 	Stays on constantly or does not come on at all - Have your vehicle checked by a dealer.	Airbag System (SRS) Problem

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

* Not available on all models

Indicator	Name	On/Blinking	Explanation	Message*
A	Vehicle Stability Assist (VSA®) System Indicator	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Blinks when VSA® is active. Comes on if there is a problem with the VSA® system or hill start assist system. 	• Stays on constantly - Have your vehicle checked by a dealer. ☑ Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System P. 471	Vehicle Stability Assist (VSA) Problem Hill Start Assist Problem
OFF	Vehicle Stability Assist (VSA®) OFF Indicator	 Comes on for a few seconds when you turn the ignition switch to ON III *1, then goes off. Comes on when you deactivate VSA®. 	► VSA® OFF Button P. 472	-

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
Models with information display Models with multi-information display	Door and Trunk Open Indicator	 Comes on for a few seconds if you turn the ignition switch to ON II *1, then goes off. Comes on if either door or the trunk is not completely closed. The beeper sounds and the indicator comes on if either door or the trunk is opened while driving. 	Goes off when both doors and the trunk are closed.	Door And Trunk Open
P″/ <u>\</u>	Parking Sensor System Indicator*	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if there is a problem with the parking sensor system. 	• Check if the area around the sensor(s) is covered with mud, ice, snow, etc. If the indicator stays on even after you clean the area, have the system checked by a dealer.	_
!	Electric Power Steering (EPS) System Indicator	 Comes on when you turn the ignition switch to ON [II]*1, and goes off when the engine starts. Comes on if there is a problem with the EPS system. 	• Stays on constantly or does not come on at all - Have your vehicle checked by a dealer. ☑ If the Electric Power Steering (EPS) System Indicator Comes On P. 574	Power Steering System (EPS) Problem

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

* Not available on all models

Indicator	Name	On/Blinking	Explanation	Message*
(!) Pr	Low Tire Pressure/ TPMS Indicator	 Comes on for a few seconds when you turn the ignition switch to ON II *1, then goes off. May come on briefly if the ignition switch is turned to ON III *1 and the vehicle is not moved within 45 seconds, to indicate the calibration process is not yet complete. Comes on and stays on when: One or more tires' pressures are determined to be significantly low. The system has not been calibrated. 	 Comes on while driving - Stop in a safe place, check tire pressures, and inflate the tire(s) if necessary. Stays on after the tires are inflated to the recommended pressures - The system needs to be calibrated. ▶ TPMS Calibration P. 475 	Pressures Low
		 Blinks for about one minute, and then stays on if there is a problem with the TPMS, or when a compact spare tire is temporarily installed. 	Blinks and remains on - Have your vehicle checked by a dealer. If the vehicle is fitted with a compact spare, get your regular tire repaired or replaced and put back on your vehicle as soon as you can.	Tire Pressure Monitor Problem TPMS

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
i	System Message Indicator*	 Comes on for a few seconds when you turn the ignition switch to ON II *1, then goes off. Comes on along with a beep when a problem is detected. A system message on the multi-information display appears at the same time. 	 While the indicator is on, press the ▲①/▼ (information) button to see the message again. Refer to the Indicators information in this chapter when a system message appears on the multi-information display. Take the appropriate action for the message. The multi-information display does not return to the normal screen unless the warning is canceled, or the	_
++	Turn Signal and Hazard Warning Indicators	 Blinks when you operate the turn signal lever. Blink along with all turn signals when you press the hazard warning button. 	• Does not blink or blinks rapidly - A turn signal light bulb has blown. Change the bulb immediately. ■ Replacing Light Bulbs P. 532, 531, 533	_
	High Beam Indicator	• Comes on when the high beam headlights are on.	_	_
=0 0=	Lights On Indicator	• Comes on whenever the light switch is on, or in AUTO when the exterior lights are on.	• If you remove the key from the ignition switch*1 while the exterior lights are on, a chime sounds when the driver's door is opened.	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

* Not available on all models Continued

79

Indicator	Name	On/Blinking	Explanation	Message*
钓	Fog Light Indicator*	 Comes on when the fog lights are on. 	-	_
c=== ==	Immobilizer System Indicator	 Comes on briefly when you turn the ignition switch to ON II *1, then goes off. Comes on if the immobilizer system cannot recognize the key information. 	 Blinks - You cannot start the engine. Turn the ignition switch to LOCK 0 *1, pull the key out, and then insert the key and turn it to ON II *1 again. Repeatedly blinks - The system may be malfunctioning. Have your vehicle checked by a dealer. Do not attempt to alter this system or add other devices to it. Electrical problems can occur. 	_
Indicator	Security System Alarm Indicator	Blinks when the security system alarm has been set.	Security System Alarm P. 133	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
*	ECON Mode Indicator	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on when you press the ECON button. 	■ ECON Button P. 441	ECON On
CRUISE MAIN	CRUISE MAIN Indicator*	• Comes on when you press the CRUISE button.	■ Cruise Control P. 442	_
CRUISE	CRUISE CONTROL Indicator*	• Comes on if you have set a speed for cruise control.	☑ Cruise Control P. 442	_
	Washer Level Indicator*	Comes on when the washer fluid gets low.	 Refill the washer fluid. Refilling Window Washer Fluid P. 528 	_
0	Maintenance Minder Indicator*	Comes on when the scheduled maintenance is due soon.	▶ Maintenance Minder™ P. 505	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
~ļ@	Smart Entry System Indicator*	 Comes on for a few seconds when you change the power mode to ON. Comes on as soon as a problem is detected in the smart entry system or push button starting system. 	Stays on constantly or does not come on at all - Have your vehicle checked by a dealer.	Keyless Access System Problem -!
U.S. STARTER SYSTEM Canada	Starter System Indicator*	 Comes on for a few seconds when you turn the ignition switch to ON II *1, then goes off. Comes on if the starter system has a problem. 	• As a temporary measure, press and hold the ENGINE START/STOP button for up to 15 seconds while pressing the brake pedal and manually start the engine. Have your vehicle checked by a dealer.	_
	Light Control Indicator*	• Comes on if there is a problem with the automatic lighting control system or low beam headlights*.	• Comes on while driving - Turn the lights on manually and have your vehicle checked by a dealer.	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
≣ (A)	Auto High-Beam Indicator (Green)*	 Comes on when all the operating conditions of the auto high-beam are met. 	■ Auto High-Beam (High Beam Support System)* P. 148	-
	Auto High-Beam	Comes on if there is a problem with the auto high-beam.	 Manually operate the headlight switch. If you are driving with the high-beam headlights when this happens, the headlights are changed to low beams. 	
	Indicator (Amber)*	 Comes on when the area around the camera on the windshield is blocked by dirt, mud, etc. 	 Stop your vehicle in a safe place, and wipe it off with a soft cloth. If the indicator does not go off after cleaning the lens, have your vehicle checked by a dealer. 	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
		 Comes on for a few seconds when you turn the ignition switch to ON II *1, then goes off. Comes on if there is a problem with the RDM system. 	Stays on constantly - Have your vehicle checked by a dealer.	Road Departure Mitigation System Problem
	Road Departure Mitigation (RDM) Indicator*	• Comes on when the RDM system shuts itself off.	• Stays on - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down. ▶ Front Sensor Camera * P. 445	Some Driver Some Driver Control Control Control Control Contro
			 Stays on - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. Have your vehicle checked by a dealer if the indicator and message come back on after you cleaned the area around the camera. Front Sensor Camera* P. 445 	Some Driver Actist Systems Great Front Windowski

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
	Adaptiva Cruica	 Comes on for a few seconds when you turn the ignition switch to ON III *1, then goes off. Comes on if there is a problem with ACC. 	Comes on while driving - Have your vehicle checked by a dealer.	Adaptive Crutec Control Problem
ACC	Adaptive Cruise Control (ACC) Indicator (Amber)*	 Comes on if anything covers the radar sensor cover and prevents the sensor from detecting a vehicle in front. May come on when driving in bad weather (rain, snow, fog, etc.) ACC has been automatically canceled. 	 When the radar sensor gets dirty, stop your vehicle in a safe place, and wipe off dirt using a soft cloth. Have your vehicle checked by a dear if the indicator does not go off even after you clean the sensor cover. 	Some Driver Assist Systems Cannot Operate: Radar Obstructed
		• Comes on when you press the MAIN button.	► Adaptive Cruise Control (ACC)* P. 447	-
ACC	Adaptive Cruise Control (ACC) Indicator (White)*	 Comes on if the temperature inside the camera is too high. ACC has been automatically canceled. 	 Use the climate control system to cool down the camera. Goes off - The camera has been cooled down. Pressing the MAIN button can resume the system. ➡ Front Sensor Camera* P. 445 ➡ Adaptive Cruise Control (ACC)* P. 447 	Some Driver send System cond System Control Temperature Control Temperature Too India

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
LKAS	Lane Keeping Assist System (LKAS) Indicator (Amber)*	 Comes on for a few seconds when you turn the ignition switch to ON II *1, then goes off. Comes on if there is a problem with the LKAS. 	Stays on constantly - Have your vehicle checked by a dealer.	Lane Keep Assist Problem LKAS
LKAS	Lane Keeping Assist System (LKAS) Indicator (White)*	Comes on when you press the MAIN button.	■ Lane Keeping Assist System (LKAS)* P. 464	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
		 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on when you deactivate the CMBS™. A multi-information display message appears for five seconds. Comes on if there is a problem with the CMBS™. 	• Stays on constantly without the CMBS™ off - Have your vehicle checked by a dealer. ☑ Collision Mitigation Braking System™ (CMBS™)* P. 483	Collision Mitigation Braking System OFF Collision Mitigation System Problem
*	Collision Mitigation Braking System™	• Comes on when the CMBS™ system shuts itself off.	 Stays on - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. Front Sensor Camera* P. 445 	Some briver Adult System Gront Greente Gront Front finished
	(CMBS™) Indicator*		 When the radar sensor gets dirty, stop your vehicle in a safe place, and wipe off dirt using a soft cloth. Have your vehicle checked by a dealer if the message does not disappear even after you clean the sensor cover. Collision Mitigation Braking System™ (CMBS™)* P. 483 	Some Driver Assist Systems Cannot Operate. Radar Obstructed
			• Stays on - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down. ▶ Front Sensor Camera* P. 445	Some Driver Assets dynamic Connot Governic Connot Governic (So 10)

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Information Display Warning and Information Messages*

The following messages appear only on the information display.

Message	Condition	Explanation
<u>CHECK</u> FUEL CRP	 Appears when the fuel fill cap is loose or is not installed. 	D Check/Tighten Fuel Cap Message P. 573
<u>CHECK</u> CHRPGE SYSTEM	• Appears when there is a problem with the sensor on the battery.	• Stays on constantly - Have your vehicle checked by a dealer.

Models with smart entry system

Message	Condition	Explanation
Automatic transmission/CVT models POWER 15 ON SHIFT TO P	• Appears if you push the ENGINE START/STOP button to turn the engine off without the shift lever in P.	 Push the ENGINE START/STOP button twice after moving the shift lever to P.
POHER IS ON	Appears when the power mode is in ACCESSORY.	_
U.S. manual transmission models Canadian models I- PUSH STRAT 2- TURN WHEEL	Appears when the steering wheel is locked.	Move the steering wheel left and right while pressing the ENGINE START/STOP button at the same time.
NOKEY	• Appears when you close the door with the power mode in ON without the smart entry remote inside the vehicle.	
KEY BATT	 Appears when the smart entry remote's battery becomes weak. 	 Replace the battery as soon as possible. ▶ Replacing the Button Battery P. 547

Multi-Information Display Warning and Information Messages*

The following messages appear only on the multi-information display. Press the \square (information) button to see the message again with the system message indicator on.

Message	Condition	Explanation
Tighten Fuel Cap	Appears when the fuel fill cap is loose or is not installed.	► Check/Tighten Fuel Cap Message P. 573
Maintenance Due Soon A2345	 Appears when the scheduled maintenance is due soon. Consequently, Maintenance Due Now and Maintenance Past Due follow. 	■ Maintenance Minder Messages on the Multi- Information Display P. 510
Engine Temperature Too Hot	Appears when the engine coolant temperature gets abnormally high.	Doverheating P. 570
Auto Light System Problem	Appears if there is a problem with the automatic lighting control system.	Appears while driving - Manually turn the lights on, and have your vehicle checked by a dealer.
Headlight Problem	Appears if there is a problem with the low beam headlights.	• Appears while driving - The low beam headlights may not be on. When conditions allow you to drive safely, have your vehicle checked by a dealer as soon as possible.

^{*} Not available on all models

Message	Condition	Explanation
Models with auto high-beam High Beam Support System Problem	Appears if there is a problem with the auto high- beam.	 Manually operate the headlight switch. If you are driving with the high-beam headlights when this happens, the headlights are changed to low beams.
Models with auto high-beam High Beam Support System Cannot Operate Clean Windshield	Appears when the area around the camera on the windshield is blocked by dirt, mud, etc.	 Stop your vehicle in a safe place, and wipe it off with a soft cloth. If the message does not disappear after cleaning the lens, have your vehicle checked by a dealer.
Models with parking sensor system Parking Sensor System Problem	Appears if there is a problem with the parking sensor system. The beeper sounds.	• Check if the area around the sensor(s) is covered with mud, ice, snow, etc. If the indicator(s) stays on even after you clean the area, have the system checked by a dealer.
Canadian models Washer Fluid Low	Appears when the washer fluid is low.	 Refill the washer fluid. ▶ Refilling Window Washer Fluid P. 528

Models without smart entry system

Message	Condition	Explanation
Accessory (I) Position	Appears when the ignition key is turned to ACCESSORY	_
Turn Ignition Switch to Lock (0) Position ⁡	• Appears when you open the driver's door while the ignition key is in ACCESSORY 1.	Turn the ignition switch to LOCK , then remove the key.
Remove Key From Ignition	 Appears when you open the driver's door while the ignition key is in LOCK 0. 	Remove the key from the ignition switch.

Models with smart entry system

Message	Condition	Explanation
To Start Engine: Brake + Push	Appears after you unlock and open the driver's door.	▶ Starting the Engine P. 423
U.S. manual transmission models Canadian models To Unlock Wheet Push + Rotate	Appears when the steering wheel is locked.	Move the steering wheel left and right while pressing the ENGINE START/STOP button.
Shift To Park	• Appears if you push the ENGINE START/STOP button to turn the engine off without the shift lever in P.	Move the shift lever to P. The power mode changes to VEHICLE OFF.
Accessory Mode	Appears when the power mode is in ACCESSORY.	_

Models with smart entry system

Message	Condition	Explanation
To Switch Vehicle Orf: Push Twice	 Appears after the driver's door is opened when the power mode is in ACCESSORY. 	 Press the ENGINE START/STOP button twice with your foot off the brake pedal to change the power mode to VEHICLE OFF (LOCK).
Keyless Remote Not Detected	 Appears when you close the door with the power mode in ON without the smart entry remote inside the vehicle. 	 Disappears when you bring the smart entry remote back inside the vehicle and close the door. Smart Entry Remote Reminder P. 143
Keyless Remote Battery Low	Appears when the smart entry remote battery becomes weak.	 Replace the battery as soon as possible. Replacing the Button Battery P. 547
To Start, Hold Remote Near Start Button	 Appears if the smart entry remote battery is too weak to start the engine or the key is not within operating range to start the engine. A beeper sounds six times. 	 Bring the smart entry remote in front of the ENGINE START/STOP button to be touched with. ☑ If the Smart Entry Remote Battery is Weak P. 564
To Switch Accessory Ors Push	• Appears three seconds after the To Start Engine: Brake + Push message appears.	⚠ Changing the Power Mode P. 141
	 Appears three seconds after you bring the smart entry remote in front of the ENGINE START/STOP button when To Start, Hold Remote Near Start Button appears. To Start Engine: Brake + Push appears sequentially. 	☑ Changing the Power Mode P. 141

Message	Condition	Explanation
Mark Sto And Shift To Fain 10 Change Settings	 Appears while you are customizing the settings and the shift lever is moved out of P. 	☑ Customized Features P. 106
Charging System Problem	 Appears when there is a problem with the sensor on the battery. Appears when the battery is not charging. 	 Have your vehicle checked by a dealer. Checking the Battery P. 546 Appears along with the battery charging system indicator - Turn off the climate control system and rear defogger to reduce electricity consumption. If the Charging System Indicator Comes On P. 572
Starter System Problem	Appears when the starter system has a problem.	 As a temporary measure, press and hold the ENGINE START/STOP button for up to 15 seconds while pressing the brake pedal and manually start the engine. Have your vehicle checked by a dealer.
***	Appears for about three seconds when ACC has been automatically canceled.	 You can resume the set speed after the condition that caused ACC to cancel improves. Press the RES/+ button. ■ Adaptive Cruise Control (ACC)* P. 447
BRAKE	Flashes when the system senses a likely collision with a vehicle in front of you.	 Take appropriate action to prevent a collision (apply the brakes, change lanes, etc.). Adaptive Cruise Control (ACC)* P. 447 Collision Mitigation Braking System™ (CMBS™)* P. 483

* Not available on all models

Message	Condition	Explanation
Some Driver Assist Systems Clean Frost Windshield	 Appears when the area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. May appear when driving in bad weather (rain, snow, fog, etc.). 	 Have your vehicle checked by a dealer if the message appears again after you cleaned the area around the camera.
Some Driver Autol Streem Autol Streem Camer Temperatur Too High	 Appears if the temperature inside the camera is too high. ACC/LKAS has been automatically canceled. 	 Use the climate control system to cool down the camera. Goes off - The camera has been cooled down. Pressing the MAIN/LKAS button can resume the system. ▶ Front Sensor Camera* P. 445 ▶ Adaptive Cruise Control (ACC)* P. 447 ▶ Lane Keeping Assist System (LKAS)* P. 464
Lane Departure	 Lane Keeping Assist System (LKAS) Appears when the vehicle is driving out of a detected line. The steering wheel vibrates rapidly. 	 Keep the vehicle within the lane you are driving. The color of either line changes from white to amber as the vehicle gets closer to that side of the lane line. ▶ Lane Keeping Assist System (LKAS)* P. 464
	Appears when the vehicle is driving out of a detected line. When you selected Warning Only The steering wheel vibrates rapidly when the vehicle is drifting out of a detected line. When you selected Normal or Wide The steering wheel vibrates rapidly when the vehicle is drifting out of a detected line. When you selected Normal or Wide The steering wheel vibrates rapidly when the vehicle is drifting out of a detected line. The system also steers the vehicle to help you remain within your driving lane.	 Keep the vehicle within the lane you are driving. The color of either line changes from white to amber as the vehicle gets closer to that side of the lane line. ▶ Road Departure Mitigation (RDM) System* P. 460 You can change the setting for the road departure mitigation system. Normal, Wide, and Warning Only can be selected. ▶ Customized Features P. 106, 298, 316

Message	Condition	Explanation
Steering Required	Blinks when you fail to steer the vehicle. The beeper sounds simultaneously.	Operate the steering wheel to resume the LKAS.
	 Appears when the LKAS is in operation, or the LKAS button is pressed, but there is a problem with a system related to the LKAS. The LKAS cancels automatically. The beeper sounds simultaneously. 	 If any other system indicators come on, such as the VSA®, ABS and brake system, take appropriate action. ▶ Indicators P. 70

Models with remote engine starter

Message	Condition	Explanation
To Start Driving: Brake + Push	 Appears when you unlock and open the driver's door while the engine is running by smart entry remote. 	Remote Engine Start* P. 425

* Not available on all models

Gauges and Displays

Gauges

Gauges include the speedometer, tachometer, fuel gauge, and related indicators. They are displayed when the ignition switch is in ON \boxed{II}^{*1} .

Speedometer

Displays your driving speed in mph (U.S.) or km/h (Canada).

■ Tachometer

Shows the number of engine revolutions per minute.

■ Fuel Gauge

Displays the amount of fuel left in the fuel tank.

■ Temperature Gauge

Displays the temperature of the engine coolant.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

∑Fuel Gauge

NOTICE

You should refuel when the reading approaches **E**. Running out of fuel can cause the engine to misfire, damaging the catalytic converter.

The actual amount of remaining fuel may differ from the fuel gauge reading.

∑Temperature Gauge

NOTICE

Driving with the temperature gauge pointer in the upper zone can cause serious engine damage. Pull safely to the side of the road and allow engine temperature to return to normal.


Overheating P. 570

Information Display*

The information display shows the odometer, trip meter, engine oil life and maintenance service item codes, and other gauges.


Switching the Display

Press the (Select/Reset) knob to change the display.



Switching the Display

Each time you press the ② knob, the information display changes as follows:



Some of the items on the information display also appear on the audio/information screen. They also change along with the information display changes while the fuel consumption is shown.

Odometer

Shows the total number of miles (U.S.) or kilometers (Canada) that your vehicle has accumulated.

■ Trip Meter

Shows the total number of miles (U.S.) or kilometers (Canada) driven since the last reset. Meters A and B can be used to measure two separate trips.

■ Resetting a trip meter

To reset a trip meter, display it, then press and hold the knob. The trip meter is reset to **0.0**.

Average Fuel Economy

Shows the estimated average fuel economy of each trip meter in mpg (U.S.) or I/100 km (Canada). The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

■ Instant Fuel Economy

Shows the instant fuel economy as a bar graph in mpg (U.S.) or I/100 km (Canada).

Engine Oil Life

Shows the remaining oil life and Maintenance Minder™.

Maintenance Minder™ P 505

∑Trip Meter

Switch between trip meter A and trip meter B by pressing the A knob.

■ Average Fuel Economy

You can change when to reset the average fuel economy.

Customized Features P. 298, 316

Outside Temperature

Shows the outside temperature in Fahrenheit (U.S.) or Celsius (Canada).

■ Adjusting the outside temperature indicator

Adjust the temperature reading up to \pm 5°F or \pm 3°C if the temperature reading seems incorrect.

- **1.** Turn the ignition switch to ON II *1.
- **2.** Press and hold the (Select/Reset) knob for 10 seconds or more while the outside temperature is shown on the information display.
 - ► The information display goes into temperature adjustment mode. The display starts showing from -5°F to +5°F (U.S.) or -3°C to +3°C (Canada).
- **3.** Release the knob when the right adjustment amount is shown.
 - ► The adjustment is complete.

Range

Shows the estimated distance you can travel on the remaining fuel. This distance is estimated from the fuel economy of your previous trips.

Outside Temperature

The temperature sensor is in the front bumper. Road heat and exhaust from another vehicle can affect the temperature reading when your vehicle speed is less than 19 mph (30 km/h).

It may take several minutes for the display to be updated after the temperature reading has stabilized.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Multi-Information Display*


The multi-information display shows the odometer, trip meter, outside temperature indicator, and other gauges.

It also displays important messages such as warnings and other helpful information.

Switching the Display


■ Main displays

Press the ▲①/▼ (information) button to change the display.



■ Lower displays

Press the **SEL/RESET** button to change the display.



Continued 103

Odometer

Shows the total number of miles (U.S.) or kilometers (Canada) that your vehicle has accumulated

■ Trip Meter

Shows the total number of miles (U.S.) or kilometers (Canada) driven since the last reset. Meters A and B can be used to measure two separate trips.

■ Resetting a trip meter

To reset a trip meter, display it, then press and hold the **SEL/RESET** button. The trip meter is reset to **0.0**.

Average Fuel Economy

Shows the estimated average fuel economy of each trip meter in mpg (U.S.) or I/100 km (Canada). The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

Range

Shows the estimated distance you can travel on the remaining fuel. This distance is estimated from the fuel economy of your previous trips.

Elapsed Time

Shows the time elapsed since Trip A or Trip B was reset.

∑Trip Meter

Switch between trip meter A and trip meter B by pressing the **SEL/RESET** button.

■ Average Fuel Economy

You can change when to reset the average fuel economy.

Customized Features P. 106, 298, 316

Elapsed Time

You can change when to reset the elapsed time.

Customized Features P. 106, 298, 316

Average Speed

Shows the average speed in mph (U.S.) or km/h (Canada) since Trip A or Trip B was reset.

■ Instant Fuel Economy

Shows the instant fuel economy as a bar graph in mpg (U.S.) or I/100 km (Canada).

Engine Oil Life

Shows the remaining oil life and Maintenance Minder™.

Maintenance Minder™ P. 505

Outside Temperature

Shows the outside temperature in Fahrenheit (U.S.) or Celsius (Canada).

■ Adjusting the outside temperature display

Adjust the temperature reading up to $\pm 5^{\circ}F$ or $\pm 3^{\circ}C$ if the temperature reading seems incorrect.

You can change when to reset the average speed.

Customized Features P. 106, 298, 316

∑Outside Temperature

The temperature sensor is in the front bumper. Road heat and exhaust from another vehicle can affect the temperature reading when your vehicle speed is less than 19 mph (30 km/h).

It may take several minutes for the display to be updated after the temperature reading has stabilized.

Use the multi-information display's customized features to correct the temperature.

Customized Features P. 106, 298, 316


Continued 105

Customized Features

Use the multi-information display to customize certain features.

■ How to customize

Select the **Vehicle Settings** screen by pressing the $\boxed{\blacktriangle}$ button while the ignition switch is in ON $\boxed{\blacksquare}^{*1}$, and the vehicle is at a complete stop. Press the **SEL/RESET** button.



○ Customized Features

To customize other features, press the ▲①/▼ button.

- List of customizable options P. 109
- **Example of customization settings** P. 113

Customization is possible when you see the driver's ID (**Driver 1** or **Driver 2**) on the screen.


The driver's ID indicates which remote transmitter you have used to unlock the driver's door. The customized settings are recalled every time you unlock the driver's door with that remote.


When you customize settings: Shift to P

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Customization flow

Press the ▲①/▼ button.





■ List of customizable options

Setup Group	Customizable Features	Description	Selectable Settings
TPMS Calibration	-	Calibrates the TPMS.	Cancel/Calibrate
	Forward Collision Warning Distance	Changes at which distance the CMBS™ alerts.	Long/Normal*1/Short
	ACC Pre-Running Car Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of ACC range.	On/Off*1
Driver Assist System Setup	ACC Display Speed Unit	Changes the ACC display speed unit.	mph*1/km/h (U.S.) mph/km/h*1 (Canada)
	Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	Normal* ¹ /Wide/Warning Only
	Lane Keep Assist Suspend Beep	Causes the system to beep when the LKAS is suspended.	On/Off*1

^{*1:}Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Meter Setup	Language Selection	Changes the displayed language.	English*1/French/Spanish
	Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	-5°F ~ ±0°F*1 ~ +5°F (U.S.) -3°C ~ ±0°C*1 ~ +3°C (Canada)
	"Trip A" Reset Timing	Changes the setting of how to reset trip meter A, average fuel economy A, average speed A, and elapsed time A.	With Refuel/IGN Off/ Manually Reset*1
	"Trip B" Reset Timing	Changes the setting of how to reset trip meter B, average fuel economy B, average speed B, and elapsed time B.	With Refuel/IGN Off/ Manually Reset*1
	Fuel Efficiency Backlight	Turns the ambient meter feature on and off.	On*1/Off
	Keyless Start Guidance Screens	Displays the push button start guidance when conditions are met to change power mode.	On*1/Off
Driving Position Setup	Memory Position Link	Changes the driver's seat position to a stored setting.	On*1/Off

^{*1:}Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Keyless Access Setup	Door Unlock Mode	Changes which doors unlock when you grab the driver's door handle.	Driver Door Only*1/All Doors
	Keyless Access Light Flash	Causes some exterior lights to blink when you unlock/lock the doors.	On*1/Off
	Keyless Access Beep	Sets the beeper sound or not when you grab either door handle.	On*1/Off
	Remote Start System ON/OFF*	Turns the remote engine start feature on and off.	ON*1/OFF
Lighting Setup	Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	60sec/30sec*1/15sec
	Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60sec/30sec/15sec* ¹ /0sec
	Auto Light Sensitivity	Changes the timing for the headlights to come on.	Max/High/Mid*1/Low/Min

^{*1:} Default Setting

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Door Setup	Auto Door Lock	Changes the setting for when the doors automatically lock.	With Vehicle Speed*1/Shift from P/Off
	Auto Door Unlock	Changes the setting for when the doors automatically unlock.	All Doors When Driver's Door Opens*1/All Doors When Shifted To Park/All Doors When Ignition Switched Off/Off
	Key And Remote Unlock Mode	Sets up either the driver's door or both doors to unlock on the first operation of the remote or built-in key.	Driver Door*1/ All Doors
	Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	On*1/Off
	Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening either door.	90sec/60sec/30sec*1
Maintenance Reset	_	Resets/Cancels the engine oil life display when you have performed the maintenance service.	Cancel/Reset
Default All	-	Cancels/Resets all the customized settings as default.	Cancel/Set

^{*1:} Default Setting

■ Example of customization settings

The steps for changing the "Trip A" Reset Timing setting to With Refuel are shown below. The default setting for "Trip A" Reset Timing is Manually Reset.




1. Press the ▲①/▼ button to select **Vehicle**Settings, then press the SEL/RESET
button.




- 2. Press the ▲①/▼ button until Meter Setup appears on the display.
- **3.** Press the **SEL/RESET** button.
 - ► Language Selection appears first in the display.

Continued 113





➤ The display switches to the customization setup screen, where you can select With Refuel, IGN Off, Manually Reset, or Exit.



- **5.** Press the ▲①/▼ button and select **With Refuel**, then press the **SEL/RESET** button.
 - ➤ The With Refuel Setup screen appears, then the display returns to the customization menu screen.



- Press the ▲③/▼ button until Exit appears on the display, then press the SEL/RESET button.
- **7.** Repeat Step 6 until you return to the normal screen.

Controls

This chapter explains how to operate the various controls necessary for driving.

Clock Locking and Unlocking the Doors	. 116
Key Types and Functions Low Smart Entry Remote Signal Strength*. Locking/Unlocking the Doors from the	120
Outside Locking/Unlocking the Doors from th Inside	. 121 าe
Auto Door Locking/Unlocking Opening and Closing the Trunk	. 128
Security System Immobilizer System Security System Alarm	
Opening and Closing the Windows Opening and Closing the Moonroof*.	.136

Operating the Switches Around th Steering Wheel	ne
Ignition Switch *	
ENGINE START/STOP Button* Ignition Switch and Power Mode	141
Comparison	144
Turn Signals	
Light Switches	
Fog Lights*	147
Auto High-Beam (High Beam Supp	ort
System)*	
Daytime Running Lights	151
Wipers and Washers	
Brightness Control	154

Rear Defogger/Heated Door Mirror* Button	155
Driving Position Memory System*	
Adjusting the Steering Wheel	
djusting the Mirrors	
Interior Rearview Mirror	159
Power Door Mirrors	160
djusting the Seats	161
iterior Lights/Interior Convenience	
tems	169
limate Control System	
Using Automatic Climate Control	
Synchronized Mode	
Automatic Climate Control Sensors	183

* Not available on all models

Adjusting the Clock

You can adjust the time in the clock display with the ignition switch is in ON III *1.

Adjusting the Time

Models with one display

■ Using the Settings menu on the audio/information screen



- 1. Press the **SETTINGS** button.
- **2.** Rotate ♥ to select **System Settings**, then press ௧.
 - Repeat the procedure to select Clock, then Clock Adjustment.
- **4.** Rotate ♥ to change minute, then press ८.

■ Adjusting the Clock

Models with one display

These indications are used to show how to operate the selector knob.

Rotate 🛜 to select.

Press & to enter.

You can customize the clock display to show the 12 hour clock or 24 hour clock.


Customized Features P. 298, 316

You can turn the clock display on and off.

Customized Features P. 298, 316

Models with one display

■ Using the SETTINGS button



- **1.** Press and hold the **CLOCK (SETTINGS)** button until the clock display blinks.
- 2. Press Preset 4 (Hour) or 5 (Minute) to adjust the time.
- **3.** Press the **CLOCK** button again to set the time.

≥Using the SETTINGS button

To set the time to the nearest hour: Press and hold the **CLOCK** button until the clock display blinks, then press the 6 (Reset) button.

Depending on the displayed time, the clock sets forward or backward.

Example:

1:06 will reset to 1:00

1:53 will reset to 2:00

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Models with two displays

■ Using the Settings menu on the audio/information touch screen



- **1.** Select then select **Settings**.
- **2.** Select **Clock/Info**, then **Clock Adjustment**.
- **3.** Adjust the hours and minutes by selecting $\boxed{\mathbf{A}}/\boxed{\mathbf{\nabla}}$.
- **4.** Select **OK** to set the time.

≥ Using the Settings menu on the audio/information touch screen

Models with two displays


The clock is automatically updated through the audio system, so the time does not need to be adjusted.

Locking and Unlocking the Doors

Key Types and Functions


This vehicle comes with the following keys:

■ Master Keys



Use the key to start and stop the engine, to lock and unlock the doors and to open the trunk. You can also use the remote transmitter or smart entry system* to lock and unlock the doors and to open the trunk.

■ Smart entry remote*



The built-in key can be used to lock/unlock the doors when the smart entry remote battery becomes weak and the power door lock/unlock operation is disabled.

To remove the built-in key, pull it out while sliding the release knob. To reinstall the built-in key, push the built-in key into the smart entry remote until it clicks.

■ Key Types and Functions

All the keys have an immobilizer system. The immobilizer system helps to protect against vehicle theft.

Immobilizer System P. 133

The keys contain precision electronics.

Adhere to the following advice to prevent damage to the electronics:

- Do not leave the keys in direct sunlight, or in locations with high temperature or high humidity.
- Do not drop the keys or set heavy objects on them.
- Keep the keys away from liquids.
- Do not take the keys apart except for replacing the battery.

If the circuits in the keys are damaged, the engine may not start, and the remote transmitter may not work.

If the keys do not work properly, have them inspected by a dealer.

Models with remote engine starter

You can remotely start the engine using the smart entry remote.

Remote Engine Start* P. 425

■ Valet Key*



Can be used to start and stop the engine, and lock and unlock driver's door.

When you need to leave a key with a third party, leave the valet key.

■ Key Number Tag



Contains a number that you will need if you purchase a replacement key.

Keep the key number tag separate from the key in a safe place outside of your vehicle.

If you wish to purchase an additional key, contact a dealer.

If you lose your key and you cannot start the engine, contact a dealer.

* Not available on all models

Low Smart Entry Remote Signal Strength*

The vehicle transmits radio waves to locate the smart entry remote when locking/unlocking the doors, opening the trunk, or to start the engine.

In the following cases, locking/unlocking the doors, opening the trunk, or starting the engine may be inhibited or operation may be unstable:

- Strong radio waves are being transmitted by nearby equipment.
- You are carrying the smart entry remote together with telecommunications equipment, laptop computers, cell phones, or wireless devices.
- A metallic object is touching or covering the smart entry remote.

∑Low Smart Entry Remote Signal Strength*


Communication between the smart entry remote and the vehicle consumes the smart entry remote's battery.

Battery life is about two years, but this varies depending on regularity of use.

The battery is consumed whenever the smart entry remote is receiving strong radio waves. Avoid placing it near electrical appliances such as televisions and personal computers.

Locking/Unlocking the Doors from the Outside

Using the Smart Entry with Push Button Start System*



When you carry the smart entry remote, you can lock/unlock the doors and open the trunk. You can lock/unlock the doors within a radius of about 32 inches (80 cm) of the outside door handle. You can open the trunk within about 32 inches (80 cm) radius from the trunk release button.

■ Locking the doors and the trunk



Press the door lock button on either door.

Some exterior lights flash; the beeper sounds; both doors and the trunk lock; and the security system sets.

■Using the Smart Entry with Push Button Start System *

- Do not leave the smart entry remote in the vehicle when you get out. Carry it with you.
- Even if you are not carrying the smart entry remote, you can lock/unlock the doors while someone else with the remote is within range.
- The door may be unlocked if the door handle is covered with water in heavy rain or in a car wash if the smart entry remote is within range.
- If you grip either door handle wearing gloves, the door sensor may be slow to respond or may not respond by unlocking the doors.
- You cannot unlock the door by gripping the handle after two seconds of locking it.
- The door might not open if you pull it immediately after gripping the door handle. Grip the handle again and confirm that the door is unlocked before pulling the handle.
- Even within the 32 inches (80 cm) radius, you may not be able to lock/unlock the doors with the smart entry remote if it is above or below the outside handle.
- The smart entry remote may not operate if it is too close to the door and door glass.

If the distance at which the remote transmitter works varies, the battery is probably low.


If the LED does not come on when you press a button, the battery is dead.

Replacing the Button Battery P. 547

You can customize the door lock mode and keyless lock acknowledgement setting.

■ Customized Features P. 106, 298, 316

■ Unlocking the vehicle





Grab the driver's door handle:

- ► The driver's door unlocks.
- Some exterior lights flash twice and the beeper sounds twice.

Grab the passenger's door handle:

- ▶ Both doors and the trunk unlock.
- Some exterior lights flash twice and the beeper sounds twice.

Press the trunk release button:

- ► The trunk unlocks and opens.
- Using the Trunk Release Button* P. 130


■Using the Smart Entry with Push Button Start System*

If you do not open a door within 30 seconds of unlocking the vehicle, the doors will automatically relock.

The light flash, beep and unlock settings can be customized using the multi-information display*, audio/information screen* or audio/information touch screen*.

Customized Features P. 106, 298, 316

Using the Remote Transmitter



■ Locking the doors

Press the lock button.

Once:

Some exterior lights flash, both doors lock, and the security system sets.

Twice (within five seconds after the first push):

► The beeper sounds and verifies the security system is set.

∑Using the Remote Transmitter

If you do not open a door within 30 seconds of unlocking the vehicle with the remote transmitter, the doors will automatically relock.

You can change the relock timer setting.

☑ Customized Features P. 106, 298, 316

If the interior light switch is in the door activated position, the interior lights come on when you press the unlock button.

No doors opened: The lights fade out after 30 seconds.

Doors relocked with the remote: The lights go off immediately.

Interior Lights P. 169

The remote transmitter uses low-power signals, so the operating range may vary depending on the surroundings.

Models without smart entry system

The remote transmitter will not work when the key is in the ignition switch.

Models with smart entry system

You can lock or unlock doors using the remote transmitter or smart entry system only when the power mode in VEHICLE OFF.

All models

The remote will not lock the vehicle when a door is open.

Continued 123

■ Unlocking the doors

Press the unlock button.

Once:

► Some exterior lights flash twice, and the driver's door unlocks.

Twice:

► The passenger's door unlocks.

∑Using the Remote Transmitter

If the distance at which the remote transmitter works varies, the battery is probably low.

If the LED does not come on when you press a button, the battery is dead.

Replacing the Button Battery P. 547

You can customize the door unlock mode setting.

■ Customized Features P. 106, 298, 316

Locking/Unlocking the Doors Using a Key




Fully insert the key and turn it.

■Locking/Unlocking the Doors Using a Key

When you lock the driver's door with a key, the passenger's door locks at the same time. When unlocking, the driver's door unlocks first. Turn the key a second time within a few seconds to unlock the passenger's door.

You can customize the door unlock mode setting.
Customized Features P. 106, 298, 316

■ Locking a Door Without Using a Key



■ Locking the driver's door

Push the lock tab forward ① or push the master door lock switch in the lock direction ②, and close the door.

➤ The doors cannot be locked when the key is in the ignition switch*1, or the smart entry remote is inside the vehicle.

■ Locking the passenger's door

Push the lock tab forward and close the door.

Locking a Door Without Using a Key


When you lock the driver's door, the passenger's door locks at the same time.

Make sure you have the key in your hand before locking the door to prevent it from being locked in the vehicle.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Locking/Unlocking the Doors from the Inside

■ Using the Lock Tab



■ Locking a door

Push the lock tab forward.

■ Unlocking a door


Pull the lock tab rearward.

≥Using the Lock Tab

When you lock the door using the lock tab on the driver's door, the passenger's door locks at the same time.

When you unlock the door using the lock tab on the driver's door, only the driver's door will unlock.

Unlocking Using the Inner Handle



Pull the inner handle.

► The door unlocks and opens in one motion.

Unlocking and opening the driver's door from the inner handle unlocks both doors.


To avoid both doors to be unlocked, use the lock tab on the driver's door to unlock, then lock again before opening the door.

➤ This setting works for one time only. If you do not want both doors to be unlocked all the time, customize the **Auto Door Unlock** setting to **Off** using the multi-information display*, audio/information screen* or audio/information touch screen*.

■ Unlocking Using the Inner Handle

The inner handles are designed to allow front seat occupants to open the door in one motion. However this feature requires that front seat occupants never pull an inner handle while the vehicle is in motion.

Using the Master Door Lock Switch



Press the master door lock switch in as shown to lock or unlock both doors.

≥Using the Master Door Lock Switch

When you lock/unlock the driver's door using the master lock switch, the passenger's door locks/ unlocks at the same time.

Auto Door Locking/Unlocking

Your vehicle locks and unlocks both doors automatically when a certain condition is met.

Auto Door Locking

■ Drive lock mode

Both doors lock when the vehicle's speed reaches about 10 mph (15 km/h).

Auto Door Unlocking

■ Driver's door open mode

Both doors unlock when the driver's door is opened.

You can turn off or change to another auto door locking/unlocking setting using the multi-information display*, audio/information screen* or audio/information touch screen*

Customized Features P. 106, 298, 316

Opening and Closing the Trunk

Precautions for Opening/Closing the Trunk

■ Opening the trunk

Open the trunk all the way.


▶ If it is not fully opened, the trunk lid may begin to close under its own weight.

■ Closing the trunk

Keep the trunk lid closed while driving to:

- Avoid possible damage.
- ▶ Prevent exhaust gas from leaking into the vehicle.
- Exhaust Gas Hazard P. 66

Using the Trunk Opener



Pulling the trunk release to the lower left of the driver's seat unlocks and opens the trunk.

Continued 129



■ Locking the trunk opener

You can lock the trunk release with the master key* or the built-in key*.

∑Locking the trunk opener

Models without smart entry system

If you need to give the key to someone else, give them the valet key.

Using the Trunk Release Button*



Press the release button on the trunk lid after the doors are unlocked


Even if the trunk is locked, you can open the trunk if you carry the smart entry remote.

► The beeper will sound.

∑Using the Trunk Release Button*


- Do not leave the smart entry remote in the vehicle when you get out. Carry it with you.
- A person who is not carrying the smart entry remote can unlock the trunk if a person who is carrying it is within range.
- Do not leave the smart entry remote inside the trunk and close the lid. The beeper sounds and the trunk cannot be closed.
- Do not carry the smart entry remote near the trunk lid when closing it.
- Do not place the smart entry remote around the rear seat when closing the trunk.

Using the Remote Transmitter



Press the trunk release button for approximately one second to unlock and open the trunk.

Trunk Main Switch*




The trunk main switch disables the trunk release button on the remote transmitter and the trunk release button on the trunk lid to protect luggage in the trunk.

- **1.** Make sure the rear seat-back is not folded down.
- **2.** Turn off the trunk main switch in the glove box.
- 3. Lock the glove box.
- 4. Lock the trunk release.
 - Using the Trunk Opener P. 129

Trunk Main Switch*

If you need to give the key to someone else, remove the built-in key from the smart entry remote by sliding the release knob, and give the remote as a valet key.

Emergency Trunk Opener



The trunk release lever allows you to open the trunk from inside for your safety.

Slide the release lever in the direction of the arrow.

Parents should decide if their children should be shown how to use this feature.

Security System

Immobilizer System

The immobilizer system prevents a key that has not been pre-registered from starting the engine. Each key contains electronic transmitters that use electronic signals to verify the key.

Pay attention to the following when inserting the key into the ignition switch or pressing the **ENGINE START/STOP** button:

- Do not allow objects that emit strong radio waves near the ignition switch or the ENGINE START/STOP button.
- Make sure the key is not covered by or touching a metal object.
- Do not bring a key from another vehicle's immobilizer system near the ignition switch or the ENGINE START/STOP button.
- Do not put the key near magnetic items. Electronic devices, such as a television set and audio system are strongly magnetic, or a key chain can become magnetic, too.

Security System Alarm

The security system alarm activates when the trunk, hood or doors are forcibly opened. The alarm does not go off if the trunk or doors are opened with the key, remote transmitter or smart entry system.

However, the alarm goes off when a door is opened with the key, then the shift lever is moved out of $\boxed{\mathbf{P}}$ (automatic transmission/CVT models) or the hood is opened before the ignition switch is turned to ON $\boxed{\mathbf{II}}^{*1}$.

■ When the security system alarm activates

The horn sounds intermittently and all the exterior lights flash.

■ To deactivate the security system alarm

Unlock the vehicle using the remote transmitter, or smart entry system. The system, along with the horn and flashing lights, is deactivated.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

NOTICE

Leaving the ignition key in the vehicle can result in theft or accidental movement of the vehicle. Always take the ignition key with you whenever you leave the vehicle unattended.

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

Security System Alarm

The security alarm continues for a maximum of two minutes until the security system deactivates.

Continued 133

■ Setting the security system alarm

The security system alarm automatically sets when the following conditions have been met:

- The ignition switch is in LOCK [0]*1, and the key has been removed from the ignition switch.
- The hood and trunk are closed.
- Both doors are locked from outside with the key, the remote transmitter, or smart entry system.

■ When the security system alarm sets

The security system alarm indicator in the instrument panel blinks. When the blinking interval changes after about 15 seconds, the security system is set.

■ To cancel the security system alarm

The security system alarm is canceled when the vehicle is unlocked using the remote transmitter, smart entry system or the ignition switch is turned to ON \boxed{II}^{*1} . The security system indicator goes off at the same time.

Security System Alarm

Do not set the security system alarm when someone is in the vehicle or a window is open. The system can accidentally activate when:

- Unlocking the door with the lock tab.
- Opening the trunk with the trunk release or the emergency trunk opener.
- Opening the hood with the hood release.

Automatic transmission/CVT models

• Moving the shift lever out of P.


If the battery goes dead after you have set the security system alarm, the security alarm may go off once the battery is recharged or replaced.

If this occurs, deactivate the security system alarm by unlocking a door using the key or remote transmitter.

Do not attempt to alter this system or add another device to it.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Panic Mode



■ The panic button on the remote transmitter

If you press the panic button for approximately one second, the following will occur for about 30 seconds:

- The horn sounds.
- Some exterior lights flash.

■ Canceling panic mode

Press any button on the remote transmitter, or turn the ignition switch to ON III^{*1} .

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Opening and Closing the Windows


Opening/Closing the Power Windows

The power windows can be opened and closed when the ignition switch is in ON \boxed{II}^{*1} , using the switches on the doors. The driver's side switches can be used to open and close both windows.

The power window lock button on the driver's side must be switched off (not pushed in, indicator off) to open and close the passenger's window from the passenger's side.

When the power window lock button is pushed in, you can only operate the driver's window. Turn the power window lock button on when children are in the vehicle.

Opening/Closing Windows with Auto-Open/Close Function



■ Automatic operation

To open: Push the switch down firmly. **To close:** Pull the switch up firmly.

The window opens or closes completely. To stop the window at any time, push or pull the switch briefly.

■ Manual operation

To open: Push the switch down lightly, and hold it until the desired position is reached. **To close:** Pull the switch up lightly, and hold it until the desired position is reached.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

∑Opening/Closing the Power Windows

AWARNING

Closing a power window on someone's hands or fingers can cause serious injury.

Make sure your passengers are away from the windows before closing them.

The power windows can be operated for up to 10 minutes after you turn the ignition switch to LOCK $\boxed{0}^{*1}$.

Opening either door cancels this function.


Auto Reverse

If a power window senses resistance when closing automatically, it stops closing and reverse direction.

The driver's window auto reverse function is disabled when you continuously pull up the switch.

The auto reverse function stops sensing when the window is almost closed to ensure that it fully closes.


■ Opening/Closing Windows without Auto-Open/Close Function*



To open: Push the switch down. **To close:** Pull the switch up.

Release the switch when the window reaches the desired position.

■ Opening Windows and Moonroof with the Remote*



To open: Press the unlock button twice within 10 seconds and hold it down for the second time.

If the windows stop midway, repeat the procedure.

Opening/Closing the Windows and Moonroof with the Key*



To open: Unlock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the unlock direction and hold it there.


To close: Lock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the lock direction and hold it there.

Release the key to stop the windows/ moonroof at the desired position. If you want further adjustment, repeat the same operation.

Opening and Closing the Moonroof*

Opening/Closing the Moonroof

You can only operate the moonroof when the ignition switch is in ON \boxed{II}^{*1} . Use the switch in the front of the ceiling to open and close the moonroof.



■ Automatic operation

To open: Pull the switch back firmly. **To close:** Push the switch forward firmly.

The moonroof will automatically open or close all the way. To stop the moonroof midway, touch the switch briefly.

■ Manual operation

To open: Pull the switch back lightly, and hold it until the desired position is reached. **To close:** Push the switch forward lightly, and hold it until the desired position is reached.

■ Tilting the moonroof up

To tilt: Push on the center of the moonroof switch.

To close: Push the switch forward firmly, then release.

■Opening/Closing the Moonroof

AWARNING

Opening or closing the moonroof on someone's hands or fingers can cause serious injury.

Make sure all hands and fingers are clear of the moonroof before opening or closing it.

NOTICE

Opening the moonroof in below freezing temperature or when it is covered with snow or ice can damage the moonroof panel or motor.

The power moonroof can be operated for up to 10 minutes after you turn the ignition switch off. Opening either door cancels this function.


When resistance is detected, the auto reverse function causes the moonroof to change directions, then stop. Auto reverse stops sensing when the moonroof is almost closed to ensure that it fully closes. Make sure that all objects, including fingers, are clear of the moonroof.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Operating the Switches Around the Steering Wheel

Ignition Switch*



- O LOCK: Insert and remove the key in this position.
- ACCESSORY: Operate the audio system and other accessories in this position.
- III ON: This is the position when driving.
- [III] START: This position is for starting the engine. The switch returns to ON [II] when you let go of the key.

■ Ignition Switch *

Manual transmission models

AWARNING

Removing the key from the ignition switch while driving locks the steering. This can cause you to lose control of the vehicle.

Remove the key from the ignition switch only when parked.

Continuously variable transmission (CVT) models

You cannot take the key out unless the shift lever is in $\boxed{\textbf{P}}$.

All models

If you open the driver's door when the key is in LOCK

O or ACCESSORY

, a warning buzzer will sound to remind you to take the key out.

Models with multi-information display

When this happens, the following messages appear on the multi-information display:


- In LOCK 0: Remove Key From Ignition
- In ACCESSORY 1: Turn Ignition Switch To Lock
 (0) Position

All models

If the key won't turn from LOCK $\boxed{0}$ to ACCESSORY $\boxed{1}$, turn the key while moving the steering wheel left and right. The steering wheel will unlock, allowing the key to turn.

ENGINE START/STOP Button*

Changing the Power Mode



*1: Except U.S. automatic transmission/CVT models

■ ENGINE START/STOP Button *

ENGINE START/STOP Button Operating Range



You can start the engine when the smart entry remote is inside the vehicle.

The engine may also run if the smart entry remote is close to the door or window, even if it is outside the vehicle

ON mode:

Indicator in the button is off, if the engine is running.

If the smart entry remote battery is weak, the beeper sounds and the **To Start, Hold Remote Near Start Button** message appears on the multi-information display*.

■ If the Smart Entry Remote Battery is Weak P. 564

Do not leave the power mode in ACCESSORY or ON when you get out.

Automatic Power Off

If you leave the vehicle for 30 to 60 minutes with the shift lever in $\boxed{\mathbf{P}}^{*1}$ and the power mode in ACCESSORY, the vehicle automatically goes into the mode similar to VEHICLE OFF (LOCK) to avoid draining the battery.

When in this mode:

Except U.S. automatic transmission/CVT models

The steering wheel does not lock.

All models

You cannot lock or unlock doors with the remote transmitter or the smart entry system.

Press the **ENGINE START/STOP** button to switch the mode to VEHICLE OFF (LOCK).

Power Mode Reminder

If you open the driver's door when the power mode is set to ACCESSORY, a warning buzzer sounds.


∑Changing the Power Mode

Except U.S. automatic transmission/CVT models

If the power mode does not change from VEHICLE OFF to ACCESSORY, press the **ENGINE START/STOP** button while moving the steering wheel left and right. The steering wheel will unlock, allowing the mode to change.

^{*1:} Automatic transmission/CVT models

Smart Entry Remote Reminder



Warning buzzers may sound from inside and/ or outside the vehicle to remind you that the smart entry remote is out of the vehicle. If the buzzer continues even after the remote is put back inside, place it within the system's operational range.

■ When the power mode is in ON

If the smart entry remote is taken out of the vehicle, and the driver's door is closed, warning buzzers sound from both inside and outside the vehicle. A warning message on the information display or multi-information display notifies the driver inside that the remote is out.

■ When the power mode is in ACCESSORY

If the smart entry remote is taken out of the vehicle, and both doors are closed, a warning buzzer sounds from outside the vehicle.

Smart Entry Remote Reminder

When the smart entry remote is within the system's operational range, and the driver's door is closed, the warning function cancels.

If the smart entry remote is taken out of the vehicle after the engine has been started, you can no longer change the **ENGINE START/STOP** button mode or restart the engine. Always make sure if the remote is in your vehicle when you operate the **ENGINE START/STOP** button.

Removing the smart entry remote from the vehicle through a window does not activate the warning buzzer.


Do not put the smart entry remote on the dashboard or in the glove box. It may cause the warning buzzer to go off. Under some other conditions that can prevent the vehicle from locating the remote, the warning buzzer may also go off even if the remote is within the system's operational range.

Ignition Switch and Power Mode Comparison

Ignition Switch Position	LOCK (0) (with/without the key)	ACCESSORY (I)	ON (II)	START (III)
Without Smart Entry System	 Engine is turned off and power is shut down. The steering wheel is locked. No electrical components can be used. 	 Engine is turned off. Some electrical components such as the audio system and the accessory power socket can be operated. 	 Normal key position while driving. All electrical components can be used. 	 Use this position to start the engine. The ignition switch returns to the ON (II) position when you release the key.
Power Mode	VEHICLE OFF (LOCK)	ACCESSORY ENGINE START STOP	ON ENGINE START STOP Indicator is: On Off	START ENGINE START STOP
With Smart Entry System and ENGINE START/STOP Button	 Indicator-Off Engine is turned off and power is shut down. The steering wheel is locked*1. No electrical components can be used. 	 Indicator-On or blinking Engine is turned off. Some electrical components such as the audio system and the accessory power socket can be operated. 	Indicator- On (engine is turned off) Off (engine is running) • All electrical components can be used.	Indicator-Off • The mode automatically returns to ON after the engine starts.

^{*1:}Except U.S. automatic transmission/CVT models

Turn Signals



The turn signals can be used when the ignition switch is in ON II *1.

■ One-touch turn signal

When you lightly push up or down and release the turn signal lever, the exterior turn signals and turn signal indicator blink three times.

This feature can be used when signaling for a lane change.

Light Switches

| Manual Operation



tail, and rear license plate lights

Turns on headlights, parking, side marker, tail, and rear license plate lights

Rotating the light switch turns the lights on and off, regardless of the position of the ianition switch*1.

■ High beams

Push the lever forward until you hear a click.

■ Low beams

When in high beams, pull the lever back to return to low beams

■ Flashing the high beams

Pull the lever back, and release it.

*1: Models with the smart entry system have an ENGINE START/STOP button instead of an ignition switch.

≫Light Switches

If you remove the key from the ignition switch while the lights are on, a chime sounds when the driver's door is opened.

When the lights are on, the lights on indicator in the instrument panel will be on.

Lights On Indicator P. 79

If you sense that the level of the headlights is abnormal, have the vehicle inspected by a dealer.

Do not leave the lights on when the engine is off because it will cause the battery to discharge.

Continued 145

Automatic Operation (automatic lighting control)



Automatic lighting control can be used when the ignition switch is in ON \boxed{II}^{*1} .


When you turn the light switch to **AUTO**, the headlights and other exterior lights will switch on and off automatically depending on the ambient brightness.


- ➤ You can change the auto light sensitivity setting.
 - Customized Features P. 106, 298, 316

■ Automatic Operation (automatic lighting control)

We recommend that you turn on the lights manually when driving at night, in a dense fog, or in dark areas such as long tunnels or parking facilities.

The light sensor is in the location shown below. Do not cover this light sensor with anything; otherwise, the automatic lighting system may not work properly.





^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Headlight Integration with Wipers*

The headlights automatically come on when the wipers are used several times within a certain number of intervals with the headlight switch in **AUTO**.

The headlights automatically go off a few minutes later if the wipers are stopped.

Automatic Lighting Off Feature

The headlights, all other exterior lights, and the instrument panel lights turn off 15 seconds after you remove the key or set the power mode to VEHICLE OFF (LOCK), take the remote with you, and close the driver's door.

▶ You can change the headlight auto off timer setting.

Customized Features P. 106, 298, 316

If you turn the ignition switch to LOCK $\boxed{0}^{*1}$ with the headlight switch on, but do not open the door, the lights turn off after 10 minutes (three minutes, if the switch is in the **AUTO** position).

The lights turn on again when you unlock or open the driver's door. If you unlock the door, but do not open it within 15 seconds, the lights go off. If you open the driver's door, you will hear a lights on reminder chime.

Fog Lights*



When the low beam headlights are on, turn the fog light switch on to use the fog lights.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

* Not available on all models

■ Automatic Operation (automatic lighting control)

Adjust the auto light sensitivity as follows:

MAX				
Pright				
HIGH	Bright			
MID				
LOW				
MIN				

This feature activates while the headlights are off in **AUTO**.

The instrument panel brightness does not change when the headlights come on.

At dark ambient light levels, the automatic lighting control feature turns on the headlights, regardless of the number of wiper sweeps.

∑Fog Lights*

When the fog lights are on, the indicator in the instrument panel will be on.

They go off when the headlights turn off, or when the daytime running lights are on.


Fog Light Indicator* P. 80

Auto High-Beam (High Beam Support System)*

Uses the camera attached, monitors the space ahead of your vehicle, and automatically changes the low beam headlights to high beam headlights when necessary.

The system operates when:

- The headlight switch is in **AUTO**.
- The lever is in the low beam position.
- The system recognizes that you are driving at night and the low beam headlights come on.
- The vehicle speed is above 25 mph (40 km/h).




The system changes between high and low beam headlights when:

The camera is not detecting any lights coming from preceding or oncoming vehicles: The headlights change to high beams.

The camera detects lights coming from a preceding or oncoming vehicle: The headlights are returned to low beams.

The camera monitors the range within the 30-degree view angle. The distance that the camera can detect lights ahead differs depending on conditions, such as the brightness of the lights and the weather.



The auto high-beam determines when to change the headlight beams by responding to the brightness of the lights ahead of your vehicle. In the following cases, however, the system may not respond to the lights properly:

- The brightness of the lights from the preceding or oncoming vehicle is intense or poor.
- Visibility is poor due to the weather (rain, snow, fog, windshield frost, etc.).
- Other light sources, such as streetlights and electric billboards are illuminating the road ahead.
- The brightness level of the road ahead constantly changes.
- The road is bumpy or has many curves.
- A vehicle ahead of you suddenly cuts you off or is not traveling in the appropriate deirection.
- Your vehicle is tilted due to a heavy load in the rear.

If you find the timing of beam changes inconvenient for driving, change the headlight beams manually.

■ To Operate the System



Turn the headlight switch in **AUTO** and pull the headlight lever to low beam.

≧ Light Switches P. 145

The auto high-beam indicator (Green) comes on.

■ Temporary cancellation

The auto high-beam operation is temporarily canceled while:

- You are continuously driving at a speed below 15 mph (24 km/h).
- The vehicle speed is below 6 mph (10 km/h).
- The windshield wipers run at high speed for more than a few seconds.

The system operation resumes once the condition that caused it to cancel improves.

■To Operate the System

For the auto high-beam to work properly:

- Do not place an object that reflects light on the dashboard.
- Keep the windshield around the camera clean.
 When cleaning the windshield, be careful not to apply the windshield cleanser to the camera lens.
- Do not attach an object, sticker or film in the area around the camera.
- Do not touch the camera lens.

If the camera receives a strong impact, or repairing of the area near the camera is required, consult a dealer.

To help reduce the likelihood that high interior temperatures will cause the camera system to shut off, when parking, find a shady area or face the front of the vehicle away from the sun.

If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on the camera.

Models with multi-information display

If the **Can Not Operate:** message appears: Park your vehicle in a safe place. Wipe away debris blocking the windshield, then start driving again. If the message remains on even after driving for a while with the clean windshield, have your vehicle checked by a dealer.

Continued 149

■ To Disable the System



Disable the system when the vehicle is parked with the ignition switch in ON \overline{II}^{*1} and the light switch is in the **AUTO** position.

To disable the system: Pull the light switch lever towards you and hold it for 40 seconds. The auto high-beam indicator in the meter will blink twice.

To enable the system: Pull the light switch lever towards you and hold it for 30 seconds. The auto high-beam indicator in the meter will blink once.

™To Disable the System

The auto high-beam will remain in the selected disabled or enabled setting each time you start the engine.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Daytime Running Lights

Models with bulb type parking lights

The high beam headlights come on slightly dimmer than normal when the following conditions have been met:

Models with LED type parking/daytime running lights

The parking/daytime running lights come on when the following conditions have been met:

- The ignition switch is in ON II *1.
- The headlight switch is off, or in 5005.
- The parking brake is released.

The lights remain on even if you set the parking brake. Turning off the ignition switch or setting the power mode to VEHICLE OFF will turn off the daytime running lights.

Models with bulb type parking lights

The high beam headlights return to the original brightness once the headlight switch is turned on.

The daytime running lights are off once the headlight switch is turned on, or when the head light switch is in **AUTO** and it is getting darker outside.


■ Daytime Running Lights

The daytime running lights come on dimmer when the headlight switch is in [2005] than when it is in **AUTO**. In **AUTO**, if the ambient brightness is dark, the low beam headlights come on.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Wipers and Washers

Windshield Wiper/Washer



4 LO: Low speed wipe

5 HI: High speed wipe

The windshield wipers and washers can be used when the ignition switch is in ON \overline{II}^{*1} .

■ MIST

The wipers run at high speed until you release the lever.

■ Wiper switch (OFF, INT*, LO, HI)

Change the wiper switch setting according to the amount of rain.

■ AUTO*

■ Automatic Intermittent Wipers* P. 153

■ Adjusting wiper operation

Turn the adjustment ring to adjust the wiper delay.



Lower speed, fewer sweeps

Higher speed, more sweeps

■ Washer

Sprays while you pull the lever toward you. When you release the lever for more than one second, the spray stops, the wipers sweep two or three more times to clear the windshield, then stop.

NOTICE

Do not use the wipers when the windshield is dry. The windshield will get scratched, or the rubber blades will get damaged.

NOTICE

In cold weather, the blades may freeze to the windshield, becoming stuck.

Operating the wipers in this condition may damage them. Use the defroster to warm the windshield, then turn the wipers on.

Models without automatic intermittent wipers

If the vehicle speeds up while the wipers are operating intermittently, the length of the wipe interval shortens.

When the vehicle starts moving, the wipers make a single sweep.

When the vehicle speeds up, the wiper operation's shortest delay setting () and the **LO** setting become the same


All models

Turn the washers off if no washer fluid comes out. The pump may get damaged.

The wiper motor may stop motor operation temporarily to prevent an overload. Wiper operation will return to normal within a few minutes, once the circuit has returned to normal.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Automatic Intermittent Wipers*



When you push the lever down to **AUTO**, the windshield wipers sweep once, and go into the automatic mode.

The wipers operate intermittently, at low speed, or at high speed and stops in accordance with the amount of rainfall the rainfall sensor detects.

■ AUTO sensitivity adjustment

When in **AUTO**, you can also adjust the rainfall sensor sensitivity using the adjustment ring.

Sensor sensitivity



Low Sensitivity:

Wipers will operate when more rainfall is detected.

High Sensitivity:


Wipers will operate when less rainfall is detected.

Wipers and Washers If the wipers step.

If the wipers stop operating due to any obstacle such as the build-up of snow, park the vehicle in a safe place.

Rotate the wiper switch to **OFF**, and turn the ignition switch to ACCESSORY I or LOCK 0*1, then remove the obstacle.

The rainfall sensor is in the location shown below.



Do not put the wiper lever in **AUTO** when cleaning the windshield or driving through a car wash. If the wiper lever is in **AUTO**, and the power mode is in ON, the rainfall sensor may respond to your hand or car wash liquids, and the wipers may operate automatically.

* Not available on all models

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Brightness Control



When the parking lights are turned on and the ignition switch is in ON [II]*1, you can use the brightness control knob to adjust instrument panel brightness.

Brighten: Turn the knob to the right. **Dim:** Turn the knob to the left.

You will hear a beep when the brightness reaches minimum or maximum. The information display*/multi-information display* will return to its original state several seconds after you adjust the brightness.

■ Brightness level indicator


The brightness level is shown on the information display*/multi-information display* while you are adjusting it.

Instrument panel brightness varies, depending on whether the exterior lights are on or off. The instrument panel dims to reduce glare when they are on.

Pressing the (Select/Reset) knob switches the display.

If you turn the knob to the right until the brightness display is up to max, the beeper sounds. This cancels the reduced instrument panel brightness when the parking lights are on.

The brightness can be set differently for when the exterior lights are on, and when they are off.



*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Rear Defogger/Heated Door Mirror* Button

Press the rear defogger and heated door mirror button to defog the rear window and mirrors when the ignition switch is in ON $|\overline{II}|^{*1}$.



The rear defogger and heated door mirrors automatically switch off after 10-30 minutes depending on the outside temperature. However, if the outside temperature is 32°F (0°C) or below, they do not automatically switch off.

■ Rear Defogger/Heated Door Mirror * Button

NOTICE

When cleaning the inside of the rear window, be careful not to damage the heating wires. It is critical to wipe the window from side to side along the defogger heating wires.

This system consumes a lot of power, so turn it off when the window has been defogged.

Also, do not use the system for a long period when the engine is idling. This may weaken the battery, making it difficult to start the engine.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Driving Position Memory System*

You can store two driver's seat positions with the driving position memory system. When you unlock and open the driver's door with a remote, the seat adjusts automatically to one of the two preset positions.

The multi-information display* shows you which remote you used to unlock the vehicle when you enter.

- **DRIVER 1** transmitter is linked to memory button 1.
- **DRIVER 2** transmitter is linked to memory button 2.



Driving Position Memory System *

Using the multi-information display*, audio/ information screen* or audio/information touch screen*, you can disable the automatic seat adjustment function.


Customized Features P. 106, 298, 316

System Operation

The system will not operate if:

- The vehicle speed is above 2 mph (3 km/h).
- Either memory position button is pressed while the seat is in motion.
- The seat position is adjusted while in operation.
- The memory 1 or 2 position is set fully to the rear.

Storing a Position in Memory




- **1.** Set the power mode to ON. Adjust the driver's seat to the desired position.
- 2. Press the SET button.
 - ➤ You will hear a beep, and the memory button indicator light will blink.
- **3.** Press and hold memory button 1 or 2 within five seconds of pressing the **SET** button.
 - ➤ Once the seat position has been memorized, the indicator light on the button you pressed stays on.

Storing a Position in Memory

After you press the **SET** button, the storing operation will be canceled when:

- You do not press the memory button within five seconds.
- You readjust the seat position before the doublebeep.
- You set the power mode to any position except ON.

Recalling the Stored Position



Automatic transmission/CVT models

1. Move the shift lever to **P**.

All models

- 2. Apply the parking brake.
- **3.** Press a memory button (1 or 2).
 - ➤ You will hear a beep, and the indicator light will blink.

The seat will automatically move to the memorized position. When it has finished moving, you will hear a beep, and the indicator light stays on.


■ Recalling the Stored Position

The seat will stop moving if you:

- Press the **SET** button, or a memory button (1 or 2).
- Adjust the seat position.
- Automatic transmission/CVT models Shift into any position except P.
- Manual transmission models
 Release the parking brake.

Adjusting the Steering Wheel

The steering wheel height and distance from your body can be adjusted so that you can comfortably grip the steering wheel in an appropriate driving posture.



- **1.** Pull the steering wheel adjustment lever up.
 - ► The steering wheel adjustment lever is under the steering column.
- **2.** Move the steering wheel up or down, and in or out.
 - ► Make sure you can see the instrument panel gauges and indicators.
- **3.** Push the steering wheel adjustment lever down to lock the steering wheel in position.
 - ➤ After adjusting the position, make sure you have securely locked the steering wheel in place by trying to move it up, down, in, and out.

∑Adjusting the Steering Wheel

AWARNING

Adjusting the steering wheel position while driving may cause you to lose control of the vehicle and be seriously injured in a crash.

Adjust the steering wheel only when the vehicle is stopped.


Make any steering wheel adjustments before you start driving.

Adjusting the Mirrors

Interior Rearview Mirror

Adjust the angle of the rearview mirror when you are sitting in the correct driving position.

■ Rearview Mirror with Day and Night Positions*



Flip the tab to switch the position.

The night position will help to reduce the glare from headlights behind you when driving after dark.


■ Adjusting the Mirrors

Keep the inside and outside mirrors clean and adjusted for best visibility.

Adjust the mirrors before you start driving.

Adjusting the Seat Positions P. 161

Automatic Dimming Rearview Mirror*




When driving after dark, the automatic dimming rearview mirror reduces the glare from headlights behind you, based in inputs from the mirror sensor. This feature is always active.

■ Automatic Dimming Rearview Mirror*

The auto dimming function cancels when the shift position is in $\boxed{\textbf{R}}$.

* Not available on all models

Power Door Mirrors




You can adjust the door mirrors when the ignition switch is in ON \boxed{II}^{*1} .

■ Mirror position adjustment

L/R selector switch: Select the left or right mirror. After adjusting the mirror, return the switch to the center position.

Mirror position adjustment switch: Press the switch left, right, up, or down to move the mirror.

■ Expanded View Driver's Mirror



The driver side door mirror has outer and inner segments.


The outer segment is slightly curved to provide a wider angle view than a standard flat mirror. This wider view may help you check areas that are not visible using a standard door mirror.

Objects visible in the outer segment of the driver side door mirror appear smaller than objects in the rest of the mirror. But in fact, they are closer than they appear.

Do not rely on your mirrors. Always look to the side and behind your vehicle before changing lanes.


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Adjusting the Seat Positions



Adjust the driver's seat as far back as possible while allowing you to maintain full control of the vehicle. You should be able to sit upright, well back in the seat and be able to adequately press the pedals without leaning forward, and grip the steering wheel comfortably. The passenger's seat should be adjusted in a similar manner, so that it is as far back from the front airbag in the dashboard as possible.

■ Adjusting the driver's power seat*



■ Adjusting the Seats

AWARNING


Sitting too close to a front airbag can result in serious injury or death if the front airbags inflate.

Always sit as far back from the front airbags as possible while maintaining control of the vehicle.

The National Highway Traffic Safety Administration and Transport Canada recommend that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and the chest.

Always make seat adjustments before driving.


■ Adjusting the front manual seat(s)



∑Adjusting the front manual seat(s)

Once a seat is adjusted correctly, rock it back and forth to make sure it is locked in position.

Adjusting the Seat-Backs



Adjust the driver's seat-back to a comfortable, upright position, leaving ample space between your chest and the airbag cover in the center of the steering wheel.

The front seat passenger should also adjust their seat-back to a comfortable, upright position.

Reclining a seat-back so that the shoulder part of the belt no longer rests against the occupant's chest reduces the protective capability of the belt. It also increases the chance of sliding under the belt in a crash and being seriously injured. The farther a seat-back is reclined, the greater the risk of injury.

∑Adjusting the Seat-Backs

AWARNING

Reclining the seat-back too far can result in serious injury or death in a crash.

Adjust the seat-back to an upright position, and sit well back in the seat.


Do not put a cushion, or other object, between the seat-back and your back.


Doing so may interfere with proper seat belt or airbag operation.

If you cannot get far enough away from the steering wheel and still reach the controls, we recommend that you investigate whether some type of adaptive equipment may help.

Head Restraints

Adjusting the Front and Rear Outer Head Restraint Positions





Your vehicle is equipped with head restraints in all seating positions.

Head restraints are most effective for protection against whiplash and other rearimpact crash injuries when the center of the back of the occupant's head rests against the center of the restraint. The tops of the occupant's ears should be level with the center height of the restraint.

To raise the head restraint: Pull it upward. **To lower the head restraint:** Push it down while pressing the release button.

➤ Head Restraints

AWARNING

Improperly positioning head restraints reduces their effectiveness and increases the likelihood of serious injury in a crash.

Make sure head restraints are in place and positioned properly before driving.

In order for the head restraint system to work properly:

- Do not hang any items on the head restraints, or from the restraint legs.
- Do not place any object between an occupant and the seat-back.
- Install each restraint in its proper location.

Changing the Rear Center Seat Head Restraint Positions



A passenger sitting in the center back seating position should adjust the height of their head restraint to an appropriate position before the vehicle begins moving.

To raise the head restraint:

Pull it upward.

To lower the head restraint:

Push it down while pressing the release button.

Removing and Reinstalling the Head Restraints

Head restraints can be removed for cleaning or repair.

To remove a head restraint:

Pull the restraint up as far as it will go. Then push the release button, and pull the restraint up and out.

To reinstall a head restraint:

Insert the legs back in place, then adjust the head restraint to an appropriate height while pressing the release button. Pull up on the restraint to make sure it is locked in position.

■ Removing and Reinstalling the Head Restraints

AWARNING

Failure to reinstall, or correctly reinstall, the head restraints can result in severe injury during a crash.

Always replace the head restraints before driving.

To remove the rear outer head restraints, fold down the seat-back first.

Folding Down the Rear Seat P. 168

Maintain a Proper Sitting Position

After all occupants have adjusted their seats and head restraints, and put on their seat belts, it is very important that they continue to sit upright, well back in their seats, with their feet on the floor, until the vehicle is safely parked and the engine is off.

Sitting improperly can increase the chance of injury during a crash. For example, if an occupant slouches, lies down, turns sideways, sits forward, leans forward or sideways, or puts one or both feet up, the chance of injury during a crash is greatly increased.

In addition, an occupant who is out of position in the front seat can be seriously or fatally injured in a crash by striking interior parts of the vehicle or being struck by an inflating front airbag.

Maintain a Proper Sitting Position

AWARNING

Sitting improperly or out of position can result in serious injury or death in a crash.

Always sit upright, well back in the seat, with your feet on the floor.

Rear Seat Access



Driver side


Models with driver's power seat

Pulling up the fold-down lever tilts the seat-back forward.



Models with driver's manual seat

Pulling up on the seat-back angle adjustment lever tilts the seat-back forward.



Passenger side

Pulling up on the seat-back angle adjustment lever, or pushing down the front passenger seat-back release lever tilts the seat-back forward.

You can also use these levers to move the seat forward.


Maintain a Proper Sitting Position

When you enter the rear seat, be careful not to trip over the front seat belt.

If necessary, move the seat forward after tilting the seat-back forward.

Rear Seats

■ Folding Down the Rear Seat



1. Remove the center shoulder belt from the quide.



2. Pull the release lever in the trunk to release the lock



3. Fold the seat-back down

If the rear head restraints get caught on the front seat-backs, remove the head restraints.

Removing and Reinstalling the Head Restraints P. 165

∑Folding Down the Rear Seat

The rear seat-back can be folded down to accommodate bulkier items in the trunk.

Never drive with the seat-back folded down and the trunk lid open.

Exhaust Gas Hazard P. 66

To lock a seat-back upright, push it backwards until it locks.

When returning the seat-back to its original position, push it firmly back. Also, make sure all rear shoulder belts are positioned in front of the seat-back, and the center shoulder belt is re-positioned in the quide.

Make sure that the folded seat-back does not press against the front passenger seat, as this can cause the weight sensors in the front passenger seat to work improperly.

Passenger Airbag Off Indicator P. 52


Make sure all items in the trunk or items extending through the opening into the rear seat is properly secured. Loose items can fly forward if you have to brake hard.

The front seat(s) must be far enough forward so they do not interfere with the rear seats as they fold down.

Interior Lights/Interior Convenience Items

Interior Lights

Interior Light Switches



ON

The interior lights come on regardless of whether the doors are open or closed.

■ Door activated

The interior lights come on in the following situations:

- When either of the doors are opened.
- You unlock the driver's door.

Models without smart entry system

• You remove the key from the ignition switch.

Models with smart entry system

 When the power mode is set to VEHICLE OFF (LOCK).

■ OFF

The interior lights remain off regardless of whether the doors are open or closed.

In the door activated position, the interior lights fade out and go off about 30 seconds after the doors are closed. The lights go off after 30 seconds in the following situations:

• When you unlock the driver's door but do not open it.

Models without smart entry system

• When you remove the key from the ignition switch but do not open a door.

Models with smart entry system

 When you set the power mode to VEHICLE OFF (LOCK) but do not open a door.

You can change the interior lights dimming time.

Customized Features P. 106, 298, 316

The interior lights go off immediately in the following situations:

- When you lock the driver's door.
- When you turn the ignition switch to ON III*1.

Models without smart entry system

• When you close the driver's door with the key in the ignition switch.

Models with smart entry system

 When you close the driver's door in ACCESSORY mode.

If you leave either door open without the key in the ignition switch*1, the interior lights go off after about 15 minutes.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Continued 169

■ Map Lights




The map lights can be turned on and off by pressing the lenses.

Map Lights

When the ceiling light switch is in the door activated position and either door is open, the map light will not go off when you press the lens.

Interior Convenience Items

■ Glove Box



Pull the handle to open the glove box.

You can lock the glove box with the master key or the built-in key.

■ Console Compartment



Pull the handle to open the console compartment.

Solove Box


AWARNING

An open glove box can cause serious injury to your passenger in a crash, even if the passenger is wearing the seat belt.

Always keep the glove box closed while driving.

Continued 171

■ Center Pocket



Pull the handle to open the pocket.

■ Beverage Holders



■ Front seat beverage holders



■ Door beverage holders



■ Rear seat beverage holders

■ Beverage Holders

NOTICE

Spilled liquids damage the upholstery, carpeting, and electrical components in the interior.

Be careful when you are using the beverage holders. Hot liquid can scald you.

Continued 173

Accessory Power Sockets

The accessory power sockets can be used when the ignition switch is in ACCESSORY \blacksquare or ON \blacksquare \blacksquare *1 .



■ Accessory power socket (console panel)
Open the cover to use it.



Accessory power socket (console compartment)

Open the console lid and the cover to use it.

NOTICE

Do not insert an automotive type cigarette lighter element.

This can overheat the power socket.

The accessory power socket is designed to supply power for 12-volt DC accessories that are rated 180 watts (15 amps) or less.

To prevent battery drain, only use the power socket with the engine running.


When both sockets are being used, the combined power rating of the accessories should not exceed 180 watts (15 amps).

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Wireless Charger*

To use the wireless charger, the ignition switch must be in ACCESSORY \boxed{I} or ON \boxed{II}^{*_1} .

Charge a compatible device on the area indicated by the \P mark as follows:



- **1.** To turn the system on and off, press and hold the (b) (power) button.
 - ► When the system is activated, the green indicator light comes on.
- **2.** Place the device you want to charge on the charging area.
 - ➤ The system will automatically start charging the device, and the amber indicator light will come on.
 - ► Make sure that the device is compatible with the system, and placed with the chargeable side in the center of the charging area.
- **3.** When charging is completed, the green indicator light will come on.
 - ➤ Depending on the device, the amber indicator light will stay on.

Wireless Charger[∗]

ACAUTION

Metal objects between the charge pad and the device to be charged will get hot and can burn you.

- Always remove foreign objects from the charge pad before charging the device.
- Be sure the surface is clear of dust and other debris before charging.
- Do not spill liquids (i. e. water, drinks, etc.) on the charger and the device.
- Do not use oil, grease, alcohol, benzine or thinner for cleaning the charge pad.
- Do not cover the system with towels, clothing, or other objects while charging etc.
- Avoid using spraying hair spray, insecticides, etc, that may contact the charge pad surface.

This system consumes a lot of power, so do not use the system for a long time when the engine is not running. This may weaken the battery, making it difficult to start the engine.

When using the wireless charger, check the user's manual that came with to the compatible device you want to charge.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ When charging does not start

Perform one of the solutions in the following table.

Indicator		Cause	Solution
Green & Amber	Blinking simulta- neously	There is an obstacle(s) between the charging area and the device.	Remove the obstacle(s).
		The device is not within the charging area.	Move the device to the center of the charging area where (f) is located.
Amber	Blinking	The wireless charger is faulty.	Contact a dealer for repairs.

Wireless Charger[∗]

NOTICE

Do not place any magnetic recording media or precision machines within the charging area while charging.

The data on your cards such as credit cards can be lost because of the magnetic effect. Also precision machines such as watches can go wrong.

"Qi" and @ marks are the registered trademarks owned by Wireless Power Consortium (WPC).

In the following cases, charging may stop or not start:

- The device is already fully charged.
- The temperature of the device is extremely high while charging.
- You are at a place that emits strong electromagnetic wave or noises such as TV station, electric power plant, or gas station.

A device may not charge if the size or shape of its chargeable side is not appropriate for use with the charging area.

Not all devices are compatible with the system.

During the charging phase, it is normal for the charging area and device to heat up.

Charging may be briefly interrupted when:

- Both doors or the trunk are closed
 - to avoid interference with the proper functioning of the smart entry system.
- The position of the device is altered.

Do not charge more than one device at a time on a charging area.

Coat Hooks



There are coat hooks behind the center pillar on both sides. Pull them down to use them.

○ Coat Hooks

The coat hooks are not designed for large or heavy

■ Cargo Hooks




The cargo hooks in the trunk can be used to install a net for securing items.

Heavy objects may damage the hook. Make sure any items put on this hook weigh less than 6.6 lbs (3 kg).

Distribute cargo evenly on the floor of the trunk, placing the heaviest items on the bottom and as far forward as possible.

Maximum Load Limit P 415

Sunglasses Holder



To open the sunglasses holder, push and release the indent. To close, push it again until it latches.

You can store eyeglasses and other small items in this holder.


∑Sunglasses Holder

Keep the holder closed while driving except when accessing stored items.

Seat Heaters*



The ignition switch must be in ON [II]*1 to use the seat heaters. The **HI** setting heats the seats faster than the **LO** setting.



While in **HI**, the heater cycles on and off.

▶ The appropriate indicator will be on while the seat heater is on. Briefly press the switch on the opposite side to turn the heater off. The indicator will be off. When a comfortable temperature is reached, select LO to keep the seat warm. Seat Heaters *

AWARNING

Heat induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lower-limb nerve damage, or paralysis) or with sensitive skin should not use seat heaters.

Do not use the seat heaters even in **LO** when the engine is off. Under such conditions, the battery may be weakened, making the engine difficult to start.


In the **LO** setting, the heater runs continuously and does not automatically turn off.

- *1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.
- * Not available on all models

Climate Control System

Using Automatic Climate Control

The automatic climate control system maintains the interior temperature you select. The system also selects the proper mix of heated or cooled air that raises or lowers the interior temperature to your preference as quickly as possible.



Use the system when the engine is running.

- **1.** Press the **AUTO** button.
- 2. Adjust the interior temperature using the driver's side or passenger's side control buttons.
- **3.** Press the SON/OFF (on/off) button to cancel.

■ Switching between the recirculation and fresh air modes

Press the (recirculation) button and switch the mode depending on environmental conditions.

Recirculation mode (indicator on): Recirculates air from the vehicle's interior through the system.

Fresh air mode (indicator off): Maintains outside ventilation. Keep the system in fresh air mode in normal situations.

If any buttons are pressed while using the climate control system in auto, the function of the button that was pressed will take priority.

The **AUTO** indicator will go off, but functions unrelated to the button that was pressed will be controlled automatically.


To prevent cold air from blowing in from outside, the fan may not start immediately when the **AUTO** button is pressed.

If the interior is very warm, you can cool it down more rapidly by partially opening the windows, turning the system on auto, and setting the temperature to low. Change the fresh mode to recirculation mode until the temperature cools down.

When you set the temperature to the lower or upper limit, ${\bf Lo}$ or ${\bf Hi}$ is displayed.

Pressing the SON button switches the climate control system between on and off. When turned on, the system returns to your last selection.


Defrosting the Windshield and Windows



Pressing the button turns the air conditioning system on and automatically switches the system to fresh air mode.

Press the button again to turn off, the system returns to the previous settings.

■ To rapidly defrost the windows



- 1. Press the button.
- 2. Press the button.

Defrosting the Windshield and Windows

For your safety, make sure you have a clear view through all the windows before driving.

Do not set the temperature near the upper or lower limit.


When cold air hits the windshield, the outside of the windshield may fog up.

If the side windows fog up, adjust the vents so that the air hits the side windows.

∑To rapidly defrost the windows

After defrosting the windows, switch over to fresh air mode. If you keep the system in recirculation mode, the windows may fog up from humidity. This impedes visibility.

Synchronized Mode



You can set the temperature synchronously for the driver side and the passenger side in synchronized mode.

- 1. Press the SYNC button.
 - ▶ The system will switch to the synchronized mode.
- **2.** Adjust the temperature using driver's side temperature control buttons.

Press the **SYNC** button to return to dual mode.

Synchronized Mode


When you press the button, the system changes to synchronized mode.

When the system is in dual mode, the driver side temperature and the passenger side temperature can be set separately.


Models with navigation system

The system adjusts each temperature based on the information of the sunlight sensor and the sun position updated by the navigation system.

Automatic Climate Control Sensors



The automatic climate control system is equipped with sensors. Do not cover or spill any liquid on them.





Audio System	
About Your Audio System	. 186
LISB Port(s*)	187
Auxiliary Input Jack *	. 188
Auxiliary Input Jack* Audio System Theft Protection*	. 189
Audio Remote Controls	. 190
Models with one display	
Audio System Basic Operation	. 192
Audio/Information Screen	. 193
Display Setup	
Playing AM/FM Radio	
Playing a CD	
Playing an iPod	
Playing Internet Radio	
Playing a USB Flash Drive	210
Playing Bluetooth® Audio	213
ajg D.actootii / taalo	

Models with two displays	
Audio System Basic Operation	215
Audio/Information Screen	
Audio/Information Touch Screen	218
Adjusting the Sound	232
Display Setup	233
Voice Control Operation	235
Playing AM/FM Radio Playing SiriusXM® Radio*	239
Playing SiriusXM® Radio *	244
Playing a CD	252
Plaving an iPod	255
Song By Voice™ (SBV) Playing Pandora®*	258
Playing Pandora® *	262
Playing Aha™	264
Playing a USB Flash Drive	265
Playing Bluetooth® Audio	268

HondaLink®	2/0
Wi-Fi Connection	275
Apple CarPlay	
Android Autó	
Siri Eyes Free	
Ludio Error Mossagos	206
Audio Error Messages	200
General Information on the A	Audio
General Information on the A	Audio
General Information on the A System Customized Features	Audio 291 298 , 316
General Information on the A System Customized Features HomeLink® Universal Transce	Audio 291 298 , 316 i iver* 340
ieneral Information on the A System Lustomized Features HomeLink® Universal Transce Bluetooth® HandsFreeLink®	Audio 291 298, 316 iver* 340 343, 374
General Information on the A System Customized Features HomeLink® Universal Transce	Audio 291 298, 316 iver* 340 343, 374


* Not available on all models

Audio System

About Your Audio System

The audio system features AM/FM radio and SiriusXM® Radio service*. It can also play audio CDs, WMA/MP3/AAC files, USB flash drives, and iPod, iPhone and *Bluetooth*® devices.

You can operate the audio system from the buttons and switches on the panel or the icons on the touchscreen interface*.



■ About Your Audio System

SiriusXM® Radio is available on a subscription basis only. For more information on SiriusXM® Radio, contact a dealer.

■ General Information on the Audio SystemP. 291

SiriusXM® Radio is available in the United States and Canada, except Hawaii, Alaska, and Puerto Rico.


SiriusXM® is a trademark of Sirius XM Radio, Inc.


Video CDs, DVDs, and 3-inch (8-cm) mini CDs are not supported.

iPod, iPhone and iTunes are trademarks of Apple Inc.

State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle.

USB Port(s*)





- **1.** Open the cover.
- **2.** Install the iPod dock connector or the USB flash drive to the USB port.

■USB Port(s*)

- Do not leave the iPod or USB flash drive in the vehicle. Direct sunlight and high temperatures may damage it.
- We recommend using an extension cable with the USB port.
- Do not connect the iPod or USB flash drive using a hub.
- Do not use a device such as a card reader or hard disk drive, as the device or your files may be damaged.
- We recommend backing up your data before using the device in your vehicle.
- Displayed messages may vary depending on the device model and software version.

If the audio system does not recognize the iPod, try reconnecting it a few times or reboot the device. To reboot, follow the manufacturer's instructions provided with the iPod or visit www.apple.com/ipod.

Auxiliary Input Jack*

Use the jack to connect standard audio devices.



- 1. Open the AUX cover.
- **2.** Connect a standard audio device to the input jack using a 1/8 inch (3.5 mm) stereo miniplug.
 - ► The audio system automatically switches to the AUX mode.

■Auxiliary Input Jack*

You can return to AUX mode by pressing the ${\bf AUX}$ button.

Replacement of the audio system with other than a genuine Honda system may make the auxiliary jack inoperable.

Audio System Theft Protection*

The audio system is disabled when it is disconnected from the power source, such as when the battery is disconnected or goes dead. In certain conditions, the system may display **Enter code**. If this occurs, reactivate the audio system.

■ Reactivating the audio system


- **1.** Turn the ignition switch to ON II^{*1}.
- 2. Turn on the audio system.
- **3.** Press and hold the audio system power button for more than two seconds.
 - ► The audio system is reactivated when the audio control unit establishes a connection with the vehicle control unit. If the control unit fails to recognize the audio unit, you must go to a dealer and have the audio unit checked.

* Not available on all models

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Audio Remote Controls

Allow you to operate the audio system while driving.



SOURCE Button

Cycles through the audio modes as follows:

Models with one display

FM→AM→CD→USB→iPod→ Bluetooth® Audio→Pandora®*→AUX

Models with two displays

FM→AM→SiriusXM®*→CD→USB→iPod→ Pandora®*→Bluetooth® Audio→Audio Apps

🛨 一 (Volume) Buttons

Press +: To increase the volume.

Press —: To decrease the volume.

■ Buttons

• When listening to the radio

Press To select the next preset radio station.

Press To select the previous preset radio station.

Press and hold To select the next strong station.

Press and hold To select the previous strong station.

When listening to a CD, iPod, USB flash drive, or Bluetooth® Audio
 Press : To skip to the next song.

Press To go back to the beginning of the current or previous song.

When listening to a CD (MP3/WMA/AAC), USB flash drive, or Bluetooth® Audio
 Press and hold : To skip to the next folder.

Press and hold To go back to the previous folder.

Some modes appear only when an appropriate device or medium is used.

Depending on the *Bluetooth*® device you connect, some functions may not be operated.

Models with two displays

Steering Wheel MENU Button

To choose options for the current audio device, press **MENU**, **Audio Menu**, and then **SOURCE**.

Options available to you for each audio device:

- Radio: You can select Scan, Auto Select, Save Preset, Seek Up, or Seek
 Down
- HD Radio™*: You can select Scan, Auto Select, Tag Song, Save Preset, Seek Up, or Seek Down.
- SiriusXM®*: You can select Scan, Tag Song, Save Preset, Channel Up, Channel Down, Category Up, or Category Down.
- CD or USB flash drive: You can select **Scan Folders**, **Scan Tracks**, **Repeat Folder**, **Repeat Track**, **Random in Folder**, or **Random All Tracks**.
- iPod: You can select **Play/Pause**, **Repeat Song**, **Shuffle Albums**, or **Shuffle All Songs**.
- Bluetooth® Audio: You can select Pause or Play.
- Pandora®*: You can select **Like**, **Dislike**, **Bookmark**, or **Play/Pause**.

To choose options for the navigation system while it is in operation, press **MENU**, select **Navi Menu**, and then **SOURCE**.

Refer to the Navigation System Manual

To choose options for HFL, press **MENU**, select **Phone Menu**, and then **SOURCE**. You can select **Speed Dial**, **Call History**, or **Redial**.

To choose options for the display setting, press **MENU**, select **Display Setting**, and then **SOURCE**.

You can select **Brightness**, **Contrast**, or **Black Level**.


■ Audio Remote Controls

The **MENU** button is available only when the audio mode is FM, AM, SiriusXM®*, CD, USB, iPod, Pandora®*, or *Bluetooth*® Audio.

Audio System Basic Operation

Models with one display

To use the audio system function, the ignition switch must be in ACCESSORY \boxed{I} or ON \boxed{II}^{*1} .



Station List Scan
Save Preset Radio Text
Change Source Tune

Use the selector knob or **MENU** button to access some audio functions.

Press 🖔 to switch between the normal and extended display for some functions.

Selector knob: Rotate left or right to scroll through the available choices. Press to set your selection.

MENU button: Press to select any mode. The available mode includes Change Source, Station List, Save Preset, Radio Text, Music Search, and play modes. Play modes can be also selected from Scan, Random/Repeat, and so on.

BACK button: Press to go back to the previous display.

button: Press to change the audio/information screen brightness.

Press *) once and make an adjustment.

► Each time you press (*), the mode switches between the daytime mode, nighttime mode and **OFF** mode.

These indications are used to show how to operate the selector knob.

Rotate To select.

Press 🛎 to enter.

Audio Menu Items

Station List P. 200

Radio text P. 200

Music Search P. 202, 205, 211

Scan P. 200, 203, 212

₹ Random/Repeat P. 203, 206, 212

This product includes software codes licensed under the conditions stated by the copyright holder. For license conditions and the copy of the corresponding source code, visit: http:// www.hondaopensource1.com/002


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Audio/Information Screen

Displays the audio status and wallpaper. From this screen, you can go to various setup options.

■ Switching the Display

Press the (display) button to change the display.



■ Audio

Shows the current audio information.

■ Trip computer (Current Drive)

Shows the range, and instant and average fuel economy of the current trip, as well as the average fuel economy from your last trip.

■ Trip computer (History of Trip A)

Shows the range, average fuel economy and distance traveled for the current trip, as well as the average fuel economy and distances traveled during the last three driving cycles.

Each time you reset the trip meter A, the information on the display updates. The history of the previous three driving cycles is kept.

■ Clock/Wallpaper

Shows a clock screen or an image you import.

Wallpaper Setup

You can change, store, and delete the wallpaper on the audio/information screen.

■ Import wallpaper

You can import up to three images, one at a time, for wallpaper from a USB flash drive.



1. Connect the USB flash drive to the USB port.

■ USB Port(s*) P. 187

- 2. Press the **SETTINGS** button.
- **3.** Rotate ⊘ to select **System Settings**, then press ⊗.
 - Repeat the procedure to select Clock, Clock/Wallpaper Type, then Wallpaper.
- **4.** Rotate '♥ to select **Add New Wallpaper**, then press ♥.
 - ► The preview of the imported data is displayed.
- **5.** Rotate 🕆 to select a desired picture.
 - ➤ The preview is displayed on the left side on the screen.
- **6.** Press 💍 to save the data.
 - ► The confirmation message will appear. Then the display will return to the wallpaper list.

Wallpaper Setup

- When importing wallpaper files, the image must be in the USB flash drive's root directory.
 Images in a folder cannot be imported.
- The file name must be fewer than 64 characters.
- The file format of the image that can be imported is BMP (bmp) or JPEG (jpg).
- The individual file size limit is 2 MB.
- The maximum image size is 1,680 x 936 pixels. If the image size is less than 420 x 234 pixels, the image is displayed in the middle of the screen with the extra area appearing in black.
- Up to 255 files can be selected.
- If the USB flash drive does not have any pictures, the **No files detected** message appears.



■ Select wallpaper

- 1. Press the **SETTINGS** button.
- **2.** Rotate ♥ to select **System Settings**, then press ८.
 - ► Repeat the procedure to select **Clock**, **Clock/Wallpaper Type**, then **Wallpaper**.
 - ► The screen changes to the wallpaper list.
- **3.** Rotate ♥ to select a desired wallpaper, then press ८.
 - ► The pop-up menu appears on the screen.
- **4.** Rotate ♥ to select **Set**, then press ८.

■ Delete wallpaper

- 1. Press the **SETTINGS** button.
- **2.** Rotate ♥ to select **System Settings**, then press ८.
 - ▶ Repeat the procedure to select Clock, Clock/Wallpaper Type, then Wallpaper.
 - ► The screen changes to the wallpaper list.
- **3.** Rotate ♥ to select a wallpaper that you want to delete, then press ८.
 - ► The pop-up menu appears on the screen.
- **4.** Rotate ♥ to select **Delete**, then press ८.
 - ► The confirmation message will appear.
- **5.** Rotate ♥ to select **OK**, then press ८ to delete completely.

Wallpaper Setup ■ Management Setup ■ M

From the pop-up menu, rotate to select **Preview** and press to see a preview at full-size screen.



To go back to the previous screen, press ĕ to select **OK**, or press the **BACK** button.

When the file size is large, it takes a while to be previewed.


Adjusting the Sound





- **1.** Press the **SETTINGS** button.
- **2.** Rotate ♂ to select **Audio Settings**, then press ఆ.
- **3.** Rotate ♂ to select **Sound**, then press ⊘.

Rotate 🔞 to scroll through the following choices:



Speed-sensitive Volume Compensation

■ Adjusting the Sound

The SVC has four modes: **Off, Low, Mid,** and **High**. SVC adjusts the volume level based on the vehicle speed. As you go faster, audio volume increases. As you slow down, audio volume decreases.

Display Setup

You can change the brightness or color theme of the audio/information screen.

■ Changing the Screen Brightness



- 1. Press the **SETTINGS** button.
- **2.** Rotate ⊘ to select **System Settings**, then press ⊘.
 - ► Repeat the procedure to select **Display**.
- 3. Rotate 😙 to select **Brightness**, then press 💍.
- **4.** Rotate ♥ to adjust the setting, then press ♥.

■ Changing the Screen's Color Theme




- 1. Press the **SETTINGS** button.
- **2.** Rotate ♂ to select **System Settings**, then press ♂.
 - ▶ Repeat the procedure to select **Other**.
- **3.** Rotate ♥ to select **Background Color**, then press ♥.
- **4.** Rotate to select the setting you want, then press

∑Changing the Screen Brightness

You can change the **Contrast** and **Black Level** settings in the same manner.

Playing AM/FM Radio



Radio Data System (RDS)

Provides text data information related to your selected RDS-capable FM station.

■ To find an RDS station from Station List

- **1.** Press 🗟 while listening to an FM station.
- **2.** Rotate to select the station, then press .

■ Manual update

Updates your available station list at any time.

- **1.** Press 🕹 while listening to an FM station.
- **2.** Rotate ♥ to select **Refresh**, then press ८.

■ Radio text

Displays the radio text information of the selected RDS station.

- 1. Press the **MENU** button.
- **2.** Rotate ♥ to select **Radio Text**, then press ८.

■ Scan

Samples each of the strongest stations on the selected band for 10 seconds.

- 1. Press the **MENU** button.
- **2.** Rotate '♥ to select **Scan**, then press ८.

To turn off scan, press 🕹 to select **Stop**, or press the **BACK** button.

▶ Playing AM/FM Radio

The **ST** indicator appears on the display indicating stereo FM broadcasts.

Stereo reproduction in AM is not available.

Switching the Audio Mode

Press the **SOURCE** button on the steering wheel.

Audio Remote Controls P. 190


You can also switch the mode by pressing the **MENU** button and selecting **Change Source** on the MENU screen.

You can store 6 AM stations and 12 FM stations into the preset memory.

When you select an RDS-capable FM station, the RDS automatically turns on, and the frequency display changes to the station name. However, when the signals of that station become weak, the display changes from the station name to the frequency.

Playing a CD


Your audio system supports audio CDs, CD-Rs and CD-RWs in either MP3, WMA, or AAC*1 format. With the CD loaded, press the **CD** button.



^{*1:}Only AAC format files recorded with iTunes are playable on this unit.

201

■ How to Select a File from the Music Search List (MP3/WMA/AAC)



- 1. Press the **MENU** button.
- **2.** Rotate 'ô' to select **Music Search**, then press ⊗.
- **3.** Rotate 😙 to select a folder.
- **4.** Press 🛎 to change the display to a list of files in that folder.
- **5.** Rotate ♥ to select a file, then press ८.

▶ Playing a CD

NOTICE

Do not use CDs with adhesive labels. The label can cause the CD to jam in the unit.

WMA files protected by digital rights management (DRM) cannot be played.

The audio system displays **Unplayable File**, then skips to the next file.

Text data appears on the display under the following circumstances:

- When you select a new folder, file, or track.
- When you change the audio mode to CD.
- When you insert a CD.

If you eject the CD but do not remove it from the slot, the system reloads the CD automatically after several seconds.

■ How to Select a Play Mode

You can select scan, repeat, and random modes when playing a track or file.



- 1. Press the **MENU** button.
- 2. Rotate 🗇 to select Scan or Random/ Repeat, then press 🕹.
- **3.** Rotate to select a mode, then press .

Play Mode Menu Items

Scan

Scan Folders (MP3/WMA/AAC): Provides 10-second sampling of the first file in each of the main folders. **Scan Tracks**: Provides 10-second sampling of all tracks on the CD (all files in the current folder in MP3, WMA, or AAC).

Random/Repeat

Repeat Folder (MP3/WMA/AAC): Repeats all files in the current folder.

Repeat Track: Repeats the current track/file.
Random in Folder (MP3/WMA/AAC): Plavs all files

in the current folder in random order.

Random All Tracks: Plays all tracks/files in random order.


■ To turn off a play mode

- **1.** Press the **MENU** button.
- **2.** Rotate ♥ to select the mode you want to turn off, then press ८.


Playing an iPod

Connect the iPod using your dock connector to the USB Port, then press the **AUX** button.

■ USB Port(s*) P. 187



■ How to Select a Song from the Music Search List



- 1. Press the **MENU** button.
- **2.** Rotate ♥ to select **Music Search**, then press ♥.
- **3.** Rotate 🗇 to select a menu.
- **4.** Press $\ensuremath{\ensuremath{\varnothing}}$ to display the items on that menu.
- **5.** Rotate to select an item, then press .

Available operating functions vary on models or versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information screen.

iPod/USB Flash Drive P. 287

Continued 205

■ How to Select a Play Mode

You can select repeat and shuffle modes when playing a file.

- Music Search
 Change Source Shuffle/Repeat

 ☐ Shuffle/Repeat

 ☐ Shuffle/Repeat

 ☐ Shuffle Albums
 ☐ Shuffle Albums
 ☐ Shuffle Albums
 ☐ Songs
 ☐ Repeat Song
- 1. Press the **MENU** button.
- **2.** Rotate ♂ to select **Shuffle/Repeat**, then press ⊗.
- **3.** Rotate ♥ to select a mode, then press ८.

Play Mode Menu Items

Repeat Song: Repeats the current file.

Shuffle Album: Plays all available albums in a selected list (playlists, artists, albums, songs, genres, or composers) in random order.

Shuffle All Songs: Plays all available files in a selected list (playlists, artists, albums, songs, genres, or composers) in random order.

■ To turn off a play mode

- 1. Press the **MENU** button.
- **2.** Rotate to select the mode you want to turn off, then press .

U.S. models

Compatible phones only

Playing Internet Radio

Connect a compatible phone through Bluetooth®.

iPhone

You can also connect the phone using your dock connector to the USB port. Press the **AUX** button to select Pandora mode.

Pandora®, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc., used with permission. Pandora®, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc. Used with permission. Pandora® is only available in certain countries. Please visit

http://www.pandora.com/legal for more information.

To find out if your phone is compatible with this feature, visit www.handsfreelink.honda.com, or call 1-888-528-7876.

To use this service in your vehicle, the Pandora® app must first be installed on your phone. Visit www.pandora.com. for more information.


Pandora® is free personalized radio that offers effortless and endless music and comedy. Just start with the name of one of your favorite artists, songs, genres, composers, or comedians and it will do the rest.

If you cannot operate Pandora® through the audio system, it may be streaming through *Bluetooth®* Audio. Make sure Pandora® mode on your audio system is selected.

Changing Stations

To change stations, activate the Pandora® menu, select **Station List**, and then select a new station.

Continued 207



Pandora® Menu

You can operate some of the Pandora® menu items from your vehicle's audio system. The available items are:

- Like (Thumbs-up)
- **Dislike** (Thumbs-down)
- Station List
- Change Source
- Bookmark Track
- Bookmark Artist
- Play/Pause

■ Operating a menu item



- 1. Press the **MENU** button.
- **2.** Rotate 😙 to select an item, then press 🕹 .

≫Pandora® Menu

Available operating functions vary on software versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information screen.

Pandora® P. 288


Pandora® may limit the total number of skips allowed on the service. If you dislike a track after the skip limit has been reached, your feedback will be saved but the current track will continue to play.

Playing a USB Flash Drive

Your audio system reads and plays sound files on a USB flash drive in either MP3, WMA or AAC*1 format.


Connect your USB flash drive to the USB port, then press the **AUX** button.

■ USB Port(s*) P. 187



- *1:Only AAC format files recorded with iTunes are playable on this unit.
- * Not available on all models

■ How to Select a File from the Music Search List



- 1. Press the **MENU** button.
- **2.** Rotate ♥ to select **Music Search**, then press ♥.
- **3.** Rotate 😙 to select a folder.
- **4.** Press 🖔 to change the display to a list of files in that folder.
- **5.** Rotate ♥ to select a file, then press ८.

∑Playing a USB Flash Drive

Use the recommended USB flash drives.

☑ General Information on the Audio System P. 291

Files in WMA format protected by digital rights management (DRM) cannot be played.

The audio system displays **Unplayable File**, and then skips to the next file.

If there is a problem, you may see an error message on the audio/information screen.

iPod/USB Flash Drive P. 287

Continued 211

■ How to Select a Play Mode

You can select scan, repeat, and random modes when playing a file.

1. Press the **MENU** button.

2. Rotate 😙 to select Scan or Random/ Repeat, then press 🕹.

3. Rotate ♥ to select a mode, then press ८.



■ To turn off a play mode

- 1. Press the **MENU** button.
- **2.** Rotate $\ \ \,$ to select the mode you want to turn off, then press $\ \ \ \,$

Play Mode Menu Items

Scan

Scan Folders: Provides 10-second sampling of the first file in each of the main folders.

Scan Tracks: Provides 10-second sampling of all files in the current folder.

Random/Repeat

Repeat Folder: Repeats all files in the current folder.

Repeat Track: Repeats the current file.

Random in Folder: Plays all files in the current folder in random order.


Random All Tracks: Plays all files in random order.

Playing Bluetooth® Audio

Your audio system allows you to listen to music from your *Bluetooth*-compatible phone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® (HFL) system.

Phone Setup P. 350



Not all *Bluetooth*-enabled phones with streaming audio capabilities are compatible with the system. For a list of compatible phones:

- U.S.: Visit www.handsfreelink.honda.com, or call 1-888-528-7876.
- Canada: Visit www.handsfreelink.ca, or call 1-888-528-7876.

In some states, it may be illegal to perform some data device functions while driving.

If more than one phone is paired to the HFL system, there will be a delay before the system begins to play.

Continued 213

■ To Play *Bluetooth®* Audio Files



- **1.** Make sure that your phone is paired and connected to HFL.
- 2. Press the AUX button.

If the phone is not recognized, another HFL-compatible phone, which is not compatible for *Bluetooth®* Audio, may already be connected.

■ To pause or resume a file

- 1. Press the **MENU** button.
- **2.** Rotate to select **Play** or **Pause**, then press .

∑To Play Bluetooth® Audio Files

To play the audio files, you may need to operate your phone. If so, follow the phone maker's operating instructions.

The pause function may not be available on some phones.

If any audio device is connected to the auxiliary input jack, you may need to press the **AUX** button repeatedly to select the *Bluetooth*® Audio system.

Switching to another mode pauses the music playing from your phone.

Audio System Basic Operation

Models with two displays

To use the audio system function, the ignition switch must be in ACCESSORY \boxed{I} or ON \boxed{II}^{*1} .



Select to go to the home screen.

Switching the Display P. 218

Select to display any mode.

The available modes include **Sound**, **View Radio Text**, **Music Search**, and play modes.

Select to go back to the previous display when it is displayed.



Button: Press to change the audio/information touch screen brightness.

Press nonce and select or to make an adjustment.

► Each time you press ※), the mode switches among the daytime mode, nighttime mode and off mode.

Audio Menu Items

Station List P. 240, 242

Music Search P. 253, 256, 266, 269

Scan P. 241, 251, 254, 267

▶ Play Mode P. 254, 257, 267


^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Audio/Information Screen

Displays the audio status, trip computer, compass*, Turn by Turn, and clock/wallpaper.

Switching the Display

Press the (display) button to change the display.



■ Turn by Turn

Displays the Turn by Turn screen.

■ Trip computer

Displays the range and average fuel economy of the current trip, as well as the average fuel economy from your last trip.

■ Audio

Displays the current audio information.


■ Clock/Wallpaper

Displays a clock screen.

Audio/Information Touch Screen

Displays the audio status and wallpaper. From this display, you can go to various setup options.

Switching the Display



Select to go to the home screen.
Select Phone, Info, Audio, Settings, Navigation*, HondaLink, Aha,
Smartphone connection, or App List.

■ Phone

Displays the HFL information.

Bluetooth® HandsFreeLink® P. 374

■ Info

Displays **Trip Computer**. To see all available information, **Trip Computer**, **Voice Info**, or **System/Device Information**, select on the **Info Menu** screen.

Trip Computer:

- Current Drive tab: Displays the current trip information.
- **History of Trip A** tab: Displays information for the three previous drives. The information is stored every time you reset Trip A.

To delete the history manually, select **Delete History** on the **History of Trip A** tab. The confirmation message appears on the screen, then select **Yes**.

Voice Info: Displays the all commands list.

System/Device Information:

- **System Info**: Displays the software version of the audio system.
- **USB Info**: Displays the memory usage of the USB device.

■ Audio

Displays the current audio information.

■ Settings

Enters the customizing menu screen.

■ Customized Features P. 316

■ Navigation*

Displays the navigation screen.

Refer to the Navigation System Manual

■ HondaLink

Connects with your smartphone*1 to play personalized music, information, and social media streams.

→ HondaLink® P. 270

■ Aha

Displays the Aha™ screen.

Playing Aha™ P. 264

■ Smartphone connection

Displays the Apple CarPlay or Android Auto.

Apple CarPlay P. 277

Android Auto P. 281

■ App List

Adds or removes App or Widget on the home screen.

Home Screen P. 224

*1: Available on specific phones only. Check *handsfreelink.honda.com* for U.S. and *www.handsfreelink.ca* for Canada for compatible phones and *hondalink.com* for U.S. and *honda.ca/hondalink* for Canada for feature details.

■ Changing the Home Screen Icon Layout



- 1. Select .
- 2. Select and hold an icon.
 - ► The screen switches to the customization screen.
- **3.** Drag and drop the icon to where you want it to be.
- 4. Select OK.
 - ► The screen will return to the home screen.

Continued 221

■ Wallpaper Setup

You can change, store, and delete the wallpaper on the audio/information touch screen.

■ Import wallpaper

Add new wallpaper

You can import up to five images, one at a time, for wallpaper from a USB flash drive.



1. Connect the USB flash drive to the USB port.

■ USB Port(s*) P. 187

- 2. Select Settings.
- 3. Select Clock/Info.
- **4.** Select **Clock/Wallpaper Type**, then open the **Wallpaper** tab.
- 5. Select Add New.
 - ► The picture name is displayed on the list.
- **6.** Select a desired picture.
 - ➤ The preview is displayed on the left side on the screen.
- **7.** Select **Start Import** to save the data.
 - ► The display will return to the wallpaper list.

Wallpaper Setup

- When importing wallpaper files, the image must be in the USB flash drive's root directory.
 Images in a folder cannot be imported.
- The file name must be fewer than 256 characters.
- The file format of the image that can be imported is BMP (bmp) or JPEG (jpg).
- The individual file size limit is 5 MB.
- The maximum image size is 4,096 x 4,096 pixels. If the image size is less than 800 x 480 pixels, the image is displayed in the middle of the screen with the extra area appearing in black.
- If the USB flash drive does not have any pictures, the **No files detected** message appears.



AA.JPG

AAA.jpg BB.JPG

BBB.ipg

CCC.bmp

Start Import

■ Select wallpaper

- 1. Select Settings.
- 2. Select Clock/Info.
- **3.** Select **Clock/Wallpaper Type**, then open the **Wallpaper** tab.
 - ▶ The screen changes to the wallpaper list.
- 4. Select a desired wallpaper.
 - ▶ The preview is displayed on the left side on the screen.
 - ► The pop-up menu appears on the screen.
- 5. Select Set.
 - ► The display will return to the wallpaper list.

■ To view wallpaper once it is set

Press the (display) button to change the audio/information screen until the wallpaper is displayed.


Switching the Display P. 216

■ Delete wallpaper

- 1. Select Settings.
- 2. Select Clock/Info.
- **3.** Select **Clock/Wallpaper Type**, then open the **Wallpaper** tab.
 - ► The screen changes to the wallpaper list.
- 4. Select a wallpaper that you want to delete.
 - ▶ The preview is displayed on the left side on the screen.
 - ► The pop-up menu appears on the screen.
- 5. Select Delete.
 - A confirmation message appears on the screen.
- **6.** Select **Yes** to delete completely.
 - ► The display will return to the wallpaper list.

Wallpaper Setup

From the pop-up menu, select **Preview** to see a preview at full-size screen.




To go back to the previous screen, select **OK**, or select $\frac{\Delta}{RACK}$.

When the file size is large, it takes a while to be previewed.

To delete all wallpapers you add, select **Delete All**, then **Yes**.

■ Home Screen


■ To change to a next screen



Selecting (() or)), or swiping the screen left or right changes to the next screen.

The home screen has 5 pages (fixed). You cannot add any more pages.

■ To use apps or widgets



- 1. Select HOME.
- 2. Select «.
- 3. Select App List.
 - ► The **APPS** screen appears.
- 4. Select the app or widget you want to use.

Preinstall app list:

- **Browser**: Displays the web browser utilized by smartphone and Wi-Fi connection.
- Calculator: Displays Calculator.
- **Downloads**: Displays the data downloaded from the web browser and so on.
- **Install USB**: Installs and updates apps stored in the USB flash drive.
- **Settings**: Displays the Android setting screen.

∑To use apps or widgets

Select and hold a selected app or widget to add that app's or widget's shortcut on the home screen.

Pre-installed apps may not start up normally. If this occurs, you need to reset the system.

Defaulting All the Settings P. 339

If you perform **Factory Data Reset**, it may reset all the settings to their factory default.

Defaulting All the Settings P. 339

In case those apps still do not startup normally even after **Factory Data Reset**, contact your dealer.

There is a possibility that a browser is shut down in the situation of the use. In that situation, the screen will return to before the browser startup.

You can delete user installed apps by the following procedure.


- 1. Select
- 2. Select Settings.
- 3. Select System.
- 4. Select the Others tab.
- 5. Select **Detail Information**.
- 6. Select an App that you want to delete.
- 7. Select **Delete**.

Pre-installed apps cannot be deleted.


Continued 225

■ To add app or widget icons on the home screen

App or widget icons can be added on the home screen.



- 1. Select .
- **2.** Select **《**.
- **3.** Select and hold empty space on the home screen.
 - ► The pop-up menu appears on the screen.
- 4. Select Add App or Add Widget.
 - ► The **APPS** screen appears.




- **5.** Select and hold an app or widget icon you want to add.
 - ► The screen switches to the customization screen
- **6.** Drag and drop the icon to where you want it to be.
- 7. Select OK.
 - ► The screen will return to the home screen.

Continued 227

■ To move icons on the home screen

You can change location on the home screen.




- 1. Select and hold an icon.
 - ► The screen switches to the customization screen.
- **2.** Drag and drop the icon to where you want it to be.
- 3. Select OK.
 - ➤ The screen will return to the home screen.

∑To move icons on the home screen

You can also move the **Phone**, **Info**, **Audio**, **Settings**, **Navigation***, **HondaLink**, **aha**, **Smartphone connection**, and **App List** icons in the same manner.

■ To remove icons on the home screen

You can delete the icons on the home screen.




- 1. Select and hold an icon.
 - The screen switches to the customization screen.
- **2.** Drag and drop the icon you want to remove to the trash icon.
 - ► The icon is removed from the home screen.
- 3. Select OK.
 - ► The screen will return to the home screen.

>> To remove icons on the home screen

You cannot delete the **Phone**, **Info**, **Audio**, **Settings**, **Navigation***, **HondaLink**, **aha**, **Smartphone connection**, and **App List** icons.

Apps or widgets will not be deleted by deleting the icon on the home screen.

Status Area



- **1.** Swipe the upper area of the screen.
 - ► The status area appears.
- 2. Select an item to see the details.
- 3. Select acc or swipe up the icon to close the area.

Closing Apps

You can close specific apps running in the background on the system.



- **1.** Select and hold
- 2. Select an app you want to close.
- **3.** Select **Stop**.
 - ► The display will return to the app list.

○ Closing Apps ○ Cl

If you leave the apps used open in the background, some apps may stop operating properly next time using them.

If this happens close unused apps.

To close all apps on the system, select **Stop All**, then **Yes**.

You cannot close the HondaLink®, Aha™ and Garmin* apps.

* Not available on all models

Adjusting the Sound





- 1. Select .
- 2. Select Audio.
- 3. Select 🖳
- 4. Select Sound.

Select a tab from the following choices: BASS, TREBLE, FADER, BALANCE, Subwoofer*, Speed Volume Compensation (SVC).

■ Adjusting the Sound

The SVC has four modes: **Off, Low, Mid,** and **High**. SVC adjusts the volume level based on the vehicle speed. As you go faster, audio volume increases. As you slow down, audio volume decreases.

You can also adjust the sound the following procedure.

- 1. Select
- 2. Select **Settings**.
- 3. Select Audio.
- 4. Select **Sound**.

Display Setup

You can change the brightness or color theme of the audio/information touch screen.

■ Changing the Screen Brightness



- 1. Select .
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Display** tab.
- 5. Select Display Settings.
- **6.** Select the setting you want.
- 7. Select OK.

Changing the Screen's Color Theme




- 1. Select .
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Display** tab.
- 5. Select Background Color.
- **6.** Select the setting you want.
- 7. Select OK.

○ Changing the Screen Brightness

You can change the **Contrast** and **Black Level** settings in the same manner.

Continued 233

■ Selecting an Audio Source



Select the current source icon, then select an icon on the source list to switch the audio source.

■ Limitations for Manual Operation

Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

Selecting an Audio Source

If you startup preinstalled audio apps, wis is displayed on the upper portion of the screen. These preinstalled apps cannot be displayed on the source select screen.

You can startup those audio apps from Apps.

When you are using the AhaTM screen and you want to select another source, select **SOURCE** on the upper left of the screen. The source select screen will appear. Select the source you want.

Voice Control Operation

Your vehicle has a voice control system that allows hands-free operation. The voice control system uses the (Talk) and (hang-up/back) buttons on the steering wheel and a microphone near the map lights on the ceiling.

Voice Recognition

To achieve optimum voice recognition when using the voice control system:

- Make sure the correct screen is displayed for the voice command that you are using.
- Close the windows and moonroof*.
- Adjust the dashboard and side vents so air does not blow onto the microphone on the ceiling.
- Speak clearly in a natural speaking voice without pausing between words.
- Reduce any background noise if possible. The system may misinterpret your command if more than one person is speaking at the same time.

When you press the £ button, a helpful prompt asks what you would like to do. Press and release the £ button again to bypass this prompt and give a command.

The voice control system can only be used from the driver's seat because the microphone unit removes noises from the front passenger's side.

■ Voice Portal Screen



When the [6] (Talk) button is pressed, available voice commands appear on the screen.

For a complete list of commands, say "Voice Help" after the beep or select **Voice Help**.

You can also see the list of commands by selecting **Info**, [INFO], and **Voice Info**.

■ Phone Call

This can be only used when the phone is connected. When the system recognizes the *Phone call* command, the screen will change to the voice recognition screen for the phone commands.

- Dial by number
- Call history
- Redial
- Call <Your Contact Name>
- Call <Phone Number>

Phone Call commands are not available if using Apple CarPlay or Android Auto.

■ Music Search*1

This can be only used when the iPod or USB device is connected.

■ Audio*1

When the system recognizes the *Audio* command, the screen will change to the audio voice recognition screen.

- Audio On
- Audio Off
- Radio FM
- Radio AM
- Radio SXM
- DISC
- Pandora*
- iPod
- USB
- Other Sources

Pandora®* cannot be used with Android Auto.

■ Navigation*1

The screen changes to the navigation voice recognition screen.

Refer to the Navigation System Manual

■ Voice Settings

The screen changes to the **Voice Recog** tab on the **System settings** screen.

■ Trip Computer

The screen changes to the trip computer screen.

- *1: Models with navigation system
- * Not available on all models

■ Voice Help

You can see a list of the available commands on the screen.

- Useful Commands
- Phone Commands
- Audio Commands
- On Screen Commands
- Music Search Commands
- General Commands
- Climate Control Commands
- All Commands
- Voice Settings
- Getting Started

Useful Commands

The system accepts these commands on the voice portal top screen.

- Call <Phone Number>
- Call <Your Contact Name>
- What time is it?
- What is today's date?

■ Phone Commands

The system accepts these commands on the dedicated screen for the voice recognition of the phone.

- Call by Number
- Call by Name
- Call <Phone Number>
- Call <Your Contact Name>

Audio Commands*1

The system accepts these commands on the dedicated screen for the voice recognition of the audio.

■ Radio FM Commands

- Radio tune to <87.7-107.9> FM
- Radio tune to <87.7 -107.9> HD <1-8> FM
- Radio FM preset <1-12>

■ Radio AM Commands

- Radio tune to <530-1710> AM
- Radio AM preset <1-6>

■ Radio SXM Commands

- SXM channel <1-999>
- SXM channel <station name>

• Radio SXM preset <1-12>

■ DISC Commands

- DISC play
- DISC play track <1-30>

■ Pandora Commands*

Pandora play

■ iPod Commands

- iPod play
- iPod play track <1-30>
- Music Search
- What album is this?
- What am I listening to?

■ USB Commands

- USB play
- USB play track <1-30>
- Music Search
- What album is this?
- What am I listening to?

■ Bluetooth® audio Commands

• Bluetooth® audio play

NOTE:

Bluetooth® Audio commands may not work on some phones or Bluetooth® Audio devices.

^{*1:} Models with navigation system

^{*} Not available on all models

On Screen Commands

When **On Screen Commands** is selected, the explanation screen is displayed.

■ Music Search Commands*1

The system accepts these commands on the **Music Search** screen.

■ Using Song By Voice

Song By VoiceTM is a feature that allows you to select music from your iPod or USB device using Voice Commands. To activate this mode, you must push the talk switch and say: "Music search".

■ Song By Voice Commands

- What am I listening to?
- Who am I listening to?
- Who is this?
- What's playing?
- Who's playing?
- What album is this?

■ Play Commands

- Play artist <Name>
- Play track/song <Name>
- Play album <Name>
- Play genre/category <Name>
- Play playlist <Name>
- Play composer <Name>

■ List Commands

- List artist <Name>
- List album <Name>
- List genre/category <Name>
- List playlist <Name>
- List composer <Name>

■ General Commands


- What time is it?
- What is today's date?

■ Climate Control Commands*1

- Climate Control on
- Climate Control off
- Fan Speed <1-7>
- Temperature max heat
- Temperature max cool
- Temperature <57-87> degrees
- Defrost on
- Defrost off
- Air conditioner on
- Air conditioner off
- More
- Climate control automatic
- Vent
- Dash and floor
- Fan speed up
- Fan speed down
- Floor vents
- Floor and defrost
- Temperature up
- Temperature down

^{*1:} Models with navigation system

Playing AM/FM Radio



^{*1:}Some or all of the lists may not be displayed.

239

Preset Memory

To store a station:

- 1. Tune to the selected station.
- **2.** Select and hold the preset number for the station you want to store.

You can also store a preset station by the following procedure.

- 1. Tune to the selected station.
- 2. Select the open/close icon to display a list.
- **3.** Select the **Preset** tab.
- **4.** Select and hold the preset number for the station you want to store.

Station List

Lists the strongest stations on the selected band.

- 1. Select the open/close icon to display a list.
- 2. Select the Station List tab.
- **3.** Select the station.

■ Manual update

Updates your available station list at any time.

- 1. Select the open/close icon to display a list.
- **2.** Select the **Station List** tab.
- 3. Select Refresh.

▶ Playing AM/FM Radio

The **ST** indicator appears on the display indicating stereo FM broadcasts.

Stereo reproduction in AM is not available.

Switching the Audio Mode
Press the **SOURCE** button on the steering wheel or
select **SOURCE** on the screen

Audio Remote Controls P. 190

You can store 6 AM stations and 12 FM stations into preset memory.

Models with HD Radio™

If the audio system has the memory capacity, the tagged song information can be stored in it.

HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. HD Radio[™] and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.



Scan

Samples each of the strongest stations on the selected band for 10 seconds. To turn off scan, select **Cancel** or ARCK.

Models with HD Radio™

■ Tag Song to Device

If your iPod/iPhone is connected to the USB port, you can store the TAG information. If the iPod/iPhone is not connected to the audio system, the information is stored in the audio system temporarily, then once the device is connected to the system, data is transferred to the iPod/iPhone.

To store the TAG information to the iPod/iPhone or the audio system, select **TAG**.

Models with HD Radio™

■ Tagged Song List

Displays the TAG information saved to the audio system.

- 1. Select 🖳
- 2. Select Song Tag List.

Continued 241

Models with HD Radio™

■ HD Subchannel

Displays the subchannel list when an HD Radio $^{\text{TM}}$ station is selected while listening to an FM station.

- 1. Select 🖺
- 2. Select HD Radio Subchannel.
- **3.** Select the channel number.

■ Radio Data System (RDS)

Provides text data information related to your selected RDS-capable FM station.

■ To find an RDS station from Station List

- **1.** Select the open/close icon to display a list while listening to an FM station.
- 2. Select the Station List tab.
- 3. Select the station.

■ Manual update

Updates your available station list at any time.

- **1.** Select the open/close icon to display a list while listening to an FM station.
- 2. Select the **Station List** tab.
- 3. Select Refresh.

When you select an RDS-capable FM station, the RDS automatically turns on, and the frequency display changes to the station name. However, when the signals of that station become weak, the display changes from the station name to the frequency.

■ Radio text

Displays the radio text information of the selected RDS station.


- 1. Select 🖳
- 2. Select View Radio Text.

■ Scan

Samples each of the strongest stations on the selected band for 10 seconds.

To turn off scan, select **Cancel** or BACK.

Playing SiriusXM® Radio*



^{*1:}Some or all of the lists may not be displayed.

■ To Change the Tune Mode

- 1. Select 🖳
- 2. Select Tune Mode.
- 3. Select Channel Mode or Category Mode.

∑Playing SiriusXM® Radio *

In the channel mode, all available channels are selectable. In the category mode, you can select a channel within a category (Jazz, Rock, Classical, etc.).

There may be instances when SiriusXM® Radio does not broadcast all the data fields (artist name, title). This does not indicate a problem with your audio system.

SiriusXM® Radio stations load in ascending order, which can take about a minute. Once they have loaded you will be able to scroll up or down to make your selections.

Switching the Audio Mode

Press the **SOURCE** button on the steering wheel or select **SOURCE** on the screen.

Audio Remote Controls P. 190

Tune Start:

When you change to a preset channel, a song being played on that channel restarts from the beginning with this function. This can be turned on or off from the **Audio settings** screen.

■ Customized Features P. 316

Preset Memory

To store a channel:

- 1. Tune to the selected channel.
- **2.** Select to hold the preset number for the station you want to store.
- 3. Select Replace.

You can also store a channel by the following procedure.

- 1. Tune to the selected channel.
- 2. Select the open/close icon to display a list.
- 3. Select the **Preset** tab.
- **4.** Select and hold the preset number for the station you want to store.

■ Multi-channel preset (for music channels only)

You can store up to four of your preferred music channels per preset.



- **1.** Tune a station.
- 2. Select the open/close icon to display a list.
- **3.** Select the **Preset** tab.
- **4.** Select and hold the preset number you want to add a music channel.
 - A message appears if there are no available presets.
- 5. Select Combine.

You can store 12 SiriusXM® channels into the preset memory.

■ Listening to Featured Channels

Suggested channel listing received from SiriusXM® can be displayed and selected.

- **1.** Select the open/close icon to display a channel list.
- 2. Select the Channel List tab.
- **3.** Select the featured channel list title you want to listen to.
 - ▶ The selected channel list of the title is displayed.
- **4.** Select the channel.

∑Listening to Featured Channels

Up to three featured channels by SiriusXM® can be displayed.

Featured channel lists are at the top of the channel list.

Continued 247

Replay Function

The system can record up to the last 60 minutes broadcast of your currently tuned channel as well as the last 30 minutes broadcast of preset channels, starting from the moment you turn the vehicle on. If you tuned to preset channel, the system records up to 60 minutes of a broadcast instead of up to 30 minutes. You can rewind and replay the last 30 or 60 minutes of a broadcast.

- 1. Select 🖳
- 2. Select Playback Position.
- **3.** Move the gauge to the position you want to replay.

To play or pause on playback mode:

- 1. Select 🖳
- 2. Select Play/Pause.

■ Returning to real-time broadcast

- 1. Select 🖳.
- 2. Select Play Live Broadcast.


■ Replay Function

The system starts storing broadcast in memory when the ignition switch is turned to ACCESSORY \boxed{I} or ON \boxed{II}^{*1} . You can go back to the program from that point.

You can no longer replay any program once the ignition switch is turned to LOCK [0]*1 as it erases memory.

You can check how long the program has been stored in memory from the audio/information touch screen.

After 30 or 60 minutes of recording the system will automatically start deleting the oldest data.



- (A): Shows how much time the replayed segment is behind the real-time broadcast $\,$
- (B): Replayed segment
- (C): Length stored in memory
- *1:Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Live Sports Alert

While listening to SiriusXM® Radio, you can receive sports alerts such as scores from your favorite teams.

■ To set up a favorite team



- 1. Select HOME.
- **2.** Select **Settings**.
- 3. Select Audio.
- 4. Select the **SXM** tab.
- 5. Select SportFlash Setup (Favorite Team).
- 6. Select a team.

■ To set up an alert message

- 1. Select .
- 2. Select Settings.
- 3. Select Audio.
- 4. Select the SXM tab.
- 5. Select SportFlash Setup(Interrupt).
- 6. Select On(one time) or On(continue).

∑Live Sports Alert

The sports alert function at SiriusXM® mode only.

∑To set up a favorite team

Sports alerts cut in only when SiriusXM® mode is on. Selecting **On(one time)** from the customize settings disables the alert feature next time you turn the ignition switch to ON $\boxed{\Pi}^{*1}$.

⊇ Customized Features P. 316

You can also set up a favorite team by the following procedure.

- 1. Select Audio.
- 2. Select 🖳.
- 3. Select **Setting**.
- 4. Select the **SXM** tab.

*1:Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ To set up an alert beep

- 1. Select
- 2. Select Settings.
- 3. Select Audio.
- 4. Select the **SXM** tab.
- 5. Select SportFlash Setup(Interrupt Beep).
- 6. Select On.

■ Traffic and Weather Information

You can receive traffic and weather information.

- 1. Select
- 2. Select Settings.
- 3. Select Audio.
- 4. Select the SXM tab.
- 5. Select Traffic & Weather Setup.
- **6.** Select the region.
 - ▶ When you do not want to receive the information, select **Unset**.

∑To set up an alert beep

You can also set up an alert beep by the following procedure.

- 1. Select Audio.
- 2. Select 🖳 .
- 3. Select **Setting**.
- 4. Select the **SXM** tab.

▼Traffic and Weather Information

The traffic and weather information function at SiriusXM® mode only.

You can also set up the traffic and weather information by the following procedure.

- 1. Select Audio.
- 2. Select 🖳
- 3. Select **Setting**.
- 4. Select the **SXM** tab.

Scan

Sample each channel on the selected mode for 10 seconds.

- 1. Select Scan
- 2. Select Scan Channels.
 - To only scan preset stations, select **Scan Songs in Presets**.

To turn off scan, select Cancel Scan.

■ Tag Song to Device

If your iPhone/iPod is connected to the USB port, you can store the TAG information. If the iPod/iPhone is not connected to the audio system, the information is stored in the audio system temporarily. Once the device is connected to the system, data is transferred to the iPod/iPhone.

To store the TAG information to the iPod/iPhone, or the audio system, select **TAG**.

■ Tagged Song List

Displays the TAG information saved to the audio system.

- 1. Select 🖳
- 2. Select Tagged Song List.

≫ Scan


The "Scan Songs in Presets" function is based on TuneScan™ technology of SiriusXM®.

The "Featured Channels" function is based on Featured Favorites™ technology of SiriusXM®.

TuneScan[™] and Featured Favorites[™] are registered trademarks of SiriusXM® Radio, Inc.

Playing a CD


Your audio system supports audio CDs, CD-Rs, and CD-RWs in either MP3, WMA, or AAC*¹ format. With the CD loaded, select the CD mode.



^{*1:}Only AAC format files recorded with iTunes are playable on this unit.

^{*2:}Some or all of the lists may not be displayed.

How to Select a File from the Music Search List (MP3/WMA/AAC)



1. Select and select **Music Search**.

2. Select a folder.

3. Select a track.

NOTICE

Do not use CDs with adhesive labels. The label can cause the CD to jam in the unit.

WMA files protected by digital rights management (DRM) cannot be played.

The audio system displays **Unplayable File**, then skips to the next file.

Text data appears on the display under the following circumstances:


- When you select a new folder, file, or track.
- When you change the audio mode to CD.
- When you insert a CD.

If you eject the CD but do not remove it from the slot, the system reloads the CD automatically after several seconds.

Continued 253

■ How to Select a Play Mode

You can select scan, repeat, and random modes when playing a track or file.



Scan

- 1. Select 🖳 .
- 2. Select Scan.
- **3.** Select a play mode.



■ Random/Repeat

Select a play mode.

■ To turn off a play mode

Select the mode you want to turn off.

Play Mode Menu Items

Scan

Scan Folders (MP3/WMA/AAC): Provides 10-second sampling of the first file in each of the main folders.

Scan Tracks: Provides 10-second sampling of all tracks on the CD (all files in the current folder in MP3, WMA, or AAC).

Random/Repeat

Repeat Folder (MP3/WMA/AAC): Repeats all files in the current folder.

Repeat Track: Repeats the current track/file.


Random in Folder (MP3/WMA/AAC): Plays all files in the current folder in random order.

Random All Tracks: Plays all tracks/files in random order.

Playing an iPod

Connect the iPod using your dock connector to the USB port, then select the iPod mode

■ USB Port(s*) P. 187



^{*1:}Some or all of the lists may not be displayed.

* Not available on all models

■ How to Select a Song from the Music Search List



1. Select and select **Music Search**.

2. Select the items on that menu.

▶ Playing an iPod

Available operating functions vary on models or versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information touch screen.

iPod/USB Flash Drive P. 287

If you operate the music app on your iPhone/iPod while the phone is connected to the audio system, you may no longer be able to operate the same app on the audio/information touch screen.

Reconnect the device if necessary.

If an iPhone is connected via Apple CarPlay, the iPod/ USB source is unavailable and audio files on the phone can only be played within Apple CarPlay.

■ How to Select a Play Mode

You can select shuffle and repeat modes when playing a file.

Select a play mode.



■ To turn off a play mode

Select the mode you want to turn off.

Play Mode Menu Items

Shuffle All Songs: Plays all available files in a selected list (playlists, artists, albums, songs, podcasts, genres, composers, or audiobooks) in random order.

Shuffle Albums: Plays all available albums in a selected list (playlists, artists, albums, songs, podcasts, genres, composers, or audiobooks) in random order.


Repeat Song: Repeats the current track.

Models with navigation system

Song By Voice™ (SBV)

Use SBV to search for and play music from your USB flash drive or iPod using voice commands.

■ To enable SBV



- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- **5.** Select **Song by Voice**.
- **6.** Select **On** or **Off**.

Song By Voice™ (SBV)

Setting options:

- On (factory default): Song By Voice™ commands are available.
- Off: Disable the feature.

■ Searching for music using SBV



- **1.** Set the **Song by Voice** setting to **On**.
- 2. Press the (Talk) button and say "Music Search" to activate the SBV feature for the USB flash drive and iPod
- 3. Press the 🛍 button and say a command.
 - Example 1: Say "(List) 'Artist A'" to view a list of songs by that artist. Select the desired song to start playing.
 - Example 2: Say "Play 'Artist A'" to start playing songs by that artist.
- **4.** To cancel SBV, press the (hang-up/back) button on the steering wheel. The selected song continues playing.

Once you have canceled this mode, you need to press the 🔊 button and say "Music Search" again to re-activate this mode.

Searching for music using SBV

Song By Voice™ Commands List

Song By Voice Commands P. 238

NOTF:

Song By Voice™ commands are available for tracks stored on the USB flash drive or iPod.

You can add phonetic modifications of difficult words so that it is easier for SBV to recognize artists, songs, albums, and composers in voice commands.

▶ Phonetic Modification P. 260

SBV is not available when using Apple CarPlay. Use Siri Eyes Free instead.

Continued 259

■ Phonetic Modification

Add phonetic modifications of difficult or foreign words so that it is easier for SBV to recognize artists, songs, albums, and composers in voice commands when searching for music on the USB flash drive or iPod.




- 1. Select .
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Song by Voice Phonetic Modification.
- 6. Select New Modification.
- 7. Select **USB** or **iPod**.

∑Phonetic Modification

Phonetic Modification is grayed out when **Song By Voice** is set to **Off**.

You can store up to 2,000 phonetic modification items.



- 8. Select the item to modify (e.g., Artist).
 - ► The list of the selected item appears on the screen.
- 9. Select an entry to modify.
 - ► The pop-up menu appears on the screen.
 - ► The listen to the current phonetic modification, select Play.
 - To delete the current phonetic modification, select **Delete**.

10. Select Modify.

11. Select the phonetic spelling you want to use (e.g., "Artist A") when prompted.

12.Select OK.

► The artist "No Name" is phonetically modified to "Artist A." When in the SBV mode, you can press the [€] (Talk) button and use the voice command "Play 'Artist A'" to play songs by the artist "No Name."


U.S. models

Playing Pandora®*

Your audio system allows you to listen to music from the Pandora® app on a compatible smartphone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*[®] HandsFreeLink[®] (HFL) system, or with an iPhone, you can connect using your USB cable to the USB port.

- Phone Setup P. 383
- **USB Port(s*)** P. 187



≫Playing Pandora® *

Pandora®, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc., used with permission. Pandora is currently available exclusively in the United States.

To find out if your phone is compatible with this feature, visit www.handsfreelink.honda.com, or call 1-888-528-7876.

To use this service in your vehicle, the Pandora® app must first be installed on your phone. Visit www.pandora.com. for more information.

Pandora® is free, personalized radio that plays music and comedy you'll love. Just start with the name of one of your favorite artists, songs, comedians or composers and Pandora® will create a custom station that plays similar tracks. Pandora® also features hundreds of genre stations ranging from Dubstep to Smooth Jazz to Power Workout.

If you cannot operate Pandora® through the audio system, it may be streaming through *Bluetooth®* Audio. Make sure Pandora® mode on your audio system is selected.

If your phone is connected to Android Auto or Apple CarPlay, Pandora® is unavailable.

Visit www.apple.com/ios/carplay/ to check Pandora® compatibility in Apple CarPlay, or www.android.com/intl/en_us/auto/ for Android Auto.

■ Pandora® Menu

You can operate some of the Pandora® menu items from your vehicle's audio system. The available items are:

- Bookmark
- Station List
- New Station
- Sound
- Setting

■ Operating a menu item



- 1. Select 🖳
- 2. Select an item.

Pandora® Menu

Available operating functions vary on software versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information touch screen.

Pandora® P. 288


Pandora® may limit the total number of skips allowed on the service. If you dislike a track after the skip limit has been reached, your feedback will be saved but the current track will continue to play.

To change stations, activate the Pandora® menu, select **Station List**, and then select a new station. It also changes stations on the main Pandora® screen.

Playing Aha™

Aha[™] can be displayed and operated on the audio/information touch screen when your smartphone is connected to the audio system by Wi-Fi or through *Bluetooth*® with the HondaLink® app downloaded to your smartphone.

- **Wi-Fi Connection** P. 275
- HondaLink® P. 270



Playing Aha[™]

AhaTM by Harman is a cloud-based service that organizes your favorite web content into live radio stations. You can access podcasts, internet radio, location-based services, and audio updates from social media sites.

Available operating functions vary on software versions. Some functions may not be available on the vehicle's audio system.

The menu items vary depending on the station you selected.

You must have a previously set up Aha^{TM} account prior to using the service in your vehicle. Visit www.aharadio.com for more information.

You want to select another source, select **AUDIO** on the upper left of the screen. The source select screen will appear. Select the source you want.

If there is an active connection to Apple CarPlay or Android Auto, Aha[™] can only be accessed when the phone is connected through Wi-Fi.


265

Playing a USB Flash Drive

Your audio system reads and plays sound files on a USB flash drive in either MP3, WMA. or AAC*1 format.

Connect your USB flash drive to the USB port, then select the USB mode.


■ USB Port(s*) P. 187



- *1:Only AAC format files recorded with iTunes are playable on this unit.
- *2:Some or all of the lists may not be displayed.

* Not available on all models Continued

■ How to Select a File from the Music Search List



- **1.** Select and select **Music Search**.
- 2. Select Music.

3. Select a folder

4. Select a track.

▶ Playing a USB Flash Drive

Use the recommended USB flash drives.

Seneral Information on the Audio System
P. 291

WMA files protected by digital rights management (DRM) cannot be played.

The audio system displays **Unplayable File**, then skips to the next file.


If there is a problem, you may see an error message on the audio/information touch screen.

iPod/USB Flash Drive P. 287

Select **Switch USB Device** in the **Audio menu** screen to switch to another USB device.

■ How to Select a Play Mode

You can select scan, repeat, and random modes when playing a file.



■ Scan

- 1. Select 🖳
- 2. Select Scan.
- **3.** Select a play mode.



■ Random/Repeat

Select a play mode.

■ To turn off a play mode

Select the mode you want to turn off.

Play Mode Menu Items

Scan

Scan Folders: Provides 10-second sampling of the first file in each of the main folders.

Scan Tracks: Provides 10-second sampling of all files

in the current folder.

Random/Repeat

Random in Folder: Plays all files in the current

folder in random order.

Random All Tracks: Plays all files in random order. **Repeat Folder**: Repeats all files in the current folder.


Repeat Track: Repeats the current file.

Playing Bluetooth® Audio

Your audio system allows you to listen to music from your *Bluetooth*-compatible phone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® (HFL) system.

Phone Setup P. 383



*1:Depending on the *Bluetooth*® device you connect, some or all of the lists may not be displayed.

Not all *Bluetooth*-enabled phones with streaming audio capabilities are compatible.
To check if your phone is compatible, visit http://www.handsfreelink.com/Honda/.

It may be illegal to perform some data device functions while driving.

Only one phone can be used with HFL at a time. When there are more than two paired phones in the vehicle, the first paired phone the system finds is automatically connected.

The connected phone for *Bluetooth*® Audio can be different.

If more than one phone is paired to the HFL system, there may be a delay before the system begins to play.

In some cases, the name of the artist, album, or track may not appear correctly.

Some functions may not be available on some devices.

If a phone is currently connected via Apple CarPlay or Android Auto, *Bluetooth*® Audio from that phone is unavailable. However, a second previously paired phone can stream *Bluetooth*® Audio by selecting **Connect** from **Bluetooth Device List**.

Phone Setup P. 383

■ To Play Bluetooth® Audio Files



1. Make sure that your phone is paired and connected to the system.


Phone Setup P. 383

2. Select the *Bluetooth®* Audio mode.

If the phone is not recognized, another HFL-compatible phone, which is not compatible for *Bluetooth*® Audio, may already be connected.

■ To pause or resume a file Select the play icon or pause icon.

Searching for Music



- 1. Select
- 2. Select Music Search.
- **3.** Select a search category (e.g., Albums).
- **4.** Select an item.
 - ► The selection begins playing.

∑To Play Bluetooth® Audio Files

To play the audio files, you may need to operate your phone. If so, follow the phone maker's operating instructions.

Switching to another mode pauses the music playing from your phone.

You can change the connected phone in the *Bluetooth*® settings on the **Audio menu** screen by the following procedure.

- 1. Select 🖳
- 2. Select **Settings**.

Searching for Music

Depending on the *Bluetooth*® device you connect, some or all of the lists may not be displayed.

HondaLink®

HondaLink® connects you to the latest information from Honda. You can connect your phone wirelessly through Wi-Fi or *Bluetooth*®.

Wi-Fi Connection P. 275

Phone Setup P. 383

■ HondaLink® Menu



■ Places*

Displays restaurants, gas stations, Honda dealer, and so on. You can also navigate to the found locations via the navigation.

■ Vehicle

Displays instruction messages when the vehicle needs service.

■ Help & Support

Displays tips for vehicle usage, and get support via road side or customer service center.

>> HondaLink®

The HondaLink® connect app is compatible with most iPhone and Android phones.

Some cell phone carriers charge for tethering and smartphone data use. Check your phone's data subscription package.

If there is an active connection to Apple CarPlay or Android Auto, HondaLink® can only be connected through Wi-Fi.

■ Messages from Honda

Displays helpful and important information from Honda.

■ Weather

Displays a weekly five-day weather forecast for any location you want. You can change the ZIP Code at any time.

■ To Set Up to Connect HondaLink® Service

Use the following procedure to connect to HondaLink® service.

■ To enable to the HondaLink® service



- 1. Select
- Select Settings.
- 3. Select Clock/Info
- **4.** Select the **HondaLink** tab.
- 5. Select Diagnostic & Location Data.
- 6. Select On.

You need to allow the consent of the location service to enable the HondaLink® service.

MAP AUDIO SOURCE

Diagnostic & Location Data

Would you like to enable hondal ink? By enabling Hondal ink, Honday Ink; By enabling Honday Ink, Honday Ink; Copiect your vehicle's diagnostic and location information. This information may be tied to the vehicle's vehicle identification number (VIN) and will be used to help improve the quality of the products and services offered by Honda. See the Hondack Ink user agreement for more details. You may change your selection later under thir hird Settings Menu.

Cancel Enable Once Always Enable

Enable Once: Allows only one time. (Prompt shows again next time.)

Always Enable: Allows anytime. (Prompt

does not show again.)

Cancel: Does not allow this consent.

Continued 271

■ To link with HondaLink®



You can see the **Connection Guide** screen after launching HondaLink®. If you do not need this guide, select check-box and select **OK**.

■ Vehicle Information and Message from Honda Tips

You can check the messages that are received guickly in the shortcut operation.



- **1.** A message appears and notifies you of a new message on the header area.
 - ► When the message is received, a notification ring can be heard.

2. A message icon is continuously displayed in the header area until the new message is read.

Continued 273



3. From the top of the screen, swipe down to see the messages.

4. Select a new message to open.

Wi-Fi Connection

You can connect the display audio to the Internet using Wi-Fi and browse websites or use online services on the audio/information touch screen. If your phone has cell hotspot capabilities, the system can be tethered to the phone. Use the following steps to setup.

■ Wi-Fi mode (setting for the first time)



- 1. Select
- 2. Select Settings.
- 3. Select Bluetooth/Wi-Fi.
- 4. Select the Wi-Fi tab.
- 5. Select Wi-Fi On/Off Status, then On.
- 6. Select Wi-Fi Network List.
 - ► Make sure your phone's Wi-Fi setting is in access point (tethering) mode.
 - Select the phone you want to connect to the system.
 - ► If you do not find the phone you want to connect in the list, select **Scan**.

7. Select Connect.

- ► Enter a password for your phone, and select **OK**.
- ➤ When the connection is successful, the icon is displayed on the list.
- **8.** Select to go back to the home screen.

Wi-Fi mode (setting for the first time)

You cannot go through the setting procedure while a vehicle is moving. Park in a safe place to setup the Wi-Fi connection.

Some cell phone carriers charge for tethering and smartphone data use. Check your phone's data subscription package.

Check your phone manual to find out if the phone has Wi-Fi connectivity.

You can confirm whether Wi-Fi connection is on or off with the icon on **Wi-Fi Network List**. Transmission speed and others will not be displayed on this screen.



Continued 275

■ Wi-Fi mode (after the initial setting has been made)

Make sure your phone's Wi-Fi setting is in access point (tethering) mode.

Wi-Fi mode (after the initial setting has been made)

iPhone users

You may need to go through an initial setup for Wi-Fi connection again after you boot your phone.

Apple CarPlay

If you connect an Apple CarPlay-compatible iPhone to the system via USB, you can use the audio/information touch screen, instead of the iPhone display, to make a phone call, listen to music, view maps (navigation), and access messages.

■ USB Port(s*) P. 187

■ Apple CarPlay

Only iPhone5 or newer versions with iOS 8.4 or later are compatible with Apple CarPlay.

Park in a safe place before connecting your iPhone to Apple CarPlay and when launching any compatible apps.

To use Apple CarPlay, connect the USB cable to the front USB port. The USB port located in the center console storage will not enable Apple CarPlay operation.

■ USB Port(s*) P. 187

To directly access the Apple CarPlay phone function, select **Phone** on the home screen. While connected to Apple CarPlay, calls are only made through Apple CarPlay. If you want to make a call with *Bluetooth*® HandsFreeLink®, turn Apple CarPlay OFF or detach the USB cable from your iPhone.


Setting Up Apple CarPlay P. 279

When your iPhone is connected to Apple CarPlay, it is not possible to use the *Bluetooth*® Audio or *Bluetooth*® HandsFreeLink®. However, other previously paired phones can stream audio via *Bluetooth*® while Apple CarPlay is connected.

Phone Setup P. 383

For details on countries and regions where Apple CarPlay is available, as well as information pertaining to function, refer to the Apple homepage.

Apple CarPlay Menu



■ Phone

Access the contact list, make phone calls, or listen to voice mail.

■ Messages

Check and reply to text messages, or have messages read to you.

■ Music

Play music stored on your iPhone.

■ Maps

Display Apple CarPlay map and use the navigation function just as you would on your iPhone.

Models with navigation system

Only one navigation system (pre-installed navigation or Apple CarPlay map) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.

■ Apple CarPlay

Apple CarPlay Operating Requirements & Limitations

Apple CarPlay requires a compatible iPhone with an active cellular connection and data plan. Your carrier's rate plans will apply.


Changes in operating systems, hardware, software, and other technology integral to providing Apple CarPlay functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Apple CarPlay functionality and services. Honda cannot and does not provide any warranty or guarantee of future Apple CarPlay performance or functionality.

It is possible to use 3rd party apps if they are compatible with Apple CarPlay. Refer to the Apple homepage for information on compatible apps.

Setting Up Apple CarPlay

After you have connected your iPhone to the system via USB, use the following procedure to set up Apple CarPlay. Use of Apple CarPlay will result in the transmission of certain user and vehicle information (such as vehicle location, speed, and status) to your iPhone to enhance the Apple CarPlay experience. You will need to consent to the sharing of this information on the audio/information touch screen.

■ Enabling Apple CarPlay



- **Enable Once**: Allows only once. (Prompt shows again next time.)
- **Always Enable**: Allows anytime. (Prompt does not show again.)
- Cancel: Does not allow this consent.

You may change the consent settings under the **Smartphone** settings menu.

Setting Up Apple CarPlay

You can also use the method below to set up Apple CarPlay:

Select HOME→Settings→Smartphone→Apple CarPlay

Use of user and vehicle information

The use and handling of user and vehicle information transmitted to/from your iPhone by Apple CarPlay is governed by the Apple iOS terms and conditions and Apple's Privacy Policy.

Continued 279

■ Operating Apple CarPlay with Siri Eyes Free

Press and hold the talk button to activate Siri Eyes Free.



■ Operating Apple CarPlay with Siri Eyes Free

Below are examples of questions and commands for Siri Eyes Free:

- What movies are playing today?
- Call dad at work.
- What song is this?
- How's the weather tomorrow?
- Read my latest email.
- Find a table for four tonight in Chicago.

For more information, please visit www.apple.com/ios/siri.

Android Auto

When you connect an Android phone to the Display Audio system via USB, Android Auto is automatically initiated. When connected via Android Auto, you can use the audio/information touch screen to access the Phone, Google Maps (Navigation), Google Play Music, and Google Now functions. When you first use Android Auto, a tutorial will appear on the screen. We recommend that you complete this tutorial while safely parked before using Android Auto.

■ USB Port(s*) P. 187

▶ Auto Pairing Connection P. 283

To use Android Auto, you need to download the Android Auto app from Google Play to your smartphone.

Only Android 5.0 (Lollipop) or later versions are compatible with Android Auto. *Bluetooth* A2DP cannot be used with Android Auto phone.

Park in a safe place before connecting your Android phone to Android Auto and when launching any compatible apps.

To use Android Auto, connect the USB cable to the front USB port. The USB port in the center console storage will not enable Android Auto operation.

■ USB Port(s*) P. 187


To directly access the Android Auto phone function, select **Phone** on the home screen. While connected to Android Auto, calls are only made through Android Auto. If you want to make a call with *Bluetooth*® HandsFreeLink®, turn Android Auto OFF or detach the USB cable from your Android phone.

■ Auto Pairing Connection P. 283

When your Android phone is connected to Android Auto, it is not possible to use *Bluetooth®* Audio or *Bluetooth®* HandsFreeLink®. However, other previously paired phones can stream audio via *Bluetooth®* while Android Auto is connected.

Phone Setup P. 383

Android Auto Menu



Maps (Navigation)

Display Google Maps and use the navigation function just as you would with your Android phone. When the vehicle is in motion, it is not possible to make keyboard entries. Stop the vehicle in a safe location to undertake a search or provide other inputs.

2 Phone (Communication)

Make and receive phone calls as well as listen to voicemail.

3 Google Now (Home screen)

Display useful information organized by Android Auto into simple cards that appear just when they're needed.

4 Music and audio

Play Google Play Music and music apps that are compatible with Android Auto. To switch between music apps, press this icon.

6 Go back to the Home screen

6 Voice

Operate Android Auto with your voice.

>> Android Auto

For details on countries and regions where Android Auto is available, as well as information pertaining to function, refer to the Android Auto homepage.

Android Auto Operating Requirements & Limitations

Android Auto requires a compatible Android phone with an active cellular connection and data plan. Your carrier's rate plans will apply.

Changes in operating systems, hardware, software, and other technology integral to providing Android Auto functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Android Auto functionality and services. Honda cannot and does not provide any warranty or guarantee of future Android Auto performance or functionality.

It is possible to use 3rd party apps if they are compatible with Android Auto. Refer to the Android Auto homepage for information on compatible apps.

Models with navigation system

Only one navigation system (pre-installed navigation or Android Auto) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.

The audio/Information screen shows you turn-by-turn driving directions to your destination.

Auto Pairing Connection

When you connect an Android phone to the unit via USB, Android Auto is automatically initiated.

■ Enabling Android Auto



- **Enable Once**: Allows only once. (Prompt shows again next time.)
- **Always Enable**: Allows anytime. (Prompt does not show again.)
- Cancel: Does not allow this consent.

You may change the consent settings under the **Smartphone** settings menu.

■ Enabling Android Auto

Only initialize Android Auto when you are safely parked. When Android Auto first detects your phone, you will need to set up your phone so that auto pairing is possible. Refer to the instruction manual that came with your phone.

You can use the method below to change Android Auto settings after you have completed the initial setup:

 ${\small {\sf Select}\, HOME \longrightarrow Settings \longrightarrow Smartphone \longrightarrow Android} \\ {\small {\sf Auto}}$


Use of user and vehicle information

The use and handling of user and vehicle information transmitted to/from your phone by Android Auto is governed by Google's Privacy Policy.

Continued 283

Operating Android Auto with Voice Recognition

Press and hold the talk button to operate Android Auto with your voice.



■ Operating Android Auto with Voice Recognition

Below are examples of commands you can give with voice recognition:

- Reply to text.
- Call my wife.
- Navigate to Honda.
- Play my music.
- Send a text message to my wife.
- Call flower shop.

For more information, please refer to the Android Auto homepage.


You can also activate the voice recognition function by pressing the 4 icon in the upper-right corner of the screen.

Siri Eyes Free

You can talk to Siri using the [6] (Talk) button on the steering wheel when your iPhone is paired to the *Bluetooth*® HandsFreeLink® (HFL) system.

Phone Setup P. 383

Using Siri Eyes Free



Siri Eyes Free

Siri is a trademark of Apple Inc.

Check Apple Inc. website for features available for Siri.

We recommend against using Siri other than in Siri Eyes Free while operating a vehicle.

■Using Siri Eyes Free

Some commands work only on specific phone features or apps.

Audio Error Messages

CD Player

If a disc error occurs, you may see the following error messages.

Error Message	Cause	Solution
Unplayable File	Track/file format not supported	 Current track/file will be skipped. The next supported track/file plays automatically.
Bad Disc Please Check Owner's Manual Push Eject*1 Bad Disc Please check Owner's Manual Please push eject button*2	Mechanical error	 Press the ▲ (eject) button and remove the disc, and check that the error message is cleared. Check that the disc is not damaged or deformed, and insert the disc again. ▶ Protecting CDs P. 293 If the error message reappears, press the ▲ button, and pull out the disc. Insert a different disc. If the new disc plays, there is a problem with the first disc. If the error message repeats, or the disc cannot be removed, contact a dealer. Do not try to force the disc out of the player.
Mecha Error Bad Disc Please Check Owner's Manual	Servo error	
Check Disc	Disc error	• Check that the disc is not damaged or deformed. ▶ Protecting CDs P. 293
Heat Error	High temperature	• Turn the audio system off and allow the player to cool down until the error message is cleared.

^{*1:}Models with one display

^{*2:}Models with two displays

iPod/USB Flash Drive

If an error occurs while playing an iPod or USB flash drive, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
USB Error	Appears when there is a problem with the USB adapter unit. Check if the device is compatible with the USB adapter unit.
Incompatible USB Device Please Check Owner's Manual ^{*1} The connected USB device has a problem. See Owner's Manual ^{*2}	Appears when an incompatible device is connected. Disconnect the device. Then turn the audio system off, and turn it on again. Do not reconnect the device that caused the error.
Unsupported Version	Appears when an unsupported iPod is connected. If it appears when a supported iPod is connected, update the iPod software to the newer version.
Connect Retry	Appears when the system does not acknowledge the iPod. Reconnect the iPod.
Unplayable File	Appears when the files in the USB flash drive are DRM or an unsupported format. This error message appears for about 3 seconds, then plays the next song.
No Data	iPod Appears when the iPod is empty. USB flash drive Appears when the USB flash drive is empty or there are no MP3, WMA, or AAC files in the USB flash drive. iPod and USB flash drive Check that compatible files are stored on the device.
Unsupported	Appears when an unsupported device is connected. If it appears when a supported device is connected, reconnect the device.

^{*1:}Models with one display *2:Models with two displays

U.S. models

Pandora[®]

If an error occurs while playing Pandora®, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Models with one display

Error Message	Solution
Incompatible USB Device Please Check Owner's Manual	Appears when an incompatible device is connected. Disconnect the device. Then turn the audio system off, and turn it on again. Do not reconnect the device that caused the error.
There is no station list in the device. Please add the station list to your device.	Appears when there is no station list on the device. Use the device to create a station.
Music licenses force us to limit the number of tracks you may skip each hour.	Appears when you try to skip a song or select Dislike over the predetermined number of times in an hour.
Unable to save rating. Unable to save bookmark or Unable to skip	Appears when the commanded operation is failed. Try again later.
No data	Appears when no data is available with Pandora® activated. Reboot the app and reconnect the device.
PANDORA ver unsupport	Appears when Pandora® version is not supported. Update Pandora® to the latest version.
PANDORA system maintenance	Appears when the Pandora® server is in maintenance. Try again later.
Cannot connect to PANDORA when stopped. Check your mobile phone	Appears when Pandora® is unable to play music. Check your device.
Unable to play PANDORA. Please try again later.	 Appears when data transfer has failed 10 times. Try again later. Appears when condition for transferring data is unstable. Try again later.
Unable to play PANDORA. Music Licensing restricts play in this area.	Appears when Pandora® service is not available in the current area.

Error Message	Solution
To begin listening, select a station from the Stations list.	Appears when there is no station list on the device. Use the device to create a station.
Unable to rate track. Please try again. Skip limit reached.	Appears when you try to skip a song or select Like/Dislike over the predetermined number of times in an hour.
Unable to play Pandora. Please try again later. Unable to retrieve a track explanation. Please try again later. Unable to create bookmark. Please try again later.	Appears when the commanded operation has failed. Try again later.
No Data	Appears when no data is available with Pandora® activated. Reboot the app and reconnect the device.
Pandora App version is not supported	Appears when Pandora® version is not supported. Update Pandora® to the latest version.
Unable to complete the operation. Please try again later.	Appears when the Pandora® server is in maintenance. Try again later.
Unable to connect Pandora. When stopped, check your mobile phone	Appears when Pandora® is unable to play music. Check your device.
Unable to connect Pandora. When stopped, check your mobile phone	Appears when Pandora® app is not installed on your device. Install Pandora® app to the your device.

Android/Apps

If an error occurs while using the audio system or apps, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message*1	Solution
Unfortunately, **** has stopped.	Error has occurred within app, select OK on the screen to close the app.
**** is not responding. Would you like to close it?	App is not responding. Select Wait if you can wait for a response from app a little longer. If it does not respond even if you keep waiting, select OK to close the app and start it up. If the error message continues, perform Factory Data Reset . Defaulting All the Settings P. 339

^{*1:****}part is variable characters, and will change depending upon where an error occurs.

General Information on the Audio System

SiriusXM® Radio Service*

Subscribing to SiriusXM® Radio

- **1.** You need your radio ID ready before registering for subscription. To see the ID in the screen, select **Channel 0**.
- 2. Have your radio ID ready, and either call or visit the SiriusXM® website to subscribe.

Receiving SiriusXM® Radio

Switch to the SiriusXM® mode by using the **SOURCE** button on the steering wheel, or through the audio/information touch screen, and stay in this mode for about 30 minutes until the service is activated. Make sure your vehicle is in an open area with good reception.

SiriusXM® Radio Display Messages

Channel Not Subscribed:

You are not subscribed to the channel selected.

Subscription Updated:

SiriusXM® radio is receiving information update from the network.

Channel Not Available:

No such channel exists, or the artist or title information is unavailable.

No Signal:

The signal is too weak in the current location.

Antenna Disconnected:

The SiriusXM® antenna is disconnected. Contact a dealer.

Subscribing to SiriusXM® Radio

Contact Information for SiriusXM® Radio:

- US: SiriusXM® Radio at www.siriusxm.com or 1-800-852-9696
- Canada: SiriusXM® Canada at www.xmradio.ca, or 1-877-209-0079

■ Receiving Sirius XM® Radio

The SiriusXM® satellites are in orbit over the equator; therefore, objects south of the vehicle may cause satellite reception interruptions. Satellite signals are more likely to be blocked by tall buildings and mountains the farther north you travel from the equator.

You may experience reception problems under the following circumstances:

- In a location with an obstruction to the south of your vehicle.
- In tunnels
- On the lower level of a multi-tiered road
- Large items carried on the roof rack

* Not available on all models

Recommended CDs

- Use only high-quality CD-R or CD-RW discs labeled for audio use.
- Use only CD-R or CD-RW discs on which the recordings are closed.
- Play only standard round-shaped CDs.



CDs with MP3, WMA, or AAC files

- Some software files may not allow for audio play or text data display.
- Some versions of MP3, WMA, or AAC formats may be unsupported.

■ Recommended CDs

A Dual-disc cannot play on this audio unit. If recorded under certain conditions, a CD-R or CD-RW may not play either.

■ Protecting CDs


Follow these precautions when handling or storing CDs:

- Store a CD in its case when it is not being played.
- When wiping a CD, use a soft clean cloth from the center to the outside edge.
- Handle a CD by its edge. Never touch either surface.
- Never insert foreign objects into the CD player.
- Keep CDs out of direct sunlight and extreme heat.
- Do not place stabilizer rings or labels on the CD.
- Avoid fingerprints, liquids, and felt-tip pens on the CD.

▶ Protecting CDs

NOTICE

Do not insert a damaged CD. It may be stuck inside and damage the audio unit.



Compatible iPod, iPhone, and USB Flash Drives

■ iPod and iPhone Model Compatibility

Model
iPod (5th generation)
iPod classic 80GB/160GB (launch in 2007)
iPod classic 120GB (launch in 2008)
iPod classic 160GB (launch in 2009)
iPod nano (1st to 7th generation) launch in 2012*1
iPod nano (1st to 7th generation) launch in 2010*2
iPod touch (1st to 5th generation) launch in 2012*1
iPod touch (1st to 4th generation) launch in 2010*2
iPhone 3G/iPhone 3GS/iPhone 4/iPhone 4S/iPhone 5*1
iPhone 3G/iPhone 3GS/iPhone 4/iPhone 4s/iPhone 5/iPhone 5c/iPhone 5s*2

^{*1:}Models with one display

USB Flash Drives

- A USB flash drive of 256 MB or higher is recommended.
- Some digital audio players may not be compatible.
- Some USB flash drives (e.g., a device with security lockout) may not work.
- Some software files may not allow for audio play or text data display.
- Some versions of MP3, WMA, or AAC formats may be unsupported.

This system may not work with all software versions of these devices.

≥ USB Flash Drives

Files on the USB flash drive are played in their stored order. This order may be different from the order displayed on your PC or device.

^{*2:}Models with two displays

Legal Information on Apple CarPlay/Android Auto

■ OWNER'S MANUAL LICENSE/LIABILITY STATEMENTS

USE OF APPLE CARPLAY IS SUBJECT TO YOUR AGREEMENT TO THE CARPLAY TERMS OF USE, WHICH ARE INCLUDED AS PART OF THE APPLE IOS TERMS OF USE. IN SUMMARY, THE CARPLAY TERMS OF USE DISCLAIM APPLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT APPLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY APPLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF CARPLAY, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE APPLE'S PRIVACY POLICY FOR DETAILS REGARDING APPLE'S USE AND HANDLING OF DATA UPLOADED BY CARPLAY.

USE OF ANDROID AUTO IS SUBJECT TO YOUR AGREEMENT TO THE ANDROID AUTO TERMS OF USE WHICH MUST BE AGREED TO WHEN THE ANDROID AUTO APPLICATION IS DOWNLOADED TO YOUR ANDROID PHONE. IN SUMMARY, THE ANDROID AUTO TERMS OF USE DISCLAIM GOOGLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT GOOGLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY GOOGLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF ANDROID AUTO, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE GOOGLE'S PRIVACY POLICY FOR DETAILS REGARDING GOOGLE'S USE AND HANDLING OF DATA UPLOADED BY ANDROID AUTO.

DISCLAIMER OF WARRANTIES; LIMITATION ON LIABILITY

YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF APPLE CARPLAY OR ANDROID AUTO ("THE APPLICATIONS") IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND THAT THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS IS PROVIDED "AS IS" AND "AS AVAILABLE." WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND. AND HONDA HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY, QUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY HONDA OR AN AUTHORIZED. REPRESENTATIVE SHALL CREATE A WARRANTY. AS EXAMPLES, AND WITHOUT LIMITATION, HONDA DISCLAIMS ANY WARRANTY REGARDING THE ACCURACY OF DATA PROVIDED BY THE APPLICATIONS. SUCH AS THE ACCURACY OF DIRECTIONS. ESTIMATED TRAVEL TIME, SPEED LIMITS, ROAD CONDITIONS, NEWS, WEATHER, TRAFFIC, OR OTHER CONTENT PROVIDED BY APPLE, GOOGLE, THEIR AFFILIATES, OR THIRD PARTY PROVIDERS; HONDA DOES NOT GUARANTEE AGAINST LOSS OF APPLICATION DATA, WHICH MAY BE LOST AT ANY TIME: HONDA DOES NOT GUARANTEE THAT THE APPLICATIONS OR ANY SERVICES PROVIDED THROUGH THEM WILL BE PROVIDED AT ALL TIMES OR THAT ANY OR ALL SERVICES WILL BE AVAILABLE AT ANY PARTICULAR TIME OR LOCATION. FOR EXAMPLE. SERVICES MAY BE SUSPENDED OR INTERRUPTED WITHOUT NOTICE FOR REPAIR, MAINTENANCE, SECURITY FIXES, UPDATES, ETC., SERVICES MAY BE UNAVAILABLE IN YOUR AREA OR LOCATION, ETC. IN ADDITION, YOU UNDERSTAND THAT CHANGES IN THIRD PARTY TECHNOLOGY OR GOVERNMENT REGULATION MAY RENDER THE SERVICES AND/OR APPLICATIONS OBSOLETE AND/OR UNUSABLE.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL HONDA OR ITS AFFILIATES BE LIABLE FOR PERSONAL INJURY, OR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, CORRUPTION OR LOSS OF DATA, FAILURE TO TRANSMIT OR RECEIVE ANY DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO THE APPLICATIONS OR YOUR USE OF OR INABILITY TO USE THE APPLICATIONS OR INFORMATION ON THE APPLICATIONS, HOWEVER CAUSED, REGARDLESS OF THE THEORY OF LIABILITY (CONTRACT, TORT OR OTHERWISE) AND EVEN IF HONDA WERE ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES AND JURISDICTIONS DISALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR DAMAGES, SO THESE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. IN NO EVENT SHALL HONDA'S TOTAL LIABILITY TO YOU FOR ALL DAMAGES (OTHER THAN AS MAY BE REQUIRED BY APPLICABLE LAW IN CASES INVOLVING PERSONAL INJURY) EXCEED THE AMOUNT OF FIVE DOLLARS (\$5.00). THE FOREGOING LIMITATIONS WILL APPLY EVEN IF THE ABOVE STATED REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

About Open Source Licenses

To see the open source license information, follow these steps.

- 1. Select
- 2. Select Settings.
- **3.** Select **System**, then open the **Others** tab.
- 4. Select **Detail Information**.
- 5. Select About device.
- 6. Select Legal information.
- **7.** Select **Open source licenses**.


Customized Features

Models with one display

Use the audio/information screen to customize certain features.

■ How to customize

While the vehicle is at a complete stop with the ignition switch in ON \boxed{II}^{*1} , press the **SETTINGS** button, rotate n to select a setting item, and press a.



○ Customized Features

When you customize settings:

• Make sure that the vehicle is at a complete stop.

Automatic transmission/CVT models

• Shift to P.

Manual transmission models

• Set the parking brake.


>> How to customize


To customize other features, rotate ♥, and press ♥.

List of customizable options P. 304


*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Customization flow











* Not available on all models



^{*1:} May change depending on your currently selected source.



■ List of customizable options

Setup Group	Customizable Features		Description	Selectable Settings
	Display	Brightness	Changes the brightness of the audio/information screen.	_
		Contrast	Changes the contrast of the audio/information screen.	_
System		Black Level	Changes the black level of the audio/information screen.	_
	Beep		Selects whether a beeper sounds when you operate the selector knob.	On*1/Off
Settings		Bluetooth On/Off	Turns the <i>Bluetooth</i> ® on and off.	On*1/Off
	Blue- tooth	Bluetooth Device List	Pairs a new phone to HFL, edits and deletes a paired phone, and create a security PIN. Phone Setup P. 350	-
		Edit Pairing Code	Changes a pairing code. To change the pairing code setting P. 352	Random/Fixed*1
	Voice Recog	Voice Prompt	Turns the voice prompt on and off.	Beginner*1/Expert

^{*1:}Default Setting

Setup Group	Customizable Features		Features	Description	Selectable Settings
	Clock	Clock/	Clock Type	Changes the clock display type.	Analog/Digital*1/ Small Digital/Off
		Wallpaper Type	Wallpaper	 Changes the wallpaper type. Imports an image file for a new wallpaper. Deletes an image file for a wallpaper. Wallpaper Setup P. 195 	Blank/Galaxy* ¹ / Metallic/Add New
		Clock Adjus	tment	Adjusts Clock. Ď Clock P. 116	_
System		Clock Forma	at	Selects the digital clock display from 12H to 24H.	12H*1/24H
Settings	Others	Language		Changes the display language.	English*¹/French/ Spanish
		Background	l Color	Changes the background color of the audio/ information screen.	Blue*1/Amber/Red/ Green
		Header Clo	ck Display	Selects whether the clock display comes on.	On*1/Off
		Factory Dat	a Reset	Resets all the settings to their factory default. Defaulting All the Settings P. 315	Yes/No
	Default			Cancels/Resets all customized items in the System Settings group as default.	Yes/No

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
	TPMS Ca	libration	Cancels/Calibrates the TPMS.	Cancel*1/Calibrate
	Driver Assist System Setup*	Forward Collision Warning Distance*	Changes at which distance the CMBS™ alerts.	Long/Normal*1/Short
Vehicle Settings		ACC Forward Vehicle Detect Beep*	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC range.	On/Off*1
		ACC Display Speed Unit*	Changes the speed unit for ACC on the multi- information display.	mph*1/km/h (U.S.) mph/km/h*1 (Canada)
		Road Departure Mitigation Setting*	Changes the setting for the road departure mitigation system.	Normal*¹/Wide/ Warning Only
		Lane Keeping Assist Suspend Beep*	Causes the system to beep when the LKAS is suspended.	On/Off*1

^{*1:}Default Setting

Setup Group	C	Customizable Features	Description	Selectable Settings
		Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	-5°F ~ ±0°F*1 ~ +5°F (U.S.) -3°C ~ ±0°C*1 ~ +3°C (Canada)
		"Trip A" Reset Timing	Changes the setting of how to reset trip meter A and average fuel economy A.	With Refuel/IGN Off/ Manually Reset*1
Vehicle	Meter Setup	"Trip B" Reset Timing	Changes the setting of how to reset trip meter B and average fuel economy B.	With Refuel/IGN Off/ Manually Reset*1
Settings		Fuel Efficiency Backlight	Turns the ambient meter feature on and off.	On*1/Off
		Keyless Start Guidance Screens*	Displays the push button start guidance when conditions are met to change power mode.	On*1/Off
		Remote Start System ON/ OFF*	Turns the remote engine start feature on and off.	On*1/Off
	Driving Position Setup*	Memory Position Link	Changes the driver's seat position to a stored setting.	On*1/Off

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
	Keyless Access Setup*	Door Unlock Mode	Changes which doors unlock when you grab the driver's door handle.	Driver Door Only*1/ All Doors
		Keyless Access Light Flash	Causes some exterior lights to blink when you unlock/lock the doors.	On*1/Off
Vehicle Settings		Keyless Access Beep	Sets the beeper sound or not when you grab either door handle.	On*1/Off
	Lighting Setup	Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	60seconds/ 30seconds* ¹ / 15seconds
		Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60seconds/ 30seconds/ 15seconds*1/ 0seconds
		Auto Light Sensitivity	Changes the timing for the headlights to come on.	Max/High/Mid* ¹ / Low/Min

^{*1:}Default Setting

Setup Group	C	Customizable Features	Description	Selectable Settings
		Auto Door Lock	Changes the setting for when the doors automatically lock.	With Vehicle Speed*1/ Shift from P*2/Off
	Door	Auto Door Unlock	Changes the setting for when the doors automatically unlock.	All Doors When Driver's Door Opens*1/ All Doors When Shifted to Park*2/All Doors When Ignition Switched Off/Off
Vehicle		Key And Remote Unlock Mode	Sets up either the driver's door or both doors to unlock on the first push of the remote.	Driver Door*1/All Doors
Settings		Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	On*1/Off
		Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening either door.	90seconds/ 60seconds/ 30seconds*1
	Mainte- nance Info.	Maintenance Reset	Resets the engine oil life display when you have performed the maintenance service.	_
	Default		Cancels/Resets all customized items in the Vehicle Settings group as default.	Yes/No

309

^{*1:}Default Setting
*2:Automatic transmission/CVT models

Setup Group	Customizable Features	Description	Selectable Settings
	Sound	Adjusts the settings of the audio speaker's sound. ▶ Adjusting the Sound P. 197	-6 ~ C*1 ~ +6 (Bass, Treble and SUBW*), -9 ~ C*1 ~ +9 (Fader and Balance), Off/Low/ Mid*1/High (SVC)
	Source Select Popup	Selects whether the list of selectable audio sources comes on when the AUDIO button is pressed.	On/Off*1
Audio Settings	iPod, USB, or Pandora®* mode Cover Art	Turns on and off the cover art display.	On*1/Off
	Bluetooth® Audio or Pandora®* mode Connect Audio	Connects, disconnects or pairs a <i>Bluetooth</i> ® Audio device to HFL.	_
	Bluetooth® Audio or Pandora®* mode Bluetooth Device List	Edits or deletes a <i>Bluetooth</i> ® Audio device paired to HFL.	_
	Default	Cancels/Resets all customized items in the Audio Settings group as default.	Yes/No

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Info Settings	Clock/	Clock Type	See System Settings on P. 304 to P. 305	
	Wall- paper type	Wallpaper		P. 305
	Clock Adjustment			
	Clock Format		<u> </u>	
	Default		Cancels/Resets all customized items in the Info Settings group as default.	Yes/No

Setup Group	Customizable Features		Description	Selectable Settings
Phone Settings	Connect Phone		Pairs a new phone to HFL, connects or disconnects a paired phone. ▶ Phone Setup P. 350	_
	Bluetooth Device List		Pairs a new phone to HFL, edits or deletes a paired phone, or creates a security PIN. ▶ Phone Setup P. 350	_
	Phone	Edit Speed Dial	Edits, adds or deletes a speed dial entry. ▶ Speed Dial P. 361	_
		Auto Transfer	Sets calls to automatically transfer from your phone to HFL when you enter the vehicle.	On*1/Off
		Auto Answer	Sets whether to automatically answer an incoming call after about four seconds.	On/Off*1
		Ring Tone	Selects the ring tone.	Fixed/Mobile Phone*1/Off
		Automatic Phone Sync	Sets a phonebook data to be automatically imported when a phone is paired to HFL.	On*1/Off

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Phone Settings	Text Messages	Enable Text Message	Turns the text message function on and off.	On*1/Off
		New Text Message Alert	Selects whether a pop-up alert comes on the screen when HFL receives a new text message.	On/Off*1
		Message Auto Reading	Sets the system to automatically read an incoming text message. On- A text message is always read aloud. Off- A text message is not read aloud. Auto- A text message is read aloud only when driving.	On/Off/Auto*1
	Default		Cancels/Resets all customized items in the Phone Settings group as default.	Yes/No

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Camera Settings	Rear Camera	Fixed Guideline	Selects whether the fixed guidelines come on the rear camera monitor.	On*1/Off
		Dynamic Guideline	Selects whether the dynamic guidelines come on the rear camera monitor.	On*1/Off
	Default		Cancels/Resets all customized items in the Camera Settings group as default.	Yes/No

^{*1:}Default Setting

Defaulting All the Settings

Reset all the menu and customized settings as the factory defaults.



- **1.** Press the **SETTINGS** button.
- **2.** Rotate [♠] to select **System Settings**, then press [♠].
 - ► Repeat the procedure to select **Other**, then **Factory Data Reset**.
 - ► The confirmation message will appear.
- **3.** Rotate ۞ to select **Yes**, then press ⊗ to reset the settings.
- **4.** Rotate 😚 to select **Yes**, then press 🕉 again to reset the settings.
 - ► The confirmation message will appear. Press 🕹 to select **OK**.

Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

The following settings will be reset:

- Audio preset settings
- Phonebook entries
- Other display and each item settings.


Customized Features

Models with two displays

Use the audio/information touch screen to customize certain features.

■ How to customize

With the ignition switch in ON \boxed{II}^{*1} , select **Settings**, then select a setting item.



○ Customized Features

When you customize settings:

• Make sure that the vehicle is at a complete stop.

Automatic transmission/CVT models

• Shift to P.

Manual transmission models


• Set the parking brake.


To customize other features, select **Settings**.


List of customizable options P. 325

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.


■ Customization flow










319










* Not available on all models



■ List of customizable options

Setup Group	Customizable Features			Description	Selectable Settings	
		Display Settings	Brightness	Changes the brightness of the audio/information touch screen.	_	
			Contrast	Changes the contrast of the audio/information touch screen.	_	
	Display		Black Level	Changes the black level of the audio/information touch screen.	_	
System	Background Color Changes the background color of the audio/ information touch screen.		Blue Green/Blue*1/ Amber/Red/Violet			
		Guidance V	olume	Changes the sound volume. Adjusts the guidance volume of the navigation system.	1~6*1~11	
	Sound/	Text Messa	ge Volume	Adjusts the guidance volume of the navigation system. Changes the text/e-mail message reading volume. 1~6*1~11		
	Beep	Voice Recog. Volume		Changes the volume of the voice prompt.	1~6*1~11	
		Verbal Rem	inder*	Turns the verbal reminders on and off.	On*1/Off	
		Beep Volum	ne	Changes the beep volume.	Off/1/2*1/3	

^{*1:}Default Setting

Setup Group	C	Customizable Features	Description	Selectable Settings	
		Voice Prompt	Turns the voice prompt on and off.	On*1/Off	
		Voice Recog. Volume	Changes the volume of the voice prompt.	1~6* ¹ ~11	
		Song by Voice*	Turns the Song By Voice™ on and off.	On*1/Off	
	Voice	Song by Voice Phonetic Modification*	Modifies a voice command for music stored in the system or an iPod/iPhone. Phonetic Modification P. 260	-	
System	Recog	Phonebook Phonetic Modification	Modifies a voice command for the phonebook. Phonebook Phonetic Modification P. 392	— On/Off	
		Automatic Phone Sync	Sets phonebook and call history data to be automatically imported when a phone is paired to HFL.		
		One Press Voice Operation	Changes the setting of the touch screen operation when using the voice operation.	On/Off*1	

^{*1:}Default Setting

Setup Group	(Customizable F	eatures	Description	Selectable Settings
		Clock/ Wallpaper Type	Clock	Changes the clock display type.	Analog/Digital/ Small Digital*1/Off
	Clock		Wallpaper	Changes the wallpaper type.Imports an image file for a new wallpaper.Deletes an image file for a wallpaper.	Galaxy*¹/Metallic/ Blank
		Clock Adjustment*		Adjusts clock.	_
		Clock Format		Selects the digital clock display from 12H to 24H.	12H*1/24H
System		Auto Time Zone*		Automatically adjusts the clock when driving through different time zones.	On*1/Off
		Manual Time Zone * Changes the time zone manually.	Changes the time zone manually.	_	
		Auto Dayligl	ht	Select On to have the GPS automatically adjust the clock to daylight savings time. Select Off to cancel this function.	On*1/Off
		Clock Display		Selects whether the clock display comes on.	On*1/Off
		Clock Reset		Resets the clock settings to the factory default.	Yes/No

^{*1:}Default Setting

* Not available on all models

Setup Group	Cu	stomizable Features	Description	Selectable Settings
		Language	Changes the display language.	English*¹/French/ Spanish
	Others	Touch Panel Sensitivity	Sets the sensitivity of the touch panel screen.	High/Low*1
System	Others	Detail Information	Displays the Android setting items.	_
3		Factory Data Reset	Resets all the settings to their factory default. Defaulting All the Settings P. 339	Yes/No
	Default		Cancels/Resets all customized items in the System settings group as default.	Yes/No

^{*1:}Default Setting

Setup Group	C	ustomizable Features	Description	Selectable Settings	
Vehicle Settings	TPMS Calibration		Cancels/Calibrates the TPMS.	Cancel*1/Calibrate	
		Forward Collision Warning Distance*	Changes distance the CMBS™ alerts.	Long/Normal*1/ Short	
	ALL FORWARD VANICIA		Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC range.	On/Off*1	
	Driver Assist System Setup*	Assist System	ACC Display Speed Unit*	Changes the speed unit for ACC on the multi- information display.	mph*1/km/h (U.S.) mph/km/h*1 (Canada)
		Road Departure Mitigation Setting*	Changes the setting for the road departure mitigation system.	Normal*¹/Wide/ Warning Only	
		Lane Keeping Assist Suspend Beep*	Causes the system to beep when the LKAS is suspended.	On/Off*1	

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle		Language Selection	Changes the displayed language on the multi- information display.	English*¹/French/ Spanish
		Adjust Outside Temp. Display Adjusts the temperature reading by a few degrees. (U3°)		-5°F ~ ±0°F*1 ~ +5°F (U.S.) -3°C ~ ±0°C*1 ~ +3°C (Canada)
	Meter Setup	"Trip A" Reset Timing	Changes the setting of how to reset trip meter A and average fuel economy A. With Refuel/IGN Off/Manually Reset*1	
		"Trip B" Reset Timing	Changes the setting of how to reset trip meter B and average fuel economy B.	With Refuel/IGN Off/Manually Reset*1
		Fuel Efficiency Backlight	Turns the ambient meter feature on and off.	On*1/Off
		Keyless Start Guidance Screens*	Displays the push button start guidance when conditions are met to change power mode.	On*1/Off

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings	
	Driving Position Setup*	Memory Position Link	Turns the driving position memory system on and off.	On*1/Off	
	Keyless Access Setup*	Door Unlock Mode	Changes which doors unlock when you grab the driver's door handle.	Driver Door Only*1/ All Doors	
Vehicle		Keyless Access Light Flash	Causes some exterior lights to flash when you unlock/lock the doors.	On*1/Off	
		Keyless Access Beep	Causes the beeper to sound when you unlock/lock the doors.	On*1/Off	
		Remote Start System On/ Off*	Turns the remote engine start feature on and off.	On*1/Off	
		Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	60 sec/30 sec*1/ 15 sec	
	Lighting Setup	Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60 sec/30 sec/ 15 sec*1/0 sec	
		Auto Light Sensitivity	Changes the timing for the headlights to come on.	Max/High/Mid* ¹ / Low/Min	

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings	
Vehicle		Auto Door Lock	Changes the setting for when the doors automatically lock.	With Vehicle Speed*1/Shift from P*2/Off	
	Door Setup	Auto Door Unlock	Changes the setting for when the doors automatically unlock.	All Doors When Driver's Door Opens*1/All Doors When Shift to P*2/ All Doors with IGN Off/Off	
	Jetup	Key And Remote Unlock Mode	Sets up either the driver's door or both doors to unlock on the first push of the remote or built-in key.	Driver Door*1/All Doors	
Vemere		Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	On*¹/Off	
		Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening either door.	90 sec/60 sec/30 sec*1	
		Mainte- nance Info.	Maintenance Reset	Resets the engine oil life display when you have performed the maintenance service.	_
	Default		Cancels/Resets all customized items in the Vehicle group as default.	Yes/No	

^{*1:}Default Setting
*2:Automatic transmission/CVT models

Setup Group	Custom	nizable Features	Description	Selectable Settings
Audio		Sound	Adjusts the settings of the audio speakers' sound. ■ Adjusting the Sound P. 232	-6 ~ 0*1 ~ +6 (BASS and TREBLE), RR9~0*1 ~FR9 (FADER), L9~*1 0~R9 (BALANCE), -6 ~ 0*1 ~ +6 (Subwoofer)*, Off/Low/Mid*1/ High (Speed Volume Compensation)
	Common	Audio Source Pop- Up	Selects whether the list of selectable audio source comes on when Audio is selected on the home screen.	On/Off*1
	iPod or USB mode [Your selected media] Turns the cocourt Art	Turns the cover art display on and off.	On*1/Off	
		Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone. ▶ Phone Setup P. 383	_
	FM/AM mode	HD Radio Mode*	Selects whether the audio system automatically switches to the digital radio waves or receives the analogue waves only.	Auto* ¹ /Analog
		RDS INFO	Turns on and off the RDS information.	On*1/Off

^{*1:}Default Setting

^{*} Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings
		Tune Start	Turns on and off, starts the song from the beginning as you change preset stations.	On*1/Off
		SportsFlash Setup(Interrupt)	Turns on and off the sports alert function.	Off*1/ On(one time)/ On(continue)
Audio	SiriusXM® mode	SportsFlash Setup(Interrupt Beep)	Causes the system to beep when the sports alert is notified.	On*1/Off
		SportsFlash Setup(Favorite Team)	Selects your favorite sports teams. Live Sports Alert P. 249	_
		Traffic & Weather Setup	Selects the region you want to receive the information.	_
	Default		Cancels/Resets all customized items in the Audio settings group as default.	Yes/No

^{*1:}Default Setting

Setup Group	Custo	omizable Features	Description	Selectable Settings
	Clock/ Clock Wallpaper Type Wallpaper			
		r		
		Clock Adjustment*	_	
		Clock Format	_	
	Clock	Auto Time Zone*	See System on P. 325	
		Manual Time Zone* Auto Daylight		
Clock/ Info				
IIIIO		Clock Display	<u> </u>	
		Clock Reset		
	HondaLink	Diagnostic & Location Data	Turns HondaLink® on and off.	On/Off
	Other	Info Screen Preference	Changes the information screen type.	Info Top/Info Menu/Off*1
	Default		Cancels/Resets all customized items in the Clock/Info settings group as default.	Yes/No

^{*1:}Default Setting

* Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings	
		Bluetooth Device List	Pairs a new phone to HFL, connects or disconnects a paired phone. Phone Setup P. 383	_	
		Edit Speed Dial	Edits, adds or deletes a speed dial entry. Speed Dial P. 389	_	
	Phone	Ring Tone	Selects the ring tone.	Fixed/Mobile Phone*1	
Phone		Automatic Phone Sync	Sets phonebook and call history data to be automatically imported when a phone is paired to HFL.	On*1/Off	
		HondaLink Assist	Turns HondaLink Assist on and off.	Fixed/Mobile Phone*1	
		Enable Text/Email	Turns the text/e-mail message function on and off.	On*1/Off	
	Text/Email	Select Account	Selects a text or e-mail message account.	On**/Off —	
		New Message Notification	Selects whether a pop-up alert comes on the screen when HFL receives a new text/e-mail messages.	On*1/Off	
	Default		Cancels/Resets all customized items in the Phone settings group as default.	Yes/No	

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Camera	Rear Camera	Fixed Guideline	Selects whether the fixed guidelines come on the rear camera monitor. Multi-View Rear Camera P. 496	On*1/Off
		Dynamic Guideline	Selects whether the dynamic guidelines come on the rear camera monitor. Multi-View Rear Camera P. 496	On*1/Off
		Default	Cancels/Resets all customized items in the Rear Camera setting group as default.	Yes/No
	LaneWatch*	Show with Turn Signal	Selects whether the LaneWatch display comes on when you move the turn signal lever to indicate a right turn.	On*1/Off
		Display Time after Turn Signal Off	Changes the length of time the LaneWatch display stays on after the turn signal lever returns to the center.	0 second* ¹ / 2 seconds
		Reference Line	Selects whether the reference lines come on the LaneWatch monitor.	On*1/Off
		Default	Cancels/Resets all customized items in the LaneWatch group as default.	Yes/No

^{*1:}Default Setting


* Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings
		Bluetooth On/Off Status	Selects to change the <i>Bluetooth</i> ® status.	On*1/Off
	Bluetooth	Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone. Phone Setup P. 383	_
Bluetooth/		Edit Pairing Code	Edits a pairing code. To change the pairing code setting P. 384	Random/Fixed*1
Wi-Fi		Wi-Fi On/Off Status	Changes the Wi-Fi mode.	On/Off*1
	Wi-Fi	Wi-Fi Network List	Connects, disconnects, or deletes the Wi-Fi device.	-
		Wi-Fi Information	Shows the Wi-Fi information of the device.	_
	Default		Cancels/Resets all customized items in the Bluetooth/Wi-Fi group as default.	Yes/No
Smartphone	Apple CarPlay/Android Auto		Sets up the Apple CarPlay/Android Auto connection.	Enable Once/ Always Enable/ Cancel

^{*1:}Default Setting

Defaulting All the Settings

Reset all the menu and customized settings as the factory defaults.



- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Others** tab.
- 5. Select Factory Data Reset.
 - A confirmation message appears on the screen.
- **6.** Select **Yes**.
- **7.** Select **Yes** again to reset the settings.
 - After selecting **Yes**, the system will reboot.

Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

If you perform **Factory Data Reset**, it will reset the preinstalled apps to their factory default.

If you perform **Factory Data Reset**, you cannot use HondaLink® because it becomes inactive and you will have to reconnect.

▶ HondaLink® P. 270

HomeLink® Universal Transceiver*

The HomeLink® Universal Transceiver can be programmed to operate up to three remote controlled devices around your home, such as garage doors, lighting, or home security systems.

■ Important Safety Precautions

Refer to the safety information that came with your garage door opener to test that the safety features are functioning properly. If you do not have the safety information, contact the manufacturer.

Before programming HomeLink, make sure that people and objects are out of the way of the garage or gate to prevent potential injury or damage.

When programming a garage door opener, park just outside the garage door's path.

≫HomeLink® Universal Transceiver*

Before programming HomeLink to operate a garage door opener, confirm that the opener has an external entrapment protection system, such as an "electronic eye," or other safety and reverse stop features. If it does not, HomeLink may not be able to operate it.

Training HomeLink




If it is necessary to erase a previously entered learned code:

- Press and hold the two outside buttons for about 20 seconds, until the red indicator blinks. Release the buttons, and proceed to step 1.
- If you are training the second or third button, go directly to step 1.

The instructions on the next page should work for most gate or garage openers, but may not work for all. For detailed instructions about your specific remote opener, visit http://www.homelink.com or call (800)355-3515.

■ Training a Button

- Position the remote transmitter you wish to link 1 to 3 inches (3 8 cm) from the HomeLink button you want to program.
- 2. Press and release the desired HomeLink button. Hold the button on the remote transmitter. Does the HomeLink indicator (LED) change from slowly blinking to constantly on or rapidly blinking? The process should take less than 60 seconds.



4. Press and hold the HomeLink button again.

HomeLink LED is

constantly on.

5. Press and hold the Homelink

Training

Complete

button again. The remote-controlled device should operate.

Training Complete

HomeLink indicator rapidly blinks.

A. The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g. garage door opener).

B. Within 30 secs, press and hold the programmed HomeLink button for 2 secs.

>> Training HomeLink

NO

Retraining a Button

If you want to retrain a programmed button for a new device, you do not have to erase all button memory. You can replace the existing memory code using this procedure:

1. Press and hold the desired HomeLink button until the HomeLink indicator begins to blink.

Standard transmitter Indicator remains on for about 25 secs

Rolling code transmitter Indicator remains on for about 25 secs.

2. Quickly release the HomeLink button and follow steps 1 - 3 under "Training a Button." You do not need to press and release the HomeLink button again in step 2.

Erasing Codes

To erase all the codes, press and hold the two outside buttons until the HomeLink indicator begins to blink (about 10 to 20 secs). You should erase all codes before selling the vehicle.

If you have any problems, see the device's instructions, visit www.homelink.com, or call HomeLink at (800) 355-3515.


HomeLink® is a registered trademark of Gentex Corporation.

Models with one display

Bluetooth® HandsFreeLink® (HFL) allows you to place and receive phone calls using your vehicle's audio system, without handling your cell phone.

Using HFL

■ HFL Buttons



(Pick-up) button: Press to answer an incoming call.

(Hang-up/back) button: Press to end a call or to cancel a command.

(Talk) button: Press to call a number with a stored voice tag, a phonebook name, or a number.

PHONE button: Press to go directly to the Phone screen.

Selector knob: Rotate ♥ to select an item on the screen, then press ८.

>> Bluetooth® HandsFreeLink®

To use HFL, you need a *Bluetooth*-compatible cell phone. For a list of compatible phones, pairing procedures, and special feature capabilities:

- U.S.: Visit www.handsfreelink.honda.com, or call 1-888-528-7876.
- Canada: Visit www.handsfreelink.ca, or call 1-888-528 -7876.

To use HFL, the **Bluetooth On/Off** setting must be **On**. **Quality Customized Features** P. 298

Voice control tips


- Aim the vents away from the ceiling and close the windows, as noise coming from them may interfere with the microphone.
- Press and release the 🔟 button when you want to call a number using a stored voice tag, a phonebook name, or a number. Speak clearly and naturally after a beep.
- If the microphone picks up voices other than yours, the command may be misinterpreted.
- To change the volume level, use the audio system's volume knob or the remote audio controls on the steering wheel.

State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle.

If you receive a call while using the audio system, the system resumes its operation after ending the call.

HFL Status Display

The audio/information screen notifies you when there is an incoming call.



■ Limitations for Manual Operation



Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

Only previously stored speed dial entries with voice tags, phonebook names, or numbers can be called using voice commands while the vehicle is in motion.

Speed Dial P. 361

>> Bluetooth® HandsFreeLink®

Bluetooth® Wireless Technology

The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Honda Motor Co., Ltd., is under license. Other trademarks and trade names are those of their respective owners.

HFL Limitations

An incoming call on HFL will interrupt the audio system when it is playing. It will resume when the call is ended.

Place your phone where you can get good reception.

► MFL Status Display

The information that appears on the audio/information screen varies between phone models.

You can change the system language to English, French, or Spanish.

Customized Features P 298

HFL Menus

The ignition switch must be in ACCESSORY I or ON III*1 to use HFL.

■ Phone Settings screen




- **1.** Press the **SETTINGS** button.


>> HFL Menus

To use HFL, you must first pair your *Bluetooth*-compatible cell phone to the system while the vehicle is parked.


Some functions are limited while driving. A message appears on the screen when the vehicle is moving and the operation is canceled.



- *1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.
- *2: Appears when a phone has already been paired to HFL.



^{*1:} Appears only when a phone is connected to HFL.




^{*1:} Appears only when a phone is connected to HFL.


■ Phone menu screen



- 1. Press the **PHONE** button.
- **2.** Press the **MENU** button to display the menu items.



*1: Appears only when a phone is connected to HFL.



^{*1:} Appears only when a phone is connected to HFL.

■ Phone Setup



- To pair a cell phone (when there is no phone paired to the system)
- 1. Press the **PHONE** button.
- **2.** Rotate to select **Yes**, then press .
- **3.** Make sure your phone is in search or discoverable mode, then press ᇫ.
 - ► HFL automatically searches for a Bluetooth device.
- **4.** When your phone appears on the list, select it by pressing *᠖*.
 - ► If your phone does not appear, you can select **Refresh** to search again.
 - ► If your phone still does not appear, select Phone Not Found and search for Bluetooth devices using your phone. From your phone, select

HandsFreeLink

- **5.** HFL gives you a pairing code on the audio/ information screen.
 - Confirm if the pairing code on the screen and your phone match.
 This may vary by phone.
- **6.** You will receive a notification on the screen if pairing is successful.

▶ Phone Setup

Your *Bluetooth*-compatible phone must be paired to HFL before you can make and receive hands-free calls.

Phone Pairing Tips:

- You cannot pair your phone while the vehicle is moving.
- Up to six phones can be paired.
- Your phone's battery may drain faster when it is paired to HFL.
- If your phone is not ready for pairing or not found by the system within three minutes, the system will time out and returns to idle.

Once you have paired a phone, you can see it displayed on the screen with one or two icons on the right side.

These icons indicate the following:

- : The phone can be used with HFL.
- **I**: The phone is compatible with *Bluetooth*® Audio.

When pairing is completed, an **Automatic Phone Sync** prompt appears. Select **On** if you want your call history and phonebook automatically imported to
HEI

Changing the Automatic Phone Sync setting P. 360



- To pair a cell phone (when a phone has already been paired to the system)
- 1. Go to the Phone Settings screen.

 ▶ Phone Settings screen P. 345
- **2.** Rotate ♥ to select **Connect Phone**, then press ♥.
 - ► Repeat the procedure to select **Add Bluetooth Device**.
- **3.** Make sure your phone is in search or discoverable mode, then press *᠖*.
 - ► HFL automatically searches for a *Bluetooth* device.
- **4.** When your phone appears on the list, select it by pressing ⊗.
 - ► If your phone does not appear, you can select **Refresh** to search again.
 - If your phone still does not appear, select

 Phone Not Found and search for

 Bluetooth devices using your phone.

 From your phone, select

 HandsFreeLink.
- **5.** HFL gives you a pairing code on the audio/ information screen.
 - ➤ Confirm if the pairing code on the screen and your phone match.

 This may vary by phone.
- **6.** You will receive a notification on the screen if pairing is successful.



■ To change the pairing code setting

- **1.** Press the **SETTINGS** button.
- **2.** Rotate ♥ to select **System Settings**, then press ♥.
 - ► Repeat the procedure to select **Bluetooth**, then **Edit Pairing Code**.
- **3.** Rotate ♥ to select **Fixed** or **Random**, then press ♥.

∑To change the pairing code setting

The pairing code may be six or four digits depending on your phone.

The default pairing code is **0000** until you change the setting.

To create your own, select **Fixed**, and delete the current code, then enter a new one.

For a randomly generated pairing code each time you pair a phone, select **Random**.



■ To replace an already-paired phone with a new phone

- 1. Go to the Phone Settings screen.

 ▶ Phone Settings screen P. 345
- **2.** Rotate ⊘ to select **Bluetooth Device List**, then press ⊘.
- **3.** Rotate ♥ to select a paired phone you want to replace, then press ♥.
- **4.** Rotate ♥ to select **Replace This Device**, then press ♥.
- **5.** HFL enters the pairing process and searches a new phone.
 - Follow the prompts to pair a new phone.
- **6.** You will receive a notification on the screen if pairing is successful.

™To replace an already-paired phone with a new phone

The replaced phone will keep the same speed dial entries, call history, and security PIN information from the previously paired phone.



■ To delete a paired phone

- **1.** Go to the **Phone Settings** screen. **▶ Phone Settings screen** P. 345
- **2.** Rotate [®] to select **Bluetooth Device List**, then press ⊗.
- **3.** Rotate ♥ to select a phone you want to delete, then press ८.
- **4.** Rotate '♥ to select **Delete This Device**, then press ८.
- **5.** You will receive a confirmation message on the screen. Rotate [♠] to select **Yes**, then press [♠].
- **6.** You will receive a notification on the screen if it is successful.

■ To Set Up Text Message Options



- To turn on or off the text message function
- **1.** Go to the **Phone Settings** screen. **▶ Phone Settings screen** P. 345
- **2.** Rotate ♥ to select **Text Messages**, then press ♥.
 - ► Repeat the procedure to select **Enable Text Message**.
 - A pop-up menu appears on the screen.
- **3.** Rotate ۞ to select **On** or **Off**, then press ⑤.



■ To turn on or off the text message notice

- 1. On the **Text Messages** screen, rotate [™] to select **New Text Message Alert**, then press [™].
- 2. Rotate ♥ to select **On** or **Off**, then press ⑤.



■ To set up the auto reading option

- 1. On the **Text Messages** screen, rotate 'ô' to select **Message Auto Reading**, then press ᇫ.
 - ► A pop-up menu appears on the screen.
- **2.** Rotate 🌣 to select **On**, **Off** or **Auto** then press 🕹.

∑To turn on or off the text message notice

On: A pop-up notification comes on every time you receive a new message.

Off: The message you receive is stored in the system without notification.

∑To set up the auto reading option

On: A text message is always read aloud. **Off**: A text message is not read aloud.

Auto: A text message is read aloud only when driving.

■ To Create a Security PIN

You can protect each of the six cell phones with a security PIN.



- **1.** Go to the **Phone Settings** screen. **▶ Phone Settings screen** P. 345
- **2.** Rotate ⊘ to select **Bluetooth Device List**, then press ⊘.
- **3.** Rotate ⊘ to select a phone you want to add a security PIN to, then press ⊗.
- **4.** Rotate ♥ to select **Edit PIN**, then press ८.
- **5.** Enter a new four-digit number.
 - ► Rotate 😙 to select, then press 🕃.

 Press 🔀 to delete. Press **OK** to enter the security PIN.
- **6.** Re-enter the four-digit number.
 - ► The screen returns to the screen in step 4.

■To Create a Security PIN

If the phone is already security PIN protected, you need to enter the current security PIN before clearing the PIN or creating a new one.

Automatic Transferring

If you get into the vehicle while you are on the phone, the call can be automatically transferred to HFL.



- 1. Go to the Phone Settings screen.

 ▶ Phone Settings screen P. 345
- **2.** Rotate roto select **Phone**, then press s.
 - Repeat the procedure to select **Auto Transfer**.
- **3.** Rotate ♥ to select **On**, then press ८.

Auto Answer


You can set HFL to automatically answer an incoming call in four seconds.



- **1.** Go to the **Phone Settings** screen.
 - ➡ Phone Settings screen P. 345
- **2.** Rotate ♥ to select **Phone**, then press ८.
 - Repeat the procedure to select **Auto Answer**.
- **3.** Rotate ♥ to select **On**, then press ८.

Ring Tone

You can change the ring tone setting.



- 1. Go to the Phone Settings screen.

 ▶ Phone Settings screen P. 345
- **2.** Rotate 😙 to select **Phone**, then press 🕹 .
 - ➤ Repeat the procedure to select **Ring Tone**.
- **3.** Rotate 🎅 to select **Fixed**, **Mobile Phone** or **Off**, then press 💆.

Ring Tone


Fixed: The fixed ring tone sounds from the speaker. **Mobile Phone**: The ring tone stored in the connected cell phone sounds from the speaker. **Off**: No ring tones sound from the speaker.

Automatic Import of Cellular Phonebook and Call History



■ When Automatic Phone Sync is set to On:

When your phone is paired, the contents of its phonebook and call history are automatically imported to HFL.



- 1. Go to the Phone Settings screen.

 ▶ Phone Settings screen P. 345
- **2.** Rotate 🛜 to select **Phone**, then press ℧.
 - ► Repeat the procedure to select **Automatic Phone Sync**.
- **3.** Rotate ♥ to select **On** or **Off**, then press ♥.

■ Automatic Import of Cellular Phonebook and Call History

When you select a person from the list in the cellular phonebook, you can see up to three category icons. The icons indicate what types of numbers are stored for that name.



On some phones, it may not be possible to import the category icons to HFL.

The phonebook is updated after every connection. Call history is updated after every connection or call.



Speed Dial

Up to 20 speed dial numbers can be stored per phone.



To store a speed dial number:

- 1. Go to the **Phone menu** screen.

 Phone menu screen P. 348
- **2.** Rotate [♠] to select **Speed Dial**, then press [♠].
 - Repeat the procedure to select New Entry.
- 3. Rotate ♂ to select a place to choose a number from, then press ૱.

 From Import from Call History:
 - ➤ Select a number from the call history. From **Manual Input**:
 - ► Input the number manually. From Import from Phonebook:
 - rom Import from Phonebook:
 - Select a number from the linked cell phone's imported phonebook.
- **4.** When the speed dial is successfully stored from **Import from Call History** or **Import from Phonebook**, you are asked to create a voice tag for the number. Rotate to select **Yes** or **No**, then press る.
- **5.** Using the button, follow the prompts to store a voice tag for the speed dial entry.

Speed Dial

When a voice tag is stored, press the \(\) button to call the number using the voice tag. Say "Call" and the voice tag name.



■ To add a voice tag to a stored speed dial number

- 1. Go to the Phone Settings screen.

 ▶ Phone Settings screen P. 345
- **2.** Rotate '♠' to select **Phone**, then press ८.
 - Repeat the procedure to select Edit Speed Dial.
- 3. Select an existing speed dial entry.
 - ► From the pop-up menu, rotate 😙 to select **Edit**, then press 🕹.
- **4.** Rotate ♥ to select **Voice Tag**, then press ⑤.
 - ► From the pop-up menu, rotate 😙 to select **Record**, then press 🕹.
- **5.** Using the button, follow the prompts to complete the voice tag.

Speed Dial

Avoid using duplicate voice tags. Avoid using "home" as a voice tag. It is easier for HFL to recognize a longer name. For example, use "John Smith" instead of "John."



■ To delete a voice tag

- 1. Go to the Phone Settings screen.

 ▶ Phone Settings screen P. 345
- **2.** Rotate ♥ to select **Phone**, then press ८.
 - Repeat the procedure to select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - ► From the pop-up menu, rotate 😚 to select **Edit**, then press 🕹.
- **4.** Rotate ♥ to select **Voice Tag**, then press ♦.
 - ► From the pop-up menu, rotate 😙 to select **Clear**, then press 🕹.
- **5.** You will receive a confirmation message on the screen. Rotate [™] to select **Yes**, then press [™].

■ To delete a speed dial

- **1.** Go to the **Phone Settings** screen.
 - **▶ Phone Settings screen** P. 345
- **2.** Rotate 😙 to select **Phone**, then press 🕹.
 - ► Repeat the procedure to select **Edit Speed Dial**.
- **3.** Select an existing speed dial entry.
 - ► From the pop-up menu, rotate 😙 to select **Delete**, then press 🕹.
- **4.** You will receive a confirmation message on the screen. Rotate '♥' to select **Yes**, then press ♥.



■ Making a Call



You can make calls by inputting any phone number, or by using the imported phonebook, call history, speed dial entries, or redial.

Any voice-tagged speed dial entry, phonebook name, or number can be dialed by voice from most screens. Press the button and say "Call" and the phonebook name, phone number, or stored voice tag.

The maximum range between your phone and vehicles is 30 feet (10 meters).

Once a call is connected, you can hear the voice of the person you are calling through the audio speakers.



■ To make a call using the imported phonebook

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 348
- **2.** Rotate 🌣 to select **Phonebook**, then press 🌣.
- **3.** Rotate ♂ to select a name, then press ゑ.
 - ▶ You can also search by letter. Rotate 🗇 to select **Alphabet Search**, then press 🗸.
- - ▶ Dialing starts automatically.

■ To make a call using the imported phonebook

This function is disabled while the vehicle is moving. However, you can call a stored voice-tagged speed dial number, phonebook name, or number using voice commands.

- **Limitations for Manual Operation** P. 344
- Speed Dial P. 361





■ To make a call using a phone number

- 1. Go to the **Phone menu** screen.
 - Phone menu screen P 348
- **2.** Rotate ♥ to select **Dial**, then press ८.
- **3.** Rotate roto select a number, then press
- **4.** Rotate ♥ to select **∠**, then press ८. ▶ Dialing starts automatically.

■ To make a call using redial

- 1. Go to the **Phone menu** screen ▶ Phone menu screen P. 348
- 2. Rotate ♥ to select **Redial**, then press ८.
 - ▶ Dialing starts automatically.

∑To make a call using a phone number

This function is disabled while the vehicle is moving. However, you can call a stored voice-tagged speed dial number, phonebook name, or number using voice commands.

▶ Limitations for Manual Operation P. 344

Speed Dial P. 361



■ To make a call using the call history Call history is stored by All, Dialed, Received, and Missed.

- 1. Go to the **Phone menu** screen.
- **2.** Rotate 🎅 to select **Call History**, then press 🎖.
- **3.** Rotate '♥' to select **All**, **Dialed**, **Received**, or **Missed**, then press ⊗.
- **4.** Rotate ♂ to select a number, then press ૱.
 - ▶ Dialing starts automatically.



- **1.** Go to the **Phone menu** screen.
 - **▶ Phone menu screen** P. 348
- **2.** Rotate [♠] to select **Speed Dial**, then press [♠].
- 3. Rotate ♂ to select a number, then press る.

 Dialing starts automatically.

∑To make a call using the call history

The call history displays the last 20 dialed, received, or missed calls.

(Appears only when a phone is connected to HFL.)

■To make a call using a speed dial entry

Select **More Speed Dials** to view another paired phone's speed dial list. You can make a call from that list using the currently connected phone.

When a voice tag is stored, press the 🛍 button to call the number using the voice tag.

Speed Dial P. 361

Any voice-tagged speed dial entry, phonebook name, or number can be dialed by voice from any screen. Press the £ button and follow the prompts.

To call stored speed dial entries 1-6, press the corresponding preset buttons from the **Phone** screen.



Receiving a Call



When there is an incoming call, an audible notification sounds (if activated) and the **Incoming Call** screen appears.

Press the button to answer the call.

Press the button to decline or end the call.

■ Receiving a Call

Call Waiting

Press the <u>C</u> button to put the current call on hold to answer the incoming call.

Press the **\(\subseteq \)** button again to return to the current call.

Ignore the incoming call if you do not want to answer it

Press the button if you want to hang up the current call.

■ Options During a Call

The following options are available during a call.

Mute: Mute your voice.

Transfer: Transfer a call from HFL to your phone.

Touch Tones: Send numbers during a call. This is useful when you call a menu-

driven phone system.



Press the **MENU** button to display the options. Rotate to select the mute option, then press .

➤ The mute icon appears when **Mute** is selected. Select **Mute** again to turn it off.

≥Options During a Call

Touch Tones: Available on some phones.

Receiving a Text Message

HFL can display newly received text messages as well as 20 of the most recently received messages on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase.



- **1.** A pop-up appears and notifies you of a new text message.
- 2. Rotate ♂ to select **Read** to listen to the message, then press ⑤.
 - ➤ The text message is displayed. The system automatically starts reading out the message.
- **3.** To discontinue the message read-out, press \mathfrak{S} .

■ Receiving a Text Message

The system does not display any received messages while you are driving. You can only hear them read aloud.

With some phones, you may be able to display up to 20 most recent text messages.

State or local laws may limit your use of the HFL text message feature. Only use the text message feature when conditions allow you to do so safely.

When you receive a text message for the first time after the phone is paired to HFL, you are asked to turn the **New Text Message Alert** setting to **On**.

▶ To turn on or off the text message notice P. 356



Displaying Text Messages



- 1. Press the **PHONE** button.
- 2. Press the **MENU** button.
- **3.** Rotate ۞ to select **Text Messages**, then press ፩.
- **4.** Rotate ♂ to select a message, then press ⑤.
 - ➤ The text message is displayed. The system automatically starts reading the message aloud.


Displaying Text Messages

The $\ \ \ \ \ \ \ \ \ \$ icon appears next to an unread message.

If you delete a message on the phone, the message is also deleted in the system. If you send a message from the system, the message goes to your phone's outbox.

To see the previous or next message, press $\stackrel{\smile}{\omega}$ on the text message screen. From the pop-up menu, rotate $\stackrel{\smile}{\varpi}$ to select **Previous Message** or **Next Message**, then press $\stackrel{\smile}{\omega}$.





☐ Text messages

Reply

I'm on my way.
I'm running late.

Talk to you later, I'm driving

12:34

12:34

Stop

Reply

Call

Next Message

■ Using the Stop or Read option

- **1.** Go to the text message screen.
 - ► The system automatically starts reading the message aloud.
 - Displaying Text Messages P. 371
- **2.** Press 💍 to have the pop-up menu appear on the screen.
- **3.** Rotate '♥ to select **Stop** or **Read**, then press ८.

■ Reply to a message

- **1.** Go to the text message screen.
 - ► The system automatically starts reading the message aloud.
 - Displaying Text Messages P. 371
- **2.** Press 💍 to have the pop-up menu appear on the screen.
- **3.** Rotate ♥ to select **Reply**, then press ८.
- **4.** Rotate ♂ to select the reply message, then press ♂.
 - ► The pop-up menu appears on the screen.
- **5.** Select **Send** to send the message.
 - ► **Complete** appears on the screen when the reply message was successfully sent.

Substitution Stop or Read option Substitution Substit

This option changes to:

- **Stop** while the text message is read out. Select this option to discontinue the message read out.
- Read when the system has finished reading out the text message, or after you selected Stop.
 Select this option to hear the system read out the selected message.

■ Reply to a message

The available fixed reply messages are as follows:

- Talk to you later, I'm driving.
- I'm on my way.
- I'm running late.
- OK
- Yes
- No

You cannot add, edit, or delete reply messages.



■ Making a call to a sender

- **1.** Go to the text message screen.
 - ► The system automatically starts reading the message aloud.

Displaying Text Messages P. 371


- **2.** Press ⊘ to have the pop-up menu appear on the screen.
- **3.** Rotate ⑦ to select **Call**, then press ♂.

Models with two displays

Bluetooth® HandsFreeLink® (HFL) allows you to place and receive phone calls using your vehicle's audio system, without handling your cell phone.

Using HFL

■ HFL Buttons



>> Bluetooth® HandsFreeLink®

To use HFL, you need a *Bluetooth*-compatible cell phone. For a list of compatible phones, pairing procedures, and special feature capabilities, ask a dealer or your local Honda.

To use the system, the **Bluetooth On/Off Status** setting must be **On**. If there is an active connection to Apple CarPlay or Android Auto, HFL is unavailable.

How to customize P 316

Voice control tips

- Aim the vents away from the ceiling and close the windows, as noise coming from them may interfere with the microphones.
- Press the button when you want to call a number using a stored voice tag. Speak clearly and naturally after a beep.
- If the microphones pick up voices other than yours, the command may be misinterpreted.
- To change the volume level, select the audio system's VOL (Volume) or use the remote audio controls on the steering wheel.

Up to five speed dial entries can be displayed among a total of 20 that can be entered. If there is no entry in the system, Speed Dial is disabled.

Speed Dial P. 389

Up to five call histories can be displayed among a total of 20 that can be entered. If there is no call history, Call History is disabled.

(Pick-up) button: Press to go directly to the phone screen, or to answer an incoming call.

(Hang-up/back) button: Press to end a call, go back to the previous command, or cancel a command.

(Talk) button: Press to call a number with a stored voice tag.

MENU button: Press to display **Speed Dial**, **Call History**, or **Redial** on the phone screen.

To go to the **Phone menu** screen:

- 1. Select
- **2.** Select **Phone** to switch the display to the phone screen.
- 3. Select 🖳.

>> Bluetooth® HandsFreeLink®

Bluetooth® Wireless Technology

The *Bluetooth*® word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc., and any use of such marks by Honda Motor Co., Ltd., is under license. Other trademarks and trade names are those of their respective owners.


HFL Limitations

An incoming call on HFL will interrupt the audio system when it is playing. It will resume when the call is ended.

Place your phone where you can get good reception.

■ HFL Status Display

The audio/information screen and audio/information touch screen notify you when there is an incoming call.



The information that appears on the audio/information screen and audio/information touch screen varies between phone models.

You can change the system language.

How to customize P. 316

■ Limitations for Manual Operation

Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

Only previously stored speed dial entries with voice tags, phonebook names, or numbers can be called using voice commands while the vehicle is in motion.

Speed Dial P. 389

HFL Menus

The ignition switch must be in ACCESSORY \boxed{I} or ON \boxed{II}^{*1} to use the system.

■ Phone settings screen




- 1. Select
- 2. Select Settings.
- 3. Select Phone.


> HFI Menus


To use HFL, you must first pair your *Bluetooth*-compatible cell phone to the system while the vehicle is parked.

Some functions are limited while driving.



^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.







■ Phone menu screen




- 1. Select
- 2. Select Phone
- 3. Select 🖳





■ Phone Setup



- To pair a cell phone (when there is no phone paired to the system)
- 1. Select Phone.
- 2. Select Yes.
- **3.** Make sure your phone is in search or discoverable mode, then select **Continue**.
 - ► HFL automatically searches for a Bluetooth® device.
- **4.** Select your phone when it appears on the list.
 - ► If your phone does not appear, you can select **Refresh** to search again.
 - ▶ If your phone still does not appear, select Phone Not Found and search for Bluetooth® devices using your phone. From your phone, search for HandsFreeLink.
- **5.** The system gives you a pairing code on the audio/information touch screen.
 - Confirm if the pairing code on the screen and your phone match.
 This may vary by phone.

∑Phone Setup

Your *Bluetooth*-compatible phone must be paired to the system before you can make and receive handsfree calls.


Phone Pairing Tips:

- You cannot pair your phone while the vehicle is moving.
- Up to six phones can be paired.
- Your phone's battery may drain faster when it is paired to the system.
- If your phone is not ready for pairing or not found by the system within three minutes, the system will time out and return to idle.

If there is an active connection to Apple CarPlay or Android Auto, pairing of additional *Bluetooth*compatible devices is unavailable and **Add Bluetooth Device** is grayed out from the **Bluetooth Device List** screen.



Wi-Fi



- **1.** Go to the **Phone settings** screen.
 - **Phone settings screen** P. 378
- 2. Select Bluetooth Device List
- **3.** Select a phone to connect.
 - ► HFL disconnects the connected phone and starts searching for another paired phone.
- **4.** Select **Connect** , or Connect ...

■ To change the pairing code setting

- 1. Select
- 2. Select Settings.
- 3. Select Bluetooth/Wi-Fi
- **4.** Select the **Bluetooth** tab
- **5.** Select **Edit Pairing Code**.



∑To change the currently paired phone

If no other phones are found or paired when trying to switch to another phone, HFL will inform you that the original phone is connected again.


To pair other phones, select **Add Bluetooth Device** from the Bluetooth device list screen

∑To change the pairing code setting

The default pairing code is **0000** until you change the setting.

To create your own, select **Fixed**, and delete the current code, then enter a new one.

For a randomly generated pairing code each time you pair a phone, select Random.



Bluetooth/Wi-Fi settings

385




■ To delete a paired phone

- **1.** Go to the **Phone settings** screen. **▶ Phone settings screen** P. 378
- 2. Select Bluetooth Device List.
- 3. Select a phone you want to delete.

- 4. Select **Delete**
- **5.** A confirmation message appears on the screen. Select **Yes**.

■ To Set Up Text Message/E-mail Options





- To turn on or off the text/e-mail function
- 1. Go to the **Phone settings** screen.

 ▶ **Phone settings screen** P. 378
- 2. Select the **Text/Email** tab, then **Enable Text/Email**.
 - A pop-up menu appears on the screen.
- **3.** Select **On** or **Off**.
- To turn on or off the text/e-mail notice
- **1.** Go to the **Phone settings** screen.
 - **▶ Phone settings screen** P. 378
- 2. Select the **Text/Email** tab, then **New Message Notification**.
 - ► A pop-up menu appears on the screen.
- 3. Select On or Off.

■To Set Up Text Message/E-mail Options

To use the text message/e-mail function, it may be necessary to set up on your phone.

>> To turn on or off the text/e-mail notice

On: A pop-up notification comes on every time you receive a new message.

Off: The message you receive is stored in the system without notification.

Ring Tone

You can change the ring tone setting.



- **1.** Go to the **Phone settings** screen. **▶ Phone settings screen** P. 378
- 2. Select Ring Tone.
- 3. Select Fixed or Mobile Phone.

Fixed: The fixed ring tone sounds from the speakers. **Mobile Phone**: The ring tone stored in the connected cell phone sounds from the speakers.

Automatic Import of Cellular Phonebook and Call History



■ When Automatic Phone Sync is set to On:

When your phone is paired, the contents of its phonebook and call history are automatically imported to the system.



- Changing the Automatic Phone Sync setting
- 1. Go to the Phone settings screen.

 ▶ Phone settings screen P. 378
- 2. Select Automatic Phone Sync.

3. Select On or Off.

Matter Automatic Import of Cellular Phonebook and Call History

When you select a name from the list in the cellular phonebook, you can see up to three category icons. The icons indicate what types of numbers are stored for that name.



On some phones, it may not be possible to import the category icons to the system.

The phonebook is updated after every connection. Call history is updated after every connection or call.

Speed Dial

Up to 20 speed dial numbers can be stored per phone.



To store a speed dial number:

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 381
- 2. Select Speed Dial.
- 3. Select New Entry.

From Import from Call History:

► Select a number from the call history.

From **Manual Input**:

▶ Input the number manually.

From Import from Phonebook:

- Select a number from the connected cell phone's imported phonebook.
- **4.** When the speed dial is successfully stored, you are asked to create a voice tag for the number. Select **Yes** or **No**.

- **5.** Select **Record** to store a voice tag for the speed dial entry.
 - ► Using the ② button, follow the prompts to store a voice tag for the speed dial entry.

Speed Dial

When a voice tag is stored, press the 😥 button to call the number using the voice tag. Say the voice tag name.



■ To add a voice tag to a stored speed dial number

- 1. Go to the Phone settings screen.

 ▶ Phone settings screen P. 378
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - From the pop-up menu, select **Edit**.
- 4. Select Voice Tag.
 - From the pop-up menu, select **Record**.
- **5.** Select **Record**, or use the <u>6</u> button and follow the prompts to complete the voice tag.

■ To delete a voice tag

- **1.** Go to the **Phone settings** screen.
 - **▶ Phone settings screen** P. 378
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - From the pop-up menu, select **Edit**.
- **4.** Select **Voice Tag**.
 - From the pop-up menu, select **Clear**.
- **5.** A confirmation message appears on the screen. Select **Yes**.

Speed Dial

Avoid using duplicate voice tags.

Avoid using "home" as a voice tag.

It is easier for the system to recognize a longer name.

For example, use "John Smith" instead of "John."



Play

Record

Edit Speed Dial



■ To edit a speed dial

- **1.** Go to the **Phone settings** screen. **▶ Phone settings screen** P. 378
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - From the pop-up menu, select **Edit**.
- **4.** Select a setting you want.

■ To delete a speed dial


- 1. Go to the Phone settings screen.

 ▶ Phone settings screen P. 378
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.

 ▶ From the pop-up menu, select **Delete**.
- **4.** A confirmation message appears on the screen. Select **Yes**.

■ Phonebook Phonetic Modification

Add phonetic modifications or a new voice tag to the phone's contact name so that it is easier for HFL to recognize voice commands.




■ To add a new voice tag

- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- **5.** Select **Phonebook Phonetic Modification**.
- **6.** Select the phone you want to add phonetic modification to.

≥ Phonebook Phonetic Modification

You can store up to 20 phonetic modification items.



- 7. Select New Voice Tag.
- **8.** Select a contact name you want to add to.
 - The pop-up menu appears on the screen.
- 9. Select Modify.
- **10.** Using **Record** or the button, follow the prompts to complete the voice tag.
- **11.** You will receive a confirmation message on the screen, then select **OK**.



■ To modify a voice tag

- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Phonebook Phonetic Modification.
- **6.** Select the phone you want to modify phonetic modification.
- **7.** Select a contact name you want to modify.
 - ► The pop-up menu appears on the screen.
- **8.** Select **Modify**.
- **9.** Using **Record** or the button, follow the prompts to complete the voice tag.
- **10.** You will receive a confirmation message on the screen, then select **OK**.

∑Phonebook Phonetic Modification

You can only modify or delete contact names for the currently connected phone.



■ To delete a modified voice tag

- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Phonebook Phonetic Modification
- **6.** Select the phone you want to delete phonetic modification.
- 7. Select a contact name you want to delete.
 - ▶ The pop-up menu appears on the screen.
- 8. Select **Delete**.
 - ► The selected contact name has been selected.
- 9. Select OK.



■ To delete all modified voice tags

- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Phonebook Phonetic Modification
- **6.** Select the phone you want to delete phonetic modification.
 - ► The contact name list appears.
- 7. Select **Delete All**
- **8.** You will receive a confirmation message on the screen, then select **Yes**.

■ Making a Call



You can make calls by inputting any phone number, or by using the imported phonebook, call history, speed dial entries, or redial.

Any voice-tagged speed dial entry can be dialed by voice from most screens.

Press the 🛍 button and say the voice tag name.

Once a call is connected, you can hear the voice of the person you are calling through the audio speakers.

While there is an active connection with Apple CarPlay or Android Auto, phone calls cannot be made with *Bluetooth*® HandsFreeLink® and are only made from Apple CarPlay or Android Auto.





■ To make a call using the imported phonebook

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 381
- 2. Select Phonebook.
- 3. Select a name.
 - You can also search by letter. Select **Search**.
 - Use the keyboard on the touch screen for entering name, if multiple numbers exist select a number.
- **4.** Select a number.
 - ▶ Dialing starts automatically.


■ To make a call using a phone number

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 381
- 2. Select Dial.
- 3. Select a number.
 - Use the keyboard on the touch screen for entering numbers.
- 4. Select Dial.
 - ▶ Dialing starts automatically.



■ To make a call using redial

- 1. Go to the **Phone menu** screen. P. 381
- 2. Select Redial.
 - Dialing starts automatically.



■ To make a call using the Call History Call history is stored by All, Dialed,

Received, and Missed.

- **1.** Go to the **Phone menu** screen. **▶ Phone menu screen** P. 381
- **2.** Select **Call History**.
- 3. Select All, Dialed, Received, or Missed.
- **4.** Select a number.
 - ▶ Dialing starts automatically.

■ To make a call using a Speed Dial entry

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 381
- 2. Select Speed Dial.
- 3. Select a number.
 - ▶ Dialing starts automatically.

∑To make a call using redial

Press and hold the button to redial the last number dialed.

∑To make a call using the Call History

The call history displays the last 20 all, dialed, received, or missed calls.

(Appears only when a phone is connected to the system.)

∑To make a call using a Speed Dial entry

When a voice tag is stored, press the 🛍 button to call the number using the voice tag.

Speed Dial P. 389

Any voice-tagged speed dial entry can be dialed by voice from any screen.

Press the 🛍 button and follow the prompts.



Receiving a Call



When there is an incoming call, an audible notification sounds (if activated) and the incoming call screen appears.

Press the button to answer the call.

Press the button to decline or end the call.

■ Receiving a Call

Call Waiting

Press the <u>L</u> button to put the current call on hold to answer the incoming call.

Press the button again to return to the current call.

Select **Ignore** to ignore the incoming call if you do not want to answer it.

Press the button if you want to hang up the current call.

You can select the icons on the audio/information touch screen instead of the and buttons.

Options During a Call

The following options are available during a call.

Mute: Mute your voice.

Transfer: Transfer a call from the system to your phone.

Touch Tones: Send numbers during a call. This is useful when you call a menudriven phone system.





The available options are shown on the lower half of the audio/information touch screen

Select the option.

➤ The mute icon appears when **Mute** is selected. Select **Mute** again to turn it off.

■Options During a Call

Touch Tones: Available on some phones.

You can select the icons on the audio/information touch screen.

Receiving a Text Message/E-mail

HFL can display newly received text or e-mail messages as well as 20 of the most recently received messages on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase.



- **1.** A pop-up appears and notifies you of a new text message or e-mail.
- **2.** Select **Read** to listen to the message.
 - ► The text message or e-mail is displayed. The system automatically starts reading out the message.
- **3.** To discontinue the message read-out, select **Stop**.

Receiving a Text Message/E-mail

The system does not display any received messages while you are driving. You can only hear them read aloud.

The system can only receive massages that are sent a text (SMS) messages. The message sent using the data services will not be displayed in the list.

With some phones, you may be able to display up to 20 most recent text messages and e-mails.

State or local laws may limit your use of the HFL text message/e-mail feature. Only use the text message/e-mail feature when conditions allow you to do so safely.

When you receive a text message or e-mail for the first time since the phone is paired to HFL, you are asked to turn the **New Message Notification** setting to **On**.

To turn on or off the text/e-mail notice P. 386



■ Selecting a Mail Account


If a paired phone has text message or mail accounts, you can select one of them to be active and receive notifications.



- **1.** Go to the **Phone settings** screen. **▶ Phone settings screen** P. 378
- 2. Select the **Text/Email** tab, then **Select** Account.
 - A pop-up menu appears on the screen.
- **3.** Select **Text Message** or an e-mail account you want.

Selecting a Mail Account

You can also select a mail account from the folder list screen or the message list screen.



You can only receive notifications from one text message or mail account at a time.

Displaying Messages




■ Displaying text messages

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 381
- 2. Select Text/Email.
 - ► Select account if necessary.
- 3. Select a message.
 - ➤ The text message is displayed. The system automatically starts reading the message aloud.

Displaying Messages

If you delete a message on the phone, the message is also deleted in the system. If you send a message from the system, the message goes to your phone's outbox.

To see the previous or next message, select on the message screen.



■ Displaying e-mails

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 381
- 2. Select Text/Email.
 - ► Select **Select Account** if necessary.
- **3.** Select a folder.
- 4. Select a message.
 - ➤ The e-mail is displayed. The system automatically starts reading the message aloud.





■ Read or Stop reading a message

- **1.** Go to the text or e-mail message screen.
 - ► The system automatically starts reading the message aloud.
 - Displaying Messages P. 403
- **2.** Select **Stop** to stop reading. Select **Read** again to start reading the message from the beginning.

■ Reply to a message

- **1.** Go to the text or e-mail message screen.
 - ► The system automatically starts reading the message aloud.
 - **Displaying Messages** P. 403
- 2. Select Reply.
- **3.** Select the reply message.
 - ► The pop-up menu appears on the screen.
- **4.** Select **Send** to send the message.
 - ► **Complete** appears on the screen when the reply message was successfully sent.

■ Reply to a message

The available fixed reply messages are as follows:

- Talk to you later, I'm driving.
- I'm on my way.
- I'm running late.
- OK
- Yes
- No

You cannot add, edit, or delete reply messages.




■ Making a call to a sender

- **1.** Go to the text message screen.
- 2. Select Call.

■ In Case of Emergency

■ Automatic collision notification



If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle automatically will attempt to connect to the HondaLink operator. If connected, information about your vehicle, its location, and its condition will be sent to the operator; you also can speak to the operator when connected.

IMPORTANT: For vehicles equipped with HondaLink Assist, owner activation constitutes authorization for Honda to collect information from your vehicle needed to provide the service, and agreement to the Terms of Use at *www.hondalink.com/TermsAndConditions*. In a crash, HondaLink Assist will attempt to notify emergency services but NEITHER Honda-PRO NOR ITS SERVICE PROVIDERS GUARANTEE THAT SUCH NOTIFICATION WILL OCCUR.

Honda reserves the right to terminate HondaLink Assist services at any time or for any reason, and in the future may not be able to provide services due to changes in, or obsolescence of, technology integral to the service or changes in governmental regulation.

Your vehicle may not be able to connect to the operator if the battery level is low, the line is disconnected, or you do not have adequate cellular coverage.

You cannot use this emergency services when:


- You travel outside the HondaLink service coverage areas.
- There is a problem with the connecting devices, such as the microphones, speakers, or the unit itself.

You cannot operate other phone-related functions using the screen while talking to the operator. Select **Hang Up** to terminate the connection to your vehicle.

■ Automatic collision notification

If the unit fails to connect to the operator, it repeatedly tries until it succeeds.

■ To enable notification



- **1.** Go to the **Phone settings** screen.
 - **▶ Phone settings screen** P. 378
- 2. Select the **Phone** tab, then **HondaLink**Assist.
 - A pop-up menu appears on the screen.
- 3. Select On or Off.

■ To enable notification

Setting options:

- On: Notification is available.
- Off: Disable the feature.

When you turn the ignition switch to ON \boxed{II}^{*1} , the compass self-calibrates, and the compass display appears.

Compass Calibration

If the compass indicates the wrong direction, or the **CAL** indicator blinks, you need to manually calibrate the system.



- **1.** Turn the ignition switch to ON II^{*1}.
- **2.** On the top screen of any audio source, press and hold for five seconds.
 - ► The display switches to the **Compass** settings screen.
- 3. Select Calibration.
- 4. Select Calibration Start
- **5.** Drive the vehicle slowly in two circles.
 - ► The compass starts to show a direction after the calibration. The CAL indicator goes off.

∑Compass *

Compass operation can be affected under the following conditions:

- Driving near power lines or stations
- Crossing a bridge
- Passing a large vehicle, or driving near a large object that can cause a magnetic disturbance
- When accessories such as antennas and roof racks are mounted by magnets

Calibrate the compass in an open area.

While setting the compass, select $\frac{1}{|\mathbf{pack}|}$ to cancel the setting mode and return to the previous screen.


* Not available on all models

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Compass Zone Selection



- **1.** Turn the ignition switch to ON II^{*1}.
- 2. On the top screen of any audio source, press and hold for five seconds.
 - The display switches to the **Compass** settings screen.
- 3. Select Zone Adjust.
 - ► The display shows the current zone number the system is set to.
- **4.** Select the zone number of your area (See Zone Map).



*1:Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

∑Compass Zone Selection

The zone selection is done to compensate the variation between magnetic north and true north.

If the calibration starts while the audio system is in use, the display returns to normal after the calibration is completed.



This chapter discusses driving, refueling, and information on items such as accessories.

Before Driving	
Driving Preparation4	12
Maximum Load Limit4	15
Towing a Trailer	
Towing Preparation4	17
Driving Safely with a Trailer 4	19
Towing Your Vehicle4	20
When Driving	
Starting the Engine 421, 4	23
Precautions While Driving4	28
Automatic Transmission/CVT*4	
Shifting430, 434, 4	
ECON Button 4	

Cruise Control	. 442
Front Sensor Camera*	. 445
Adaptive Cruise Control (ACC)*	. 447
Road Departure Mitigation (RDM) System*	
Lane Keeping Assist System (LKAS)*	
Vehicle Stability Assist (VSA®), aka Elec	
Stability Control (ESC), System	
LaneWatch™*	. 473
Tire Pressure Monitoring System (TPMS).	
Tire Pressure Monitoring System (TPI	MS) -
Required Federal Explanation	. 477
raking	
Brake System	. 479

Anti-lock Brake System (ABS) Brake Assist System	
Collision Mitigation Braking System	
(CMBS™)*	483
arking Your Vehicle	
When Stopped	491
Parking Sensor System*	492
Iulti-View Rear Camera	496
efueling	
Fuel Information	497
How to Refuel	498
uel Economy	
Improving Fuel Economy	499
ccessories and Modifications	500

Before Driving

Driving Preparation

Check the following items before you start driving.

■ Exterior Checks

- Make sure there are no obstructions on the windows, door mirrors, exterior lights, or other parts of the vehicle.
 - Remove any frost, snow, or ice.
 - ► Remove any snow on the roof, as this can slip down and obstruct your field of vision while driving. If frozen solid, remove ice once it has softened.
 - ▶ When removing ice from around the wheels, be sure not to damage the wheel or wheel components.
- Make sure the hood is securely closed.
 - ▶ If the hood opens while driving, your front view will be blocked.
- Make sure the tires are in good condition.
 - ► Check air pressure, check for damage and excessive wear.

≧ Checking and Maintaining Tires P. 537

- Make sure there are no people or objects behind or around the vehicle.
 - ▶ There are blind spots from the inside.

NOTICE

When doors are frozen shut, use warm water around the door edges to melt any ice. Do not try to force them open, as this can damage the rubber trim around the doors. When done, wipe dry to avoid further freezing.

Do not pour warm water into the key cylinder. You will be unable to insert the key if the water freezes in the hole.

Heat from the engine and exhaust can ignite flammable materials left under the hood, causing a fire. If you've parked your vehicle for an extended period, inspect and remove any debris that may have collected, such as dried grass and leaves that have fallen or have been carried in for use as a nest by a small animal.

Also check under the hood for leftover flammable materials after you or someone else has performed maintenance on your vehicle.

Interior Checks

- Store or secure all items on board properly.
 - ► Carrying too much cargo, or improperly storing it, can affect your vehicle's handling, stability, stopping distance, and tires, and make it unsafe.
 - Maximum Load Limit P. 415
- Do not pile items higher than the seat height.
 - ► They can block your view and may be thrown forward in the event of sudden braking.
- Do not place anything in the front seat footwells. Make sure to secure the floor mat.
 - ► An object or unsecured floor mat can interfere with your brake and accelerator pedal operation while driving.
- If you have any animals on board, do not let them move around in the vehicle.
 - ▶ They may interfere with driving and a crash could occur.
- Securely close and lock both doors and the trunk.
 - **Locking/Unlocking the Doors from the Inside** P. 126
- Adjust your seating position properly.
 - Adjust the head restraint, too.
 - Adjusting the Seats P. 161
 - **► Adjusting the Front and Rear Outer Head Restraint Positions** P. 164
- Adjust the mirrors and steering wheel properly for your driving.
 - Adjust them while sitting in the proper driving position.
 - Adjusting the Mirrors P. 159
 - **Adjusting the Steering Wheel** P. 158


The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the trunk or tow a trailer, have the aiming readjusted at a dealer or by a qualified technician.

- Be sure items placed on the floor behind the front seats cannot roll under the seats.
 - ▶ They can interfere with the driver's ability to operate the pedals, the operation of the seats, or the operation of the sensors under the seats.
- Everyone in the vehicle must fasten their seat belt.
 - Fastening a Seat Belt P. 37
- Make sure that the indicators in the instrument panel come on when you start the vehicle, and go off soon after.
 - ▶ Always have a dealer check the vehicle if a problem is indicated.
 - Indicators P. 70

Maximum Load Limit

The maximum load for your vehicle is 850 lbs (385 kg). See the Tire and Loading Information label attached to the driver's doorjamb.

Label Example



This figure includes the total weight of all occupants, cargo, and accessories, and the tongue load if you are towing a trailer.

Steps for Determining Correct Load Limit -

- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1,400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1,400 750 (5 x 150) = 650 lbs.)

Maximum Load Limit

AWARNING

Overloading or improper loading can affect handling and stability and cause a crash in which you can be hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Gross Vehicle Weight Rating (GVWR):

The maximum allowable weight of the vehicle, all occupants, all accessories, all cargo, and the tongue load.

▶ Specifications P. 582, 584


Gross Axle Weight Rating (GAWR):

The maximum allowable weight of the vehicle axle.

▶ Specifications P. 582, 584

- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.
- (6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

In addition, the total weight of the vehicle, all occupants, accessories, cargo, and trailer tongue load must not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR). Both are on a label on the driver's doorjamb.




Towing a Trailer

Towing Preparation


■ Towing Load Limits

Your vehicle can tow a trailer if you carefully observe the load limits, use the proper equipment, and follow the towing guidelines. Check the load limits before driving.



■ Total trailer weight

Maximum allowable weight of the trailer, cargo, and everything in or on it must not exceed 1,000 lbs (450 kg). Towing loads in excess of this can seriously affect vehicle handling and performance and can damage the engine and drivetrain.



■ Tongue load

The weight of the tongue with a fully loaded trailer on the hitch should be approximately 10% of the total trailer weight.

- Excessive tongue load reduces front tire traction and steering control. Too little tongue load can make the trailer unstable and cause it to sway.
- To achieve a proper tongue load, start by loading 60% of the load toward the front of the trailer and 40% toward the rear. Readjust the load as needed.

■ Towing Load Limits

AWARNING

Exceeding any load limit or improperly loading your vehicle and trailer can cause a crash in which you can be seriously hurt or killed.

Check the loading of your vehicle and trailer carefully before starting to drive.

Check if all loads are within limits at a public scale. If a public scale is not available, add the estimated weight of your cargo load to the weight of your trailer (as quoted by the manufacturer), and the tongue load.

Break-in Period

Avoid towing a trailer during your vehicle's first 600 miles (1,000 km).

Never exceed the gross weight ratings. Gross weight information

▶ Vehicle Specifications P. 582, 584

■ Towing Equipment and Accessories

Towing equipment varies by the size of your trailer, how much load you are towing, and where you are towing.

■ Hitches

The hitch must be of an approved type and properly bolted to the underbody.

■ Safety chains

Always use safety chains when you tow a trailer. Leave enough slack to allow the trailer to turn corners easily, but do not allow the chains to drag on the ground.

■ Trailer brakes

There are two common types of trailer brakes: surge and electric. Surge brakes are common for boat trailers, since the brakes will get wet. If you choose electric brakes, be sure they are electronically actuated. Do not attempt to attach trailer brakes to your vehicle's hydraulic system, as it will lower braking effectiveness and create a potential hazard.

■ Additional towing equipment

Many states and provinces/territories require special outside mirrors when towing a trailer. Even if mirrors are not required in your locale, you should install special mirrors if visibility is restricted in any way.

■ Trailer light

Trailer lights and equipment must comply with federal, state, province/territory, and local regulations. Check with your local trailer sales or rental agency for the requirements in the area where you plan to tow.

∑Towing Equipment and Accessories

Make sure that all equipment is properly installed and maintained, and that it meets federal, state, province/territory, and local regulations.

Consult your trailer sales or rental agency if any other items are recommended or required for your towing situation.

The lighting and wiring of trailers can vary by type and brand. If a connector is required, it should only be installed by a qualified technician.

Driving Safely with a Trailer

■ Things You Need To Know Before Towing a Trailer

- Have the trailer properly serviced and keep it in good condition.
- Make sure that all the weights and load in the vehicle and trailer are within limits.
 Towing Load Limits P. 417
- Securely attach the hitch, safety chains, and other necessary parts to the trailer.
- Securely store all the items in and on the trailer so that they do not shift while driving.
- Check if the lights and brakes on the trailer are working properly.
- Check the pressures of the trailer tires, including the spare.

■ Towing Speeds and Gears

- Drive slower than normal.
- Obey posted speed limits for vehicles with trailers.

Automatic transmission/CVT models

• Use the **D** position when towing a trailer on level roads.

■ Turning and Braking

- Turn more slowly and with a wider turning arc than normal.
- Allow more time and distance for braking.
- Do not brake or turn suddenly.

Driving Safely with a Trailer

Parking

In addition to the normal precautions, place wheel chocks at each of the trailer's tires

Driving in Hilly Terrain

• Monitor your temperature gauge. If it nears the red (Hot) mark, turn off the climate control system and reduce speed. Pull to the side of the road safely to cool down the engine if necessary.

Automatic transmission models

• Shift to the S position if the transmission shifts frequently.

Towing Your Vehicle


Your vehicle is not designed to be towed behind a motor home. If your vehicle needs to be towed in an emergency, refer to the emergency towing information.

Emergency Towing P. 580


When Driving

Models without smart entry system

Starting the Engine




1. Make sure the parking brake is applied.





- **2.** Check that the shift lever is in P, then depress the brake pedal.
 - ► Although it is possible to start the vehicle in N, it is safer to start it in P.



Manual transmission models

- **2.** Check that the shift lever is in N. Then depress the brake pedal with your right foot, and the clutch pedal with your left foot.
 - ► The clutch pedal must be fully depressed to start the engine.

Starting the Engine

Keep your foot firmly on the brake pedal when starting the engine.

The engine is harder to start in cold weather and in thinner air found at altitudes above 8,000 feet (2,400 meters).

When starting the engine in cold weather, turn off all electrical accessories such as the lights, climate control system, and rear defogger in order to reduce battery drain.

If you live in a region where winter is extremely cold, an engine block heater will improve starting and warming of the engine. If temperatures consistently below -22°F (-30°C) are expected, the coolant mixture should be changed to a higher concentration to prevent freezing. Consult a dealer for details.

If the exhaust system sounds abnormal or you can smell exhaust gas inside the vehicle, have your vehicle checked by a dealer. There may be a problem with the engine or exhaust system.



3. Turn the ignition switch to START **III** without depressing the accelerator pedal.

Starting to Drive

Continuously variable transmission (CVT) models

- **1.** Keeping your right foot on the brake pedal, release the parking brake. Check that the parking brake indicator has gone off.
 - Parking Brake P. 479
- **2.** Put the shift lever in **D**. Select **R** when reversing.
- **3.** Gradually release the brake pedal and gently depress the accelerator pedal to pull away.

■ Hill start assist system

Hill start assist keeps the brake engaged briefly to help prevent the vehicle from rolling on inclines as you move your foot from the brake pedal to the accelerator.

Manual transmission models

Depress the clutch pedal, and shift to one of the forward gears when facing uphill, or $\boxed{\mathbf{R}}$ when facing downhill, then release the brake pedal.

Continuously variable transmission (CVT) models

Move the shift lever to \overline{D} or \overline{S} when facing uphill, or \overline{R} when facing downhill, then release the brake pedal.

Starting the Engine

Do not hold the key in START [III] for more than 10 seconds.

- If the engine does not start right away, wait for at least 30 seconds before trying again.
- If the engine starts, but then immediately stops, wait at least 30 seconds before repeating step 3 while gently depressing the accelerator pedal. Release the accelerator pedal once the engine starts.

The immobilizer system protects your vehicle from theft. If an improperly coded key (or other device) is used, the engine's fuel system is disabled.


Immobilizer System P. 133

Hill start assist may not prevent the vehicle from rolling downhill on a very steep or slippery slope, and does not operate on small inclines.


Hill start assist is not a replacement for the parking brake.

Models with smart entry system

Starting the Engine




1. Make sure the parking brake is applied.



Automatic transmission/CVT models

- **2.** Check that the shift lever is in \boxed{P} , then depress the brake pedal.
 - ► Although it is possible to start the vehicle in N, it is safer to start it in P.



Manual transmission models

- **2.** Check that the shift lever is in N. Then depress the brake pedal with your right foot, and the clutch pedal with your left foot.
 - ➤ The clutch pedal must be fully depressed to start the engine.

Starting the Engine

Keep your foot firmly on the brake pedal when starting the engine.

The engine is harder to start in cold weather and in thinner air found at altitudes above 8,000 feet (2,400 meters).

When starting the engine in cold weather, turn off all electrical accessories such as the lights, climate control system, and rear defogger in order to reduce battery drain.

If you live in a region where winter is extremely cold, an engine block heater will improve starting and warming of the engine. If temperatures consistently below -22°F (-30°C) are expected, the coolant mixture should be changed to a higher concentration to prevent freezing. Consult a dealer for details.

If the exhaust system sounds abnormal or you can smell exhaust gas inside the vehicle, have your vehicle checked by a dealer. There may be a problem with the engine or exhaust system.

The immobilizer system protects your vehicle from theft.

If an improperly coded device is used, the engine's fuel system is disabled.

▶ Immobilizer System P. 133



All models

3. Press the **ENGINE START/STOP** button without depressing the accelerator pedal.

Stopping the Engine

You can turn the engine off when the vehicle is completely stopped.

Automatic transmission/CVT models

- **1.** Shift to P.
- 2. Press the **ENGINE START/STOP** button.

Manual transmission models

- If the shift lever is in N, press the **ENGINE START/STOP** button.
- If the shift lever is in any gear other than N, depress the clutch pedal, then press the **ENGINE START/STOP** button.

Starting the Engine

Bring the smart entry remote close to the **ENGINE START/STOP** button if the battery in the smart entry remote is weak.

▶ If the Smart Entry Remote Battery is Weak P. 564

The engine may not start if the smart entry remote is subjected to strong radio waves.


Do not hold the **ENGINE START/STOP** button to start the engine.

If the engine does not start, wait at least 30 seconds before trying again.

Remote Engine Start*

You can remotely start the engine using the smart entry remote.

■ To start the engine



The engine runs for up to 10 minutes without you starting the vehicle.

To extend the run time for another 10 minutes during the first run, press the button, then press and hold the button.

► The turn signal lights come back on three times, twice, if a 10-minute extension request was transmitted successfully.

■ Remote Engine Start*

AWARNING

Engine exhaust contains toxic carbon monoxide

Breathing carbon monoxide can kill you or cause unconsciousness.

Never use the remote engine starter when the vehicle is parked in a garage or other area with limited ventilation.

If there are buildings and obstacles between your vehicle and the remote, the range will be reduced. While the vehicle is moving, the range may be reduced.

This distance may vary by external electrical interference.

The engine may not start by the remote engine start if:

- You have disabled a remote engine start setting using the multi-information display* or audio/ information touch screen*.
- The power mode is not in VEHICLE OFF (LOCK).
- The shift lever is in a position other than **P**.
- The hood is open, or any door or the trunk is unlocked.
- You have already used the remote twice to start the engine.
- Another registered smart entry remote is in the vehicle.

■ To stop the engine



Press and hold the button for one second.

- There is any antenna failure.
- Door is unlocked with the built-in key.
- The engine oil pressure is low.
- The engine coolant temperature is extremely high.
- The security system alarm is not set.

The engine may stop while it is running if:

- You do not start the vehicle within 10 minutes of starting the engine with the button on the smart entry remote.
- The engine is stopped by using the smart entry remote.
- Door is unlocked with the built-in key.
- The hood is open.
- The shift lever is in a position other than P.
- The engine coolant temperature is extremely high.
- The engine oil pressure is low.
- The Malfunction Indicator Lamp (MIL) comes on if there is a problem with the emissions control systems.

While the engine is running, the vehicle will automatically precondition inside the vehicle. When it is warm outside:

• The climate control system is activated in recirculation mode.

When it is cold outside:

- The defroster is activated at a moderately warm temperature.
- The rear defogger and door mirror heaters* are activated.

Automatic transmission/CVT models

Starting to Drive

When the engine was started using the Q button* on the smart entry remote

1. While depressing the brake pedal, press the **ENGINE START/STOP** button.

When the engine was started in any case

2. Keeping your right foot on the brake pedal, release the parking brake. Check that the parking brake indicator has gone off.

Parking Brake P. 479

- **3.** Put the shift lever in \boxed{D} . Select \boxed{R} when reversing.
- **4.** Gradually release the brake pedal and gently depress the accelerator pedal to pull away.

■ Hill start assist system

Hill start assist keeps the brake engaged briefly to help prevent the vehicle from rolling on inclines as you move your foot from the brake pedal to the accelerator.

Manual transmission models

Depress the clutch pedal, and shift to one of the forward gears when facing uphill, or $\boxed{\mathbf{R}}$ when facing downhill, then release the brake pedal.

Automatic transmission/CVT models

Move the shift lever to \boxed{D} or \boxed{S} when facing uphill, or \boxed{R} when facing downhill, then release the brake pedal.

Starting to Drive

When the engine was started using the D button on the smart entry remote

The engine stops when the shift lever is moved out of P before the **ENGINE START/STOP** button is pressed. Follow the step 1 when starting to drive.

Hill start assist may not prevent the vehicle from rolling downhill on a very steep or slippery slope, and does not operate on small inclines.

Hill start assist is not a replacement for the parking brake.

* Not available on all models

Precautions While Driving

In Rain

Avoid driving in deep water and on flooded roads. This can damage the engine or driveline, or cause electrical component failure.

Other Precautions

If there is a strong impact with something under the vehicle, stop in a safe location. Check the underside of the vehicle for damage or any fluid leaks.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

NOTICE

Do not operate the shift lever while pressing the accelerator pedal. You could damage the transmission.

If the ignition switch is turned to ACCESSORY $\boxed{1}^{*1}$ while driving, the engine will shut down and all steering and brake power assist functions will stop, making it difficult to control the vehicle.

Do not put the shift lever in $\boxed{\mathbf{N}}$, as you will lose engine braking (and acceleration) performance.

During the first 600 miles (1,000 km) of operation, avoid sudden acceleration or full throttle operation so as to not damage the engine or powertrain.

Avoid hard braking for the first 200 miles (300 km). You should also follow this when the brake pads are replaced.

NOTICE

If you repeatedly turn the steering wheel at an extremely low speed, or hold the steering wheel on the full left or right position for a while, the electric power steering (EPS) system heats up. The system goes into a protective mode, and limits its performance. The steering wheel becomes harder and harder to operate. Once the system cools down, the EPS system is restored.

Repeated operation under these conditions can eventually damage the system.

Automatic Transmission/CVT*

Creeping

The engine runs at a higher idle speed and creeping increases. Keep the brake pedal firmly depressed when stopped.

Kickdown

Quickly depressing the accelerator pedal while driving uphill may cause the transmission to drop to a lower gear, unexpectedly increasing vehicle speed. Depress the accelerator pedal carefully, especially on slippery roads and curves.


* Not available on all models 429

Continuously variable transmission (CVT) models

Shifting

Change the shift position in accordance with your driving needs.

■ Shift lever positions



^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Shifting


You cannot turn the ignition switch to LOCK 0^{*1} and remove the key unless the shift lever is in P.

The vehicle may move forward very slightly even in $\boxed{\bf N}$ while the engine is cold.

Depress the brake pedal firmly and, when necessary, apply the parking brake.

When shifting positions in extremely low temperatures (-22°F/-30°C), there may be a short delay before the shift position is displayed. Always confirm you are in the correct shift position before driving.

Shift Lever Operation



Shift Lever Operation

NOTICE

When you change the shift lever from $\boxed{\mathbf{D}}$ to $\boxed{\mathbf{R}}$ and vice versa, come to a complete stop and keep the brake pedal depressed.

Operating the shift lever before the vehicle has come to a complete standstill can damage the transmission.

Use the shift lever position indicator to check the lever position before pulling away.

If the transmission indicator blinks when driving, in any shift position, there is a problem with the transmission.

Avoid sudden acceleration and have the transmission checked by a dealer as soon as possible.

The fuel supply may be cut off if you drive at engine speeds in or over the tachometer's red zone (engine speed limit). If this happens, you may experience a slight jolt.

It may not be possible to operate the shift lever if the brake pedal is applied while the shift lever release button is held down.

Depress the brake pedal first.

■ 7-Speed Manual Shift Mode

Use the paddle shifters to change between 1st and 7th speeds without removing your hands from the steering wheel. The transmission switches to the 7-speed manual shift mode when you pull a paddle shifter while driving. This mode is useful when engine braking is needed.

■ When the shift lever is in D:

The shift mode goes into the 7-speed manual shift mode temporarily, and the number is displayed in the shift indicator.

The 7-speed manual shift mode is canceled automatically if you drive at constant speed or accelerate, and the number in the shift indicator goes off.

You can cancel this mode by pulling the + paddle shifter for a few seconds. The 7-speed manual shift mode is especially useful when reducing the vehicle speed temporarily before making a turn.

■ When the shift lever is in S:

The shift mode goes into the 7-speed manual shift mode. The \mathbf{M} indicator and the speed number are displayed in the shift indicator. As the vehicle speed slows down, the transmission automatically shifts down accordingly. When the vehicle comes to a stop, it automatically shifts down into 1st.

If the vehicle speed increases and the engine speed reaches near the tachometer's red zone, the transmission automatically shifts up.

You can only pull away in 1st speed.

When canceling the 7-speed manual shift mode, move the shift lever from $\boxed{\textbf{S}}$ to $\boxed{\textbf{D}}$. When the 7-speed manual shift mode is canceled, the M indicator and shift indicator go off.

≥ 7-Speed Manual Shift Mode

To improve fuel economy, the transmission may shift up to a higher speed than the seventh under certain circumstances. In this case, the number in the shift indicator remains as **7**.

In the 7-speed manual shift mode, the transmission shifts up or down by operating either paddle shifter under the following conditions:


Shift Up: The engine speed reaches the lowest threshold of the higher speed position. Shift Down: The engine speed reaches the highest threshold of the lower speed position.

When the engine speed reaches near the tachometer's red zone, the transmission shifts up automatically.

When the engine speed reaches the lowest threshold of the selected speed position, the transmission shifts down automatically.

Operating the paddle shifters on slippery surfaces may cause the tires to lock up. In this case, the 7-speed manual shift mode is canceled and goes back to the normal D driving mode.

■ 7-Speed Manual Shift Mode Operation



≥ 7-Speed Manual Shift Mode Operation

Each paddle shift operation makes a single speed change.

To change continuously, release the paddle shifter before pulling it again for the next speed.

Recommended Shift Points

Use this table as a guideline to help increase fuel efficiency and reduce emissions.

Shift Up	Normal Acceleration	
1 to 2	15 mph (24 km/h)	
2 to 3	25 mph (40 km/h)	
3 to 4	40 mph (64 km/h)	
4 to 5	45 mph (72 km/h)	
5 to 6	50 mph (80 km/h)	
6 to 7	55 mph (89 km/h)	

The shift indicator blinks when you cannot shift up or down. It indicates that your vehicle speed is not in its allowable shifting range.


Slightly accelerate to shift up and decelerate to shift down while the indicator is blinking.

Automatic transmission models

Shifting

Change the shift position in accordance with your driving needs.

■ Shift lever positions



Shifting


You cannot change the power mode from ON to VEHICLE OFF (LOCK) unless the shift lever is in P.

The vehicle may move forward very slightly even in $\boxed{\mathbf{N}}$ while the engine is cold.

Depress the brake pedal firmly and, when necessary, apply the parking brake.

When shifting gears in extremely low temperatures (-22°F/-30°C), there may be a short delay before the shift is indicated in the display. Always confirm you are in the correct gear before driving.

Shift Lever Operation



Shift Lever Operation

NOTICE

When you change the shift lever from $\boxed{\mathbf{D}}$ to $\boxed{\mathbf{R}}$ and vice versa, come to a complete stop and keep the brake pedal depressed.

Operating the shift lever before the vehicle has come to a complete standstill can damage the transmission.

Use the shift lever position indicator to check the lever position before pulling away.

If the transmission indicator blinks when driving, in any shift position, there is a problem with the transmission.

Avoid sudden acceleration and have the transmission checked by a dealer as soon as possible.

The fuel supply may be cut off if you drive at engine speeds in or over the tachometer's red zone (engine speed limit). If this happens, you may experience a slight jolt.

It may not be possible to operate the shift lever if the brake pedal is applied while the shift lever release button is held down

Depress the brake pedal first.

Sequential Shift Mode

Use the paddle shifters to change between 1st and 6th gears without removing your hands from the steering wheel. The transmission will switch to the sequential shift mode.

■ When the shift lever is in D:

The vehicle will go into the sequential shift mode momentarily, and the gear position indicator will come on.

Once you start traveling at a constant speed, the sequential shift mode will automatically switch off, and the gear position indicator will go off.

Hold the $\boxed{+}$ paddle shifter for two seconds to return to normal drive.

■ When the shift lever is in S:

The vehicle will go into the sequential shift mode, and the **M** (sequential shift mode) indicator and gear position indicator will come on. At speeds of 6 mph (10 km/h) or less, the vehicle automatically shift down into 1st gear.

If you do not operate the paddle shifters while in 1st gear, the transmission automatically shift up to 2nd gear. It does not shift automatically from 2nd through 6th gears.

You can only pull away in 1st and 2nd gear.


When canceling the sequential shift mode, move the shift lever from \underline{S} to \underline{D} . When the sequential shift mode is canceled, the \underline{M} indicator and gear position indicator go off.

■ Second gear lock mode

If you pull the + paddle shifter while stopped or driving at 6 mph (10 km/h) or less, the gear position will be locked in 2nd gear. This makes it easier to pull away on slippery surfaces such as snow covered roads.

To cancel the 2nd gear lock mode, pull the \Box paddle shifter, or move the shift lever from \Box to \Box .

■ Sequential Shift Mode Operation



Sequential Shift Mode Operation

Each paddle shift operation makes a single gear change.

To change gear continuously, release the paddle shifter before pulling it again for the next gear.

Recommended Shift Points

Use this table as a guideline to help increase fuel efficiency and reduce emissions.

Shift Up	Normal Acceleration	
1st to 2nd	15 mph (24 km/h)	
2nd to 3rd	25 mph (40 km/h)	
3rd to 4th	40 mph (64 km/h)	
4th to 5th	47 mph (76 km/h)	
5th to 6th	52 mph (84 km/h)	

The gear position indicator blinks when you cannot shift up or down. It indicates that your vehicle speed is not in its allowable gear shifting range.

Slightly accelerate to shift up and decelerate to shift down while the indicator is blinking.

Manual transmission models

Shifting

Shift Lever Operation

Fully depress the clutch pedal to operate the shift lever and change gears, then slowly release the pedal.

Depress the clutch pedal, and pause for a few seconds before shifting into \mathbb{R} , or shift into one of the forward gears for a moment. This stops the gears so they do not "grind."

≫Shifting

NOTICE

Do not shift to $\overline{\mathbf{R}}$ before the vehicle comes to a complete stop.

Shifting to R before stopping can damage the transmission.

NOTICE

Before downshifting, make sure the engine will not go into the tachometer's red zone. Should this occur, it can severely damage your engine.

There is a metallic part on the shift lever. If you leave the vehicle parked outside for a long time on a hot day, be careful before moving the shift lever. Because of heat, the shift lever may be extremely hot. If the outside temperature is low, the shift lever may feel cold.



When you are not shifting, do not rest your foot on the clutch pedal. This can cause your clutch to wear out faster.

Shifting

Recommended Shift Points

Driving in the highest gear that allows the engine to run and accelerate smoothly helps to optimize fuel economy and effective emissions control. The following shift points are recommended:

4-cylinder models

U.S. LX-S and Canadian LX models

Shift Up	Normal Acceleration	
1st to 2nd	17 mph (27 km/h)	
2nd to 3rd	29 mph (46 km/h)	
3rd to 4th	37 mph (60 km/h)	
4th to 5th	43 mph (69 km/h)	
5th to 6th	49 mph (79 km/h)	

4-cylinder models

Except U.S. LX-S and Canadian LX models

	Shift Up	Normal Acceleration
	1st to 2nd	15 mph (24 km/h)
	2nd to 3rd	25 mph (40 km/h)
	3rd to 4th	40 mph (64 km/h)
	4th to 5th	47 mph (76 km/h)
	5th to 6th	52 mph (84 km/h)

■ Reverse Lockout

The manual transmission has a lockout mechanism that stops you from accidentally shifting into $\boxed{\mathbf{R}}$ from a forward gear while the vehicle is moving above a certain speed.

If you cannot shift to $\boxed{\mathbf{R}}$ when the vehicle is stopped, do the following:



- **1.** Depress the clutch pedal, move the shift lever all the way to the left, and shift to \boxed{R} .
- **2.** If you still cannot shift into $\boxed{\mathbb{R}}$, apply the parking brake, and turn the ignition switch to ACCESSORY $\boxed{\mathbb{I}}$ or LOCK $\boxed{\mathbb{O}}^{*1}$.
- **3.** Depress the clutch pedal and shift into $\boxed{\mathbf{R}}$.
- **4.** Keep depressing the clutch pedal and start the engine.

Have the vehicle checked by a dealer if you have to go through this procedure repeatedly.

Shifting

6-cylinder models	
Shift Up	Normal Acceleration
1st to 2nd	17 mph (28 km/h)
2nd to 3rd	27 mph (44 km/h)
3rd to 4th	36 mph (57 km/h)
4th to 5th	41 mph (66 km/h)
5th to 6th	44 mph (71 km/h)

If you exceed the maximum speed for the gear you are in, the engine speed will enter into the tachometer's red zone. When this happens, you may experience a slight jolt.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

ECON Button





The **ECON** button turns the ECON mode on and off.

The ECON mode helps you improve your fuel economy by adjusting the performance of the engine, transmission, climate control system, and cruise control.

Cruise Control

Maintains a constant vehicle speed without having to keep your foot on the accelerator. Use cruise control on freeways or open roads where you can travel at a constant speed with little acceleration or deceleration.





○ Cruise Control

AWARNING

Improper use of the cruise control can lead to a crash.

Use the cruise control only when traveling on open highways in good weather.

It may not be possible to maintain a constant speed when driving uphill or downhill.

When not using cruise control:
Turn off cruise control by pressing the **CRUISE***/

While in the ECON mode, it may take relatively more time to accelerate to maintain the set speed.


Manual transmission models

MAIN* button

When the engine speed slows down, try to downshift.

You can maintain the set speed if you change gear within five seconds.

■ To Set the Vehicle Speed



Take your foot off the pedal and press the **–/SET** button when you reach the desired speed.

The moment you release the **-/SET** button, the set speed is fixed, and cruise control begins. The **CRUISE CONTROL** indicator comes on.

Models without adaptive cruise control

During cruise control, Straight Driving Assist Function is activated. This control function is an EPS function and it helps reduce the steering effort to keep the steering angle on a straight road with cants.


To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+** or **-/SET** buttons on the steering wheel.



- Each time you press the button, the vehicle speed is increased or decreased by about 1 mph (1.6 km/h).
- If you keep the button pressed, the vehicle speed increases or decreases until you release it. This speed is then set.

■ To Cancel



To cancel cruise control, do any of the following:

- Press the **CANCEL** button.
- Press the **CRUISE***/**MAIN*** button.
- Depress the brake pedal.
- Depress the clutch pedal for five seconds or more.

The **CRUISE CONTROL** indicator goes off.

■To Adjust the Vehicle Speed

You can set the vehicle speed using the **-/SET** button on the steering wheel when adjusting the speed with the accelerator and brake pedals.

∑To Cancel

Resuming the prior set speed:

After cruise control has been canceled, you can still resume the prior set speed by pressing the **RES/+** button while driving at a speed of at least 25 mph (40 km/h) or more.

You cannot set or resume in the following situations:


- When vehicle speed is less than 25 mph (40 km/h)
- When the **CRUISE***/**MAIN*** button is turned off

At vehicle speeds of 22 mph (35 km/h) or less, cruise control is canceled automatically.

Front Sensor Camera*

The camera, used in systems such as LKAS, RDM, ACC, and CMBS™, is designed to detect an object that triggers any of the systems to operate its functions.

Camera Location and Handling Tips



This camera is located behind the rearview mirror.

To help reduce the likelihood that high interior temperatures will cause the camera's sensing system to shut off, when parking, find a shady area or face the front of the vehicle away from the sun. If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on it.

Never apply a film or attach any objects to the windshield, the hood, or the front grill that could obstruct the camera's field of vision and cause the system to operate abnormally.

Scratches, nicks, and other damage to the windshield within the camera's field of vision can cause the system to operate abnormally. If this occurs, we recommend that you replace the windshield with a genuine Honda replacement windshield. Making even minor repairs within the camera's field of vision or installing an aftermarket replacement windshield may also cause the system to operate abnormally. After replacing the windshield, have a dealer recalibrate the camera. Proper calibration of the camera is necessary for the system to operate properly.

Do not place an object on the top of the instrument panel. It may reflect onto the windshield and prevent the system from detecting lane lines properly.

>> Front Sensor Camera *

If the Some Driver Assist Systems Cannot Operate: Camera Temperature Too High message appears:


- Use the climate control system to cool down the interior and, if necessary, also use defroster mode with the airflow directed towards the camera.
- Start driving the vehicle to lower the windshield temperature, which cools down the area around the camera.

If the Some Driver Assist Systems Cannot Operate: Clean Front Windshield message appears:

 Park your vehicle in a safe place, and clean the windshield. If the message does not disappear after you have cleaned the windshield and driven for a while, have your vehicle checked by a dealer.

Adaptive Cruise Control (ACC)*

Helps maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours, without you having to keep your foot on the brake or the accelerator.



AWARNING

Improper use of ACC can lead to a crash.

Use ACC only when traveling on open highways in good weather.

AWARNING

ACC has limited braking capability.


When your vehicle speed drops below 22 mph (35 km/h), ACC will automatically cancel and no longer will apply your vehicle's brakes.

Always be prepared to apply the brake pedal when conditions require.

Important Reminder

As with any system, there are limits to ACC. Use the brake pedal whenever necessary, and always keep a safe distance between your vehicle and other vehicles.

Be careful not to have the radar sensor cover strongly impacted.



When the **MAIN** button is pressed, ACC and Lane Keeping Assist System (LKAS) are both turned on or off.


ACC may not work properly under certain conditions. **ACC Conditions and Limitations** P. 452

When not using ACC: Turn off adaptive cruise by pressing the **MAIN** button. This also will turn off the Lane Keeping Assist System (LKAS).


Do not use ACC under the following conditions:

- On roads with heavy traffic or while driving in continuous stop and go traffic.
- On roads with sharp turns.
- On roads with steep downhill sections, as the set vehicle speed can be exceeded by coasting. In such cases, ACC will not apply the brakes to maintain the set speed.
- On roads with toll collection facilities or other objects between lanes of traffic, or in parking areas, or facilities with drive through access.

■ To Set the Vehicle Speed



Take your foot off the pedal and press down the **–/SET** button when you reach the desired speed. The moment you release the button, the set speed is fixed, and ACC begins.



When ACC starts operating, the vehicle icon, distance bars and set speed appear on the multi-information display.

∑To Set the Vehicle Speed

You can switch the displayed set speed measurements on the multi-information display between mph and km/h.


Customized Features P. 106, 298, 316


When in Operation

■ There is a vehicle ahead

ACC monitors if a vehicle ahead of you enters the ACC range. If a vehicle is detected doing so, the ACC system maintains or decelerates your vehicle's set speed in order to keep the vehicle's set following-distance from the vehicle ahead.

To Set or Change Following-Distance P. 455





When a vehicle whose speed is slower than your set speed comes in or cuts in front of you and is detected by the radar, your vehicle starts to slow down.

When in Operation ■ Continuous States States

If the vehicle detected ahead of you slows down abruptly, or if another vehicle is detected cutting in front of you, the beeper sounds and a message appears on the multi-information display. Depress the brake pedal, and keep an appropriate distance from the vehicle ahead.



Even if the distance between your vehicle and the vehicle detected ahead is short, ACC may start accelerating your vehicle under the following circumstances:

- The vehicle ahead of you is going at almost the same speed as, or faster than, your vehicle.
- A vehicle that cuts in front of you is going faster than your vehicle, gradually increasing the distance between the vehicles

You can also set the system to beep when a vehicle detected in front of you comes in and goes out of the ACC detecting range. Change the **ACC Forward Vehicle Detect Beep** setting.

Customized Features P. 106, 298, 316

■ There is no vehicle ahead



Your vehicle maintains the set speed without having to keep your foot on the brake or accelerator pedal.

If there previously was a vehicle detected ahead that kept your vehicle from traveling at the set speed, ACC accelerates your vehicle to the set speed, and then maintains it.

■ When you depress the accelerator pedal

You can temporarily increase the vehicle speed.

ACC stays on unless you cancel it. Once you release the accelerator pedal, the system resumes the set speed or a sufficient speed to keep the following-distance.

₩When you depress the accelerator pedal

While the accelerator pedal is depressed, the system does not apply the brakes to keep the following-distance, as well as the **BRAKE** message on the multi-information display does not appear.

When in Operation P. 450 **When in Operation** P. 450

ACC Conditions and Limitations

The system may automatically shut off and the **ACC** indicator will come on under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the ACC functions.

Front Sensor Camera* P. 445

■ Environmental conditions

• Driving in bad weather (rain, fog, snow, etc.).

■ Roadway conditions

• Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).

■ Vehicle conditions

- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- An abnormal tire or wheel condition (Wrong sized, varied size or construction, improperly inflated, compact spare tire, etc.).
- The camera temperature gets too high.
- The parking brake is applied.
- When the radar sensor cover is dirty.
- When the front of the vehicle tilts up due to heavy cargo in the trunk or rear seats.
- When tire chains are installed

The radar sensor for ACC is shared with the collision mitigation braking systemTM (CMBSTM).

Collision Mitigation Braking System™ (CMBS™)* P. 483

Do not put a sticker on the radar sensor cover or replace the radar sensor cover.

Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

If the front of the vehicle is impacted in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:

- The vehicle mounted onto a bump, curb, chock, embankment, etc.
- You drive the vehicle where the water is deep.
- Your vehicle has a frontal collision.

You can read about handling information for the camera equipped with this system.


Front Sensor Camera* P. 445

■ Detection limitations

- A vehicle or pedestrian suddenly crosses in front of you.
- The distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter, or other small vehicle.
- When there are animals in front of your vehicle.
- When you drive on a curved or winding or undulating road that makes it difficult for the sensor to properly detect a vehicle or a pedestrian in front of you.
- The speed difference between your vehicle and a vehicle or pedestrian in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the vehicle ahead of you brakes suddenly.
- When the vehicle ahead of you has a unique shape.
- When your vehicle or the vehicle ahead of you is driving on one edge of the lane.

■ To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+** or **-/SET** buttons on the steering wheel.




- Each time you press the switch up or down, the vehicle speed is increased or decreased by about 1 mph or 1 km/h accordingly.
- If you keep the switch pressed up or down, the vehicle speed increases or decreases by about 5 mph or 5 km/h accordingly.

∑To Adjust the Vehicle Speed

If a vehicle detected ahead is going at a speed slower than your increased set speed, ACC may not accelerate your vehicle. This is to maintain the set following-distance between your vehicle and the vehicle ahead.

■ To Set or Change Following-Distance



Press the (distance) button to change the ACC following-distance.


Each time you press the button, the followingdistance (the interval behind a vehicle detected ahead of you) setting cycles through extra long, long, middle, and short followingdistances.

Determine the most appropriate followingdistance setting based on your specific driving conditions. Be sure to adhere to any following-distance requirements set by local regulation.

The higher your vehicle's following-speed is, the longer the short, middle, long or extra long following-distance becomes. See the following examples for your reference.

Vehicle Distance		When the Set Speed is:	
		50 mph (80 km/h)	65 mph (104 km/h)
Short		84 feet 26 meters 1.1 sec	102 feet 31 meters 1.1 sec
Middle		111 feet 34 meters 1.5 sec	139 feet 43 meters 1.5 sec
Long		155 feet 48 meters 2.1 sec	202 feet 62 meters 2.1 sec
Extra Long	<u>=</u>	215 feet 66 meters 3.0 sec	285 feet 87 meters 3.0 sec

■ To Cancel



To cancel ACC, do any of the following:

- Press the **CANCEL** button.
- Press the **MAIN** button.
 - ► The **ACC** indicator (white) goes off.
- Depress the brake pedal.

∑To Cancel

Resuming the prior set speed: After you have canceled ACC, you can resume the prior set speed while it is still displayed. Press the **RES/+** button when driving at a speed of at least 25 mph (40 km/h) or more.

The set speed cannot be set or resumed when ACC has been turned off using the **MAIN** button. Press the **MAIN** button to activate the system, then set the desired speed.

■ Automatic cancellation

The beeper sounds and a message appears on the multi-information display when ACC is automatically canceled. Any of these conditions may cause the ACC to automatically cancel:

- Bad weather (rain, fog, snow, etc.)
- When the radar sensor at the lower part of the front bumper gets dirty.
- The vehicle ahead of you cannot be detected.
- An abnormal tire condition is detected, or the tires are skidding.
- Driving on a mountainous road, or driving off road for extended periods.
- Abrupt steering wheel movement.
- When the ABS, VSA® or CMBS™ is activated.
- When the ABS or VSA® system indicator comes on.
- When you manually apply the parking brake.
- When the detected vehicle within the ACC range is too close to your vehicle.
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.

>> Automatic cancellation


Even though ACC has been automatically canceled, you can still resume the prior set speed. Wait until the condition that caused ACC to cancel improves, then press the **RES/+** button.

■ To Switch ACC to Cruise Control

Press and hold the 🖺 (distance) button for one second.

Cruise Mode Selected appears on the multi-information display for two seconds, and then the mode switches to Cruise.

To switch back to ACC, press and hold the 🖺 button again for one second.




▼To Switch ACC to Cruise Control

Always be aware which mode you are in. When you are driving in Cruise mode, the system will not assist you to maintain a following-distance from a vehicle ahead of you.

Road Departure Mitigation (RDM) System*

Alerts and helps to assist you when the system determines a possibility of your vehicle unintentionally crossing over detected lane markings.

■ How the System Works



The front camera behind the rearview mirror monitors left and right lane markings (in white or yellow). If your vehicle is getting too close to detected lane markings without a turn signal activated, the system, in addition to a visual alert, applies steering torque and alerts you with rapid vibrations on the steering wheel, to help you remain within the detected lane.

As a visual alert, the **Lane Departure** message appears on the multi-information display.

If the system determines that its steering input is insufficient to keep your vehicle on the roadway, it may apply braking.

➤ Braking is applied only when the lane markings are solid continuous lines.

The system cancels assisting operations when you turn the steering wheel to avoid crossing over detected lane markings.

If the system operates several times without detecting driver response, the system beeps to alert you.

■ Road Departure Mitigation (RDM) System *

Important Safety Reminder

Like all assistance systems, the RDM system has limitations.

Over-reliance on the RDM system may result in a collision. It is always your responsibility to keep the vehicle within your driving lane.

The RDM system only alerts you when lane drift is detected without a turn signal in use. The RDM system may not detect all lane markings or lane or roadway departures; accuracy will vary based on weather, speed and lane marker condition. It is always your responsibility to safely operate the vehicle and avoid collisions.

You can read about handling information for the camera equipped with this system.

Front Sensor Camera* P. 445

The RDM system may not work properly or may work improperly under the certain conditions:

₹ RDM Conditions and Limitations P. 462


* Not available on all models

■ How the System Activates

The system becomes ready to start searching for lane markings when all the following conditions are met:

- The vehicle is traveling between about 45 and 90 mph (72 and 145 km/h).
- The vehicle is on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in continuous operation.
- The system makes a determination that the driver is not actively accelerating, braking or steering.

RDM On and Off



Press the RDM button to turn the system on and off.

▶ The indicator in the button comes on and the message appears on the multiinformation display when the system is on.

The RDM system may automatically shut off and the spin indicator comes and stays on.

Indicators P. 70

RDM system function can be impacted when the vehicle is:

- Not driven within a traffic lane.
- Driven on the inside edge of a curve, or outside of a lane.
- Driven in a narrow lane.

RDM On and Off

When you have selected **Warning Only** from the customized options using the multi-information display, the system does not operate the steering wheel and braking.

■ RDM Conditions and Limitations

The system may not properly detect lane markings and the position of your vehicle under certain conditions. Some examples of these conditions are listed below.

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the windshield.

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.
- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.
- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white lines (or yellow lines).
- Driving on roads with double lines.

■ Vehicle conditions


- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.
- When tire chains are installed.

Lane Keeping Assist System (LKAS)*

Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

■ Steering input assist

The system applies torque to the steering to keep the vehicle between the left and right lane lines. The applied torque becomes stronger as the vehicle gets closer to either of the lane lines.



When you operate the turn signals to change lanes, the system is suspended, and resumes after the signals are off.

If you make a lane change without operating the turn signals, the LKAS alerts activate, and torque is applied to the steering.

∑Lane Keeping Assist System (LKAS)*

Important Safety Reminders

The LKAS is for your convenience only. It is not a substitute for your vehicle control. The system does not work if you take your hands off the steering wheel or fail to steer the vehicle.

Multi-Information Display Warning and Information Messages* P. 96

Do not place objects on the instrument panel.

Objects may reflect on the windshield and prevent correct detection of the traffic lanes.

The LKAS only alerts you when lane drift is detected without a turn signal in use. The LKAS may not detect all lane markings or lane departures; accuracy will vary based on weather, speed, and lane marker condition.

It is always your responsibility to safely operate the vehicle and avoid collisions.

The LKAS is convenient when it is used on freeways.

The LKAS may not work properly or may work improperly under the certain conditions:


LKAS Conditions and Limitations P. 469

You can read about handling information for the camera equipped with this system.

Front Sensor Camera* P. 445


■ Lane Keep Support Function

Provides assistance to keep the vehicle in the center of the lane. When the vehicle nears a white or yellow line, steering force of the electric power steering will become stronger.



■ Lane Departure Warning Function

When the vehicle enters the warning area, the LKAS alerts you with slight steering wheel vibration as well as a warning display.



∑Lane Keeping Assist System (LKAS)*

The LKAS may not function as designed on while driving in frequent stop and go traffic, or on roads with sharp curves.


When it fails to detect lanes, the system will temporarily be canceled. When lane is detected, system will recover automatically.

When the System can be Used

The system can be used when the following conditions are met.

- The lane in which you are driving has detectable lane markers on both sides, and your vehicle is in the center of the lane.
- The vehicle speed is between 45 and 90 mph (72 and 145 km/h).
- You are driving on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in continuous operation.

■ How to activate the system




- 1. Press the MAIN button.
 - ► The LKAS is on in the multi-information display.

The system is ready to use.

- 2. Press the LKAS button.
 - Lane outlines appear on the multiinformation display.

The system is activated.

If the vehicle drifts toward either left or right lane line due to the system applying torque, turn off the LKAS and have your vehicle checked by a dealer.



- **3.** Keep your vehicle near the center of the lane while driving.
 - ➤ The dotted outer lines change to solid ones once the system starts operating after detecting the left and right lane markings.

When the System can be Used

The LKAS temporarily deactivates when it fails to detect lane lines. When the system detects the lines again, it comes back on automatically.

■ To cancel



To cancel the LKAS:

Press the **MAIN** or LKAS button.

The LKAS is turned off every time you stop the engine, even if you turned it on the last time you drove the vehicle.

∑To cancel

Pressing the **MAIN** button also turns ACC on and off.



When the LKAS is suspended, the lane lines on the multi-information display change to contour lines, and the beeper sounds.

■ The system operation is suspended if you:

- Set the wipers to continuous operation.
 - Turning the wipers off resumes the LKAS.

Models with automatic intermittent wipers

- Set the wiper switch to **AUTO** and the wipers operate continuously.
 - ► The LKAS resumes when the wipers stop or operate intermittently.

All models

- Decrease the vehicle speed to about 40 mph (64 km/h) or less.
 - ► Increasing the vehicle speed to about 45 mph (72 km/h) or more resumes the I KAS
- Depress the brake pedal.
 - ► The LKAS resumes and starts detecting the lane lines again once you release the brake pedal.

■ The LKAS may automatically be suspended when:

- The system fails to detect lane lines.
- The steering wheel is quickly turned.
- You fail to steer the vehicle.
- The vehicle runs on a curved road over the speed limit.
- Driving through a sharp curve.
- Driving at a speed in excess of approximately 90 mph (145 km/h).

Once these conditions no longer exist, the LKAS automatically resumes.

■ The LKAS may automatically be canceled when:

- The camera temperature gets extremely high or low.
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.
- The ABS or VSA system engages.

The beeper sounds if the LKAS is automatically canceled.

LKAS Conditions and Limitations

The system may not detect lane markings and therefore may not keep the vehicle in the middle of a lane under certain conditions, including the following:

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the windshield

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.
- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.
- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white lines (or yellow lines).
- Driving on roads with double lines.


■ Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.

Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System

Helps to stabilize the vehicle during cornering if the vehicle turns more or less than what was intended. It also assists in maintaining traction on slippery surfaces. It does so by regulating engine output and selectively applying the brakes.

■ VSA® Operation



When VSA® activates, you may notice that the engine does not respond to the accelerator. You may also notice some noise from the hydraulic system. You will also see the indicator blink.

■Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System

VSA® may not function properly if tire type and size are mixed. Make sure to use the same size and type of tire, and the air pressures as specified.


When the VSA® indicator comes on and stays on while driving, there may be a problem with the system. While this may not interfere with normal driving, have your vehicle checked by a dealer immediately.

VSA® cannot enhance stability in all driving situations and does not control the entire braking system. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

The main function of the VSA® system is generally known as Electronic Stability Control (ESC). The system also includes a traction control function.

Continued 471

■ VSA® OFF Button



This button is on the driver side control panel. To partially turn the VSA features on and off, press and hold it until you hear a beep.

The traction control stops fully functioning, allows the wheels to spin more freely at low speed. The VSA® OFF indicator will also come on.

To turn it on again, press the (VSA® **OFF**) button until you hear a beep.

VSA® is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System

With the Button pressed, your vehicle will have normal braking and cornering ability, but VSA® traction and stability enhancement becomes less effective.

In certain unusual conditions when your vehicle gets stuck in shallow mud or fresh snow, it may be easier to free it with the VSA® temporarily switched off.


When the B button is pressed, the traction control function becomes less effective. This allows for the wheels to spin more freely at low speed. You should only attempt to free your vehicle with the VSA® off if you are not able to free it when the VSA® is on.

Immediately after freeing your vehicle, be sure to switch VSA® on again. We do not recommend driving your vehicle with the VSA® system switched off.

You may hear a motor sound coming from the engine compartment while system checks are being performed immediately after starting the engine or while driving. This is normal.

LaneWatch™*

Is an assistance system that allows you to check the passenger side rear areas displayed on the audio/information screen when the turn signal is activated to the passenger's side. A camera in the passenger side door mirror monitors these areas and allows you to check for vehicles, in addition to your visual check and use of the passenger door mirror. You can also keep the system on for your convenience while driving.



∑LaneWatch™*

AWARNING

Failure to visually confirm that it is safe to change lanes before doing so may result in a crash and serious injury or death.

Do not rely only on LaneWatch while driving.

Always look in your mirrors, to either side of your vehicle, and behind you for other vehicles before changing lanes.

Important Safety Reminder

Like all assistance systems, LaneWatch has limitations. Over reliance on LaneWatch may result in a collision.

The LaneWatch function can be affected by weather, lighting (including headlights and low sun angle), ambient darkness, camera condition, and loading.

The LaneWatch may not provide the intended display of traffic to the side and rear under the following conditions:

- Your vehicle's suspension has been altered, changing the height of the vehicle.
- Your tires are over or under inflated.
- Your tires or wheels are of varied size or construction.

■ Customizing the LaneWatch settings

You can customize the following items using the audio/information touch screen.

- **Show with Turn Signal**: Selects whether LaneWatch monitor comes on when you operate the turn signal light lever.
- Reference Lines: Selects whether the reference lines appear on the LaneWatch monitor.
- **Display Time after Turn Off**: Changes the remaining LaneWatch display time after you pull the turn signal lever back.
- Display: Adjusts display settings.
 Customized Features P. 316

■ Reference Lines



Three lines that appear on the screen can give an idea of how far the vehicles or objects on the screen are from your vehicle, respectively. If an object is near line 1 (in red), it indicates that it is close to your vehicle whereas an object near line 3 farther away.

LaneWatch™*

The LaneWatch camera view is restricted. Its unique lens makes objects on the screen look slightly different from what they are.

LaneWatch display does not come on when the shift lever is in \boxed{R} .

For proper LaneWatch operation:

- The camera is located in the passenger side door mirror. Always keep this area clean. If the camera lens is covered with dirt or moisture, use a soft, moist cloth to keep the lens clean and free of debris.
- Do not cover the camera lens with labels or stickers of any kind.
- Do not touch the camera lens.

■ Reference Lines

The area around the reference line 1 (red) is very close to your vehicle. As always, make sure to visually confirm the safety of a lane change before changing lanes.

The distance between your vehicle and lines 1, 2 and 3 on the screen vary depending on road conditions and vehicle loading. For example, the reference lines on the screen may seem to appear closer than the actual distances when the rear of your vehicle is more heavily loaded.

Consult a dealer if:

- The passenger side door mirror, or area around it is severely impacted, resulting in changing the camera angle.
- The LaneWatch display does not come on at all.

Tire Pressure Monitoring System (TPMS)

Instead of directly measuring the pressure in each tire, the TPMS on this vehicle monitors and compares the rolling radius and rotational characteristics of each wheel and tire while you are driving to determine if one or more tires are significantly under-inflated. This will cause the low tire pressure/TPMS indicator to come on and a message to appear on the multi-information display*.

■ TPMS Calibration

You must start TPMS calibration every time you:

- Adjust the pressure in one or more tires.
- Rotate the tires.
- Replace one or more tires.

Before calibrating the TPMS:

• Set the cold tire pressure in all four tires.

EXECUTE: ■ Checking Tires P. 537

Make sure:

• The vehicle is at a complete stop.

Manual transmission models

• The shift lever is in **N**.

Automatic transmission/CVT models

• The shift lever is in **P**.

All models

• The ignition switch is in ON III *1.

* Not available on all models

∑Tire Pressure Monitoring System (TPMS)

The system does not monitor the tires when driving at low speed.

Conditions such as low ambient temperature and altitude change directly affect tire pressure and can trigger the low tire pressure/TPMS indicator to come on.

Tire pressure checked and inflated in:

- Warm weather can become under-inflated in colder weather.
- Cold weather can become over-inflated in warmer weather.

The low tire pressure indicator will not come on as a result of over inflation.

The TPMS may not function properly if tire type and size are mixed. Make sure to use the same size and type of tire.

⚠ Checking and Maintaining Tires P. 537


The low tire pressure/TPMS indicator may come on with a delay or may not come on at all when:

- You rapidly accelerate, decelerate, or turn the steering wheel.
- You drive on snowy or slippery roads.
- Snow chains are used.

The low tire pressure/TPMS indicator may come on under the following conditions:

- A compact spare tire is used.
- There is a heavier and uneven load on the tires, such as when towing a trailer, than the condition at calibration.
- Snow chains are used.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.



Group

TPMS Calibration

1/10

Setup

TPMS Calibration

Models with information display

Press and hold the TPMS button until the low tire pressure/TPMS indicator blinks twice, indicating the calibration process has begun.

- If the low tire pressure/TPMS indicator does not blink, confirm the above conditions then press and hold the TPMS button again.
- The calibration process finishes automatically.

Models with multi-information display

You can calibrate the system from the customized features on the multi-information display.

- Press the ▲①/▼ button to select Vehicle Settings, then press the SEL/RESET button.
 - **► TPMS Calibration** appears on the display.
- 2. Press the **SEL/RESET** button.
 - ➤ The display switches to the customization setup screen, where you can select Cancel or Calibrate.
- Press the ▲①/▼ button and select
 Calibrate, then press the SEL/RESET button.
 - ► Calibration Started screen appears, then the display returns to the customization menu screen.
- If the **Calibration Failed to Start** message appears, repeat steps 2-3.
- The calibration process finishes automatically.

TPMS Calibration

- TPMS cannot be calibrated if a compact spare tire is installed.
- The calibration process requires approximately 30 minutes of cumulative driving at speeds between 30-60 mph (48-97 km/h).
- During this period, if the ignition is turned on and the vehicle is not moved within 45 seconds, you may notice the low tire pressure indicator comes on briefly. This is normal and indicates that the calibration process is not yet complete.

You can calibrate the system using the audio/information screen* or audio/information touch screen*.

≧ Customized Features P. 298, 316

If the snow chains are installed, remove them before calibrating the TPMS.

If the low tire pressure/TPMS indicator comes on even when the properly inflated specified regular tires are installed, have the vehicle checked by a dealer.

We recommend that the tires be replaced with the same brand, model, and size as the originals. Ask a dealer for details.



U.S. models

Tire Pressure Monitoring System (TPMS) - Required Federal Explanation

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label.

(If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale



when one or more of your tires is significantly under-inflated.

Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure.

Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Brake System


■ Parking Brake

Use the parking brake to keep the vehicle stationary when parking.



To apply:

Pull the lever fully up without pressing the release button.



To release:

- **1.** Pull the lever slightly, and press and hold the release button.
- **2.** Lower the lever down all the way, then release the button.

▶ Parking Brake

NOTICE

Release the parking brake fully before driving. The rear brakes and axle can be damaged if you drive with the parking brake applied.

If you start driving without fully releasing the parking brake, a buzzer sounds as a warning, and **Release Parking Brake** appears on the multi-information display*.

Always apply the parking brake when parking.

Foot Brake

Your vehicle is equipped with disc brakes at all four wheels. A vacuum power assist helps reduce the effort needed on the brake pedal. The brake assist system increases the stopping force when you depress the brake pedal hard in an emergency situation. The anti-lock brake system (ABS) helps you retain steering control when braking very hard.

Brake Assist System P. 482

▶ Anti-lock Brake System (ABS) P. 481

≫Foot Brake

Check the brakes after driving through deep water, or if there is a buildup of road surface water. If necessary, dry the brakes by lightly depressing the pedal several times.

If you hear a continuous metallic friction sound when applying the brakes, this is caused by the brake wear indicator rubbing on the brake rotor and indicates that the brake pads need to be replaced. Have the vehicle checked by a dealer. If you hear only an occasional squeak or squeal when you initially apply the brake pedal, this may be normal and caused by high frequency vibration of the brake pads against the rotating brake disc.

Constantly using the brake pedal while going down a long hill builds up heat, which reduces the brake effectiveness. Apply engine braking by taking your foot off the accelerator pedal and downshifting to a lower gear. With manual transmission use a lower gear for greater engine braking.

Do not rest your foot on the brake pedal while driving, as it will lightly apply the brakes and cause them to lose effectiveness over time and reduce pad life. It will also confuse drivers behind you.

Anti-lock Brake System (ABS)

ABS

Helps prevent the wheels from locking up, and helps you retain steering control by pumping the brakes rapidly, much faster than you.

The electronic brake distribution (EBD) system, which is part of the ABS, also balances the front-to-rear braking distribution according to vehicle loading.

You should never pump the brake pedal. Let the ABS work for you by always keeping firm, steady pressure on the brake pedal. This is sometimes referred to as "stomp and steer."

■ ABS operation

The brake pedal may pulsate slightly when the ABS is working. Keep holding the pedal firmly down. On dry pavement, you will need to press on the brake pedal very hard before the ABS activates. However, you may feel the ABS activate immediately if you are trying to stop on snow or ice.

When the vehicle speed goes under 6 mph (10 km/h), the ABS stops.

Mari Anti-lock Brake System (ABS)

Mari Anti-

NOTICE

The ABS may not function correctly if you use an incorrect tire type and size.

When the **ABS** indicator comes on while driving, there may be a problem with the system. While normal braking is not affected, there is a possibility of the ABS not operating. Have the vehicle checked by a dealer immediately.

The ABS does not reduce the time or distance it takes to stop the vehicle. It only helps with steering control during hard braking.

In the following cases, your vehicle may need more stopping distance than a vehicle without the ABS:

- When driving on rough road surfaces, including when driving on uneven surfaces, such as gravel or snow.
- When snow chains are installed.

You may hear a motor sound coming from the engine compartment while system checks are being performed immediately after starting the engine or while driving. This is normal.

Brake Assist System

■ Brake Assist System

Designed to assist the driver by generating greater braking force when you depress the brake pedal hard during emergency braking.

■ Brake assist system operation


Press the brake pedal firmly for more powerful braking.

When brake assist operates, the pedal may wiggle slightly and an operating noise may be heard. This is normal. Keep holding the brake pedal firmly down.

Collision Mitigation Braking System™ (CMBS™)*

Can assist you when there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of yours. The CMBS[™] is designed to alert you when a potential collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

■ How the system works



The system starts monitoring the roadway ahead when your vehicle speed is about 3 mph (5 km/h) and there is a vehicle in front of you.

The CMBS™ activates when:

- The speed difference between your vehicle and a vehicle or pedestrian detected in front of you becomes about 3 mph (5 km/h) and over with a chance of a collision.
- Your vehicle speed is about 62 mph (100 km/h) or less and there is a chance of a collision with an oncoming detected vehicle or a pedestrian in front of you.

Collision Mitigation Braking System™ (CMBS™)*

Important Safety Reminder

The CMBSTM is designed to reduce the severity of an unavoidable collision. It does not prevent collision nor stop the vehicle automatically. It is still your responsibility to operate the brake pedal and steering wheel appropriately according to the driving conditions.

The CMBS[™] may not activate or may not detect a vehicle in front of your vehicle under certain conditions:

■ CMBSTM Conditions and Limitations P. 487

You can read about handling information for the camera equipped with this system.

▶ Front Sensor Camera* P. 445

Be careful not to have the radar sensor cover strongly impacted.


Rapid vibrations on the steering wheel alert you when your vehicle speed is between 19 and 62 mph (30 and 100 km/h) with an oncoming vehicle detected in front of you.

When the CMBS™ activates, it may automatically apply the brake. It will be canceled when your vehicle stops or a potential collision is not determined.

■ When the system activates

The system provides visual, audible and tactile alerts of a possible collision, and stops if the collision is avoided.

► Take appropriate action to prevent a collision (apply the brakes, change lanes, etc.)



At system's earliest collision alert stage, you can change the distance (**Long/Normal/Short**) between vehicles at which alerts will come on through multi-information display setting options.

▶ List of customizable options P. 109

■ Vibration alert on the steering wheel

When a potential collision to an oncoming detected vehicle is determined, the system alerts you with rapid vibration on the steering wheel, in addition to visual and audible alerts.

► Take appropriate action to prevent a collision (apply the brakes, operate the steering wheel, etc.).

When the system activates

The camera in the CMBS™ is also designed to detect pedestrians.


However, this pedestrian detection feature may not activate or may not detect a pedestrian in front of your vehicle under certain conditions.

Refer to the ones indicating the pedestrian detection limitations from the list

EXECUTE: Conditions and Limitations P. 487

The head-up warning uses a lens located at the front end of the dashboard.

Do not cover the lens or spill any liquid on it.



Vibration alert function is disabled when the electric power steering (EPS) system indicator comes on.


Electric Power Steering (EPS) SystemIndicator P. 77

■ Collision Alert Stages

The system has three alert stages for a possible collision. However, depending on circumstances, the CMBS™ may not go through all of the stages before initiating the last stage.

Distance between vehicles		CMBS TM			
		The radar sensor detects a vehicle	Audible & Visual WARNINGS	Steering Wheel	Braking
Stage	Normal Vehicle Ahead Your Vehicle	There is a risk of a collision with the vehicle ahead of you.	When in Long , visual and audible alerts come on at a longer distance from a vehicle ahead than in Normal setting, and in Short , at a shorter distance than in Normal .	In case of an oncoming vehicle detected, rapid vibration is provided.	_
Stage two	Your Vehicle Vehicle Ahead	The risk of a collision has increased, time to respond is reduced.			Lightly applied
Stage three	Your Vehicle Vehicle Ahead	The CMBS [™] determines that a collision is unavoidable.	Visual and audible alerts.	_	Forcefully applied

I CMBS™ On and Off



Press this button until the beeper sounds to switch the system on or off.

When the CMBS™ is off:

- The beeper sounds.
- The CMBS™ indicator in the instrument panel comes on.
- A message on the multi-information display reminds you that the system is off.

The CMBS $^{\text{TM}}$ is in the previously selected ON or OFF setting each time you start the engine.

Collision Mitigation Braking System™ (CMBS™)*

The CMBS™ may automatically shut off, and the CMBS™ indicator will come and stay on under certain conditions:

► CMBS™ Conditions and Limitations P. 487

■ CMBS™ Conditions and Limitations

The system may automatically shut off and the CMBS™ indicator will come on under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the CMBS™ functions.

Front Sensor Camera* P. 445

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between objects and the background.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Roadway objects or structures are misinterpreted as vehicles and pedestrians.
- Reflections on the interior of the windshield.

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on curvy, winding, or undulating roads.

■ Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire, etc.).
- When tire chains are installed.
- The vehicle is tilted due to a heavy load or suspension modifications.
- The camera temperature gets too high.
- Driving with the parking brake applied.
- When the radar sensor at the lower part of the front bumper gets dirty.

■ Detection limitations

- A vehicle or pedestrian suddenly crosses in front of you.
- The distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter or other small vehicle
- When there are animals in front of your vehicle.
- When you drive on a curved, winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.
- The speed difference between your vehicle and a vehicle or pedestrian in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Another vehicle suddenly comes in front of you at an intersection, etc.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the lead vehicle suddenly slows down.

Limitations applicable to pedestrian detection only

- When there is a group of people in front of your vehicle walking together side by side.
- Surrounding conditions or belongings of the pedestrian alter the pedestrian's shape, preventing the system from recognizing that the person is a pedestrian.
- When the pedestrian is shorter than about 3.3 feet (1 meter) or taller than about 6.6 feet (2 meters) in height.
- When a pedestrian blends in with the background.
- When a pedestrian is bent over or squatting, or when their hands are raised or they are running.
- When several pedestrians are walking ahead in a group.
- When the camera cannot correctly identify that a pedestrian is present due to an unusual shape (holding luggage, body position, size).

Continued 489

■ With Little Chance of a Collision

The CMBS™ may activate even when you are aware of a vehicle ahead of you, or when there is no vehicle ahead. Some examples of this are:

■ When Passing

Your vehicle approaches another vehicle ahead of you and you change lanes to pass.

■ At an intersection

Your vehicle approaches or passes another vehicle that is making a left or right turn.

On a curve

When driving through curves, your vehicle comes to a point where an oncoming vehicle is right in front of you.

■ Through a low bridge at high speed

You drive under a low or narrow bridge at high speed.

■ Speed bumps, road work sites, train tracks, roadside objects, etc.

You drive over speed bumps, steel road plates, etc., or your vehicle approaches train tracks or roadside objects [such as a traffic sign and guard rail] on a curve or, when parking, stationary vehicles and walls.

Collision Mitigation Braking System™ (CMBS™)*

For the CMBS™ to work properly:

Always keep the radar sensor cover clean.

Never use chemical solvents or polishing powder for cleaning the sensor cover. Clean it with water or a mild detergent.

Do not put a sticker on the radar sensor cover or replace the radar sensor cover.

If you need the radar sensor to be repaired, or removed, or the radar sensor cover is strongly impacted, turn off the system by pressing the $CMBS^{TM}$ off button and take your vehicle to a dealer.

Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

If the front of the vehicle is impacted in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:

- The vehicle mounted onto a bump, curb, chock, embankment, etc.
- You drive the vehicle where the water is deep.
- Your vehicle has a frontal collision.

Parking Your Vehicle

When Stopped

- **1.** Depress the brake pedal firmly.
- 2. Firmly apply the parking brake.

Automatic transmission/CVT models

3. Move the shift lever from **D** to **P**.

Manual transmission models

3. Move the shift lever to \boxed{R} or $\boxed{1}$.

All models

4. Turn off the engine.

Always set the parking brake firmly, in particular if you are parked on an incline.

▶ Parking Your Vehicle

Do not park your vehicle near flammable objects, such as dry grass, oil, or timber.

Heat from the exhaust can cause a fire.

When Stopped

Automatic transmission/CVT models

NOTICE


The following can damage the transmission:

- Depressing the accelerator and brake pedals simultaneously.
- Holding the vehicle in place when facing uphill by depressing the accelerator pedal.
- Moving the shift lever into P before the vehicle stops completely.

Parking Sensor System*

The corner and center sensors monitor obstacles around your vehicle, and the beeper and audio/information screen let you know the approximate distance between your vehicle and the obstacle.

■ The sensor location and range



▶ Parking Sensor System *

Even when the system is on, always confirm if there is no obstacle near your vehicle before parking.

The system may not work properly when:


- The sensors are covered with snow, ice, mud or dirt.
- The vehicle is on uneven surface, such as grass, bumps, or a hill.
- The vehicle has been out in hot or cold weather.
- The system is affected by devices that emit ultrasonic waves.
- Driving in bad weather.

The system may not sense:

- Thin or low objects.
- Sonic-absorptive materials, such as snow, cotton, or sponge.
- Objects directly under the bumper.

Do not put any accessories on or around the sensors.

■ Parking sensor system on and off



With the power mode in ON, press the parking sensor system button to turn on or off the system. The indicator in the button comes on when the system is on.

The rear center and corner sensors start to detect an obstacle when the shift lever is in $\boxed{\mathbf{R}}$, and the vehicle speed is less than 5 mph (8 km/h).

The front corner sensors start to detect an obstacle when the shift lever is in any position other than $\boxed{\mathbf{P}}$, and the vehicle speed is less than 5 mph (8 km/h).

▶ Parking Sensor System *

When you set the power mode to ON, the system will be in the previously selected condition.

■ When the distance between your vehicle and obstacles behind becomes shorter

Length of the	Distance between the Bumper and Obstacle		Indicator	Audio/information screen	
intermittent beep	Corner Sensors	Center Sensors	indicator	Addio/information screen	
Moderate	_	Rear: About 43-24 in (110-60 cm)	Blinks in Yellow*1	WARNING: APPROACHING OBJECT	
Short	About 24-18 in (60-45 cm)	About 24-18 in (60-45 cm)	Blinks in Amber	Indicators light where the	
Very short	About 18-14 in (45-35 cm)	About 18-14 in (45-35 cm)	DIIIIKS III AITIDEI	sensor detects an obstacle.	
Continuous	About 14 in (35 cm) or less	About 14 in (35 cm) or less	Blinks in Red	Indicators light where the sensor detects an obstacle.	

^{*1:}At this stage, only the center sensors detect obstacles.

■ Turning off All Rear Sensors

- **1.** Make sure that the parking sensor system is not activated. Set the power mode to VEHICLE OFF (LOCK).
- **2.** Press and hold the parking sensor system button, and set the power mode to ON.
- **3.** Keep pressing the button for ten seconds. Release the button when the indicator in the button blinks.
- **4.** Press the button again. The indicator in the button goes off.
 - ▶ The beeper sounds twice. The rear sensors are now turned off.

To turn the rear sensors on again, follow the above procedure. The beeper sounds three times when the rear sensors come back on.

■Turning off All Rear Sensors


When you shift to $\boxed{\mathbf{R}}$, the indicator in the parking sensor system button blinks as a reminder that the rear sensors have been turned off.

Multi-View Rear Camera

About Your Multi-View Rear Camera

The audio/information screen can display your vehicle's rear view. The display automatically changes to the rear view when the shift lever is moved to $\boxed{\mathbf{R}}$.

■ Multi-View Rear Camera Display Area



You can view three different camera angles on the rearview display. Press the selector knob or the interface dial to switch the angle.

If the last used viewing mode is Wide or Normal, the same mode is selected the next time you shift into $\boxed{\mathbf{R}}$. If Top View was last used, Wide mode is selected. If you shift out of $\boxed{\mathbf{R}}$ in Top View mode, then shift into $\boxed{\mathbf{R}}$ again 10 seconds later, Wide mode is selected

■ About Your Multi-View Rear Camera

The rear camera view is restricted. You cannot see the corner ends of the bumper or what is underneath the bumper. Its unique lens also makes objects appear closer or farther than they actually are.

Visually confirm that it is safe to drive before backing up. Certain conditions (such as weather, lighting, and high temperatures) may also restrict the rear view. Do not rely on the rearview display which does not give you all information about conditions at the back of your vehicle.

If the camera lens is covered with dirt or moisture, use a soft, moist cloth to keep the lens clean and free of debris.

You can change the **Fixed Guideline** and **Dynamic Guideline** settings.

Customized Features P. 298, 316

Fixed Guideline

On: Guidelines appear when you shift into **R**.

Off: Guidelines do not appear.

Dynamic Guideline

On: Guidelines move according to the steering wheel direction.

Off: Guidelines do not move.

Refueling

Fuel Information

■ Fuel recommendation

Unleaded gasoline, pump octane number 87 or higher

Use of a lower octane gasoline can cause a persistent, heavy metallic knocking noise that can lead to engine damage.

■ Top tier detergent gasoline

Because the level of detergency and additives in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. TOP TIER Detergent Gasoline meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines.

Qualifying gasoline retailers will, in most cases, identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. The proper level of detergent additives, and absence of harmful metallic additives in gasoline, help avoid build-up of deposits in your engine and emission control system.

For further important fuel-related information for your vehicle, or on information on gasoline that does not contain MMT, visit www.hondacars.com. In Canada, visit www.honda.ca for additional information on gasoline. For more information on top tier gasoline, visit www.toptiergas.com.

■ Fuel tank capacity: 17.2 US gal (65 liters)


∑Fuel Information

NOTICE

We recommend quality gasoline containing detergent additives that help prevent fuel system and engine deposits. In addition, in order to maintain good performance, fuel economy, and emissions control, we strongly recommend the use of gasoline that does NOT contain harmful manganese-based fuel additives such as MMT, if such gasoline is available.

Use of gasoline with these additives may adversely affect performance, and cause the malfunction indicator lamp on your instrument panel to come on. If this happens, contact a dealer for service. Some gasoline today is blended with oxygenates such as ethanol. Your vehicle is designed to operate on oxygenated gasoline containing up to 15% ethanol by volume. Do not use gasoline containing methanol. If you notice any undesirable operating symptoms, try another service station or switch to another brand of gasoline.


How to Refuel



- **1.** Stop your vehicle with the service station pump on the left side of the vehicle in the rear.
- 2. Turn off the engine.
- **3.** Push on the fuel fill door release handle at the foot of the driver's seat.
 - ► The fuel fill door opens.



4. Remove the fuel fill cap slowly. If you hear a release of air, wait until this stops, then turn the knob slowly to open the fuel fill cap.



- **5.** Place the fuel fill cap in the holder.
- **6.** Insert the filler nozzle fully.
 - ➤ When the tank is full, the fuel nozzle will click off automatically. This leaves space in the fuel tank in case the fuel expands with a change in the temperature.
- After filling, replace the fuel fill cap, tightening it until you hear it click at least once.
 - ► Shut the fuel fill door by hand.

AWARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

The filler nozzle automatically stops to leave space in the fuel tank so that fuel does not overflow as a result of changes in air temperature.

If the fuel nozzle keeps turning off when the tank is not full, there may be a problem with the pump's fuel vapor recovery system. Try filling at another pump. If this does not fix the problem, consult a dealer.

Do not continue to add fuel after the nozzle has automatically stopped. Additional fuel can exceed the full tank capacity.

Fuel Economy

Improving Fuel Economy

Fuel economy depends on several conditions, including driving conditions, your driving habits, the condition of your vehicle, and loading. Depending on these and other conditions, you may or may not achieve the rated fuel economy of this vehicle.

Maintenance and Fuel Economy

You can optimize your fuel economy with proper maintenance of your vehicle. Always maintain your vehicle in accordance with the messages displayed on the information display*/multi-information display*.

- Use the recommended viscosity engine oil, displaying the API Certification Seal.
- Maintain the specified tire pressure.
- Do not load the vehicle with excess cargo.
- Keep your vehicle clean. A buildup of snow or mud on your vehicle's underside adds weight and increases wind resistance.

Direct calculation is the recommended method to determine actual fuel consumed while driving.



In Canada, posted fuel economy numbers are established following a simulated test. For more information on how this test is performed, please visit http://oee.nrcan.gc.ca/

* Not available on all models 499

Accessories and Modifications

Accessories

When installing accessories, check the following:

- Do not install accessories on the windshield. They can obstruct your view and delay your reaction to driving conditions.
- Do not install accessories over areas marked **SRS AIRBAG**, on the sides or backs of the front seats, on front or side pillars, or near the side windows. Accessories installed in these areas may interfere with proper operation of the vehicle's airbags or may be propelled into you or another occupant if the airbags deploy.
- Be sure electronic accessories do not overload electrical circuits or interfere with proper operation of your vehicle.

Fuses P. 576

 Before installing any electronic accessory, have the installer contact a dealer for assistance. If possible, have a dealer inspect the final installation.

Modifications

Do not modify your vehicle or use non-Honda components that can affect its handling, stability, and reliability.

Overall vehicle performance can be affected. Always make sure all equipment is properly installed and maintained, and that it meets federal, state, province, territory, and local regulations.

■ Accessories and Modifications

AWARNING

Improper accessories or modifications can affect your vehicle's handling, stability, and performance, and cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Honda Genuine accessories are recommended to ensure proper operation on your vehicle.

Maintenance

This chapter discusses basic maintenance.

Before Performing Maintenance	
Inspection and Maintenance	502
Safety When Performing Maintenance.	503
Parts and Fluids Used in Maintenand	ce
Service	504
Maintenance Minder™	505

laintenance Under the Hood	
Maintenance Items Under the Hood!	513
Opening the Hood	515
Recommended Engine Oil	517
Oil Check	518
Adding Engine Oil	520
Changing the Engine Oil and Oil Filter	521

Engine Coolant	523
Transmission Fluid	525
Brake/Clutch Fluid	527
Refilling Window Washer Fluid	528
Replacing Light Bulbs	529
Checking and Maintaining Wiper	
Blades	535
Checking and Maintaining Tires	
Checking Tires	537
Tire and Loading Information Label	538
Tire Labeling	538
DOT Tire Quality Grading (U.S. Vehicles)	. 540
Wear Indicators	542

Tire Service Life	542
Tire and Wheel Replacement	543
Tire Rotation	544
Winter Tires	545
attery	546
emote Transmitter Care	
Replacing the Button Battery	547
limate Control System Maintenance	. 549
leaning	
Interior Care	
Exterior Care	552

Before Performing Maintenance

Inspection and Maintenance

For your safety, perform all listed inspections and maintenance to keep your vehicle in good condition. If you become aware of any abnormality (noise, smell, insufficient brake fluid, oil residue on the ground, etc.), have your vehicle inspected by a dealer. (Note, however, that service at a dealer is not mandatory to keep your warranties in effect.)

■ Types of Inspection and Maintenance

■ Daily inspections

Perform inspections before long distance trips, when washing the vehicle, or when refueling.

■ Periodic inspections

- Check the brake fluid level monthly.
 - **Brake/Clutch Fluid** P. 527
- Check the tire pressure monthly. Examine the tread for wear and foreign objects.
 Checking and Maintaining Tires P. 537
- Check the operation of the exterior lights monthly.
 - Replacing Light Bulbs P. 529
- Check the condition of the wiper blades at least every six months.
 - **≧** Checking and Maintaining Wiper Blades P. 535

U.S. models

Maintenance, replacement, or repair of emissions control devices and systems may be done by any automotive repair establishment or individuals using parts that are "certified" to EPA standards.

According to state and federal regulations, failure to perform maintenance on the maintenance main items marked with # will not void your emissions warranties. However, all maintenance services should be performed in accordance with the intervals indicated by the information display*/multi-information display*.

Maintenance Service Items P. 507, 511

If you want to perform complex maintenance tasks that require more skills and tools, you can purchase a subscription to the Service Express website at www techinfo honda com

Authorized Manuals P. 593

If you want to perform maintenance yourself, make sure that you have the necessary tools and skills first. After performing maintenance, update the records in the separate maintenance booklet.

Safety When Performing Maintenance

Some of the most important safety precautions are given here. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

■ Maintenance Safety

- To reduce the possibility of fire or explosion, keep cigarettes, sparks, and flames away from the battery and all fuel related parts.
- Never leave rags, towels, or other flammable objects under the hood.
 - ▶ Heat from the engine and exhaust can ignite them causing a fire.
- To clean parts, use a commercially available degreaser or parts cleaner, not gasoline.
- Wear eye protection and protective clothing when working with the battery or compressed air.
- $\bullet\,$ Engine exhaust contains carbon monoxide, which is poisonous and can kill you.
 - ▶ Operate the engine only when there is sufficient ventilation.

Vehicle Safety

- The vehicle must be in a stationary condition.
 - ► Make sure your vehicle is parked on level ground, the parking brake is set, and the engine is off.
- Be aware that hot parts can burn you.
 - ► Make sure to let the engine and exhaust system cool thoroughly before touching vehicle parts.
- Be aware that moving parts can injure you.
 - ▶ Do not start the engine unless instructed, and keep your hands and limbs away from moving parts.

Safety When Performing Maintenance

AWARNING

Improperly maintaining this vehicle or failing to correct a problem before driving can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations according to the schedules in this owner's manual.

AWARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

Parts and Fluids Used in Maintenance Service

The use of Honda genuine parts and fluids is recommended when maintaining and servicing your vehicle. Honda genuine parts are manufactured according to the same high quality standards used in Honda vehicles.

If the engine oil life is less than 15%, you will see the Maintenance Minder messages appear on the information display*/multi-information display* every time you turn the ignition switch to ON [II]*1. The messages notify you when to change the engine oil, or when to bring your vehicle to a dealer for indicated maintenance services.


Models with information display

To Use Maintenance Minder™

Displaying the Maintenance Minder Information

Maintenance items, which should be serviced at the same time that you replace the engine oil, appear on the information display.

You can view them on the engine oil life screen at any time.



- **1.** Turn the ignition switch to ON II^{*1}.
- **2.** Press the (Select/Reset) knob repeatedly until the engine oil life appears on the information display.

The Maintenance Minder indicator () stays on in the instrument panel after the engine oil life becomes **0%**. Have the indicated maintenance done by a dealer immediately.

mition switch.

Displaying the Maintenance Minder Information

Based on the engine operating conditions, the remaining engine oil life is calculated and displayed as a percentage.

Displayed Engine Oil Life (%)	Calculated Engine Oil Life (%)	
100	100 to 91	
90	90 to 81	
80	80 to 71	
70	70 to 61	
60	60 to 51	
50	50 to 41	
40	40 to 31	
30	30 to 21	
20	20 to 16	
15	15 to 11	
10	10 to 6	
5	5 to 1	
0	0	

There is a list of maintenance main and sub items you can view on the information display.

► Maintenance Service Items P. 507

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Maintenance Minder Messages on the Information Display

To switch the display, press the (2) (Select/Reset) knob.

Oil Life Display	Explanation	Information	Maintenance Minder Indicator
OLLEFE 2345 15%	The engine oil life indicator starts to appear along with other due soon maintenance item codes when the remaining oil life becomes 15 percent.	The engine oil is approaching the end of its service life.	Starts to come on when the remaining engine oil life becomes 15 percent. It goes off when the display is switched.
SERVICE 23 HS SN.	The SERVICE message also starts to appear along with the engine oil life indicator and the maintenance item codes.	The engine oil has almost reached the end of its service life, and the maintenance items should be inspected and serviced as soon as possible.	
SERVICE 2:345 -:38 <u>F</u>	The remaining engine oil life has passed its service life, and a negative distance appears after driving over 10 miles (U.S. models) or 10 km (Canadian models). The negative distance on the display blinks.	The engine oil life has passed. The maintenance items must be inspected and serviced immediately.	Stays on as a reminder even when the display is switched.

■ Maintenance Service Items



Maintenance Service Items

- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

CODE Maintenance Main Items

- A Replace engine oil*1
- Replace engine oil*1 and oil filter
 - Inspect front and rear brakes/service as necessary
 - Check parking brake adjustment
 - Inspect tie rod ends, steering gearbox, and boots
 - Inspect suspension components
 - Inspect driveshaft boots
 - Inspect brake hoses and lines (Including ABS/VSA)
 - Inspect all fluid levels and condition of fluids
 - Inspect exhaust system#
 - Inspect fuel lines and connections#
- *1: If a message SERVICE does not appear more than 12 months after the display is reset, change the engine oil every year.
- #: See information on maintenance and emissions warranty.


CODE Maintenance Sub Items

- Rotate tires
- Replace air cleaner element*2
 - Replace dust and pollen filter*3
 - Inspect drive belt
- Replace transmission fluid*4,*5
- Replace spark plugs
 - Replace timing belt and inspect water pump*6,*7
 - Inspect valve clearance
 - Replace engine coolant
- *2: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).
- *3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).
- *4: Continuously variable transmission (CVT) models
- *5: Driving in mountainous areas at very low vehicle speeds or trailer towing results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 25,000 miles (40,000 km).
- *6: 6-cylinder models
- *7: If you drive regularly in very high temperatures (over 110 °F, 43 °C), in very low temperatures (under -20 °F, -29 °C), or tow a trailer, replace every 60,000 miles/100,000 km.

Continued 507

Resetting the Display

Reset the maintenance minder information display if you have performed the maintenance service.



- **1.** Turn the ignition switch to ON $[II]^{*1}$.
- 2. Display the engine oil life by repeatedly pressing the (2) (Select/Reset) knob.
- **3.** Press and hold the knob for ten seconds or more.
 - ► The engine oil life indicator and the maintenance item codes blink.
- **4.** Press the knob for five seconds or more.
 - ➤ The displayed maintenance items disappear, and the engine oil life display returns to **100%**.

■ Resetting the Display

NOTICE

Failure to reset the Maintenance Minder™ display after a maintenance service results in the system showing incorrect maintenance intervals, which can lead to serious mechanical problems.

The dealer will reset the Maintenance Minder™ display after completing the required maintenance service. If someone other than a dealer performs maintenance service, reset the Maintenance Minder™ display yourself.

You can reset the Maintenance MinderTM display using the audio/information screen* or audio/information touch screen*.

Customized Features P. 298, 316

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Models with multi-information display


To Use Maintenance Minder™

■ Displaying the Maintenance Minder Information

Maintenance items, which should be serviced at the same time that you replace the engine oil, appear on the multi-information display.

You can view them on the engine oil life screen at any time.

- **1.** Turn the ignition switch to ON II^{*1}.
- 2. Press the ▲①/▼ (Information) button repeatedly until the engine oil life appears on the multi-information display.



Displaying the Maintenance Minder Information ■ Output Displaying the Maintenance Minder Information ■ Displaying the Maintenance Minder Information Displaying the Maintenance Minder Information

Based on the engine operating conditions, the remaining engine oil life is calculated and displayed as a percentage.

Displayed Engine Oil	Calculated Engine Oil		
Life (%)	Life (%)		
100	100 to 91		
90	90 to 81		
80	80 to 71		
70	70 to 61		
60	60 to 51		
50	50 to 41		
40	40 to 31		
30	30 to 21		
20	20 to 16		
15	15 to 11		
10	10 to 6		
5	5 to 1		
0	0		

There is a list of maintenance main and sub items you can view on the information display.

Maintenance Service Items P. 511

Continued 509

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Maintenance Minder Messages on the Multi-Information Display

Maintenance Message	Oil Life Display	Explanation	Information
Maintenance Due Soon Maintenance Due Soon A2345	15 %	The remaining engine oil life is 15 to 6 percent. Once you switch the display by pressing the ▲①/▼ (Information) button, this message will go off.	The engine oil is approaching the end of its service life, and the maintenance items should be inspected and serviced soon.
Maintenance Due Now Maintenance Due Now A2345	5 % Service 1234 1234 1234 1273	The remaining engine oil life is 5 to 1 percent. Press the ▲①/▼ button to switch to another display.	The engine oil has almost reached the end of its service life, and the maintenance items should be inspected and serviced as soon as possible.
Maintenance Past Due Maintenance Past Due 30 miles A2345	Negative Distance Service A2349 -3miles A 123.4 miss	The remaining engine oil life has passed its service life, and a negative distance appears after driving over 10 miles (U.S. models) or 10 km (Canadian models). Press the ▲⑤/▼ button to switch to another display.	The engine oil life has passed. The maintenance items must be inspected and serviced immediately.

The system message indicator (1) comes on along with the Maintenance Minder message.

■ Maintenance Service Items



Maintenance Service Items ■ Maintenanc

- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

A • Replace engine oil*1 B • Replace engine oil*1 and oil filter • Inspect front and rear brakes/service as necessary • Check parking brake adjustment • Inspect tie rod ends, steering gearbox, and boots • Inspect suspension components • Inspect driveshaft boots • Inspect brake hoses and lines (Including ABS/VSA) • Inspect all fluid levels and condition of fluids • Inspect exhaust system# • Inspect fuel lines and connections#

*1: If a message **Service** does not appear more than 12 months after the display is reset, change the engine oil every year.

CODE Maintenance Sub Items


- Rotate tires
- Replace air cleaner element*2
 - Replace dust and pollen filter*3
 - Inspect drive belt
- Replace transmission fluid*4, *5
- Replace spark plugs
 - Replace timing belt and inspect water pump*6, *7
 - Inspect valve clearance
- Replace engine coolant
- *2: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).
- *3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).
- *4: Continuously variable transmission (CVT) models
- *5: Driving in mountainous areas at very low vehicle speeds or trailer towing results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 25,000 miles (40,000 km).
- *6: 6-cylinder models
- *7: If you drive regularly in very high temperatures (over 110 °F, 43 °C), in very low temperatures (under 20 °F, -29 °C), or tow a trailer, replace every 60,000 miles/100,000 km.

Continued

^{#:} See information on maintenance and emissions warranty.

Resetting the Display

Reset the maintenance minder information display if you have performed the maintenance service.



- **1.** Turn the ignition switch to ON II *1.
- 2. Press the ▲①/▼ button to select **Vehicle Settings**, then press the **SEL/RESET** button.
- **3.** Press the **△**①/**▼** button until **Maintenance Reset** appears on the display.
- 4. Press the **SEL/RESET** button.
 - ▶ The oil life reset mode is displayed on the multi-information display.
- **5.** Select **Reset** with the **▲**①**/**▼ button, then press the **SEL/RESET** button.
 - ▶ The displayed maintenance items disappear, and the engine oil life display returns to 100%.

To cancel the oil life reset mode, select **Cancel**, then press the **SEL/RESET** button.

≥ Resetting the Display

NOTICE

Failure to reset the Maintenance Minder™ display after a maintenance service results in the system showing incorrect maintenance intervals, which can lead to serious mechanical problems.

The dealer will reset the Maintenance Minder™ display after completing the required maintenance service. If someone other than a dealer performs maintenance service, reset the Maintenance Minder™ display yourself.

You can reset the Maintenance MinderTM display using the audio/information screen* or audio/information touch screen*.

Customized Features P. 298, 316


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models


Maintenance Under the Hood

Maintenance Items Under the Hood

4-cylinder models



6-cylinder models



Opening the Hood




- **1.** Park the vehicle on a level surface, and set the parking brake.
- **2.** Pull the hood release handle under the lower left corner of the dashboard.
 - ► The hood will pop up slightly.



3. Push up the hood latch lever in the center of the hood to release the lock mechanism, and open the hood.

4-cylinder models



When closing, remove the support rod, and stow it in the clamp, then gently lower the hood. Remove your hand at a height of approximately 12 inches (30 cm) and let the hood close

○ Opening the Hood


NOTICE

Do not open the hood when the wiper arms are raised.

The hood will strike the wipers, and may damage either the hood or the wipers.

When closing the hood, check that the hood is securely latched.

If the hood latch lever moves stiffly, or if you can open the hood without lifting the lever, the latch mechanism should be cleaned and lubricated.



Continued 515



6-cylinder models

- **4.** Lift the hood up most of the way.
 - ► The hydraulic supports will lift it up the rest of the way and hold it up.

When closing, lower it to approximately 12 inches (30 cm), then press down firmly with your hands.

Recommended Engine Oil

- Genuine Honda Motor Oil
- Premium-grade 0W-20 detergent oil with an API Certification Seal on the container.



Oil is a major contributor to your engine's performance and longevity. If you drive the vehicle with insufficient or deteriorated oil, the engine may fail or be damaged.


This seal indicates the oil is energy conserving and that it meets the American Petroleum Institute's latest requirements.

Use Genuine Honda Motor Oil or another commercial engine oil of suitable viscosity for the ambient temperature as shown here.

■ Recommended Engine Oil

Engine Oil Additives

Your vehicle does not require oil additives. In fact, they may adversely affect the engine performance and durability.




■ Synthetic oil

You may also use synthetic motor oil if it is labeled with the API Certification Seal and is the specified viscosity grade.

Oil Check

We recommend that you check the engine oil level every time you refuel. Park the vehicle on level ground.


Wait approximately three minutes after turning the engine off before you check the oil.



- **1.** Remove the dipstick (orange).
- **2.** Wipe the dipstick with a clean cloth or paper towel.
- **3.** Insert the dipstick back all the way into its hole.


≫Oil Check

If the oil level is near or below the lower mark, slowly add oil being careful not to overfill.



4. Remove the dipstick again, and check the level. It should be between the upper and lower marks. Add oil if necessary.

Adding Engine Oil



- **1.** Unscrew and remove the engine oil fill cap.
- 2. Add oil slowly.
- **3.** Reinstall the engine oil fill cap, and tighten it securely.
- **4.** Wait for three minutes and recheck the engine oil dipstick.

■ Adding Engine Oil

If any oil spills, wipe it away immediately. Spilled oil may damage the engine compartment components.


NOTICE

Do not fill the engine oil above the upper mark. Overfilling the engine oil can result in leaks and engine damage.

Changing the Engine Oil and Oil Filter

You must change the engine oil and oil filter regularly in order to maintain the engine's lubrication. The engine may be damaged if they are not changed regularly.

Change the oil and filter in accordance with the maintenance message on the information display*/multi-information display*.




- **1.** Run the engine until it reaches normal operating temperature, and then turn the engine off.
- **2.** Open the hood and remove the engine oil fill cap.
- **3.** Remove the drain bolt and washer from the bottom of the engine, and drain the oil into a suitable container.

∑Changing the Engine Oil and Oil Filter

NOTICE

You may damage the environment if you do not dispose of the oil in a suitable way. If you are changing the oil by yourself, appropriately dispose of the used oil. Put the oil in a sealed container and take it to a recycling center. Do not throw the oil away into a garbage can or onto the ground.



- **4.** Remove the oil filter and dispose of the remaining oil.
- **5.** Check that the filter gasket is not stuck to the engine contact surface.
 - If it is stuck, you must detach it.
- **6.** Wipe away dirt and dust adhering to the contact surface of the engine block, and install a new oil filter.
 - Apply a light coat of new engine oil to the oil gasket.
- **7.** Put a new washer on the drain bolt, then reinstall the drain bolt.
 - ► Tightening torque:

4-cylinder models

30 lbf·ft (40 N·m, 4.0 kgf·m)

6-cylinder models

29 lbf·ft (39 N·m, 4.0 kgf·m)

- 8. Pour the recommended engine oil into the engine.
 - Engine oil change capacity (including filter):

4-cylinder models

4.4 US at (4.2 L)

6-cylinder models

4.5 US at (4.3 L)

- **9.** Reinstall the engine oil fill cap securely and start the engine.
- **10.** Run the engine for a few minutes, and then check that there is no leak from the drain bolt or oil filter.
- 11. Stop the engine, wait for three minutes, and then check the oil level on the dipstick.If necessary, add more engine oil.

∑Changing the Engine Oil and Oil Filter

You will need a special wrench to replace the oil filter. You can buy this wrench from a dealer.

When installing the new oil filter, follow the instructions supplied with the oil filter.

Reinstall the engine oil fill cap. Start the engine. The low oil pressure indicator should go off within five seconds. If it does not, turn off the engine, and check your work.


Engine Coolant

Specified coolant: Honda Long Life Antifreeze/Coolant Type 2

This coolant is premixed with 50% antifreeze and 50% water. Do not add any straight antifreeze or water.

We recommend you check the engine coolant level every time you refuel. Check the reserve tank first. If it is completely empty, also check the coolant level in the radiator. Add the engine coolant accordingly.

Reserve Tank



1. Check the amount of coolant in the reserve tank.



- If the coolant level is below the MIN mark, add the specified coolant until it reaches the MAX mark.
- **3.** Inspect the cooling system for leaks.

NOTICE


If temperatures consistently below –22°F (–30°C) are expected, the coolant mixture should be changed to a higher concentration. Consult a dealer for more information.

If Honda antifreeze/coolant is not available, you may use another major brand non-silicate coolant as a temporary replacement. Check that it is a high quality coolant recommended for aluminum engines. Continued use of any non-Honda coolant can result in corrosion, causing the cooling system to malfunction or fail. Have the cooling system flushed and refilled with Honda antifreeze/coolant as soon as possible.

Do not add rust inhibitors or other additives to your vehicle's cooling system. They may not be compatible with the coolant or with the engine components.

Continued 523

Radiator



- Make sure the engine and radiator are cool.
- **2.** Turn the radiator cap counterclockwise to relieve any pressure in the cooling system. Do not push the cap down when turning.
- **3.** Push down and turn the radiator cap counterclockwise to remove it.
- **4.** The coolant level should be up to the base of the filler neck. Add coolant if it is low.
- **5.** Put the radiator cap back on, and tighten it fully.
- **6.** Pour coolant into the reserve tank until it reaches the **MAX** mark. Put the cap back on the reserve tank.

AWARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

NOTICE

Pour the fluid slowly and carefully so you do not spill any. Clean up any spills immediately; they can damage components in the engine compartment.

Transmission Fluid

4-cylinder models with continuously variable transmission (CVT)

■ Continuously Variable Transmission (CVT) Fluid

Specified fluid: HCF-2

Have a dealer check the fluid level and replace if necessary.

4-cylinder/6-cylinder models with manual transmission

Manual Transmission Fluid

Specified fluid: Honda Manual Transmission Fluid (MTF)

Have a dealer check the fluid level and replace if necessary.

○ Continuously Variable Transmission (CVT) Fluid

NOTICE

Do not mix HCF-2 with other transmission fluids.

Using a transmission fluid other than HCF-2 may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission. Any damage caused by using a transmission fluid that is not equivalent to HCF-2 is not covered by Honda's new vehicle warranty.

Manual Transmission Fluid

If Honda MTF is not available, you may use the API certificated SAE 0 W-20 or 5 W-20 viscosity motor oil as a temporary measure.

Replace with MTF as soon as possible. Motor oil does not contain the proper additives for the transmission and continued use can cause decreased shifting performance and lead to transmission damage.

Continued 525

6-cylinder models with automatic transmission

Automatic Transmission Fluid

Specified fluid: Honda ATF DW-1 (automatic transmission fluid)

Have a dealer check the fluid level and replace if necessary.

■ Automatic Transmission Fluid

NOTICE

Do not mix Honda ATF DW-1 with other transmission fluids.

Using a transmission fluid other than Honda ATF DW-1 may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission.


Any damage caused by using a transmission fluid that is not equivalent to Honda ATF DW-1 is not covered by Honda's new vehicle warranty.

Brake/Clutch Fluid

Specified fluid: Honda Heavy Duty Brake Fluid DOT 3

Use the same fluid for both the brakes and clutch.


Checking the Brake Fluid



The fluid level should be between the **MIN** and **MAX** marks on the side of the reservoir.

Manual transmission models

Checking the Clutch Fluid



The fluid level should be between the **MIN** and **MAX** marks on the side of the reservoir.

■Brake/Clutch Fluid

NOTICE

Brake fluid marked DOT 5 is not compatible with your vehicle's braking system and can cause extensive damage.

If the specified brake fluid is not available, you should use only DOT 3 or DOT 4 fluid from a sealed container as a temporary replacement.

Using any non-Honda brake fluid can cause corrosion and decrease the longevity of the system. Have the brake system flushed and refilled with Honda Heavy Duty Brake Fluid DOT 3 as soon as possible.

If the brake fluid level is at or below the **MIN** mark, have a dealer inspect the vehicle for leaks or worn brake pads as soon as possible.

∑Checking the Clutch Fluid

If the clutch fluid level is at or below the **MIN** mark, have a dealer inspect for leaks or an excessively worn clutch plate as soon as possible.

Refilling Window Washer Fluid

Check the amount of window washer fluid by looking at the reservoir.

If the level is low, fill the washer reservoir.

Canadian models with information display

If the washer fluid is low, the washer level indicator comes on.

Canadian models with multi-information display

If the washer fluid is low, a message appears on the multi-information display.

All models

Pour the washer fluid carefully. Do not overflow the reservoir.

≥ Refilling Window Washer Fluid

NOTICE

Do not use engine antifreeze or a vinegar/water solution in the windshield washer reservoir. Antifreeze can damage your vehicle's paint. A vinegar/water solution can damage the windshield washer pump.

Replacing Light Bulbs

Headlight Bulbs

When replacing, use the following bulbs.

High beam headlight: LED type*


High beam headlight: 60 W (HB3 for halogen bulb type)*

Low beam headlight: LED type*

Low beam headlight: 55 W (H11 for halogen bulb type)*

High Beam Headlights

Models with halogen headlights



Driver side

6-cylinder models

1. Unlock the holding clips, then remove the upper part of the air intake duct and the air intake tube.

Passenger side

All models

1. Remove the reserve tank.

Models with halogen headlights

NOTICE

Halogen bulbs get very hot when lit.

Oil, perspiration, or a scratch on the glass can cause the bulb to overheat and shatter.

All models

The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the trunk or tow a trailer, have the aiming readjusted at a dealer or by a qualified technician.


Models with halogen headlights

When replacing a halogen bulb, handle it by its base, and protect the glass from contact with your skin or hard objects. If you touch the glass, clean it with denatured alcohol and a clean cloth.

Models with LED headlights

High beam headlights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.







- 2. Push the tab to remove the coupler.
- **3.** Rotate the old bulb counter-clockwise to remove.
- **4.** Insert a new bulb into the headlight assembly and turn it clockwise.
- **5.** Insert the coupler into the connector of the bulb.

Holding clip

Press down the center pin until it clicks to unlock it.



Push the center pin back to lock the clip. Then, insert the clip into the hole and press on the center pin until it is flat.




≫Low Beam Headlights

Models with LED headlights

Low beam headlights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

■ Low Beam Headlights

Models with halogen headlights



- **1.** Push the tab to remove the coupler.
- **2.** Rotate the old bulb counter-clockwise to remove.
- **3.** Insert a new bulb into the headlight assembly and turn it clockwise.
- **4.** Insert the coupler into the connector of the bulb.

Fog Lights*

Fog lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

Models with LED headlights

Front Turn Signal Lights

Front turn signal lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

Models with LED headlights

Front Side Marker Lights

Front side marker lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

Models with LED type parking/daytime running lights

Parking/Daytime Running Lights

Parking/daytime running lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

Side Turn Signal/Emergency Indicator Lights*

Door mirror side turn lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

* Not available on all models

Models with halogen headlights and LED type parking/daytime running lights

Front Turn Signal/Side Marker Light Bulbs

Models with halogen headlights and bulb type parking lights

Front Turn Signal/Side Marker/Parking Light Bulbs


When replacing, use the following bulbs.


Models with halogen headlights and LED type parking/daytime running lights

Front Turn Signal/Side Marker Light: 28/8 W (Amber)

Models with halogen headlights and bulb type parking lights

Front Turn Signal/Side Marker/Parking Light: 28/8 W (Amber)






 Turn the steering wheel all the way to the opposite side from the light being replaced.
 Passenger side: Turn the steering wheel to the left.

Driver side: Turn the steering wheel to the right.


- **2.** Remove the holding clips and screw, and pull the inner fender back.
- **3.** Turn the socket counter-clockwise and remove it.
- **4.** Remove the old bulb and insert a new bulb.

∑Front Turn Signal/Side Marker Light Bulbs

Insert a flat-tip screwdriver, lift and remove the center pin to remove the clip.



Insert the clip with the center pin raised, and push until it is flat.




Brake Light, Back-Up Light, Rear Turn Signal Light Bulbs and Rear Side Marker/Taillights


When replacing, use the following bulbs.

Brake Light: 21 W Back-Up Light: 16 W

Rear Turn Signal Light: 21 W (Amber)
Rear Side Marker/Taillight: LED



- **1.** Remove the cargo hook by squeezing the tabs on both sides
- **2.** Remove the holding clips using a flat-tip screwdriver, then pull the lining back.




- **3.** Turn the socket counter-clockwise and remove it.
- **4.** Remove the old bulb and insert a new bulb


▶ Brake Light, Back-Up Light, Rear Turn Signal Light Bulbs and Rear Side Marker/Taillights

Rear side marker/taillights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

When removing the clip, insert a flat-tip screwdriver, then lift and remove the clip.




Insert the clip with the pin raised, and push until it is flat.




Rear License Plate Light Bulbs

When replacing, use the following bulbs.

Rear License Plate Light: 5 W



1. Remove the lens by carefully prying on its left edge with a small flat-tip screwdriver.



2. Remove the old bulb and insert a new bulb.

High-Mount Brake Light

High-mount brake light is LED type. Have an authorized Honda dealer inspect and replace the light assembly.

Checking and Maintaining Wiper Blades


Checking Wiper Blades

If the wiper blade rubber has deteriorated, it will leave streaks and the hard surfaces of the blade may scratch the window glass.

Changing the Wiper Blade Rubber



1. Lift the driver side wiper arm first, then the passenger side.




2. Press and hold the tab, then slide the blade from the wiper arm.


NOTICE

Avoid dropping the wiper arm; it may damage the windshield.

Continued 535




3. Slide the wiper blade out from its holder by pulling the tabbed end out.



4. Remove the retainers from the rubber blade that has been removed, and mount to a new rubber blade.

Correctly align the rubber protrusion and the retainer grooves.



- **5.** Slide the new wiper blade onto the holder from the bottom end.
 - ➤ The tab on the holder should fit in the indent of the wiper blade.
- **6.** Slide the wiper blade onto the wiper arm, then push down the lock tab.
- **7.** Lower the passenger side wiper arm first, then the driver side.

Checking and Maintaining Tires

Checking Tires

To safely operate your vehicle, your tires must be of the proper type and size, in good condition with adequate tread, and properly inflated.

■ Inflation guidelines

Properly inflated tires provide the best combination of handling, tread life, and comfort. Refer to the driver's doorjamb label or specification's page for the specified pressure.

Underinflated tires wear unevenly, adversely affect handling and fuel economy, and are more likely to fail from overheating.

Overinflated tires make your vehicle ride harshly, are more prone to road hazards, and wear unevenly.

Every day before you drive, look at each of the tires. If one looks lower than the others, check the pressure with a tire gauge.

At least once a month or before long trips, use a gauge to measure the pressure in all tires, including the spare. Even tires in good condition can lose 1 to 2 psi (10 to 20 kPa, 0.1 to 0.2 kgf/cm²) per month.

■ Inspection guidelines

Every time you check inflation, also examine the tires and valve stems. Look for:

- Bumps or bulges on the side or in the tread. Replace the tire if you find any cuts, splits, or cracks in the side of the tire. Replace it if you see fabric or cord.
- Remove any foreign objects and inspect for air leaks.
- Uneven tread wear. Have a dealer check the wheel alignment.
- Excessive tread wear.

Wear Indicators P. 542

• Cracks or other damage around valve stem.

■ Checking Tires

AWARNING

Using tires that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tire inflation and maintenance.

Measure the air pressure when tires are cold. This means the vehicle has been parked for at least three hours, or driven less than 1 mile (1.6 km). If necessary, add or release air until the specified pressure is reached.

If checked when hot, tire pressure can be as much as 4–6 psi (30–40 kPa, 0.3–0.4 kgf/cm²) higher than if checked when cold.

Whenever tire pressure is adjusted, you must calibrate the TPMS.


TPMS Calibration P. 475

Have a dealer check the tires if you feel a consistent vibration while driving. New tires and any that have been removed and reinstalled should be properly balanced.


Check the spare tire pressure once a month or before long trips.

Tire and Loading Information Label

The label attached to the driver's doorjamb provides necessary tire and loading information.



Tire Labeling



The tires that came on your vehicle have a number of markings. Those you should be aware of are described below.

■ Tire Sizes

Whenever tires are replaced, they should be replaced with tires of the same size.

∑Tire and Loading Information Label

The tire and loading information label attached to the driver's doorjamb contains:

- 1 The number of people your vehicle can carry.
- 2 The total weight your vehicle can carry. Do not exceed this weight.
- 3 The original tire sizes for front, rear, and spare.
- **4** The proper cold tire pressure for front, rear, and spare.

∑Tire Sizes

Following is an example of tire size with an explanation of what each component means.

215/55R17 94V

- 215. Tire width in millimeters
- 55: Aspect ratio (the tire's section height as a percentage of its width).
- R: Tire construction code (R indicates radial).
- 17: Rim diameter in inches.
- 94: Load index (a numerical code associated with the maximum load the tire can carry).
- V: Speed symbol (an alphabetical code indicating the maximum speed rating).

■ Tire Identification Number (TIN)

The tire identification number (TIN) is a group of numbers and letters that look like the example in the side column. TIN is located on the sidewall of the tire.

■ Glossary of Tire Terminology

Cold Tire Pressure – The tire air pressure when the vehicle has been parked for at least three hours or driven less than 1 mile (1.6 km).

Load Rating – Means the maximum load that a tire is rated to carry for a given inflation pressure.

Maximum Inflation Pressure – The maximum tire air pressure that the tire can hold

Maximum Load Rating – Means the load rating for a tire at the maximum permissible inflation pressure for that tire.

Recommended Inflation Pressure – The cold tire inflation pressure recommended by the manufacturer.

Treadwear Indicators (TWI) – Means the projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread.

∑Tire Identification Number (TIN)

DOT B97R FW6X 2209

DOT: This indicates that the tire meets all requirements of the U.S. Department of Transportation.

B97R: Manufacturer's identification mark.

FW6X: Tire type code. 22 09: Date of manufacture.

Year Week

DOT Tire Quality Grading (U.S. Vehicles)

The tires on your vehicle meet all U.S. Federal Safety Requirements. All tires are also graded for treadwear, traction, and temperature performance according to Department of Transportation (DOT) standards. The following explains these gradings.

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half (1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Uniform Tire Quality Grading

For example:
Treadwear 200
Traction AA
Temperature A

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

■ Traction

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

Temperature

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.


>>> Traction

Warning: The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

∑Temperature

Warning: The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Wear Indicators



The groove where the wear indicator is located is 1/16 inch (1.6 mm) shallower than elsewhere on the tire. If the tread has worn so that the indicator is exposed, replace the tire. Worn out tires have poor traction on wet roads.

Tire Service Life

The life of your tires is dependent on many factors, including driving habits, road conditions, vehicle loading, inflation pressure, maintenance history, speed, and environmental conditions (even when the tires are not in use).

In addition to regular inspections and inflation pressure maintenance, it is recommended that you have annual inspections performed once the tires reach five years old. All tires, including the spare, should be removed from service after 10 years from the date of manufacture, regardless of their condition or state of wear.

○ Checking Tires

Models with 235/45R18 tires*1

Models with 235/40R19 tires

High speed driving

We recommend that you do not drive faster than the posted speed limits and conditions allow. If you drive at sustained high speeds (over 99 mph or 160 km/h), adjust the cold tire pressures as shown below to avoid excessive heat build up and sudden tire failure.

Models with 235/45R18 tires*1

Tire Size	235/45R18 94V
Pressure	Front: 35 psi (240 kPa, 2.4 kgf/cm²)
	Rear: 35 psi (240 kPa, 2.4 kgf/cm²)

^{*1:} Except Canadian models

Models with 235/40R19 tires

Tire Size	235/40R19 96V
	Front: 38 psi (260 kPa, 2.6 kgf/cm²)
	Rear: 35 psi (240 kPa, 2.4 kgf/cm²)

Tire and Wheel Replacement

Replace your tires with radials of the same size, load range, speed rating, and maximum cold tire pressure rating (as shown on the tire's sidewall). Using tires of a different size or construction can cause the ABS and vehicle stability assist (VSA®) system to work incorrectly.

It is best to replace all four tires at the same time. If that isn't possible, replace the front or rear tires in pairs.

Make sure that the wheel's specifications match those of the original wheels.

∑Tire and Wheel Replacement

AWARNING


Installing improper tires on your vehicle can affect handling and stability. This can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.

Tire Rotation


Rotating tires according to the maintenance messages on the information display*/ multi-information display* helps to distribute wear more evenly and increase tire life.

■ Tires without rotation marks



Rotate the tires as shown here


■ Tires with rotation marks



Rotate the tires as shown here.

∑Tire Rotation

Tires with directional tread patterns should only be rotated front to back (not from one side to the other). Directional tires should be mounted with the rotation indication mark facing forward, as shown below.



Whenever tires are rotated, you must calibrate the TPMS

TPMS Calibration P. 475

Winter Tires

If driving on snowy or frozen roads, mount all season marked **M+S** tires, snow tires, or tire chains; reduce speed; and maintain sufficient distance between vehicles when driving.

Be particularly careful when operating the steering wheel or brakes to prevent skidding.

Use tire chains, snow tires, or all season tires when necessary or according to the law.

When mounting, refer to the following points.

For winter tires:

- Select the size and load ranges that are the same as the original tires.
- Mount the tires to all four wheels.

For tire chains:

- Install them on the front tires only.
- Because your vehicle has limited tire clearance, we strongly recommend using the chains listed below:

Models with 215/55R17 tires

Cable-type: SCC Radial Chain SC1034

Models with 235/45R18 tires
Models with 235/40R19 tires

Cable-type: SCC Radial Chain SC1040

- Follow the chain manufacturer's instruction when installing. Mount them as tightly as you can.
- Check that the chains do not touch the brake lines or suspension.
- Drive slowly.

Winter Tires

AWARNING

Using the wrong chains, or not properly installing chains, can damage the brake lines and cause a crash in which you can be seriously injured or killed.

Follow all instructions in this owner's manual regarding the selection and use of tire chains.

NOTICE

Traction devices that are the wrong size or improperly installed can damage your vehicle's brake lines, suspension, body, and wheels. Stop driving if they are hitting any part of the vehicle.

When tire chains are mounted, follow the chain manufacturer's instructions regarding vehicle operational limits.

If your vehicle is equipped with summer tires, be aware that these tires are not designed for winter driving conditions. For more information, contact a dealer.

Battery

Checking the Battery



Check the battery terminals for corrosion monthly.

The battery condition is being monitored by the sensor on the negative terminal. If there is a problem with the sensor, the warning message on the information display*/multi-information display* will let you know. Have your vehicle checked by a dealer.

If your vehicle's battery is disconnected or goes dead:

- The audio system is disabled.
 - Reactivating the audio system P. 189
- The clock resets.
 - **Clock** P. 116
- The navigation system* is disabled.
 - Refer to the Navigation System Manual

Charging the Battery

Disconnect both battery cables to prevent damaging your vehicle's electrical system. Always disconnect the negative (–) cable first, and reconnect it last.

Battery

AWARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.

When conducting any battery maintenance, wear protective clothing and a face shield, or have a skilled technician do it.

WARNING: Battery post, terminals, and related accessories contain lead and lead compounds.

Wash your hands after handling.

When you find corrosion, clean the battery terminals by applying a baking powder and water solution. Clean the terminals with a damp towel. Cloth/towel dry the battery. Coat the terminals with grease to help prevent future corrosion.

When replacing the battery, the replacement must be of the same specifications.


Please consult a dealer for more information.

Remote Transmitter Care

Replacing the Button Battery

If the indicator does not come on when the button is pressed, replace the battery.


■ Master Keys with Remote Transmitter*



Battery

Battery type: CR1620

- **1.** Unscrew the cover with a small Phillipshead screwdriver.
- **2.** Open the remote transmitter.
 - ➤ Wrap the small flat-tip screwdriver with a cloth to prevent scratching the transmitter.



4. Make sure to replace the battery with the correct polarity.

■ Replacing the Button Battery

NOTICE

An improperly disposed of battery can damage the environment. Always confirm local regulations for battery disposal.


Replacement batteries are commercially available or at a dealer.

■ Smart Entry Remote*



Battery type: CR2032

1. Remove the built-in key.



- **2.** Remove the upper half of the cover by carefully prying on the edge with a coin.
 - ► Remove carefully to avoid losing the buttons.
 - ► Wrap a coin with a cloth to prevent scratching the smart entry remote.
- **3.** Make sure to replace the battery with the correct polarity.

Climate Control System Maintenance

Dust and Pollen Filter

The climate control system is equipped with a dust and pollen filter that collects pollen, dust, and other debris in the air. The Maintenance Minder $^{\text{TM}}$ messages will let you know when to replace the filter.

We recommend that you replace the dust and pollen filter sooner when using your vehicle in areas with high concentrations of dust.

Dust and Pollen Filter

If the airflow from the climate control system deteriorates noticeably, and the windows fog up easily, the filter may need to be replaced. Please contact a dealer for replacement.


Cleaning

Interior Care

Use a damp cloth with a mixture of mild detergent and warm water to remove dirt. Use a clean cloth to remove detergent residue.

Cleaning Seat Belts

Use a soft brush with a mixture of mild soap and warm water to clean the seat belts. Let the belts air dry. Wipe the openings of the seat belt anchors using a clean cloth.



Cleaning the Window

Wipe using a glass cleaner.

Do not spill liquids inside the vehicle.

Electrical devices and systems may malfunction if liquids are splashed on them.

Do not use silicone based sprays on electrical devices such as audio devices and switches.

Doing so may cause the items to malfunction or a fire inside the vehicle.

If a silicone based spray is inadvertently used on electrical devices, consult a dealer.

Depending on their composition, chemicals and liquid aromatics may cause discoloration, wrinkles, and cracking to resin-based parts and textiles. Do not use alkali solvents or organic solvents such as benzene or gasoline.


After using chemicals, make sure to gently wipe them away using a dry cloth.

Do not place used cloths on top of resin based parts or textiles for long periods of time without washing.

○ Cleaning the Window

Wires are mounted to the inside of the rear window. Wipe along the same direction as the wires with a soft cloth so as not to damage them.

■ Floor Mats



The floor mats for the driver, and the rear passenger on the passenger's side hook over the floor anchors, which keep the mats from sliding forward. To remove a mat for cleaning, turn the anchor knobs to the unlock position. When reinstalling the mat after cleaning, turn the knobs to the lock position.

Do not put additional floor mats on top of the anchored mat.

≫Floor Mats

If you use any floor mats that were not originally provided with your vehicle, make sure they are designed for your specific vehicle, fit correctly, and are securely anchored by the floor anchors. Position the rear seat floor mats properly. If they are not properly positioned, the floor mats can interfere with the front seat functions.

■ Maintaining Genuine Leather*

Vacuum dirt and dust from the leather frequently. Pay close attention to the pleats and seams. Clean the leather with a soft cloth dampened with a 90% water and 10% neutral soap solution. Then buff it with a clean, dry cloth. Remove any dust or dirt on leather surfaces immediately.

* Not available on all models

Exterior Care

Dust off the vehicle body after you drive.

Regularly inspect your vehicle for scratches on painted surfaces. A scratch on a painted surface can result in body rust. If you find a scratch, promptly repair it.

■ Washing the Vehicle

Wash the vehicle regularly. Wash more frequently when driving in the following conditions:

- If driving on roads with road salt.
- If driving in coastal areas.
- If tar, soot, bird droppings, insects, or tree sap are stuck to painted surfaces.

Using an Automated Car Wash

- Make sure to follow the instructions indicated on the automated car wash.
- Fold in the door mirrors.
- Turn off the automatic intermittent wipers*.

Using High Pressure Cleaners

- Keep sufficient distance between the cleaning nozzle and the vehicle body.
- Take particular care around the windows. Standing too close may cause water to enter the vehicle interior. Do not spray water into the engine compartment.
- Do not spray high pressure water directly into the engine compartment. Instead, use low pressure water and a mild detergent.

≥ Washing the Vehicle

Do not spray water into the air intake vents. It can cause a malfunction.



Applying Wax

A good coat of automotive body wax helps protect your vehicle's paint from the elements. Wax will wear off over time and expose your vehicle's paint to the elements, so reapply as necessary.

■ Maintaining the Bumpers and Other Resin Coated Parts

If you get gasoline, oil, engine coolant, or battery fluid on resin coated parts, they may be stained or the coating may peel. Promptly wipe it away using a soft cloth and clean water.

Cleaning the Window

Wipe using a glass cleaner.

Maintaining Aluminum Wheels

Aluminum is susceptible to deterioration caused by salt and other road contaminants. Use a sponge and mild detergent to wipe away promptly. Be careful not to use harsh chemicals (including some commercial wheel cleaners) or a stiff brush. They can damage the clear coat of the aluminum alloy wheels that helps keep the aluminum from corroding and tarnishing.

■ Applying Wax

NOTICE

Chemical solvents and strong cleaners can damage the paint, metal, and plastic on your vehicle. Wipe away spills immediately.

Maintaining the Bumpers and Other Resin Coated Parts

Ask a dealer about the correct coating material when you want to repair the painted surface of the parts made of resin.

Continued 553

■ Fogged Exterior Light Lenses

The inside lenses of exterior lights (headlights, brake lights, etc.) may fog temporarily if you have driven in the rain, or after the vehicle has been run through a car wash. Dew condensation also may build up inside the lenses when there is a significant enough difference between the ambient and inside lens temperatures (similar to vehicle windows fogging up in rainy conditions). These conditions are natural processes, not structural design problems in the exterior lights.

Lens design characteristics may result in moisture developing on the light lens frame surfaces. This also is not a malfunction.

However, if you see large amounts of water accumulation, or large water drops building up inside the lenses, have your vehicle inspected by a dealer.


Handling the Unexpected

This chapter explains how to handle unexpected troubles.

10015	
Types of Tools	556
If a Tire Goes Flat	
Changing a Flat Tire	557
Engine Does Not Start	
Checking the Engine	563
If the Smart Entry Remote	Battery is
Weak	564
Emergency Engine Stop	565
Jump Starting	566
Shift Lever Does Not Move	569

If the Electric Power Steering (EPS) Sy	ystem
Indicator Comes On	574
If the Low Tire Pressure/TPMS Indica	tor
Comes On or Blinks	575
uses	
Fuse Locations	576
Inspecting and Changing Fuses	579
mergency Towing	. 580

Types of Tools



∑Types of Tools

The tools are stored in the trunk.

If a Tire Goes Flat

Changing a Flat Tire

If a tire goes flat while driving, grasp the steering wheel firmly, and brake gradually to reduce speed. Then, stop in a safe place. Replace the flat tire with a compact spare tire. Go to a dealer as soon as possible to have the full-size tire repaired or replaced.

1. Park the vehicle on firm, level, and non-slippery surface, and apply the parking brake.

Automatic transmission/CVT models

2. Move the shift lever to P.

Manual transmission models

2. Move the shift lever to **R**.

All models

3. Turn on the hazard warning lights and turn the ignition switch to LOCK 0^{*1} .

○ Changing a Flat Tire

Follow these compact spare precautions: Periodically check the tire pressure of the compact spare. It should be set to the specified pressure. Specified Pressure: 60 psi (420 kPa, 4.2 kgf/cm²)

When driving with the compact spare tire, keep the vehicle speed under 50 mph (80 km/h). Replace with a full-size tire as soon as possible.

The compact spare tire and wheel in your vehicle are specifically for this model. Do not use them with another vehicle. Do not use another type of compact spare tire or wheel with your vehicle.

Do not mount tire chains on a compact spare tire. If a chain-mounted front tire goes flat, remove one of the full-size rear tires and replace it with the compact spare tire. Remove the flat front tire and replace it with the full-size tire that was removed from the rear. Mount the tire chains on the front tire.

Do not use the jack if it doesn't work properly. Call your dealer or a professional towing service.

Continued 557

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.


■ Getting Ready to Replace the Flat Tire



1. Open the trunk floor lid.



- **2.** Take the tool case out of the trunk. Take the jack and wheel nut wrench out of the tool case.
- **3.** Unscrew the wing bolt, and remove the spacer cone. Then, remove the spare tire.



4. Place a wheel block or rock in front and rear of the wheel diagonal to the flat tire.




5. Place the compact spare tire (wheel side up) under the vehicle body, near the tire that needs to be replaced.




6. Loosen each wheel nut about one turn using the wheel nut wrench.

Continued 559

■ How to Set Up the Jack



1. Place the jack under the jacking point closest to the tire to be changed.



3. Raise the vehicle, using the jack handle bar and the jack handle, until the tire is off the ground.


2. Turn the end bracket clockwise as shown in

the jacking point.

the image until the top of the jack contacts

► Make sure that the jacking point tab is

resting in the jack notch.



■ How to Set Up the Jack

AWARNING

The vehicle can easily roll off the jack, seriously injuring anyone underneath.

Follow the directions for changing a tire exactly, and never get under the vehicle when it is supported only by the jack.

Do not use the jack with people or luggage in the vehicle.

Use the jack provided in your vehicle. Other jacks may not support the weight ("load") or may not fit the jacking point.


The following instructions must be followed to use the jack safely:

- Do not use while the engine is running.
- Use only where the ground is firm and level.
- Use only at the jacking points.
- Do not get in the vehicle while using the jack.
- Do not put anything on top of or underneath the jack.


■ Replacing the Flat Tire



1. Remove the wheel nuts and flat tire.



- **2.** Wipe the mounting surfaces of the wheel with a clean cloth.
- 3. Mount the compact spare tire.
- **4.** Screw the wheel nuts until they touch the lips around the mounting holes, then stop rotating.



5. Lower the vehicle and remove the jack. Tighten the wheel nuts in the order indicated in the image. Go around, tightening the nuts, two to three times in this order.

Wheel nut torque:


80 lbf·ft (108 N·m, 11 kgf·m)

■ Replacing the Flat Tire

Do not over tighten the wheel nuts by applying extra torque using your foot or a pipe.

Continued 561

Storing the Flat Tire



- **1.** Remove the center cap.
- 2. Place the flat tire face down in the spare tire well.
- **3.** Remove the spacer cone from the wing bolt, flip it over, and insert it back on the bolt. Secure the flat tire with the wing bolt.
- **4.** Securely put the jack and wheel nut wrench back in the tool case. Store the case in the trunk.

■ TPMS and the Spare Tire

If you replace a flat tire with the spare tire, the low tire pressure/TPMS indicator comes on while you are driving. After driving for a few miles (kilometers), the indicator will start blinking for a short time and then stay on. **Tire Pressures Low** appears on the multi-information display*, but this is normal.

Calibrate the TPMS when you replace the tire with a specified regular tire.

▶ TPMS Calibration P. 475

Storing the Flat Tire

AWARNING

Loose items can fly around the interior in a crash and can seriously injure the occupants.

Store the wheel, jack, and tools securely before driving.

Engine Does Not Start

Checking the Engine

If the engine does not start, check the starter.

○ Checking the Engine

If you must start the vehicle immediately, use an assisting vehicle to jump start it.

Dump Starting P. 566

Starter condition	Checklist
Starter doesn't turn or turns over slowly. The battery may be dead. Check each of the items on the right and respond accordingly.	Models with multi-information display Models with smart entry system Check for a message on the multi-information display. If the To Start, Hold Remote Near Start Button message appears If the Smart Entry Remote Battery is Weak P. 564 Make sure the smart entry remote is in its operating range. ENGINE START/STOP Button Operating Range P. 141 Check brightness of the interior lights. Turn on the interior lights and check the brightness. If the interior lights are dim or do not come on at all Battery P. 546 If the interior lights come on normally Fuses P. 576
The starter turns over normally but the engine doesn't start. There may be a problem with the fuse. Check each of the items on the right and respond accordingly.	Review the engine start procedure. Follow its instructions, and try to start the engine again. Starting the Engine P. 421, 423 Check the immobilizer system indicator. When the immobilizer system indicator is blinking, the engine cannot be started. Immobilizer System P. 133
	Check the fuel level. There should be enough fuel in the tank. Fuel Gauge P. 98
	Check the fuse. Check all fuses, or have the vehicle checked by a dealer. Inspecting and Changing Fuses P. 579
	If the problem continues: Emergency Towing P. 580

Models with smart entry system

If the Smart Entry Remote Battery is Weak

If the beeper sounds, the indicator on the **ENGINE START/STOP** button flashes, and the engine won't start.

Models with multi-information display

The **To Start, Hold Remote Near Start Button** message appears on the multi-information display.

All models

Start the engine as follows.





- Touch the center of the ENGINE START/ STOP button with the H logo on the smart entry remote while the indicator on the ENGINE START/STOP button is flashing. The buttons on the smart entry remote should be facing you.
 - ► The indicator flashes for about 30 seconds
- Depress the brake pedal (automatic transmission) or clutch pedal (manual transmission) and press the ENGINE START/STOP button within 10 seconds after the beeper sounds and the indicator stays on.
 - ► If you don't depress the pedal, the mode will change to ACCESSORY.

Models with smart entry system

Emergency Engine Stop

The **ENGINE START/STOP** button may be used to stop the engine due to an emergency situation even while driving. If you must stop the engine, do either of the following operations:

- Press and hold the **ENGINE START/STOP** button for about two seconds.
- Firmly press the **ENGINE START/STOP** button twice.

The steering wheel will not lock. However, because turning off the engine disables the power assist the engine provides to the steering and braking systems, it will require significantly more physical effort and time to steer and slow the vehicle. Use both feet on the brake pedal to slow down the vehicle and stop immediately in a safe place. With manual transmission models you can also downshift the transmission to utilize engine braking.

U.S. automatic transmission/CVT models

The power mode is in ACCESSORY when the engine is stopped.

To change the mode to VEHICLE OFF, move the shift lever to $\boxed{\mathbf{P}}$ after the vehicle comes to a complete stop.

Canadian automatic transmission/CVT models

Then press the **ENGINE START/STOP** button twice without depressing the brake pedal.

Manual transmission models


The power mode changes to VEHICLE OFF.

Do not press the button while driving unless it is absolutely necessary for the engine to be switched off

Jump Starting

Jump Starting Procedure

Turn off the power to electric devices, such as audio and lights. Turn off the engine, then open the hood.



Booster Battery


- **1.** Connect the first jumper cable to your vehicle's battery \oplus terminal.
- **2.** Connect the other end of the first jumper cable to the booster battery (+) terminal.
 - ▶ Use a 12-volt booster battery only.
 - ➤ When using an automotive battery charger to boost your 12-volt battery, select a lower charging voltage than 15-volt. Check the charger manual for the proper setting.
- **3.** Connect the second jumper cable to the booster battery \bigcirc terminal.


AWARNING

A battery can explode if you do not follow the correct procedure, seriously injuring anyone nearby.

Keep all sparks, open flames, and smoking materials away from the battery.

Securely attach the jumper cables clips so that they do not come off when the engine vibrates. Also be careful not to tangle the jumper cables or allow the cable ends to touch each other while attaching or detaching the jumper cables.





- **4.** Connect the other end of the second jumper cable to the engine mounting bolt as shown. Do not connect this jumper cable to any other part.
- **5.** If your vehicle is connected to another vehicle, start the assisting vehicle's engine and increase its rpm slightly.
- **6.** Attempt to start your vehicle's engine. If it turns over slowly, check that the jumper cables have good metal-to-metal contact.

Battery performance degrades in cold conditions and may prevent the engine from starting.

Continued 567

■ What to Do After the Engine Starts

Once your vehicle's engine has started, remove the jumper cables in the following order.

- **1.** Disconnect the jumper cable from your vehicle's ground.
- **2.** Disconnect the other end of the jumper cable from the booster battery \bigcirc terminal.
- **3.** Disconnect the jumper cable from your vehicle's battery \oplus terminal.
- **4.** Disconnect the other end of the jumper cable from the booster battery \oplus terminal.


Have your vehicle inspected by a nearby service station or a dealer.

Shift Lever Does Not Move

Automatic transmission/CVT models

Follow the procedure below if you cannot move the shift lever out of the P position.

■ Releasing the Lock



1. Set the parking brake.

Models without smart entry system

2. Remove the key from the ignition switch.

Models with smart entry system

2. Remove the built-in key from the smart entry remote.

All models

- **3.** Wrap a cloth around the tip of a small flattip screwdriver. Put it into the shift lock release slot as shown in the image, and remove the cover.
- **4.** Insert the key into the shift lock release slot.
- **5.** While pushing the key down, press the shift lever release button and place the shift lever into [N].
 - ➤ The lock is now released. Have the shift lever checked by a dealer as soon as possible.



Overheating

How to Handle Overheating

Overheating symptoms are as follows:

- The temperature gauge needle is at the H mark or the engine suddenly loses power.
- Steam or spray comes out of the engine compartment.

■ First thing to do

- 1. Immediately park the vehicle in a safe place.
- 2. Turn off all accessories and turn on the hazard warning lights.
 - ▶ No steam or spray present: Keep the engine running and open the hood.
 - ➤ Steam or spray is present: Turn off the engine and wait until it subsides. Then open the hood.

AWARNING


Steam and spray from an overheated engine can seriously scald you.

Do not open the hood if steam is coming out.

NOTICE

Continuing to drive with the temperature gauge needle at the $\boxed{\mathbf{H}}$ mark may damage the engine.

■ Next thing to do



- **1.** Check that the cooling fan is operating and stop the engine once the temperature gauge needle comes down.
 - ► If the cooling fan is not operating, immediately stop the engine.
- **2.** Once the engine has cooled down, inspect the coolant level and check the cooling system components for leaks.
 - ► If the coolant level in the engine coolant reserve tank is low, add coolant until it reaches the **MAX** mark.
 - ▶ If there is no coolant in the reserve tank, check that the radiator is cool. Cover the radiator cap with a heavy cloth and open the cap. If necessary, add coolant up to the base of the filler neck, and put the cap back on.

■ Last thing to do

Once the engine has cooled sufficiently, restart it and check the temperature gauge. If the temperature gauge needle has gone down, resume driving. If it has not gone down, contact a dealer for repairs.

➤ How to Handle Overheating

AWARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

If the coolant is leaking, contact a dealer for repairs.

Use water as an emergency/temporary measure only. Have a dealer flush the system with proper antifreeze as soon as possible.

Indicator, Coming On/Blinking

If the Low Oil Pressure Indicator Comes On



■ Reasons for the indicator to come on

Comes on when the engine oil pressure is low.

- What to do as soon as the indicator comes on
- 1. Immediately park the vehicle in a safe place.
- **2.** If necessary, turn the hazard warning lights on.
- What to do after parking the vehicle
- **1.** Stop the engine and let it sit for about three minute.
- 2. Open the hood and check the oil level.
 - Add oil as necessary.
- **3.** Start the engine and check the low oil pressure indicator.
 - ► The indicator goes off: Start driving again.
 - ► The indicator does not go off within 10 seconds: Stop the engine and contact a dealer for repairs immediately.

If the Charging System Indicator Comes On



■ Reasons for the indicator to come on

Comes on when the battery is not being charged.

■ What to do when the indicator comes on

Turn off the climate control system, rear defogger, and other electrical systems, and immediately contact a dealer for repairs.

If the Low Oil Pressure Indicator Comes On

NOTICE

Running the engine with low oil pressure can cause serious mechanical damage almost immediately.

If the Charging System Indicator Comes On

If you need to stop temporarily, do not turn off the engine. Restarting the engine may rapidly discharge the battery.

If the Malfunction Indicator Lamp Comes On or Blinks



■ Reasons for the indicator lamp to come on or blink

- Comes on if there is a problem with the engine emissions control system, or the fuel fill cap is missing, or loose.
- Blinks when engine misfiring is detected.

■ What to do when the indicator lamp comes on

Avoid high speeds and immediately get your vehicle inspected at a dealer.

■ What to do when the indicator lamp blinks

Park the vehicle in a safe place with no flammable items and wait at least 10 minutes or more with the engine stopped until it cools.

■ Check/Tighten Fuel Cap Message

■ The message appears on when:

An evaporative system leak is detected. This may be caused by the fuel fill cap being loose or not being installed.

■ What to do when the message appears:

- **1.** Stop the engine.
- **2.** Check if the fuel fill cap is fully installed.
 - If not, loosen the cap, and then retighten it until it clicks at least once.
- **3.** Drive for several days of normal driving.
 - ► The message should go off.

■ When the malfunction indicator lamp comes on

The malfunction indicator lamp comes on if the system continues to detect a leak of gasoline vapor. If this happens, check the fuel fill cap using the procedures described above.

≥ If the Malfunction Indicator Lamp Comes On or Blinks

NOTICE

If you drive with the malfunction indicator lamp on, the emissions control system and the engine could be damaged.

If the malfunction indicator lamp blinks again when restarting the engine, drive to the nearest dealer at 31 mph (50 km/h) or less. Have your vehicle inspected.

If the Brake System Indicator (Red) Comes On



■ Reasons for the indicator to come on

- The brake fluid is low.
- There is a malfunction in the brake system.

Canada

■ What to do when the indicator comes on while driving Press the brake pedal lightly to check pedal pressure.

- If normal, check the brake fluid level the next time you stop.
- If abnormal, take immediate action. If necessary, downshift the transmission to slow the vehicle using engine braking.

If the Electric Power Steering (EPS) System Indicator Comes On



■ Reasons for the indicator to come on

- Comes on if there is a problem with the EPS system.
- If you depress the accelerator pedal repeatedly to increase the engine speed while the engine is idling, the indicator comes on, and sometimes the steering wheel becomes harder to operate.

■ What to do when the indicator comes on

Stop the vehicle in a safe place and restart the engine. If the indicator comes on and stays on, immediately have your vehicle inspected by a dealer.

≥ If the Brake System Indicator (Red) Comes On

Have your vehicle repaired immediately. It is dangerous to drive with low brake fluid. If there is no resistance from the brake pedal, stop immediately in a safe place. If necessary, downshift the gears.

If the brake system indicator and **ABS** indicator come on simultaneously, the electronic brake distribution system is not working. This can result in vehicle instability under sudden braking.

Have your vehicle inspected by a dealer immediately.

If the Low Tire Pressure/TPMS Indicator Comes On or Blinks



■ Reasons for the indicator to come on or blink

A tire pressure is significantly low, or the TPMS has not been calibrated. If there is a problem with the TPMS or the compact spare tire is installed, the indicator blinks for about one minute, and then stays on.

■ What to do when the indicator comes on

Drive carefully and avoid abrupt cornering and hard braking. Stop your vehicle in a safe place. Check the tire pressure and adjust the pressure to the specified level. The specified tire pressure is on a label on the driver side doorjamb.

- Calibrate the TPMS after the tire pressure is adjusted.
- What to do when the indicator blinks, then remains on Have the tire inspected by a dealer as soon as possible. If the compact spare tire causes the indicator to blink, change the tire to a full-size tire. The indicator goes off after driving for a few miles (kilometers).
 - ► Calibrate the TPMS after a full-size tire is reinstalled.

≥ If the Low Tire Pressure/TPMS Indicator Comes On or Blinks

NOTICE

Driving on an extremely underinflated tire can cause it to overheat. An overheated tire can fail. Always inflate your tires to the prescribed level.

Fuse Locations

If any electrical devices are not working, turn the ignition switch to LOCK 0^{*1} and check to see if any applicable fuse is blown.

■ Engine Compartment Fuse Box

Located near the brake fluid reservoir. Push the tabs to open the box.

Fuse locations are shown on the fuse box cover. Locate the fuse in question by the fuse number and box cover number.



*1:Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	Battery	125 A
	EPS	70 A
	Fuse Box Main 1	(60 A)
	Fuse Box Option 1	(40 A)
	_	_
2	_	
	ABS/VSA FSR	20 A*2
	AU3/ V3/A 1 3/K	40 A*3
	ABS/VSA Motor	40 A*2
	7 (23) 7 37 (1710 (0)	30 A*3
	-	_
3	-	_
	-	_
	-	-
4	Front Fog Light*	(10 A)
5	Horn	10 A
6	Stop Light	10 A
7	FI Sub	15 A
8	DRL	(7.5 A)
9	IG Coil	15 A
10	Injector*4 _*5	(20 A)*4 -*5

^{*2:}Models with LKAS

	Circuit Protected	Amps
11	Hazard	15 A
	Fuse Box Main 2	60 A
	Fuse Box Option 2	(40 A)
	IG Main 1	30 A*6
		50 A* ⁷
	IG Main 2*6	30 A*6
	_*7	_*7
12	Sub Fan Motor	20 A*4
12		30 A*5
	Headlight Low Beam Main	30 A
	Fuse Box	30 A
	Wiper Motor	30 A
	Main Fan Motor	30 A
	Starter Motor*6	30 A*6
	_*7	_*7
13	Rear Defogger	40 A
14	Heater Motor	40 A
15	FI Main	15 A
16	Heated Door Mirror*, *4	(10 A)*4
10	_ *5	- *5
17	MG Clutch	7.5 A
18	DBW	15 A
19	Small Light	20 A
20	Interior Light	7.5 A

^{*6:}Models with smart entry system

^{*3:}Models without LKAS

^{*4:4-}cylinder models

^{*5:6-}cylinder models

^{*7:}Models without smart entry system


	Circuit Protected	Amps
21	Back Up	10 A
22	Audio	10 A
23	Fan Timer	7.5 A
24	Right Headlight Low Beam	10 A
25	Left Headlight Low Beam	10 A
26	ABS/VSA ECU*2 _*3	7.5 A*2 -*3

^{*2:}Models with LKAS

^{*3:}Models without LKAS

■ Interior Fuse Box

Located under the dashboard.



Fuse locations are shown on the label on the side panel.

Locate the fuse in question by the fuse number and label number.


■ Circuit protected and fuse rating


	Circuit Protected	Amps
1	A/C	7.5 A
2	DRL	7.5 A
3	-	-
4	-	-
5	Meter	7.5 A
6	SRS	7.5 A
7	Option*	(7.5 A)
8	MISS SOL	10 A
9	Fuel Pump	20 A

	Circuit Protected	Amps
10	ABS/VSA	7.5 A
11	-	-
12	Front Wiper	7.5 A
13	ACG	15 A
14	Rear Accessory Power Socket (Console Compartment)	(20 A)
15	Driver's Power Seat Reclining*	(20 A)
16	Moonroof*	(20 A)
17	Front Seat Heaters*	(20 A)
18	-	-
19	Passenger Side Door Unlock	10 A
20	Driver Side Rear Door Unlock*	10 A
21	Driver's Door Lock	10 A
22	Passenger Side Door Lock	10 A
23	Driver's Door Unlock	10 A
24	SRS	10 A
25	Illumination	10 A
26	Key Lock	7.5 A
27	Parking Lights	10 A
28	Lumbar Support*	(10 A)
29	Right Headlight High Beam	10 A
30	Washer	15 A
31	SMART*	(10 A)
32	Driver's Power Window	20 A

	Circuit Protected	Amps
33	Front Passenger's Power Window	20 A
34	Rear Driver Side Power Window*	20 A
35	Rear Passenger Side Power Window*	20 A
36	Driver's Power Seat Sliding*	(20 A)
37	ACCESSORY	7.5 A
38	-	_
39	Left Headlight High Beam	10 A
40	Front Accessory Power Socket (Console Panel)	20 A
41	Driver Side Rear Door Lock*	10 A
42	Door Lock	20 A
а	Audio*	(7.5 A)
b	ACM*	(20 A)
С	Rear Seat Heaters*	(15 A)
d	Premium Amp*	(20 A)
е	-	-
f	_	-
g	Passenger's Power Seat Reclining*	(20 A)
h	Passenger's Power Seat Sliding*	(20 A)

Inspecting and Changing Fuses





- **1.** Turn the ignition switch to LOCK 0^{*1} . Turn headlights and all accessories off.
- 2. Remove the fuse box cover.
- **3.** Check the large fuse in the engine compartment.
 - ▶ If the fuse is blown, use a Phillips-head screwdriver to remove the screw and replace it with a new one.
- **4.** Inspect the small fuses in the engine compartment and the vehicle interior.
 - ▶ If there is a burned out fuse, remove it with the fuse puller and replace it with a new one.

NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chances of damaging the electrical system.

Replace fuse with a spare fuse of the same specified amperage.

Confirm the specified amperage using the charts on P. 576 to 578.

There is a fuse puller on the back of the engine compartment fuse box cover.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Emergency Towing

Call a professional towing service if you need to tow your vehicle.

■ Flat bed equipment

The operator loads your vehicle on the back of a truck.

This is the best way to transport your vehicle.

■ Wheel lift equipment

The tow truck uses two pivoting arms that go under the front tires and lift them off the ground. The rear tires remain on the ground. **This is an acceptable way to tow your vehicle.**

Emergency Towing

NOTICE

Trying to lift or tow your vehicle by the bumpers will cause serious damage. The bumpers are not designed to support the vehicle's weight.

NOTICE

Improper towing such as towing behind a motorhome or other motor vehicle can damage the transmission.

Never tow your vehicle with just a rope or chain. It is very dangerous since ropes or chains may shift from side to side or break.

Information

This chapter includes your vehicle's specifications, locations of identification numbers, and other information required by regulation.

Specifications	. 582
dentification Numbers	
Vehicle Identification Number (VIN),	
Engine Number and Transmission	
Number	586
Devices that Emit Radio Waves	587
Reporting Safety Defects	588

Emissions Testing	
Testing of Readiness Codes	589
Warranty Coverages	591
Authorized Manuals	593
Customer Service Information	594

Specifications

4-cylinder models

■ Vehicle Specifications

Model	Honda Accord Coupe
No. of Passengers:	
Front	2
Rear	3
Total	5
Weights:	
Gross Vehicle Weight Rating	U.S.: 4,189 lbs (1,900 kg)* ¹ 4,255 lbs (1,930 kg)* ² Canada: 1,900 kg* ³ 1,930 kg* ⁴
Gross Axle Weight	
Rating (Front)	U.S.: 2,271 lbs (1,030 kg)*1 2,315 lbs (1,050 kg)*2 Canada: 1,040 kg*3 1,055 kg*4

Gross Axle Weight Rating (Rear)

U.S.: 1,962 lbs (890 kg)*1 2,006 lbs (910 kg)*2 Canada: 890 kg*3 910 ka*4

Air Conditioning:

Refrigerant Type HFC-134a (R-134a) Charge Quantity 15.0 - 16.8 oz (425 - 475 g)

Lubricant Type ND-OIL 8

*1: LX-S models

*2: Except LX-S models

*3: LX models *4: Except LX models

■ Engine Specifications

Displacement	144 cu-in (144 cu-in (2,356 cm³)		
	NGK	DILKAR7G11GS		
Spark Plugs		DILKAR7H11GS		
	DENSO	DXE22HQR-D11S		

■ Fuel

Fuel:	Unleaded gasoline, Pump octane number
Type	of 87 or higher
Fuel Tank Capacity	17.2 US gal (65 ℓ)

■ Washer Fluid

Tank Canacity	U.S.: 2.6 US qt (2.5 ℓ)	
Tank Capacity	Canada: 4.85 ℓ	

■ Light Bulbs

Headlights (Low Beam)		55W (H11)*5 LED*6
Headlights (High Beam)		60W (HB3)*5 LED*6
Fog Lights*		LED
	Side Marker/Parking Lights*5, *7 al/Side Marker Lights*5, *8	28/8W (Amber)
Front Turn Signa	al Lights*6	LED
Front Side Mark	cer Lights*6	LED
Side Turn Signal Lights (on Door Mirrors)*		LED
Brake Lights		21W
Rear Side Marker/Taillights		LED
Back-Up Lights		16W
Rear Turn Signal Lights		21W (Amber)
High-Mount Brake Light		LED
Rear License Plate Lights		5W
Trunk Light		5W
Interior Lights		
	Map Lights	8W
	Ceiling Light	8W
	Vanity Mirror Lights	1.4W
*F. Madalanda	k kalana kaadiinka	

- *5: Models with halogen headlights *6: Models with LED headlights
- *7: Models with bulb type parking lights
 *8: Models with LED type parking/daytime running lights

■ Brake/Clutch Fluid

Specified	Honda Heavy Duty Brake Fluid DOT 3

■ Continuously Variable Transmission (CVT) Fluid

Specified	HCF-2	
Capacity	Change	3.9 US qt (3.7 ℓ)

■ Manual Transmission Fluid

Specified	Honda Manual Tran	nsmission Fluid
Capacity	Change	2.0 US qt (1.9 ℓ)

■Engine Oil

Recommended	-Genuine Honda Motor Oil 0W-20 -API Premium-grade 0W-20 detergent oil	
	Change	4.2 US qt (4.0 ℓ)
Capacity	Change including filter	4.4 US qt (4.2 ℓ)

■ Engine Coolant

Specified	Honda Long-Life Antifreeze/Coolant Type2
Ratio	50/50 with distilled water
Capacity	1.66 US gal (6.28 ℓ)*1 1.66 US gal (6.30 ℓ)*2 (change including the remaining 0.17 US gal (0.64 ℓ) in the reserve tank)

^{*1:} Continuously variable transmission (CVT) models
*2: Manual transmission models

■ Tiro

= 1116		
		215/55R17 94V*3
	Size	235/45R18 94V*4
		235/40R19 96V*5
	Pressure	
Regular	psi (kPa [kgf/cm²])	
	Front	33 (225 [2.3])*3, *4
	FIUIIL	33 (230 [2.3])*5
	Rear	33 (225 [2.3])*3, *4
		32 (220 [2.2])*5
	Size	T135/90D16 102M*3, *4
Compact Spare		T135/80D17 103M*5
	Pressure	60 (420 [4.2])
	psi (kPa [kgf/cm²])	
Wheel Size		17 x 7 1/2J*3
	Regular	18 x 8J*4
		19 x 8J*5
	Compact Spare	16 x 4T*3
	compact spare	17 x 4T*4, *5
*2 116 11/1		

^{*3:} U.S. LX-S and Canadian LX models

^{*4:} U.S. EX, EX-L models and Canadian EX models

^{*5:} Canadian Touring models

6-cylinder models

Model

■Vehicle Specifications

No. of Passengers: Front Rear Total	2 3 5	
Weights:		
Gross Vehicle Weight Rating	U.S.: 4,387 lbs (1,990 kg)*1 4,475 lbs (2,030 kg)*2 Canada: 1,990 kg*1 2,030 kg*2	
Gross Axle Weight		
Rating (Front)	U.S.: 2,403 lbs (1,090 kg)*1 2,513 lbs (1,140 kg)*2 Canada: 1,090 kg*1 1,145 kg*2	
Gross Axle Weight		

U.S.: 2,006 lbs (910 kg) Canada: 910 kg

15.0 - 16.8 oz (425 - 475 g)

HFC-134a (R-134a)

ND-OIL 8

Honda Accord Coupe

*1: Manual transmission models

Rating (Rear)

Air Conditioning: Refrigerant Type

Charge Quantity

Lubricant Type

*2: Automatic transmission models

■ Engine Specifications

212 cu-in (3,471 cm³)	
NGK	ILZKR7B11
DENSO	SXU22HCR11
	NGK

■ Fuel

Fuel:	Unleaded gasoline, Pump octane number
. = =	
Туре	of 87 or higher
Fuel Tank Capacity	17.2 US gal (65 ℓ)

■ Washer Fluid

Tank Capacity	U.S.: 2.6 US qt (2.5 ℓ)	
тапк Сараспу	Canada: 4.85 ℓ	

■ Light Bulbs

Headlights (Low Beam)	55W (H11)* ³ LED* ⁴
Headlights (High Beam)	60W (HB3)*3 LED*4
Fog Lights	LED
Parking/Daytime Running Lights	LED
Front Turn Signal/Side Marker Lights*3	28/8W (Amber)
Front Turn Signal Lights*4	LED
Front Side Marker Lights*4	LED
Side Turn Signal Lights (on Door Mirrors)	LED
Brake Lights	21W
Rear Side Marker/Taillights	LFD
Back-Up Lights	16W
Rear Turn Signal Lights	21W (Amber)
High-Mount Brake Light	LED
Rear License Plate Lights	5W
Trunk Light	5W
Interior Lights	
Map Lights	8W
Ceiling Light	8W
Vanity Mirror Lights	1.4W
Courtesy Lights	2CP

^{*3:} Models with halogen headlights *4: Models with LED headlights

■ Brake/Clutch Fluid

Specified	Honda Heavy Duty Brake Fluid DOT 3

■ Automatic Transmission Fluid

Specified	Honda ATF DW-1 (automatic transmission fluid)	
Capacity	Change	3.3 US qt (3.1 ℓ)

■ Manual Transmission Fluid

Specified	Honda Manual Transmission Fluid		
Capacity	Change	2.2 US qt (2.1 ℓ)	

■Engine Oil

Recommended	·Genuine Honda Motor Oil 0W-20 ·API Premium-grade 0W-20 detergent oil		
	Change	4.2 US qt (4.0 ℓ)	
Capacity	Change including filter	4.5 US qt (4.3 ℓ)	

■ Engine Coolant

Specified	Honda Long-Life Antifreeze/Coolant Type2
Ratio	50/50 with distilled water
Capacity	1.66 US gal (6.3 ℓ) ¹ 1.72 US gal (6.5 ℓ) ² (change including the remaining 0.17 US gal (0.64 ℓ) in the reserve tank)

^{*1:} Manual transmission models

■ Tire

Size	235/45R18 94V*3 235/40R19 96V*4
Pressure psi (kPa [kgf/cm²])	
Front	33 (225 [2.3])*3 33 (230 [2.3])*4
Rear	32 (220 [2.2])*3, *4
Size	T135/90D16 102M*3 T135/80D17 103M*4
Pressure psi (kPa [kgf/cm ²])	60 (420 [4.2])
Regular	18 x 8J* ³ 19 x 8J* ⁴
Compact Spare	16 x 4T* ³ 17 x 4T* ⁴
	Pressure psi (kPa [kgf/cm²]) Front Rear Size Pressure psi (kPa [kgf/cm²]) Regular

^{*3:} U.S. EX-L V6 models


^{*2:} Automatic transmission models

^{*4:} U.S. Touring models and Canadian V6 Touring models

Identification Numbers


Vehicle Identification Number (VIN), Engine Number and Transmission Number

Your vehicle has a 17-digit vehicle identification number (VIN) used to register your vehicle for warranty purposes, and for licensing and insuring your vehicle. The locations of your vehicle's VIN, engine number and transmission number are shown as follows.



■ Vehicle Identification Number (VIN), Engine Number and Transmission Number

The interior vehicle identification number (VIN) is located under the cover.



Devices that Emit Radio Waves

The following products and systems on your vehicle emit radio waves when in operation.

Audio System

Bluetooth® Audio

Bluetooth® HandsFreeLink®

Bluetooth® Universal Transceiver

Immobilizer System

Keyless Access System*

Remote Transmitter

Wireless Charger*

Each of the above complies with the appropriate requirements or the required standards of FCC (Federal Communications Commission) and Industry Canada Standard, described below:

As required by the FCC:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada Standard RSS-Gen/210/251/310. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

* Not available on all models

Reporting Safety Defects

In the U.S.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying American Honda Motor Co., Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or American Honda Motor Co., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

In Canada

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Honda Canada Inc. and you may also inform Transport Canada.

If Transport Canada receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may lead to a recall and remedy campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or Honda Canada Inc.

To contact Transport Canada's Defect Investigations and Recalls Division, you may call 1-800-333-0510. For more information on reporting safety defects or about motor vehicle safety, go to http://www.tc.gc.ca/roadsafety.

Emissions Testing

Testing of Readiness Codes

Your vehicle has "Readiness Codes," as part of the onboard self diagnostic system. Some States use these codes as a test to see if your vehicle's emissions components are working properly.

The codes may not be read properly if testing is performed just after the battery has gone dead or been disconnected.

To check if they are set, turn the ignition switch to ON \boxed{II}^{*1} , without starting the engine. The malfunction indicator lamp will come on for several seconds. If it then goes off, the readiness codes are set. If it blinks five times, the readiness codes are not set.

If you are required to have your vehicle tested before the readiness codes are ready, prepare the vehicle for retesting by doing the following:

- 1. Fill the gas tank to approximately 3/4 full.
- **2.** Park the vehicle and leave the engine off for six hours or more.
- **3.** Make sure the ambient temperature is between 40°F and 95°F (4°C and 35°C).
- **4.** Start the engine without touching the accelerator pedal, and let it idle for 20 seconds.
- **5.** Keep the vehicle in P (automatic transmission/CVT) or N (manual transmission). Increase the engine speed to 2,000 rpm, and hold it there for about three minutes.
- **6.** Let the engine idle with your foot off the accelerator for 20 seconds.

∑Testing of Readiness Codes

The readiness codes are erased when the battery is disconnected, and set again only after several days of driving under a variety of conditions.

If a testing facility determines that the readiness codes are not set, you may be requested to return at a later date to complete the test.

If the testing facility determines the readiness codes are still not set, see a dealer.

Continued 589

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

- 7. Select a nearby, lightly traveled major highway where you can maintain a speed of 50 to 60 mph (80 to 97 km/h) for at least 20 minutes. Drive on the highway in D (automatic/CVT) or 5th (manual). Do not use cruise control. When traffic allows, drive for 90 seconds without moving the accelerator pedal. (Vehicle speed may vary slightly; this is okay.) If you cannot do this for a continuous 90 seconds because of traffic conditions, drive for at least 30 seconds, then repeat it two more times (for a total of 90 seconds).
- **8.** Drive in city/suburban traffic for at least 10 minutes. When traffic conditions allow, let the vehicle coast for several seconds without using the accelerator pedal or the brake pedal.
- **9.** Park the vehicle and leave the engine off for 30 minutes.

Warranty Coverages

■ U.S. Owners

Your new vehicle is covered by these warranties:

New Vehicle Limited Warranty – covers your new vehicle, except for the emissions control systems and accessories, against defects in materials and workmanship.

Emissions Control Systems Defects Warranty and Emissions Performance Warranty – these two warranties cover your vehicle's emissions control systems.

Time, mileage, and coverage are conditional. Please read your warranty booklet for exact information.

Seat Belt Limited Warranty – a seat belt that fails to function properly is covered by a limited warranty. Please read your warranty booklet for details.

Rust Perforation Limited Warranty – all exterior body panels are covered for rust-through from the inside for the specified time period with no mileage limit.

Accessory Limited Warranty – Honda accessories are covered under this warranty. Time and mileage limits depend on the type of accessory and other factors. Please read your warranty booklet for details.

Replacement Parts Limited Warranty – covers all Honda replacement parts against defects in materials and workmanship.

Continued 591

Replacement Battery Limited Warranty – provides prorated coverage for a replacement battery purchased from a dealer.

Replacement Muffler Lifetime Limited Warranty – provides coverage for as long as the purchaser of the muffler owns the vehicle.

Restrictions and exclusions apply to all these warranties. Please read the Honda warranty information booklet that came with your vehicle for precise information on warranty coverages. Your vehicle's original tires are covered by their manufacturer. Tire warranty information is in a separate booklet.

■ Canadian Owners

Please refer to the warranty manual that came with your vehicle.

Authorized Manuals

■ Service Express

For electronic copies of service publications, you can purchase a subscription to Service Express. Visit www.techinfo.honda.com for pricing and options.

For U.S. Owners:

Manuals can be purchased from Helm Incorporated. You can order a manual by phone at (800) 782-4356 (credit card orders only), or online at www.helminc.com.

■ For Canadian Owners:

Please contact a dealer to order any manuals that you may require.

Customer Service Information

Honda dealership personnel are trained professionals.

They should be able to answer all your questions. If you encounter a problem that your dealership does not solve to your satisfaction, please discuss it with the dealership's service manager or general manager. If you are dissatisfied with the decision made by the dealership's management, contact Honda Customer Services.

U.S. Owners:

American Honda Motor Co., Inc. Honda Automobile Customer Services Mail Stop 500-2N-7A 1919 Torrance Blvd. Torrance, CA 90501-2746 Tel: (800) 999-1009

Canadian Owners:

Honda Canada Inc. Customer Relations 180 Honda Boulevard Markham, ON L6C 0H9

Tel: 1-888-9-HONDA-9 Fax: 1-877-939-0909

E-mail: Honda_cr@ch.honda.com

In Puerto Rico and the U.S. Virgin Islands:

Bella International P.O. Box 190816 San Juan, PR 00919-0816

Tel: (787) 620-7546

Customer Service Information

When you call or write, please give us the following information:

- Vehicle Identification Number
 - Vehicle Identification Number (VIN), Engine Number and Transmission Number P 586
- Date of purchase
- Odometer reading of your vehicle
- Your name, address, and telephone number
- A detailed description of the problem
- Name of the dealer who sold the vehicle to you

Gracenote Music Recognition Service (CDDB)



Music recognition technology and related data are provided by Gracenote®.

Gracenote is the industry standard in music recognition technology and related content delivery.

For more information, visit www.gracenote.com.

When music is recorded to the HDD from a CD, information such as the recording artist and track name are retrieved from the Gracenote Database and displayed (when available).

Gracenote may not contain information for all albums.

Gracenote is an internet-based music recognition service that allows artist, album, and track information from CDs to display on the HDD.

Gracenote users are allowed 4 free updates a year. More information about Gracenote, its features, and downloads are available at www.honda.com (in U.S.) or www.honda.ca (in Canada).

CD and music-related data from Gracenote, Inc., copyright © 2000 to present Gracenote. Gracenote Software, copyright © 2000 to present Gracenote.

One or more patents owned by Gracenote apply to this product and service. See the Gracenote website for a non-exhaustive list of applicable Gracenote patents. Gracenote, CDDB, MusicID, MediaVOCS, the Gracenote logo and logotype, and the "Powered by Gracenote" logo are either registered trademarks or trademarks of Gracenote in the United States and/or other countries.

Gracenote® END USER LICENSE AGREEMENT

This application or device contains software from Gracenote, Inc. of Emeryville, California ("Gracenote"). The software from Gracenote (the "Gracenote Software") enables this application to perform disc and/or file identification and obtain music- related information, including name, artist, track, and title information ("Gracenote Data") from online servers or

embedded databases (collectively, "Gracenote Servers") and to perform other functions. You may use Gracenote Data only by means of the intended End-User functions or this application or device.

You agree that you will use Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal noncommercial use only.

You agree not to assign, copy, transfer, or transmit the Gracenote Software or any Gracenote Data to any third party.

YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE DATA, THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED HEREIN.

You agree that your non-exclusive license to use the Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenote Data, the Gracenote Software, and Gracenote Servers

Gracenote reserves all rights in Gracenote Data, the Gracenote Software, and the Gracenote Servers, including all ownership rights. Under no circumstances will Gracenote become liable for any payment to you for any information that you provide. You agree that Gracenote, Inc. may enforce its rights under this Agreement against you directly in its own name.

The Gracenote service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenote service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenote Privacy Policy for the Gracenote service.

The Gracenote Software and each item of Gracenote Data are licensed to you "AS IS."

Gracenote makes no representations or warranties, express or implied, regarding the accuracy of any Gracenote Data from in the Gracenote Servers. Gracenote reserves the right to delete data from the Gracenote Servers or to change data categories for any

cause that Gracenote deems sufficient. No warranty is made that the Gracenote Software or Gracenote Servers are errorfree or that functioning of Gracenote Software or Gracenote Servers will be uninterrupted.

Gracenote is not obligated to provide you with new enhanced or additional data types or categories that Gracenote may provide in the future and is free to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NONINFRINGEMENT. GRACENOTE DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENOTE SOFTWARE OR ANY GRACENOTE SERVER. IN NO CASE WILL GRACENOTE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES.

© Gracenote 2009

Disclaimer of Pandora®

Requirements to access Pandora®

- Latest version of the Pandora application installed on your mobile device. (Visit the Apple iTunes store or Google Play Marketplace to download the latest version.)
- Registered Pandora account (you can create a free account at www.pandora.com <http:// www.pandora.com/> or on your smartphone)
- Connection to the internet via WiFi or cellular data network.
- Android devices must be connected to the vehicle via *Bluetooth*, iPhone devices may be connected via *Bluetooth* or USB.

Limitations

- Access to Pandora requires an active internet connection
- Ability to access Pandora through this system is subject to change without notice
- Certain functionality of Pandora service is not available when accessing the service through this system including, but not limited to, creating new stations, deleting stations, emailing current stations, buying songs, viewing additional text information, logging in to Pandora, and adjusting Cell Network Audio Quality. Pandora internet radio is a music service not affiliated with HONDA More information is available at http:// www.pandora.com <http:// www.pandora.com/>. Pandora, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc., used with permission.
- Mobile access requires a smartphone with an active data plan. Standard data rates may apply.
- Pandora is only available in the United States.

Recirculation/Fresh Air Mode................................. 180 Numbers 7-Speed Manual Shift Mode 432 General Information 291 Using Automatic Climate Control........... 180 Airbags 41 iPod 204, 255, 294 Limitations for Manual ABS (Anti-lock Brake System)...... 481 Accessories and Modifications 500 MP3/WMA/AAC 201, 210, 252, 265 Accessory Power Sockets 174 Adaptive Cruise Control (ACC)......... 85, 447 Additives Coolant 523 Passenger Airbag Off Indicator 52 Engine Oil...... 517 Washer...... 528 Additives, Engine Oil 517 Side Curtain Airbags...... 50 Adjusting Android Auto 281 Front Seats 161 Anti-lock Brake System (ABS) 481 Head Restraints 164 Wallpaper Setup 195, 222 Apple CarPlay 277 Audio/Information Touch Screen 218 Authorized Manuals 593 Auto Door Locking/Unlocking 128 Air Conditioning System (Climate Control Auto High-Beam (High Beam Support Changing the Mode 180 Changing the Home Screen Icon Indicator 83 Defrosting the Windshield and Windows 181 Automatic Lighting...... 146 Dust and Pollen Filter 549

Automatic Transmission	Brake System Indicator (Red) 70	Child Seat54
Creeping 429	Brightness Control (Instrument Panel) 154	Booster Seats
Fluid 526	Bulb Replacement 529	Child Seat for Infants 56
Kickdown 429	Brake Lights, Back-Up Lights, Rear Turn Signal	Child Seat for Small Children 57
Operating the Shift Lever 20, 435	Lights and Rear Side Marker/Taillights 533	Installing a Child Seat with a Lap/Shoulder Seat
Shift Lever Does Not Move 569	Fog Lights 531	Belt 61
Shifting 434	Front Side Marker Lights 531	Larger Children 64
Auxiliary Input Jack 188	Front Turn Signal/Side Marker Lights 532	Rear-facing Child Seat 56
Average Fuel Economy 100, 104	Front Turn Signal/Side Marker/Parking	Selecting a Child Seat
Average Speed 105	Lights 532	Using a Tether63
	Headlights 529	Cleaning the Exterior 552
D	High-Mount Brake Light 534	Cleaning the Interior 550
В	Parking/Daytime Running Lights 531	Climate Control System 180
Battery 546	Rear License Plate Lights 534	Changing the Mode 180
Charging System Indicator 71, 572	Side Turn Signal/Emergency Indicator	Defrosting the Windshield and
Jump Starting 566	Lights 531	Windows 181
Maintenance (Checking the Battery) 546	Bulb Specifications 582, 584	Dust and Pollen Filter 549
Maintenance (Replacing) 547		Recirculation and Fresh Air Mode 180
Belts (Seat)	С	Sensors 183
Beverage Holders 173	C	Synchronized Mode
<i>Bluetooth</i> ® Audio	Carbon Monoxide Gas 66	Using Automatic Climate Control 180
Bluetooth® HandsFreeLink® 343, 374	Cargo Hooks 177	Clock
Booster Seats (For Children)	Carrying Cargo 413, 415	Clutch Fluid 527
Brake System	CD Player 201, 252	CMBS [™] (Collision Mitigation Braking
Anti-lock Brake System (ABS) 481	Center Pocket 172	System ™)
Brake Assist System	Certification Label 586	Coat Hook 177
Fluid 527	Changing Bulbs 529	Collision Mitigation Braking System™
Foot Brake	Charging System Indicator 71, 572	(CMBS [™]) 483
Indicator	Child Safety54	Compact Spare Tire 557, 583, 585
Parking Brake	Emergency Trunk Opener 132	Compass

Brake System Indicator (Amber) 70

Console Compartment 171

Continuously Variable Transmission (CVT)	Rearview Mirror	Elapsed Time 104
Creeping 429	Dipstick (Engine Oil)518	Electric Power Steering (EPS) System
Fluid 525	Directional Signals (Turn Signal) 145	Indicator 77, 574
Kickdown 429	Display Button 193, 216	Electronic Stability Control (ESC) 471
Operating the Shift Lever 19, 431	Door Mirrors 160	Emergency 580
Shift Lever Does Not Move 569	Doors	Emergency Engine Stop 565
Shifting	Auto Door Locking 128	Emergency Trunk Opener 132
Controls	Auto Door Unlocking 128	Emissions Testing (Readiness Codes) 589
Coolant (Engine) 523	Door and Trunk Open Indicator 33, 77	Engine 586
Adding to the Engine Coolant Reserve	Keys118	Coolant 523
Tank 523	Locking/Unlocking the Doors from	Jump Starting 566
Adding to the Radiator 524	the Inside 126	Oil 517
Overheating 570	Locking/Unlocking the Doors from	Remote Engine Start
Creeping (Automatic Transmission	the Outside 121	Starting 421, 423
/CVT) 429	Lockout Prevention System 125	Switch Buzzer 140
Cruise Control	DOT Tire Quality Grading 540	Engine Coolant 523
Indicator81	Driving 411	Adding to the Engine Coolant Reserve
Cup Holders	Adaptive Cruise Control (ACC) 447	Tank 523
Customer Service Information 594	Automatic Transmission/CVT	Adding to the Radiator 524
Customized Features 106, 298, 316	Braking 479	Overheating 570
	Cruise Control	Temperature Gauge
D	Shifting Gear	Engine Oil 517
D	Shifting Position	Adding 520
Daytime Running Lights 151	Starting the Engine 421, 423	Checking 518
Dead Battery 566	Driving Position Memory System 156	Displaying Oil Life 505, 509
Defaulting All the Settings 315, 339	Dust and Pollen Filter 549	Low Oil Pressure Indicator 71, 572
Defrosting the Windshield and		Recommended Engine Oil 517
Windows 181	_	ENGINE START/STOP Button 141
Devices that Emit Radio Waves 587	E	EPS (Electric Power Steering)
Dimming	Eco Assist System 9	System 77, 574
Headlights 145	ECON Button 441	

Exhaust Gas Hazard (Carbon		Fuel	. 22, 497	Glass (care) 550,	55
Monoxide)	66	Economy	499	Glove Box	17
Expanded View Driver's Mirror 1	160	Gauge	98		
Exterior Care (Cleaning) 5	552	Instant Fuel Economy	100, 105	Н	
Exterior Mirrors 1	160	Low Fuel Indicator	75	П	
		Range	101, 104	Halogen Bulbs	
_		Recommendation	497	Handling the Unexpected	55
F		Refueling	497	HandsFreeLink® (HFL)	374
Features 1	185	Fuel Economy	499	Auto Answer	358
Filters		Fuel Fill Cap	. 22, 498	Automatic Import of Cellular Phonebook a	and
Dust and Pollen5	549	Message	573	Call History 360,	388
Oil 5	521	Fuel Fill Door	. 22, 498	Automatic Transferring	358
Flat Tire 5	557	Fuses	576	Displaying Messages	40
Floor Mats 5	551	Inspecting and Changing	579	Displaying Text Messages	37
Fluids		Locations	576, 578	HFL Buttons 343,	374
Automatic Transmission 5	526			HFL Menus 345,	378
Brake/Clutch 5	527	C		HFL Status Display 344,	37
Continuously Variable Transmission		G		In Case of Emergency	40
(CVT) 5	525	Gasoline (Fuel)		Limitations for Manual Operation 344,	37
Engine Coolant 5	523	Economy	499	Making a Call	39
Manual Transmission 5	525	Gauge	98	Options During a Call	400
Windshield Washer 5	528	Information	497	Phone Setup	38
FM/AM Radio 199, 2	239	Instant Fuel Economy	100, 105	Phonebook Phonetic Modification	39
Fog Light Indicator	80	Low Fuel Indicator	75	Receiving a Call	399
Folding Down the Rear Seat 1	168	Refueling	497	Receiving a Text Message	370
Foot Brake 4	480	Gauges	98	Receiving a Text Message/E-mail	40
Front Airbags (SRS)	44	Gear Shift Lever Positions		Ring Tone	38
Front Seats 1	161	Automatic Transmission	434	Selecting a Mail Account	40
Adjusting 1	161	Continuously Variable Transmission		Speed Dial	389
Front Sensor Camera 4	145	(CVT)	430	To Create a Security PIN	35
		Manual Transmission	439		

To Set Up Text Message Options 355	Anti-lock Brake System (ABS)	Seat Belt Reminder 35, 74
To Set Up Text Message/E-mail Options 386	Auto High-Beam (Amber)83	Security System Alarm 80
Hazard Warning Button 4	Auto High-Beam (Green) 83	Smart Entry System 82
HD Radio [™]	Brake System (Amber) 70	Starter System 82
Head Restraints 164	Brake System (Red) 70	Supplemental Restraint System 51, 75
Headlights145	Charging System 71, 572	System Message 79
Aiming 529	Collision Mitigation Braking System™	Transmission 74
Auto High-Beam148	(CMBS TM) 87	Turn Signal and Hazard Warning 79
Automatic Operation 146	CRUISE CONTROL 81, 443	Vehicle Stability Assist (VSA®)
Dimming 145, 151	CRUISE MAIN 81, 442	System 76, 471
Operating 145	Door and Trunk Open 77	VSA® OFF 76, 472
Heaters (Seat)	ECON Mode 81, 441	Washer Level 81
High Beam Indicator 79	Electric Power Steering (EPS)	Information 581
Hill Start Assist System 422, 427	System 77, 574	Information Display 99
HomeLink® Universal Transceiver 340	Fog Light80	Instant Fuel Economy 100, 105
HondaLink®270	High Beam 79	Instrument Panel 69
	Immobilizer System 80	Brightness Control
	Lane Keeping Assist System (LKAS)	Interior Lights
I	(Amber)	Interior Rearview Mirror 159
Identification Numbers	Lane Keeping Assist System (LKAS)	iPod 204, 255, 294
Engine and Transmission 586	(White)	
Vehicle Identification 586	Light Control 82	
Ignition Switch140	Lights On 79	J
Illumination Control	Low Fuel 75	Jack (Wheel Nut Wrench) 560
Knob 154	Low Oil Pressure	Jump Starting 566
Immobilizer System 133	Low Tire Pressure/TPMS 78, 475, 477	
Indicator80	Maintenance Minder 81, 505	K
Indicators 70	Malfunction Indicator Lamp	N
Adaptive Cruise Control (ACC) (Amber) 85	Parking Brake and Brake System 70, 574	Key Number Tag 119
Adaptive Cruise Control (ACC)	Parking Sensor System	Keyless Lockout Prevention 125
(White) 85, 448	Road Departure Mitigation (RDM) 84	

Keys	118	Locking/Unlocking	118	Safety	503
Lockout Prevention	125	Auto Door Locking/Unlocking	128	Service Items	. 507, 511
Master Keys	118	From Inside	126	Tires	537
Number Tag	119	From Outside	121	Transmission Fluid	525
Remote Engine Start	425	Keys	118	Under the Hood	513
Remote Transmitter	123	Using a Key	125	Malfunction Indicator Lamp	71, 573
Types and Functions	118	Lockout Prevention System	125	Manual Transmission	
Valet Key	119, 131	Low Battery Charge	572	Map Lights	170
Won't Turn		Low Fuel Indicator	75	Maximum Load Limit	415
Kickdown (Automatic Transm	ission	Low Oil Pressure Indicator	71, 572	Meters, Gauges	98
/CVT)	429	Low Smart Entry Remote Signa	ıl	Mirrors	159
		Strength	120	Adjusting	159
		Lower Anchors	59	Door	
L		Lubricant Specifications Chart.	582, 584	Exterior	160
Lane Keeping Assist System (L	KAS) 464	Luggage (Maximum Load Limit	t) 415	Interior Rearview	159
LaneWatch [™]	473			Modifications (and Accessories)	500
Language (HFL)	344, 376	B.4		Moonroof	139
LATCH (Child Seats)	59	M		MP3 201, 210	, 252, 265
Lights	145, 529	Maintenance	501	Multi-Information Display	102
Auto High-Beam		Battery	546	Multi-View Rear Camera	496
Automatic	146	Brake/Clutch Fluid	527		
Bulb Replacement	529	Cleaning	550	N.I.	
Daytime Running Lights	151	Climate Control System	549	N	
Fog Lights	147	Coolant	523	Numbers (Identification)	586
High Beam Indicator	79	Maintenance Minder [™]	505		
Interior	169	Oil	518	0	
Light Switches	145	Precautions	502	0	
Lights On Indicator	79	Radiator	524	Odometer	. 100, 104
Turn Signals	145	Remote Transmitter	547		

Replacing Light Bulbs...... 529

Playing Rivetooth® Audio 213 268	Fuses 576, 578
, ,	Tires
	Wiper Blade Rubber 535
3	Reporting Safety Defects
	Resetting a Trip Meter 100, 104
3	
runcture (me)	Road Departure Mitigation (RDM) 460 Indicator 84
	On and Off
R	On and On 461
Padiator E24	
	S
·	Safa Driving
	Safe Driving
	Safety Check
	Safety Labels
	Safety Message 1
	Seat Belts 34
33	Automatic Seat Belt Tensioners
	Checking 40
=	Fastening 37
	Installing a Child Seat with a Lap/Shoulder Seat
Rearview Mirror 159	Belt 61
Refueling 497	Pregnant Women
Fuel Gauge	Reminder
Gasoline 497, 582, 584	Warning Indicator 35, 74
Low Fuel Indicator	Seat Heaters 179
Regulations 477, 540, 587	Seats
Remote Engine Start 425	Adjusting 161
Remote Transmitter 123	Front Seats
Replacement	Rear Seat Access
Battery 547	Rear Seats
Bulbs	Seat Heaters
	Fuel Gauge 98 Gasoline 497, 582, 584 Low Fuel Indicator 75 Regulations 477, 540, 587 Remote Engine Start 425 Remote Transmitter 123 Replacement 547

Security System
Immobilizer System Indicator 80
Security System Alarm Indicator 80
SEL/RESET Button 103
Select/Reset Knob
Selecting a Child Seat 58
Selector Knob (Audio) 192
Sequential Shift Mode 436
Operation 437
Shift Lever 19, 430, 434, 438
Operation 19, 431, 435, 438
Releasing 569
Won't Move 569
Shift Lever Position Indicator 72, 431, 435
Shifting (Transmission) 430, 434, 438
Side Airbags
Side Curtain Airbags 50
Siri Eyes Free
SiriusXM® Radio 244
Smart Entry Remote 118, 425
Smart Entry with Push Button Start
System 121
Snow Tires 545
Song By Voice [™] (SBV)
Spare Tire 557, 583, 585
Spark Plugs 582, 584
Specifications 582
Specified Fuel 497, 582, 584
Speedometer
SRS Airbags (Airbags) 44

Starting the Engine	421, 423
Does Not Start	563
Engine Switch Buzzer	140
Jump Starting	566
Remote Engine Start	425
Steering Wheel	
Adjusting	158
Stopping	491
Summer Tires	545
Sunglasses Holder	178
Supplemental Restraint System	(SRS) 44
Switches (Around the Steering	
Wheel)	4, 5, 140
SYNC Mode	182
System Message Indicator	79
-	
T	
Tachometer	98
Temperature	
Outside Temperature Display	101, 105
Temperature Sensor	101, 105, 183
Time (Setting)	116
Tire Pressure Monitoring System	า
(TPMS)	475
Indicator	78, 575
Tires	537
Air Pressure	538, 583, 585
Checking and Maintaining	
Inspection	

Spare Tire 557, 583, 585				
Puncture (Flat Tire) 557 Regulations 540 Rotation 544 Spare Tire 557, 583, 585 Summer 545 Tire Chains 545 Wear Indicators 542 Winter 545 Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring 59 System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 430 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Labeling			538
Rotation 544 Spare Tire 557, 583, 585 Summer 545 Tire Chains 545 Wear Indicators 545 Winter 545 Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 430 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	_			
Spare Tire 557, 583, 585 Summer 545 Tire Chains 545 Wear Indicators 545 Winter 545 Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 430 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Regulations			540
Summer 545 Tire Chains 545 Wear Indicators 542 Winter 545 Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 430 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Rotation			544
Tire Chains 545 Wear Indicators 542 Winter 545 Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 430 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Spare Tire	557,	583,	585
Wear Indicators 542 Winter 545 Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 430 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Summer			545
Winter 545 Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 432 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Tire Chains			545
Tools 556 Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 430 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Wear Indicators			542
Towing a Trailer 417 Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 432 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Winter			545
Equipment and Accessories 418 Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 432 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Tools			556
Load Limits 417 Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 432 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Towing a Trailer			417
Towing Your Vehicle 420 Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 432 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Equipment and Accessories			418
Emergency 580 TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 432 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Load Limits			417
TPMS (Tire Pressure Monitoring System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 432 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Towing Your Vehicle			420
System) 475 Indicator 78, 575 Transmission 430, 434, 438 Automatic 434 Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Emergency			580
Indicator 78, 575 Transmission 430, 434, 438 Automatic 436 Continuously Variable (CVT) 436 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	TPMS (Tire Pressure Monitoring	g		
Transmission 430, 434, 438 Automatic 434 Continuously Variable (CVT) 436 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	System)			475
Automatic 434 Continuously Variable (CVT) 436 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Indicator		. 78,	575
Continuously Variable (CVT) 430 Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Transmission	430,	434,	438
Fluid 525, 526 Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Automatic			434
Manual 438 Number 586 Shift Lever Position Indicator 72, 431, 435	Continuously Variable (CVT)			430
Number	Fluid		525,	526
Shift Lever Position Indicator 72, 431, 435	Manual			438
	Number			586
Trip Meter 100, 104				
	Trip Meter		100,	104

Troubleshooting 555	Vehicle Identification Number 586	Window Washers	163
Blown Fuse 576, 578	Vehicle Stability Assist (VSA®)	Adding/Refilling Fluid	
Brake Pedal Vibrates	Off Button	Switch	
Buzzer Sounds When Opening Door	Off Indicator		
, 3		Windows (Opening and Closing)	
Emergency Towing	System Indicator		
Engine Won't Start	Ventilation	Cleaning 550, !	
Noise When Braking	Viscosity (Oil)	Defrosting/Defogging	
Overheating	Voice Control Operation	Washer Fluid	
Puncture/Flat Tire	Audio Commands	Wiper Blades	
Shift Lever Won't Move 569	Climate Control Commands 238	Wipers and Washers	152
Warning Indicators 70	General Commands 238	Winter Tires	
Trunk 129	Music Search Commands 238	Snow Tires	
Lid	On Screen Commands	Tire Chains	545
Light Bulb 582, 584	Phone Commands	Wipers and Washers	152
Main Switch 131	Useful Commands237	Automatic Intermittent Wipers	153
Turn Signals	Voice Portal Screen	Checking and Replacing Wiper Blades!	535
Indicators (Instrument Panel)	Voice Recognition 235	Wireless Charger	175
	VSA® (Vehicle Stability Assist)	WMA 201, 210, 252, 2	265
U	•	Worn Tires	537
Unlocking the Doors	W		
Unlocking the Doors from the Inside 13	Wallpaper 195, 222		
USB Flash Drives	Warning and Information Messages 88, 90		
USB Port(s)	Warning Indicator On/Blinking 572		
Using the Smart Entry with Push Button Start	Warning Labels		
System	Warranties (Warranty Manual provided		
System 121	separately) 591		
	•		
V	Watts		
Valet Kov. 110, 131	Wear Indicators (Tire)		
Valet Key	Wheel Nut Wrench (Jack Handle)		
Vanity Mirrors 7	Wi-Fi Connection 275		