

# THE BMW 5 SERIES SEDAN. OWNER'S MANUAL.

## BMW EfficientDynamics Less emissions. More driving pleasure.

## **5 Series**

### Owner's Manual for the vehicle

Thank you for choosing a BMW.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new BMW. Also use the Integrated Owner's Manual in your vehicle. It contains important information on vehicle operation that will help you make full use of the technical features available in your BMW. The manual also contains information designed to enhance operating reliability and road safety, and to contribute to maintaining the value of your BMW.

Any updates made after the editorial deadline can be found in the appendix of the printed Owner's Manual for the vehicle.

Supplementary information can be found in the additional brochures in the onboard literature.

We wish you a safe and enjoyable trip.



The Owner's Manual is available in many countries as an app. Additional information on the Internet:

www.bmw.com/bmw\_drivers\_guide

© 2016 Bayerische Motoren Werke Aktiengesellschaft Munich, Germany Reprinting, including excerpts, only with the written consent of BMW AG, Munich. US English ID4 VI/16, 07 16 490 Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

## **Contents**

The fastest way to find information on a particular topic or item is by using the index, refer to page 280.

6 Information

### At a glance

- 14 Cockpit
- 18 iDrive
- 26 Voice activation system
- 29 Integrated Owner's Manual in the vehicle

#### **Controls**

- 34 Opening and closing
- 53 Settings
- 66 Transporting children safely
- 70 Driving
- 87 Displays
- 107 Lights
- 113 Safety
- 141 Driving stability control systems
- 149 Driving comfort
- 171 Climate control
- 178 Interior equipment
- 188 Storage compartments

### **Driving tips**

- 196 Things to remember when driving
- 200 Loading
- 203 Saving fuel

### **Mobility**

- 212 Refueling
- 214 Fuel
- 219 Wheels and tires
- 241 Engine compartment
- 244 Engine oil
- 248 Coolant
- 250 Maintenance
- 252 Replacing components
- 259 Breakdown assistance
- 266 Care

#### Reference

- 274 Technical data
- 278 Appendix
- 280 Everything from A to Z

## Information

## **Using this Owner's Manual**

#### Orientation

The fastest way to find information on a particular topic is by using the index.

An initial overview of the vehicle is provided in the first chapter.

## Updates made after the editorial deadline

Due to updates after the editorial deadline, differences may exist between the printed Owner's Manual and the following Owner's Manuals:

- Integrated Owner's Manual in the vehicle.
- Online Owner's Manual.
- BMW Driver's Guide app.

Notes on updates can be found in the appendix of the printed Owner's Manual for the vehicle.

### Owner's Manual for Navigation, Entertainment, Communication

The Owner's Manual for Navigation, Entertainment, and Communication can be obtained as printed book from the service center.

The topics of Navigation, Entertainment, and Communication can be called up via the following Owner's Manuals:

- Integrated Owner's Manual in the vehicle on the Control Display.
- Online Owner's Manual.
- BMW Driver's Guide app.

## Additional sources of information

#### Dealer's service center

A dealer's service center will be glad to answer additional questions at any time.

#### Internet

Owner's Manual and general information about BMW, such as about the technology, in the Internet: www.bmwusa.com.

### **BMW Driver's Guide App**



The Owner's Manual is available in many countries as an app. Additional information on the Internet:

www.bmw.com/bmw\_drivers\_guide

## Symbols and displays

## Symbols in the Owner's Manual

- Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.
- → Marks the end of a specific item of information.
- Refers to measures that can be taken to help protect the environment.
- "..." Identifies display texts in vehicle used to select individual functions.
- >.... Verbal instructions to use with the voice activation system.
- »...« Identifies the answers generated by the voice activation system.

### **Action steps**

Action steps to be carried out are presented as numbered list. The steps must be carried out in the defined order.

- First action step.
- 2. Second action step.

#### **Enumerations**

Enumerations without mandatory order or alternative possibilities are presented as list with bullet points.

- First possibility.
- Second possibility.

### Symbols on vehicle components

II Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

## Vehicle features and options

This Owner's Manual describes all models and all standard, country-specific and optional equipment that is offered in the model series. Therefore, this Owner's Manual also describes and illustrates features and functions that are not available in your vehicle, e.g., because of the selected optional features or the country-specific version.

This also applies to safety-related functions and systems.

When using these functions and systems, the applicable country provisions must be observed.

For any options and equipment not described in this Owner's Manual, refer to the Supplementary Owner's Manuals.

On right-hand drive vehicles, some control elements are arranged differently from what is shown in the illustrations.

## Status of the Owner's Manual

#### **Basic information**

The manufacturer of your vehicle pursues a policy of constant development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards. In rare cases, therefore, the features described in this Owner's Manual may differ from those in your vehicle.

## Updates made after the editorial deadline

Due to updates after the editorial deadline, differences may exist between the printed Owner's Manual and the following Owner's Manuals:

- Integrated Owner's Manual in the vehicle.
- Online Owner's Manual.
- BMW Driver's Guide app.

Notes on updates can be found in the appendix of the printed Owner's Manual for the vehicle.

## **Own safety**

#### Intended use

Observe the following when using the vehicle:

- Owner's Manual.
- Information on the vehicle. Do not remove stickers.
- Technical vehicle data.
- ► The laws and safety standards applicable in the country, where the vehicle is driven.
- Vehicle documents and statutory documents.

### Warranty

Your vehicle is technically configured for the operating conditions and registration require-

ments applying in the country of first delivery, also known as homologation. If your vehicle is to be operated in a different country it might be necessary to adapt your vehicle to potentially differing operating conditions and permit requirements. If your vehicle does not comply with the homologation requirements in a certain country you may not be able to lodge warranty claims for your vehicle there. Further information on warranty is available from a dealer's service center.

### Maintenance and repairs

Advanced technology, e.g., the use of modern materials and high-performance electronics, requires suitable maintenance and repair work.

The manufacturer of the vehicle recommends that you entrust corresponding procedures to a BMW dealer's service center. If you choose to use another service facility, BMW recommends use of a facility that performs work, e.g., maintenance and repair, according to BMW specifications with properly trained personnel, referred to in this Owner's Manual as "another qualified service center or repair shop".

If work, e.g., maintenance and repair, is performed improperly, there is a risk of subsequent damage and related safety risks.

#### Parts and accessories

BMW recommends the use of parts and accessory products approved by BMW.

Approved parts and accessories, and advice on their use and installation are available from a BMW dealer's service center.

BMW parts and accessories have been tested by BMW for their safety and suitability in BMW vehicles.

BMW warrants genuine BMW parts and accessories.

BMW does not evaluate whether each individual product from another manufacturer can be used with BMW vehicles without presenting a safety hazard, even if a country-specific official

approval was issued. BMW does not evaluate whether these products are suitable for BMW vehicles under all usage conditions.

### **California Proposition 65 Warning**

California laws require us to state the following warning:

Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition. certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water.

## Service and warranty

We recommend that you read this publication thoroughly. Your vehicle is covered by the following warranties:

- New Vehicle Limited Warranty.
- Rust Perforation Limited Warranty.
- Federal Emissions System Defect Warranty.
- Federal Emissions Performance Warranty.
- California Emission Control System Limited Warranty.

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to de-

liver the full driving pleasure while the vehicle is operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

#### Maintenance

Maintain the vehicle regularly to sustain the road safety, operational reliability and the New Vehicle Limited Warranty.

Specifications for required maintenance measures:

- BMW Maintenance system
- Service and Warranty Information Booklet for US models
- Warranty and Service Guide Booklet for Canadian models

If the vehicle is not maintained according to these specifications, this could result in serious damage to the vehicle. Such damage is not covered by the BMW New Vehicle Limited Warranty.

## **Data memory**

Many electronic components on your vehicle are equipped with data memories that temporarily or permanently store technical information about the condition of the vehicle, events and faults. This technical information generally records the state of a component, a module, a system or the environment:

- Operating states of system components, e.g., fill levels.
- Status messages for the vehicle and from its individual components, e.g., wheel rotation speed, wheel speed, deceleration, transverse acceleration.

- Malfunctions and faults in important system components, e.g., lights and brakes.
- Responses by the vehicle to special situations such as airbag deployment or engagement of the stability control systems.
- Ambient conditions, such as temperature.

This data is purely technical in nature and is used to detect and correct faults and to optimize vehicle functions. Motion profiles over routes traveled cannot be created from this data. When service offerings are used, e.g., repair services, service processes, warranty claims, quality assurance, this technical information can be read out from the event and fault memories by employees of a dealer's service center or another qualified service center or repair shop, including the manufacturer, using special diagnostic tools. You can obtain further information there if you need it. After an error is corrected, the information in the fault memory is deleted or overwritten on a continuous basis.

With the vehicle in use there are situations where you can associate this technical data with individuals if combined with other information, e.g., an accident report, damage to the vehicle, eye witness accounts — possibly with the assistance of an expert.

Additional functions that are contractually agreed with the customer — such as vehicle emergency locating — allow certain vehicle data to be transmitted from the vehicle.

## **Event Data Recorder EDR**

This vehicle is equipped with an event data recorder EDR. The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a

short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating.
- Whether or not the driver and passenger safety belts were fastened.
- How far, if at all, the driver was depressing the accelerator and/or brake pedal.
- How fast the vehicle was traveling.

This data can help provide a better understanding of the circumstances in which crashes and injuries occur.

EDR data is recorded by your vehicle only if a nontrivial crash situation occurs; no data is recorded by the EDR under normal driving conditions and no personal data, e.g., name, gender, age, and crash location, are recorded.

However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

## Vehicle identification number



The vehicle identification number can be found in the engine compartment.

The vehicle identification number can also be found behind the windshield.

## **Reporting safety defects**

#### For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA, in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.

However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other in-

formation about motor vehicle safety from http://www.safercar.gov.

## For Canadian customers

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may call the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from http://www.tc.gc.ca/roadsafety.






## **Cockpit**

## Vehicle features and options

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## Functions and controls in the cockpit




1 Seating comfort features



Seat, mirror, steering wheel memory 61



Active seat 56



- 3 Rear window safety switch 50
- 4 Power windows 48
- 5 Exterior mirror operation 62
- 6 Driver assistance systems



Active Blind Spot Detection 136



Intelligent Safety 122



Lane departure warning 134



Night Vision 131



Head-up Display 104

7 Lights



Front fog lights 110



Light switch 107





Lights off

Daytime running lights 109



Parking lights 107



Low beams 107



Automatic headlamp control 108

Adaptive Light Control 109

High-beam Assistant 110



Instrument lighting 111

Steering column stalk, left



Turn signal 78



High beams, headlight flasher 78



High-beam Assistant 110



Roadside parking lights 108



Onboard computer 100

- 9 Shift paddles 85
- 10 Steering wheel buttons, left



Active Cruise Control on/off, interrupt 149



Cruise control on/off, interrupting 156



Cruise control: store speed



Cruise control: resume speed



Active Cruise Control: reduce distance



Active Cruise Control: increase distance

Cruise control rocker switch

- 11 Instrument cluster 87
- **12** Steering wheel buttons, right



Entertainment source



Volume



Voice activation 26



Telephone, see Owner's Manual for Navigation, Entertainment and Communication

Thumbwheel for selection lists 100

13 Steering column stalk, right



Wiper 78



Rain sensor 79



Clean the windshield and headlights 78



Start/stop the engine and switch the ignition on/off 71



Auto Start/Stop function 72



Horn, entire surface





Steering wheel heating 65

18


Open the tailgate 41

17

Adjust the steering wheel 64

19 Unlock the hood

## Functions and controls in the center console



- 1 Control Display 18
- 2 Glove compartment 188
- 3 Ventilation 174

4

Hazard warning system 259



Central locking system 38

- 5 Radio/CD/multimedia, see Owner's Manual for Navigation, Entertainment and Communication
- 6 Automatic climate control 171
- 7 Controller with buttons 19

8



Parking brake 74



Auto Hold 76





PDC Park Distance Control 158

Top View 164

Rearview camera 160

Parking assistant 166



Side View 163



HDC Hill Descent Control 143


10

Driving Dynamics Control 146 11 Transmission selector lever



DSC Dynamic Stability Control 141

## All around the roofliner





Intelligent emergency call 259

Reading lights 111

2



Glass sunroof, electric 50

5

Interior lights 111

3

Indicator lamp, front-seat passenger airbag 115

## **iDrive**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## **Concept**

The iDrive combines the functions of many switches. Thus, these functions can be operated from a central location.

## **Safety information**


WARNING

the vehicle is stationary. ◀

Operating the integrated information systems and communication devices while driving can distract from traffic. It is possible to lose control of the vehicle. There is a risk of an accident. Only use the systems or devices when the traffic situation allows. If necessary, stop and use the systems and devices while

## **Overview of control elements**

### Operation



- Control Display
- 2 Controller with buttons and, depending on the equipment version, with touchpad

### **Control Display**

### **General information**

To clean the Control Display, follow the care instructions.

Do not place objects close to the Control Display; otherwise, the Control Display can be damaged.

In the case of very high temperatures on the Control Display, e.g., due to intense solar radiation, the brightness may be reduced down to complete deactivation. Once the temperature is reduced, e.g., through shadow or climate control system, the normal functions are restored.


## **Switching on**

- 1. Switch on the ignition.
- 2. Press the controller.

## Switching off

1. Press button.

### 2. "Turn off control display"



#### Controller

The buttons can be used to open the menus directly. The controller can be used to select menu items and enter the settings.

Some iDrive functions can be operated using the touchpad on the controller.

### 1. Turn.



#### Press.



### 3. Move in four directions.



### **Buttons on the controller**


Button	Function
MENU	Opens the main menu.
RADIO	Opens the Radio menu.
MEDIA	Opens the Multimedia menu.
NAV	Opens the Navigation menu.
TEL	Opens the Phone menu.
BACK	Displays the previous panel.
OPTION	Open the Options menu.

## **Operating concept**

## Opening the main menu



Press button.




The main menu is displayed.

All iDrive functions can be called up via the main menu.

### Selecting menu items

Highlighted menu items can be selected.

 Turn the controller until the desired menu item is highlighted.



2. Press the controller.


#### Menu items in the Owner's Manual

In the Owner's Manual, menu items that can be selected are set in quotation marks, e.g., "Settings".

### **Changing between panels**

After a menu item is selected, e.g., "Radio", a new panel is displayed. Panels can overlap.

- Move the controller to the left.
   Closes current panel and shows previous display.
  - Reopens previous display by pressing BACK button. In this case, the current panel is not closed.
- Move the controller to the right.
   Opens new panel on top of previous screen.




White arrows pointing to the left or right indicate that additional panels can be opened.

### Opening the Options menu



Press button.

The "Options" menu is displayed.



Additional options: move the controller to the right repeatedly until the "Options" menu is displayed.


### Options menu

The "Options" menu consists of various areas:

- ▷ Screen settings, e.g., "Split screen".
- ▶ Control options for the selected main menu, e.g., for "Radio".
- ▶ If applicable, further operating options for the selected menu, e.g., "Store station".

## **Changing settings**

- 1. Select a field.
- Turn the controller until the desired setting is displayed.



Press the controller.

### **Activating/deactivating the functions**

Several menu items are preceded by a checkbox. It indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.

- Function is activated.
- Function is deactivated.

## **Touchpad**

Some iDrive functions can be operated using the touchpad on the controller.

### **Selecting functions**

- 1. "Settings"
- 2. "Touchpad"
- 3. Select the desired function.
  - "Speller": enter letters and numbers.
  - "Interactive map": use the interactive map.
  - ▶ "Browser": enter Internet addresses.
  - "Audio feedback": pronounces entered letters and numbers.

## **Entering letters and numbers**

Entering letters requires some practice at the beginning. When entering, pay attention to the following:

- The system distinguishes between upper and lower-case letters and numbers. For entries, it may be necessary to change between upper and lower-case letters, numbers and characters, refer to page 25.
- Enter characters as they are displayed on the Control Display.
- Always enter associated characters, such as accents or periods so that the letter can be clearly recognized. The set language determines what input is possible. Where necessary, enter special characters via the controller.

- ➤ To delete a character, swipe to the left on the touchpad.
- ➤ To enter a blank space, swipe to the right in the center of the touchpad.
- To enter a hyphen, swipe to the right in the upper area of the touchpad.
- ➤ To enter an underscore, swipe to the right in the lower area of the touchpad.

### Using the interactive map and Internet

The interactive map in the navigation system and Internet pages can be moved using the touchpad.

Function	Operation
Move interactive map or Internet pages.	Swipe into respective direction.
Enlarge/shrink interactive map or Internet pages.	Drag in or out on the touchpad with fingers.
Display the menu or open	Tap once.

## **Changing settings**

a link on the Internet.


You can use the touchpad to change Control Display settings, e.g., volume. Swipe left or right accordingly.

## **Example: setting the clock**

### Setting the clock

On the Control Display:

- Press button. The main menu is displayed.
- 2. Turn the controller until "Settings" is highlighted, and then press the controller.



- If necessary, move the controller to the left to display "Time/Date".
- Turn the controller until "Time/Date" is highlighted, and then press the controller.



Turn the controller until "Time:" is highlighted, and then press the controller.



- 6. Turn the controller to set the hours, and then press the controller.
- 7. Turn the controller to set the minutes, and then press the controller.

## Status information

#### Status field

The following information is displayed in the status field at the top right:

- ▶ Time.
- Current entertainment source.
- Sound output, on/off.
- Wireless network reception strength.
- Phone status.
- Traffic bulletin reception.

### Status field symbols

The symbols are grouped as follows:

## Radio symbols

Symbol	Meaning
H))	HD Radio station is being received.
1	Satellite radio is switched on.

## **Telephone symbols**

Symbol	Meaning
~	Incoming or outgoing call.
X	Missed call.
atl	Wireless network reception strength.  Symbol flashes: network search.
atl	Wireless network is not available.
3	Bluetooth is switched on.
<b>A</b>	Roaming is active.

Symbol	Meaning
$\bowtie$	Text message was received.
<b></b> €0	Check the SIM card.
<b>■</b> ê	SIM card is blocked.
<b>/</b>	SIM card is missing.
<u> </u>	Enter PIN.

### **Entertainment symbols**

Symbol	Meaning
<b>(3)</b>	CD/DVD player.
	Music collection.
gracenote	Gracenote® database.
P	AUX-IN port in the front or in the rear.
ψ	USB audio interface.
Ø.	Mobile phone audio interface.

## **Additional symbols**

Symbol	Meaning
炣	Spoken instructions are turned off.
0	Check the current vehicle position.

## **Split screen**

### **General information**

Additional information can be displayed on the right side of the split screen, e.g., information from the onboard computer.

In the divided screen view, the so-called split screen, this information remains visible even when switching to another menu.

### Switching the split screen on/off


On the Control Display:

- OPTION Pr
  - Press button.
- 2. "Split screen"

### Selecting the display

On the Control Display:

- OPTION
  - Press button.
- 2. "Split screen"
- Move the controller until the split screen is selected.
- Press the controller or select "Split screen content".
- 5. Select the desired menu item.



## Programmable memory buttons

#### General information

The iDrive functions can be stored on the programmable memory buttons and called up directly, e.g., radio stations, navigation destinations, phone numbers and menu entries.

Settings are stored for the profile currently used.

### Saving a function

1. Highlight the function via iDrive.

2. 1...8 Press and hold the desired button, until a signal sounds.

## **Running a function**

Press button.


The function will work immediately.

This means, e.g., that the number is dialed when a phone number is selected.

## Displaying the key assignment

Touch buttons with finger. Do not wear gloves or use objects.

The button assignment is displayed at the top edge of screen.



## **Deleting the button assignments**

- 1. Press buttons 1 and 8 simultaneously for approx. 5 seconds.
- 2. "OK"

## **Deleting personal data in the vehicle**

## Concept

Depending on the usage, the vehicle saves personal data, such as stored radio stations. This personal data can be permanently deleted using iDrive.

### **General information**

Depending on the equipment package, the following data can be deleted:

- Personal Profile settings.
- Stored radio stations.
- Stored Favorites buttons.
- ▶ Travel and onboard computer information.
- Music collection.
- Navigation, e.g., stored destinations.
- ▶ Phone book.
- Online data, e.g., Favorites, cookies.
- Voice notes.
- Login accounts.
- RemoteApp smartphone tethering.

Altogether, the deletion of the data can take up to 30 minutes.

### **Functional requirement**

Data can only be deleted while stationary.

### **Deleting data**

Heed and follow the instructions on the Control Display.

- 1. Switch on the ignition.
- 2. "Settings"
- 3. Open "Options".
- "Delete personal data"
- 5. "Continue"
- 6. "OK"

## **Entering letters and numbers**

#### General information

On the Control Display:

- Turn the controller: select a letter or number.
- Select additional letters or numbers, if needed.
- 3. "OK": confirm the entry.

Symbol	Function
l←	Press the controller: delete the letter or number.
l←	Press the controller for an extended period: delete all letters or numbers.

## Switching between upper/lower case, numbers and characters

Depending on the menu, you can switch between entering upper and lower case letters and numbers:

Symbol	Function
A <sup>B</sup> C	Enter the letters.
1@+	Enter the numbers.
abc or ABC	Tip the controller up.

### Without navigation system

### **Entry comparison**

When entering names and addresses, the choice is narrowed down with every letter entered and letters may be added automatically.

Entries are continuously compared with data stored in the vehicle.

- Only those letters are offered during entry for which data is available.
- Destination search: place names can be entered in all languages that are available on the Control Display.

## Voice activation system

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## **Concept**

- Most functions displayed on the Control Display can be operated by voice commands via the voice activation system. The system supports you with announcements during input.
- Functions that can only be used when the vehicle is stationary cannot be used via the voice activation system.
- ➤ The system uses a special microphone on the driver's side.
- > .... in the Owner's Manual denotes verbal instructions to use with the voice activation system.

## Requirements

Via the Control Display, set a language that is also supported by the voice activation system so that the spoken commands can be identified.

Set the language, refer to page 103.

## Using the voice activation system

## **Activating the voice activation system**

- 1. Press button on the steering wheel.
- 2. Wait for the signal.
- 3. Say the command.

A command that is recognized by the voice activation system is announced and displayed in the instrument cluster.

wh This symbol in the instrument cluster indicates that the voice activation system is active. If no other commands are possible, operate the function via iDrive.

## Terminating the voice activation system



Press the button on the steering wheel or Cancel.

## Possible commands

Most menu items on the Control Display can be voiced as commands.

The available commands depend on the menu that is currently displayed on the Control Display.

There are short commands for many functions.

You may select list entries such as phone list entries via voice activation. Read these list entries out loud exactly as they are shown in the respective list.

## Having possible commands read aloud

You can have available commands read out loud for you: >Voice commands.

E.g., if the "Settings" menu is displayed, the commands for the settings are read out loud.

## **Executing functions using short commands**

Execute functions on the main menu via short commands. It almost doesn't matter which menu item is selected, e.g., >Vehicle status.

List of short commands for the voice activation system, see Navigation, Entertainment, Communication Owner's Manual.

The list for short commands of the voice activation system can be called up via the Integrated Owner's Manual on the Control Display.

## Help dialog for the voice activation system

Calling up help dialog: >Help«.

Additional commands for the help dialog:

- > Help with examples: announces information about the current operating options and the most important commands for them.
- Help with voice activation: announces information about the principle of operation for the voice activation system.

## **Example: opening the tone settings**

### Via the main menu

The commands of the menu items are spoken just as they are selected via the controller.

- Turn on the Entertainment sound output, if needed.
- 2. Press button on the steering wheel.
- 3. →Radio
- 4. ⇒Tone«

#### Via short command

The desired tone settings can also be started via a short command.


- Turn on the Entertainment sound output, if needed.
- 2. Press button on the steering wheel.
- Tone

## **Setting the voice dialog**

You can set the system to use standard dialog or a short version.

The short version of the voice dialog plays back short messages in abbreviated form.

- 1. "Settings"
- 2. "Language/Units"
- 3. "Speech type:"
- Select setting.



## Adjusting the volume

Turn the volume button during the spoken instructions until the desired volume is set.

- ➤ The volume remains constant even if the volume of other audio sources is changed.
- ➤ The volume is stored for the profile currently used.

## Information on Emergency Requests

Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a phone connection.

Instead, use the SOS button, refer to page 259, close to the interior mirror.

### **Environmental conditions**

- Say the commands, numbers, and letters smoothly and with normal volume, emphasis, and speed.
- Always say commands in the language of the voice activation system.
- Keep the doors, windows, and glass sunroof closed to prevent noise interference.
- Avoid making other noise in the vehicle while speaking.

## **Integrated Owner's Manual in the vehicle**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## Integrated Owner's Manual in the vehicle

The Integrated Owner's Manual can be displayed on the Control Display. It specifically describes features and functions found in the vehicle.

## Components of the Integrated Owner's Manual

The Integrated Owner's Manual consists of three parts, which offer various levels of information or possible access.

### **Quick Reference Guide**

The Quick Reference Guide provides information on how to operate the vehicle, how to use basic vehicle functions and what to do in case of a breakdown. This information can also be displayed while driving.

## Search by images


Based on illustrations, image search provides information and descriptions. This is useful, e.g., when the terminology for a feature is not known.

### **Owner's Manual**

Search for information and descriptions by entering terms selected from the index.

### Select components

- MENU
- Press button.
- 2. Turn the controller: open "Vehicle info".
- 3. Press the controller.
- 4. Selecting desired range:
  - "Quick reference"
  - "Search by pictures"
  - "Owner's Manual"



## **Leafing through the Owner's Manual**

## Page by page with link access

Turn the controller until the next or previous page is displayed.

## Page by page without link access

Scroll through the pages directly while skipping the links.

Highlight the symbol once. Now simply press the controller to browse from page to page.



Scroll back.



Scroll forward.

## Context help - operating instructions for the currently selected function

The relevant information can be opened directly.

### **Opening via iDrive**

To move directly from the application on the Control Display to the Options menu:

- 1. Press button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"

## Opening when a Check Control message is displayed

Directly from the Check Control message on the Control Display:

"Display Owner's Manual"

## Changing between a function and the operating instructions

To switch from a function, e.g., radio, to the Owner's Manual on the Control Display and to alternate between the two displays:

- 1. Press button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"
- Select the desired page in the Owner's Manual.
- 4. Press button again to return to last displayed function.
- 5. Press button to return to the page of the Owner's Manual displayed last.

To alternate permanently between the last displayed function and the Owner's Manual repeat steps 4 & 5. Opens a new display every time.

### **Programmable memory buttons**

### **General information**

The Owner's Manual can be stored on the programmable memory buttons and called up directly.


### **Storing**

- 1. "Owner's Manual" Select via iDrive.
- 2. Press selected button for more than 2 seconds.

### **Executing**

Press button.
The Owner's Manual is displayed immediately.





## **Opening and closing**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

### Remote control

### **General information**

The vehicle is supplied with two remote controls with integrated key.

Each remote control contains a replaceable battery. Replace the battery, refer to page 36.

You may set the key functions depending on the optional features and country-specific version. Settings, refer to page 46.

The vehicle stores personal settings for every remote control. Personal Profile, refer to page 44.

The remote controls hold information about required maintenance. Service data in the remote control, refer to page 250.

## Safety information

WARNING
People or animals in the vehicle can lock
the doors from the inside and lock themselves
in. The vehicle can then not be opened from
the outside. There is a risk of injury. Take the
remote control with you so that the vehicle can
be opened from the outside.

✓

## WARNING

Unlocking from the inside is only possible with special knowledge.

If people must spend a longer time in the vehicle while it is very hot or cold outside, there is a risk of injury or danger to life. Do not lock the vehicle from the outside when there are people in it.◀


### WARNING

Unattended children or animals can cause the vehicle to move and endanger themselves and traffic, e.g., due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the remote control with you when exiting and lock the vehicle. ◀

#### Overview



- 1 Unlock
- 2 Lock

- 3 Opening the tailgate
- 4 Press briefly: headlamp courtesy delay feature

Press and hold: panic mode

### **Unlocking**



Press button on the remote control.

Depending on the settings, refer to page 46, the following access points are unlocked.

- Driver's door and fuel filler flap.
- ▶ All doors, tailgate, and fuel filler flap.

In addition, the following functions are executed:

- The settings saved in the driver profile, refer to page 44, are applied.
- The interior lights and courtesy lamps are activated. This function is not available, if the interior lamps were switched off manually.
- The welcome lights are switched on, if this function was activated.
- With anti-theft protection: Anti-theft protection is switched off.
- The alarm system, refer to page 47, is switched off.

The light functions may depend on the ambient brightness.

## **Convenient opening**



Press and hold this button on the remote control after unlocking.

The windows and the glass sunroof are opened, as long as the button on the remote control is pressed.

### Locking

- 1. Close the driver's door.
- 2.

Press button on the remote control.

- All doors, the tailgate, and the fuel filler flap are being locked.
- With anti-theft protection: Anti-theft protection is switched on. It prevents the doors from being unlocked using the lock buttons or the door openers.
- The alarm system, refer to page 47, is switched on.

If the vehicle horn honks twice when you lock the vehicle, this means that the engine or ignition is still switched on. In this case, switch off the engine or the ignition using the Start/Stop button.

#### Lock



Press button on the remote control with the vehicle locked.

This function is not available, if the interior lamps were switched off manually.

The light functions may depend on the ambient brightness.

If the button is pressed again within 10 seconds after vehicle was locked, the interior motion sensor and tilt alarm sensor of the antitheft warning system, refer to page 48, are turned off. After locking, wait 10 seconds before pressing the button again.

## **Tailgate**

### **General information**

To avoid locking it into the vehicle, do not place the remote control in the cargo area.

Depending on your vehicle's equipment and the country version, it is possible to specify whether the doors are also unlocked when unlocking with the remote control. Create the settings, refer to page 46.

### **Safety information**

WARNING

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailgate is clear during opening and closing. ◄

NOTE

During opening, the tailgate pivots back and up. There is a risk of property damage. Make sure that the area of movement of the tailgate is clear during opening and closing.

### **Opening**



Press button on the remote control for approx. 1 second.

### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.



Press button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

### Switching on the headlamp courtesy delay feature



Briefly press the button on the remote control.

Set length of time, refer to page 108.


## Replacing the battery

- 1. Remove the integrated key from the remote control, refer to page 38.
- 2. Place the integrated key underneath the battery compartment cover, arrow 1, and

lift the cover with a lever movement of the integrated key, arrow 2.



3. Using a pointed object, press battery in direction of arrow and lift it out.



- 4. Insert a type CR 2450 battery with the positive side facing up.
- Press the cover closed.



Have old batteries disposed of by a dealer's service center or another qualified service center or repair shop or take them to a collection point.

#### New remote controls

New remote controls are available from a dealer's service center or another qualified service center or repair shop.

## **Blocking remote controls**

A lost remote control can be blocked by a dealer's service center or another qualified service center or repair shop.

#### Malfunction

#### **General information**


A Check Control message is displayed.

Remote control detection by the vehicle may malfunction under the following circumstances:

- The battery of the remote control is discharged. Replace the battery, refer to page 36.
- Interference of the radio connection from transmission towers or other equipment with high transmitting power.
- Shielding of the remote control due to metal objects.
  - Do not transport the remote control together with metal objects.
- Interference of the radio connection from mobile phones or other electronic devices in direct proximity to the remote control.
  - Do not transport the remote control together with electronic devices.
- Interference of radio transmission by a charging process of a mobile device, e.g., charging of a mobile phone.

In the case of interference, the vehicle can be unlocked and locked from the outside with the integrated key, refer to page 37.

## Starting the engine via emergency detection of the remote control



 Hold the remote control with its back against the marked area on the steering column. 2. Start the engine within 10 seconds.

If the remote control is not detected, slightly change the position of the remote control and repeat the procedure.

## **Integrated key**

#### General information

The driver's door can be locked and unlocked without remote control using the integrated key.

The integrated key can also be used for the storage compartment in the front center armrest.

### **Safety information**

WARNING

Unlocking from the inside is only possible with special knowledge.

If people must spend a longer time in the vehicle while it is very hot or cold outside, there is a risk of injury or danger to life. Do not lock the vehicle from the outside when there are people in it.◀

NOTE

The door lock is permanently joined with the door. The door handle can be moved. When pulling the door handle with the integrated key inserted, paint or key can be damaged. There is a risk of property damage. Remove the integrated key before pulling the outside door handle.

### Removing



Press button, arrow 1, and remove key, arrow 2.

## Locking/unlocking via the door lock



Unlock or lock the driver's door via the door lock using the integrated key.

The other doors must be unlocked or locked from the inside.

## **Alarm system**

The alarm system is not switched on if the vehicle is locked with the integrated key.

The alarm system is triggered when the door is opened, if the vehicle has been unlocked via the door lock.

In order to stop this alarm, unlock vehicle with the remote control or switch on the ignition, if needed, through emergency detection of the remote control, refer to page 37.

# **Button for central locking system**

#### **General information**

In the event of a severe accident, the vehicle is automatically unlocked. The hazard warning system and interior lights come on.

#### **Overview**



Button for the central locking system.

### **Unlocking and locking**

Pressing the central locking system button locks or unlocks the vehicle with the front doors closed.

- ▶ The fuel filler flap remains unlocked.
- ▶ The vehicle is not secured against theft when locking.

## **Unlocking and opening**

- Press the central locking system button to unlock the doors together, and then pull the door handle above the armrest.
- On the door to be opened, pull the door handle twice: the first time unlocks the door, the second time opens it. The other doors remain locked.

## **Comfort Access**

### Concept

The vehicle can be accessed without activating the remote control.

All you need to do is to have the remote control with you, such as in your pants pocket.

The vehicle automatically detects the remote control when it is in close proximity or in the vehicle's interior.

#### **General information**

Comfort Access supports the following functions:

- Unlocking/locking of the vehicle.
- Convenient closing. **>**
- Opening tailgate.
- Open tailgate with no-touch activation.
- Opening/closing tailgate with no-touch activation.

#### **Functional requirements**

- ▶ To lock the vehicle, the remote control must be located outside of the vehicle near the doors.
- The next unlocking and locking cycle is not possible until after approx. 2 seconds.

## **Unlocking**



Grasp the handle of a vehicle door completely, arrow.

This corresponds with pressing the button of on the remote control.

#### Locking



Touch the surface on the handle of a vehicle door, arrow, with your finger for approx. 1 second without grasping the door handle.

This corresponds with pressing the button 🔮 on the remote control.



## Convenient closing

### Safety information

WARNING

With convenient closing, body parts can be jammed. There is a risk of injury. Make sure that the area of movement of the doors is clear durina convenient closina.◀

## Closing



Touch the surface on the handle of a vehicle door, arrow, with your finger and hold it there without grasping the door handle.

This corresponds with pressing and holding the button (a) on the remote control.

In addition to locking, the windows and the glass sunroof close and the exterior mirrors fold in.

#### **Open tailgate**

#### **General information**

If you open the tailgate via Comfort Access, locked doors will not be unlocked.

To avoid locking it in the vehicle, do not place the remote control in the cargo area.

#### **Safety information**

WARNING

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailgate is clear during opening and closing.

NOTE

During opening, the tailgate pivots back and up. There is a risk of property damage. Make sure that the area of movement of the tailgate is clear during opening and closing.

## **Opening**



Press button on the tailgate.

## Opening and closing tailgate with notouch activation

## Concept

The tailgate can be opened with no-touch activation using the remote control you are carry-

ing. With automatic tailgate operation, it can also be closed with no-touch activation. Two sensors detect a forward-directed foot motion in the center of the area at the rear of the vehicle and the tailgate opens and/or closes.

#### **General information**

To avoid locking it in the vehicle, do not place the remote control in the cargo area.

If the remote control is in the sensor range, the tailgate may open or close inadvertently if you unintentionally move your foot or if something else moves in the detection range.

The sensor has an approximate range of 5 ft/1.50 m extending from the rear of the vehicle.

If you open the tailgate with no-touch activation, locked doors will not be unlocked.

#### **Safety information**

WARNING

During no-touch activation, vehicle parts may be touched, e.g., hot exhaust system.

There is a risk of injury. When moving your foot, make sure you have a firm stance and do not touch the vehicle.

WARNING

NOTE

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailgate is clear during opening and closing. ◄

During opening, the tailgate pivots back and up. There is a risk of property damage. Make sure that the area of movement of the tailgate is clear during opening and closing.

## **Performing the foot movement**

**↑** WARNING

During no-touch activation, vehicle parts may be touched, e.g., hot exhaust system.

There is a risk of injury. When moving your

foot, make sure you have a firm stance and do not touch the vehicle. ◀

- Stand in the middle behind the vehicle at about an arm's length away from the rear of the vehicle.
- Wave a foot under the vehicle in the direction of travel and immediately pull it back.With this movement, the leg must pass through the ranges of both sensors.



### **Opening**

Perform the foot movement described earlier.

The tailgate opens, regardless of whether it was previously locked or unlocked.

Before the opening, the hazard warning system flashes.

## Closing

Tailgate closing with no-touch activation is only possible with automatic tailgate operation.

Perform the foot movement described earlier.

The hazard warning system flashes on and an acoustic signal sounds before the tailgate closes.

You can interrupt the closing operation by moving your foot again.

#### Malfunction

Remote control detection by the vehicle may malfunction under the following circumstances:

- The battery of the remote control is discharged. Replace the battery, refer to page 36.
- Interference of the radio connection from transmission towers or other equipment with high transmitting power.
- Shielding of the remote control due to metal objects.
  - Do not transport the remote control together with metal objects.
- Interference of the radio connection by mobile phones or other electronic devices in direct proximity of the remote control.
  - Do not transport the remote control together with electronic devices.

In the case of a malfunction, unlock and lock the vehicle using the buttons of the remote control or using the integrated key, refer to page 37.

## **Tailgate**

#### **General information**

To avoid locking it into the vehicle, do not place the remote control in the cargo area.

Depending on your vehicle's equipment and the country version, it is possible to specify whether the doors are also unlocked when unlocking with the remote control. Create the settings, refer to page 46.

## Safety information

WARNING

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailgate is clear during opening and closing. ◄

#### NOTE

During opening, the tailgate pivots back and up. There is a risk of property damage. Make sure that the area of movement of the tailgate is clear during opening and closing.

### Without automatic tailgate operation

## **Opening from the outside**



Without Comfort Access: unlock the vehicle.

Press on the top half of the BMW label.



Press button on the remote control for approx. 1 second.

As the case may be, the doors are also unlocked. Unlocking with the remote control, refer to page 35.

## **Opening from the inside**



With the vehicle stationary, press the button in the driver's floor area.

#### Lock



With the driver's door shut, press button on the inside of the tailgate.

### Closing



Grasp the recess grip and pull tailgate down.

## With automatic tailgate operation

## **Opening**

#### From the outside



Without Comfort Access: unlock the vehicle.

Press button on the exterior of the tailgate.

Press button on the remote control for approx. 1 second.

As the case may be, the doors are also unlocked. Opening with the remote control, refer to page 35.

#### From the inside



Push the button in the driver's floor

#### **Canceling the opening operation**

The opening procedure is interrupted in the following situations:

- When the vehicle starts moving.
- By pressing the button on the outside of the tailgate.
- By pressing the button on the inside of the tailgate.
- By pressing the button on the remote control.
- By pressing the button in the driver's foot area.

## Closing

#### From the outside

Press button on the exterior of the tailgate.

#### From inside the tailgate

Without Comfort Access:



Press button on the inside of the tailgate.

With Comfort Access:



- Press button, arrow 1, on the inside of the tailgate.
- Press button, arrow 2.

The vehicle will be locked after closing the tailgate. The driver's door must be closed for this purpose and the remote control must be outside of the vehicle in the area of the tailgate.

#### **Canceling the closing operation**

The closing procedure is interrupted in the following situations:

- If the vehicle starts off with a jerky movement.
- By pressing the button on the outside of the tailgate.
- By pressing the button on the inside of the tailgate.

#### Malfunction

## **Safety information**

WARNING

With manual operation of a blocked tailgate, it can release itself unexpectedly from the blockage. There is a risk of injury or risk of property damage. Do not operate the tailgate manually if it is blocked. Have it checked by a dealer's service center or another qualified service center or repair shop.

#### Manual operation

In the event of an electrical malfunction, operate the unlocked tailgate manually with a slow and smooth motion.

To close it completely, push the tailgate down lightly. Closing occurs automatically.

#### Locking separately

The tailgate can be locked separately using the switch in the center armrest. If the center armrest is locked, the tailgate cannot be opened.



- ▶ Tailgate secured, arrow 1.
- Tailgate not secured, arrow 2.

Slide the switch into the arrow 1 position. The tailgate is secured and disconnected from the central locking system.

This is beneficial when the vehicle is parked using valet service. The remote control can be handed out without the integrated key.

### **Emergency unlocking**



Pull the handle inside the cargo area.

The tailgate unlocks.

WARNING

during opening and closing.

## **Automatic Soft Closing**

Thanks to Soft Close the closing goes into the lock automatically. Body parts can be jammed. There is a risk of injury. Make sure that the area of movement of the doors is clear

Push the doors and, if applicable, the tailgate lightly.

The closing happens automatically.

## **Personal Profile**

#### Concept

Using Personal Profile, individual settings for several drivers can be saved and called up again at a later time.

#### **General information**

There are three driver profiles with which personal vehicle settings can be stored. Every remote control has one of these driver profiles assigned.

If the vehicle is unlocked using a remote control, the assigned personal driver profile will be activated. All settings stored in the driver profile are automatically applied.

If several drivers use their own remote control, the vehicle will adjust the personal settings during unlocking. These settings are also restored, if the vehicle has been used in the meantime by a person with a different remote control.

Changes to the settings are automatically saved in the driver profile currently activated.

If another driver profile is selected via iDrive, the settings saved in it will be applied automatically. The new driver profile is assigned to the remote control currently used.

There is an additional profile available that is not assigned to any remote control: It can be used to apply settings in the vehicle without changing the personal driver profiles.

## **Settings**

The settings for the following systems and functions are saved in the active profile. The scope of storable settings depends on country and equipment.

- Unlocking and locking.
- ▶ Lights.

- Climate control.
- Radio.
- Instrument cluster.
- Programmable memory buttons.
- Volumes, tone.
- Control Display.
- Navigation.
- Park Distance Control PDC.
- Rearview camera.
- Side View.
- Top View.
- Head-up Display.
- Driving Dynamics Control.
- Driver's seat position, exterior mirror position, steering wheel position.
- Intelligent Safety.
- Active Blind Spot Detection.
- Night vision.

## **Profile management**

## **Opening profiles**

Regardless of the remote control in use, a different profile may be activated. This allows you to call up personal vehicle settings if you did not unlock the vehicle with your own key.

#### Via iDrive:

- 1. "Settings"
- 2. "Profiles"
- 3. Select a profile.
- All settings stored in the called-up profile are automatically applied.
- The called-up profile is assigned to the remote control being used at the time.
- If the profile is already assigned to a different remote control, this profile will apply to both remote controls.

### Using the guest profile

The guest profile is for individual settings that are saved in none of the three personal profiles.

This can be useful for drivers who are using the vehicle temporarily and do not have their own profile.

On the Control Display:

- 1. "Settings"
- 2. "Profiles"
- 3. "Guest"

The guest profile cannot be renamed. It is not assigned to the current remote control.

### **Renaming profiles**

A personal name can be assigned to every profile to avoid confusion between the profiles.

On the Control Display:

- "Settings"
- 2. "Profiles"
- 3. Open "Options".
- "Rename current profile"

## **Reset profiles**

The settings of the active profile are reset to their factory settings.

On the Control Display:

- 1. "Settings"
- "Profiles"
- Open "Options".
- "Reset current profile"

## **Exporting profiles**

Most settings of the active profile can be exported.

This can be helpful for saving and retrieving personal settings, e.g., before delivering the vehicle to a workshop. Profiles can be taken to another vehicle equipped with the Personal Profile function.

#### On the Control Display:

- 1. "Settings"
- 2. "Profiles"
- "Export profile"
- BMW Online: "BMW Online" USB interface: "USB device"

## **Importing profiles**

Profiles exported via BMW Online can also be imported via BMW Online.

Profiles stored on a USB storage device can be imported via the USB interface.

Existing settings are overwritten with the imported profile.

On the Control Display:

- 1. "Settings"
- 2. "Profiles"
- "Import profile"
- BMW Online: "BMW Online"
   USB interface: "USB device"

## Display profile list during start

The profile list can be displayed during each start to select the desired profile.

On the Control Display:

- "Settings"
- 2. "Profiles"
- 3. Open "Options".
- 4. "Display user list at startup"

## **Settings**

#### **General information**

Depending on the equipment and countryspecific variant of your vehicle, different opening and closing settings are available.

These settings are saved in the active driver profile, refer to page 44.

#### **Unlocking**

#### **Doors**

- 1. "Settings"
- "Doors/key"
- 3. f Select the symbol.
- 4. Select the desired function:
  - "Driver's door only"
     Only the driver's door and the fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.
  - "All doors"
     The entire vehicle is unlocked.

#### **Tailgate**

- 1. "Settings"
- 2. "Doors/key"
- Select the symbol.
- 4. Select the desired function:
  - ▶ "Tailgate"
    The tailgate is opened.
  - "Tailgate + door(s)"
     The tailgate is opened and the doors are unlocked.

## **Confirmation signals from the vehicle**

- 1. "Settings"
- 2. "Doors/key"
- Deactivate or activate the desired confirmation signals.
  - With alarm system:
    - "Acoustic sig. lock/unlock"
    - Unlocking is signaled by one honk of the horn.
  - "Flash when lock/unlock"
     Unlocking is signaled by two flashes, locking by one.

#### **Automatic locking**

- "Settings"
- 2. "Doors/key"
- 3. Select the desired function:
  - "Lock if no door is opened"
    The vehicle locks automatically after a short period of time if no door is opened after unlocking.
  - "Lock after start driving"
     The vehicle locks automatically after you drive off.

## Adjusting the last seat, mirror, and steering wheel position

- 1. "Settings"
- 2. "Doors/key"
- "Last seat position autom."

Unlocking the vehicle adjusts the last adjusted positions for driver's seat, exterior mirrors, and steering wheel.

## **Alarm system**

#### **General information**

When the vehicle is locked, the vehicle alarm system reacts to the following changes:

- Unauthorized opening of a door, the hood or the tailgate.
- Movements in the interior.
- Changes in the vehicle tilt, e. g., during attempts at stealing a wheel or when towing the vehicle.
- Disconnected battery voltage.

The alarm system signals these changes visually and acoustically:

- Acoustic alarm.
- By switching on the hazard warning system.
- By flashing the daytime running lights.

#### Switching on and off

When you lock and unlock the vehicle with the remote control or with Comfort Access, the alarm system is switched on and off at the same time.

## Door lock with the alarm system switched on

The alarm system is triggered when the door is opened, if the vehicle has been unlocked via the door lock.

Switching off the alarm, refer to page 48.

## Tailgate with the alarm system switched on

The tailgate can be opened even when the alarm system is switched on.

After the tailgate is closed, it is locked and monitored again provided the doors are locked. The hazard warning system flashes once.

#### Panic mode


You can trigger the alarm system if you find yourself in a dangerous situation.



Press button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

## Indicator lamp on the interior mirror



The indicator lamp flashes briefly every 2 seconds:

The alarm system is switched on.

Indicator lamp flashes for approx. 10 seconds, then it flashes briefly every 2 seconds:

Interior motion sensor and tilt alarm sensor are not active, as doors, hood, or tailgate are not correctly closed. Correctly closed access points are secured.

When the still open access points are closed, interior motion sensor and tilt alarm sensor will be switched on.

- The indicator lamp goes out after unlocking:
  - The vehicle has not been tampered with.
- ➤ The indicator lamp flashes after unlocking until the engine ignition is switched on, but no longer than approx. 5 minutes:

An alarm has been triggered.

#### Tilt alarm sensor

The tilt of the vehicle is monitored.

The alarm system responds in situations such as attempts to steal a wheel or when the vehicle is towed.

#### Interior motion sensor

The windows and the glass sunroof must be closed for the system to function properly.

## **Avoiding unintentional alarms**

#### General information

The tilt alarm sensor and interior motion sensor can trigger an alarm, although no unauthorized action occurred.

Possible situations for an unwanted alarm:

- In automatic vehicle washes.
- In duplex garages.
- During transport on trains carrying vehicles, at sea or on a trailer.
- With animals in the vehicle.

The tilt alarm sensor and the interior motion sensor can be switched off in such situations.

## Switching off the tilt alarm sensor and interior motion sensor

Press the remote control button again within 10 seconds as soon as the vehicle is locked.

The indicator lamp lights up for approx. 2 seconds and then continues to flash.

The tilt alarm sensor and interior motion sensor are turned off until the vehicle is locked again.

#### Switching off the alarm

- Unlock the vehicle with the remote control or switch on the ignition, if needed through emergency detection of remote control, refer to page 37.
- With Comfort Access:

If you are carrying the remote control on your person, grasp the door handle on the driver's or front passenger door completely.

## **Power windows**

## Safety information

WARNING

When operating the windows, body parts and objects can be jammed. There is a risk of injury or risk of property damage. Make sure that the area of movement of the windows is clear during opening and closing.

**№** WARNING

Unattended children or animals can cause the vehicle to move and endanger themselves and traffic, e.g., due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.

- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the remote control with you when exiting and lock the vehicle. ◀

#### **Overview**





Power windows



Safety switch

## **Opening**

Press the button to the resistance point.

The window opens while the switch is held.

Press the switch beyond the resistance point.

The window opens automatically. Pressing the switch again stops the motion.

Convenient opening via the remote control, refer to page 35.

## Closing

Pull the switch to the resistance point.

The window closes while the switch is held

Pull the switch beyond the resistance point.

The window closes automatically. Pulling again stops the motion.

Closing by means of Comfort Access, refer to page 39.

#### **Pinch protection system**

#### **General information**

If closing force exceeds a specific threshold as a window closes, closing is interrupted.

The window reopens slightly.

## **Safety information**

WARNING

Accessories on the windows such as antennas can impact jam protection. There is a risk of injury. Do not install accessories in the area of movement of the windows.

## Closing without the pinch protection system

In case of danger from the outside or if ice might prevent normal closing, proceed as follows:

1. Pull the switch past the resistance point and hold it there.

The pinch protection is limited and the window reopens slightly if the closing force exceeds a certain threshold.

2. Pull the switch past the resistance point again within approx. 4 seconds and hold it there.

The window closes without jam protection.

## Safety switch

#### **General information**

The safety switch in the driver's door can be used to prevent children, e.g., from opening and closing the rear windows using the switches in the rear.

If an accident of a certain severity occurs, the safety function is switched off automatically.

#### Switching on and off

Press button.

The LED lights up if the safety function is switched on.

## Roller sunblinds

#### **General information**

If you are no longer able to move the roller sunblind for the rear window after having activated it a number of times in a row, the system is blocked for a limited time to prevent overheating. Let the system cool.

The roller sunblind for the rear window cannot be moved at low interior temperatures.

#### **Driver's door controls**



#### Roller sunblind for rear window



Press button.

## Roller sunblinds for the rear side windows

Pull out the roller sunblind at the loop and hook it onto the bracket.

WARNING

With closed roller sunblinds and open windows, the roller sunblinds can be loaded heavily while driving due to the wind. The roller sunblinds can be damaged and compromise the passengers. There is risk of injuries. Do not open the windows while driving if the roller sunblinds are closed.

## Glass sunroof, electric

#### General information

The glass sunroof and the sliding visor can be operated together or separately using the same switch.

The glass sunroof is operational when the ignition is switched on.

## **Safety information**

WARNING

Body parts can be jammed when operating the glass sunroof. There is a risk of injury. Make sure that the area of movement of the glass sunroof is clear during opening and closing.

**★** WARNING

Unattended children or animals can cause the vehicle to move and endanger themselves and traffic, e.g., due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the remote control with you when exiting and lock the vehicle. ◀

#### **Overview**



## Tilting up and closing the tilted glass sunroof



Push switch briefly upward.

- The closed glass sunroof is tilted and the sliding visor opens slightly.
- The opened glass sunroof closes until it is in its tilted position. The sliding visor does not move.
- The tilted glass sunroof is closed. The sliding visor does not move.

## Opening/closing the glass sunroof and sliding visor separately



- Press the switch in the desired direction to the resistance point and hold it there.
  - The sliding visor opens, as long as the switch is held down. If the sliding visor is already fully open, the glass sunroof opens.

The glass sunroof closes as long as the switch is held down. If the glass sunroof is already closed or in the tilted

- position, the sliding visor closes.
- Press the switch in the desired direction past the resistance point.

The sliding visor opens automatically. If the sliding visor is already fully open, the glass sunroof opens automatically.

The glass sunroof closes automatically. If the glass sunroof is already closed or in the tilted position, the sliding visor closes automatically.

Pressing the switch upward stops the motion.

## Opening/closing the glass sunroof and sliding visor together



Briefly press the switch twice in succession in the desired direction past the resistance point.

The glass sunroof and sliding visor move together. Pressing the

switch upward stops the motion.

Convenient opening via the remote control, refer to page 35.

Closing by means of Comfort Access, refer to page 39.

## **Comfort position**

If the glass sunroof is not completely opened automatically, the comfort position has been attained. In this position the wind noises in the interior are the least.

If desired, continue the movement by pressing the switch.

## Pinch protection system

#### **General information**

If the closing force when closing the glass sunroof exceeds a certain value, the closing movement is stopped, beginning at approximately the middle of the opening in the roof, or from the tilted position during closing. The glass sunroof reopens slightly.

## Closing from the open position without pinch protection

If there is an external danger, proceed as follows:



- Press the switch forward beyond the resistance point and hold.
  - The pinch protection is limited and the glass sunroof reopens slightly if the closing force exceeds a certain threshold.
- Press the switch forward again beyond the resistance point and hold until the glass sunroof closes without jam protection. Make sure that the closing area is clear.

## Closing from the raised position without pinch protection



If there is an external danger, push the switch forward past the resistance point and hold it.

The glass sunroof closes without jam protection.

## Initializing after a power interruption

#### **General information**

After a power failure during the opening or closing process, the glass sunroof can only be operated to a limited extent.

The system can be initialized when the vehicle is stationary and the engine is running.

During the initialization, the glass sunroof closes without jam protection.

Make sure that the closing area is clear.

#### Initializing the system



Press the switch up and hold it until the initialization is complete:

Initialization begins within 15 seconds and is completed

when the glass sunroof and sliding visor are completely closed.

## **Settings**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## Sitting safely

The ideal seating position meeting the needs of the occupants can make a vital contribution to relaxed, fatigue-free driving.

The seating position plays an important role in an accident in combination with:

- Safety belts, refer to page 57.
- Head restraints, refer to page 59.
- Airbaas.

## **Seats**

# Safety information WARNING

Seat adjustments while driving can lead to unexpected movements of the seat. Vehicle control could be lost. There is a risk of an accident. Only adjust the seat on the driver's side when the vehicle is stationary.

WARNING

With a backrest inclined too far to the rear, the protective effect of the safety belt cannot be ensured anymore. There is a risk of sliding under the safety belt in an accident. There is a risk of injuries or danger to life. Adjust the seat prior to starting the trip. Adjust


the backrest so that it is in the most upright position as possible and do not adjust again while driving. ◀

**WARNING** 

There is a risk of jamming when moving the seats. There is a risk of injury or risk of property damage. Make sure that the area of movement of the seat is clear prior to any adjustment.◀

## Semi-electrically adjustable seats

#### **Overview**



- Forward/backward
- 2 Thigh support
- 3 Height, tilt
- 4 Backrest
- 5 Lumbar support

#### Seat tilt



Move switch up or down.

#### Forward/backward



Pull the lever and slide the seat in the desired direction.

After releasing the lever, move the seat forward or back slightly making sure it engages properly.

## Height



Push switch up or down.


#### **Backrest tilt**



Move switch forward or backward.

## **Electrically adjustable seats**

#### **Overview**



- 1 Thigh support
- 2 Forward/back, height, tilt
- 3 Shoulder support
- 4 Backrest width
- 5 Lumbar support
- 6 Backrest, head restraint

#### **General information**


The seat setting for the driver's seat is stored for the profile currently used. When the vehicle is unlocked via the remote control, the position is automatically retrieved if the Function is activated for this purpose.

#### Forward/backward



Push switch forward or backward.

## Height



Push switch up or down.

#### Seat tilt



Move switch up or down.


#### **Backrest tilt**



Move switch forward or backward.

## **Thigh support**

#### **Multifunctional seat**



Push switch forward or backward.

## **Lumbar support**

The curvature of the seat backrest can be adjusted in a way that it supports the lumbar region of the spine. The lower back and the spine are supported for upright posture.



- Press the front/rear section of the switch:
  - The curvature is increased/ decreased.
- Press the upper/lower section of the switch:
  - The curvature is shifted up/down.

#### **Backrest width**

To adjust the lateral support, the width of the backrest can be changed using the side wings.



Press button on the corresponding side

#### **Shoulder support**



The shoulder support supports the back in the shoulder area:

- Results in a relaxed seating position.
- Reduces strain on the shoulder muscles.

Press button on the corresponding side.

#### **Active seat**

#### The concept

Active adjustment of the seat cushion's contours reduces muscular tension and fatigue to help prevent lower back pain.

#### Overview





Press button. The LED lights up.

### Front seat heating

#### **Overview**





Seat heating

#### Switching on



Press button once for each temperature level.

The maximum temperature is reached when three LEDs are lit.

If the trip is continued within approx. 15 minutes after a stop, seat heating is activated automatically with the temperature selected last.

When ECO PRO is activated, the heater output is reduced

## **Switching off**



Press and hold the button, until the LEDs go out.

## **Temperature distribution**

The heating action in the seat cushion and backrest can be distributed in different ways.

About iDrive:

- 1. "Climate"
- 2. "Front seat heating"

- 3. Select desired seat.
- Turn the Controller to set the temperature distribution.

#### Rear seat heating

#### **Overview**





Seat heating

#### **Switching on**



Press button once for each temperature level.

The maximum temperature is reached when three LEDs are lit.

If the trip is continued within approx. 15 minutes after a stop, seat heating is activated automatically with the temperature selected last.

When ECO PRO is activated, the heater output is reduced.

## **Switching off**



Press and hold the button, until the LEDs go out.

## **Active seat ventilation, front**

## The concept

The seat cushion and backrest surfaces are cooled by means of integrated fans.

The ventilation cools the seat, e.g., if the vehicle interior is overheated or for continuous cooling at high temperatures.

#### Overview





Active seat ventilation

#### Switching on



Press button once for each ventilation level

The highest level is active when three LEDs are lit.

After a short time, the system automatically moves down one level in order to prevent excessive cooling.

## Switching off



Press and hold the button, until the LEDs go out.

## Safety belts

## **Number of safety belts**

The vehicle is fitted with five safety belts to ensure occupant safety. However, they can only offer protection when adjusted correctly.

The two outer safety belt buckles, integrated into the rear seat, are for passengers sitting on the left and right.

The center rear safety belt buckle is solely intended for the center passenger.

#### General information

Always make sure that safety belts are being worn by all occupants before driving off. Al-

though airbags enhance safety by providing added protection, they are not a substitute for safety belts.

Slowly guide the safety belt out of the holder when fastening it.

The upper shoulder strap's anchorage point will be correct for adult seat occupants of every build if the seat is correctly adjusted.

# Safety information WARNING

WARNING

If the safety belt is used by more than one person, the protective effect of the safety belt cannot be ensured anymore. There is a risk of injuries or danger to life. Do not allow more than one person to wear a single safety belt. Infants and children are not allowed on an occupant's lap, but must be transported and respectively secured in designated child restraint systems.


The protective effect of the safety belts can be limited or lost when safety belts are fastened incorrectly. An incorrectly fastened safety belt can cause additional injuries, e.g., in the event of an accident or during braking and evasive maneuvers. There is a risk of injuries or danger to life. Make sure that all occupants are wearing safety belts correctly.

## **Correct use of safety belts**

- Wear the safety belt twist-free and as tight to your body as possible over your lap and shoulders.
- Wear the safety belt deep on your hips over your lap. The safety belt may not press on your stomach.
- Do not wear the safety belt on your throat, rub it on sharp edges, guide it or jam it in across hard or fragile objects.
- Avoid thick clothing.

Re-tighten the safety belt frequently upward around your upper body.

### **Buckling the safety belt**



Make sure you hear the latch plate engage in the belt buckle.

## Tensioning the safety belt automatically

When the safety belt is buckled, the belt strap is automatically tightened once after the vehicle drove off.

## Unbuckling the safety belt

- 1. Hold the safety belt firmly.
- 2. Press the red button in the belt buckle.
- Guide the safety belt back into its roll-up mechanism.

## Safety belt reminder for driver's and passenger's seat



The indicator lamp lights up and a signal sounds. Make sure that the safety belts are positioned correctly. The

safety belt reminder is active at speeds above approx. 6 mph/10 km/h. It can also be activated if objects are placed on the front passenger seat.

## Safety mode

In critical situations, for example during an emergency stop, the front safety belts tighten automatically.

If the situation passes without an accident occurring, the belt tension relaxes.

If the belt tension does not loosen automatically, stop the vehicle and unbuckle the safety belt using the red button in the buckle. Fasten the safety belt before continuing on your trip.

### Damage to safety belts

WARNING

The protective effect of the safety belts may not be fully functional or fail in the following situations:

- Safety belts are damaged, soiled or changed in any other way.
- Safety belt buckle is damaged or heavily soiled.
- Belt tensioners or belt retractors were modified.

Safety belts can be imperceptibly damaged in the event of an accident. There is a risk of injuries or danger to life. Do not modify safety belts, safety belt buckles, belt tensioners, belt retractors or belt anchors and keep them clean. Have the safety belts checked after an accident at the dealer's service center or another qualified service center or repair shop. ◀

## Front head restraints

## **Safety information**

WARNING

A missing protective effect due to removed or not correctly adjusted head restraints can cause injuries in the head and neck area. There is a risk of injury. Install head restraints on occupied seats prior to driving and make sure that the center of the head restraint supports the back of the head at eye level.

### WARNING

Body parts can be jammed when moving the head restraint. There is a risk of injury.

Make sure that the area of movement is clear when moving the head restraint.

## WARNING

Objects on the head restraint reduce the protective effect in the head and neck area. There is a risk of injury.

- Do not use seat or head restraint covers.
- Do not hang objects, e.g., clothes hangers, directly on the head restraint.
- Only use accessories that have been determined to be safe for attachment to a head restraint.
- Do not use any accessories, e.g., pillows, while driving. ◀

## **Correctly adjusted head restraint**

#### **General information**

A correctly adjusted head restraint reduces the risk of injury to cervical vertebrae in the event of an accident.

## Height

Adjust the head restraint so that its center is approximately at eye level.

#### **Distance**


Adjust the distance so that the head restraint is as close as possible to the back of the head.

#### Active head restraint

In the event of a rear-end collision with a certain severity, the active head restraint automatically reduces the distance from the head.


In the event of wear and tear due to an accident, or if otherwise damaged, have the active head restraint checked and if necessary replaced

## Adjusting the height: manual head restraints



- To raise: push head restraint upwards.
- To lower: press button, arrow 1, and push head restraint down.

## Adjusting the height: electrical head restraints



Push switch up or down.

## Distance to the back of the head: manual head restraints



- Forward: pull head restraint forwards.
- Back: press the button and push the head restraint toward the rear.

## Distance to the back of the head: electrical head restraints

The head restraint is automatically repositioned when the shoulder support is adjusted.

### Adjusting the side extensions



Fold the side extensions on the head restraint forward for increased lateral support in the resting position.

## Removing

The head restraints cannot be removed.

## Rear head restraints

## Safety information

WARNING

A missing protective effect due to removed or not correctly adjusted head restraints can cause injuries in the head and neck area. There is a risk of injury. Install head restraints on occupied seats prior to driving and make sure that the center of the head restraint supports the back of the head at eye level.

WARNING

Body parts can be jammed when moving the head restraint. There is a risk of injury.

Make sure that the area of movement is clear when moving the head restraint.

#### WARNING

Objects on the head restraint reduce the protective effect in the head and neck area. There is a risk of injury.

- Do not use seat or head restraint covers.
- Do not hang objects, e.g., clothes hangers, directly on the head restraint.
- Only use accessories that have been determined to be safe for attachment to a head restraint.
- Do not use any accessories, e.g., pillows, while driving. ◀

## **Correctly adjusted head restraint**

#### **General information**

A correctly adjusted head restraint reduces the risk of injury to cervical vertebrae in the event of an accident.


### Height

Adjust the head restraint so that its center is approximately at eye level.

#### **Distance**


Adjust the distance so that the head restraint is as close as possible to the back of the head.

## Adjusting the height



- To raise: push head restraint upwards.
- ▶ To lower: press button, arrow 1, and push head restraint down.


### **Folding forward**



Press button, arrow 1, and fold the head restraint forward.

### Removing

Only remove the head restraint if no one will be sitting in the seat in question.



- Raise the head restraint up against the resistance.
- Press button, arrow 1, and pull the head restraint out completely.

# Seat, mirror, and steering wheel memory

### Concept

Two driver's seat and exterior mirror positions can be stored per profile and called up. Settings for the backrest width and lumbar support are not stored in memory.

## **Safety information**

WARNING

Using the memory function while driving can lead to unexpected seat or steering wheel movements. Vehicle control could be lost. There is a risk of an accident. Only retrieve the

There is a risk of an accident. Only retrieve the memory function when the vehicle is stationary. ◀

#### WARNING

There is a risk of jamming when moving the seats. There is a risk of injury or risk of property damage. Make sure that the area of movement of the seat is clear prior to any adjustment.◄

#### Overview

#### **Front**



## **Storing**

- 1. Switch on the ignition.
- 2. Set the desired position.
- 3. Press button. The LED in the button lights up.
- 4. Press selected button 1 or 2 while the LED is lit. The LED goes out.



Button was pressed inadvertently: Press button again.

The LED goes out.

#### **Calling up settings**

The stored position is called up automatically.

Press selected button 1 or 2.

The procedure stops when a switch for setting the seat or one of the memory buttons is pressed.

While driving, the seat position adjustment on the driver's side is interrupted after a short time.

## Calling up of a seat position deactivated

After a brief period, calling up stored seat positions is deactivated to save battery power.

To reactivate calling up of a seat position:

- Open or close the door or tailgate.
- Press a button on the remote control.
- Press the Start/Stop button.

### **Mirrors**

#### **Exterior mirrors**

#### **General information**

The mirror on the passenger side is more curved than the driver's side mirror.

Depending on the vehicle equipment, the mirror setting is stored for the profile currently used. When the vehicle is unlocked via the remote control, the position is automatically retrieved if this function is active.

## **Safety information**

WARNING

Objects reflected in the mirror are closer than they appear. The distance to the traffic behind could be incorrectly estimated, e.g., while changing lanes. There is a risk of an accident. Estimate the distance to the traffic behind by looking over your shoulder.

#### **Overview**



- 1 Settings 63
- 2 Left/right, Automatic Curb Monitor
- 3 Folding in and out 63

#### Selecting a mirror



To change over to the other mirror: Slide the switch.

### **Adjusting electrically**



Press button.

The mirror movement follows the button movement.

## **Saving positions**

The current exterior mirror position can be stored via the seat, mirror, and steering wheel memory.

## **Adjusting manually**

In case of electrical malfunction press edges of mirror.

#### **Automatic Curb Monitor**

#### Concept

If reverse gear is engaged, the mirror glass on the front passenger side is tilted downward. This improves your view of the curb and other low-lying obstacles when parking, e.g.

#### Activating

- 1. Slide the switch to the driver's side mirror position.
- 2. Engage selector lever position R.

#### **Deactivating**

Slide the switch to the passenger side mirror position.

#### Folding in and out

A

NOTE

Depending on the vehicle width, the vehicle can be damaged in vehicle washes. There is a risk of property damage. Before washing, fold in the mirrors by hand or with the button.



Press button.

Possible at speeds up to approx. 15 mph/20 km/h.

Fold the mirrors in and out is advantageous in the following situations:

- In vehicle washes.
- On narrow roads.
- For folding mirrors back out that were folded away manually.

Mirrors that were folded in are folded out automatically at a speed of approx. 25 mph/40 km/h.

## **Automatic heating**


Both exterior mirrors are automatically heated whenever the engine is running.

## **Automatic dimming feature**

The exterior mirror on the driver's side is automatically dimmed. Photocells are used to control the Interior mirror.

## Interior mirror, manually dimmable


#### **Turn knob**



Turn the knob to reduce the blinding effect by the interior mirror.

## Interior mirror, automatic dimming feature

#### Overview



Photocells are used for control:

- In the mirror glass.
- On the back of the mirror.

### **Functional requirements**

- Keep the photocells clean.
- Do not cover the area between the inside rearview mirror and the windshield.


## Steering wheel

#### **Safety information**

WARNING

Steering wheel adjustments while driving can lead to unexpected steering wheel movements. Vehicle control could be lost. There is a risk of an accident. Adjust the steering wheel while the vehicle is stationary only.


#### Manual steering wheel adjustment



- Fold the lever down.
- Move the steering wheel to the preferred height and angle to suit your seating position.
- Fold the lever back.

## Power steering wheel adjustment

## **Settings**



Press the switch to move the steering wheel to the preferred height and angle to suit your seating position.

## Storing the position

Seat, mirror, and steering wheel memory, refer to page 61.

## **Heated steering wheel**

#### **Overview**





Heated steering wheel

## Switching on/off



Press button.

- ▷ On: the LED lights up.
- ▶ Off: the LED goes out.

If the trip is resumed within approx. 15 min after an interim stop, steering wheel heating is automatically activated again.

## **Transporting children safely**

## Vehicle features and options

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# The right place for children Safety information

WARNING

Unattended children or animals can cause the vehicle to move and endanger themselves and traffic, e.g., due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the remote control with you when exiting and lock the vehicle. ◀

## Children should always be in the rear

#### **General information**

Accident research shows that the safest place for children is in the rear seat.

Only transport children younger than 13 years of age or shorter than 5 ft, 150 cm in the rear in suitable child restraint systems provided in accordance with the age, weight and size of the child. Children 13 years of age or older must wear a safety belt as soon as a suitable child restraint system can no longer be used due to their age, weight and size.

#### **Safety information**

WARNING

Children shorter than 5 ft, 150 cm cannot correctly fasten the safety belt without suitable additional restraint systems. The protective effect of the safety belts can be limited or lost when safety belts are fastened incorrectly. An incorrectly fastened safety belt can cause additional injuries, e.g., in the event of an accident or during braking and evasive maneuvers. There is a risk of injuries or danger to life. Secure children shorter than 5 ft, 150 cm using suitable restraint systems.

## Children on the front passenger seat

Should it ever be necessary to use a child restraint system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated. Automatic deactivation of front-seat passenger airbags, refer to page 115.

## **Safety information**

WARNING

Active front-seat passenger airbags can injure a child in a child restraint system when the airbags are activated. There is a risk of injury. Make sure that the front-seat passenger airbags are deactivated and that the PASSENGER AIRBAG OFF indicator lamp lights up.

#### WARNING

The stability of the child restraint system is limited or compromised with incorrect seat adjustment or improper installation of the child seat. There is a risk of injuries or danger to life. Make sure that the child restraint system fits securely against the backrest. If possible, adjust the backrest tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged. If possible, adjust the height of the head restraints or remove them.

# Installing child restraint systems

# Safety information WARNING

The stability of the child restraint system is limited or compromised with incorrect seat adjustment or improper installation of the child seat. There is a risk of injuries or danger to life. Make sure that the child restraint system fits securely against the backrest. If possible, adjust the backrest tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged. If possible, adjust the height of the head restraints or remove them.

## On the front passenger seat

## **Deactivating airbags**

WARNING
Active front-seat passenger airbags can injure a child in a child restraint system when the airbags are activated. There is a risk of injury. Make sure that the front-seat passenger airbags are deactivated and that the PASSENGER AIRBAG OFF indicator lamp lights up.

After installing a child restraint system in the front passenger seat, make sure that the front,

knee and side airbags on the front passenger side are deactivated.

Deactivate the front-seat passenger airbags automatically, refer to page 115.

#### **Seat position and height**

Before installing a child restraint system, move the front passenger seat as far back as possible and bring it possibly up to medium height to obtain the best possible position for the belt and to offer optimal protection in the event of an accident.

If the upper anchorage of the safety belt is located in front of the belt guide of the child seat, move the passenger seat carefully forward until the best possible belt guide position is reached.

#### Child seat security



The rear safety belts and the front passenger safety belt can be permanently locked to fasten child restraint systems.

## Locking the safety belt

- 1. Pull out the belt strap completely.
- Secure the child restraint system with the safety belt.
- Allow the belt strap to be pulled in and pull it tight against the child restraint system. The safety belt is locked.

## Unlocking the safety belt

- 1. Unbuckle the belt buckle.
- Remove the child restraint system.

3. Allow the belt strap to be pulled in completely.

## LATCH child restraint fixing system

#### General information

LATCH: Lower Anchors and Tether for Children.

Pay attention to the operating and safety information of the child restraint system manufacturer when installing and using LATCH child restraint fixing system.

#### Mounts for the lower LATCH anchors


The lower anchors may be used to attach the CRS to the vehicle seat up to a combined child and CRS weight of 65 lb/30 kg when the child is restrained by the internal harnesses.

## **Safety information** WARNING

If the LATCH child restraint fixing systems are not correctly engaged, the protective effect of the LATCH child restraint fixing system can be limited. There is a risk of injuries or danger to life. Make sure that the lower anchors are securely engaged and that the LATCH child restraint fixing system fits securely against the backrest. ◄

#### **Position**





install a child restraint system in the center is not recommended. For the center position. use the vehicle seat helt instead.

### Before installing LATCH child restraint fixing systems

Pull the safety belt away from the area of the child restraint system.

## Assembly of LATCH child restraint fixing systems

- 1. Install child restraint system, see manufacturer's information.
- 2. Ensure that both LATCH anchors are properly connected.

## Child restraint system with a tether strap

## **Mounting points**



The respective symbol shows the anchor for the upper retaining strap. Seats with an upper top tether are

marked with this symbol. It can be found on the rear seat backrest or the rear window shelf.


## Safety information

The mounting points for the upper retaining straps of child restraint systems are only provided for these retaining straps. When other objects are mounted, the anchors can be damaged. There is a risk of property damage. Only mount child restraint systems to the upper retaining straps. ◀

## Routing the retaining strap

WARNING

If the upper retaining strap is incorrectly used for the child restraint system, the protective effect can be reduced. There is a risk of injury. Make sure that the upper retaining strap is not guided across sharp edges and without twisting to the upper retaining strap. ◄




- 1 Direction of travel
- 2 Head restraint
- 3 Hook for upper retaining strap
- 4 Mounting point
- 5 Rear window shelf
- 6 Seat backrest
- 7 Upper retaining strap

## Attaching the upper retaining strap to the mounting point

- 1. Remove the mounting point cover.
- 2. Raise the head restraint. Do not change the middle head restraint.
- 3. Guide the upper retaining strap between the supports of the head restraint.
  - Guide it over the head restraint of the middle seat.
- 4. Attach the hook of the retaining strap to the anchor.
- 5. Tighten the retaining strap by pulling it down.
- 6. Lower and lock head restraints as needed.

# Locking the doors and windows in the rear

#### **Rear doors**



Push the locking lever on the rear doors down.

The door can now be opened from the outside only.

#### Safety switch for the rear

Press button on the driver's door.
The LED lights up if the safety function is switched on.

This locks various functions so that they cannot be operated from the rear.

## **Driving**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## **Start/Stop button**

### Concept



Pressing the Start/Stop button switches the ignition on or off and starts the engine.

Steptronic transmission: the engine starts with the brake pedal

pressed when you press the Start/Stop button.

Manual transmission: the engine starts with the clutch pedal pressed when the Start/Stop button is pressed.

## **Ignition on**

Steptronic transmission: press the Start/Stop button, and do not press on the brake pedal at the same time.

Manual transmission: press the Start/Stop button without stepping on the clutch pedal.

All vehicle systems are ready for operation.

Most of the indicator and warning lights in the instrument cluster light up for a varied length of time.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.

#### **Ignition off**

Steptronic transmission: press the Start/Stop button again without stepping on the brake.

Manual transmission: press the Start/Stop button again without stepping on the clutch pedal.

All indicator lights in the instrument cluster go out.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.

#### Safety measures

When switching off the ignition, the selector lever position P is selected automatically if the selector lever position D or R is selected.

The ignition is switched off automatically in the following situations while the vehicle is stationary and the engine is off:

- When locking the vehicle, and when the low beams are activated.
- Shortly before the battery is discharged completely, so that the engine can still be started.
- When opening or closing the driver door, if the driver's safety belt is unbuckled and the low beams are switched off.
- While the driver's safety belt is unbuckled with driver's door open and low beams off.

The low beams switch to parking lights after approx. 15 minutes of no use.

## Radio ready state

Activate radio-ready state: when the engine is running: press the Start/Stop button.

Some electronic systems/power consumers remain ready for operation.

The radio-ready state is switched off automatically in the following situations:

After approx. 8 minutes.

- When the vehicle is locked using the central locking system.
- Shortly before the battery is discharged completely, so that the engine can still be started.

The radio-ready state remains active if, e.g., the ignition is automatically switched off for the following reasons:

- Opening or closing the driver's door.
- Unfastening of the driver's safety belt.
- When automatically switching from low beams to parking lights.

If the engine is switched off and the ignition is switched on, the system automatically switches to the radio-ready state if the lights are turned off or, if correspondingly equipped, the daytime running lights are activated.

## Starting the engine

## **Safety information**

DANGER

If the exhaust pipe is blocked or ventilation is insufficient, harmful exhaust gases can enter into the vehicle. The exhaust gases contain carbon monoxide, an odorless and colorless but highly toxic gas. In enclosed areas, exhaust gases can also accumulate outside of the vehicle. There is danger to life. Keep the exhaust pipe free and ensure sufficient ventilation.

WARNING

An unsecured vehicle can begin to move and possibly roll away. There is a risk of an accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, observe the following:

Set the parking brake.

- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, e.g., with a wheel chock. ◄

**№** NOTE

In the case of repeated starting attempts or repeated starting in quick succession, the fuel is not burned or is inadequately burned. The catalytic converter can overheat. There is a risk of property damage. Avoid repeated starting in quick succession.

#### **Diesel engine**

If the engine is cold and temperatures are below approx. 32 °F/0 °C, the start process may be delayed somewhat due to automatic preheating.



A Check Control message with yellow indicator lamp is displayed.

## **Steptronic transmission**

## Starting the engine

- Depress the brake pedal.
- 2. Press the Start/Stop button.

The ignition is activated automatically for a certain time and is stopped as soon as the engine starts.

#### Manual transmission

### Starting the engine

- Depress the brake pedal.
- Press on the clutch pedal and shift to neutral.
- Press the Start/Stop button.

The ignition is activated automatically for a certain time and is stopped as soon as the enqine starts.

## **Engine stop**

# Safety information WARNING

Unattended children or animals can cause the vehicle to move and endanger themselves and traffic, e.g., due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the remote control with you when exiting and lock the vehicle. ◀

WARNING

An unsecured vehicle can begin to move and possibly roll away. There is a risk of an accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, observe the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- ▷ On uphill grades or on a downhill slope, also secure the vehicle, e.g., with a wheel chock.

## Before driving into a vehicle wash

So that the vehicle can roll into a vehicle wash, observe instructions for going into an automatic vehicle wash, refer to page 266.

## **Steptronic transmission**

#### Switching off the engine

- Engage selector lever position P with the vehicle stopped.
- Press the Start/Stop button.
   The engine is switched off.
   The radio-ready state is switched on.
- 3. Set the parking brake.

#### Manual transmission

#### Switching off the engine

- With the vehicle at a standstill, press the Start/Stop button.
- 2. Shift into first gear or reverse.
- 3. Set the parking brake.

## **Auto Start/Stop function**

#### Concept

The Auto Start/Stop function helps save fuel. The system switches off the engine during a stop, e.g., in traffic congestion or at traffic lights. The ignition remains switched on. The engine starts again automatically for driving off.

#### General information

After every start of the engine using the Start/ Stop button, the Auto Start/Stop function is in the last selected state. When the Auto Start/ Stop function is active, it is available when the vehicle is traveling faster than about 3 mph/5 km/h.

## Engine stop

The engine is switched off automatically during a stop under the following conditions:

Steptronic transmission:

- The selector lever is in selector lever position D.
- The brake pedal remains pressed while the vehicle is stationary or the vehicle is held by Automatic Hold.
- The driver's safety belt is buckled or the driver's door is closed.

#### Manual transmission:

- Neutral is engaged and the clutch pedal is not pressed.
- The driver's safety belt is buckled or the driver's door is closed.

The air flow from the air conditioner is reduced when the engine is switched off.

#### Displays in the instrument cluster



The display indicates that the Auto Start/Stop function is ready for an Automatic engine start.



The display indicates that the conditions for an automatic engine stop have not been met.

#### **Functional limitations**

The engine is not switched off automatically in the following situations:

- External temperature too low.
- The external temperature is high and automatic climate control is running.
- The vehicle's interior has not yet been heated or cooled to the required level.
- The engine is not yet at operating temperature.
- The wheels are at a sharp angle or the steering wheel is being turned.
- After driving in reverse.

- Fogging of the windows when the automatic climate control is switched on.
- Vehicle battery is heavily discharged.
- At higher elevations.
- ▶ The engine compartment lid is unlocked.
- HDC Hill Descent Control is activated.
- The parking assistant is activated.
- Stop-and-go traffic.
- Selector lever in selector lever position N, M/S or R.
- Use of fuel with high ethanol content.

### Starting the engine

The engine starts automatically under the following conditions:

- Steptronic transmission: by releasing the brake pedal.
  - When Automatic Hold is activated: press the accelerator pedal.
- Manual transmission: clutch pedal is pressed.

After the engine starts, accelerate as usual.

# Safety mode

After the engine switches off automatically, it will not start again automatically if any one of the following conditions are met:

- ➤ The driver's safety belt is unbuckled and the driver's door is open.
- The hood was unlocked.

Some indicator lights light up for a varied length of time.

The engine can only be started via the Start/Stop button.

#### **Functional limitations**

Even if driving off was not intended, the deactivated engine starts up automatically in the following situations:

Excessive warming of the vehicle's interior when the cooling function is switched on.

- The steering wheel is turned.
- Steptronic transmission: change from selector lever position D to R, N or M/S.
- Steptronic transmission: change from selector lever position P to N, D, R or M/S.
- The vehicle begins rolling.
- Fogging of the windows when the automatic climate control is switched on.
- Vehicle battery is heavily discharged.
- Excessive cooling of the vehicle's interior when the heating is switched on.
- Low brake vacuum pressure; this can occur, e.g., if the brake pedal is depressed a number of times in succession.

# Activating/deactivating the system manually

### **Using the button**





Press button.

 LED comes on: Auto Start/Stop function is deactivated.

The engine is started during an automatic engine stop.

The engine can only be stopped or started via the Start/Stop button.

 LED goes out: Auto Start/Stop function is activated.

# Switching off the vehicle during an automatic engine stop

During an automatic engine stop, the vehicle can be switched off permanently, e.g., when leaving it.

Steptronic transmission:

- Press the Start/Stop button. The ignition is switched off. The Auto Start/Stop function is deactivated.
  - Selector lever position P is engaged automatically.
- 2. Set the parking brake.

Manual transmission:

- Press the Start/Stop button. The ignition is switched off. The Auto Start/Stop function is deactivated.
- 2. Shift into first gear or reverse.
- 3. Set the parking brake.

Engine start as usual via Start/Stop button.

#### **Automatic deactivation**

In certain situations, the Auto Start/Stop function is deactivated automatically for safety reasons, e.g., if no driver is detected.

#### Malfunction

The Auto Start/Stop function no longer switches off the engine automatically. A Check Control message is displayed. It is possible to continue driving. Have the system checked by a dealer's service center or another qualified service center or repair shop.

# **Parking brake**

# Concept

The parking brake is used to prevent the vehicle from rolling when it is parked.

### **Safety information**

WARNING

An unsecured vehicle can begin to move and possibly roll away. There is a risk of an accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, observe the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, e.g., with a wheel chock. ◄

WARNING

Unattended children or animals can cause the vehicle to move and endanger themselves and traffic, e.g., due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the remote control with you when exiting and lock the vehicle. ◄

#### Overview





Parking brake

#### Setting



Pull the switch.

The LED lights up.



The indicator lamp lights up red. The parking brake is set.

#### While driving

To use as emergency brake while driving:

Pull the switch and hold it. The vehicle brakes hard while the switch is being pulled.



The indicator lamp lights up red, a signal sounds and the brake lights light up.

A Check Control message is displayed.

If the vehicle is slowed down to a speed of approx. 2 mph/3 km/h the parking brake is set.

#### Releasing

With the ignition switched on:



Manual transmission: Press the switch while the brake pedal is pressed.

Steptronic transmission: press the switch while the brake is pressed or selector lever position P is set.

The LED and indicator lamp go out.

The parking brake is released.

#### Automatic release in cars with Steptronic transmission

For automatic release, step on the accelerator pedal.

The LED and indicator lamp go out.

The parking brake is automatically released when you step on the accelerator under the following conditions:

Engine on.

- Drive mode engaged.
- Driver buckled in and doors closed.

# Automatic release in cars with manual transmission

Drive off as usual. The parking brake disengages when the clutch pedal is released.

The LED and indicator lamp go out.

Under the following conditions, the parking brake is automatically released:

- Engine on.
- Gear engaged.
- Driver buckled in and doors closed.
- Engine power is sufficient to drive off.

#### **Automatic Hold**

#### Concept

This system assists the driver by automatically setting and releasing the brake, such as when moving in stop-and-go traffic.

The vehicle is automatically held in place when it is stationary.

On inclines, the system prevents the vehicle from rolling backward when driving off.

#### Overview





Automatic Hold

#### **Safety information**

lack

WARNING

An unsecured vehicle can begin to move and possibly roll away. There is a risk of an accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, observe the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- ▷ On uphill grades or on a downhill slope, also secure the vehicle, e.g., with a wheel chock.

Under the following conditions, Automatic Hold is automatically deactivated and the parking brake is set:

- ▶ The engine is switched off.
- A door is opened and driver's safety belt is unbuckled while the vehicle is stationary.
- The moving vehicle is brought to a standstill using the parking brake.



The indicator lamp switches from green to red and the letters AUTO H go out.

# **Activating**

This function can be activated when the driver's door is closed, the safety belt is fastened and the engine is running.

AUTO H

Press button.

The LED and the letters AUTO H light

up.

AUTO H

The indicator lamp lights up. Automatic Hold is activated.

# **Deactivating**



Press button again.

The LED and the letters AUTO H go out.

Automatic Hold is deactivated.

If the vehicle is being held by Automatic Hold, press on the brake pedal to deactivate it.

When the parking brake is set manually, Automatic Hold is deactivated automatically.

#### **Driving**

Automatic Hold is activated: the vehicle is automatically secured against rolling after braking to a standstill.



The indicator lamp lights up green.

Step on the accelerator pedal to drive off.

The brake is released automatically.

The indicator lamp goes out.

NOTE

If the vehicle is stationary, Automatic Hold engages the parking brake. It prevents the vehicle from rolling in a vehicle wash. There is a risk of property damage. Deactivate Automatic Hold prior to entering the vehicle wash. ◀

# **Parking**

PARK

**(P)** 

The parking brake is automatically set if the engine is switched off while the vehicle is being held by Automatic Hold.

The indicator lamp changes from green to red.

The parking brake is not set if the engine is switched off while the vehicle is coasting to a halt. Automatic Hold is deactivated.

Automatic Hold remains activated during the engine stop brought about by the Auto Start/ Stop function.

#### WARNING

Unattended children or animals can cause the vehicle to move and endanger themselves and traffic, e.g., due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the remote control with you when exiting and lock the vehicle. ◄

#### Malfunction

In the event of a failure or malfunction of the parking brake, secure the vehicle against rolling using a wheel chock, e.g., when leaving it.

#### After a power failure

# Putting the parking brake into operation

- 1. Switch on the ignition.
- 2. Press the switch while stepping on the brake pedal or selector lever position P is set.

It may take several seconds for the brake to be put into operation. Any sounds associated with this are normal.



The indicator lamp in the instrument cluster goes out as soon as the parking brake is ready for operation.


# Turn signal, high beams, headlight flasher

#### **Turn signal**

#### Turn signal in exterior mirror

When driving and during operation of the turn signals or hazard warning system, do not fold in the exterior mirrors, so that the signal lights on the exterior mirror are easy to see.

#### **Using turn signals**



Press the lever beyond the resistance point.

The lever returns into its starting position after actuation.

To switch off manually, slightly tap the lever to the resistance point.

# **Triple turn signal activation**

Lightly tap the lever up or down.

The turn signal flashes three times.

The function can be activated or deactivated.

On the Control Display:

- 1. "Settings"
- 2. "Lighting"
- 3. "Triple turn signal"

Settings are stored for the profile currently used.

### Signaling briefly

Press the lever to the resistance point and hold it there for as long as you want the turn signal to flash.

#### Malfunction

Unusually rapid flashing of the indicator lamp indicates that a turn signal bulb has failed.

#### High beams, headlight flasher

Push the lever forward or pull it backward.



- ▶ High beams, arrow 1.
- ▶ High beams off/headlight flasher, arrow 2.

# Washer/wiper system

#### **General information**

Do not use the wipers if the windshield is dry, as this may damage the wiper blades or cause them to become worn more quickly.

# **Safety information**

**∧** NOTE

If the wipers are frozen to the windshield, the wiper blades can be torn off and the wiper motor can overheat when switching on. There is a risk of property damage. Defrost the windshield prior to switching the wipers on. ◀

#### **Switching on**



Tap the lever up or press it beyond the resistance point.

- Normal wiper speed: tap up once.
   The wipers switch to intermittent operation when the vehicle is stationary.
- Fast wiper speed: tap up twice or tap once beyond the resistance point.

Wipers change to normal speed when vehicle comes to standstill.

The lever automatically returns to its initial position when released.

### Switching off and brief wipe



Press the lever down.

- To switch off from fast wiper speed: press down twice.
- ➤ To switch off from normal wiper speed: press down once.
- Single wipe: press down once.

The lever automatically returns to its initial position when released.

#### Interval mode or rain sensor

#### Concept

The rain sensor automatically controls the time between wipes depending on the intensity of the rainfall.

#### **General information**


The sensor is located on the windshield, directly in front of the interior mirror. Without the rain sensor, the frequency of the wiper operation is preset.

#### **Safety information**

NOTE
If the rain sensor is activated, the wipers can accidentally start moving in vehicle washes. There is a risk of property damage.

Deactivate the rain sensor in vehicle washes. ◀

#### **Activating/deactivating**



Press button on the wiper lever.

Wiping is started.

If the vehicle is equipped with a rain sensor: LED in wiper lever lights up.

If wipers are frozen to windshield, wiper operation is deactivated.

During trip interruption with the rain sensor switched on: if the trip is resumed within approx. 15 minutes, the rain sensor is automatically activated again.

# Setting the frequency or sensitivity of the rain sensor



Turn the thumbwheel to adjust the frequency or sensitivity of the rain sensor.

Up: short interval or high sensitivity of the rain sensor.

Down: long interval or low sensitivity of the rain sensor.

# Windshield and headlamp washer system

# Safety information WARNING

NOTE

The washer fluid can freeze onto the window at low temperatures and obstruct the view. There is a risk of an accident. Only use the washer systems, if the washer fluid cannot freeze. Use antifreeze, if needed.

When the washer fluid reservoir is empty, the wash pump cannot work as intended. There is a risk of property damage. Do not use the washer system when the washer fluid reservoir is empty.

#### **Cleaning**



Pull the lever.

The system sprays washer fluid on the windshield and activates the wipers briefly.

In addition, the headlights are cleaned at regular intervals when the vehicle's lights are activated.

#### Windshield washer nozzles

The windshield washer nozzles are automatically heated while the ignition is switched on.

# Fold-away position of the wipers

# Concept

The wipers can be folded away from the windshield in the fold-away position.

#### **General information**

Important, e.g., when changing the wiper blades or when folding out under frosty conditions.

# Safety information WARNING

If the wipers start moving in the folded away state, body parts can be jammed or damage may occur to parts of the vehicle. There is a risk of injury or risk of property damage. Make sure that the vehicle is switched off when the wipers are in the folded away state and the wipers are folded in when switching on.

#### Folding away the wipers

- 1. Switch the ignition on and off again.
- With frosty conditions, make sure that the blades are not frozen to the windshield.
- Press the wiper lever up beyond the point of resistance and hold it for approx. 3 seconds, until the wipers remain in a nearly vertical position
- Lift the wiper all the way off of the windshield.



#### Folding down the wipers

After the wipers are folded back down, the wiper system must be reactivated.

- 1. Switch on the ignition.
- Push wiper lever down. Wipers return to their resting position and are ready again for operation.

# **Washer fluid**

#### **General information**

All washer nozzles are supplied from one reservoir.

Use a mixture of tap water, windshield washer concentrate, and possibly antifreeze for the windshield washer system.

Recommended minimum fill quantity: 0.2 US gal/1 liter.

### Safety information

A

WARNING

Some antifreeze agents can contain harmful substances and are flammable. There is a risk of fire and a risk of injury. Observe the instructions on the containers. Keep antifreeze away from ignition sources. Do not refill operating materials into different bottles. Store operating materials out of reach of children.

United States: The washer fluid mixture ratio is regulated by the U.S. EPA and many individual states; do not exceed the allowable washer fluid dilution ratio limits that apply. Follow the usage instructions on the washer fluid container.

Use of BMW's Windshield Washer Concentrate or the equivalent is recommended. ◀

WARNING

Washer fluid can ignite and catch fire on contact with hot engine parts. There is a risk of injury or risk of property damage. Only add washer fluid when the engine is cooled down. Next, fully close the lid of the washer fluid reservoir.

NOTE

Silicon-containing additives in the washer fluid for the water-repelling effect on the windows can lead to damage to the washing system. There is a risk of property damage. Do not add silicon-containing additives to the washer fluid.

**№** NOTE

Mixing different windshield washer concentrates or antifreeze agents can damage the washing system. There is a risk of property damage. Do not mix different windshield washer concentrates or antifreeze agents. Observe the information and mixing ratios provided on the containers.

#### **Overview**



The washer fluid reservoir is located in the engine compartment.

#### Malfunction

The use of undiluted windshield washer concentrate or alcohol-based antifreeze can lead to incorrect readings at temperatures below  $+ 5 \,^{\circ}\text{F/-} 15 \,^{\circ}\text{C}$ .

#### **Manual transmission**

# **Safety information**

WARNING

An unsecured vehicle can begin to move and possibly roll away. There is a risk of an accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, observe the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- > On uphill grades or on a downhill slope, also secure the vehicle, e.g., with a wheel chock.◄

NOTE
When shifting to a lower gear, excessive speeds can damage the engine. There is a risk of property damage. When shifting into 5th or

6th gear, press the gearshift lever to the right. ◀

#### Shifting

#### **General information**

The engine speed during a shifting operation is adjusted automatically for harmonious and dynamic gear shifting.

#### Reverse gear

Select only when the vehicle is stationary.

To overcome the resistance push the gearshift lever dynamically to the left and engage reverse gear with a forward shifting movement.

# **Steptronic transmission**

#### **Safety information**

WARNING

An unsecured vehicle can begin to move and possibly roll away. There is a risk of an accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, observe the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- > On uphill grades or on a downhill slope, also secure the vehicle, e.g., with a wheel chock. ◀

# **Selector lever positions**

#### **D** Drive

Selector lever position for normal vehicle operation. All gears for forward travel are activated automatically.

#### **R** Reverse

Select only when the vehicle is stationary.

#### N is Neutral

The vehicle may roll in selector lever position N, e.g., in vehicle washes.

#### P Park

Select only when the vehicle is stationary. The drive wheels are blocked.

Selector lever position P is engaged automatically in the following situations:

- After the engine is switched off when the vehicle is in radio-ready state, refer to page 70, or when the ignition is switched off, refer to page 70, and when selector lever position R or D is set.
- If the driver's safety belt is unbuckled, the driver's door is opened, and the brake pedal is not pressed while the vehicle is stationary and selector lever position D or R is engaged.

#### **Kickdown**

Kickdown is used to achieve maximum driving performance. Step on the accelerator pedal beyond the resistance point at the full throttle position.

# **Engaging selector lever positions**

#### General information

To prevent the vehicle from creeping after you select a gear, maintain pressure on the brake pedal until you are ready to start.

- It is not possible to shift out of selector lever position P until the engine is running and the brake is applied.
- With the vehicle stationary, depress the brake pedal before shifting out of selector lever position P or N; otherwise, the shift block will not be deactivated and the shift command will not be executed.

#### Selector lever lock

A lock prevents the inadvertent switching to selector lever position P or R or the inadvertent change from selector lever position P.



To release the lock: press button, arrow.

# Engaging selector lever position D, N, R



With the driver's safety belt fastened, tap the selector lever in the desired direction, beyond a resistance point, if needed.

After releasing the selector lever, it returns to its center position.

#### **Engaging selector lever position P**



Press P button, arrow.

# Sport program and manual mode

#### **Activating the sport program**



Press the selector lever to the left out of selector lever position D.

The engaged gear is displayed in the instrument cluster, e.g., S1.

The sport program of the transmission is activated.

# Activating the M/S manual mode

- Press the selector lever to the left out of selector lever position D.
- Push the selector lever forward or pull it backward.

Manual mode M/S becomes active and the gear is changed.

The engaged gear is displayed in the instrument cluster, e.g., M1.

If the situation requires, the Steptronic transmission continues to shift automatically.

Example: once maximum engine speed is attained, M/S manual mode is automatically upshifted as needed.

#### Switching to manual mode

- To shift down: press the selector lever forward.
- To shift up: pull the selector lever rearwards.

Gears will only be shifted at appropriate engine and road speeds, e.g., downshifting is not possible if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the currently selected gear.

# Not M550d xDrive: Steptronic Sport transmission: preventing automatic upshifting in M/S manual mode

The Steptronic Sport transmission does not automatically upshift in M/S manual mode once the maximum speed is reached, if one of the following conditions is met:

- DSC deactivated.
- TRACTION activated.
- SPORT+ activated.

In addition, there is no downshifting for kick-down.

With the respective transmission version, the lowest possible gear can be selected by simultaneously operating the kickdown and the left shift paddles. This is not possible, when switching briefly via the shift paddles from selector lever position D to manual mode M/S.

# **Ending the sport program/manual mode**

Push the selector lever to the right.

D is displayed in the instrument cluster.

#### Shift paddles



The shift paddles on the steering wheel allow you to shift gears quickly while keeping both hands on the steering wheel.

- ▶ To shift up: briefly pull right shift paddle.
- ▶ To shift down: briefly pull left shift paddle.
- With the respective transmission version, the lowest possible gear can be selected by pulling and holding the left shift paddle.

Gears will only be shifted at appropriate engine and road speeds, e.g., downshifting is not possible if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

If the shift paddles on the steering wheel are used to shift gears in automatic mode, the transmission switches to manual mode temporarily in selector lever position D and permanently in selector lever position S.

In selector lever position D, after conservative driving for a certain amount of time in manual mode or if there has been no acceleration or shifting of the shift paddles within a certain amount of time, the transmission switches back to automatic mode.

If the selector lever is still in selector lever position D, it is possible to switch into automatic mode with some transmission versions:

- Pull and hold right shift paddle.
  - Or
- In addition to the briefly pulled right shift paddle, briefly pull the left shift paddle.

#### Displays in the instrument cluster



The selector lever position is displayed, for example: P.

# Electronic unlocking of the transmission lock

#### **General information**

Electronically unlock the transmission lock to maneuver vehicle from a danger area.

Unlocking is possible, if the starter can spin the engine.

Before unlocking the transmission lock, set the parking brake to prevent the vehicle from rolling away.

#### **Engaging selector lever position N**

- 1. Press and hold down brake pedal.
- Press the Start/Stop button. The starter must audibly start.
- 3. Press the button on the selector lever, see arrow 1, and press and hold the selector lever into selector lever position N, see arrow N, until selector lever position N is displayed in the instrument cluster.

A corresponding Check Control message is displayed.



Release the selector lever.

- Release brake, as soon as the starter stops.
- Maneuver the vehicle from the danger area and secure it against moving on its own.

For additional information, see chapter Towstarting and towing.

# Steptronic Sport transmission: Launch Control

#### Concept

Launch Control enables optimum acceleration on surfaces with good traction.

#### **General information**

The use of Launch Control causes premature component wear since this function represents a very heavy load for the vehicle.

Do not use Launch Control during the break-in, refer to page 196, period.

To increase vehicle stability, activate DSC again as soon as possible.

An experienced driver may be able to achieve better acceleration values in DSC OFF mode.

#### Requirements

Launch Control is available when the engine is warmed up, that is, after uninterrupted driving of at least 6 miles/10 km.

To start with Launch Control do not steer the steering wheel.

#### Start with launch control

While the engine is running:

- Press button or select Sport+ with the Driving Dynamics Control.
  - TRACTION is displayed in the instrument cluster and the indicator lamp for DSC OFF lights up.
- 2. Engage selector lever position S.

- With the left foot, forcefully press down on the brake.
- 4. Press and hold down the accelerator pedal beyond the resistance point at the full throttle position, kickdown.
  - A flag symbol is displayed in the instrument cluster.
- 5. The starting engine speed adjusts. Within 3 seconds, release the brake.

Before using Launch Control, allow the transmission to cool down for approx. 5 minutes.


Launch Control adjusts to the surrounding conditions, e.g., wet pavement, when used again.

# **Displays**

# Vehicle features and options

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **Overview, instrument cluster**



- 1 Fuel gauge 95
- 2 Speedometer
- 3 Messages, for example, Check Control
- 4 Tachometer 95

- 5 Engine oil temperature 95
- 6 Current fuel consumption
- 7 Electronic displays 87
- 8 Reset miles 95

# **Electronic displays**

- Selection lists, refer to page 100.
- ▶ External temperature, refer to page 96.
- ▶ Auto Start/Stop function, refer to page 73.
- ▶ Onboard computer, refer to page 100.
- Date, refer to page 96.
- Energy recovery, refer to page 97.
- ▶ Transmission display, refer to page 85.
- Miles/trip miles, refer to page 95.


- Messages, e.g., Check Control, refer to page 91.
- Current fuel consumption, refer to page 96.
- Navigation display, see Owner's Manual for Navigation, Entertainment and Communication.
- ▶ Range, refer to page 96.
- Status, Driving Dynamics Control, refer to page 146.
- ▷ Service requirements, refer to page 97.
- Speed Limit Info, refer to page 98.

# **Multifunctional instrument display**

#### The concept

The instrument display is a variable display. In the event of a program change, the display rendition adapts to the respective program through the Driving Dynamics Control. The change of the display type can be deactivated via iDrive Some of the displays in the instrument display may differ from the way they are shown in this Owner's Manual.

#### **Overview**



- 1 Fuel gauge 95
- 2 Indicator/warning lights 91
- 3 Speedometer
- 4 Variable displays

- 5 Tachometer 95
  Selection lists 100
  ECO PRO displays 204
- 6 Engine oil temperature 95

#### 7 Onboard computer 100

# Switching the change of display on and off

You can set whether the instrument display automatically changes to the ECO PRO or SPORT in the display when you switch driving modes.

On the Control Display:

- 1. "Settings"
- 2. "Instrument cluster"
- 3. "ECO PRO Info"

#### 8 Reset miles 95

Or "Driving mode view"


# With Professional Navigation System: switching zoom function on/off

You can program whether the current speed is to appear enlarged in the speedometer.

On the Control Display:

- 1. "Settings"
- 2. "Instrument cluster"
- 3. "Magnifier function"

# **ECO PRO displays**




- 1 Speedometer
- 2 Variable displays: ECO PRO Tips, Deceleration assistant instructions, Driver assist system displays
- 3 Efficiency display 204
- In the ECO PRO program the instrument display switches to the ECO PRO displays. These

- 4 Transmission display
- - Gray: range

displays support a driving style that saves on fuel consumption with more prominent repre-

sentation of the efficiency display and various ECO PRO tips.

# **Sport displays**



- Speedometer
- 2 Tachometer 95
- 3 Transmission display

In the Sport and Sport+ programs the instrument display switches to the sport displays. These displays support a sporty driving style with more prominent representation of the tachometer, the transmission displays, and the vehicle speed.

# Shift lights in the instrument display

#### The concept

The shift point indicator indicates the optimum shift moment in the tachometer. Thus, with a sporty driving style, the best possible vehicle acceleration is achieved.

- 4 Shift lights, when respectively equipped
- 5 Performance display
- 6 Variable displays

#### **General information**

Steptronic Sport transmission: shift lights are shown, when the SPORT+ driving program is activated.

Manual transmission: shift lights are shown, when the SPORT or SPORT+ driving program is activated.

# **Switching on shift lights**

Steptronic Sport transmission:

- Select SPORT+ using the Driving Dynamics Control.
- Activate the M/S manual mode of the transmission.

#### Manual transmission:

- Select SPORT or SPORT+ using the Driving Dynamics Control.
- 2. Deactivate DSC if needed.

### Display in the instrument display



- Current engine speed is displayed in the tachometer.
- Arrow 1: successive yellow illuminated fields indicate an increase in the speed.
- Arrow 2: successive orange illuminated fields indicate the upcoming shift moment.
- Arrow 3: fields are illuminated in red. Do not wait any further to shift.

When the maximum possible speed is reached, the entire display flashes. When the maximum speed is exceeded, the supply of fuel is interrupted in order to protect the engine.

# **Check Control**

# **Concept**

The Check Control system monitors functions in the vehicle and notifies you of malfunctions in the monitored systems.

#### **General information**

A Check Control message is displayed as a combination of indicator or warning lights and SMS text messages in the instrument cluster and in the Head-up Display.

In addition, an acoustic signal may sound and a SMS text message may appear on the Control Display.

#### Indicator/warning lights

#### **General information**

The indicator and warning lights in the instrument cluster can light up in a variety of combinations and colors.

Several of the lights are checked for proper functioning and light up temporarily when the engine is started or the ignition is switched on.

#### **Red lights**

#### Safety belt reminder



Safety belt on the driver's side is not buckled. For some country-specific models: passenger belt is not worn or

objects are detected on the front passenger seat.

Indicator lamp flashes or is illuminated: safety belt on the driver or passenger side is not buckled. The safety belt reminder can also be activated if objects are placed on the front passenger seat.

Make sure that the safety belts are positioned correctly.

#### Airbag system



Airbag system and belt tensioner are not working.

Have the vehicle checked immediately by a dealer's service center or another qualified service center or repair shop.

#### Parking brake



The parking brake is set.

For additional information, see Releasing the parking brake, refer to page 75.

#### **Brake system**



Braking system impaired. Continue to drive moderately.



Have the vehicle checked immediately BRAKE by a dealer's service center or another qualified service center or repair shop.

#### Approach control warning



Indicator lamp illuminates: advance warning is issued, for example when there is the impending danger of a col-

lision or the distance to the vehicle ahead is too small.

Increase distance.

Indicator lamp flashes: acute warning of the imminent danger of a collision when the vehicle approaches another vehicle at a relatively high differential speed.

Intervention by braking or make an evasive maneuver.

#### **Person warning**



Symbol in the instrument cluster.

If a collision with a person detected in this way is imminent, the symbol lights

up and a signal sounds.



Symbol in the instrument display.

If a collision with a person detected in this way is imminent, the symbol lights

up and a signal sounds.

# **Orange lights**

#### **Active Cruise Control**



The number bars shows the selected distance from the vehicle driving ahead.

For additional information, refer to Active Cruise Control with Stop&Go function, ACC, refer to page 149.

#### **Vehicle detection, Active Cruise Control**



Indicator lamp illuminates: a vehicle has been detected ahead of you.

Indicator lamp flashes: the conditions are not adequate for the system to work.

The system was deactivated but applies the brakes until you actively resume control by pressing on the brake pedal or accelerator pedal.

#### Yellow lights

#### **Anti-lock Braking System ABS**



Braking force boost may not be working. Avoid abrupt braking. Take the longer braking distance into account.



ARS Have the system immediately checked by a dealer's service center or another

qualified service center or repair shop.

#### **DSC Dynamic Stability Control**



The indicator lamp flashes: DSC controls the drive and braking forces. The vehicle is stabilized. Reduce speed and

adapt driving style to the driving circumstances.

The indicator lamp lights up: DSC has malfunctioned.

Have the system checked by a dealer's service center or another qualified service center or repair shop.

For additional information, refer to Dynamic Stability Control DSC, refer to page 141.

#### **DSC Dynamic Stability Control is** deactivated or DTC Dynamic Traction Control is activated



DSC Dynamic Stability Control is deactivated or DTC Dynamic Traction Control is activated.

For additional information, refer to Dynamic Stability Control DSC, refer to page 141, and Dynamic Traction Control DTC, refer to page 142.

#### **Flat Tire Monitor FTM**



The Flat Tire Monitor signals a loss of tire inflation pressure in a tire.

Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.

For more information, see Flat Tire Monitor, refer to page 120.

#### **Tire Pressure Monitor TPM**



The indicator lamp is illuminated.

The Tire Pressure Monitor reports a low tire inflation pressure or a flat tire.

Observe the information in the Check Control message.

The indicator lamp flashes and is then illuminated continuously.

No flat tire or loss of tire inflation pressure can be detected.

- Interference caused by systems or devices with the same radio frequency: After leaving the area of the interference, the system automatically becomes active again.
- TPM was unable to complete the reset. Reset the system again.
- A wheel without TPM electronics is mounted: Have it checked by a dealer's service center or another qualified service center or repair shop as needed.
- Malfunction: have the system checked by a dealer's service center or another qualified service center or repair shop.

For more information, see Tire Pressure Monitor, refer to page 116.

#### Steering system



Steering system in some cases not working.

Have the steering system checked by a dealer's service center or another qualified service center or repair shop.

#### **Engine functions**



Engine function impaired.

Have the vehicle checked by a dealer's service center or another qualified

service center or repair shop.

For additional information, refer to On-board Diagnostics socket, refer to page 251.

#### Lane departure warning



System is switched on and under certain circumstances warns if a detected lane is left without flashing beforehand.

For additional information, refer to Lane departure warning, refer to page 134.

# **Green lights**

# Turn signal



Turn signal switched on.

Unusually rapid flashing of the indicator lamp indicates that a turn signal bulb

has failed.

For additional information, refer to Turn signal, refer to page 78.

#### Parking lights, headlight

€D Q€

Parking lights or headlights are activated.

For additional information, refer to Parking lights/low beams, headlamp control, refer to page 107.

#### **Front fog lights**



Front fog lights are activated.

For additional information, refer to Front fog lights, refer to page 110.

#### **High-beam Assistant**



High-beam Assistant is switched on.

High beams are switched on and off automatically depending on the traffic

For additional information, refer to High-beam Assistant, refer to page 110.

#### **Cruise control**



The system is switched on. It maintains the speed that was set using the control elements on the steering wheel.

#### **Automatic Hold**



Automatic Hold is activated. The vehicle is automatically held in place when it is stationary.

For more information, see Automatic Hold, refer to page 76.

### **Blue lights**

#### **High beams**



High beams are activated.

For additional information, see High beams, refer to page 78.

# **General lamps**

#### **Check Control**



At least one Check Control message is displayed or is stored.

#### SMS text messages

SMS text messages in combination with a symbol in the instrument cluster explain a Check Control message and the meaning of the indicator and warning lights.

#### Supplementary SMS text messages

Additional information, such as on the cause of an error or the required action, can be called up via Check Control.

With urgent messages the added text will be automatically displayed on the Control Display.

#### **Symbols**

Depending on the Check Control message, the following functions can be selected.

- Display additional information about the Check Control message in the Integrated Owner's Manual.
- "Service request" Contact a dealer's service center or another qualified service center or repair shop.
- ▶ M "Roadside Assistance"
  Contact Roadside Assistance.

# **Hiding Check Control messages**



Press and hold button on signal lever.

 Some Check Control messages are displayed continuously and are not cleared until the malfunction is eliminated. If several malfunctions occur at once, the messages are displayed consecutively.

- These messages can be hidden for approx. 8 seconds. After this time, they are displayed again automatically.
- Other Check Control messages are hidden automatically after approx. 20 seconds.
   They are stored and can be displayed again later.

# **Displaying stored Check Control messages**

On the Control Display:

- 1. "Vehicle info"
- 2. "Vehicle status"
- 3. 

  ∧ "Check Control"
- 4. Select the SMS text message.

#### Messages after trip completion

Special messages displayed while driving are displayed again after the ignition is switched off.

# Fuel gauge



Vehicle tilt position may cause the display to vary.

Depending on the equipment version, the arrow beside the fuel pump symbol shows which

side of the vehicle the fuel filler flap is on. Notes on refueling, refer to page 212.



The yellow indicator lamp illuminates, once the fuel reserve is reached.

# **Tachometer**

Always avoid engine speeds in the red warning field. In this range, the fuel supply is interrupted to protect the engine.

# **Engine oil temperature**



- Cold engine: the pointer is at the low temperature end.
   Drive at moderate engine and vehicle speeds.
- Normal operating temperature: the pointer is in the middle or in the left half of the temperature display.
- Hot engine: the pointer is at the high end of the temperature range. A Check Control message is also displayed.



When the engine oil temperature is too high, a red indicator lamp is displayed.

# **Coolant temperature**

If the coolant along with the engine becomes too hot, a Check Control message is displayed.



A red indicator lamp is displayed.

Check the coolant level.

# **Odometer and trip odometer**

# **Display**



- Odometer, arrow 1.
- Trip odometer, arrow 2.

#### Show/reset miles



Press the button.

 When the ignition is switched off, the time, the external temperature and the odometer are displayed. When the ignition is switched on, the trip odometer is reset.

# **External temperature**

WARNING

Even at temperatures above +37 °F/+3 °C there can be a risk of icy roads, e.g., on bridges or shady sections of road. There is a risk of an accident. Adjust your driving style to the weather conditions at low temperatures. ◄



If the indicator drops to +37 °F/+3 °C or lower, a signal sounds.

A Check Control message is displayed.

There is an increased risk of ice on roads.

#### **Time**



The time is displayed at the bottom of the instrument cluster.

The time can be set on the Control Display.

# **Date**



The date is displayed in the onboard computer.

The date and date format can be set on the Control Display.

# Range

# **Display**



With a low remaining range:

A Check Control message is displayed briefly.

- The remaining range is shown on the onboard computer.
- With a dynamic driving style, e.g., taking curves aggressively, the engine function is not always ensured.

The Check Control message appears continuously below a range of approx. 30 miles/50 km.

NOTE

With a range of less than 30 miles/50 km it is possible that the engine will no longer have sufficient fuel. Engine functions are not ensured anymore. There is a risk of property damage. Refuel promptly.◀

#### Displaying the cruising range

Depending on your vehicle's optional features, the range can also be displayed as bar in the instrument cluster.

- 1. "Settings"
- 2. "Instrument cluster"
- "Additional indicators"

# With navigation system: range with destination guidance active



If respective equipment is fitted and destination guidance is active, the remaining range is displayed when the destination is reached.

# **Current fuel consumption**

# **Display**



Depending on your vehicle's optional features, the current fuel consumption can be displayed in the instrument cluster. Check whether you are currently driv-

ing in an efficient and environmentally-friendly manner.

# Displaying the current fuel consumption

- 1. "Settings"
- 2. "Instrument cluster"
- 3. "Additional indicators"

The bar display for the current fuel consumption is displayed in the instrument cluster.

# **Energy recovery**

#### **Display**



The kinetic energy of the vehicle is converted to electrical energy while Coasting. The vehicle battery is partially charged and fuel consumption can be reduced.

# Service requirements

#### Concept

The function displays the service requirements and the corresponding maintenance scopes.

#### General information

After the ignition is turned on the instrument cluster briefly displays available driving distance or time to the next scheduled maintenance.

A service advisor can read out the current service requirements from your remote control.

#### **Display**

# Detailed information on service requirements

More information on the scope of service required can be displayed on the Control Display.

- 1. "Vehicle info"
- 2. "Vehicle status"
- Service required"

Required maintenance procedures and legally mandated inspections are displayed.

Select an entry to call up detailed information.

# **Symbols**

Sym- Description bols



No service is currently required.



The deadline for scheduled maintenance or a legally mandated inspection is approaching.



The service deadline has already passed.

# **Entering appointment dates**

Enter the dates for the required vehicle inspections.

Make sure that the vehicle's date and time are set correctly.

On the Control Display:

- 1. "Vehicle info"
- 2. "Vehicle status"
- 3. Service required"
- 4. "§ Vehicle inspection"
- "Date:"

- 6. Adjust the settings.
- Confirm.

The entered date is stored.

#### **Automatic Service Request**

Data regarding the service status or legally mandated vehicle inspections is automatically transmitted to your dealer's service center before a service due date.

You can check when your dealer's service center was notified.

On the Control Display:

- "Vehicle info"
- 2. "Vehicle status"
- 3. Open "Options".
- 4. "Last Service Request"

# **Gear shift indicator**

#### Concept

The system recommends the most fuel efficient gear for the current driving situation.

# **General information**

Depending on the vehicle's features and country version of the vehicle, the gear shift indicator is active in the manual mode of the Steptronic transmission and with manual transmission.

Suggestions to shift gear up or down are displayed in the instrument cluster.

On vehicles without a gear shift indicator, the engaged gear is displayed.

### Manual transmission: displaying

Symbol	Description
<b>\$</b>	Fuel efficient gear is set.
<b>^3</b>	Shift up to fuel efficient gear.
<b>▼3</b>	Shift down to fuel efficient gear.
N	Shift into neutral.

# Steptronic transmission: displaying

Example	Description
<b>M3</b>	Fuel efficient gear is set.
314	Shift into fuel efficient gear.

# **Speed Limit Info**

# **Speed Limit Info**

# Concept

Speed Limit Info shows the current maximum permitted speed in the instrument cluster.

#### General information

The camera in the area of the interior mirror detects traffic signs at the edge of the road as well as variable overhead sign posts. Traffic signs with extra symbols for wet road conditions, etc. are also detected and compared with the vehicle's onboard data, such as for the rain sensor, and will be displayed depending on the situation. The system takes into account the information stored in the navigation

system and also displays speed limits present on routes without signs.

#### **Safety information**

WARNING

The system does not release from the personal responsibility to correctly assess visibility and traffic situation. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### **Overview**

#### Camera



The camera is installed near the interior mirror. Keep the windshield in front of the interior mirror clean and clear.

# Switching on/off

On the Control Display:

- 1. "Settings"
- 2. "Instrument cluster"
- "Speed limit information"

If Speed Limit Info is switched on, it can be displayed on the CID (central information display) in the instrument cluster via the onboard computer.

# **Display**

The following is displayed in the instrument cluster:

#### **Speed Limit Info**



Current speed limit.



Speed Limit Info not available.

Speed Limit Info can also be displayed in the Head-up Display.

#### **System limits**

The system may not be fully functional and may provide incorrect information in the following situations:

- In heavy fog, rain or snowfall.
- When signs are fully or partially concealed by objects, stickers or paint.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights or strong reflections.
- When the windshield in front of the interior mirror is fogged over, dirty or covered by a sticker, etc.
- In the event of incorrect detection by the camera.
- ▶ If the speed limits stored in the navigation system are incorrect.
- In areas not covered by the navigation system.
- When roads differ from the navigation, such as due to changes in road routing.
- When passing buses or trucks with a speed sticker.
- If the traffic signs are non-conforming.
- During calibration of the camera immediately after vehicle delivery.

When signs that are valid for a parallel road are detected.


# Selection lists in the instrument cluster

#### General information

Depending on your vehicle's equipment, the following can be displayed or operated using the buttons and the thumbwheel on the steering wheel as well as the displays in the instrument cluster and the Head-up Display:

- Current audio source.
- Redial phone feature.
- Turn on voice activation system.

# Activating a list and adjusting the setting



On the right side of the steering wheel, turn the thumbwheel to activate the corresponding list.

- Turn the thumbwheel and select the desired setting.
- Press the thumbwheel.

#### **Display**



Depending on your vehicle's optional features, the list in the instrument cluster can differ from the illustration shown.


# Onboard computer

# Indication in the info display



The information from the onboard computer is shown in the info display in the instrument cluster.

# Calling up information on the CID (central information display)



Press and hold button on signal lever.

Information is displayed in the CID (central information display) of the instrument cluster.

# Information at a glance

Repeatedly pressing the button on the turn signal lever calls up the following information in the CID (central information display):

- Range.
- Average consumption, fuel.
- Average consumption, fuel.
- Average speed.
- Date.
- Speed limit detection.
- Time of arrival.

When destination guidance is activated in the navigation system.

- Distance to destination.
   When destination guidance is activated in the navigation system.
- ▶ ECO PRO bonus range.

#### **Selecting information**

Depending on the vehicle equipment version, you can select what information from the onboard computer is to be displayed on the CID (central information display) of the instrument cluster.

On the Control Display:

- 1. "Settings"
- "Instrument cluster"
- Select the desired information.

Settings are stored for the profile currently used.

#### Information in detail

# Range

Displays the estimated cruising range available with the remaining fuel.

It is calculated based on your driving style over the last 20 miles/30 km.

If there is only enough fuel left for less than 45 miles/80 km, the color of the display changes.

# **Average fuel consumption**


The average fuel consumption is calculated for the period while the engine is running.

The average fuel consumption is calculated for the distance traveled since the last reset by the onboard computer.

#### Average speed

Periods in which the vehicle is parked with the engine manually stopped are not included in the calculation of the average speed.

#### Resetting average values



Press and hold button on turn signal lever.

#### Distance to destination

The distance remaining to the destination is displayed if a destination is entered in the navigation system before the trip is started.

The distance to the destination is adopted automatically.

#### Time of arrival



The estimated time of arrival is displayed if a destination is entered in the navigation system before the trip is started.

The time must be correctly set.

# Speed Limit Info

Further information, see chapter Speed Limit Info.

# Trip onboard computer

The vehicle features two types of onboard computers.

- "Onboard info": the values can be reset as often as necessary.
- "Trip computer": the values provide an overview of the current trip.

# Resetting the trip computer

On the Control Display:

- 1. "Vehicle info"
- 2. "Trip computer"
- "Reset": all values are reset.

"Automatically reset": all values are reset approx. 4 hours after the vehicle has come to a standstill.

# **Display on the Control Display**

Display the onboard computer or trip onboard computer on the Control Display.

- 1. "Vehicle info"
- 2. "Onboard info" or "Trip computer"

#### Reset the fuel consumption or speed

On the Control Display:

- 1. "Vehicle info"
- "Onboard info"
- 3. "Consumpt." or "Speed"
- 4. "Yes"

# **Sport displays**

# The concept

On the Control Display, the current values for performance and torque can be displayed if the vehicle is appropriately equipped.

# **Displaying sport displays**

- 1. "Vehicle info"
- 2. "Sport displays"

# **Speed warning**

#### Concept

A speed limit can be set that when reached will cause a warning to be issued.

#### General information

The warning is repeated if the vehicle speed drops below the set speed limit once by at least 3 mph/5 km/h.

# Displaying, setting or changing the speed warning

On the Control Display:

- 1. "Settings"
- 2. "Speed"
- 3. "Warning at:"
- Turn the controller until the desired speed is displayed.
- 5. Press the controller.

Speed warning is stored.

# Activating/deactivating the speed warning

On the Control Display:

- 1. "Settings"
- "Speed"
- 3. "Warning"
- 4. Press the controller.

# Setting your current speed as the speed warning

On the Control Display:

- 1. "Settings"
- 2. "Speed"
- 3. "Select current speed"
- Press the controller.

The current vehicle speed is stored as the speed warning.

# **Settings on the Control Display**

#### **Time**

#### Setting the time zone

- 1. "Settings"
- 2. "Time/Date"
- 3. "Time zone:"
- Select the desired time zone.

The time zone is stored.

#### Setting the time

- 1. "Settings"
- 2. "Time/Date"
- 3. "Time:"
- Turn the controller until the desired hours are displayed.
- 5. Press the controller.
- Turn the controller until the desired minutes are displayed.
- 7. Press the controller.

The time is stored.

# **Setting the time format**

- 1. "Settings"
- 2. "Time/Date"
- 3. "Format:"
- 4. Select the desired format.

The time format is stored.

# **Automatic time setting**

Depending on your vehicle's optional features, the time, date and, if needed, the time zone are updated automatically.

- 1. "Settings"
- 2. "Time/Date"
- 3. "Auto time set"

#### **Date**

#### Setting the date

- "Settings"
- 2. "Time/Date"
- 3. "Date:"
- Turn the controller until the desired day is displayed.
- Press the controller.
- 6. Make the necessary settings for the month and year.

The date is stored.

#### **Setting the date format**

- "Settings"
- 2. "Time/Date"
- 3. "Format:"
- 4. Select the desired format.

The date format is stored.

#### Language

# Setting the language

To set the language on the Control Display:

- 1. "Settings"
- "Language/Units"
- 3. "Language:"
- 4. Select the desired language.

Settings are stored for the profile currently used.

#### Setting the voice dialog

Voice dialog for the voice activation system, refer to page 27.

#### **Units of measurement**

#### **Setting the units of measurement**

To set the units for fuel consumption, route/ distance and temperature:

- "Settings"
- 2. "Language/Units"
- 3. Select the desired menu item.
- 4. Select the desired unit.

Settings are stored for the profile currently used.

#### **Brightness**

#### **Setting the brightness**

To set the brightness of the Control Display:

- "Settings"
- "Control display"
- 3. "Brightness"
- Turn the controller until the desired brightness is set.
- 5. Press the controller.

Settings are stored for the profile currently used.

Depending on the light conditions, the brightness settings may not be clearly visible.

# Activating/deactivating the display of the current vehicle position

If GPS geolocation has been activated, the current vehicle position can be displayed in the BMW ConnectedDrive app or in the ConnectedDrive customer portal.

- 1. "Settings"
- "GPS tracking"
- 3. "GPS tracking"

# **Head-up Display**

#### Concept

This system projects important information into the driver's field of vision, e.g., the speed.

The driver can get information without averting his or her eyes from the road.

#### **Overview**



#### **Display visibility**

The visibility of the displays in the Head-up Display is influenced by the following factors:

- Certain sitting positions.
- Objects on the cover of the Head-up Display.
- Sunglasses with certain polarization filters.
- Wet roads.
- Unfavorable light conditions.

If the image is distorted, have the basic settings checked by a dealer's service center or another qualified service center or repair shop.

Follow the instructions for cleaning the Headup Display, refer to page 269.

### Switching on/off





Press button.

#### **Display**

#### Overview

The following information is displayed on the Head-up Display:

- Speed.
- Navigation system.
- Check Control messages.
- Selection list from the instrument cluster.
- Driver assistance systems.

Some of this information is only displayed briefly as needed.

# Selecting displays in the Head-up Display

On the Control Display:

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Displayed information"
- 4. Select the desired displays in the Head-up Display.

Settings are stored for the profile currently used.

# **Setting the brightness**

The brightness is automatically adjusted to the ambient brightness.

The basic setting can be adjusted.

On the Control Display:

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Brightness"
- Turn the controller until the desired brightness is set.
- Press the controller.

When the low beams are activated, the brightness of the Head-up Display can be additionally influenced using the instrument lighting.

Settings are stored for the profile currently used.

#### Adjusting the height

On the Control Display:

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Height"
- Turn the controller until the desired height is reached.
- Press the controller.

Settings are stored for the profile currently used.

# **Setting the rotation**

The screen of the Head-up Display can be rotated around its own axis.

On the Control Display:

- "Settings"
- "Head-Up Display"
- 3. "Rotation"
- Turn the controller until the desired setting is selected.
- Press the controller.

Settings are stored for the profile currently used.

# **Special windshield**

The windshield is part of the system.

The shape of the windshield makes it possible to display a precise image.

A film in the windshield prevents double images from being displayed.

For this reason, it is strongly suggested to have the special windshield replaced by a dealer's service center or another qualified service center or repair shop.

# Lights

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

Symbol	Function
€D Q€	Parking lights
<b></b> ■D	Low beams
E J	Instrument lighting

#### **Overview**

#### Switches in the vehicle



The light switch element is located next to the steering wheel.

# **Light functions**

Symbol	Function
わ	Front fog lights
	Automatic headlamp control Adaptive Light Control
0	Lights off Daytime running lights

# Parking lights, cornering lights and roadside parking lights

#### **General information**

Position of switch: 0, ▮D, ▮₺

If the driver door is opened with the ignition switched off, the exterior lighting is automatically switched off at these switch settings.

# Parking lights

Position of switch: =D 0=

The vehicle is illuminated on all sides.

Do not use the parking lights for extended periods; otherwise, they might drain the battery and it would then be impossible to start the engine.

When parking, switch on the one-sided roadside parking lamp, refer to page 108.

#### Low beams

Position of switch: **■**D


The low beams light up when the ignition is switched on.

#### Roadside parking lights

#### Concept

The vehicle can be illuminated on one side.

#### **Switching on**



With the ignition switched off, press the lever either up or down past the resistance point for approx. 2 seconds.

# **Switching off**

Briefly press the lever to the resistance point in the opposite direction.

# Welcome lights and headlamp courtesy delay feature

# **Welcome lights**

#### **General information**

Depending on the equipment, when switching off the vehicle, switch position  $\ D$  or  $\ D$ .

Depending on the ambient brightness, individual light functions may be switched on briefly, when the vehicle is unlocked.

# **Activating/deactivating**

On the Control Display:

- 1. "Settings"
- 2. "Lighting"
- 3. "Welcome lights"

Settings are stored for the profile currently used.

#### Headlamp courtesy delay feature

#### **General information**

The low beams stay lit for a short while after the radio-ready state is switched off if the lights are turned off and the headlight flasher is switched on.

#### **Setting the duration**

On the Control Display:

- 1. "Settings"
- 2. "Lighting"
- 3. "Pathway lighting:"
- 4. Set length of time.

Settings are stored for the profile currently used.

# **Automatic headlamp control**

# Concept

The low beams are switched on and off automatically depending on the ambient brightness, e.g., in tunnels, in twilight or if there is precipitation.

#### General information

A blue sky with the sun low on the horizon can cause the lights to be switched on.

When emerging from a tunnel during the day, the low beams are not switched off immediately but instead only after approx. 2 minutes.

The low beams always stay on when the fog lamp is switched on.

# **Activating**

Position of switch: #C

The indicator lamp in the instrument cluster is illuminated when the low beams are switched on.

#### **System limits**

The automatic headlamp control cannot serve as a substitute for your personal judgment of lighting conditions.

For example, the sensors are unable to detect fog or hazy weather. To avoid safety risks under these conditions, you should always switch on the lights manually.

### **Daytime running lights**

#### **General information**

Position of switch: 0, ₹D0€, ∰C

The daytime running lights light up when the ignition is switched on. After the ignition is switched off, the parking lights light up in position **EDGE**.

### **Activating/deactivating**

In some countries, daytime running lights are mandatory, so it may not be possible to deactivate the daytime running lights.

On the Control Display:

- 1. "Settings"
- 2. "Lighting"
- 3. "Daytime running lamps"

Settings are stored for the profile currently used.

### **Adaptive Light Control**

### The concept

Adaptive Light Control is a variable headlight control system that enables dynamic illumination of the road surface.

#### **General information**

Depending on the steering angle and other parameters, the light from the headlight follows the course of the road.

To avoid blinding oncoming traffic, the Adaptive Light Control does not swivel to the driver's side when the vehicle is at a standstill.

Depending on the equipment version, Adaptive Light Control consists of one or several systems:

- Cornering light, refer to page 109.
- Adaptive headlight range control, refer to page 109.

### **Activating**

Position of switch **\*** with the ignition switched on.

### **Corner-illuminating lights**

In tight curves, e.g., on mountainous roads or when turning, an additional, corner-illuminating lamp is switched on that lights up the inside of the curve when the vehicle is moving below a certain speed.

The turning lights are automatically switched on depending on the steering angle or the use of turn signals.

When driving in reverse, the turning lights may be automatically switched on regardless of the steering angle.

### Self-leveling headlights

The self-leveling headlights compensate for acceleration and braking operations in order not to blind the oncoming traffic and to achieve optimum illumination of the roadway.

#### Malfunction

A Check Control message is displayed.

Adaptive Light Control is malfunctioning or has failed. Have the system immediately checked by a dealer's service center or another qualified service center or repair shop.

### **High-beam Assistant**

#### The concept


The high-beam Assistant detects other traffic participants early on and automatically switches the high beams on or off depending on the traffic situation. The assistant ensures that the high beams are switched on, whenever the traffic situation allows. In the low speed range, the high beams are not switched on by the system.

#### General information

The system responds to light from oncoming traffic and traffic driving ahead of you, and to adequate illumination, e.g., in towns and cities.

The driver can intervene at any time and switch the high beams on and off as usual.

#### **Activating**



- Press button on the turn signal lever, arrow.



The indicator lamp in the instrument cluster is illuminated when the low beams are switched on.

The high beams are switched on and off automatically.



The blue indicator lamp in the instrument cluster lights up when the system switches on the high beams.

#### **Deactivating**

The High-beam Assistant is deactivated when manually switching the high beams on and off, refer to page 78. To reactivate the high-beam Assistant, press the button on the turn signal lever.

#### **System limits**

The high-beam Assistant cannot serve as a substitute for the driver's personal judgment of when to use the high beams. Therefore, manually switch off the high beams in situations where required to avoid a safety risk.

The system is not fully functional in the following situations, and driver intervention may be necessary:

- ▶ In very unfavorable weather conditions, such as fog or heavy precipitation.
- When detecting poorly-lit road users such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; and at animal crossings.
- ▶ In tight curves, on hilltops or in depressions, in cross traffic or half-obscured oncoming traffic on highways.
- ▶ In poorly-lit towns and cities and in the presence of highly reflective signs.
- When the windshield in front of the interior mirror is fogged over, dirty or covered with stickers, etc.

### Fog lights

### **Front fog lights**

The parking lights or low beams must be switched on.



Press button. The green indicator lamp lights up.

If the automatic headlamp control, refer to page 108, is activated, the low beams will come on automatically when you switch on the front fog lights.

When the high beams or headlight flasher are activated, the front fog lights are not switched on.

### **Instrument lighting**

### **Settings**



The parking lights or low beams must be switched on to adjust the brightness.

Adjust the brightness with the thumbwheel.


### **Interior lights**

#### **General information**

Depending on the equipment, the interior lights, footwell lights, entry lamps, and courtesy lamps are controlled automatically.

Thumb wheel for the instrument lighting controls brightness of some of these features.

#### **Overview**



- 1 Interior lights
- 2 Reading lights

### Switching the interior lights on and off



Press button.

To switch off permanently: press the button for approx. 3 seconds.

Switch back on: press button.

## Switching the reading lamps on and off manually



Press button.

Reading lights are located at the front and rear next to the interior lights.

## Bang & Olufsen High End Surround Sound System

### **Adjusting speaker lighting**

Some speakers in the vehicle are illuminated. The lighting can be individually set.

- "Settings"
- 2. "Lighting"
- 3. "B&O"
- Select the desired lighting setting.
  - ▶ "Off": no lighting.
  - "Reduced": the speakers in the field of view are faded while driving.
  - "On": the speakers are always illuminated.

### **Ambient light**

Depending on the equipment, the lighting can be individually adjusted in the interior for some lights.

### **Selecting color scheme**

On the Control Display:

- "Settings"
- 2. "Lighting"
- "Ambient:"
- 4. Select the desired setting.

When they are activated and a color scheme is selected, the welcome lights illuminate in color when the vehicle is unlocked.

### **Setting the brightness**

On the Control Display:


- 1. "Settings"
- 2. "Lighting"
- 3. "Brightness:"
- 4. Adjust the brightness.

## **Safety**

### Vehicle features and options

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

### **Airbags**



- 1 Front airbag, driver
- 2 Front airbag, front passenger
- 3 Head airbag

- 4 Side airbag
- 5 Knee airbag

### Front airbags

Front airbags help protect the driver and front passenger by responding to frontal impacts in which safety belts alone would not provide adequate restraint.

### Side airbag

In a lateral impact, the side airbag supports the side of the body in the chest and lap area.

### **Head airbag**

In a lateral impact, the head airbag supports the head.

### **Knee airbag**

The knee airbag supports the legs in a frontal impact.

#### **Protective action**

WARNING

Airbags are not triggered in every impact situation, e.g., in less severe accidents or rear-end collisions.

## Information on optimum effect of the airbags

If the seat position is incorrect or the deployment area of the airbags is impaired, the airbag system cannot protect as intended or may cause additional injuries due to triggering. There is a risk of injuries or danger to life. Follow the information on optimum protective effect of the airbag system.

- Keep a distance from the airbags.
- Make sure that occupants keep their heads away from the side airbag.
- Always grasp the steering wheel on the steering wheel rim. Hold your hands at the 3 o'clock and 9 o'clock positions, to keep the risk of injury to your hands or arms as low as possible when the airbag is triggered.
- Make sure that the front passenger is sitting correctly, i.e., keeps his or her feet and legs in the floor area and does not support them on the dashboard.
- There should be no additional persons, animals or objects between an airbag and a person.
- Do not apply adhesive materials to the airbag cover panels, do not cover them or modify them in any way.
- Dashboard and windshield on the front passenger side must stay clear - do not attach adhesive labels or coverings and do not attach brackets or cables, for instance for GPS devices or mobile phones.

- Do not use the cover of the front airbag on the front passenger side as a storage area.
- Do not place slip covers, seat cushions or other objects on the front passenger seat that are not specifically suited for seats with integrated side airbags.
- Do not hang pieces of clothing, such as jackets, over the backrests.
- Never modify either the individual components or the wiring in the airbag system.
   This also applies to steering wheel covers, the dashboard, and the seats.
- Do not remove the airbag system.

Even when you follow all instructions very closely, injury from contact with the airbags cannot be fully ruled out in certain situations.

The ignition and inflation noise may lead to short-term and, in most cases, temporary hearing impairment in sensitive occupants.

Vehicle modifications for a person with disabilities may affect the air bag system; therefore, contact BMW Customer Relations or your authorized BMW service center.

Warnings and information on the airbags are also found on the sun visors.

# Functional readiness of the airbag system

### Safety information

WARNING

Individual components can be hot after triggering of the airbag system. There is a risk of injury. Do not touch individual components. ◀

WARNING

Improperly executed work can lead to failure, malfunction or unintentional triggering of the airbag system. In the case of a malfunction, the airbag system might not trigger as intended in the event of an accident despite respective accident severity. There is a risk of

injuries or danger to life. Have the airbag system checked, repaired, dismantled and scrapped by a dealer's service center or another qualified service center or repair shop. ◄

#### **Correct function**



When the ignition is switched on, the warning lamp in the instrument cluster lights up briefly and thereby indicates

the operational readiness of the entire airbag system and the belt tensioner.

#### Airbag system malfunctioning

- Warning lamp does not come on when the ignition is turned on.
- The warning lamp lights up continuously.

### Automatic deactivation of the frontseat passenger airbags

### Concept

The system reads if the front passenger seat is occupied by measuring the human body's resistance.

Front, knee and side airbag on the front passenger's side are either activated or deactivated.

#### **General information**

Before transporting a child on the front passenger seat, refer to the safety notes and instructions for children on the front passenger seat, see Children.

# Safety information WARNING

To ensure the front-seat passenger airbag function, the system must be able to detect whether a person is sitting in the front passenger seat. The entire seat cushion area must be used for this purpose. There is a risk of injuries or danger to life. Make sure that the

front passenger keeps his or her feet in the floor area. ◀

## Malfunction of the automatic deactivation system

When transporting older children and adults, the front-seat passenger airbags may be deactivated in certain sitting positions. In this case, the indicator lamp for the front-seat passenger airbags lights up.

In this case, change the sitting position so that the front-seat passenger airbags are activated and the indicator lamp goes out.

If it is not possible to activate the airbags, have the person sit in the rear.

To enable correct recognition of the occupied seat cushion

- Do not attach covers, cushions, ball mats or other items to the front passenger seat unless they are specifically determined to be safe for use on the front passenger seat.
- Do not place any electronic devices on the passenger seat if a child restraint system is to be installed on it.
- Do not place objects under the seat that could press against the seat from below.
- No moisture in or on the seat.

# Indicator lamp for the front-seat passenger airbags



The indicator lamp for the front-seat passenger airbags indicates the operating state of the front-seat passenger airbags.

The lamp indicates whether the airbags are either activated or deactivated.



- The indicator lamp lights up when a child is properly seated in a child restraint fixing system or when the seat is empty. The airbags on the front passenger side are not activated.
- ➤ The indicator lamp does not light up when, e.g., a correctly seated person of sufficient size is detected on the seat. The airbags on the front passenger side are activated.

#### **Detected child seats**

The system generally detects children seated in a child seat, particularly in child seats required by NHTSA at the point in time when the vehicle was manufactured. After installing a child seat, make sure that the indicator lamp for the front-seat passenger airbags lights up. This indicates that the child seat has been detected and the front-seat passenger airbags are not activated.

## Strength of the driver's and front-seat passenger airbag

The explosive power that activates driver's/ front passenger's airbags very much depends on the positions of the driver's/front passenger's seat.

To maintain the accuracy of this function over the long term, calibrate the front seats as soon as a respective message appears on the Control Display.

### **Calibrating the front seats**

WARNING
There is a risk of jamming when moving the seats. There is a risk of injury or risk of property damage. Make sure that the area of movement of the seat is clear prior to any adjustment.◄

A corresponding message appears on the Control Display.

- Press the switch and move the respective seat all the way forward.
- 2. Press the switch forward again. The seat still moves forward slightly.
- 3. Readjust the seat to the desired position.

The calibration procedure is completed when the message on the Control Display disappears.

If the message continues to be displayed, repeat the calibration.

If the message does not disappear after a repeat calibration, have the system checked as soon as possible.

### **Tire Pressure Monitor TPM**

#### Concept

The system monitors tire inflation pressure in the four mounted tires. The system warns you if there is a significant loss of pressure in one or more tires. For this purpose, sensors in the tire valves measure the tire inflation pressure and tire temperature.

#### **General information**

With use of the system observe further information found under Tire inflation pressure, refer to page 219.

### **Functional requirements**

The system must have been reset with the correct tire inflation pressure; otherwise, reliable signaling of tire inflation pressure loss is not assured.

Reset the system after each adjustment of the tire inflation pressure and after every tire or wheel change.

Always use wheels with TPM electronics to ensure that the system will operate properly.

### **Status display**

The current status of the Tire Pressure Monitor TPM can be displayed on the Control Display, e.g., whether or not the TPM is active.

On the Control Display:

- 1. "Vehicle info"
- 2. "Vehicle status"
- 3. (!) "Tire Pressure Monitor (TPM)"

The status is displayed.

#### Status control display

Tire and system status are indicated by the color of the wheels and a SMS text message on the Control Display.

#### All wheels green

System is active and will issue a warning related to the tire inflation pressures stored during the last reset.

#### One wheel is yellow

A flat tire or major drop in inflation pressure in the indicated tire.

### All wheels are yellow

A flat tire or major drop in inflation pressure in several tires.

### **Gray wheels**

The system cannot detect a flat tire. Reasons for this may be:

- The system is being reset.
- Malfunction.

#### **Status information**

The status control display additionally shows the current tire inflation pressures and, depending on the model, tire temperatures. It shows the actual values read; they may vary depending on driving style or weather conditions.

#### Resetting the system

Reset the system after each adjustment of the tire inflation pressure and after every tire or wheel change.

On the Control Display and on the vehicle:

- 1. "Vehicle info"
- 2. "Vehicle status"
- 3. (!) "Perform reset"
- 4. Start the engine but do not drive off.
- Reset tire inflation pressure: "Perform reset".
- 6. Drive away.

The wheels are displayed in gray and the status is displayed.

After driving faster than 19 mph/30 km/h for a short period, the set tire inflation pressures are accepted as reference values. The reset is completed automatically while driving.

After a successfully completed Reset, the wheels on the Control Display are shown in green and "Tire Pressure Monitor (TPM) active" is displayed.

You may interrupt this trip at any time. When you continue the reset resumes automatically.

### Low tire pressure message



The yellow warning lamp lights up. A Check Control message is displayed.

- There is a flat tire or a major loss in tire inflation pressure.
- No reset was performed for the system. The system therefore issues a warning based on the tire inflation pressures before the last reset.
- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- Check whether the vehicle is fitted with normal tires or run-flat tires.

Run-flat tires, refer to page 232, are labeled with a circular symbol containing the letters RSC marked on the tire's sidewall.

WARNING
A damaged regular tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. Runflat tires can maintain limited stability. There is a risk of an accident. Do not continue driving if the vehicle is not equipped with run-flat tires. Follow the information on run-flat tires and continued driving with these tires.

A low tire inflation pressure might turn on DSC Dynamic Stability Control.

#### Actions in the event of a flat tire

#### **Normal tires**

1. Identify the damaged tire.

Check the air pressure in all four tires, e.g., using the tire pressure gage of a tire repair kit.

If the tire inflation pressure in all four tires is correct, the Tire Pressure Monitor may not have been reset. In this case, perform the reset.

If identification of flat tire damage is not possible, please contact a dealer's service center or another qualified service center or repair shop.

2. Repair the flat tire, e.g., with a tire repair kit or by changing the tire.

Use of tire sealant, e.g., the Mobility System, may damage the TPM wheel electronics. In this case, have the electronics checked at the next opportunity and have them replaced, if needed.

#### **Run-flat tires**

#### Maximum speed

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

#### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, the Tire Pressure Monitor may not have been reset. In this case, perform the reset.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance with a flat tire depends on cargo load, driving style and road conditions.

A vehicle with an average load has a possible driving range of approx. 50 miles/80 km.

A vehicle with a damaged tire reacts differently, e.g., it has reduced lane stability during braking, a longer braking distance and different self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be shorter or longer depending on the driving speed, road conditions, external temperature, cargo load, etc.

#### WARNING

Your vehicle handles differently when a run-flat tire is damaged and has low or missing tire inflation pressure, e.g., your lane stability is reduced when braking, braking distances are longer and the self-steering properties will change. There is a risk of an accident.

Drive moderately and do not exceed a speed of 50 mph/80 km/h. ◀

#### Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire.

Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident.

Do not continue driving. Contact a dealer's service center or another qualified service center or repair shop.

## Required tire inflation pressure check message

A Check Control message is displayed in the following situations

- The system has detected a wheel change, but no reset was done.
- Inflation was not carried out according to specifications.
- The tire inflation pressure has fallen below the level of the last confirmation.

In this case:

- Check the tire pressure and correct as needed.
- Carry out a reset of the system after a tire change.

### **System limits**

The system does not function properly if a reset has not been carried out, e.g., a flat tire is reported though tire inflation pressures are correct.

The tire inflation pressure depends on the tire's temperature. Driving or exposure to the sun will increase the tire's temperature, thus increasing the tire inflation pressure. The tire inflation pressure is reduced when the tire temperature falls again. These circumstances may cause a warning when temperatures fall very sharply.

The system cannot indicate sudden serious tire damage caused by external circumstances.

#### Malfunction



The yellow warning lamp flashes and then lights up continuously. A Check Control message is displayed. No flat

tire or loss of tire inflation pressure can be detected.

Examples and recommendations in the following situations:

- A wheel without TPM electronics is mounted: Have it checked by a dealer's service center or another qualified service center or repair shop as needed.
- Malfunction: Have system checked by a dealer's service center or another qualified service center or repair shop.
- TPM was unable to complete the reset. Reset the system again.
- Interference caused by systems or devices with the same radio frequency: After leaving the area of the interference, the system automatically becomes active again.

### Declaration according to NHTSA/ FMVSS 138 Tire Pressure Monitoring System

Each tire, including the spare (if provided) should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.) As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to

tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale. Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

### **FTM Flat Tire Monitor**

### Concept

The system detects tire inflation pressure loss on the basis of rotation speed differences between the individual wheels while driving.

In the event of a tire inflation pressure loss, the diameter and therefore the rotational speed of the corresponding wheel changes. This will be detected and reported as a flat tire.

The system does not measure the actual inflation pressure in the tires.

#### **Functional requirements**

The system must have been initialized when the tire inflation pressure was correct; otherwise, reliable flagging of a flat tire is not assured. Initialize the system after each correction of the tire inflation pressure and after every tire or wheel change.

#### Status display

The current status of the Flat Tire Monitor can be displayed on the Control Display, e.g., whether or not the FTM is active.

On the Control Display:

- 1. "Vehicle info"
- 2. "Vehicle status"
- 3. (!) "Flat Tire Monitor (FTM)"

The status is displayed.

#### Initialization

When initializing, the set tire inflation pressures serve as reference values in order to detect a flat tire. Initialization is started by confirming the tire inflation pressures.

Do not initialize the system when driving with snow chains.

On the Control Display:

- 1. "Vehicle info"
- 2. "Vehicle status"
- 3. (!) "Perform reset"
- 4. Start the engine but do not drive off.
- 5. Start the initialization with "Perform reset".
- 6. Drive away.

The initialization is completed while driving, which can be interrupted at any time.

The initialization automatically continues when driving resumes.

#### Indication of a flat tire



The yellow warning lamp lights up. A Check Control message is displayed.

There is a flat tire or a major loss in tire inflation pressure.

- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- 2. Check whether the vehicle is fitted with normal tires or run-flat tires.

Run-flat tires, refer to page 232, are labeled with a circular symbol containing the letters RSC marked on the tire's sidewall.

WARNING

A damaged regular tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. Runflat tires can maintain limited stability. There is a risk of an accident. Do not continue driving if the vehicle is not equipped with run-flat tires. Follow the information on run-flat tires and continued driving with these tires.

When a flat tire is indicated, DSC Dynamic Stability Control is switched on, if needed.

### **System limits**

A natural, even tire inflation pressure loss in all four tires will not be recognized. Therefore, check the tire inflation pressure regularly.

Sudden serious tire damage caused by external circumstances cannot be recognized in advance.

The system could be delayed or malfunction in the following situations:

- When the system has not been initialized.
- When driving on a snowy or slippery road surface.
- Sporty driving style: spinning traction wheels, high lateral acceleration (drifting).
- When driving with snow chains.

#### Actions in the event of a flat tire

#### **Normal tires**

1. Identify the damaged tire.

Check the air pressure in all four tires, e.g., using the tire pressure gage of a tire repair kit.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

- If identification of flat tire damage is not possible, please contact a dealer's service center or another qualified service center or repair shop.
- 2. Repair the flat tire, e.g., with a tire repair kit or by changing the tire.

#### **Run-flat tires**

#### Maximum speed

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

#### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- 3. Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance with a flat tire depends on cargo load, driving style and road conditions.

A vehicle with an average load has a possible driving range of approx. 50 miles/80 km.

A vehicle with a damaged tire reacts differently, e.g., it has reduced lane stability during braking, a longer braking distance and different self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering ma-

neuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be shorter or longer depending on the driving speed, road conditions, external temperature, cargo load, etc.

#### WARNING

Your vehicle handles differently when a run-flat tire is damaged and has low or missing tire inflation pressure, e.g., your lane stability is reduced when braking, braking distances are longer and the self-steering properties will change. There is a risk of an accident.

Drive moderately and do not exceed a speed of 50 mph/80 km/h. ◀

#### Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire.

Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident.

Do not continue driving. Contact a dealer's service center or another qualified service center or repair shop.

### **Intelligent Safety**

### The concept

Intelligent Safety enables central operation of the driver assistance system.

Depending on how the vehicle is equipped, Intelligent Safety consists of one or more systems that can help prevent a imminent collision. These systems are active automatically every time the engine is started using the Start/Stop button:

- ▶ Front-end collision warning, refer to page 123.
- Pedestrian warning, refer to page 129.

### **Safety information**

### WARNING

Indicators and warnings do not relieve the driver from personal responsibility. Due to system limits, warnings or reactions of the system may not be output or they may be output too late or incorrectly. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### WARNING

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated, e.g., approach control warning with light braking function. There is a risk of an accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

#### **Overview**


#### **Button in the vehicle**





Intelligent Safety button

#### Camera



The camera is installed near the interior mirror. Keep the windshield in front of the interior mirror clean and clear.

### Switching on/off

The Intelligent Safety systems are automatically active after every departure.



Press button: the systems are turned off. The LED goes out.

Press button: the systems are turned on. The LED lights up.

Settings can be made on the Control Display.

### Front-end collision warning

Depending on the equipment, the collision warning system consists of one of the two systems:

- Front-end collision warning with City Braking function, refer to page 123.
- Front-end collision warning with braking function, refer to page 126

# Approach control warning with City light braking function

#### Concept

The system can help prevent accidents. If an accident cannot be prevented, the system will help reduce the collision speed.

The system sounds a warning before an imminent collision and actuates brakes independently, if needed.

The automatic braking intervention is done with limited force and duration.

A camera in the area of the rearview mirror controls the system.

The approach control warning is available even if cruise control has been deactivated.


With the vehicle approaching another vehicle intentionally, the approach control warning and braking are delayed in order to avoid false system reactions.

#### General information

The system warns at two levels of an imminent danger of collision at speeds from approx. 3 mph/5 km/h. Time of warnings may vary with the current driving situation.

Appropriate braking kicks in at speeds of up to 35 mph/60 km/h.

### **Detection range**



Objects are responded to if they are detected by the system.

### **Safety information**

WARNING

Indicators and warnings do not relieve the driver from personal responsibility. Due to system limits, warnings or reactions of the system may not be output or they may be output too late or incorrectly. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

### WARNING

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated, e.g., approach control warning with light braking function. There is a risk of an accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

#### **Overview**

#### Button in the vehicle





Intelligent Safety button

#### Camera



The camera is installed near the interior mirror. Keep the windshield in front of the interior mirror clean and clear.

### Switching on/off

### Switching on automatically

The system is automatically active after every driving off.

### **Switching off**



Press button: the system is switched off. The LED goes out.

Re-press button: the system is switched on. The LED lights up.

### **Setting the warning time**

The warning time can be set via iDrive.

- 1. "Settings"
- 2. "Frontal Coll. Warning"
- 3. Activate the desired time on the Control Display.

The selected time is stored for the profile currently used.

### Warning with braking function

### **Display**

If a collision with a recognized vehicle is imminent a warning symbol appears in the instrument cluster and in the Head-Up Display.

#### Symbol Measure



Symbol lights up red: prewarning. Brake and increase distance.



Symbol flashes red and an acoustic signal sounds: acute warning.

You are requested to intervene by braking or make an evasive maneuver.

#### **Prewarning**

This warning is issued, e.g., when there is the impending danger of a collision or the distance to the vehicle ahead is too small.

The driver must intervene actively when there is a prewarning.

#### Acute warning with braking function

Acute warning is displayed in case of the imminent danger of a collision when the vehicle approaches another object at a high differential speed.

The driver must intervene actively when there is an acute warning. If necessary, the driver is assisted by a minor automatic braking intervention in a possible risk of collision.

Acute warnings can also be triggered without previous forewarning.

### **Braking intervention**

The warning prompts the driver himself/herself to react. During a warning, the maximum braking force is used. Prerequisite for the brake booster is sufficiently quick and hard stepping on the brake pedal. The system can assist with some braking intervention if there is a risk of a collision. At low speeds vehicles may thus come to a complete stop.

Manual transmission: During a braking intervention up to a complete stop, the engine may be shut down.

The braking intervention is executed only if vehicle stability has not been restricted, e.g., by

deactivating the DSC Dynamic Stability Control.

The braking intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

Object detection can be restricted. Observe the limitations of the detection range and functional restrictions.

### System limits

### Safety information

₩ARNING

The system can react incorrectly or not at all due to the system limits. There is a risk of accidents or risk of property damage. Observe the information regarding the system limits and actively intervene, if needed. ◄

### **Detection range**

The system's detection potential is limited.

Thus, a system reaction might not come or might come late.

E.g., the following situations may not be detected:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you, or sharply decelerating vehicles.
- ▶ Vehicles with an unusual rear appearance.
- ▶ Two-wheeled vehicles ahead of you.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- If the driving stability control systems are limited or deactivated, e.g., DSC OFF.
- ▶ If, depending on the vehicle equipment version, the field of view of the camera in

the mirror or the radar sensor is dirty or obscured.

- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.
- During calibration of the camera immediately after vehicle delivery.
- ▶ If there are constant blinding effects because of oncoming light, e.g., from the sun low in the sky.

#### Warning sensitivity

The more sensitive the warning settings are, such as the warning time, the more warnings are displayed. However, there may also be an excess of false warnings.

# Collision warning with braking function

#### The concept

The system can help prevent accidents. If an accident cannot be prevented, the system will help reduce the collision speed.

The system sounds a warning before an imminent collision and actuates brakes independently if needed.

The automatic braking intervention may be executed with maximum braking force and for a brief period only as necessary.

If the vehicle is equipped with Active Cruise Control with Stop&Go, the front-end collision warning is controlled via the cruise control radar sensor in conjunction with a camera.


The front-end collision warning is available even if cruise control has been deactivated.

With the vehicle approaching another vehicle intentionally, the collision warning and braking are delayed in order to avoid false system reactions.

#### **General information**

The system issues a two-phase warning of a possible danger of collision with vehicles at speeds above approx. 3 mph/5 km/h. Time of warnings may vary with the current driving situation.

#### **Detection range**



Objects are responded to if they are detected by the system.

### **Safety information**

WARNING

Indicators and warnings do not relieve the driver from personal responsibility. Due to system limits, warnings or reactions of the system may not be output or they may be output too late or incorrectly. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

WARNING

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated, e.g., approach control warning with light braking function. There is a risk of an accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

#### **Overview**


#### **Button** in the vehicle





Intelligent Safety button


#### Radar sensor



The radar sensor is located in the lower area of the front bumper.

Always keep radar sensor clean and unobstructed.

#### Camera



The camera is installed near the interior mirror.

Keep the windshield in the area behind the interior mirror clean and clear.

#### Switching on/off

### **Switching on automatically**

The system is automatically active after every driving off.

### Switching off



Press button: the system is switched off. The LED goes out.

Re-press button: the system is switched on. The LED lights up.

### **Setting the warning time**

The warning time can be set via iDrive.

- 1. "Settings"
- 2. "Frontal Coll. Warning"
- 3. Activate the desired time on the Control Display.

The selected time is stored for the profile currently used.

### Warning with braking function

### **Display**

If a collision with a recognized vehicle is imminent a warning symbol appears in the instrument cluster and in the Head-Up Display.

### Symbol Measure



Symbol lights up red: prewarning.

Brake and increase distance.



Symbol flashes red and an acoustic signal sounds: acute warning.

You are requested to intervene by braking or make an evasive maneuver.

#### **Prewarning**

This warning is issued, e.g., when there is the impending danger of a collision or the distance to the vehicle ahead is too small.

The driver must intervene actively when there is a prewarning.

### Acute warning with braking function

Acute warning in displayed in case of the imminent danger of a collision when the vehicle approaches another object at a high differential speed.

The driver must intervene actively when there is an acute warning. If necessary, the driver is assisted by an automatic braking intervention in a possible risk of collision.

Acute warnings can also be triggered without previous forewarning.

### **Braking intervention**

The warning prompts the driver himself/herself to react. During a warning, the maximum braking force is used. Premise for the brake booster is sufficiently quick and hard stepping on the brake pedal. The system can assist with automatic braking intervention if there is risk of a collision. The intervention can bring the vehicle to a complete stop.

Manual transmission: During a braking intervention up to a complete stop, the engine may be shut down.

The braking intervention is executed only if vehicle stability has not been restricted, e.g. by deactivating the DSC Dynamic Stability Control.

Above approx. 130 mph/210 km/h the braking intervention occurs as a brief braking pressure. No automatic delay occurs.

The braking intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

Object detection can be restricted. Limitations of the detection range and functional restrictions are to be considered.

#### **System limits**

# Safety information WARNING

The system can react incorrectly or not at all due to the system limits. There is a risk of accidents or risk of property damage. Observe the information regarding the system limits and actively intervene, if needed.

#### **Detection range**

The system's detection potential is limited.

Thus, a system reaction might not come or might come late.

E.g., the following situations may not be detected:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you, or sharply decelerating vehicles.
- ▶ Vehicles with an unusual rear appearance.
- ▶ Two-wheeled vehicles ahead of you.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- ▶ If the driving stability control systems are limited or deactivated, e.g., DSC OFF.
- If, depending on the vehicle equipment version, the field of view of the camera in the mirror or the radar sensor is dirty or obscured.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

- During calibration of the camera immediately after vehicle delivery.
- If there are constant blinding effects because of oncoming light, e.g., from the sun low in the sky.

### Warning sensitivity

The more sensitive the warning settings are, such as the warning time, the more warnings are displayed. However, there may also be an excess of false warnings.

### **Pedestrian warning**

Depending on how the vehicle is equipped, the function warns of an imminent collision with pedestrians during daytime or nighttime.

The function is subdivided into the following systems:

- During daytime:
   Pedestrian warning with city braking function, refer to page 129
- ▶ At night: Night vision, refer to page 131

# Pedestrian warning with Approach control

### Concept

The system can help prevent accidents with pedestrians.

When driving at city speeds, the system will issue a warning if there is imminent danger of a collision with pedestrians and includes a braking function.

The camera in the area of the rearview mirror controls the system.


#### **General information**

With sufficient brightness, the system warns about possible collision danger with pedestrians starting at approx. 6 mph/10 km/h to ap-

prox. 35 mph/60 km/h and assists with braking before a collision.

Under those circumstances it reacts to people who are within the detection range of the system.

### **Detection range**



The detection area in front of the vehicle is divided into two areas:

- Central area, arrow 1, directly in front of the vehicle.
- Expanded area, arrow 2, to the right and left.

A collision is imminent if pedestrians are located within the central area. A warning is issued about pedestrians who are located within the extended area only if they are moving in the direction of the central area.

### Safety information

WARNING

Indicators and warnings do not relieve the driver from personal responsibility. Due to system limits, warnings or reactions of the system may not be output or they may be output too late or incorrectly. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### WARNING

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated,

e.g., approach control warning with light braking function. There is a risk of an accident. Switch all Intelligent Safety systems off prior to tow-starting/towing. ◄

#### **Overview**

#### **Button in the vehicle**





Intelligent Safety button

#### Camera



The camera is installed near the interior mirror. Keep the windshield in front of the interior mirror clean and clear.

### Switching on/off

### Switching on automatically

The system is automatically active after every driving off.

### **Switching off**



Press button: the systems are turned off. The LED goes out.

Press button: the systems are turned on. The LED lights up.

### Warning with braking function

#### **Display**

If a collision with a person detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.



The red symbol is displayed and a signal sounds.



With instrument display: The red symbol is displayed and a signal sounds.

Intervene immediately by braking or make an evasive maneuver.

#### **Braking intervention**

The warning prompts the driver himself/herself to react. During a warning, the maximum braking force is used. Prerequisite for the brake booster is sufficiently quick and hard stepping on the brake pedal. The system can assist with some braking intervention if there is a risk of a collision. At low speeds vehicles may thus come to a complete stop.

Manual transmission: During a braking intervention up to a complete stop, the engine may be shut down.

The braking intervention is executed only if vehicle stability has not been restricted, e.g., by deactivating the DSC Dynamic Stability Control.

The braking intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

Object detection can be restricted. Observe the limitations of the detection range and functional restrictions

#### **System limits**

# Safety information WARNING

The system can react incorrectly or not at all due to the system limits. There is a risk of accidents or risk of property damage. Observe the information regarding the system limits and actively intervene, if needed. ◄

#### **Detection range**

The detection potential of the camera is limited.

Thus, a warning might not be issued or be issued late.

E.g., the following situations may not be detected:

- Partially covered pedestrians.
- Pedestrians that are not detected as such because of the viewing angle or contour.
- Pedestrians outside of the detection range.
- Pedestrians having a body size less than 32 in/80 cm.

#### **Functional limitations**

The system may not be fully functional or may not be available in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- If the driving stability control systems are deactivated, e.g., DSC OFF.
- If the field of view of the camera or the windshield are dirty or covered.
- Up to 10 seconds after the start of the engine via the Start/Stop button.
- During calibration of the camera immediately after vehicle delivery.
- If there are constant blinding effects because of oncoming light, e.g., from the sun low in the sky.

When it is dark outside.

# Night Vision with Pedestrian and Animal Detection

#### Concept

Night Vision with pedestrian and animal detection is a night vision system.

An infrared camera scans the area in front of the vehicle and issues a warning if it detects pedestrians and animals on the street. Warm objects that are similar in shape to human beings or animals are detected by the system. If necessary, the heat image can be displayed on the Control Display.

#### **Heat image**



The image shows the heat radiated by objects in the field of view of the camera.

Warm objects have a light appearance and cold objects a dark appearance.

The ability to detect an object depends on the temperature difference between the object and the background and on the level of heat radiation emitted by the object. Objects that are similar in temperature to the environment or that radiate very little heat are difficult to detect.

For safety reasons, when driving at speeds above approx. 3 mph/5 km/h and in low ambient light, the image is only displayed when the low beams are activated.

A still image is displayed at regular intervals for a fraction of a second.

#### **Pedestrian and animal detection**



Object detection and object warning only function in darkness.

Objects whose form is similar to people with sufficient heat radiation are detected.

In addition, the system also detects animals above a certain minimum size, for example, deer.

Display on the Control Display with heat image activated:

- People detected by the system: in light vellow.
- Animals detected by the system: in dark yellow.

Range of object detection, with good ambient conditions:

- Pedestrian detection: up to approx. 330 ft/100 m
- Detection of large animals: up to approx. 490 ft/150 m
- Detection of medium animals: up to approx. 230 ft/70 m

Environmental influences can limit the availability of object detection.

If the vehicle systems detect that the vehicle is located in a residential area, the animal detection is temporarily switched off.

#### **Safety information**

WARNING

The system does not release from the personal responsibility to correctly assess visibility and traffic situation. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### Overview

#### **Buttons in the vehicle**




圇

Intelligent Safety button



Switching on/switching off heat image

#### Camera



The camera is automatically heated when the external temperatures are low.

The camera lens is automatically cleaned together with the headlamps.

#### Switching on/off

### Switching on automatically

When it is dark outside, the system is automatically active after every driving-off.

#### **Switching off**



Press button.

The LED goes out.

#### Switching on heat image additionally

The heat image from the Night Vision camera can also be displayed on the Control Display. This function has no effect on object detection.



Press button.

The image from the camera is displayed on the Control Display.

#### Adjustments via the iDrive

With heat image switched on:

- Press the Controller.
- Select brightness or contrast.
  - Select the symbol.
  - Select the symbol.
- Turn the Controller until the desired setting is selected.
- 4. Press the Controller.


### **Display**

# Warning of people or animals in danger

If a collision with a person or an animal detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.

Although both the shape and the heat radiation are analyzed, false warnings cannot be ruled out.

#### Warning area in front of the vehicle



The warning area for the pedestrian warning consists of two parts:

- Central area, arrow 1, directly in front of the vehicle.
- Expanded area, arrow 2, to the right and left

With animal warnings, no distinction is made between the central or expanded area.

The entire area moves along with the vehicle in the direction of the steering angle and changes with the vehicle speed. As the vehicle speed increases, the area becomes longer and wider, for example.

### **Symbols**

Symbol	Meaning
<u> </u>	Prewarning: pedestrian warning.
4	Prewarning: animal warn-ing.
<u>_</u>	Acute warning: pedestrian warning in the instrument cluster.
(( † ))	Acute warning: pedestrian warning in the instrument display.
<i>}</i> <	Acute warning: animal warning in the instrument cluster.

Symbol	Meaning
$\left( ((\boldsymbol{\mathcal{L}}_{\boldsymbol{\mathcal{L}}_{\boldsymbol{\mathcal{L}}}})) \right)$	Acute warning: animal warning in the instrument display.
Symbol lights up yellow.	Prewarning.
Symbol lights up red and a signal sounds.	Acute warning.

The displayed symbol may vary and shows the side of the road on which the person or animal was detected.

#### **Display in the Head-up Display**

The warning is displayed simultaneously in the Head-up Display and on the instrument cluster.

#### **Prewarning**

Prewarning for persons is displayed when a person is detected in the central area immediately in front of the vehicle as well as on the left or right side in the extended area.

Prewarning for animals is displayed when an animal is detected in the front of the vehicle.

The driver must intervene actively by braking or making an evasive maneuver when there is a prewarning.

### **Acute warning**

Acute warning is displayed if a person or an animal is detected in direct proximity if front of the vehicle.

The driver must immediately intervene actively by braking or making an evasive maneuver when there is an acute warning.

#### **System limits**

#### **Basic limits**

The system may not be fully functional in the following situations:

- On steep hills, in steep depressions or in tight curves.
- ▶ If the camera is soiled or damaged.
- In heavy fog, rain or snowfall.
- At very high external temperatures.

## Limits of pedestrian and animal detection

In some situations, it may occur that pedestrians are detected as animals or animals as pedestrians.

Small animals are not detected by the object detection function, even if they are clearly visible in the image.

Limited detection, for example in the following circumstances:

- People or animals who are fully or partially covered, especially when their heads are covered.
- People who are not in an upright position, for example, lying down.
- Cyclists on unconventional bicycles (for example, recumbent bicycles).
- After physical damage to the system, for example, after an accident.

### No display on the rear screen

The image from Night Vision cannot be displayed on the rear screen.

### Lane departure warning

#### Concept

Starting at a specific speed, this system alerts you when the vehicle on streets with lane markings is about to leave the lane. This

speed, depending on the country version, is between 35 mph/55 km/h and 45 mph/70 km/h.

When switching on the system below this speed, a message is displayed in the instrument cluster.

The steering wheel begins vibrating gently in the event of warnings. The time of the warning may vary depending on the current driving situation.

The system does not provide a warning if the turn signal is set before leaving the lane.

### **Safety information**

WARNING

The system does not release the driver from the personal responsibility to correctly assess route and traffic situation. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations. In the event of a warning, do not unnecessarily jerk the steering wheel.

#### Overview


#### Button in the vehicle





Lane departure warning

#### Camera



The camera is installed near the interior mirror. Keep the windshield in front of the interior mirror clean and clear.

### Switching on/off



Press button.

- On: the LED lights up.
- Off: the LED goes out.

Settings are stored for the profile currently used.

### Display in the instrument cluster



- Lines: system is activated.
- Arrows: at least one lane marking was detected and warnings can be issued.

### Display in the instrument display



- Symbol orange: system is activated.
- Green symbol: at least one lane marking was detected and warnings can be issued.

### **Issued warning**

If you leave the lane and if a lane marking has been detected, the steering wheel begins vibrating.

If the turn signal is set before changing the lane, a warning is not issued.

#### **End of warning**

The warning is canceled in the following situations:

- Automatically after approx. 3 seconds.
- When returning to your own lane.
- When braking hard.
- When using the turn signal.

### **System limits**

# Safety information WARNING

The system can react incorrectly or not at all due to the system limits. There is a risk of accidents or risk of property damage. Observe the information regarding the system limits and actively intervene, if needed. ◄


#### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain or snowfall.
- In the event of missing, worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.
- When lane markings are covered in snow, ice, dirt or water.
- In tight curves or on narrow lanes.
- When the lane markings are covered by objects.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights.
- When the windshield in front of the interior mirror is fogged over, dirty or covered with stickers, etc.
- During calibration of the camera immediately after vehicle delivery.

### **Active Blind Spot Detection**

#### The concept



Two radar sensors in the rear bumper monitor the area behind and next to the vehicle at speeds above approx. 30 mph/50 km/h.

The system indicates whether there are vehicles in the blind spot, arrow 1, or approaching from behind on the adjacent lane, arrow 2.

The lamp in the exterior mirror housing is dimmed.

Before you change lanes after setting the turn signal, the system issues a warning in the situations described above.

The lamp in the exterior mirror housing flashes and the steering wheel vibrates.

### Safety information

WARNING

The system does not release from the personal responsibility to correctly assess visibility and traffic situation. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### **Overview**

#### **Button in the vehicle**





Active Blind Spot Detection

#### Radar sensors



The radar sensors are located in the rear bumper.

### Switching on/off



Press button.

- On: the LED lights up.
- Off: the LED goes out.

Settings are stored for the profile currently used.

#### **Display**

#### Lamp in the exterior mirror housing



### **Prewarning**

The dimmed lamp in the exterior mirror housing indicates when there are vehicles in the blind spot or approaching from behind.

#### **Acute warning**

If the turn signal is set while a vehicle is in the critical zone, the steering wheel vibrates briefly and the lamp in the exterior mirror housing flashes brightly.

The warning stops when the turn signal is switched off, or the other vehicle leaves the critical zone.

### **Brief flashing**

A brief flashing of the lamp during vehicle unlocking serves as system self-test.

### System limits

### **Safety information**

WARNING

The system can react incorrectly or not at all due to the system limits. There is a risk of accidents or risk of property damage. Observe the information regarding the system limits and actively intervene, if needed. ◄

#### **Functional limitations**

The system may not be fully functional in the following situations:

- When a vehicle is approaching at a speed much faster than your own.
- In heavy fog, rain or snowfall.
- In tight curves or on narrow lanes.
- If the bumper is dirty or iced up, or covered with stickers.
- If cargo protrudes.

A Check Control message is displayed when the system is not fully functional.

### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

#### FCC ID:

▶ NBG009014A.

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

### **Brake force display**

### Concept

Additional brake lamps indicate emergency braking to the traffic behind. This can reduce the risk of a rear-end collision.

#### **General information**



- During normal brake application, the outer brake lights light up.
- During heavy brake application, the inner brake lights additionally light up.

### **Active Protection**

#### **General information**

The Active Protection safety package consists of systems that are independent of each other:

- Attentiveness assistant.
- PreCrash.
- PostCrash.

### **Attentiveness assistant**

### Concept

The system can detect decreasing alertness or fatigue of the driver during long, monotonous trips, e.g., on highways. In this situation, it is recommended that the driver takes a break.

### **Safety information**

WARNING

The system does not release from the personal responsibility to correctly assess one's physical state. An increasing lack of alertness or fatigue may not be detected or not be detected in time. There is a risk of an accident. Make sure that the driver is rested and

alert. Adjust the driving style to the traffic conditions.◀

#### **Function**

The system is activated each time the engine is started and cannot be switched off.

After travel has begun, the system monitors certain aspects of the driver's behavior, so that decreasing alertness or fatigue can be detected.

This procedure takes the following criteria into account:

- Personal driving style, e.g., steering behavior.
- Driving conditions, e.g., length of trip.

Starting at approximately 43 mph/70 km/h, the system is active and can display a recommendation to take a break.

#### **Break recommendation**

If the driver becomes less alert or fatigued, a message is displayed in the Control Display with the recommendation to take a break.

A recommendation to take a break is displayed only once during an uninterrupted trip.

After a break, another recommendation to take a break cannot be displayed until after approximately 45 minutes.

### **System limits**

The function may be limited in the following situations, e.g., and will either output an incorrect warning or no warning at all:

- When the clock is set incorrectly.
- When the vehicle speed is mainly below about 43 mph/70 km/h.
- With a sporty driving style, such as during rapid acceleration or when cornering fast.
- In active driving situations, such as when changing lanes frequently.
- ▶ When the road surface is poor.
- In the event of strong side winds.

The system is reset approx. 45 minutes after parking the vehicle, e.g., in the case of a break during longer trips on highways.

#### **PreCrash**

#### The concept

With this system critical driving situations that might result in an accident can be detected above a speed of approx. 20 mph/30 km/h. In these situations, preventive measures are automatically taken to minimize the risk of an accident as much as possible.

Critical driving situations may include:

- Emergency stop.
- Severe understeering.
- Severe oversteering.

If the vehicle includes the front-end collision warning or front-end collision warning with braking feature, impending collisions with vehicles driving ahead or stopped in front of you can also be detected within the system's range.

### **Safety information**

**№** WARNING

The system does not release from the personal responsibility. Due to the system limits, critical situation could not be detected reliably or in time. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### **Function**

After the safety belt is buckled, the front safety belts are automatically tightened once after the vehicle drove off.

In critical driving situations, the following individual functions become active as needed:

The front safety belts are automatically pretensioned.

- Automatic closing of the windows.
- Automatic closing of the glass sunroof.
- For vehicles equipped with Comfort Seats: automatic positioning of the backrest for the front passenger seat.

After a critical driving situation without an accident, the front safety belts are loosened again. All other systems can be restored to the desired setting.

If the belt tension does not loosen automatically, stop the vehicle and unbuckle the safety belt using the red button in the buckle. Fasten the safety belt before continuing on your trip.

#### **PostCrash**

#### Concept

In the event of an accident, the system can bring the vehicle to a halt automatically without intervention by the driver in certain situations. This can reduce the risk of a further collision and the consequences thereof.

### Harder vehicle braking

It can be necessary to bring the vehicle in certain situations to a halt quicker.

Here, a higher braking pressure must be generated for a short period when pressing the brake pedal than during automatic braking. This interrupts automatic braking.

### Interrupting automatic braking

It can be necessary to interrupt automatic braking in certain situations, e.g., for an evasive maneuver.

Interrupt automatic braking:

- > By pressing the brake pedal.
- > By pressing the accelerator pedal.

#### At standstill

After coming to a halt, the brake is released automatically.

## **Driving stability control systems**

### Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# Anti-lock Braking System ABS

ABS prevents locking of the wheels during braking.

The vehicle maintains its steering power even during full brake applications, thus increasing active safety.

ABS is operational every time you start the enqine.

### **Brake assistant**

When you apply the brakes rapidly, this system automatically produces the greatest possible braking force boost. It reduces the braking distance to a minimum during emergency stop. This system utilizes all of the benefits provided by ABS.

Do not reduce the pressure on the brake pedal for the duration of the emergency stop.

### Adaptive brake assistant

In combination with the Active Cruise Control, this system ensures that the brakes respond even more rapidly when braking in critical situations.

### **Drive-off assistant**

#### Concept

This system supports driving off on inclines. The parking brake is not required.

#### Driving off with the drive-off assistant

- Hold the vehicle in place with the foot brake.
- Release the foot brake and drive off without delay.

After the foot brake is released, the vehicle is held in place for approx. 2 seconds.

Depending on the vehicle load, the vehicle may roll back slightly.

# DSC Dynamic Stability Control

### Concept

Within the physical limits, the system helps to keep the vehicle on a steady course by reducing engine speed and by applying brakes to the individual wheels.

#### **General information**

Dynamic Stability Control detects, e.g., the following unstable driving conditions:

- Fishtailing, which can lead to oversteering.
- Loss of traction of the front wheels, which can lead to understeering.

Dynamic Traction Control DTC, refer to page 142, is a version of the DSC where forward momentum is optimized.

### **Safety information**

WARNING

The system does not release from the personal responsibility to correctly assess the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### WARNING

When driving with roof load, e.g., with roof-mounted luggage rack, driving safety may not be ensured in driving-critical situations due to the elevated center of gravity. There is a risk of accidents or risk of property damage. Do not deactivate Dynamic Stability Control DSC when driving with roof load.

#### **Overview**

#### **Button in the vehicle**





DSC OFF button

### **Indicator/warning lights**



The indicator lamp flashes: DSC controls the drive and braking forces.

The indicator lamp lights up: DSC has malfunctioned.

### **Deactivating DSC: DSC OFF**

When DSC is deactivated, driving stability is reduced during acceleration and when driving in curves.

Stabilizing interventions by the Integral Active Steering system are only performed by the rear axle steering.

To increase vehicle stability, activate DSC again as soon as possible.

### **Deactivating DSC**



Press and hold this button but not longer than approx. 10 seconds, until the

indicator lamp for DSC OFF lights up in the instrument cluster and displays DSC OFF.

DSC is switched off.

The steering and, depending on the equipment, suspension are tuned for sporty driving.

### **Activating DSC**



Press button.

DSC OFF and the DSC OFF indicator lamp go out.

### **Indicator/warning lights**

When DSC is deactivated, DSC OFF is displayed in the instrument cluster.



The indicator lamp lights up: DSC is deactivated.

# **DTC Dynamic Traction Control**

### Concept

DTC is a version of the DSC where forward momentum is optimized.

The system ensures maximum headway on special road conditions or loose road surfaces, e.g., unplowed snowy roads, but with somewhat limited driving stability.

When DTC is activated, the vehicle has maximum traction. Driving stability is limited during acceleration and when driving in curves.

Therefore, drive with appropriate caution.

You may find it useful to briefly activate DTC under the following special circumstances:

- When driving in slush or on uncleared, snow-covered roads.
- When freeing vehicle from deep snow or driving off from loose ground.
- When driving with snow chains.

## Deactivating/activating DTC Dynamic Traction Control

#### **Activating DTC**

Press button.

TRACTION is displayed in the instrument cluster and the indicator lamp for DSC OFF lights up.

### **Deactivating DTC**

Press button again.

TRACTION and the DSC OFF indicator lamp go out.

### **Indicator/warning lights**

If DTC is activated, TRACTION is displayed in the instrument cluster.



The indicator lamp lights up: DTC Dynamic Traction Control is activated.

### **xDrive**

xDrive is the all-wheel-drive system of your vehicle. Concerted action by the xDrive and DSC further optimize traction and driving dynamics. The xDrive all-wheel-drive system variably distributes the drive forces to the front and rear axles as demanded by the driving situation and road surface.

### **HDC Hill Descent Control**

#### Concept

HDC is a downhill driving assistant that automatically controls vehicle speed on steep downhill gradients. Without applying the brakes, the vehicle moves at slightly more than walking speed. It the brakes are actively applied, the system distributes force according to the traction.


Vehicle stability and maneuverability are improved on downhill gradients.

Hill Descent Control can be activated at speeds below approx. 22 mph/35 km/h. When driving downhill, the vehicle reduces its speed and then keeps its speed constant.

Only use HDC in low gears or in selector lever position D or R.

## Increasing or decreasing vehicle speed

Specify desired speed in the range from approx. 4 mph/6 km/h to approx. 15 mph/25 km/h using the rocker switch of the cruise control on the steering wheel. Vehicle speed can be changed by lightly accelerating.



- Press the rocker switch up to the point of resistance: the speed increases gradually.
- Press up the rocker switch past the point of resistance: the speed increases while the rocker switch is pressed.
- Press the rocker switch down to the point of resistance: the speed decreases gradually.

Press the rocker switch down past the point of resistance: when driving forward, the speed decreases to approx. 6 mph/10 km/h; when reversing, the speed decreases to approx. 4 mph/6 km/h.

### **Activating HDC**





Press button; the LED above the button lights up.

### **Deactivating HDC**



Press button again. The LED goes out. HDC is automatically deactivated above approx. 37 mph/60 km/h.

### Display in the instrument cluster



The selected speed is displayed in the speedometer.

- Green: the system is actively braking the vehicle.
- Orange: the system is on standby.

#### Malfunction

A message is displayed in the instrument cluster. HDC is not available, e.g., due to elevated brake temperatures.

### **Adaptive Drive**

### The concept

Adaptive Drive includes the following systems:

- Dynamic Drive, refer to page 144.
- Dynamic Damping Control, refer to page 144.

The system increases driving stability and drivina comfort.

### **Dynamic Drive**

#### The concept

The system reduces the lateral inclination of the vehicle that occurs during rapid driving in curves or during quick evasive maneuvers.

Driving stability and driving comfort are increased under all driving conditions. The system utilizes active stabilizer bars on the front and rear axles that react immediately to all driving situations.

### **Programs**

The system offers two different programs.

Select the programs via the Driving Dynamics Control.

#### **SPORT**

Sporty tuning for greater driving agility.

#### COMFORT

Comfort-oriented tuning for optimal comfort.

### **Dynamic Damping Control**

#### Concept

This system reduces undesirable vehicle motion when using a dynamic driving style or traveling on uneven road surfaces.

This enhances the driving dynamics and driving comfort depending on the road surface condition and driving style.

#### **Programs**

The system offers several different programs. Select the programs via the Driving Dynamics Control.

#### **SPORT/SPORT+**

Consistently sporty control of the shock absorbers for greater driving agility.

#### **COMFORT/ECO PRO**

Balanced tuning.

#### **COMFORT+**

Comfort-oriented tuning of the shock absorbers for optimal traveling comfort.

# **Integral Active Steering**

# Concept

Integral Active Steering is a combination of Active Steering and rear axle steering.

Active Steering varies the steering angle of the wheels in relation to the steering wheel movement as a function of the speed.

At speeds up to approx. 37 mph/60 km/h, e.g., in curves, the steering angle is increased, i.e., steering becomes more direct.

The rear axle steering acts to increase maneuverability by turning the rear wheels slightly in a direction opposite to the front wheels.

At higher speeds, the steering angle is increasingly reduced.

The rear wheels are turned to the same angle as the front wheels.

In critical situations, Integral Active Steering can specifically steer the front and rear wheels to stabilize the vehicle before the driver intervenes, e.g., when braking where road condi-

tions differ on the left and right sides of the vehicle.

# Initializing

In rare cases, it may become necessary to initialize the Integral Active Steering.



The warning lamp lights up. A Check Control message is displayed.

- With the engine running, turn the steering wheel all the way to the left and right several times in a uniform manner until the warning lamp disappears.
- Have the system checked if the warning lamp does not go out after moving the steering wheel approx. 6 times or if the steering wheel is at an angle.

# Using snow chains

# **General information**

When snow chains are in use, refer to page 236, rear wheel steering is deactivated.

# **Programs**

The system offers several different programs. Select the programs via the Driving Dynamics Control, refer to page 146.

#### **SPORT**

Consistently sporty tuning of the Integral Active Steering for greater driving agility.

#### Malfunction

In the event of a malfunction, the steering wheel must be turned further, while the vehicle responds more sensitively to steering wheel movements in the higher speed range.

The stability-enhancing intervention may be deactivated.

Proceed cautiously and drive defensively. Have the system checked.

# **Driving Dynamics Control**

#### The concept

The Driving Dynamics Control can be used to adjust the driving dynamics of the vehicle. For this purpose various programs are available for selection that are activated via the two buttons of the Driving Dynamics Control and the DSC OFF-button.

#### **Overview**

#### **Button in the vehicle**



# **Operating the programs**

Press button	Program
<b>₽</b> off	DSC OFF TRACTION
	SPORT+
	SPORT
▽	COMFORT
	COMFORT+
	ECO PRO

# **Automatic program change**

The system may automatically switch to COM-FORT in the following situations:

- Failure of Integral Active Steering.
- Failure of Dynamic Damping Control.
- Failure of DSC Dynamic Stability Control.
- The vehicle has a flat tire.

When activating cruise control in TRAC-TION or DSC OFF mode.

#### **DSC OFF**

When DSC OFF, refer to page 142, is active, driving stability is limited during acceleration and when driving in curves.

#### **TRACTION**

When TRACTION is active, the vehicle has maximum traction on loose road surfaces. DTC Dynamic Traction Control, refer to page 143, is activated. Driving stability is limited during acceleration and when driving in curves.

#### SPORT+

Sporty driving with optimized chassis and suspension and adjusted drivetrain with limited driving stabilization.

Dynamic Traction Control is switched on.

The driver handles several of the stabilization tasks.

# **Activating SPORT+**

Press button repeatedly until SPORT+ appears in the instrument cluster and the DSC OFF indicator lamp lights up.

# **Automatic program change**

When switching on the manual speed limiter or activating cruise control, the program automatically switches to SPORT mode.

# **Indicator/warning lights**

SPORT+ is displayed in the instrument cluster.



The DSC OFF indicator lamp lights up: Dynamic Traction Control is activated.

# **SPORT**

Consistently sporty tuning of the suspension and drivetrain for greater driving agility with maximum driving stabilization.

#### **Activating SPORT**



Press button repeatedly until SPORT is displayed in the instrument cluster.

# **Configuring SPORT**

When the display is activated on the Control Display, refer to page 148, the SPORT driving mode can be set.

After the SPORT driving mode is activated, select "Configure SPORT" on the displayed panel and configure the program.

SPORT can also be configured before it is activated:

- 1. "Settings"
- 2. "SPORT mode" or: "Driving mode"
- 3. Configure driving mode.

The configuration is stored for the profile currently used.

This configuration is retrieved when the SPORT driving mode is activated.

#### COMFORT

For a balanced tuning with maximum driving stabilization.

# **Activating COMFORT**



Press button repeatedly until COM-FORT is displayed in the instrument

In certain situations, the system automatically changes to the NORMAL program, automatic program change, refer to page 146.

#### **COMFORT+**

Comfort-oriented tuning of the shock absorbers and adapted engine control for optimal traveling comfort with maximum driving stabilization.

#### **COMFORT+** activation



Press button repeatedly until COM-FORT+ is displayed in the instrument cluster.

#### **ECO PRO**

ECO PRO, refer to page 204, provides consistent tuning to minimize fuel consumption for maximum range with maximum driving stabilization.

Comfort functions and the engine controller are adjusted.

The program can be configured to individual specifications.

#### Activating ECO PRO



Press button repeatedly until ECO PRO is displayed in the instrument cluster.

# **Configuring ECO PRO**

- Activate FCO PRO.
- "Configure ECO PRO"

Make the desired settings.

# Configure driving mode

Settings can be made for the following driving modes in Driving mode:

- SPORT driving mode, refer to page 147.
- ECO PRO driving mode, refer to page 205.

# Displays in the instrument cluster

# Selected program



The instrument cluster displays the selected program.

# **Program selection**



Pressing the button displays a list of the selectable programs. Depending on your vehicle's optional features, the list in the instrument cluster can differ from

the illustration shown.

# **Display on the Control Display**

Program changes can be displayed briefly on the Control Display.

To do so, make the following settings:

- "Settings"
- 2. "Driving mode"
- "Driving mode info"

# **Driving comfort**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# Active Cruise Control with Stop&Go function, ACC

#### Concept

Using this system, a desired speed and a distance to a vehicle ahead can be adjusted using the buttons on the steering wheel.

The system maintains the desired speed on clear roads. For this purpose, the vehicle accelerates or brakes automatically.

If a vehicle is driving ahead of you, the system adjusts the speed of your vehicle within the given system limits so that the set distance to the vehicle ahead is maintained.

The distance can be adjusted in several steps. For safety reasons, it depends on the respective speed.

If the vehicle ahead of you brakes to a halt, and then proceeds to drive again within a brief period, the system is able to detect this within the given system limits.

#### **General information**

Depending on the driving settings, the features of the cruise control can change in certain areas.

# **Safety information**

**↑** W

WARNING

The system does not release from the personal responsibility to correctly assess the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

WARNING

An unsecured vehicle can begin to move and possibly roll away. There is a risk of an accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, observe the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, e.g., with a wheel chock. ◀

WARNING

The desired speed can be incorrectly adjusted or called up by mistake. There is a risk of an accident. Adjust the desired speed to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

WARNING

Risk of accident due to too high speed differences to other vehicles, e.g., in the following situations:

- When fast approaching a slowly moving vehicle.
- Suddenly swerving vehicle onto the own lane.

When fast approaching standing vehicles.

There is a risk of injuries or danger to life. Watch traffic closely and actively intervene in the respective situations. ◀

#### **Overview**

# **Buttons on the steering wheel**

# **Button Function**



Cruise control on/off, interrupt, refer to page 150



Store/maintain speed, refer to page 151



Resume speed, continue cruise control, refer to page 152



Reduce distance, refer to page 152



Increase distance, refer to page 152



Rocker switch:

Set speed, refer to page 151

#### Radar sensor


A radar sensor is located in the front bumper for detecting vehicles on the road ahead of the vehicle.



Always keep radar sensor clean and unobstructed.

#### Camera

A camera serves to detect vehicles.



The camera is installed near the interior mirror.

Keep the windshield in front of the interior mirror clean and clear.

# **Functional requirements**

# **Speed range**

The system is best used on well-constructed roads.

The minimum speed that can be set is 20 mph/30 km/h. The maximum speed that can be set depends on the vehicle.

The system can also be activated when stationary.

# Switching on/off and interrupting cruise control

# Switching on



Press button on the steering wheel.

The indicator lights in the instrument cluster light up and the mark in the speedometer is set to the current speed.

Cruise control can be used.

DSC will be switched on, if needed.

# **Switching off**

To switch off the system while standing, step on brake pedal at the same time.



Press button on the steering wheel.

- If active: press twice.
- If interrupted: press once.

The displays go out. The stored desired speed is deleted.

# Interrupting manually



Press button on the steering wheel.

If interrupting the system while stationary, press on the brake pedal at the same time.


# Interrupting automatically

The system is automatically interrupted in the following situations:

- When the driver applies the brakes.
- When the clutch pedal is depressed.
- When selector lever position D is disengaged.
- When DTC is activated or DSC is deactivated.
- When DSC is actively controlling stability.
- When SPORT+ is activated with Driving Dynamics Control.
- If the safety belt is unbuckled and the driver's door is opened while the vehicle is standing still.
- If the system has not detected objects for an extended period, e.g., on a road with very little traffic without curb or shoulder markings.
- ▶ If the detection range of the radar is impaired, e.g., by dirt or heavy fog.
- After a longer stationary period when the vehicle has been braked to a stop by the system.

# Setting the speed

#### Maintaining/storing the speed



Press the rocker switch while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the desired speed.

The stored speed is displayed in the speedometer and briefly in the instrument cluster, refer to page 152.


DSC will be switched on, if needed.



The speed can also be stored by pressing a button.

Press button.

# **Changing the speed**



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

- Each time the rocker switch is pressed to the point of resistance, the desired speed increases or decreases by approx.
   1 mph/1 km/h.
- ▶ Each time the rocker switch is pressed past the point of resistance, the desired speed increases or decreases by a maximum of 5 mph/10 km/h.

Hold the rocker switch in position to repeat the action.

# **Adjusting distance**

#### Safety information

WARNING
The system does not release from the personal responsibility. Due to the system lim-

personal responsibility. Due to the system limits, braking can be late. There is a risk of accidents or risk of property damage. Be aware to the traffic situation at all times. Adjust the distance to the traffic and weather conditions and maintain the prescribed safety distance, possibly by braking.◀

#### Reduce distance



Press button repeatedly until the desired distance is set.

Instrument cluster will display selected distance, refer to page 152.

#### Increase distance



Press button repeatedly until the desired distance is set.

Instrument cluster will display selected distance, refer to page 152.

# **Continuing cruise control**

#### **General information**

An interrupted cruise control can be continued by calling up the stored speed.

Make sure that the difference between current speed and stored speed is not too large before calling up the stored speed. Otherwise, unintentional braking or accelerating may occur.

In the following cases, the stored speed value is deleted and cannot be called up again:

- When the system is switched off.
- When the ignition is switched off.

# Calling up stored speed and distance



Press button with the system switched on.

# Displays in the instrument cluster

# Desired speed and stored speed



- Marking lights up green: system is active, the marking indicates the desired speed.
- Marking lights up orange: system is interrupted, the marking indicates the stored speed.
- The marking does not light up: the system is switched off.



With instrument display: the symbol is displayed in the speedometer similarly to the mark for the desired speed.

# **Brief status display**



Selected desired speed.

If no speed is indicated, it is possible that the conditions necessary for operation are not currently fulfilled.

# Distance to vehicle ahead of you

Selected distance to the vehicle ahead of you is shown.

# Distance display



Distance 1



Distance 2



Distance 3



Distance 4

This value is set automatically after the system is switched on.



The system has been interrupted or distance control is temporarily suppressed because the accelerator pedal is being pressed; a vehicle was not detected.



Distance control is temporarily suppressed because the accelerator pedal is being pressed; a vehicle was detected.

#### **Detected vehicle**



Symbol lights up orange:

A vehicle has been detected ahead of you.

Rolling bars: the detected vehicle has driven away.

ACC does not accelerate. To accelerate, activate ACC by briefly stepping on the accelerator pedal, pressing the RES button or rocker switch.

# **Indicator/warning lights**



Symbol flashes orange:

The conditions are not adequate for the system to work.

The system was deactivated but applies the brakes until you actively resume control by

pressing on the brake pedal or accelerator pedal.



Symbol flashes red and a signal sounds:

You are requested to intervene by braking or make an evasive maneuver.

# **Displays in the Head-up Display**

Some system information can also be displayed in the Head-up Display.

#### Distance information




The symbol is displayed when the distance from the vehicle traveling ahead is too short

The distance information is active under the following circumstances:

- Active Cruise Control switched off.
- Display in the Head-up Display selected, refer to page 104.
- Distance too short.
- Speed greater than approx. 40 mph/70 km/h.

# **System limits**

# **Detection range**



The detection capacity of the system and the automatic braking capacity are limited.


Two-wheeled vehicles for instance might not be detected.

#### **Deceleration**

The system also does not decelerate in the following situations:

- For pedestrians or similarly slow-moving road users.
- For red traffic lights.
- For cross traffic.
- For oncoming traffic.


# **Swerving vehicles**



A vehicle driving in front of you is not detected until it is completely within the same lane as your vehicle.

If a vehicle driving ahead of you suddenly swerves into your lane, the system may not be able to automatically restore the selected distance. This also applies to major speed differences to vehicles driving ahead of you, e.g., when rapidly approaching a truck. When a vehicle driving ahead of you is reliably detected, the system requests that the driver intervene by braking and carrying out evasive maneuvers, if needed.

# **Cornering**



If the desired speed is too high for a curve, the speed is reduced slightly, although curves cannot be anticipated in advance. Therefore, drive into a curve at an appropriate speed.

In tight curves the system offers only restricted detection where a vehicle ahead of you might be detected late or not at all.



When you approach a curve the system may briefly report vehicles in the next lane due to the bend of the curve. If the system decelerates you may compensate it by briefly accelerating.

After releasing the accelerator pedal the system is reactivated and controls speed independently.

# **Driving away**

In some situations, the vehicle cannot drive off automatically; for example:

- On steep inclines.
- From bumps in the road.

In these cases, step on the accelerator pedal.

#### Weather

In the event of unfavorable weather and light conditions, e.g., if there is rain, snowfall, slush, fog or glare, this may result in poorer recognition of vehicles as well as short-term interruptions for vehicles that are already detected. Drive attentively, and react to the current traffic situation. If necessary, intervene actively, e.g., by braking, steering or evading.

# **Engine power**

The desired speed is also maintained downhill, but may not be maintained on uphill grades if engine power is insufficient.

#### Malfunction

The system cannot be activated if the radar sensor is not aligned correctly. This may be caused by damage incurred, e.g., during parking.

A Check Control message is displayed if the system fails.

The function for detecting and responding when approaching stationary vehicles may be limited in the following situations:

- During calibration of the camera immediately after vehicle delivery.
- If the camera is malfunctioning or dirty. A Check Control message is displayed.

# **Cruise control**

# The concept

Using this system, a desired speed can be adjusted using the buttons on the steering wheel. The system maintains the desired speed. The system accelerates and brakes automatically as needed.

#### **General information**

Depending on the driving settings, the features of the cruise control can change in certain areas.

# **Safety information**

 $\Lambda$ 

WARNING

The system does not release from the personal responsibility to correctly assess the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

# $\Lambda$

WARNING

The use of the system can lead to an increased risk of accidents in the following situations:

- On winding roads.
- In heavy traffic.
- On slippery roads, in fog, snow or rain, or on a loose road surface.

There is a risk of accidents or risk of property damage. Only use the system if driving at constant speed is possible. ◄

# lack

WARNING

The desired speed can be incorrectly adjusted or called up by mistake. There is a risk of an accident. Adjust the desired speed to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

#### **Overview**

# **Buttons on the steering wheel**

Press but- ton	Function
<b>්</b> ග	Cruise control on/off, interrupting, refer to page 156.
SET	Store/maintain speed, refer to page 156.

Press but- ton	Function
RES	Resume speed, continue cruise control, refer to page 157.
	Rocker switch: Set speed, refer to page 157.

# Switching on/off and interrupting cruise control

# Switching on



Press button on the steering wheel.

The marking in the speedometer is set to the current speed.

The cruise control can be used.

DSC will be switched on if needed.

# **Switching off**



Press button on the steering wheel.

- If active: press twice.
- If interrupted: press once.

The displays go out. The stored desired speed is deleted.

# Interrupting manually



When active, press the button.

# **Automatic interruption**


The system is automatically interrupted in the following situations:

- When the driver applies the brakes.
- If the clutch pedal is depressed for a few seconds or released while a gear is not engaged.
- ▶ If the gear engaged is too high for the current speed.

- When selector lever position D is disengaged.
- When DTC is activated or DSC is deactivated.
- When DSC is actively controlling stability.
- If HDC is activated.
- When SPORT+ is activated with Driving Dvnamics Control.

# Setting the speed

# Maintaining/storing the speed



Press the rocker switch while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the desired speed.

This is displayed in the speedometer and briefly in the instrument cluster, refer to page 157.


DSC will be switched on if needed.



The speed can also be stored by pressing a button.

Press button.

# **Changing the speed**



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

- Each time the rocker switch is pressed to the point of resistance, the desired speed increases or decreases by approx.
   1 mph/1 km/h.
- Each time the rocker switch is pressed past the point of resistance, the desired speed increases or decreases by a maximum of 5 mph/10 km/h.
  - The maximum speed that can be set depends on the vehicle.
- Pressing the rocker switch to the resistance point and holding it accelerates or decelerates the vehicle without requiring pressure on the accelerator pedal.
  - After the rocker switch is released, the vehicle maintains its final speed. Pressing the switch beyond the resistance point causes the vehicle to accelerate more rapidly.

# **Continuing cruise control**

#### **General information**

An interrupted cruise control can be continued by calling up the stored speed.

Make sure that the difference between current speed and stored speed is not too large before calling up the stored speed. Otherwise, unintentional braking or accelerating may occur. In the following cases, the stored speed value is deleted and cannot be called up again:

- When the system is switched off.
- When the ignition is switched off.

# Calling up stored speed



Press button.

The stored speed is reached and maintained.

# Displays in the instrument cluster

# **Indicator lamp**



Depending on how the vehicle is equipped, the indicator lamp in the instrument cluster indicates whether the sys-

tem is switched on.

# **Desired speed and stored speed**



- Marking lights up green: system is active, the marking indicates the desired speed.
- Marking lights up orange: system is interrupted, the marking indicates the stored speed.
- The marking does not light up: the system is switched off.



With instrument display: the symbol is displayed in the speedometer similarly to the mark for the desired speed.

# **Brief status display**



Selected desired speed.

If no speed is indicated, it is possible that the conditions necessary for operation are not currently fulfilled.

# **Displays in the Head-up Display**

Some system information can also be displayed in the Head-up Display.

# System limits

#### **Engine power**

The desired speed is also maintained downhill, but may not be maintained on uphill grades if engine power is insufficient.

# **PDC Park Distance Control**

# Concept

PDC is a support when parking. When you slowly approach an object in the rear - or also in the front of the vehicle if the feature is available - then the object is reported through:

- Signal tones.
- Visual display.

### **General information**

The ultrasound sensors for measuring the distances are located in the bumpers.

The maneuvering range, depending on the obstacle and environmental conditions, is approx. 6 ft/2 m.

An acoustic warning is first given in the following situations:

- By the front sensors and the two rear corner sensors at approx. 24 in/60 cm from the object.
- By the rear middle sensors at a distance to the object of approx. 5 ft/1.50 m.
- When a collision is imminent.

# Safety information WARNING

The system does not release from the personal responsibility to correctly assess the traffic situation. Based on the limits of the system, it cannot independently react to all traffic

situations. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

**∧** WARNING

Due to high speeds when PDC is activated, the warning can be delayed due to physical circumstances. There is a risk of injury or risk of property damage. Avoid approaching an object too fast. Avoid driving off fast while PDC is not yet active.

#### **Overview**

#### With front PDC: button in vehicle





Park assistance button

#### **Ultrasound sensors**



Ultrasound sensors of the PDC, e.g., in the bumpers.

# **Functional requirements**

To ensure full functionality:

- ▶ Do not cover sensors, e.g., with stickers, bicycle racks.
- Keep sensors clean and unobstructed.

# Switching on/off

# Switching on automatically

With the engine running, engage lever in position R.

The rearview camera also switches on.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

# With front PDC: switching on/off manually



Press park assistance button.

- ▷ On: the LED lights up.
- Off: the LED goes out.

The rearview camera image is displayed when the reverse gear is engaged when pressing the park assistance button.

#### **WARNING**

# Signal tones

When approaching an object, an intermittent sound indicates the position of the object. E.g., if an object is detected to the left rear of the vehicle, a signal tone sounds from the left rear speaker.

The shorter the distance to the object, the shorter the intervals.

If the distance to a detected object is less than approx. 10 inches/25 cm, a continuous tone is sounded.

With front PDC: if objects are located both in front of and behind the vehicle, an alternating continuous signal is sounded.

An interval tone is interrupted with the appropriate equipment after about 3 seconds:

- If the vehicle stops in front of an object that is detected by only one of the corner sensors.
- If moving parallel to a wall.

The signal tone is switched off, when selector lever position P is engaged on vehicles with Steptronic transmission.

#### Volume

The ratio of the PDC signal tone volume to the entertainment volume can be adjusted.

- 1. "Multimedia", "Radio" or "Settings"
- 2. "Tone"
- 3. "Volume settings"
- 4. "PDC"
- Turn the controller until the desired setting is selected.
- 6. Press the controller.

Settings are stored for the profile currently used.

# Visual warning

The approach of the vehicle to an object can be shown on the Control Display. Objects that are farther away are already displayed on the Control Display before a signal sounds.

A display appears as soon as Park Distance Control (PDC) is activated.

The range of the sensors is represented in the colors green, yellow and red.

When the image of the rearview camera is displayed, the switch can be made to PDC:

rc "Rear view camera"

# System limits

# **Safety information**

**№** WARNING

The system can react incorrectly or not at all due to the system limits. There is a risk of accidents or risk of property damage. Observe

the information regarding the system limits and actively intervene, if needed. ◀

#### Limits of ultrasonic measurement

Ultrasonic measurements might not function in the following situations:

- For small children and animals.
- For persons with certain clothing, e.g., coats.
- With external interference of the ultrasound, e.g., from passing vehicles or loud machines.
- When sensors are dirty, iced over, damaged or out of position.
- Under certain weather conditions such as high relative humidity, rain, snowfall, extreme heat or strong wind.
- With tow bars and trailer couplings of other vehicles.
- ▶ With thin or wedge-shaped objects.
- With moving objects.
- With elevated, protruding objects such as ledges or cargo.
- With objects with corners and sharp edges.
- With objects with a fine surface structure such as fences.
- For objects with porous surfaces.
- If cargo protrudes.
- Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

# **False warnings**

The system may issue a warning under the following conditions even though there is no obstacle within the detection range:

- In heavy rain.
- When sensors are very dirty or covered with ice.
- When sensors are covered in snow.

- On rough road surfaces.
- On uneven surfaces, such as speed bumps.
- In large buildings with right angles and smooth walls, e.g., in underground garages.
- In automatic vehicle washes.
- Due to heavy exhaust.
- Due to other ultrasound sources, e.g., sweeping machines, high pressure steam cleaners or neon lights.

#### Malfunction

A Check Control message is displayed.

The range of the sensors is shown as a shaded area on the Control Display.

PDC has failed. Have the system checked.

# **Surround View**

# Concept

Surround View comprises various camera assistance systems that help the driver when parking, maneuvering, and at complex exits and intersections.

- Rearview camera, refer to page 160
- Side View, refer to page 163.
- Top View, refer to page 164.

# **Rearview camera**

# Concept

The rearview camera provides assistance in parking and maneuvering backwards. The area behind the vehicle is shown on the Control Display.

# **Safety information**

WARNING

The system does not relieve from the personal responsibility to correctly assess the traffic situation. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene in the respective situations.

#### Overview

#### **Button in the vehicle**





Park assistance button

#### Camera



The camera lens is located in the handle of the tailgate. The image quality may be impaired by dirt.

Clean the camera lens if necessary.

# Switching on/off

# Switching on automatically

The system is switched on automatically if selector lever position R is engaged when the engine is running.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

# Switching on/off manually



Press park assistance button.

- ▷ On: the LED lights up.
- Off: the LED goes out.

The PDC is shown on the Control Display.

The rearview camera image is displayed when the reverse gear is engaged when pressing the park assistance button.

# Switching the view via iDrive

With PDC activated or Top View switched on:

#R "Rear view camera"

The rearview camera image is displayed.

# **Display on the Control Display**

# **Functional requirement**

- > The rearview camera is switched on.
- The tailgate is fully closed.
- Keep the recording range of the camera clear. Protruding cargo or carrier systems and trailers that are not connected to a trailer power socket can lead to malfunctions.

# **Activating assistance functions**

More than one assistance function can be active at the same time.

- Parking aid lines
  - "Parking aid lines"


Lanes and turning radius are indicated.

- Obstacle marking
  - <sup>₱</sup>

    ☐ "Obstacle marking"

Spatially-shaped markings are displayed.

# **Pathway lines**



Pathway lines can be superimposed on the image of the rearview camera.

Pathway lines help you to estimate the space required when parking and maneuvering on level roads.

Pathway lines depend on the current steering angle and are continuously adjusted to the steering wheel movements.

# **Turning radius lines**




Turning radius lines can only be superimposed on the rearview camera image together with pathway lines.

Turning radius lines show the course of the smallest possible turning radius on a level road.

Only one turning radius line is displayed after the steering wheel is turned past a certain angle.

# **Obstacle marking**




Obstacle markings can be faded into the image of the rearriew camera.


The colored thresholds of the obstacle markings match the markings of the PDC.

# Parking using pathway and turning radius lines

 Position the vehicle so that the turning radius lines lead to within the limits of the parking space.



Turn the steering wheel to the point where the pathway line covers the corresponding turning radius line.



#### **Display settings**

# **Brightness**

With the rearview camera switched on:

- 1. Select the symbol.
- 2. Turn the controller until the desired setting is reached, and press the controller.

#### **Contrast**

With the rearview camera switched on:

- 2. Turn the controller until the desired setting is reached, and press the controller.

# **System limits**

# **Detection of objects**

Very low obstacles as well as high, protruding objects such as ledges may not be detected by the system.

Assistance functions also take into account data of the PDC.

Follow instructions in the PDC chapter.

The objects displayed on the Control Display may be closer than they appear. Do not estimate the distance from the objects on the display.

# **Side View**

#### Concept

Side View provides an early look at cross traffic at blind driveways and intersections. Road users concealed by obstacles to the left and right of the vehicle can only be detected relatively late from the driver's seat. To improve visibility, two cameras in the front of the vehicle record the traffic situation on each side. The images from both cameras are shown simultaneously on the Control Display.

# **Safety information**

WARNING

The system does not relieve from the personal responsibility to correctly assess the traffic situation. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene in the respective situations.

#### Overview

#### **Button in the vehicle**





Side View

#### **Cameras**



Two cameras integrated in the bumpers capture the image.

The two camera lenses are located on the sides of the bumper.

The image quality may be impaired by dirt. If required, clean the camera lenses.

# Switching on/off

### Switching on/off manually



Press button.


# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

# **Display**

The traffic area to the left and right is displayed on the Control Display.



Guidelines at the bottom of the image show the position of the front of the vehicle.

#### **Brightness**

With the Side View switched on:

- 1. 🌣 "Brightness"
- 2. Turn the Controller until the desired setting is reached, and press the Controller.

#### **Contrast**

With the Side View switched on:

- Contrast"
- 2. Turn the Controller until the desired setting is reached, and press the Controller.

# System limits

The cameras capture a maximum range of 330 ft/100 m.

# **Top View**

# The concept

Top View provides assistance in parking and maneuvering. The area around the doors and the road area around the vehicle are shown on the Control Display for this purpose.

#### **General information**

The image is captured by two cameras integrated in the exterior mirrors and by the rearview camera.

The range is at least 7 ft/2 m to the side and rear.

In this way, obstacles up to the height of the exterior mirrors are detected early.

### **Safety information**



#### WARNING

The system does not relieve from the personal responsibility to correctly assess the traffic situation. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene in the respective situations.

#### **Overview**

#### **Button in the vehicle**





Park assistance button

#### **Cameras**



Cameras at the bottom in the mirror housings.



Rearview camera

The image quality may be impaired by dirt. If required, clean the camera lenses.

# Switching on/off

# Switching on automatically

The system is switched on automatically if selector lever position R is engaged when the engine is running.

The rearview camera image is displayed. To switch to the Top View:

"Rear view camera"

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

# Switching on/off manually



Press park assistance button.

- ▷ On: the LED lights up.
- Off: the LED goes out.

Top View is displayed.

The rearview camera image is displayed when the reverse gear is engaged when pressing the park assistance button.

# **Display**

# Visual warning

The approach of the vehicle to an object can be shown on the Control Display.

When the distance to an object is small, a red bar is shown in front of the vehicle, as it is in the PDC display.



The display appears as soon as Top View is activated

When the image of the rearview camera is displayed, it is possible to switch to top view:

r® "Rear view camera"

# **Brightness**

With Top View switched on:

- 1. Select the symbol.
- Turn the controller until the desired setting is reached, and press the controller.

#### Contrast

With Top View switched on:

- 1. Select the symbol.
- Turn the controller until the desired setting is reached, and press the controller.

# Displaying the turning radius and pathway lines

The static, red turning radius line shows the space needed to the side of the vehicle when the steering wheel is turned all the way. The variable, green pathway line assists you in assessing the amount of space actually needed to the side of the vehicle.

The lane line depends on the engaged gear and the current steering angle. The track line is continuously adjusted for the steering wheel movement.

"Parking aid lines"

Turning circle and pathway lines are displayed.

#### **System limits**


Top View cannot be used in the following situations:

- With a door open.
- With the tailgate open.
- ▶ With an exterior mirror folded in.
- ▶ In poor light.

A Check Control message is displayed in some of these situations.

# Parking assistant

# Concept



This system assists the driver in parking parallel to the road.

#### **General information**

Parking assistant handling is divided into three steps:

- Switching on and activating.
- Parking space search.
- Parking.

System status and instructions on required actions are displayed on the Control Display.

Ultrasound sensors measure parking spaces on both sides of the vehicle.

#### Manual transmission:

The parking assistant calculates the best possible parking line and takes control of steering during the parking procedure.

#### Steptronic transmission:

The parking assistant calculates the best possible parking line and during the parking procedure takes control of steering, the acceleration and braking, and if needed, changes the gears. Press and hold the park assistance button for the duration of the parking procedure.

The parking assistant uses the sensors of PDC Park Distance Control. Also observe the safety information for PDC Park Distance Control.

# **Safety information**

WARNING

The system does not release from the personal responsibility to correctly assess the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of an accident. Adjust the driving style to the traffic conditions. Watch traffic closely and actively intervene in the respective situations.

# NOTE

The parking assistant can steer the vehicle over or onto curbs. There is a risk of property damage. Watch traffic closely and actively intervene in the respective situations.

#### **Overview**

#### Button in the vehicle





Park assistance button

#### **Ultrasound sensors**



The ultrasound sensors for measuring parking spaces are located on the side of the vehicle.

# **Functional requirements**

#### **Ultrasound sensors**

To ensure full functionality:

- Do not cover sensors, e.g., with stickers.
- Keep sensors clean and unobstructed.

# For measuring parking spaces

- Maximum speed while driving forward approx. 22 mph/35 km/h.
- Maximum distance to row of parked vehicles: 5 ft/1.5 m.

# Suitable parking space

- Gap between two objects with a minimum length of approx. 5 ft/1.5 m.
- Min. length of gap between two objects: your vehicle's length plus approx.
   4 ft/1.2 m.
- Minimum depth: approx. 5 ft/1.5 m.

# For parking

- Doors and tailgate are closed.
- The parking brake is released.
- When parking in parking spaces on the driver's side, the corresponding turn signal must be set where applicable.

#### Steptronic transmission:

Driver's safety belt is fastened.

# Switching on and activating

# Switching on with the button



Press park assistance button.

The LED lights up.

The current status of the parking space search is indicated on the Control Display.

Parking assistant is activated automatically.

# Switching on with reverse gear

Shift into reverse.

The current status of the parking space search is indicated on the Control Display.


To activate: Parking Assistant"

# **Display on the Control Display**

# System activated/deactivated

# Symbol Meaning Po Gray: the system is not available. White: the system is available but not activated. Po The system is activated.

# Parking space search and system status



- Colored symbols, see arrows, on the side of the vehicle illustrated. Parking assistant is activated and search for parking space active.
- Control Display shows suitable parking spaces at the edge of the road next to the vehicle symbol. When the parking assistant is active, suitable parking spaces are highlighted.
- P

The parking procedure is active. Steering control has been taken over by system.

Parking space search is always active whenever the vehicle is moving forward slow and straight, even if the system is deactivated. When the system is deactivated, the displays on the Control Display are shown in gray.

# Parking using the parking assistant

# **Parking**

- 1. Press park assistance button or shift into reverse gear to switch the parking assistant on, refer to page 168. Activate the parking assistant, if needed.
  - Parking assistant is activated.
- Pass the row of parked vehicles at a speed of up to approx. 22 mph/35 km/h and at a distance of maximum 5 ft/1.5 m.
  - The status of the parking space search and possible parking spaces are displayed on the Control Display, refer to page 168.
- Follow the instructions on the Control Display.

Manual transmission:

The best possible parking position will come after gear change on the stationary vehicle - wait for the automatic steering wheel move.

Steptronic transmission:

Press and hold the park assistance button for the duration of the parking procedure. At the end of the parking procedure, the P selector lever position is set.

The end of the parking procedure is indicated on the Control Display.

 Adjust the parking position yourself, if needed.

# Interrupting manually

The parking assistant can be interrupted at any time:

- P P//<u>▲</u>
- Press park assistance button.
- ▶ Parking Assistant" Select the symbol on the Control Display.

# Interrupting automatically

The system is interrupted automatically in the following situations:

- ▶ If the driver grasps the steering wheel or takes over steering.
- ▶ If a gear is selected that does not match the instruction on the Control Display.
- If the vehicle speed exceeds approx.6 mph/10 km/h.
- Possibly on snow-covered or slippery road surfaces.
- When there are obstacles that are hard to overcome, such as curbs.
- When there are obstacles that suddenly appear.
- If the Park Distance Control PDC displays clearances that are too small.
- If a maximum number of parking attempts or the time taken for parking is exceeded.
- ▶ If a turn signal has been actuated contrary to the desired side for parking.
- When switching to another function on the Control Display.

#### Steptronic transmission:

- When the park assistance button is released.
- If the tailgate is open.
- If doors are open.
- When setting the parking brake.
- During acceleration.
- When braking.
- ▶ When unfastening the driver's safety belt.

A Check Control message is displayed.

# Resuming

An interrupted parking procedure can be continued, if needed.

Reactivate the parking assistant, refer to page 168, and follow the instructions on the Control Display.

# Switching off

The system can be switched off as follows:



Press park assistance button.

Switching off the ignition.

# **System limits**

# **Safety information**

WARNING

The system can react incorrectly or not at all due to the system limits. There is a risk of accidents or risk of property damage. Observe the information regarding the system limits and actively intervene, if needed. ◄

# No parking assistance

The parking assistant does not offer assistance in the following situations:

In tight curves.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- On bumpy road surfaces such as gravel roads.
- On slippery ground.
- On steep uphill or downhill grades.
- With accumulations of leaves/snow in the parking space.
- With ditches or edges, e.g., an edge of a port.

# **Limits of ultrasonic measurement**

Ultrasonic measurements might not function in the following situations:

- For small children and animals.
- For persons with certain clothing, e.g., coats.
- With external interference of the ultrasound, e.g., from passing vehicles or loud machines.

- When sensors are dirty, iced over, damaged or out of position.
- Under certain weather conditions such as high relative humidity, rain, snowfall, extreme heat or strong wind.
- With tow bars and trailer couplings of other vehicles.
- With thin or wedge-shaped objects.
- With moving objects.
- With elevated, protruding objects such as ledges or cargo.
- With objects with corners and sharp edges.
- With objects with a fine surface structure such as fences.
- ▶ For objects with porous surfaces.
- If cargo protrudes.
- Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

Parking spaces that are not suitable may be detected or suitable parking spaces may not be detected at all.

#### Malfunction

A Check Control message is displayed.


The parking assistant failed. Have the system checked.

# **Climate control**

# Vehicle features and options

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **Automatic climate control**



- 1 Air distribution, left
- 2 Temperature, left
- 3 AUTO program, left
- 4 Air flow, AUTO intensity, left, residual heat
- 5 Remove ice and condensation
- 6 Maximum cooling
- 7 Display
- 8 Air flow, AUTO intensity, right
- 9 AUTO program, right
- 10 Temperature, right

- 11 Air distribution, right
- **12** Seat heating, right **56**
- 13 Active seat ventilation, right 57
- 14 Automatic recirculated-air control/recirculated-air mode
- **15** Air conditioning
- 16 Rear window defroster
- 17 SYNC program
- **18** Active seat ventilation, left 57
- **19** Seat heating, left **56**

#### Climate control functions in detail

# Switching the system on/off


#### Switching on

Press any button except:

- Rear window defroster.
- Left side of Air flow button.
- Seat heating.
- Seat ventilation.
- If necessary, SYNC program.

#### **Switching off**

Complete system:



On the front passenger side:



Press and hold the left button on the front passenger side.

# **Temperature**



Turn the ring to set the desired temperature.

The automatic climate control achieves this temperature as quickly as possible, if needed, by using the maximum cooling or heating capacity, and then keeps it constant.

Do not rapidly switch between different temperature settings. Otherwise, the automatic climate control will not have sufficient time to adjust the set temperature.

# Air conditioning

The air in the vehicle's interior will be cooled and dehumidified and, depending on the temperature setting, warmed again.

The vehicle's interior can only be cooled with the engine running.



Press button.

Air conditioning is switched on or off.

Depending on the weather, the windshield and side windows may fog up briefly when the engine is started.

The cooling function is switched on automatically with the AUTO program.

When using the automatic climate control, condensation water, refer to page 199, develops and drains underneath the vehicle. This is normal.

# **Maximum cooling**

Press button.

The system is set to the lowest temperature, optimum air flow and recirculated-air mode.

Air flows out of the vents to the upper body region. The vents need to be open for this.

The function is available above an external temperature of approx. 32 °F/0 °C and with the engine running is indicated.

The air flow can be adjusted with the air flow active.

# **AUTO** program

Press button.

Air flow, air distribution and temperature are controlled automatically.

Depending on the selected temperature, the intensity of the AUTO program, and outside influences, the air is directed to the windshield, side windows, upper body, and into the floor area.

The cooling function, refer to page 172, is switched on automatically with the AUTO program.

At the same time, a condensation sensor controls the program so as to prevent window condensation as much as possible.

# **Intensity of the AUTO program**

With the AUTO program activated, the automatic intensity control can be changed.



Press the left or right side of the button: decrease or increase intensity.

The selected intensity is shown on the display of the automatic climate control.

# Automatic recirculated-air control/ recirculated-air mode

You may react to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the air currently within the vehicle.



Press button repeatedly to select an operating mode:

- LEDs off: outside air flows in continuously.
- Left LED on, automatic recirculated-air control: a sensor detects pollutants in the outside air and shuts off automatically.
- Right LED on, recirculated-air mode: the supply of outside air into the vehicle is permanently blocked.

With constant recirculated-air mode, the air quality in the vehicle's interior deteriorates and the fogging of the windows increases.

If the windows are fogged over, switch off the recirculated-air mode and press the AUTO button on the driver's side to utilize the condensation sensor. Make sure that air can flow to the windshield.

# Air flow, manual

To manually adjust air flow turn off AUTO program first.



Press the left or right side of the button: decrease or increase air flow.

The selected air flow is shown on the display of the automatic climate control.

The air flow of the automatic climate control may be reduced automatically to save battery power.

#### Manual air distribution



Press button repeatedly to select a program:

- Upper body region.
- Upper body region and floor area.
- Floor area.
- Windows and floor area.
- Windows, upper body region, and floor area.
- ▶ Windows: driver's side only.
- Windows and upper body region.

If the windows are fogged over, press the AUTO button on the driver's side to utilize the condensation sensor.

#### **SYNC** program



The current settings on the driver's side for temperature, air flow, air distri-

bution, and AUTO program are transferred to the front passenger side and to the left and right rear.

The program is switched off if the settings on the front passenger side or in the rear are changed.

#### Residual heat

The heat stored in the engine is used to heat the interior.

#### **Functional requirement**

- ▶ Up to 15 minutes after switching off the engine.
- Warm engine.
- ▶ The battery is sufficiently charged.
- ▶ External temperature below 77 °F/25 °C.

The availability of the function is shown on the display of the automatic climate control.

#### **Switching on**

- 1. Switching off the ignition.
- 2. Press the right side of the button on the driver's side.

The symbol appears on the automatic climate Control Display.

The interior temperature, air flow and air distribution can be adjusted with the ignition switched on.

# **Switching off**

At the lowest fan speed, press the left side of the button on the driver's side.

The symbol on the display of the automatic climate control flashes.

# Defrosting windows and removing condensation

W

Press button.

lce and condensation are quickly removed from the windshield and the front side windows.

For this purpose, point the side vents towards the side windows as needed.

The air flow can be adjusted with the air flow active.

If the windows are fogged over, you can also switch on the cooling function or press the AUTO button to utilize the condensation sensor.

# Rear window defroster

Press button.

The rear window defroster switches off automatically after a certain period of time.

#### Microfilter/activated-charcoal filter


The microfilter removes dust and pollen from the incoming air.

The activated-charcoal filter removes gaseous pollutants from the outside air that enters the vehicle.

This combined filter should be replaced during maintenance, refer to page 250, of the vehicle.

# Ventilation

#### Front ventilation



➤ Thumbwheels to vary the ventilation temperature in the upper body region, arrow 1.

Toward blue: colder.

Toward red: warmer.

This does not change the set interior temperature for the driver and front passenger.

- Lever for changing the air flow direction, arrow 2.
- ➤ Thumbwheels for opening and closing the vents continuously, arrows 3.

#### Ventilation levels

Draft-free ventilation:

Thumbwheel, arrow 3, in level  $\subset$ : the air current is fanned out.

Maximum air flow:

Thumbwheel, arrow 3, in level €: the air is partially fanned out and partially bundled. This maximizes the air supply.


#### Direct ventilation:

Thumbwheel, arrow 3, in level →: the air is bundled and can be directed to a specific point.

# Adjusting the ventilation

- Ventilation for cooling:
  - Direct vent in your direction when vehicle's interior is too hot.
- Draft-free ventilation:Adjust the vent to let the air flow past you.

# Ventilation in rear, center




Thumbwheels to vary the temperature, arrow 1.

Toward blue: colder.

Toward red: warmer.

- Lever for changing the air flow direction, arrow 2.
- ▶ Thumbwheels for continuous opening and closing of the vents, arrow 3.

# Ventilation, side



- Thumbwheel for continuous opening and closing of the vents, arrow 1.
- Lever for changing the air flow direction, arrow 2.

# Rear automatic climate control

#### Overview



- 1 Temperature
- 2 AUTO program
- 3 Vent settings
- 4 Air flow, AUTO intensity
- 5 Display
- 6 Maximum cooling
- 7 Seat heating 57

# Switching the rear automatic climate control on/off

- 1. "Settings"
- 2. "Climate"

#### 3. "Rear climate"

The rear automatic climate control is not operational if the automatic climate control is switched off or if the function for defrosting or defogging the windows is active.

# Switching the system on/off

# **Switching on**

Press any button except:

- Left side of Air volume button.
- Seat heating.

# **Switching off**



Press and hold the left button.

# **Temperature**



Turn the ring to set the desired temperature.

The automatic climate control achieves this temperature as quickly as possible, if needed, by using the maximum cooling or heating capacity, and then keeps it constant.

Do not rapidly switch between different temperature settings. The automatic climate control will not have sufficient time to adjust the set temperature.

# **Maximum cooling**

Press button.

The system is set to the lowest temperature, maximum air flow and recirculated-air mode.

Air flows out of the vents to the upper body region. The vents need to be open for this.

Air is cooled as quickly as possible:

At an external temperature of approx. 32 °F/0 °C. When the engine is running.

# **AUTO** program

AUTO

Press button.

Air flow, air distribution, and temperature are controlled automatically:

Depending on the selected temperature, the AUTO intensity, and outside influences, the air is directed to the upper body and into the floor area.

The cooling function is switched on automatically with the AUTO program.

# Intensity of the AUTO program

With the AUTO program activated, the automatic intensity control can be changed:



Press the left or right side of the button: decrease or increase intensity.

The selected intensity is shown on the display of the automatic climate control.

# Air flow, manual

To manually adjust air flow turn off AUTO program first.



Press the left or right side of the button: decrease or increase air flow.

The selected air flow is shown on the display of the automatic climate control.

#### Manual air distribution

The air distribution can be adjusted to individual needs.



Press button repeatedly to select a program:

- Upper body region.
- Upper body region and floor area.
- Floor area.

# Parked-vehicle ventilation

# Concept

The parked-vehicle ventilation ventilates the vehicle interior and lowers its temperature, if needed.

#### **General information**

The parked-vehicle ventilation system is operated via iDrive.

#### **Functional requirements**

#### Parked-car ventilation

- Using the preset activation time or when operated directly: any external temperature.
- ▶ Battery is sufficiently charged. If parked-car ventilation is switched on, the vehicle battery will be discharged. Thus, limit the maximum activation time to save the vehicle battery. The system will be available again after engine starting and/or a short trip.
- Make sure that the vehicle's date and time are set correctly.

Open the vents to allow air to flow out.

# Switching on/off directly

On the Control Display:

- 1. "Settings"
- 2. "Climate"
- 3. "Activate comf. ventilation"
- **%** The symbol on the automatic climate control flashes if the system is switched on.

The system continues to run for some time after being switched off.

# Preselecting the switch-on time

On the Control Display:

- 1. "Settings"
- 2. "Climate"
- 3. "Timer 1:" or "Timer 2:"
- Set the desired time.

# Activating the activation time

On the Control Display:

- 1. "Settings"
- 2. "Climate"
- 3. "Activate timer 1" or "Activate timer 2"
- **%** The symbol on the automatic climate control lights up when the switch-on time is activated.
- **%** The symbol on the automatic climate control flashes when the system has been switched on.

The system will only be switched on within the next 24 hours. After that, it needs to be reactivated.

# Interior equipment

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **Universal Integrated Remote Control**

# Concept

The Universal Integrated Remote Control can operate up to 3 functions of remote-controlled systems such as garage door drives or lighting systems. The Universal Integrated Remote Control replaces up to 3 different hand-held transmitters. To operate the remote control, the buttons on the interior mirror must be programmed with the desired functions. The hand-held transmitter for the particular system is required in order to program the remote control.

Before selling the vehicle, delete the stored functions for the sake of security.

# **Safety information**

WARNING
Body parts can be jammed when operating remote-controlled systems, e.g., the garage door, using the integrated universal remote control. There is a risk of injury or risk of property damage. Make sure that the area of movement of the respective system is clear during programming and operation. Also follow

the safety instructions of the hand-held transmitter. ◄

# Compatibility



If this symbol is printed on the packaging or in the owner's manual of the system to be controlled, the system is


generally compatible with the Universal Integrated Remote Control.

If you have any questions, please contact:

- A dealer's service center or another qualified service center or repair shop.
- www.homelink.com on the Internet.

HomeLink is a registered trademark of Gentex Corporation.

#### Control elements on the interior mirror



- ▶ LED, arrow 1.
- ▶ Buttons, arrow 2.
- ▶ The hand-held transmitter, arrow 3, is required for programming.

# **Programming**

#### **General information**

- 1. Switch on the ignition.
- 2. Initial setup:

Press and hold the left and right button on the interior mirror simultaneously for ap-

proximately 20 seconds until the LED on the interior mirror flashes. This erases all programming of the buttons on the interior mirror.

- 3. Hold the hand-held transmitter for the system to be controlled approx. 1 to 3 inches/2.5 to 8 cm away from the buttons of the interior mirror. The required distance depends on the hand-held transmitter.
- Simultaneously press and hold the button of the desired function on the hand-held transmitter and the button to be programmed on the interior mirror. The LED on the interior mirror will begin flashing slowly.

Release both buttons as soon as the LED

flashes more rapidly. The LED flashing faster indicates that the button on the interior mirror has been programmed.

If the LED does not flash faster after at least 60 seconds, change the distance between the interior mirror and the hand-held

tween the interior mirror and the hand-held transmitter and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.

6. To program other functions on other buttons, repeat steps 3 to 5.

The systems can be controlled using the interior mirror buttons.

# Special feature of the rolling code wireless system

If you are unable to operate the system after repeated programming, please check if the system to be controlled features a rolling code radio system.

Read the system's owner's manual, or press the programmed button on the interior mirror longer. If the LED on the interior mirror starts flashing rapidly and then stays lit constantly for 2 seconds, the system features a rolling code radio system. Flashing and continuous illumination of the LED will repeat for approximately 20 seconds.

For systems with a rolling code radio system, the universal remote control and the system also have to be synchronized.

Please read the owner's manual to find out how to synchronize the system.

Synchronizing is easier with the aid of a second person.

Synchronizing the universal remote control with the system:

- Park the vehicle within range of the remote-controlled system.
- Program the relevant button on the interior mirror as described.
- Locate and press the synchronizing button on the system being programmed. You have approx. 30 seconds for the next step.
- 4. Hold down the programmed button on the interior mirror for approximately 3 seconds and then release it. If necessary, repeat this step up to three times in order to finish synchronization. Once synchronization is complete, the programmed function will be carried out.

# Reprogramming individual buttons

- 1. Switch on the ignition.
- 2. Press and hold the interior mirror button to be programmed.
- As soon as the interior mirror LED starts flashing slowly, hold the hand-held transmitter for the system to be controlled approx. 1 to 3 inches/2.5 to 8 cm away from the buttons of the interior mirror. The required distance depends on the hand-held transmitter.

- Likewise, press and hold the button of the desired function on the hand-held transmitter.
- Release both buttons as soon as the interior mirror LED flashes more rapidly. The
  LED flashing faster indicates that the button on the interior mirror has been programmed. The system can then be controlled by the button on the interior mirror.

If the LED does not flash faster after at least 60 seconds, change the distance and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.

# **Operation**

WARNING

Body parts can be jammed when operating remote-controlled systems, e.g., the garage door, using the integrated universal remote control. There is a risk of injury or risk of property damage. Make sure that the area of movement of the respective system is clear during programming and operation. Also follow the safety instructions of the hand-held transmitter.

The system, such as the garage door, can be operated using the button on the interior mirror while the engine is running or when the ignition is started. To do this, hold down the button within receiving range of the system until the function is activated. The interior mirror LED stays lit while the wireless signal is being transmitted.

# **Deleting stored functions**

Press and hold the left and right button on the interior mirror simultaneously for approximately 20 seconds until the LED flashes rap-

idly. All stored functions will be deleted. The functions cannot be deleted individually.

# **Sun visor**

#### Glare shield

Fold the sun visor down or up.

# Vanity mirror

A vanity mirror is located in the sun visor behind a cover. When the cover is opened, the mirror lighting switches on.

# **Ashtray/cigarette lighter**

# **Manual transmission: Front**

# **Opening**



Press on the cover.

# **Emptying**

Take out the insert.

# Lighter



Push in the lighter.

The lighter can be removed as soon as it pops back out.

#### WARNING

Contact with hot heating elements or the hot socket of the cigarette lighter can cause burns. Flammable materials can ignite if the cigarette lighter falls down or is held against the respective objects. There is a risk of fire and injuries. Hold the cigarette lighter by its handle. Make sure that children do not use the cigarette lighter and do not burn themselves, e.g., by carrying the remote control with you when exiting the vehicle.

### NOTE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of property damage. Replace the cigarette lighter or socket cover again after using the socket.

## **Steptronic transmission: Front**

# **Opening**



Press on the cover.

### **Emptying**

Take out the insert.

### Lighter



Press on the cover.

Push in the lighter.

The lighter can be removed as soon as it pops back out.

WARNING

Contact with hot heating elements or the hot socket of the cigarette lighter can cause burns. Flammable materials can ignite if the cigarette lighter falls down or is held against the respective objects. There is a risk of fire and injuries. Hold the cigarette lighter by its handle. Make sure that children do not use the cigarette lighter and do not burn themselves, e.g., by carrying the remote control with you when exiting the vehicle.

NOTE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of property damage. Replace the cigarette lighter or socket cover again after using the socket.

### Rear

### Lighter



Push in the lighter.

The lighter can be removed as soon as it pops back out.

### ■ WARNING

Contact with hot heating elements or the hot socket of the cigarette lighter can cause burns. Flammable materials can ignite if the cigarette lighter falls down or is held against the respective objects. There is a risk of fire and injuries. Hold the cigarette lighter by its handle. Make sure that children do not use the cigarette lighter and do not burn themselves, e.g., by carrying the remote control with you when exiting the vehicle.

**∧** NOTE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of property damage. Replace the cigarette lighter or socket cover again after using the socket.

# Connecting electrical devices

# **Safety information**

NOTE

Battery chargers for the vehicle battery can work with high voltages and currents, which means that the 12 volt on-board network can be overloaded or damaged. There is

a risk of property damage. Only connect battery chargers for the vehicle battery to the starting aid terminals in the engine compartment.

NOTE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of property damage. Replace the cigarette lighter or socket cover again after using the socket.

#### Sockets

### **General information**

The lighter socket can be used as a socket for electrical equipment while the engine is running or when the ignition is switched on.

The total load of all sockets must not exceed 140 watts at 12 volts.

Do not damage the socket by using non-compatible connectors.

# Safety information


NOTE

Battery chargers for the vehicle battery can work with high voltages and currents, which means that the 12 volt on-board network can be overloaded or damaged. There is a risk of property damage. Only connect battery chargers for the vehicle battery to the starting aid terminals in the engine compartment.

NOTE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of property damage. Replace the cigarette lighter or socket cover again after using the socket.

# Front center console: manual transmission



Press on the cover.

Remove the cover or cigarette lighter.

# Front center console: Steptronic transmission



Press on the cover.

Remove the cover or cigarette lighter.

#### Center armrest



Remove the cover.

### Rear center console



Remove the cover or cigarette lighter.

### In the front passenger floor area



Socket is located below the glove compartment.

To access the socket: fold open the cover.

# In the cargo area

The socket is located in the cover of the loading lip.

To access the socket: fold open the cover.

# **USB** interface/AUX-IN port

### Concept

Mobile devices with USB port can be connected to the USB interface.

A mobile audio device, e.g., a MP3 player, can be connected using the AUX-IN port.

#### General information

The following devices can be connected:


- Mobile phones supported by the USB interface.
  - The snap-in adapter features a separate USB port that is automatically connected when a compatible mobile phone is inserted.
- Audio devices with USB port, e.g., MP3 player.
- USB storage devices.
  - Common file systems are supported. FAT32 and exFAT are the recommended formats.

Information about compatible USB media can be found at www.bmwusa.com/bluetooth.

The following applications are possible:

- Exporting and importing driver profiles, refer to page 44.
- Playing music files via USB audio.
- Adding music files to the music collection and saving the music collection.
- Playing videos via USB video.
- Loading of software updates.

### **Overview**



The USB interface and the AUX-IN port are located in the center armrest.

# Connecting an external device

Observe the following when connecting:

- Do not use force when plugging the connector into the USB interface.
- Use a flexible adapter cable.

- Protect the USB storage device against mechanical damage.
- Due to the large number of USB media available on the market, it cannot be guaranteed that every device is operable on the vehicle.
- Do not expose USB media to extreme environmental conditions, such as very high temperatures; refer to the device owner's manual.
- Due to the many different compression techniques, proper playback of the media stored on the USB storage device cannot be guaranteed in all cases.
- A connected USB storage device will be supplied with charging current via the USB interface if the device supports this.
- To ensure proper transmission of the stored data, do not charge a USB storage device via the onboard socket, when it is connected to the USB interface.
- Depending on how the USB storage device should be used, settings may be required on the USB storage device, refer to the device owner's manual.

Non- compatible USB media:

- USB hard drives.
- USB hubs.
- USB memory card readers with multiple inserts.
- HFS-formatted USB media.
- MTP devices.
- Devices such as fans or lights.

# Through-loading system

### Concept

The cargo area can be enlarged by folding down the rear seat backrest.

The rear seat backrest is divided into two parts at a ratio of 60 to 40.

The sides can be folded down separately or together.

# **Safety information**

★ WARNING

Danger of jamming with folding down the backrests. There is a risk of injury or risk of property damage. Make sure that the area of movement of the rear backrest and the of the head restraint is clear prior to folding down.

WARNING

The stability of the child restraint system is limited or compromised with incorrect seat adjustment or improper installation of the child seat. There is a risk of injuries or danger to life. Make sure that the child restraint system fits securely against the backrest. If possible, adjust the backrest tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged. If possible, adjust the height of the head restraints or remove them.


### **Opening**

**∧** NOTE

Screens in the rear can be damaged when folding down the rear backrest. There is a risk of property damage. Before folding down

the rear backrest, make sure that the area of movement is clear.◀

- Unlock the belt lock of the center safety belt in the rear using the latch plate of another safety belt.
- Insert the latch plate at the end of the belt into the specially designated fixture on the rear window shelf.



- Push the corresponding head restraint down as far as it will go.
- Pull the corresponding lever in the cargo area to release the rear seat backrest.



The unlocked rear seat backrest moves forward slightly.



Fold backrest forward.

### Closing

 $\Lambda$ 

WARNING

With an unlocked backrest, an unsecured load can be thrown into the vehicle's interior, e.g., in case of an accident, braking or evasive maneuver. There is a risk of injury. Make sure that the backrest engages into the locking after folding it back.◀

- Return the rear seat backrest to the upright seating position and engage it.
- Release the belt tongue from the fixture on the rear window shelf.
- Insert the belt tongue in the belt lock of the center safety belt. Make sure you hear the latch plate engage.

To secure cargo, refer to page 201, with nets or draw straps, the cargo area is fitted with lashing eyes.

# Ski bag

## **Capacity**

The ski bag can be used to transport up to four pairs of skis with a length of up to 6 ft/2.10 m or, depending on the binding, up to two snow-boards with a length of up to 5 ft/1.60 m.

### Preparing and loading the ski bag

- 1. Fold open the center armrest on the inside.
- 2. Open the inside cover and cargo area by pressing the button.



Lay out the ski bag.

- 4. Load the ski bag. If necessary, wrap the sharp edges of the skis.
- 5. Insert the tongue plate into the belt buckle.



Tighten the retaining strap.



| WARNING

The content of the ski bag can compromise the vehicle occupants if it is not secured correctly, for example in case of an accident, braking or evasive maneuvers. There is risk of injuries or danger to life. Secure ski bag with the retaining strap.

# Removing the ski bag

The ski bag can be removed entirely, for example, to dry quickly or to use other inserts.



- 1. Pull the handle forward and lift the ski bag out.
- 2. Close the cover in the cargo area.

Detailed information regarding different inserts is available from a dealer's service center or another qualified service center or repair shop.

# **Storage compartments**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **Safety information**

WARNING
Loose objects or devices with a cable
connection to the vehicle, e.g., mobile phones,
can be thrown into the vehicle's interior while
driving, e.g., in the event of an accident or during braking and evasive maneuvers. There is a
risk of injury. Secure loose objects or devices
with a cable connection to the vehicle in the
vehicle's interior.

NOTE
Anti-slip pads such as anti-slip mats can damage the dashboard. There is a risk of property damage. Do not use anti-slip pads. ◄

# **Storage compartments**

The following storage compartments are available in the vehicle interior:

- Glove compartment on the driver's and front passenger side, refer to page 188.
- Storage compartment on the center console: manual transmission.
- Storage compartment, refer to page 191, in the center console for remote control: Steptronic transmission.

- Storage compartment in the center armrest, refer to page 189, in the front and rear.
- Compartments in the doors.
- Pockets on the backrests of the front seats.
- Net in the front passenger floor area.

# **Glove compartment**

### Front passenger side

### Safety information

WARNING

Folded open, the glove compartment protrudes in the vehicle's interior. Objects in the glove compartment can be thrown into the vehicle's interior while driving, e.g., in the event of an accident or during braking and evasive maneuvers. There is a risk of injury. Always close the glove compartment immediately after using it.

# **Opening**



Pull the handle.

The light in the glove compartment switches on.

### Closing

Fold cover closed.

### **Driver's side**

### **Safety information**

WARNING

Folded open, the glove compartment protrudes in the vehicle's interior. Objects in the glove compartment can be thrown into the vehicle's interior while driving, e.g., in the event of an accident or during braking and evasive maneuvers. There is a risk of injury. Always close the glove compartment immediately after using it.

### **Opening**



Pull the handle.

## Closing


Fold cover closed.

# **Center armrest**

### **Front**


A storage compartment is located in the center armrest between the front seats.

### **Opening**



Press button.

### **Locking the storage compartment**



The storage compartment in the armrest can be locked with an integrated key to separately secure the tailgate, refer to page 44, e.g.

After the storage compartment is locked, the remote control can be handed out without the integrated key, refer to page 37, for instance at a hotel.

This prevents access to the storage compartment and to the cargo area.

# Connection for an external audio device



An external audio device, e.g., an MP3 player, can be connected via the AUX-IN port or the USB audio interface in the center armrest.

#### Rear


The center armrest contains a storage compartment.

### **Folding down**



Pull on the opener and fold the armrest forward.

### **Opening**



Pull on the handle and fold open the cover.

# **Cup holders**

# Safety information WARNING

Unsuitable containers in the cup holder and hot beverages can damage the cup holder and increase the risk of injury in the event of an accident. There is a risk of injury or risk of property damage. Use light-weight, unbreakable, and sealable containers. Do not transport hot beverages. Do not force objects into the cup holder.

#### Manual transmission: Front

### On the center console



To open: press the button.

The insert folds out.

To use as a storage compartment, fold the insert back in.


# **Steptronic transmission: Front**



To open: press on the cover.

### Rear

In the front center armrest.



The cup holder can be adjusted for three different container sizes.

To open: press the button.

To reduce in size: fold closed to the desired position.

To close: fold all the way closed. The cup holder must be closed before it can be opened fully.

# Remote control storage compartment

### **Opening**



Press on the cover.

### Remote control storage compartment



Storage is possible in a vertical position in the center armrest.

# **Clothes hooks**

The clothes hooks are located next to the grab handles in the rear and on the door pillar in the rear.

### WARNING

Clothing articles on the clothes hooks can obstruct the view while driving. There is a risk of an accident. When suspending clothing articles from the hooks, ensure that they will not obstruct the driver's view.

# WARNING

Improper use of the clothes hooks can lead to a risk of objects flying about during braking and evasive maneuvers. There is a risk of injury and risk of property damage. Only hang lightweight objects, e.g., clothing articles, from the clothes hooks.

# Storage compartments in the cargo area

#### Net

Smaller objects can be stored in the net on the side of the cargo area.

To transport larger objects, it can be pushed down.

### **Multi-function hook**

WARNING

Improper use of the multi-function hooks can lead to a risk of objects flying about during braking and evasive maneuvers. There is a risk of injury and risk of property damage. Only hang lightweight objects, e.g., shopping bags, from the multi-function hooks. Only transport heavy luggage in the cargo area if it has been appropriately secured.

A multi-function hook is located on the left side in the cargo area.

# Storage under the cargo floor panel



Fold up the cargo floor panel.

## Storage compartment on the side

A storage compartment is located at the side of the cargo area.

## **Lashing eyes**

To secure the cargo, refer to page 201, there are lashing eyes in the cargo area.



# **Driving tips**

This chapter provides you with information useful in dealing with specific driving and operating modes.

# Things to remember when driving

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **Breaking-in period**

### **General information**

Moving parts need time to adjust to one another (break-in time).

The following instructions will help you to achieve a long vehicle life and good efficiency.

During break-in, do not use the Launch Control.

### Safety information

WARNING

Due to new parts and components, safety and driver assistance systems can react with a delay. There is a risk of an accident. After installing new parts or with a new vehicle, drive conservatively and intervene early if necessary. Observe the break-in procedures of the respective parts and components.

# Engine, transmission, and axle drive

### Up to 1,200 miles/2,000 km

Do not exceed the maximum engine and road speed:

For gasoline engine 4,500 rpm and 100 mph/160 km/h. For diesel engine 3,500 rpm and 93 mph/150 km/h.

Avoid full load or kickdown under all circumstances.

### From 1,200 miles/2,000 km

The engine and vehicle speed can gradually be increased.

#### **Tires**

Tire traction is not optimal due to manufacturing circumstances when tires are brand-new; they achieve their full traction potential after a break-in time.

Drive conservatively for the first 200 miles/300 km.

### **Brake system**

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimal performance between brake discs and brake pads. Drive moderately during this break-in period.

#### Clutch

The function of the clutch reaches its optimal level only after a distance driven of approx. 300 miles/500 km. During this break-in period, engage the clutch gently.

### Following part replacement

The same break-in procedures should be observed if any of the components above-mentioned have to be renewed in the course of the vehicle's operating life.

# **General driving notes**

# Closing the trunk lid WARNING

An open tailgate protrudes from the vehicle and can endanger occupants and other traffic participants or damage the vehicle in the event of an accident, braking or evasive maneuvers. In addition, exhaust fumes may enter the vehicle interior. There is a risk of injury or risk of property damage. Do not drive with the tailgate open.

If driving with the tailgate open cannot be avoided:

- Close all windows and the glass sunroof.
- Greatly increase the air flow from the vents.
- Drive moderately.

# Hot exhaust system WARNING

During driving operation, high temperatures can occur underneath the vehicle body, e.g., caused by the exhaust gas system. If combustible materials, such as leaves or grass, come in contact with hot parts of the exhaust gas system, these materials can ignite. There is a risk of injury or risk of property damage. Do not remove the heat shields installed and never apply undercoating to them. Make sure that no combustible materials can come in contact with hot vehicle parts in driving operation, idle or during parking. Do not touch the hot exhaust system.

# Diesel particulate filter


The diesel particulate filter collects soot particles and burns them periodically at high temperatures.

During several minutes of cleaning the following may occur:

Temporarily, the engine may run less smoothly.

- Noises and a slight amount of smoke coming from the exhaust until shortly after the engine is shut down.
- A somewhat higher engine speed is necessary to reach usual performance.

### Climate control windshield



The marked area is not covered with heat reflective coating.

Use this area for garage door openers, devices for electronic toll collection, etc.

# Climate control laminated tinted safety glass

The vehicle glass provides full protection against the harmful effects of UV radiation on the skin.

# Mobile communication devices in the vehicle

Vehicle electronics and mobile phones can influence one another. There is radiation due to the transmission operations of mobile phones. There is a risk of injury or risk of property damage. If possible, in the vehicle's interior use only mobile phones with direct connections to an exterior antenna in order to exclude mutual interference and deflect the radiation from the vehicle's interior.◀

# **Hydroplaning**

WARNING

On wet or slushy roads, a wedge of water can form between the tires and road surface.

This phenomenon is referred to as hydroplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface, ultimately undermining your ability to steer and brake the vehicle.

### **Driving through water**

NOTE

When driving too quickly through too deep water, water can enter into the engine compartment, the electrical system or the transmission. There is a risk of property damage. When driving through water, do not exceed the maximum indicated water level and the maximum speed for driving through water.

When driving through water, observe the following:

- Drive through calm water only.
- Drive through water only if it is not deeper than maximum 9.8 in/25 cm.
- Drive through water no faster than walking speed, up to 3 mph/5 km/h.

### **Braking safely**

Your vehicle is equipped with ABS as a standard feature.

Perform an emergency stop in situations that require such.

Steering is still responsive. You can still avoid any obstacles with a minimum of steering effort.

Pulsation of the brake pedal and sounds from the hydraulic circuits indicate that ABS is in its active mode.

In certain braking situations, the perforated brake discs can emit functional noises. However, this has no effect on the performance and operational reliability of the brake.

# Objects in the movement area around pedals and floor area

WARNING

Objects in the driver's floor area can limit the pedal distance or block a depressed pedal. There is a risk of an accident. Stow objects in the vehicle such that they are secured and cannot enter into the driver's floor area. Use floor mats that are suitable for the vehicle and can be safely attached to the floor. Do not use loose floor mats and do not layer several floor mats. Make sure that there is sufficient clearance for the pedals. Ensure that the floor mats are securely fastened again after they were removed, e.g., for cleaning.

### **Driving in wet conditions**

When roads are wet, salted, or in heavy rain, gently press the brake pedal every few miles.

Ensure that this action does not endanger other traffic.

The heat generated during braking dries brake discs and brake pads and protects them against corrosion.

In this way braking efficiency will be available when you need it.

### Hills

Light but consistent brake pressure can lead to high temperatures, brakes wearing out and possibly even brake failure. There is a risk of an accident. Avoid placing excessive stress on the brake system.

### WARNING

In idle state or with the engine switched off, safety-relevant functions, e.g., engine braking effect, braking force boost and steering assistance, are restricted or not available at all. There is a risk of an accident. Do not drive in idle state or with the engine switched off.

Drive long or steep downhill gradients in the gear that requires least braking effort. Otherwise, the brakes may overheat and reduce brake efficiency.

You can increase the engine's braking effect by shifting down, going all the way to first gear, if needed.

#### Brake disc corrosion

Corrosion on the brake discs and contamination on the brake pads are increased by the following circumstances:

- Low mileage.
- Extended periods when the vehicle is not used at all.
- Infrequent use of the brakes.
- Aggressive, acidic, or alkaline cleaning agents.

Corrosion buildup on the brake discs will cause a pulsating effect on the brakes in their response - generally this cannot be corrected.

# Condensation water under the parked vehicle

When using the automatic climate control, condensation water develops and collects underneath the vehicle.

# **Driving on racetracks**

Higher mechanical and thermal loads during racetrack operation lead to increased wear. This wear is not covered by the warranty. The vehicle is not designed for motorsports competitive use.

# Loading

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **Safety information**

WARNING
High gross weight can overheat the tires,
damage them, and cause a sudden drop in tire
inflation pressure. There is a risk of an accident. Pay attention to the permitted load capacity of the tires and never exceed the permitted gross weight.

WARNING

Loose objects or devices with a cable connection to the vehicle, e.g., mobile phones, can be thrown into the vehicle's interior while driving, e.g., in the event of an accident or during braking and evasive maneuvers. There is a risk of injury. Secure loose objects or devices with a cable connection to the vehicle in the vehicle's interior.

WARNING

Improperly stowed objects can shift and be thrown into the vehicle's interior, e.g., in the event of an accident or during braking and evasive maneuvers. Vehicle occupants can be hit and injured. There is a risk of injury. Stow and secure objects and cargo properly.

## NOTE

Fluids in the cargo area can cause damage. There is a risk of property damage. Make sure that no fluids leak in the cargo area.

# **Determining the load limit**

Locate the following statement on your vehicle's placard:

The combined weight of occupants and cargo should never exceed XXX kg or YYY lbs. Otherwise, damage to the vehicle and unstable driving situations may result.



- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX kilograms or YYY pounds.
- The resulting figure equals the available amount of cargo and luggage load capacity.
  - E.g., if the YYY amount equals 1,000 lbs and there will be four 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 400 lbs: 1,000 lbs minus 600 lbs = 400 lbs.
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the

available cargo and luggage load capacity calculated in Step 4.

### Load




The maximum load is the sum of the weight of the occupants and the cargo.

The greater the weight of the occupants, the less cargo that can be transported.

# Stowing and securing cargo

- Cover sharp edges and corners on the cargo.
- Heavy cargo: stow as far forward as possible, directly behind and at the bottom of the rear passenger seat backrests.
- Very heavy cargo: when the rear seat is not occupied, secure each of the outer safety belts in the opposite buckle.
- ▶ If necessary, fold down the rear backrests to stow cargo.
- Do not stack cargo above the top edge of the backrests.
- Smaller and lighter cargo: secure with ratchet straps or with a cargo net or draw straps.
- ▶ Larger and heavy cargo: secure with cargo straps.

# Lashing eyes in the cargo area



There are four lashing eyes in the cargo area for securing cargo.

Attach load securing aids, such as lashing straps, retaining straps, draw straps or cargo nets, to the lashing eyes in the cargo area.

# **Roof-mounted luggage rack**

### **General information**

Roof racks are available as special accessories.

### **Safety information**

WARNING
When driving with roof load, e.g., with roof-mounted luggage rack, driving safety may not be ensured in driving-critical situations due to the elevated center of gravity. There is a risk of accidents or risk of property damage. Do not deactivate Dynamic Stability Control DSC when driving with roof load.◄

### Securing

Follow the installation instructions of the roof rack.

### Roof drip rail with flaps



The anchorage points are located in the roof drip rail above the doors.

Fold the cover outward.

### Loading

Because roof-mounted luggage racks raise the vehicle's center of gravity when loaded, they have a major effect on vehicle handling and steering response.

Therefore, note the following when loading and driving:

- Do not exceed the approved roof/axle loads and the approved gross vehicle weight.
- Be sure that adequate clearance is maintained for tilting and opening the glass sunroof.
- Distribute the roof load uniformly.
- The roof load should not extend past the loading area.
- Always place the heaviest pieces on the bottom.
- Secure the roof luggage firmly, e.g., using ratchet straps.
- Do not let objects project into the opening path of the tailgate.
- Drive cautiously and avoid sudden acceleration and braking maneuvers. Take corners gently.

# **Saving fuel**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **General information**

The vehicle contains advanced technologies for the reduction of fuel consumption and emission values.

Fuel consumption depends on a number of different factors.

Carrying out certain measures, such as a moderate driving style and regular maintenance, can influence fuel consumption and the environmental impact.

# Remove unnecessary cargo

Additional weight increases fuel consumption.

# Remove attached parts following use

Remove roof-mounted luggage racks which are no longer required following use.

Attached parts on the vehicle impair the aerodynamics and increase the fuel consumption.

# Close the windows and glass sunroof

Driving with the glass sunroof and windows open results in increased air resistance and thereby reduces the range.

### **Tires**

### **General information**

Tires can affect fuel consumption in various ways, e.g., tire size may influence fuel consumption.

# Check the tire inflation pressure regularly

Check and, if needed, correct the tire inflation pressure at least twice a month and before starting on a long trip.

Low tire inflation pressure increases rolling resistance and thus raises fuel consumption and tire wear.

# **Drive away immediately**

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving right away, but at moderate engine speeds.

This is the quickest way of warming the cold engine up to operating temperature.

# Look well ahead when driving

Avoid unnecessary acceleration and braking.

By maintaining a suitable distance to the vehicle driving ahead of you.

Driving smoothly and proactively reduces fuel consumption.

# **Avoid high engine speeds**

As a rule: driving at low engine speeds lowers fuel consumption and reduces wear.

Use 1st gear to get the vehicle moving. Starting with the 2nd gear, accelerate rapidly. When accelerating, shift up before reaching high engine speeds.

When you reach the desired speed, shift into the highest applicable gear and drive with the engine speed as low as possible and at a constant speed.

If necessary, observe the gear shift indicator of the vehicle, refer to page 98.

# **Use coasting**

When approaching a red light, take your foot off the accelerator and let the vehicle coast to a halt.

For going downhill take your foot off the accelerator and let the vehicle roll.

The flow of fuel is interrupted while coasting.

# Switch off the engine during longer stops

Switch off the engine during longer stops, e.g., at traffic lights, railroad crossings or in traffic congestion.

# Auto Start/Stop function

The Auto Start/Stop function of the vehicle automatically switches off the engine during a stop.

If the engine is switched off and then restarted rather than leaving the engine running constantly, fuel consumption and emissions are reduced. Savings can begin within a few seconds of switching off the engine.

In addition, fuel consumption is also determined by other factors, such as driving style,

road conditions, maintenance or environmental factors.

# Switch off any functions that are not currently needed

Functions such as seat heating and the rear window defroster require a lot of energy and reduce the range, especially in city and stopand-go traffic.

Switch off these functions if they are not needed.

The ECO PRO driving program supports the energy conserving use of comfort features. These functions are automatically deactivated partially or completely.

# Have maintenance carried out

Have the vehicle maintained regularly to achieve optimal vehicle efficiency and service life. BMW recommends that maintenance work be performed by a BMW dealer's service center.

For information on the BMW Maintenance System, refer to page 250.

## **ECO PRO**

# Concept

ECO PRO supports a driving style that saves on fuel consumption. For this purpose, the engine control and comfort features, e.g., the climate control output, are adjusted.

Under certain conditions the engine is automatically decoupled from the transmission in the D selector lever position. The vehicle continues traveling with the engine idling to reduce fuel consumption. Selector lever position D remains engaged.

In addition, context-sensitive instructions are displayed to assist with an optimized fuel consumption driving style.

The achieved extended range is displayed in the instrument cluster as bonus range.

### **General information**

The system includes the following EfficientDynamics functions and displays:

- ▶ ECO PRO bonus range, refer to page 206.
- ▶ ECO PRO tips driving instruction, refer to page 206.
- ▶ ECO PRO climate control, refer to page 205.
- ECO PRO coasting driving condition, refer to page 207.

#### Overview





**Driving Dynamics Control** 

### **Activating ECO PRO**

Press button repeatedly until ECO PRO is displayed in the instrument cluster.

### **Configuring ECO PRO**

# **Via the Driving Dynamics Control**

- Activate FCO PRO.
- 2. "Configure ECO PRO"

#### Via iDrive

- "Settings"
- 2. "ECO PRO mode"

With respective equipment:

- "Settings"
- 2. "Driving mode"
- 3. "Configure ECO PRO"

### **ECO PRO limit**

- "ECO PRO speed warning":
   An ECO PRO tip is displayed if the speed of the set ECO PRO limit is exceeded.
- ▶ "Tip at:": Set the desired ECO PRO speed.

#### **ECO PRO climate control**

To activate ECO PRO climate control:

"ECO PRO climate control"

Climate control is set to be fuel-efficient.

By making a slight change to the set temperature, or slowly adjusting the rate of heating or cooling of the vehicle's interior, fuel consumption can be economized.

The mirror heating is made available when outside temperatures are very cold.

### Coasting

To activate coasting:

"Coasting"

Fuel-efficiency can be optimized by disengaging the engine and coasting with the engine idling.

This function is only available in ECO PRO mode.

Deactivate the function to use the braking effect of the engine when traveling downhill.

### **ECO PRO potential savings**

Shows potential savings with the current settings in percentages.

### Display in the instrument cluster

### Display in the instrument display

When ECO PRO mode is activated, the display switches to a special configuration.

Some of the displays may differ from the display in the instrument cluster.

Blue bar segments symbolize the gained bonus range in stages.

In addition, the bonus range is highlighted in blue in the total range display.

### **ECO PRO bonus range**




An adjusted driving style helps you extend your driving range.

This may be displayed as the bonus range in the instrument cluster.

The bonus range is shown in the range display. The bonus range is automatically reset every time the vehicle is refueled.

### **ECO PRO efficiency display**

Display in the instrument cluster



### Display in the instrument display



A mark in the efficiency display informs about the current driving style.

Mark in the area of arrow 1: display of the energy recovered by coasting or when braking.

Mark in the area of arrow 2: display when accelerating.

Your driving style's efficiency is shown by the bar's color:

- ▶ Blue display: efficient driving style as long as the mark moves within the blue range.
- Gray display: adjust driving style, e.g., by backing off the accelerator pedal.

The display switches to blue as soon as all conditions for driving with optimized fuel efficiency.

### **ECO PRO tip, driving tip**



The arrow indicates that the driving style can be adjusted to be more fuel efficient, e.g., by backing off the accel-

erator.

# Activating the driving style indicator and ECO PRO tips

The efficiency display and ECO PRO tips in the instrument cluster appear when the ECO PRO display is activated.

To activate the indicator:

- 1. "Settings"
- "Instrument cluster"
- "ECO PRO Info"

In the instrument display:

- 1. "Settings"
- 2. "Instrument cluster"
- 3. "Driving mode view"

### **ECO PRO tip, symbols**

An additional symbol and text instructions are displayed.

### Symbol Measure



For efficient driving back off the accelerator or delay accelerating to allow time to assess road conditions.



Reduce speed to the selected ECO PRO speed.



Steptronic transmission: shift from M/S to D.



Steptronic transmission/manual transmission: follow shifting instructions.



Manual transmission: engage neutral for engine stop.

# **Indications on the Control Display**

## **Displaying EfficientDynamics info**

Information on fuel consumption and technology can be displayed while driving.

- "Vehicle info"
- 2. "EfficientDynamics"

### **Displaying fuel consumption history**

The average fuel consumption can be displayed within an adjustable time frame.

Vertical bars show consumption for the selected time frame.

Trip interruptions are represented below the bar on the time axis.

"Consumption history"

# Adjusting the fuel consumption history time frame

- 1. Select the symbol.
- 2. Adjust the time frame.

### **Resetting fuel consumption history**

- 1. Open "Options".
- 2. "Reset consumption history"

### **Displaying EfficientDynamics info**

The current efficiency can be displayed.

エ "EfficientDynamics info"

The following systems are displayed:

- Auto Start/Stop function.
- Energy recovery.
- Climate control output.
- Coasting.

### **Display ECO PRO tips**

i "ECO PRO tips"

Settings are stored for the profile currently used.

# Coasting

### Concept

The function helps to conserve fuel.

To do this, under certain conditions the engine is automatically decoupled from the transmission when selector lever position D is set. The vehicle continues traveling with the engine idling to reduce fuel consumption. Selector lever position D remains engaged.

This driving condition is referred to as coasting.

As soon as you step on the brake or accelerator pedal, the engine is automatically coupled again.

#### **General information**

Coasting is a component of the ECO PRO driving mode.

Coasting is automatically activated when ECO PRO mode is called via the Driving Dynamics Control.

The function is available in a certain speed range.

A proactive driving style helps the driver to use the function as often as possible and supports the fuel-conserving effect of coasting.

### **Functional requirements**

In ECO PRO mode, this function is available in a speed range from approximately 30 mph/50 km/h to 100 mph/160 km/h if the following conditions are met:

- Accelerator pedal and brake pedal are not operated.
- The selector lever is in selector lever position D.
- Engine and transmission are at operating temperature.

### **Operation via shift paddles**

### Concept

Depending on your vehicle's equipment, the coasting mode can be influenced with the shift paddles.

# Activating, deactivating coasting via shift paddles

- Using the shift paddle + shift to the highest gear.
- Press shift paddle + again to enter coasting mode.

To deactivate, press shift paddle - .

### **Display**

### Display in the instrument cluster



The mark in the efficiency display below the tachometer is backlit in blue and is located at the zero point. The tachometer approximately indicates idle

speed.

The coasting point indicator is illuminated at the zero point during coasting.

### Display in the instrument display




The mark in the efficiency display is backlit in blue and is located at the zero point.

The coasting point indicator is illuminated at the zero point dur-

ing coasting.

### **Indications on the Control Display**

The coasting driving condition is displayed in EfficientDynamics Info while this driving mode is active.



Color code blue, arrow 1, and symbol, arrow 2: driving condition coasting.

## **Displaying EfficientDynamics info**

- 1. "Vehicle info"
- "EfficientDynamics"
- 3. ## "EfficientDynamics info"

# **Deactivating the function manually**

The function can be deactivated in the Configure ECO PRO menu, e.g., to use the braking effect of the engine when traveling downhill.

Settings are stored for the profile currently used.

### **System limits**

The function is not available if one of the following conditions applies:

- DSC OFF or TRACTION activated.
- If cruise control is activated.
- ▶ If driving in the dynamic limit range.
- ▶ If driving on steep uphill or downhill grades.
- If the battery charge state is temporarily too low.
- If the vehicle electrical system is drawing excessive current.



# **Mobility**

In order to always ensure your mobility, you will find important information on operating fluids, wheels and tires, maintenance and Roadside Assistance in the following.

# Refueling

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **General information**

Observe the fuel recommendation, refer to page 214, prior to refueling.

### **Diesel engines**

The filler neck is designed for refueling at diesel fuel pumps.

# **Safety information**

NOTE
With a range of less than 30 miles/50 km
it is possible that the engine will no longer have sufficient fuel. Engine functions are not ensured anymore. There is a risk of property damage. Refuel promptly.

■


# Fuel cap

### **Opening**

 Briefly press the rear edge of the fuel filler flap.



2. Turn the fuel cap counterclockwise.



3. Place the fuel cap in the bracket attached to the fuel filler flap.



### Closing

1. Fit the lid and turn it clockwise until you clearly hear a click.

### 2. Close the fuel filler flap.

WARNING

The retaining strap of the fuel cap can be jammed and crushed during closing. The cap cannot be correctly closed. Fuel or fuel vapors can escape. There is a risk of injury or risk of property damage. Pay attention that the retaining strap is not jammed or crushed when closing the lid.

### Manually unlocking fuel filler flap

E.g., in the event of an electrical malfunction.

Have fuel filler flap unlocked by a dealer's service center or another qualified service center or repair shop.

# Observe the following when refueling

#### **General information**

The fuel tank is full when the filler nozzle clicks off the first time.

Observe safety regulations posted at the gas station.

## Safety information

**♠** NOTE

Fuels are toxic and aggressive. Overfilling of the fuel tank can damage the fuel system. Painted surfaces may be damaged by contact with fuel. Escaping fuel can harm the environment. There is a risk of property damage. Avoid overfilling.

# **Fuel**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

### **Fuel recommendation**

#### **General information**

Depending on the region, many gas stations sell fuel that has been customized to winter or summer conditions. Fuel that is available in winter, e.g., helps make a cold start easier.

#### Gasoline

### **General information**

For the best fuel efficiency, the gasoline should be sulfur-free or very low in sulfur content.

Fuels that are marked on the gas pump as containing metal must not be used.

Fuels with a maximum ethanol content of 10 %, i. e., E10, may be used for refueling. Ethanol should satisfy the following quality

US: ASTM 4806-xx

standards:

CAN: CGSB-3.511-xx

xx: comply with the current standard in each case.

### Safety information

NOTE

Do not press the Start/Stop button after refueling with the wrong fuel. Furthermore, the catalytic converter is permanently damaged. There is a risk of property damage. Do not refuel or add the following in the case of gasoline engines:

- Leaded gasoline.
- Metallic additives, e.g., manganese or iron.

Do not press the Start/Stop button after refueling with the wrong fuel. Contact a dealer's service center or another qualified service center or repair shop. ◄

NOTE

Incorrect fuels can damage the fuel system and the engine. There is a risk of property damage. Do not use a fuel with a higher ethanol percentage than recommended or one with other types of alcohol, e.g., M5 to M100.

NOTE

Fuel that does not comply with the minimum quality can compromise engine function or cause engine damage. There is a risk of property damage. Do not fill with fuel that does not comply with the minimum quality.

CAUTION

The use of poor-quality fuels may result in harmful engine deposits or damage. Additionally, problems relating to drivability, starting and stalling, especially under certain environmental conditions such as high ambient temperature and high altitude, may occur.

If drivability problems are encountered, we recommend switching to a high quality gasoline brand and a higher octane grade — AKI number — for a few tank fills. To avoid harmful en-

gine deposits, it is highly recommended to purchase gasoline from Top Tier retailers.

Failure to comply with these recommendations may result in the need for unscheduled maintenance.◀

### Recommended fuel grade

BMW recommends AKI 91.

### Minimum fuel grade

BMW recommends AKI 89.

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high outside temperatures. This has no effect on the engine life.

### **Diesel**

### **Safety information**

NOTE

Do not press the Start/Stop button after refueling with the wrong fuel. There is a risk of property damage.

Observe the following for diesel engines:

- Use only Ultra-Low Sulfur Diesel. Maximum content of biodiesel: 5 %, B5.
- Do not use rapeseed methyl ester RME.
- Do not use biodiesel above 5 %, B5.
- Do not use gasoline.
- No diesel additives.

Do not press the Start/Stop button after refueling with the wrong fuel. Contact a dealer's service center or another qualified service center or repair shop. ◀

### **Low-Sulfur Diesel**

The engine of your BMW is designed for diesel with low sulfur content:

Ultra-Low Sulfur Diesel ASTM D 975-xx. xx: comply with the current standard in each case.

Use only Ultra-Low Sulfur Diesel.

The fraction of biodiesel in the fuel must not exceed 5 %, referred to as B5. Do not use gasoline. If you do fill the tank with the wrong fuel, e.g., gasoline, do not start the engine as this may damage the engine.

In the case of incorrect refueling, contact a dealer's service center or another qualified service center or repair shop or Roadside Assistance.

If the fuel pump nozzle does not fit in the filler pipe of your BMW, please check to ensure that you are refueling at a diesel fuel pump that is equipped with a diesel fuel pump nozzle.

In the event the Ultra-Low Sulfur Diesel fuel cannot be fully inserted into the fuel filler neck, please contact BMW Roadside Assistance for instructions on how to add fuel.

For additional information regarding Roadside Assistance, refer to the Owner's Manual for Navigation, Entertainment and Communication.

# BMW recommends Shell Quality Fuels

# **BMW Advanced Diesel**

# Concept

BMW Advanced Diesel reduces nitrogen oxides in the diesel emissions by injecting diesel exhaust fluid into the exhaust system. A chemical reaction takes place inside the catalytic converter that minimizes nitrogen oxides.

The vehicle has a tank system that can be refilled.

To be able to start the engine as usual, there must be an adequate diesel exhaust fluid.

### Warming up the system

In order to warm the engine up to its operating temperature after a cold start, the Steptronic transmission may subsequently shift up to the next higher gear.

### Displays in the instrument cluster

#### Reserve indication

This display in the instrument cluster provides information about the distance that can still be driven with the current reserve level.

Do not continue driving to the limit of the remaining travel distance. It is not possible to restart the engine after switching it off.



- Lamp white: refill with diesel exhaust fluid at the next opportunity.
- Lamp yellow: not enough diesel exhaust fluid present. The remaining range is displayed in the instrument cluster. Immediately refill with diesel exhaust fluid.

### Diesel exhaust fluid on minimum



The remaining range is displayed in the instrument cluster: add diesel exhaust fluid. The engine will continue to run as long as it is not switched off and all other operating conditions are satisfied; sufficient fuel, e.g.

### **System malfunction**

A Check Control message is displayed when there is a system not working.

# Have the diesel exhaust fluid replenished

BMW recommends that diesel exhaust fluid be added by the dealer's service center within the course of regular maintenance.

In addition it may be necessary to have the fluid replenished several times under particular circumstances, e.g., if the vehicle is driven in a particularly sporty style or if it is driven at high altitudes.

The diesel exhaust fluid must be replenished as soon as the reserve display appears in the instrument cluster to avoid not being able to restart the engine.

# Diesel exhaust fluid at low temperatures

Due to its physical properties, it is possible that the diesel exhaust fluid may also need to be replenished between regular maintenance appointments if it is exposed to temperatures under + 23  $^{\circ}$ F/- 5  $^{\circ}$ C. In this case, add diesel exhaust fluid only immediately before driving off.

At temperatures below + 12  $^{\circ}$ F/- 11  $^{\circ}$ C, the filling level cannot be measured in some cases.

# Replenishing diesel exhaust fluid yourself in exceptional cases

#### **General information**

You can replenish Diesel exhaust fluid yourself in exceptional cases, e.g., to get to your scheduled service.

# **Safety information**

WARNING

Small amounts of ammonia fumes can escape when opening the diesel exhaust fluid container. Ammonia fumes have a pungent odor and irritate skin, mucous membranes, and eyes. There is a risk of injury. Do not inhale escaping ammonia fumes. Avoid the contact of articles of clothing, skin or eyes with diesel exhaust fluid. Do not swallow any diesel exhaust

fluid. Keep children away from diesel exhaust fluids.◀

#### WARNING

Operating materials, e.g., oils, greases, coolants, fuels, can contain harmful ingredients. There is a risk of injuries or danger to life. Observe the instructions on the containers. Avoid the contact of articles of clothing, skin or eyes with operating materials. Do not refill operating materials into different bottles. Store operating materials out of reach of children.

#### NOTE

The diesel exhaust fluid ingredients are very aggressive. There is a risk of property damage. Avoid contact of diesel exhaust fluid with surfaces of the vehicle.

#### Suitable diesel exhaust fluid

- Recommended: BMW Diesel Exhaust Fluid. With this bottle and its special adapter, diesel exhaust fluid can be replenished simply and safely.
- Alternatively recommended: NOx Diesel exhaust fluid AUS 32.


Diesel exhaust fluid can be purchased at a dealer's service center or another qualified service center or repair shop.

# **Refill quantity**

When the Reserve display starts, add at least 3 bottles of diesel exhaust fluid.

This corresponds to approx. 1.5 US gal/6 liters.

#### Tank for diesel exhaust fluid



The fuel cap for diesel exhaust fluids is next to the fuel cap for the fuel tank.

#### Adding the diesel exhaust fluid

Add the diesel exhaust fluid when the ignition is switched on.

- 1. Open the fuel filler flap, refer to page 212.
- 2. Turn the fuel cap of the diesel exhaust fluid tank counterclockwise and remove.
- 3. Place the bottle on it and turn it as far as it will go, see arrow.



Press the bottle down, see arrow.The vehicle tank will be filled.

The tank is full when the fill level in the bottle no longer changes. It is not possible to overfill.



Pull back the bottle, see arrow, and unscrew it.



- 6. Replace the fuel cap and turn it clockwise.
- 7. Close the fuel filler flap.

#### Filling with an incorrect fluid

#### Information

WARNING

After adding an incorrect fluid, e.g., antifreeze for washer fluid, the system can heat and ignite. There is a risk of fire and injuries. Do not add incorrect fluids. Do not start the engine after adding an incorrect fluid.

A Check Control message is displayed when an incorrect fluid is added.

In the case that an incorrect liquid was refilled, contact a dealer's service center or another qualified service center or repair shop.

#### **Disposing of bottles**



Diesel exhaust fluid bottles can be disposed of at a dealer's service center or another qualified service center or re-

pair shop.

Do not dispose of empty bottles with household waste unless this is permitted by local regulations.

#### **Reserve indication**



The Reserve display will still appear along with the remaining range after refilling.

Engine can be started.

After several minutes of driving, the Reserve indication goes out.

#### Diesel exhaust fluid on minimum



After filling, the indicator is still displayed.

The engine can only be started after the indicator goes out.

- Switch on the ignition.
   The indicator goes out after approx. 1 minute.
- 2. Engine can be started.

# Wheels and tires

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# Tire inflation pressure

#### **Safety information**

The tire characteristics and tire inflation pressure influence the following:

- The service life of the tires.
- Road safety.
- Driving comfort.

WARNING

# Checking the tire inflation pressure

A tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. There is a risk of an accident. Regularly check the tire inflation pressure, and correct it as needed, e.g., twice a month and before a long trip.

Tires have a natural, consistent loss of tire inflation pressure.

Tires heat up while driving, and the tire inflation pressure increases along with the tire's temperature. The tire inflation pressure specifications relate to cold tires or tires at ambient temperature.

Only check the tire inflation pressure when the tires are cold. This means after driving no more

than 1.25 miles/2 km or when the vehicle has been parked for at least 2 hours.

The displays of inflation devices may underread by up to 0.1 bar/2 psi.

For Flat Tire Monitor: after correcting the tire inflation pressure, reinitialize the Flat Tire Monitor.

For Tire Pressure Monitor: perform a reset of the Tire Pressure Monitor after adjusting tire pressure to a new value.

#### Tire inflation pressure specifications

The tire inflation pressure table, refer to page 220, contains all tire inflation pressure specifications for the specified tire sizes at the ambient temperature. The tire inflation pressure values apply to tire sizes approved by the manufacturer of the vehicle for the vehicle type.

To identify the correct tire inflation pressure, please note the following:

- Tire sizes of your vehicle.
- Maximum permitted driving speed.

# Tire inflation pressures up to 100 mph/160 km/h

For speeds of up to 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire inflation pressure table, refer to page 220, and adjust as necessary.



These pressure values can also be found on the tire inflation pressure label on the driver's door pillar.

Do not exceed a speed of 100 mph/160 km/h.

# Tire inflation pressure values up to 100 mph/160 km/h

#### **528i**

Tire size	Pressure specifications in bar/PSI
Specifications in bar/PSI with cold tires	† † † † + † / D
225/55 R 17 97 V M +S A/S RSC 225/55 R 17 97 H M +S RSC	2.2/32 2.4/35
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M +S XL A/S RSC 245/45 R 18 96 Y RSC 245/45 R 18 100 V M+S XL RSC	2.4/35 2.6/38
Front: 245/45 R 18 96 Y RSC	2.4/35 -

Tire size	Pressure specifications in bar/PSI		
Rear: 275/40 R 18 99 Y RSC	-	2.4/35	
Front: 245/40 R 19 94 Y RSC	2.4/35	-	
Rear: 275/35 R 19 96 Y RSC	-	2.6 / 38	
Front: 245/35 R 20 95 Y XL RSC	2.4/35	-	
Rear: 275/30 R 20 97 Y XL RSC	-	2.9 /42	
Emergency wheel: T 135/90 R 17 104 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60		

## 535i, 535d

Tire size	Pressure specifications in bar/PSI
Specifications in bar/PSI with cold tires	* * * * * * / D
245/45 R 18 100 V M+S XL A/S RSC	2.4/35 2.7/39
245/40 R 19 98 V M+S XL A/S RSC	
245/45 R 18 96 Y RSC	
225/55 R 17 97 H M+S RSC	
245/45 R 18 100 V M+S XL RSC	
Front: 245/45 R 18 96 Y RSC	2.4/35 -

Pressure specifications

in bar/PSI

Tire size	Pressure specifications in bar/PSI		
Rear: 275/40 R 18 99 Y RSC	-	2.4 / 35	
Front: 245/40 R 19 94 Y RSC	2.4/35	-	
Rear: 275/35 R 19 96 Y RSC	-	2.6 / 38	
Front: 245/35 R 20 95 Y XL RSC	2.4/35	-	
Rear: 275/30 R 20 97 Y XL RSC	-	2.9/42	
Emergency wheel: T 135/90 R 17 104 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60		

#### 550i

Tire size	Pressure sp in bar/PSI	ecifications
Specifications in bar/PSI with cold tires	† † † † +	· / / D
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M+S XL A/S RSC 245/45 R 18 96 Y RSC 245/45 R 18 100 V M+S XL RSC	2.5 / 36	2.7 / 39
Front: 245/45 R 18 96 Y RSC	2.5 / 36	-
Rear: 275/40 R 18 99 Y RSC	-	2.5 / 36
Front: 245/40 R 19 94 Y RSC	2.5 / 36	-

Tire size	Pressure sp in bar/PSI	ecifications
Rear: 275/35 R 19 96 Y RSC	-	2.6 / 38
Front: 245/35 R 20 95 Y XL RSC	2.6 / 38	-
Rear: 275/30 R 20	-	2.9/42

#### 528i xDrive

Tire size

	III bairi Oi	
Specifications in bar/PSI with cold tires	# # # + •	**/*
225/55 R 17 97 V M+S A/S RSC	2.4/35	2.6 / 38
225/55 R 17 97 H M+S RSC		
245/45 R 18 100 V M+S XL A/S RSC		
245/40 R 19 98 V M+S XL A/S RSC		
245/45 R 18 96 Y RSC		
245/45 R 18 100 V M+S XL RSC		
Front: 245/45 R 18 96 Y RSC	2.4/35	-
Rear: 275/40 R 18 99 Y RSC	-	2.4/35

Front: 245/40 R 19 2.4 / 35

Rear: 275/35 R 19 -

94 Y RSC

96 Y RSC

2.6/38

Tire size	Pressure sp in bar/PSI	ecifications	Tire size	Pressure spein bar/PSI	ecifications
Front: 245/35 R 20 95 Y XL RSC	2.5 / 36	-	Rear: 275/30 R 20 97 Y XL RSC	-	3.0 / 44
Rear: 275/30 R 20 97 Y XL RSC	-	3.0 / 44	Emergency wheel: T 135/90 R 17 104	Speed up to 50 mph / 80	
Emergency wheel:	Speed up to		М	4.2 / 60	
T 135/90 R 17 104 M	50 mph / 80 4.2 / 60	km/n	550i xDrive		
535i xDrive, 5350	d xDrive		Tire size	Pressure sp in bar/PSI	ecifications
Tire size	Pressure sp in bar/PSI	ecifications	Specifications in bar/PSI with cold	<b>*</b> * * * * +	· <b>†</b> /Ø
Specifications in bar/PSI with cold	<b>                                      </b>	<b>†</b> /0	tires		
tires			245/45 R 18 100 V M+S XL A/S RSC	2.6 / 38	2.7/39
245/45 R 18 100 V M+S XL A/S RSC	2.4/35	2.7 / 39	245/40 R 19 98 V M+S XL A/S RSC		
245/40 R 19 98 V M+S XL A/S RSC			245/45 R 18 96 Y RSC		
245/45 R 18 96 Y RSC			245/45 R 18 100 V M+S XL RSC		
225/55 R 17 97 H M+S RSC			Front: 245/45 R 18 96 Y RSC	2.6 / 38	-
245/45 R 18 100 V M+S XL RSC			Rear: 275/40 R 18 99 Y RSC	-	2.6/38
Front: 245/45 R 18 96 Y RSC	2.4/35	-	Front: 245/40 R 19 94 Y RSC	2.6 / 38	-
Rear: 275/40 R 18 99 Y RSC	-	2.4 / 35	Rear: 275/35 R 19 96 Y RSC	-	2.7/39
Front: 245/40 R 19 94 Y RSC	2.4/35	-	Front: 245/35 R 20 95 Y XL RSC	2.7 / 39	-
Rear: 275/35 R 19 96 Y RSC	-	2.6 / 38	Rear: 275/30 R 20 97 Y XL RSC	-	3.1 / 45
Front: 245/35 R 20 95 Y XL RSC	2.5 / 36	-			

in bar/PSI

Pressure specifications

Speed up to a max. of

50 mph / 80 km/h

4.2 / 60

2.6 / 38

2.9/42

Front: 245/35 R 20 2.4 / 35

With high-speed tuning feature

Tire size

96 Y RSC

95 Y XL RSC

97 Y XL RSC

M

Rear: 275/35 R 19

Rear: 275/30 R 20

Emergency wheel:

T 135/90 R 17 104

# Tire inflation pressures at max. speeds above 100 mph/160 km/h

WARNING

In order to drive at maximum speeds in excess of 100 mph/160 km/h, please observe, and, if necessary, adjust tire pressures for speeds exceeding 100 mph/160 km/h from the relevant table on the following pages. Otherwise, tire damage and accidents could occur.

# Tire inflation pressure values over 100 mph/160 km/h

#### **528i**

vvitnout nign-speed	tuning reatur	е		with nigh-speed tun	ing reature	
Tire size	Pressure sp in bar/PSI	Pressure specifications in bar/PSI		Tire size	Pressure sp in bar/PSI	ecifications
Specifications in bar/PSI with cold tires	# # # # + •	<b>†</b> /0		Specifications in bar/PSI with cold tires	# # # + •	*/0
225/55 R 17 97 V M+S A/S RSC 225/55 R 17 97 H M+S RSC	2.2/32	2.6/38		225/55 R 17 97 V M+S A/S RSC 225/55 R 17 97 H M+S RSC	2.5 / 36	3.0 / 44
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M+S XL A/S RSC 245/45 R 18 96 Y RSC 245/45 R 18 100 V M+S XL RSC	2.4/35	2.9 /42	_	245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M+S XL A/S RSC 245/45 R 18 96 Y RSC 245/45 R 18 100 V M+S XL RSC	2.7/39	3.2 / 46
Front: 245/45 R 18 96 Y RSC	2.4/35	-		Front: 245/45 R 18 96 Y RSC	2.7 / 39	-
Rear: 275/40 R 18 99 Y RSC	-	2.4 / 35		Rear: 275/40 R 18 99 Y RSC	-	2.7 / 39
Front: 245/40 R 19 94 Y RSC	2.4/35	-		Front: 245/40 R 19 94 Y RSC	2.7/39	-

Tire size	Pressure specifications in bar/PSI		-	Tire size	Pressure specification in bar/PSI	
Rear: 275/35 R 19 96 Y RSC	-	3.0 / 44		Rear: 275/35 R 19 96 Y RSC	-	2.6 / 38
Front: 245/35 R 20 95 Y XL RSC	2.7 / 39	-		Front: 245/35 R 20 95 Y XL RSC	2.4 / 35	-
Rear: 275/30 R 20 97 Y XL RSC	-	3.2 / 46		Rear: 275/30 R 20 97 Y XL RSC	-	2.9 /42
Emergency wheel: T 135/90 R 17 104 M	FO		-	Emergency wheel: T 135/90 R 17 104 M	Speed up to 50 mph / 80 4.2 / 60	

With high-speed tuning feature

Pressure specifications

in har/PSI

Tire size

# 535i, 535d

Tire size	Pressure sp	ecifications		in bar/PSI	
	in bar/PSI		Specifications in	<b>                                      </b>	<b>†</b> /67
Specifications in bar/PSI with cold	<b>                                      </b>	<b>†</b> /Ø	bar/PSI with cold tires		( <del>-</del> )
tires					
	*	•	245/45 R 18 100	2.7 / 39	3.2 / 46
245/45 R 18 100 V M+S XL A/S RSC	2.4 / 35	2.9 /42	V M+S XL A/S RSC		
245/40 R 19 98 V M+S XL A/S RSC			245/45 R 18 96 Y RSC		
245/45 R 18 96 Y RSC			225/55 R 17 97 H M+S RSC		
225/55 R 17 97 H M+S RSC			245/45 R 18 100 V M+S XL RSC		
245/45 R 18 100 V M+S XL RSC			245/40 R 19 98 V M+S XL A/S RSC	2.8 / 41	3.3 / 48
Front: 245/45 R 18 96 Y RSC	2.4/35	-	Front: 245/45 R 18 96 Y	2.7 / 39	-
Rear: 275/40 R 18	_	2.4/35	RSC		
99 Y RSC			Rear: 275/40 R 18	-	2.7 / 39
Front: 245/40 R 19	2.4/35	-	99 Y RSC		
94 Y RSC		2.7 / 39	-		
			245/40 R 19 94 Y RSC		

Tire size	Pressure specifications in bar/PSI		
Rear: 275/35 R 19 96 Y RSC	-	3.0 / 44	
Front: 245/35 R 20 95 Y XL RSC	2.7 / 39	-	
Rear: 275/30 R 20 97 Y XL RSC	-	3.2 / 46	
Emergency wheel: T 135/90 R 17 104 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60		

#### 550i

#### Without high-speed tuning feature

Without ringht opood tarining routare						
Tire size	Pressure sp in bar/PSI	ecifications				
Specifications in bar/PSI with cold tires	<b>* † † † †</b>	· / / D				
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M+S XL A/S RSC 245/45 R 18 96 Y RSC 245/45 R 18 100 V M+S XL RSC	2.5 / 36	3.0 / 44				
Front: 245/45 R 18 96 Y RSC	2.5 / 36	-				
Rear: 275/40 R 18 99 Y RSC	-	2.5 / 36				
Front: 245/40 R 19 94 Y RSC	2.5 / 36	-				
Rear: 275/35 R 19 96 Y RSC	-	2.6 / 38				

Tire size	Pressure sp in bar/PSI	ecifications
Front: 245/35 R 20 95 Y XL RSC	2.6 / 38	-
Rear: 275/30 R 20 97 Y XL RSC	-	2.9 /42

#### With high-speed tuning feature

• .	•
Tire size	Pressure specifications in bar/PSI
Specifications in bar/PSI with cold tires	* * * * * * * / 1
245/45 R 18 100 V	2.9 / 42 3.3 / 48

M+S XL A/S RSC 245/40 R 19 98 V M+S XL A/S RSC 245/45 R 18 96 Y **RSC** 245/45 R 18 100 V M+S XL RSC Front: 245/45 R 18 2.9 /42 96 Y RSC Rear: 275/40 R 18 2.9/42 99 Y RSC Front: 245/40 R 19 2.9 /42 94 Y RSC Rear: 275/35 R 19 3.3 / 48 96 Y RSC Front: 245/35 R 20 2.9 /42 95 Y XL RSC Rear: 275/30 R 20 3.3 / 48 97 Y XL RSC

#### 528i xDrive

T'	D	! (! ! !	T'	D	! [] !	
Tire size	Pressure specifications in bar/PSI		Tire size	Pressure specifications in bar/PSI		
Specifications in bar/PSI with cold tires	* * * * +	* / 10	Specifications in bar/PSI with cold tires	* * * * -		
225/55 R 17 97 V M+S A/S RSC	2.4 / 35	2.9 /42	225/55 R 17 97 V M+S A/S RSC	2.8 / 41	3.3 / 48	
225/55 R 17 97 H M+S RSC			245/45 R 18 100 V M+S XL A/S RSC			
245/45 R 18 100 V M+S XL A/S RSC			245/40 R 19 98 V M+S XL A/S RSC			
245/40 R 19 98 V M+S XL A/S RSC			225/55 R 17 97 H M+S RSC			
245/45 R 18 96 Y RSC			245/45 R 18 96 Y RSC			
245/45 R 18 100 V M+S XL RSC			245/45 R 18 100 V M+S XL RSC			
Front: 245/45 R 18 96 Y RSC	2.4 / 35	-	Front: 245/45 R 18 96 Y RSC	2.8 / 41	-	
Rear: 275/40 R 18 99 Y RSC	-	2.4 / 35	Rear: 275/40 R 18 99 Y RSC	-	2.8 / 41	
Front: 245/40 R 19 94 Y RSC	2.4 / 35	-	Front: 245/40 R 19 94 Y RSC	2.8 / 41	-	
Rear: 275/35 R 19 96 Y RSC	-	2.6 / 38	Rear: 275/35 R 19 96 Y RSC	-	3.0 / 44	
Front: 245/35 R 20 95 Y XL RSC	2.5 / 36	-	Front: 245/35 R 20 95 Y XL RSC	2.9/42	-	
Rear: 275/30 R 20 97 Y XL RSC	-	3.0 / 44	Rear: 275/30 R 20 97 Y XL RSC	-	3.3 / 48	
Emergency wheel: T 135/90 R 17 104 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60		Emergency wheel: T 135/90 R 17 104 M		Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	

With high-speed tuning feature

**535i xDrive, 535d xDrive**Without high-speed tuning feature

Tire size	Pressure specifications in bar/PSI		Tire size	Pressure spin bar/PSI	oecifications
Specifications in bar/PSI with cold tires	<b>* † † † †</b>	**/*	Specifications in bar/PSI with cold tires	* * * * -	**/*
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M +S XL A/S RSC 245/45 R 18 96 Y RSC 225/55 R 17 97 H M+S RSC 245/45 R 18 100 V M+S XL RSC	2.5 / 36	2.9 /42	245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M +S XL A/S RSC 245/45 R 18 96 Y RSC 225/55 R 17 97 H M+S RSC 245/45 R 18 100 V M+S XL RSC	2.8 / 41	3.3 / 48
Front: 245/45 R 18 96 Y RSC	2.5 / 36	-	Front: 245/45 R 18 96 Y RSC	2.8 / 41	-
Rear: 275/40 R 18 99 Y RSC	-	2.5 / 36	Rear: 275/40 R 18 99 Y RSC	-	2.8 / 41
Front: 245/40 R 19 94 Y RSC Rear: 275/35 R 19	2.4/35	2.6/38	Front: 245/40 R 19 94 Y RSC	2.8 / 41	-
96 Y RSC Front:	2.5 / 36	-	Rear: 275/35 R 19 96 Y RSC	-	3.0 / 44
245/35 R 20 95 Y XL Rear: 275/30 R 20		3.0 / 44	Front: 245/35 R 20 95 Y XL RSC	2.9/42	-
97 Y XL	-		Rear: 275/30 R 20 97 Y	-	3.3 / 48
Emergency wheel: T 135/90 R 17 104	Speed up to a max. of 50 mph / 80 km/h		XL RSC	Cnood t	o o mov of
M 4.2 / 60 With high-speed tuning feature			Emergency wheel: T 135/90 R 17 104 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	
g opood turm					

## 550i xDrive

Tire size	Pressure specifications in bar/PSI			Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	* * * * * *	**/*		Specifications in bar/PSI with cold tires	* * * * ·	+ <b>†</b> / Ø
245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M+S XL A/S RSC 245/45 R 18 96 Y RSC 245/45 R 18 100 V M+S XL RSC	2.6 / 38	3.0 / 44	-	245/45 R 18 100 V M+S XL A/S RSC 245/40 R 19 98 V M+S XL A/S RSC 245/45 R 18 96 Y RSC 245/45 R 18 100 V M+S XL RSC	3.0 / 44	3.4 / 49
Front: 245/45 R 18 96 Y RSC	2.6 / 38	-	_	Front: 245/45 R 18 96 Y RSC	3.0 / 44	-
Rear: 275/40 R 18 99 Y RSC	-	2.6 / 38		Rear: 275/40 R 18 99 Y RSC	-	3.0 / 44
Front: 245/40 R 19 94 Y RSC	2.6 / 38	-		Front: 245/40 R 19 94 Y RSC	3.0 / 44	-
Rear: 275/35 R 19 96 Y RSC	-	2.7 / 39		Rear: 275/35 R 19 96 Y RSC	-	3.2 / 46
Front: 245/35 R 20 95 Y XL RSC	2.7 / 39	-		Front: 245/35 R 20 95 Y XL RSC	3.1 / 45	-
Rear: 275/30 R 20 97 Y XL RSC	-	3.1 / 45		Rear: 275/30 R 20 97 Y XL RSC	-	3.4 / 49

With high-speed tuning feature

# **Tire identification marks**

#### Tire size

245/45 R 18 96 Y

245: nominal width in mm

45: aspect ratio in %

R: radial tire code

18: rim diameter in inches

96: load rating, not for ZR tires

Y: speed rating, before the R on ZR tires

#### **Speed letter**

Q = up to 100 mph, 160 km/h

R = up to 106 mph, 170 km/h

S = up to 112 mph, 180 km/h

T = up to 118 mph, 190 km/h

H = up to 131 mph, 210 km/h

V = up to 150 mph, 240 km/h

W = up to 167 mph, 270 km/h

Y = up to 186 mph, 300 km/h

#### **Tire Identification Number**

DOT code: DOT xxxx xxx 2116

xxxx: manufacturer code for the tire brand

xxx: tire size and tire design

2116: tire age

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

#### Tire age

DOT ... 2116: the tire was manufactured in the 21st week of 2016.

#### Recommendation

Regardless of wear and tear, replace tires at least every 6 years.

# **Uniform Tire Quality Grading**

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

E.g.: Treadwear 200; Traction AA; Temperature A

# **DOT Quality Grades**

Treadwear

Traction AA A B C

Temperature ABC

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades.

#### **Treadwear**

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. E.g., a tire graded 150 would wear one and one-half, 1 g, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### **Traction**

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

#### **Temperature**

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger vehicle tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades Band A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

#### WARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.◀

#### **RSC - Run-flat tires**

Run-flat tires, refer to page 232, are labeled with a circular symbol containing the letters RSC marked on the sidewall.

#### M+S

Winter and all-season tires with better cold weather performance than summer tires.

#### Tire tread

#### **Summer tires**

Do not drive with a tire tread depth of less than 0.12 inches/3 mm.


There is an increased risk of hydroplaning if the tire tread depth is less than 0.12 inches/3 mm.

#### Winter tires

Do not drive with a tire tread depth of less than 0.16 inches/4 mm.

Below a tread depth of 0.16 inches/4 mm, tires are less suitable for winter operation.

#### Minimum tread depth



Wear indicators are distributed around the tire's circumference and have the legally required minimum height of 0.063 inches/1.6 mm.

They are marked on the side of the tire with TWI, Tread Wear Indicator.

# **Tire damage**

#### **General information**

Inspect your tires regularly for damage, foreign objects lodged in the tread, and tread wear.

Driving over rough or damaged road surfaces, as well as debris, curbs and other obstacles can cause serious damage to wheels, tires and suspension parts. This is more likely to occur with low-profile tires, which provide less cushioning between the wheel and the road. Be careful to avoid road hazards and reduce your speed, especially if your vehicle is equipped with low-profile tires.

Indications of tire damage or other vehicle malfunctions:

- Unusual vibrations while driving.
- Unusual handling such as a strong tendency to pull to the left or right.

Damage can, e.g., be caused by driving over curbs, road damage, or similar things.

#### **Safety information**

WARNING

Damaged tires can lose tire inflation pressure, which can lead to loss of vehicle control. There is a risk of an accident. If tire damage is suspected while driving, immediately reduce speed and stop. Have wheels and tires checked. For this purpose, drive carefully to the nearest dealer's service center or another qualified service center or repair shop. Have vehicle towed or transported as needed.

**MARNING** 

Damaged tires can lose tire inflation pressure, which can lead to loss of vehicle control. There is a risk of an accident. Do not repair damaged tires, but have them replaced. ◀

# **Changing wheels and tires**

# Mounting

Have mounting and wheel balancing carried out by a dealer's service center or another qualified service center or repair shop.

#### Wheel and tire combination

You can ask the dealer's service center or another qualified service center or repair shop about the correct wheel/tire combination and wheel rim versions for the vehicle.

Incorrect wheel and tire combinations impair the function of a variety of systems such as ABS or DSC.

To maintain good handling and vehicle response, use only tires with a single tread configuration from a single manufacturer.

Following tire damage, have the original wheel and tire combination remounted on the vehicle as soon as possible.

#### WARNING

Wheels and tires which are not suitable for your vehicle can damage parts of the vehicle, e.g., due to contact with the body due to tolerances despite the same official size rating. There is a risk of an accident. The manufacturer of your vehicle strongly suggests that you use wheels and tires that have been recommended by the vehicle manufacturer for your vehicle type.

#### Recommended tire brands



For each tire size, BMW recommends certain tire brands. These can be identified by a star on the tire sidewall.

#### **New tires**

Tire traction is not optimal due to manufacturing circumstances when tires are brand-new; they achieve their full traction potential after a break-in time.

Drive conservatively for the first 200 miles/300 km.

#### Retreaded tires

The manufacturer of your vehicle does not recommend the use of retreaded tires.

WARNING

Retreaded tires can have different tire casing structures. With advanced age the service life can be limited. There is a risk of an accident. The manufacturer of your vehicle does not recommend the use of retreaded tires.

#### Winter tires

Winter tires are recommended for operating on winter roads.

Although so-called all-season M+S tires provide better winter traction than summer tires, they do not provide the same level of performance as winter tires.

#### **Maximum speed of winter tires**

If the maximum speed of the vehicle is higher than the permissible speed for the winter tires, then attach a corresponding information label/ sticker in the field of view. The label is available from a dealer's service center or another qualified service center or repair shop.

With mounted winter tires, observe and adhere to the permissible maximum speed.

#### **Run-flat tires**

If you are already using run-flat tires, for your own safety you should replace them only with the same kind. No spare tire is available in the case of a flat tire. Further information is available from a dealer's service center or another qualified service center or repair shop.

## **Rotating wheels between axles**

Different wear patterns can occur on the front and rear axles depending on individual driving conditions. The tires can be rotated between the axles to achieve even wear. Further information is available from a dealer's service center or another qualified service center or repair shop. After rotating, check the tire pressure and correct, if needed.

Rotating the tires between the axes is not permissible on vehicles with different tire sizes or rim sizes on the front and rear axles.

#### Storage

Store wheels and tires in a cool, dry place with as little exposure to light as possible.

Always protect tires against all contact with oil, grease and fuels.

Do not exceed the maximum tire inflation pressure indicated on the side wall of the tire.

#### **Run-flat tires**

#### Label



RSC label on the tire sidewall.

The wheels consist of tires that are self-supporting, to a limited degree, and possibly special rims.

The support of the sidewall allows the tire to remain drivable to a restricted degree in the event of a tire inflation pressure loss.

Follow the instructions for continued driving with a flat tire.

## **Changing run-flat tires**

For your own safety, only use run-flat tires. No spare tire is available in the case of a flat tire.

A dealer's service center will be glad to answer additional questions at any time.

# Repairing a flat tire

#### Safety measures

- Park the vehicle as far away as possible from passing traffic and on solid ground.
- Switch on the hazard warning system.
- Secure the vehicle against rolling away by setting the parking brake.

- Turn the steering wheel until the front wheels are in the straight-ahead position and engage the steering wheel lock.
- Have all vehicle occupants get out of the vehicle and ensure that they remain outside the immediate area in a safe place, such as behind a quardrail.
- If necessary, set up a warning triangle at an appropriate distance.

# **Mobility System**

#### Concept

With the Mobility System, minor tire damage can be sealed temporarily to enable continued travel. To accomplish this, sealant is pumped into the tires, which seals the damage from the inside.

The compressor can be used to check the tire inflation pressure.

#### **General information**

- Follow the instructions on using the Mobility System found on the compressor and sealant container.
- Use of the Mobility System may be ineffective if the tire puncture measures approx. 1/8 inches/4 mm or more.
- Contact a dealer's service center or another qualified service center or repair shop if the tire cannot be made drivable.
- If possible, do not remove foreign bodies that have penetrated the tire.
- Pull the speed limit sticker off the sealant container and apply it to the steering wheel.
- The use of a sealant can damage the TPM wheel electronics. In this case, have the electronics checked at the next opportunity and have them replaced, if needed.

#### **Storage**

The Mobility System is located under the cargo floor panel.


#### Sealant container



- ▶ Sealant container, arrow 1.
- Filling hose, arrow 2.

Observe use-by date on the sealant container.

#### Compressor




- 1 Holder for sealant container
- 2 Compressor
- 3 Connector/cable for socket
- 4 Connection hose
- 5 On/off switch
- 6 Inflation pressure dial
- 7 Reduce inflation pressure

#### Filling the tire with sealant


1. Shake the sealant container.



2. Pull the connection hose fully out of the compressor housing. Do not kink the hose.




Screw the connection hose onto the connector of the sealant container.




4. Insert the sealant container on the compressor housing in an upright position.




Screw the filling hose of the sealant container onto the tire valve of the nonworking wheel.



With the compressor switched off, insert the plug into the power socket inside the vehicle.



7. With the ignition turned on or the engine running, switch on the compressor.



DANGER

If the exhaust pipe is blocked or ventilation is insufficient, harmful exhaust gases can enter into the vehicle. The exhaust gases contain carbon monoxide, an odorless and colorless but highly toxic gas. In enclosed areas, exhaust gases can also accumulate outside of the vehicle. There is danger to life. Keep the exhaust pipe free and ensure sufficient ventilation.

NOTE

The compressor can overheat during extended operation. There is a risk of property damage. Do not run the compressor for more than 10 min.

Let the compressor run for approx. 3 to 8 minutes to fill the tire with sealant and achieve a tire inflation pressure of approx. 2.5 bar.

While the tire is being filled with sealant, the tire inflation pressure may sporadically reach approx. 5 bar. Do not switch off the compressor at this point.

If a tire inflation pressure of 2 bar is not reached:

- 1. Switch off the compressor.
- 2. Unscrew the filling hose from the wheel.
- 3. Drive 33 ft/10 m forward and back to distribute the sealant in the tire.
- 4. Inflate the tire again using the compressor.

If a tire inflation pressure of 2 bar cannot be reached, contact your dealer's service center or another qualified service center or repair shop.

#### **Stowing the Mobility System**

- Unscrew the filling hose of the sealant container from the wheel.
- Unscrew the connection hose of the compressor from the sealant container.
- Connect the filling hose of the sealant container previously connected to the tire valve with the available connector on the sealant container.
  - This prevents leftover sealant from escaping from the container.
- Wrap the empty sealant container in suitable material to avoid dirtying the cargo area.
- Stow the Mobility System back in the vehicle.

#### Distributing the sealant

Immediately drive approx. 5 miles/10 km to ensure that the sealant is evenly distributed in the tire.

Do not exceed a speed of 50 mph/80 km/h.

If possible, do not drive at speeds less than 12 mph/20 km/h.

# Correcting the tire inflation pressure

- 1. Stop at a suitable location.
- Screw the connection hose of the compressor directly onto the tire valve stem.
- Insert the connector into the power socket inside the vehicle.
- 4. Correct the tire inflation pressure to 2.5 bar.
  - Increase pressure: with the ignition turned on or the engine running, switch on the compressor.

➤ To reduce the pressure: press the button on the compressor.

#### **Continuing the trip**

Do not exceed the maximum permissible speed of 50 mph/80 km/h.

Reinitialize the Flat Tire Monitor.

Reinitialize the Tire Pressure Monitor.

Replace the nonworking tire and the sealant container of the Mobility System as soon as possible.

#### **Snow chains**

#### Fine-link snow chains

The manufacturer of your vehicle recommends use of fine-link snow chains. Certain types of fine-link snow chains have been tested by the manufacturer of the vehicle and recommended as road-safe and suitable.

Information regarding suitable snow chains is available from a dealer's service center or another qualified service center or repair shop.

#### Use

**№** WARNING

With the mounting of snow chains on unsuitable tires, the snow chains can come into contact with vehicle parts. There is a risk of accidents or risk of property damage. Only mount snow chains on tires that are designated by their manufacturer as suitable for the use of snow chains.

Use only in pairs on the rear wheels, equipped with the tires of the following size:

- > 225/55 R 17.
- > 245/45 R 18.

Follow the snow chain manufacturer's instructions.

Make sure that the snow chains are always sufficiently tight. Re-tighten as needed ac-

cording to the snow chain manufacturer's instructions.

Do not initialize the Flat Tire Monitor after mounting snow chains, as doing so may result in incorrect readings.

Do not initialize the Tire Pressure Monitor after mounting snow chains, as doing so may result in incorrect readings.

When driving with snow chains, briefly activate Dynamic Traction Control, if needed.

#### Maximum speed with snow chains

Do not exceed a speed of 30 mph/50 km/h when using snow chains.

#### Snow chain detection

#### Concept

When using snow chains, settings should be made via iDrive for the snow chains being applied.

The snow chain detection system supports you by automatically showing the detected state on the Control Display.

When snow chains are in use, the rear axle steering of the Integral Active Steering is deactivated automatically.

At speeds above the maximum permitted speed with snow chains of 30 mph/50 km/h, the rear axle steering is activated again automatically.

#### **Activating the status**

- 1. "Settings"
- "Tire chains"
- 3. "Tire chains installed"

#### **Automatic detection**

If functioning properly:

Snow chains are mounted. Settings are not activated ■.

After you drive a short distance, a Check Control message is shown and the state is activated automatically.

Confirm the automatic activation.

Snow chains are not mounted. Settings are activated .

At speeds above 30 mph/50 km/h, a Check Control message is displayed. Deactivate the status manually.

If not functioning properly:

 Snow chains are mounted. Settings are not activated .

A Check Control message is not displayed. The automatic detection system is malfunctioning. Activate the status manually.

# Activating/deactivating rear axle steering

If the status indicating that snow chains are in use is activated, the rear axle steering is deactivated automatically.

At speeds above 30 mph/50 km/h, the rear axle steering is activated again, even though snow chains are in use.

# **Changing wheels/tires**

#### **General information**

When using run-flat tires or tire sealants, a tire does not always need to be changed immediately in the event of pressure loss due to a flat tire.

If needed, the tools for changing wheels are available as accessories from a dealer's service center or another qualified service center or repair shop.

# Safety information WARNING

On soft or slippery ground, e.g., snow, ice, tiles, etc., the vehicle jack can slip away. There is a risk of injury. If possible, change the

tire/wheel on a flat, solid and slip-resistant surface. ◀

#### 

The vehicle jack is only provided for short-term lifting of the vehicle for wheel changes. Even if all safety measures are observed, there is a risk of the raised vehicle falling, if the vehicle jack tilts over. There is a risk of injuries or danger to life. If the vehicle is raised, do not lie under the vehicle and do not start the engine.

#### WARNING

The vehicle jack is optimized for lifting the vehicle and for the jacking points on the vehicle only. There is a risk of injury. Do not lift any other vehicle or cargo using the vehicle jack.

#### WARNING

If the vehicle jack is not inserted into the designated jacking point, damage to the vehicle may occur while cranking the vehicle up, or the vehicle jack can slip away. There is a risk of injury or risk of property damage. Make sure that the vehicle jack is inserted into the jacking point next to the wheel house while cranking the vehicle up.

# Securing the vehicle against rolling

#### **General information**

The vehicle manufacturer recommends to additionally secure the vehicle against rolling away when changing a wheel.

#### On a level surface



Place chocks or other suitable objects, for example a rock, in front of and behind the wheel that is diagonally opposite to the wheel that you wish to change.

#### On slight down-hill grades




If a wheel needs to be changed on a slight down-hill grade, place wheel chocks or other suitable objects, e.g. a stone, under the wheels of the front and rear axle.

#### Preparing the vehicle

- Change the wheel as far away as possible from passing traffic.
- Park the vehicle on solid, non-slip and level ground.
- Switch on the hazard warning system.
- Set the parking brake.
- Engage a gear or selector lever position P.
- As soon as permitted by the traffic flow, have all vehicle occupants get out of the vehicle and ensure that they remain out-

- side the immediate area in a safe place, such as behind a guardrail.
- Depending on the equipment version, get tools and the emergency wheel from the vehicle.
- If necessary, set up a warning triangle or portable hazard warning lamp at an appropriate distance.
- Do not place wood blocks or similar items under the vehicle jack; otherwise, it cannot reach its carrying capacity because of the restricted height.
- Secure the vehicle additionally against rolling.
- Loosen the lug bolts a half turn.

#### Jacking points for the vehicle jack



The jacking points for the vehicle jack are located at the positions shown.


# Jacking up the vehicle

 Hold the vehicle jack with one hand, arrow 1, and grasp the crank, arrow 2, with the other hand.


WARNING

Hands and fingers can be jammed when using the vehicle jack. There is a risk of injury. Comply with the described hand


position and do not change this position while using the vehicle jack.◀




Insert the vehicle jack into the rectangular recess of the jacking point closest to the wheel to be changed.




Extend the vehicle jack by turning the crank clockwise.



4. Make sure that the vehicle jack foot is extended vertically.



Make sure that the vehicle jack foot stands vertically and perpendicularly beneath the jacking point after extending the vehicle jack.



 Crank up the vehicle jack until the entire surface of the jack is in contact with the ground and the wheel in question is raised a maximum of 1.2 inches/3 cm off the ground.

#### Wheel mounting

Mount a maximum of one emergency wheel.

- 1. Unscrew the lug bolts and remove the wheel.
- Put the new wheel or emergency wheel on and hand-tighten at least two bolts in a crosswise pattern.
  - If non-original light-alloy wheels of the vehicle manufacturer are mounted, the accompanying lug bolts may have to be used as well.
- Hand-tighten the remaining lug bolts and tighten all bolts well in a crosswise pattern.

- Turn the crank of the vehicle jack counterclockwise to retract the vehicle jack and lower the vehicle.
- 5. Remove the vehicle jack.

#### After the wheel change


- 1. Tighten the lug bolts crosswise. The tightening torque is 101 lb ft/140 Nm.
- Stow the nonworking wheel in the cargo area.
  - The nonworking wheel cannot be stored under the cargo floor panel because of its size.
- Check tire inflation pressure at the next opportunity and correct as needed.
- Reinitialize the Flat Tire Monitor.
   Reset the Tire Pressure Monitor.
- 5. Check to make sure the lug bolts are tight with a calibrated torque wrench.
- Drive to the nearest dealer's service center or another qualified service center or repair shop to have the damaged tire replaced.

# **Engine compartment**

# Vehicle features and options

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# Important features in the engine compartment



- Vehicle identification number
- 2 Jump-starting, negative battery terminal
- 3 Washer fluid reservoir

- 4 Jump-starting, positive battery terminal
- 5 Oil filler neck
- 6 Coolant reservoir

# **Hood**

# **Safety information**

WARNING
Improperly executed work in the engine compartment can damage vehicle components and impair vehicle functions. There is a risk of personal and property damage. The

manufacturer of your vehicle recommends that, in the effort to avoid such risks, work in the engine compartment be performed by a dealer's service center or another qualified service center or repair shop.

#### WARNING

The engine compartment accommodates moving components. Certain components in the engine compartment can also move with the vehicle switched off, e.g., the radiator fan. There is a risk of injury. Do not reach into the area of moving parts. Keep articles of clothing and hair away from moving parts.

#### WARNING

There are protruding parts, e.g., locking hook, on the inside of the hood. There is a risk of injury. If the hood is open, pay attention to protruding parts and keep these areas clear.

#### WARNING

An incorrectly locked hood can open while driving and restrict visibility. There is a risk of an accident. Stop immediately and correctly close the hood.

#### WARNING


Body parts can be jammed when opening and closing the hood. There is a risk of injury. Make sure that the area of movement of the hood is clear during opening and closing.

#### NOTE


Folded-away wipers can be jammed when the hood is opened. There is a risk of property damage. Make sure that the wipers with the wiper blades mounted are folded down onto the windshield before opening the hood.

#### **Opening the hood**

Pull the lever.



Press the release handle and open the hood.



3. Be careful of protruding parts on the hood.



# **Closing the hood**



Let the hood drop from a height of approx. 16 inches/40 cm and push down on it to lock it fully.

The hood must engage on both sides.

# **Engine oil**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

#### **General information**

The engine oil consumption is dependent on the driving style and driving conditions.

The engine oil consumption can increase in the following situations, for example:

- Sporty driving style.
- Break-in of the engine.
- ▶ Idling of the engine.
- With use of engine oil types that are classified as not suitable.

Therefore, regularly check the engine oil level after refueling.

The vehicle is equipped with electronic oil measurement.

The electronic oil measurement has two measuring principles:

- Status display.
- Detailed measurement.

# **Electronic oil measurement**

#### Status display

#### Concept

The engine oil level is monitored electronically while driving and shown on the Control Display.

If the engine oil level reaches the minimum level, a Check Control message is displayed.

#### Requirements

A current measured value is available after approx. 30 minutes of driving. During a shorter trip, the status of the last, sufficiently long trip is displayed.

With frequent short-distance trips, regularly perform a detailed measurement.

## Displaying the engine oil level

Via iDrive:

- 1. "Vehicle info"
- "Vehicle status"
- "Engine oil level"

The engine oil level is displayed.

# Engine oil level display messages

Different messages appear on the display depending on the engine oil level. Pay attention to these messages.

If the engine oil level is too low within the next 125 miles/200 km, add engine oil.



A red indicator lamp indicates too high engine oil pressure.

NOTE

An engine oil level that is too low causes engine damage. There is a risk of property damage. Immediately add engine oil. ◀

Take care not to add too much engine oil.

**№** NOTE

Too much engine oil can damage the engine or the catalytic converter. There is a risk of property damage. Do not add too much engine oil. When too much engine oil is added, have oil level corrected by a dealer's service center or another qualified service center or repair shop.◀

#### **Detailed measurement**

#### Concept

In the detailed measurement the engine oil level is checked when the vehicle is stationary, and displayed via a scale.

Gasoline engine:

If the engine oil level reaches the minimum level, a Check Control message is displayed.

Diesel engine:

If the engine oil level reaches the minimum level or an overfilling is detected, a Check Control message is displayed.

During the measurement, the idle speed is increased somewhat.

#### **General information**

A detailed measurement is only possible with certain engines.

#### Requirements

- Vehicle is parked in a horizontal position.
- Manual transmission: shift lever in neutral position, clutch and accelerator pedals not depressed.
- Steptronic transmission: selector lever in selector lever position N or P and accelerator pedal not depressed.
- Engine is running and is at operating temperature.

#### Performing a detailed measurement

In order to perform a detailed measurement of the engine oil level:

- 1. "Vehicle info"
- 2. "Vehicle status"
- 3. "Measure engine oil level"
- 4. "Start measurement"

The engine oil level is checked and displayed via a scale.

Time: approx. 1 minute.

# Adding engine oil

#### General information

Only add engine oil when the message is displayed in the instrument cluster. The quantity to be added is indicated in the message displayed in the instrument cluster.

Switch off the ignition and safely park the vehicle before engine oil is added.

Take care not to add too much engine oil.

# **Safety information**

WARNING

Operating materials, e.g., oils, greases, coolants, fuels, can contain harmful ingredients. There is a risk of injuries or danger to life. Observe the instructions on the containers. Avoid the contact of articles of clothing, skin or eyes with operating materials. Do not refill operating materials into different bottles. Store operating materials out of reach of children.

**№** NOTE

An engine oil level that is too low causes engine damage. There is a risk of property damage.

Add engine oil within the next 125 miles/200 km. ◀

NOTE


Too much engine oil can damage the engine or the catalytic converter. There is a risk of property damage. Do not add too much engine oil. When too much engine oil is added, have oil level corrected by a dealer's service center or another qualified service center or repair shop.

#### **Overview**

The oil filler neck is located in the engine compartment, refer to page 241.

#### Opening the oil filler neck

- 1. Opening the hood, refer to page 242
- 2. Turn the oil filler neck counter-clockwise.



3. Add engine oil.

# Engine oil types to add

#### **General information**

The engine oil quality is critical for the life of the engine.

#### **Safety information**

NOTE

Oil additives can damage the engine.

There is a risk of property damage. Do not use oil additives.  $\blacktriangleleft$ 

NOTE

Incorrect engine oil can cause malfunctions in the engine or damage it. There is a risk of property damage. When selecting an engine oil, make sure that the engine oil has the correct oil rating.

#### Suitable engine oil types

You can add engine oils that meet the following oil rating standards:

#### Gasoline engine

BMW Longlife-01 FE.

BMW Longlife-14 FE+.

The oil rating BMW Longlife-14 FE+ is only suitable for particular gasoline engines.

#### Diesel engine

BMW Longlife-12 FE.

More information about suitable engine oil ratings and viscosities of engine oils is available at a dealer's service center or another qualified service center or repair shop.

## Alternative engine oil types

If an engine oil suitable for continuous use is not available, up to 1 US quart/liter of an engine oil with the following oil rating can be added:

#### Gasoline engine

BMW Longlife-01.

API SL or superior oil rating.

#### Diesel engine

BMW Longlife-04.

API SL or superior oil rating.

#### Viscosity grades

#### Gasoline engine:

When selecting an engine oil, make sure that the engine oil has the viscosity grade SAE 0W-30 or SAE 0W-20. Alternatively, also engine oils with viscosity grades SAE 5W-20, SAE 5W-30, SAE 0W-40 or SAE 5W-40 can be used.

The viscosity grades SAE 0W-20 or SAE 5W-20 are only suitable for particular engines.

#### Diesel engine:

When selecting an engine oil, make sure that the engine oil has the viscosity grade SAE 0W-30. Alternatively, also engine oils with viscosity grades SAE 5W-30, SAE 0W-40 or SAE 5W-40 can be used.

More information about suitable engine oil ratings and viscosities of engine oils can be requested from a dealer's service center or another qualified service center or repair shop.

# **Engine oil change**

NOTE

Engine oil that is not changed in timely fashion can cause increased engine wear and thus engine damage. There is a risk of property damage. Do not exceed the service data indicated in the vehicle.

The vehicle manufacturer recommends that you have a dealer's service center or another qualified service center or repair shop change the engine oil.

BMW recommends
Original BMW Engine Oil.

# Coolant

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

#### **General information**

Not all commercially available additives are suitable for the vehicle. Information about suitable additives is available from a dealer's service center or another qualified service center or repair shop.

# **Safety information**

WARNING

With the engine hot and the cooling system open, coolant can escape and lead to scalding. There is a risk of injury. Only open the cooling system with the engine cooled down.

WARNING

Additives are harmful and incorrect additives can damage the engine. There is a risk of injury and risk of property damage. Do not allow additives to come into contact with skin, eyes or articles of clothing. Use suitable additives only.

# **Coolant level**

#### **General information**

If there is no Min. and Max. mark in the filler neck of the coolant reservoir, have the coolant level checked, if needed, by a dealer's service center or another qualified service center or repair shop and add coolant as needed.

#### Overview

Depending on the engine installation, the coolant reservoir is located on the right side or the left side of the engine compartment.

#### Checking

- 1. Let the engine cool.
- Turn the lid of the coolant reservoir slightly counterclockwise to allow any excess pressure to dissipate, then open it.



- 3. Open the coolant reservoir lid.
- The coolant level is correct if it lies between the minimum and maximum marks in the filler neck.



#### **Adding**

- 1. Let the engine cool.
- 2. Turn the lid of the coolant reservoir slightly counterclockwise to allow any excess pressure to dissipate, then open it.



- 3. If the coolant is low, slowly add coolant up to the specified level; do not overfill.
- Turn the lid until there is an audible click.
   The arrows on the coolant reservoir and the lid must point towards one another.
- 5. Have the cause of the coolant loss eliminated as soon as possible.

# **Disposal**



Comply with the relevant environmental protection regulations when disposing of coolant and coolant additives.

# **Maintenance**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# **BMW** maintenance system

The maintenance system indicates required maintenance measures, and thereby provides support in maintaining road safety and the operational reliability of the vehicle.

In some cases, scopes and intervals may vary according to the country-specific version. Replacement work, spare parts, fuels and lubricants, and wear materials are calculated separately. Further information is available from a dealer's service center or another qualified service center or repair shop.

# **Condition Based Service CBS**

Sensors and special algorithms take into account the driving conditions of the vehicle.

Based on this, Condition Based Service recognizes the maintenance requirements.

The system makes it possible to adapt the amount of maintenance corresponding to your user profile.

Information on service requirements can be displayed on the Control Display.

#### Service data in the remote control

Information on the required maintenance is continuously stored in the remote control. The dealer's service center can read this data out and suggest a maintenance scope for the vehicle.

Therefore, hand the service advisor the remote control with which the vehicle was driven most recently.

#### Storage periods

Storage periods during which the vehicle battery was disconnected are not taken into account.

If this occurs, have a dealer's service center or another qualified service center or repair shop update the time-dependent maintenance procedures, such as checking brake fluid and, if necessary, changing the engine oil and the microfilter/activated-charcoal filter.

# Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models

Please consult your Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models for additional information on service requirements.

The manufacturer of your vehicle recommends that maintenance and repair be performed by a dealer's service center or another qualified service center or repair shop. Records of regular maintenance and repair work should be retained.

# Socket for OBD Onboard Diagnosis

#### **Safety information**

NOTE

The socket for Onboard Diagnosis is an intricate component intended to be used in conjunction with specialized equipment to check the vehicle's primary emissions system. Improper use of the socket for Onboard Diagnosis, or contact with the socket for Onboard Diagnosis for other than its intended purpose, can cause vehicle malfunctions and creates risks of personal and property damage. Given the foregoing, the manufacture of your vehicle strongly recommends that access to the socket for Onboard Diagnosis be limited to a dealer's service center or another qualified service center or repair shop or other persons that have the specialized training and equipment for purposes of properly utilizing the socket for Onboard Diagnosis. ◄

▶ The warning lamp flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.

Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.

#### **Position**



There is an OBD socket on the driver's side for checking the primary components in the vehicle's emissions.

#### **Emissions**



The warning lamp lights up: Emissions are deteriorating. Have the vehicle checked as soon as possible.

# **Replacing components**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

# Onboard vehicle tool kit



The onboard vehicle tool kit is located in a fold-down cover in the tailgate.

Unscrew the wing nut to open.

# Wiper blade replacement

# **Safety information**

NOTE

If the wiper arm falls onto the windshield without the wiper blades installed, the windshield can be damaged. There is a risk of property damage. Secure the wiper arm when replacing the wiper blades and do not fold down the wipers without the wiper blades installed.

#### Replacing the wiper blades

- 1. To change the wiper blades, fold up, refer to page 80, the wiper arms.
- 2. Fold up the wipers.



- Position the wiper blade in a horizontal position.
- 4. Remove the wiper blade toward one side.



- 5. Insert the new wiper blade in reverse order of removal until it locks in place.
- 6. Fold down the wipers.

# Lamp and bulb replacement

#### **General information**

# **Lights and bulbs**

Lights and bulbs make an essential contribution to vehicle safety.

The vehicle manufacturer recommends that you have the relevant work carried out a deal-

er's service center or another qualified service center or repair shop.

A spare lamp box is available from a dealer's service center or another qualified service center or repair shop.

Observe the safety information, refer to page 253.

#### **Light-emitting diodes (LEDs)**

Some items of equipment use light-emitting diodes installed behind a cover as a light source. These light-emitting diodes, which are related to conventional lasers, are officially designated as Class 1 light-emitting diodes.

Observe the safety information, refer to page 253.

#### **Headlight glass**

Condensation can form on the inside of the external lights in cool or humid weather. When driving with the lights switched on, the condensation evaporates after a short time. The headlight glass does not need to be changed.

If despite driving with the lights switched on, increasing humidity forms, e.g., water droplets in the lamp, the manufacturer of your vehicle recommends having it checked by a dealer's service center or another qualified service center or repair shop.

## **Headlight setting**

The headlight adjustments can be affected by changing lights and bulbs. After the headlight adjustment was changed, have it checked and, if necessary, corrected by a dealer's service center or another qualified service center or repair shop.

#### **Safety information**

## **Lights and bulbs**

WARNING
Bulbs can get hot during operation. Contact with the bulbs can cause burns. There is a risk of injury. Only change bulbs after they have cooled off.

WARNING

Work on switched-on lighting systems can cause short circuits. There is a risk of injury or risk of property damage. When working on the lighting system, switch off the lamps in question. If necessary, heed the bulb manufacturer's instructions.

NOTE

Dirty bulbs have a reduced service life.
There is a risk of property damage. Do not hold new bulbs with your bare hands. Use a clean cloth or something similar, or hold the bulb by its base.

## **Xenon headlights**

DANGER

There can be high voltage in the lighting system. There is danger to life. The manufacturer of your vehicle recommends that the work on the lighting system including bulb replacement be performed by a dealer's service center or another qualified service center or repair shop.

## Light-emitting diodes (LEDs)


WARNING

Too intensive brightness can irritate or damage the retina of the eye. There is a risk of injury. Do not look directly into the headlights or other light sources. Do not remove the LED covers.

#### Front lights, bulb replacement

#### **Xenon headlights**

#### Overview



- Corner-illuminating lights
- 2 Parking lamp, daytime running lights
- 3 Low beams/high beams
- 4 Turn signal

## Safety information DANGER

There can be high voltage in the lighting system. There is danger to life. The manufacturer of your vehicle recommends that the work on the lighting system including bulb replacement be performed by a dealer's service center or another qualified service center or repair shop.

## Parking lights and roadside parking lamp

Observe the safety information, refer to page 253.

These lights feature LED technology.

In the case of a malfunction, contact a dealer's service center or another qualified service center or repair shop.

#### Accessing the bulbs



Remove the screws and fold down the lid.

#### Turn signal

Observe the safety information, refer to page 253.

The illustration shows the left side of the engine compartment.

24-watt bulb, PY.



Unscrew the lid, remove it, and change the bulb.

#### **Corner-illuminating lights**

Observe the safety information, refer to page 253.


The illustration shows the left side of the engine compartment.

#### 55-watt bulb, H7.


Fold open the cover in the engine compartment.



2. Unscrew the lid and remove it.




Unscrew the bulb holder counterclockwise.



- 4. Remove the bulb and replace it.
- 5. Insert the new bulb and attach the cover in the reverse order.

#### **LED** headlights

#### Overview



- 1 Corner-illuminating lights
- 2 Low beams/high beams
- 3 Parking lamp, daytime running lights
- 4 Turn signal
- 5 Side marker lights

#### **Light-emitting diodes (LEDs)**

All front lamps and side turn signals are designed with LED technology.

In the case of a malfunction, contact a dealer's service center or another qualified service center or repair shop.

## **LED** front fog lights


These front fog lights are made using LED technology. In the case of a malfunction, contact a dealer's service center or another qualified service center or repair shop.

## Turn signal in exterior mirror

The turn signals in the exterior mirrors feature LED technology. In the case of a malfunction, contact a dealer's service center or another qualified service center or repair shop.

#### Tail lamps, bulb replacement

#### **Overview**



- Turn signal
- 2 Reversing lamp
- 3 Inside brake lamp
- 4 Rear lamp
- 5 Outside brake lamp
- 6 Rear reflector

## Turn signal, outer brake, tail, and license plate lights

Observe the safety information, refer to page 253.


These lights feature LED technology.

In the case of a malfunction, contact a dealer's service center or another qualified service center or repair shop.

## Lights in the tailgate

### Access to the lights

 Remove the three screws using the screw driver from the onboard vehicle tool kit.



#### 2. Fold away the cover.




#### Inside brake lamp

Observe the safety information, refer to page 253.

21-watt bulb, H21W.



The illustration shows the position of the bulb in the installed bulb holder.



Squeeze the clips together and remove the bulb holder.

Press the bulb into the bulb holder, turn counterclockwise and remove.


#### **Reversing lamp**

Observe the safety information, refer to page 253.

16-watt bulb, W16W.



The illustration shows the position of the bulb in the installed bulb holder.



Squeeze the clips together and remove the bulb holder.

Pull out the bulb and replace it.

## **Vehicle battery**

#### **Maintenance**

The battery is maintenance-free.

The added amount of acid is sufficient for the service life of the battery.

More information about the battery can be requested from a dealer's service center or another qualified service center or repair shop.

#### **Battery replacement**

 $\Lambda$ 

NOTE

Vehicle batteries that are not compatible can damage vehicle systems and impair vehicle functions. There is a risk of personal and property damage. Only vehicle batteries that are compatible with your vehicle type should be installed in your vehicle. Information on compatible vehicle batteries is available at your dealer's service center.

After a battery replacement, the manufacturer of your vehicle recommends that the vehicle battery be registered on the vehicle by a dealer's service center or another qualified service center or repair shop to ensure that all comfort features are fully available and that any Check Control messages of these comfort features are no longer displayed.

#### Charging the battery

#### **General information**

Make sure that the battery is always sufficiently charged to guarantee that the battery remains usable for its full service life.



A discharged battery is indicated by a red indicator lamp.

The battery may need to be charged in the following cases:

- When making frequent short-distance drives.
- If the vehicle is not used for more than a month.

## **Safety information**

NOTE

Battery chargers for the vehicle battery can work with high voltages and currents, which means that the 12 volt on-board network can be overloaded or damaged. There is a risk of property damage. Only connect battery chargers for the vehicle battery to the

starting aid terminals in the engine compartment.◀

#### Starting aid terminals

In the vehicle, only charge the battery via the starting aid terminals, refer to page 261, in the engine compartment with the engine off.

#### Power failure

After a power loss, some equipment needs to be newly initialized or individual settings updated, for example:

- Seat, mirror, and steering wheel memory: store the positions again.
- Time: update.
- Date: update.
- Glass sunroof: initialize the system.

#### Disposing of old batteries




Have old batteries disposed of by a dealer's service center or another qualified service center or repair shop

or take them to a collection point.

Maintain the battery in an upright position for transport and storage. Secure the battery so that it does not tip over during transport.

#### In the glove compartment



Push the handle up, arrow 1, and open the lid, arrow 2.

#### In the cargo area



Open the cover on the right side trim, arrow.

Information on the fuse types and locations is found on a separate sheet.

## **Fuses**

#### **General information**

Plastic tweezers and information on the fuse types and locations are stored in the fuse box in the cargo area.

## Safety information WARNING

Incorrect and repaired fuses can overload electrical lines and components. There is a risk of fire. Never attempt to repair a blown fuse. Do not replace a nonworking fuse with a substitute of another color or amperage rating.

## **Breakdown assistance**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## **Hazard warning flashers**



The button is located in the center console.

The red lamp in the button flashes with the hazard warning flashers switched on.

## Intelligent emergency call

## Concept

In case of an emergency, an Emergency Request can be made through the system.

#### **General information**

Only press the SOS button in an emergency.

For technical reasons, the Emergency Request cannot be guaranteed under unfavorable conditions.

#### **Overview**



SOS button in the roofliner

#### Requirements

- ➤ The SIM card integrated in the vehicle has been activated.
- The radio-ready state is switched on.
- The Assist system is functional.

## **Initiating an Emergency Request**

- 1. Press the cover briefly to open it.
- 2. Press the SOS button until the LED at the button lights up green.
- The LED illuminates green when the Emergency Request has been initiated.
  - If a cancel prompt appears on the Control Display, the Emergency Request can be aborted.
  - If the situation allows, wait in your vehicle until the voice connection has been established.
- The LED flashes green when a connection to the BMW Response Center has been established.
  - When the Emergency Request is received at the BMW Response Center, the BMW Response Center contacts you and takes further steps to help you.

Even if you are unable to respond, the BMW Response Center can take further steps to help you under certain circumstances.

For this, data is transmitted to the BMW Response Center which serves to determine the necessary rescue measures. E.g., the current position of the vehicle, if it can be established.

▶ If the LED is flashing green, but the BMW Response Center can no longer be heard via the speaker, you can nevertheless still be heard at the BMW Response Center.

## Initiating an Emergency Request automatically

Under certain conditions, an Emergency Request is automatically initiated immediately after a severe accident. Automatic Collision Notification is not affected by pressing the SOS button.

## **Roadside Assistance**

## Service availability

Roadside Assistance can be reached around the clock in many countries. You can obtain assistance there in the event of a vehicle breakdown

#### **Roadside Assistance**

The Roadside Assistance phone number can be viewed via iDrive or a connection to Roadside Assistance can be established directly.

## Warning triangle



The warning triangle is located in the container on the inside of the tailgate.

Unscrew the wing nut to open.

## First-aid kit

#### **General information**

Some of the articles have a limited service life.

Check the expiration dates of the contents regularly and replace any expired items promptly.

## Storage



The first-aid kit is located in the container on the inside of the tailgate.

Unscrew the wing nut to open.

## **Jump-starting**

#### **General information**

If the battery is discharged, the engine can be started using the battery of another vehicle and two jumper cables. Only use jumper cables with fully insulated clamp handles.

#### **Safety information**

DANGER

Contact with live components can lead to an electric shock. There is a risk of injuries or danger to life. Do not touch any components that are under voltage.

To prevent personal injury or damage to both vehicles, adhere strictly to the following procedure.

#### **Preparation**

**∧** NOTE


In the case of body contact between the two vehicles, a short circuit can occur during jump-starting. There is a risk of property damage. Make sure that no body contact occurs.

- Check whether the battery of the other vehicle has a voltage of 12 volts. The voltage information can be found on the battery.
- Switch off the engine of the assisting vehicle.
- Switch off any electronic systems/power consumers in both vehicles.

## Starting aid terminals

WARNING

If the jumper cables are connected in the incorrect order, sparking may occur. There is a risk of injury. Pay attention to the correct order during connection.



The starting aid terminal in the engine compartment acts as the battery's positive terminal



The body ground or a special nut acts as the battery negative terminal.

## **Connecting the cables**

- Pull off the lid of the BMW starting aid terminal.
- Attach one terminal clamp of the positive jumper cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle providing assistance.
- Attach the terminal clamp on the other end of the cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle to be started.
- Attach one terminal clamp of the negative jumper cable to the negative terminal of the battery, or to the corresponding engine or body ground of assisting vehicle.
- 5. Attach the second terminal clamp to the negative terminal of the battery, or to the

corresponding engine or body ground of the vehicle to be started.

#### Starting the engine

Never use spray fluids to start the engine.

- Start the engine of the assisting vehicle and let it run for several minutes at an increased idle speed.
  - If the vehicle to be started has a diesel engine: let the engine of the assisting vehicle run for approx. 10 minutes.
- 2. Start the engine of the vehicle that is to be started in the usual way.
  - If the first starting attempt is not successful, wait a few minutes before making another attempt in order to allow the discharged battery to recharge.
- 3. Let both engines run for several minutes.
- Disconnect the jumper cables in the reverse order.

Check the battery and recharge, if needed.

## **Tow-starting and towing**

# Safety information WARNING

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated, e.g., approach control warning with light braking function. There is a risk of an accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

## Steptronic transmission: transporting the vehicle

#### **General information**

The vehicle is not permitted to be towed.


#### **Safety information**

A

#### NOTE

The vehicle can be damaged when towing the vehicle with a single lifted axle. There is a risk of property damage. The vehicle should only be transported on a loading platform. ◀

#### **Tow truck**



The vehicle should only be transported on a loading platform.

#### NOTE

When lifting the vehicle by the tow fitting or body and chassis parts; damage can occur on vehicle parts. There is a risk of property damage. Lift vehicle using suitable means.

Use tow fitting located in the front only for positioning the vehicle.

## Pushing the vehicle

To remove a disabled vehicle from the danger area, it can be pushed for a short distance. The vehicle can only be pushed in selector lever position N.

In order to ensure that the vehicle can roll, proceed as follows:

- 1. Switch on the ignition.
- 2. Depress brake pedal.
- Engage selector lever position N.

If there is a malfunction, it may happen that you cannot change the selector lever position.

Electronically unlock the transmission lock, refer to page 85, if needed.

#### **Manual transmission**

#### Observe before towing your vehicle

Gearshift lever in neutral position.

#### **Towing**


**↑** NOTE

If manual unlocking of the parking brake is not possible, the vehicle cannot be moved or towed. There is a risk of property damage. The vehicle should only be transported on a loading platform. ◀

Information the following instructions:

- Make sure that the ignition is switched on; otherwise, the low beams, tail lamps, turn signals, and wipers may be unavailable.
- Do not tow the vehicle with the rear axle tilted, as the front wheels could turn.
- When the engine is stopped, there is no power assist. Consequently, more force needs to be applied when braking and steering.
- Larger steering wheel movements are required.
- The towing vehicle must not be lighter than the vehicle being towed; otherwise, it will not be possible to control the vehicle's response.
- Do not exceed a towing speed of 30 mph/50 km/h.
- Do not exceed a towing distance of 30 miles/50 km.

#### Tow truck



Have your vehicle transported with a tow truck with a so-called lift bar or on a flat bed.

NOTE

When lifting the vehicle by the tow fitting or body and chassis parts; damage can occur on vehicle parts. There is a risk of property damage. Lift vehicle using suitable means.

#### **Towing other vehicles**

#### **General information**

Switch on the hazard warning system, depending on local regulations.

If the electrical system has failed, clearly identify the vehicle being towed by placing a sign or a warning triangle in the rear window.

## **Safety information**

WARNING

If the approved gross vehicle weight of the towing vehicle is lighter than the vehicle to be towed, the tow fitting can tear off or it will not be possible to control the vehicle's response. There is a risk of an accident! Make sure that the gross vehicle weight of the towing vehicle is heavier than the vehicle to be towed.

NOTE

If the tow bar or tow rope is attached incorrectly, damage to other vehicle parts can occur. There is a risk of property damage. Correctly attach the tow bar or tow rope to the tow fitting.◀

#### Tow bar

The tow fittings used should be on the same side on both vehicles.

Should it prove impossible to avoid mounting the tow bar at an offset angle, please observe the following:

- Maneuvering capability is limited going around corners.
- The tow bar will generate lateral forces if it is secured with an offset.

#### Tow rope

When starting to tow the vehicle, make sure that the tow rope is taut.

To avoid jerking and the associated stresses on the vehicle components when towing, always use nylon ropes or nylon straps.

#### **Tow fitting**

#### **General information**



The screw-in tow fitting should always be carried in the vehicle.

The tow fitting can be screwed in at the front or rear of the vehicle.

The tow fitting and the onboard vehicle tool kit. refer to page 252, are together in the cargo area.

Use of the tow fitting:

- Use only the tow fitting provided with the vehicle and screw it all the way in.
- Use the tow fitting for towing on paved roads only.
- Use tow fitting located in the front only for positioning the vehicle.
- Avoid lateral loading of the tow fitting, e.g., do not lift the vehicle by the tow fitting.

#### Safety information

NOTE

If the tow fitting is not used as intended, there can be damage to the vehicle or to the tow fitting. There is a risk of property damage. Observe the notes on using the tow fitting. ◀

#### Screw thread for tow fitting



Push out the cover by pressing on the top edge.

## Tow-starting

## Steptronic transmission

Do not tow-start the vehicle.

Tow-starting the engine is not possible due to the transmission.

Have the cause of the starting problems fixed.

#### Manual transmission

If possible, do not tow-start the vehicle but start the engine by jump-starting, refer to page 261. If the vehicle is equipped with a catalytic converter, only tow-start while the engine is cold.

- 1. Switch on the hazard warning system and comply with local regulations.
- 2. Ignition, refer to page 70, on.
- 3. Engage third gear.
- 4. Have the vehicle tow-started with the clutch pedal pressed and slowly release the pedal. After the engine starts, immediately press on the clutch pedal again.
- Stop at a suitable location, remove the tow bar or rope, and switch off the hazard warning system.
- 6. Have the vehicle checked.

## Care

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## Vehicle washes

#### **General information**

Regularly remove foreign objects such as leaves in the area below the windshield when the hood is raised.

Wash your vehicle frequently, particularly in winter. Intense soiling and road salt can damage the vehicle.

## Steam blaster and high-pressure washer

## **Safety information**

NOTE

When cleaning with high-pressure washers, components can be damaged due to the pressure or temperatures being too high. There is a risk of property damage. Maintain sufficient distance and do not spray too long continuously. Follow the operating instructions for the high-pressure washer.

## **Distances and temperature**

- Maximum temperature: 140 °F/60 °C.
- Minimum distance from sensors, cameras, seals: 12 inches/30 cm.

 Minimum distance from glass sunroof: 31.5 in/80 cm.

#### Automatic vehicle washes

## **Safety information**

**∧** NOTE

Improper use of automatic vehicle washes can cause damage to the vehicle.

There is a risk of property damage. Information the following instructions:

- Give preference to cloth vehicle washes or those that use soft brushes in order to avoid paint damage.
- Avoid vehicle washes with guide rails higher than 4 in/10 cm to avoid damage to the chassis.
- Observe the tire width of the guide rail to avoid damage to tires and rims.
- Fold in exterior mirrors to avoid damage to the exterior mirrors.
- Deactivate rain sensor, if necessary, to avoid damage to the wiper system. ◄

## Before driving into a vehicle wash

In order to ensure that the vehicle can roll in a vehicle wash, take the following steps:

Manual transmission:

- 1. Drive into the vehicle wash.
- 2. Shift to neutral.
- Switch the engine off.
- 4. Switch on the ignition.

Steptronic transmission:

- 1. Drive into the vehicle wash.
- 2. Engage selector lever position N.
- 3. Deactivating Automatic Hold, refer to page 76.

- 4. Release the parking brake.
- 5. Switch the engine off.

In this way, the ignition remains switched on, and a Check-Control message is displayed.

## NOTE

Selector lever position P is automatically engaged when the ignition is switched off. There is a risk of property damage. Do not switch drive-ready state off in vehicle washes.

In some vehicle washes, you are required to leave the vehicle. The vehicle cannot be locked from the outside when in selector lever position N. A signal sounds when an attempt is made to lock the vehicle.

#### Driving out of a vehicle wash

To start the engine with manual transmission:

- Ensure that the vehicle key is in the car.
- 2. Press on the clutch pedal.
- Press the Start/Stop button.

To start the engine with Steptronic transmission:

- 1. Ensure that the vehicle key is in the car.
- 2. Depress the brake pedal.
- 3. Press the Start/Stop button.

Pressing the Start/Stop button without stepping on the brake turns the ignition off.

#### Selector lever position

Selector lever position P is engaged automatically:

- When the ignition is switched off.
- After approx. 15 minutes.

## **Headlamps**

 Do not rub dry and do not use abrasive or acidic cleansers.

- Soak areas that have been dirtied, e.g., from insects, with shampoo and wash off with water.
- Thaw ice with de-icing spray; do not use an ice scraper.

### After washing the vehicle

After washing the vehicle, apply the brakes briefly to dry them; otherwise, braking action can be reduced. The heat generated during braking dries brake discs and brake pads and protects them against corrosion.

Completely remove all residues on the windows, to minimize loss of visibility due to smearing and to reduce wiper noises and wiper blade wear.

## Vehicle care

### Vehicle care products

#### **General information**

BMW recommends using vehicle care and cleaning products from BMW.

## **Safety information**

WARNING

Cleansers can contain substances that are dangerous and harmful to your health. There is a risk of injury. When cleaning the interior, open the doors or windows. Only use products intended for cleaning vehicles. Follow the instructions on the container. ◀

#### Vehicle paint

Regular care contributes to driving safety and value retention. Environmental influences in areas with elevated air pollution or natural contaminants, such as tree resin or pollen can affect the vehicle's paintwork. Tailor the frequency and extent of your vehicle care to these influences

Aggressive substances such as spilled fuel, oil, grease or bird droppings, must be removed immediately to prevent the finish from being altered or discolored.

#### **Matte finish**

Only use cleaning and care products suitable for vehicles with matte finish. These are available from a dealer's service center or another qualified service center or repair shop.

#### Leather care

Remove dust from the leather often, using a cloth or vacuum cleaner.

Otherwise, particles of dust and road grime chafe in pores and folds, and lead to increased wear and premature degradation of the leather surface.

To guard against discoloration, such as from clothing, clean leather and provide leather care roughly every two months.

Clean light-colored leather more frequently because soiling on such surfaces is substantially more visible.

Use leather care products; otherwise, dirt and grease will gradually break down the protective layer of the leather surface.

Suitable care products are available from a dealer's service center or another qualified service center or repair shop.

## **Upholstery material care**

#### **General information**

Vacuum regularly with a vacuum cleaner.

If upholstery is very dirty, e.g., with beverage stains, use a soft sponge or microfiber cloth with a suitable interior cleaner.

Clean the upholstery down to the seams using large sweeping motions. Avoid rubbing the material vigorously.

### **Safety information**

lack

#### NOTE

Open Velcro® fasteners on articles of clothing can damage the seat covers. There is a risk of property damage. Ensure that any Velcro® fasteners are closed.

#### **Caring for special components**

#### **Light-alloy wheels**

When cleaning the vehicle, use only neutral wheel cleaners having a pH value from 5 to 9. Do not use abrasive cleaning agents or steam jets above 140 °F/60 °C. Follow the manufacturer's instructions.

Aggressive, acidic or alkaline cleaning agents can destroy the protective layer of adjacent components, such as the brake disk.

After cleaning, apply the brakes briefly to dry them. The heat generated during braking dries brake discs and brake pads and protects them against corrosion.

#### Chrome surfaces

Carefully clean components such as the radiator grille or door handles with an ample supply of water, possibly with shampoo added, particularly when they have been exposed to road salt.

## **Rubber components**

Environmental influences can cause surface soiling of rubber parts and a loss of gloss. Use only water and suitable cleaning agents for cleaning. The manufacturer of your vehicle recommends original BMW care products.

Treat especially worn rubber parts with rubber care agents at regular intervals. When cleaning rubber seals, do not use any silicon-containing vehicle care products in order to avoid damage or noises.

### Fine wood parts

Clean fine wood facing and fine wood components only with a moist rag. Then dry with a soft cloth.

#### **Plastic components**

**№** NOTE

Cleansers that contain alcohol or solvents, such as lacquer thinners, heavy-duty grease removers, fuel, or such, can damage plastic parts. There is a risk of property damage. Clean with a microfiber cloth. Dampen cloth lightly with water.

Plastic components are e.g.:

- Imitation leather surfaces.
- Roofliner.
- ▶ Lamp lenses.
- Instrument cluster cover.
- Matt black spray-coated components.
- Painted parts in the interior.

Clean with a microfiber cloth.

Dampen cloth lightly with water.

Do not soak the roofliner.

## Safety belts

WARNING

Chemical cleansers can destroy the safety belt webbing. Missing protective effect of the safety belts. There is a risk of injuries or danger to life. Use only a mild soapy solution for cleaning the safety belts. ◄

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

Use only a mild soapy solution, with the safety belts clipped into their buckles.

Do not allow the switchs to retract the safety belts until they are dry.

#### **Carpets and floor mats**

**★** WARNING

Objects in the driver's floor area can limit the pedal distance or block a depressed pedal. There is a risk of an accident. Stow objects in the vehicle such that they are secured and cannot enter into the driver's floor area. Use floor mats that are suitable for the vehicle and can be safely attached to the floor. Do not use loose floor mats and do not layer several floor mats. Make sure that there is sufficient clearance for the pedals. Ensure that the floor mats are securely fastened again after they were removed, e.g., for cleaning.

Floor mats can be removed from the vehicle's interior for cleaning.

If the floor carpets are very dirty, clean with a microfiber cloth and water or a textile cleaner. To prevent matting of the carpet, rub back and forth in the direction of travel only.

#### Sensor/camera lenses

To clean sensors and camera lenses, use a cloth moistened with a small amount of glass detergent.

## Displays/Screens/protective glass of the Head-up Display

**№** NOTE

Chemical cleansers, moisture or fluids of any kind can damage the surface of displays and screens. There is a risk of property damage. Clean with a clean, antistatic microfiber cloth.

NOTE

The surface of displays can be damaged with improper cleaning. There is a risk of property damage. Avoid pressure that is too high and do not use any scratching materials.

Clean with a clean, antistatic microfiber cloth. Head-up Display:

Clean the protective glass of the Head-up Display using a microfiber cloth and commercially available dish-washing soap.

#### Long-term vehicle storage

When the vehicle is shut down for longer than three months, special measures must be taken. Further information is available from a dealer's service center or another qualified service center or repair shop.



## Reference

This chapter contains the technical data and an index that will quickly take you to the information you need.

## **Technical data**

## Vehicle features and options

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your vehicle, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable country provisions must be observed.

## **General information**

The technical data and specifications in this Owner's Manual are used as guidance values. The vehicle-specific data can deviate from this, e.g., due to the selected special equipment, country version or country-specific measurement method. Detailed values can be found in the approval documents, on labels on the vehi-

cle or can be obtained from a dealer's service center or another qualified service center or repair shop.

The information in the vehicle documents always has priority over the information in this Owner's Manual.

## **Dimensions**

The dimensions can vary depending on the model version, equipment or country-specific measurement method.

The specified heights do not take into account attached parts, e.g., a roof antenna, roof racks

or spoiler. The heights can deviate, e.g., due to the selected special equipment, tires, load and chassis version.

BMW 5 Series Sedan		
Width with mirrors	inches/mm	82.8/2,102
Width without mirrors	inches/mm	73.2/1,860
Height	inches/mm	57.6/1,464
Length	inches/mm	193.4/4,913
Wheelbase	inches/mm	116.9/2,968
Smallest turning radius diam.	ft/m	39.4-39.7/12.0-12.1

## Weights

528i			
Approved gross vehicle weight	lbs/kg	4,971/2,255	
Load	lbs/kg	937/425	
Approved front axle load	lbs/kg	2,359/1,070	
Approved rear axle load	lbs/kg	2,844/1,290	
Approved roof load capacity	lbs/kg	220/100	
Cargo area capacity	cu ft	18.4	
Canada: cargo area capacity	cu ft/l	18.3/520	
535i			
Approved gross vehicle weight	lbs/kg	5,181/2,350	
Load	lbs/kg	992/450	
Approved front axle load	lbs/kg	2,491/1,130	
Approved rear axle load	lbs/kg	2,910/1,320	
Approved roof load capacity	lbs/kg	220/100	
Cargo area capacity	cu ft	18.4	
Canada: cargo area capacity	cu ft/l	18.3/520	
550i			
Approved gross vehicle weight	lbs/kg	5,401/2,450	
Load	lbs/kg	922/418	
Approved front axle load	lbs/kg	2,712/1,230	
Approved rear axle load	lbs/kg	2,932/1,330	
Approved roof load capacity	lbs/kg	220/100	
Cargo area capacity	cu ft	18.4	
Canada: cargo area capacity	cu ft/l	18.3/520	

528i xDrive			
Approved gross vehicle weight	lbs/kg	5,170/2,345	
Load	lbs/kg	948/430	
Approved front axle load	lbs/kg	2,447/1,110	
Approved rear axle load	lbs/kg	2,888/1,310	
Approved roof load capacity	lbs/kg	220/100	
Cargo area capacity	cu ft	18.4	
Canada: cargo area capacity	cu ft/l	18.3/520	
535i xDrive			
Approved gross vehicle weight	lbs/kg	5,379/2,440	
Load	lbs/kg	992/450	
Approved front axle load	lbs/kg	2,701/1,225	
Approved rear axle load	lbs/kg	2,910/1,320	
Approved roof load capacity	lbs/kg	220/100	
Cargo area capacity	cu ft	18.4	
Canada: cargo area capacity	cu ft/l	18.3/520	
550i xDrive			
Approved gross vehicle weight	lbs/kg	5,600/2,540	
Load	lbs/kg	948/430	
Approved front axle load	lbs/kg	2,800/1,270	
Approved rear axle load	lbs/kg	2,954/1,340	
Approved roof load capacity	lbs/kg	220/100	
Cargo area capacity	cu ft	18.4	

Canada: cargo area capacity

18.3/520

cu ft/l

220/100

18.3/520

18.4

535d			
Approved gross vehicle weight	lbs/kg	5,300/2,404	
Load	lbs/kg	950/431	
Approved front axle load	lbs/kg	2,550/1,157	
Approved rear axle load	lbs/kg	2,910/1,320	
Approved roof load capacity	lbs/kg	220/100	
Cargo area capacity	cu ft	18.4	
Canada: cargo area capacity	cu ft/l	18.3/520	
535d xDrive			
Approved gross vehicle weight	lbs/kg	5,390/2,445	
Load	lbs/kg	880/399	
Approved front axle load	lbs/kg	2,700/1,225	
Approved rear axle load	lbs/kg	2,910/1,320	

## **Capacities**

Approved roof load capacity

Canada: cargo area capacity

Cargo area capacity

	US gal/liters	Notes
Fuel tank, approx.	18.4/70.0	Fuel quality, refer to page 214

lbs/kg

cu ft

cu ft/l

## **Appendix**

Any updates to the Owner's Manual of the vehicle are listed here.

## Updates made after the editorial deadline

These chapters of the printed Owner's Manual contain updates made after the editorial deadline.

 Airbags: protective effect: information on the optimum protective effect of the airbags, refer to page 114.

## **Everything from A to Z**

#### Index

## A

ABS, Antilock Brake System 141 ACC, Active Cruise Control with Stop&Go function 149 Acceleration Assistant, see Launch Control 86 Accessories and parts 8 Activated-charcoal filter 174 Active Blind Spot Detection 136 Active Cruise Control with Stop&Go function, ACC 149 Active Protection 138 Active seat, front 56 Active seat ventilation, front 57 Active Steering, integral 145 Adaptive brake assistant 141 Adaptive brake lights, see Brake force display 138 Adaptive drive 144 Adaptive Light Control 109 Additives, oil 246 Adjustments, seats/head restraints 53 After washing vehicle 267 Airbags 113 Airbags, indicator/warning light 114 Air circulation, see Recirculated-air mode 173 Air, dehumidifying, see Cooling function 172 Air distribution, manual 173 Air flow, automatic climate control 173 Air outlets, see Ventilation 174

Air pressure, tires 219 Alarm system 47 Alarm, unintentional 48 All around the roofliner 17 All-season tires, see Winter tires 232 All-wheel-drive 143 Alternative oil types 246 Ambient light 111 Animal detection, see Night Vision 131 Antifreeze, washer fluid 81 Antilock Brake System, **ABS 141** Anti-slip control, see **DSC 141** Anti-theft protection, vehicle 35 App, BMW Driver's Guide 6 Approach control warning with City light braking function 123 Approved axle load 275 Armrest, see Center armrest 189 Arrival time 101 Ashtray 180 Ashtray, front 180, 181 Assistance, Roadside Assistance 260 Assistance when driving off 141 Attentiveness assistant 138 AUTO H button 76 AUTO H button, see Automatic Hold 76 **AUTO intensity 173** Automatic climate control 171 Automatic cruise control with Stop&Go function 149

Automatic Curb Monitor 63 Automatic deactivation. Front-seat passenger airbags 115 Automatic headlamp control 108 Automatic Hold 76 Automatic locking 47 Automatic recirculated-air control 173 Automatic tailgate 42 Automatic transmission, see Steptronic transmission 82 Automatic vehicle wash 266 AUTO program, automatic climate control 172 AUTO program, intensity 173 Auto Start/Stop function 72 Auto washing 266 AUX-IN port, general information 183 Average fuel consumption 101 Average speed 101 Axle loads, weights 275

## B

Backrest curvature, see Lumbar support 55
Backrest, width 56
Band-aids, see First-aid kit 260
Battery replacement, vehicle battery 257
Battery replacement, vehicle remote control 36
Battery, vehicle 257
Being towed, see Tow-starting and towing 262
Belts, safety belts 57

#### C

California Proposition 65 Warning 8 Calling up mirror adjustment 47 Calling up seat adjustment 47 Calling up steering wheel adiustment 47 Camera-based assistance systems, see Intelligent Safety 122 Camera lenses, care 269 Camera, rearview camera 161 Camera, Side View 164 Camera, Top View 165 Can holder, see Cup holder 190 Care, displays 269 Care, vehicle 267 Care, washing the vehicle 266 Cargo 200 Cargo area, enlarging 184 Cargo area, loading 201 Cargo area, storage compartments 191 Cargo, stowing and securing 201 Cargo straps 201 Carpet, care 269 Catalytic converter, see Hot exhaust system 197 CBS Condition Based Service 250 CD/multimedia, see Owner's Manual for Navigation, Entertainment and Communication Center armrest 189 Center console 16 Central locking system 38 Central screen, see Control Display 18

Changes, technical, see Own Safety 7 Changing parts 252 Changing wheels 237 Changing wheels/tires 231 Chassis number, see Vehicle identification number 10 Check Control 91 Checking the engine oil level electronically 244 Checking the oil level electronically 244 Children, seating position 66 Children, transporting safely 66 Child restraint fixing system LATCH 68 Child restraint system 66 Child restraint systems, mounting 67 Child safety locks 69 Child seat, mounting 67 Child seats 66 Chrome parts, care 268 Cigarette lighter 180 City light braking function warning with braking function 126 Cleaning, displays 269 Climate control 171 Climate control laminated tinted safety glass 197 Climate control windshield 197 Closing the tailgate with notouch activation 40 Clothes hooks 191 Coasting 207 Coasting with engine decoupled, coasting 207 Coasting with idling engine 207 Cold starting, refer to Starting the engine 71 Combination switch, see Turn

signals 78

Combination switch, see
Wiper system 78
COMFORT+ program, Driving
Dynamics Control 147
Comfort Access 39
COMFORT program, Driving
Dynamics Control 147
Compressor 233
Condensation on win-
dows 174
Condensation under the vehi-
cle 199
Condition Based Service
CBS 250
Configure driving mode 147
Confirmation signal 46
ConnectedDrive, see Owner's
Manual for Navigation, En-
tertainment and Communi-
cation
ConnectedDrive Services
Container for washer fluid 81
Continued driving with a flat
tire 118, 121
Control Display 18
Control Display, settings 103
Controller 19
Control systems, driving sta-
bility 141
Convenient opening with the
remote control 35
Coolant 248
Coolant level 248
Coolant temperature 95
Cooling function 172
Cooling, maximum 172
Cooling system 248
Cornering light 109
Corrosion on brake discs 199
Cosmetic mirror 180
Courtesy lamps during un-
locking 35
Courtesy lamps with the vehi-
cle locked 35
Cruise control 155

Cruise control, active with Stop&Go function 149 Cruise control with distance control, see active cruise control, ACC 149 Cruise control without distance control, see cruise control 155 Cruising range 96 Cup holder 190 Current fuel consumption 96

#### D

Damage, tires 230 Damping control, dynamic 144 Data, technical 274 Date 103 Date display 96 Daytime running lights 109 Defrosting, see Windows, defrostina 174 Dehumidifying, air 172 Deleting personal data 24 Deletion of personal data 24 Destination distance 101 Diesel exhaust fluid, at low temperatures 216 Diesel exhaust fluid, having refilled 216 Diesel exhaust fluid, on minimum 216 Diesel exhaust fluid, replenishing yourself 216 Diesel fuel 215 Diesel particulate filter 197 Digital clock 96 Dimensions 274 Dimmable exterior mirrors 63 Dimmable interior mirror 64 Direction indicator, see Turn signals 78 Display, electronic, instrument cluster 87

Display lighting, see Instrument lighting 111 Displays 88 Displays, care 269 Disposal, coolant 249 Disposal, vehicle battery 258 Distance control, see **PDC 158** Distance to destination 101 Divided screen view, split screen 23 Door key, see Remote con-Downhill control 143 Drive mode 146 Drive-off assistant 141 Drive-off assistant, see **DSC 141** Driver assistance, see Intelligent Safety 122 Driving Assistant, see Intelligent Safety 122 Driving Dynamics Control 146 Driving instructions, breakin 196 Driving instructions, ECO **PRO 206** Driving notes, general 197 Driving on racetracks 199 Driving stability control systems 141 Driving tips 197 DSC Dynamic Stability Control 141 DTC Dynamic Traction Control 142 Dynamic Damping Control 144 Dynamic Drive 144 Dynamic Stability Control **DSC 141 Dynamic Traction Control DTC 142** 

Display in windshield 104

## F

ECO PRO 204 ECO PRO, bonus range 206 ECO PRO display 204 ECO PRO displays 89 ECO PRO driving mode 204 ECO PRO mode 204 ECO PRO tips 206 Efficiency display, ECO PRO 206 EfficientDynamics info 207 Electronic displays, instrument cluster 87 Electronic oil measurement 244 **Electronic Stability Program** ESP, see DSC 141 Emergency release, fuel filler flap 213 **Emergency Request 259** Emergency service, see Roadside Assistance 260 Emergency unlocking, tailgate 44 Emergency unlocking, transmission lock 85 **Energy Control 96** Energy recovery 97 Engine, automatic Start/Stop function 72 Engine, automatic switchoff 72 Engine compartment 241 Engine compartment, working in 241 Engine coolant 248 Engine idling when driving, coasting 207 Engine oil 244 Engine oil, adding 245 Engine oil additives 246 Engine oil change 247 Engine oil filler neck 245 Engine oil temperature 95

Engine oil types, alternative 246 Engine oil types, suitable 246 Engine start, jump-startina 261 Engine start, see Starting the engine 71 Engine stop 72 Engine temperature 95 Entering a vehicle wash 266 Equipment, interior 178 Error displays, see Check Control 91 ESP Electronic Stability Program, see DSC 141 Exchanging wheels/tires 231 Exhaust system 197 Exiting a vehicle wash 266 Exterior mirror, automatic dimming feature 63 Exterior mirrors 62 External start 261 External temperature display 96 External temperature warning 96 Eyes for securing cargo 201

## F

Control 91 False alarm, see Unintentional alarm 48 Fan, see Air flow 173 Filler neck for engine oil 245 Fine wood, care 269 First-aid kit 260 Flat tire, changing wheels 237 Flat Tire Monitor FTM 120 Flat tire, repairing 232 Flat tire, Tire Pressure Monitor TPM 116 Flat tire, warning lamp 117, 120

Failure message, see Check

Flooding 198 Floor carpet, care 269 Floor mats, care 269 Fold-away position, wiper 80 Fold down the rear seat backrest, see Though-loading system 184 Foot brake 198 Front airbags 113 Front fog lamps, , LED, bulb replacement 255 Front fog lights 110 Front lights 254 Front-seat passenger airbags, automatic deactivation 115 Front-seat passenger airbags, indicator lamp 115 FTM Flat Tire Monitor 120 Fuel 214 Fuel cap 212 Fuel consumption, see Average fuel consumption 101 Fuel filler flap 212 Fuel gauge 95 Fuel quality 214 Fuel recommendation 214 Fuel, tank capacity 277 Functions and controls in the center console 16 Functions and controls in the cockpit 14 Fuse 258

## G

Garage door opener, see Universal Integrated Remote Control 178 Gasoline 214 Gear change, Steptronic transmission 83 Gear shift indicator 98 General driving notes 197 Glare shield 180 Glass sunroof, electric 50

Glass sunroof, initialize the
system 52
Glove compartment 188
GPS location, vehicle posi-
tion 104
Gross vehicle weight, ap-
proved 275

Handbrake, see Parking

## Н

brake 74 Hand-held transmitter, alternating code 179 Hazard warning flashers 259 HDC Hill Descent Control 143 Head airbags 113 Headlamp control, automatic 108 Headlamp courtesy delay feature 108 Headlamp courtesy delay feature via remote control 36 Headlamps, care 267 Headlight flasher 78 Headlight glass 253 Headlights 254 Head restraints 53 Head restraints, front 59 Head restraints, rear 60 Head-up Display 104 Head-up Display, care 269 Heavy cargo, stowing cargo 201 Height, vehicle 274 High-beam Assistant 110 High beams 78 High beams/low beams, see High-beam Assistant 110 Hill Descent Control **HDC 143** Hills 198 Hill start assistant, see Driveoff assistant 141 Holder for beverages 190

Homepage 6 Hood 241 Horn 14 Hotel function, tailgate 44 Hot exhaust system 197 HUD Head-up Display 104 Hydroplaning 197

Ice warning, see External temperature warning 96 Icy roads, see External temperature warning 96 Identification marks, tires 228 Identification number, see Vehicle identification number 10 iDrive 18 Ignition key, see Remote control 37 Ignition off 70 Ignition on 70 Indication of a flat tire 117, 120 Indicator and alarm lamps, see Check Control 91 Indicator lamp, see Check Control 91 Individual air distribution 173 Individual settings, see Personal Profile 44 Inflation pressure, tires 219 Inflation pressure warning FTM, tires 120 Info display, see On-Board computer 100 Information 6 Initialization, Integral Active Steering 145 Initialize, Tire Pressure Monitor TPM 117 Initializing, Flat Tire Monitor FTM 120 Instrument cluster 87

Instrument cluster, electronic displays 87 Instrument display, multifunctional 88 Instrument lighting 111 Integral Active Steering 145 Integrated key 37 Integrated Owner's Manual in the vehicle 29 Intelligent emergency call 259 Intelligent Safety 122 Intended use 7 Intensity, AUTO program 173 Interior equipment 178 Interior lights 111 Interior lights during unlockina 35 Interior lights with the vehicle locked 35 Interior mirror, automatic dimming feature 64 Interior mirror, manually dimmable 64 Interior motion sensor 48 Internet page 6 Interval display, service requirements 97 Interval mode 79

## J

Jacking points for the vehicle jack 238 Joystick, Steptronic transmission 83 Jump-starting 261

## K

Key/remote control 37 Keyless Go, see Comfort Access 39 Key Memory, see Personal Profile 44 Key, see Remote control 34 Kickdown, Steptronic transmission 83 Knee airbag 114

#### L

Label on recommended tires 231 Lamp in the exterior mirror, see Active Blind Spot Detection 136 Lamp replacement 252 Lamp replacement, front 254 Lamp replacement, rear 256 Lane departure warning 134 Lane threshold, warning 134 Language on Control Display 103 Lashing eyes 201 LATCH child restraint fixing system 68 Launch Control 86 Leather, care 268 LED headlights, bulb replacement 255 LED light 255 LEDs, light-emitting diodes 253 Length, vehicle 274 Letters and numbers, entering 24 License plate lamp, bulb replacement 256 Light 107 Light-alloy wheels, care 268 Light control 109 Light-emitting diodes, **LEDs 253** Lighter, front 180, 181 Lighter, rear 182 Lighting 107 Lighting, speaker 111 Lights and bulbs 252 Light switch 107

Load 201

Loading 200
Locking, automatic 47
Locking, settings 46
Locking via tailgate 42
Low beams 107
Low beams, automatic, see
High-beam Assistant 110
Lower back support 55
Low-Sulfur Diesel 215
Luggage rack, see Roofmounted luggage rack 201
Lumbar support 55

#### M

Maintenance 250 Maintenance requirements 250 Maintenance, service requirements 97 Maintenance system, **BMW 250** Make-up mirror 180 Malfunction displays, see Check Control 91 Manual air distribution 173 Manual air flow 173 Manual brake, see Parking brake 74 Manual mode, Steptronic transmission 84 Manual operation, exterior mirrors 63 Manual operation, fuel filler flap 213 Manual operation, Park Distance Control PDC 159 Manual operation, rearview camera 161 Manual operation, Side View 164 Manual operation, Top **View 165** Manual transmission 82 Marking, run-flat tires 232

Massage seat, see Active seat 56 Master key, see Remote control 37 Maximum cooling 172 Maximum speed, display 98 Maximum speed, winter tires 232 Measurement, units of 104 Medical kit 260 Memory for seat, mirrors, steering wheel 61 Menu in instrument cluster 100 Menus, operating, iDrive 18 Menus, see iDrive operating concept 19 Messages, see Check Control 91 Microfilter 174 Minimum tread, tires 230 Mirror 62 Mirror memory 61 Mobile communication devices in the vehicle 197 Mobility System 233 Modifications, technical, see Own Safety 7 Moisture in headlight 253 Monitor, see Control Display 18 Mounting of child restraint systems 67 Multifunctional instrument display 88 Multifunction steering wheel,

## N

buttons 14

Navigation, see Owner's Manual for Navigation, Entertainment and Communication Neck restraints, front, see

Head restraints 59

Neck restraints, rear, see Head restraints 60 Neutral cleaner, see Wheel cleaner 268 New wheels and tires 231 Night Vision 131 Night Vision device, see Night Vision 131

## O

OBD Onboard Diagnosis 251 OBD, see OBD Onboard Diagnosis 251 Object detection, see Night Vision 131 Obstacle marking, rearview camera 162 Octane rating, see Recommended fuel grade 215 Odometer 95 Office, see Owner's Manual for Navigation, Entertainment and Communication Oil 244 Oil, adding 245 Oil additives 246 Oil change 247 Oil change interval, service requirements 97 Oil filler neck 245 Oil types, alternative 246 Oil types, suitable 246 Old batteries, disposal 258 Onboard computer 100 Onboard computer, see Onboard computer 100 Onboard monitor, see Control Display 18 Onboard vehicle tool kit 252 Opening and closing 34 Opening the tailgate with noOutside air, see Automatic recirculated-air control 173 Overheating of engine, see Coolant temperature 95 Own Safety 7

#### P

Paint, vehicle 267 Parallel parking assistant 166 Park Distance Control PDC 158 Parked vehicle, condensation 199 Parked-vehicle ventilation 177 Parking aid, see PDC 158 Parking assistant 166 Parking brake 74 Parking lights 107 Parking with Automatic Hold 76 Particulate filter 197 Parts and accessories 8 Passenger side mirror, tilting downward 63 Pathway lines, rearview camera 162 PDC Park Distance Control 158 Pedestrian detection, see Night Vision 131 Pedestrian warning with Approach control 129 Personal Profile 44 Personal Profile, exporting profiles 45 Pinch protection system, glass sunroof 51 Pinch protection system, windows 49 Plastic, care 269 PostCrash 140 Power failure 258 Power sunroof, glass 50 Power windows 48

Prescribed engine oil types 246 Pressure, tire air pressure 219 Pressure warning FTM, tires 120 Profile, see Personal Profile 44 Programmable memory buttons, iDrive 23 Protective function, glass sunroof 51 Protective function, windows 49 Push-and-turn reel, refer to controller 19

## R

Racetrack operation 199 Radiator fluid 248 Radio-operated key, see Remote control 37 Radio-operated remote control, opening/closing 34 Radio ready state 70 Radio, see Owner's Manual for Navigation, Entertainment and Communication Rain sensor 79 Rapeseed-oil methyl ester RME 215 Ratchet straps 201 Rear automatic climate control 175 Rear axle steering 145 Rear lights 256 Rear socket 183 Rearview camera 160 Rearview mirror 62 Rear window defroster 174 Recirculated-air mode 173 Recommended fuel grade 215 Recommended tire brands 231

touch activation 40

Optional equipment 7

Operating concept, iDrive 18

Refueling 212	RSC Run Flat System Com-	Service requirements, Condi-
Remaining range 96	ponent, see Run-flat	tion Based Service
Remote control/key 37	tires 232	CBS 250
Remote control, malfunc-	Rubber components,	Service requirements, dis-
tion 37	care 268	play 97
Remote control, opening/ closing 34	Run-flat tires 232	Service, Roadside Assistance 260
Remote control, univer- sal 178	S	Services, ConnectedDrive SET button, see Active
Replacement fuse 258	Safe braking 198	Cruise Control, ACC 149
Replacing parts 252	Safety belt reminder for driv-	SET button, see Cruise con-
Replacing wheels/tires 231	er's seat and front passen-	trol 155
Reporting safety malfunc-	ger seat 58	Settings, locking/unlock-
tions 10	Safety belts 57	ing 46
RES button 152	Safety belts, care 269	Settings on Control Dis-
RES button, see Active	Safety locks, doors, and win-	play 103
Cruise Control, ACC 149	dows 69	Settings, storing for seat, mir-
RES button, see Cruise con-	Safety Package, see Active	rors, steering wheel 61
trol 155	Protection 138	Shift paddles on the steering
Reserve warning, see	Safety switch, windows 50	wheel 85
Range 96	Safety systems, airbags 113	Shift point indicator 90
Reset, Tire Pressure Monitor	Saving fuel 203	Shoulder support 56
TPM 117	Screen, see Control Dis-	Side airbags 113
Residual heat, automatic cli-	play 18	Side View 163
mate control 173	Screwdriver, see Onboard ve-	Signaling, horn 14
Retreaded tires 231	hicle tool kit 252	Signals when unlocking 46
Reversing lamp, bulb replace-	Sealant 233	Sitting safely 53
		Size 274
ment 256	Seat belts, see Safety	
RME rapeseed-oil methyl es- ter 215	belts 57	Ski bag 186
	Seat heating, front 56	Slide/tilt glass roof 50
Roadside parking lights 108	Seat heating, rear 57	Smallest turning radius 274
Roller sunblinds 50	Seating position for chil-	Smoker's package 180
Rolling code hand-held trans-	dren 66	SMS SMS text message,
mitter 179	Seat, mirror, and steering	supplementary 94
Roll stabilization, see Adap-	wheel memory 61	Snow chains 236
tive Drive 144	Seats 53	Socket 182
Roll stabilization, see Dy- namic Drive 144	Seat ventilation, front 57 Securing cargo 201	Socket, OBD Onboard Diag- nostics 251
RON recommended fuel	Selection list in instrument	Soot particulate filter 197
grade 215	cluster 100	SOS button 259
Roofliner 17	Selector lever, Steptronic	Spare fuse 258
Roof load capacity 275	transmission 83	Speaker lighting 111
Roof-mounted luggage	Sensors, care 269	Speed, average 101
rack 201	Service and warranty 8	Speed Limit Info 98
		Speed Limit Info, com-
		puter 101

Speed limits, display 98 Speed warning 102 Split screen 23 SPORT+ - program, Dynamic	Surround View 160 Suspension settings 146 Switch for Dynamic Driving Control 146	Thermal camera, see Night Vision 131 Thigh support 55 Through-loading system 184
Driving Control 146 Sport displays, torque display, performance display 102	Switch-on times, parked-car ventilation 177 Switch, see Cockpit 14 Symbols 6	Tilt alarm sensor 48 Time 103 Time of arrival 101 Tire damage 230
SPORT program, driving dy- namics 146	Symbols in the status field 22 SYNC program, automatic cli-	Tire identification marks 228 Tire inflation pressure 219
Sport program, transmission 84	mate control 173	Tire inflation pressure monitor, see FTM 120
Stability control systems 141 Standard equipment 7	Т	Tire Pressure Monitor TPM 116
Start/stop, automatic function 72	Tachometer 95 Tail and brake lights 256	Tire repair kit, see Mobility System 233
Start/Stop button 70	Tailgate, automatic 42	Tires, changing 231
Starting the engine 71	Tailgate closing 42	Tire sealant, see Mobility
Status control display,	Tailgate, closing with no-	System 233
tires 117	touch activation 40	Tires, everything on wheels
Status information, iDrive 22	Tailgate, emergency unlock-	and tires 219
Status of Owner's Manual 7	ing 44	Tires, run-flat tires 232
Steering, Integral Active	Tailgate, hotel function 44	Tire tread 230
Steering 145	Tailgate opening 42	Tone, see Owner's Manual for
Steering wheel, adjusting 64	Tailgate, opening with no-	Navigation, Entertainment
Steering wheel heating 65	touch activation 40	and Communication
Steering wheel memory 61	Tailgate via remote con-	Tool 252
Steptronic Sport transmis-	trol 35	Top View 164
sion, see Steptronic trans-	Tail lamps 256	Total vehicle weight 275
mission 82	Tail lamps, bulb replace-	Touchpad 21
Steptronic transmission 82	ment 256	Towing 262
Stopping the engine 72	Technical changes, see Own	Tow-starting 262
Storage compartment, re-	Safety 7	TPM Tire Pressure Moni-
mote control 191	Technical data 274	tor 116
Storage compartments 188	Telephone, see Owner's	Traction control 142
Storage compartments, locations 188	Manual for Navigation, En- tertainment and Communi-	TRACTION, driving dynamics 142
Storage, tires 232	cation	Transmission lock, electronic
Storing the vehicle 270	Temperature, automatic cli-	unlocking 85
Stowing and securing	mate control 172	Transmission, manual trans-
cargo 201	Temperature display for ex-	mission 82
Suitable engine oil types 246	ternal temperature 96	Transmission, see Steptronic
Summer tires, tread 230	Temperature, engine oil 95	transmission 82
Sun visor 180	Terminal, starting aid 261	Transporting children
Supplementary SMS SMS	Theft alarm system, see	safely 66
text message 94	Alarm system 47	Tread, tires 230

Triple turn signal activation 78
Trip odometer 95
Trip onboard computer 101
Trip recorder, see Trip odometer 95
Turning circle 274
Turning radius lines, rearview camera 162
Turn signals, operation 78
Turn signals, rear, bulb replacement 256

#### U

Unintentional alarm 48
Units of measurement 104
Universal remote control 178
Unlock button, Steptronic
transmission 83
Unlocking, settings 46
Updates made after the editorial deadline 7
Upholstery care 268
USB interface, general information 183
USB port, see USB interface 183
Use, intended 7

## V

Vanity mirror 180
Variable steering, Integral Active Steering 145
Vehicle battery 257
Vehicle battery, replacing 257
Vehicle, break-in 196
Vehicle care 267
Vehicle care products 267
Vehicle features and options 7
Vehicle identification number 10
Vehicle jack 238

Vehicle key, see Remote control 37 Vehicle paint 267 Vehicle position, GPS location 104 Vehicle storage 270 Vehicle wash 266 Vehicle, washing 266 Ventilation 174 Ventilation, see Parked-vehicle ventilation 177 Venting, see Ventilation 174 Vent. see Ventilation 174 VIN. see Vehicle identification number 10 Voice activation system 26

Warning and indicator lamps,

## W

see Check Control 91 Warning displays, see Check Control 91 Warning lamp in the exterior mirror, see Active Blind Spot Detection 136 Warning messages, see Check Control 91 Warning triangle 260 Warranty 7 Washer fluid 81 Washer nozzles, windshield 80 Washer system 78 Washing the vehicle 266 Water on roads 198 Weights 275 Welcome lights 108 Welcome lights during unlocking 35 Wheel base, vehicle 274 Wheel cleaner 268 Wheels, changing 231 Wheels, everything on wheels and tires 219

Wheels, Flat Tire Monitor FTM 120 Wheels, Tire Pressure Monitor TPM 116 Width, vehicle 274 Window defroster, rear 174 Windows, powered 48 Windshield, climate control 197 Windshield washer fluid 81 Windshield washer nozzles 80 Windshield washer system 78 Windshield washer system, see washer/wiper system 78 Windshield wiper 78 Winter storage, care 270 Winter tires, suitable tires 232 Winter tires, tread 230 Wiper 78 Wiper blades, replacing 252 Wiper fluid 81 Wiper, fold-away position 80 Wiper system 78 Wood, care 269 Word match concept 25 Wrench, see Onboard vehicle tool kit 252



xDrive 143 Xenon headlights, bulb replacement 254

More about BMW



bmwusa.com

